# TM33 Pumper Carburetor Upgrade For The Yamaha XT225

# Installation Guide and Setup Instructions



TM33 Kit

Copyright 2004 ENDUCO, Inc.

# **Introduction:**

This manual describes the TM33 pumper carburetor and explains how to install it on the XT225 Yamaha motorcycle. Please read the information carefully to avoid problems with the installation.

The stock carburetor on the XT225 is a CV type. This means the carburetor's slide is not under direct control of the throttle cable but is, instead, operated by vacuum built up by a butterfly valve which is controlled directy by the throttle cables. Carburetors of this type will exhibit a small hesitation during acceleration due to the time required for the vacuum mechanism to move the throttle slide. Under certain circumstances this delay may be objectionable to some riders. The TM33 carburetor allows direct control over the throttle slide and includes an accelerator pump. This improves throttle response, provides more confident acceleration and makes the bike a little more snappy off the line. This comes at the expense of increased fuel consumption and emissions.

The TM33 carburetor may not meet current emission standards in some locations and therefore would be considered an illegal modification for a street bike. Before installing the TM33 make sure you understand the local emission laws in your riding area. Installing the TM33 kit does not require any permanent changes to the bike, should it be necessary to put the stock carburetor back on the bike this may be done easily.

It should be noted that the stock carburetor provides overall good performance. If you are cruising the bike and want to maintain maximum gas mileage the TM33 kit will most likely not be an enhancement. Although the stock carburetor may not deliver maximum power it does do a good job of maintaining generally good performance. It also includes a coaster enrichment system that allows a smooth "throttle up" after coasting the engine during down hill runs.

Since the TM33 carburetor includes an accelerator pump starting a cold bike is easier. A twist of the throttle primes the engine and eliminates repeated stalling and stumbles common with the stock carburetor.



Please read this manual carefully

Visit www.xt225.com for more information about the TM33 kit.

Kit	$\mathbf{C}_{\mathbf{A}}$	nto	nta.
	W		1115.

The TM33 kit contains the following items:

- ☐ 1 Mikuni TM33-8012 Pumper Carburetor\*
- ☐ 1 Aluminum Cable Spacer
- ☐ 4' 5/16" Drain & vent hose
- □ 1 16" piece of 3/16" drain hose
- ☐ 1 Instruction Manual (PDF file)
- □ 3 Nylon zip ties



DO NOT SMOKE AROUND GASOLINE

<sup>\*</sup> The TM33 carburetor supplied in this kit has been modified to include a custom cable bracket and a special jet needle.

# **Installing the TM33:**

#### Overview:

Although the TM33 carburetor's inlet and outlet flanges match those of the stock carburetor other dimensional and mechanical differences exist. The installation steps supplied in this manual account for this and explain how to make a neat and clean installation that's easily reversible should it be necessary to restore the bike to stock condition. Please read these instructions carefully, use common sense and good judgement during the installation process. Don't force parts or over tighten screws and bolts. Make sure to turn off the fuel petcock before beginning the installation. Spilled fuel presents a potential fire hazzard. Don't smoke around gasoline and have a fire extinguisher handy at all times. Do not perform this installation on a hot engine or near an open flame. Make sure to work in a well ventilated area at all times.

# TOOLS YOU WILL NEED

10 & 12 mm sockets and rachet handle Phillips head screw driver (medium bit size) 3 & 4 mm allen wrenches (hex key) WD40 spray lubricant or equivilent Bike tool kit Small adjustable wrench

#### STEP 1

Remove the left and right plastic side panels that are in the center of the bike. These panels are held in place by pins pressed into rubber grommets on the frame up near the seat and a single phillips head screw down at the bottom of each panel. On some bikes the phillips screw includes a plastic shoulder washer and retainer to keep the screw with the panel. Back out both of these phillips head screws and make sure the panels are loose at the bottom. Pull the panels out of their rubber grommets and remove them completely from the bike. The soft plastic may bend a little near the seat during the removal process.

#### STEP 2

Remove the left and right air scoop panels on either side of the gas tank. These panels are held in place by tabs on the gas tank, pins, grommets and a strap just in front of the engine's cylinder. A plastic pin with a rubber grommet on each panel engages a hole in the fuel tank flange. Pins may be pulled from their grommets by hand. Using a 10mm socket remove the bolt on the strap. Spray

# **STEP 2 (continued)**

with WD40 if required. If the bolt is stubborn, hold the strap with an adjustable wrench close to the threads. With the strap loose pull scoop panel pins from grommets then slide the scoop panels forward off the gas tank tabs. Small rubber grommets are on the gas tank tabs so make sure not to lose them.

# STEP 3

*Remove the seat.* Using the 10mm socket remove the two bolts on either side of the seat. These bolts are located just in front of the handles. With the bolts completely out, remove the seat by lifting it up in the back and sliding it towards the back away from the tank.

#### STEP 4

Remove the gas tank. Using the 10mm socket remove the bolt that holds the rear of the tank down. This includes the small flat bracket that craddles the tank in its rubber mounts. Turn off the fuel petcock. Disconnect the rubber fuel hose by pinching the small clamping ring and pulling the hose off the petcock barb fitting. Lift the tank just off the rubber mount. While pulling the tank towards the rear of the bike rock the tank from left to right an inch or two until the tank slides off its front rubber mounts. If the tank hasn't been off the bike in a while you may need to pull strongly to break it loose from the mounts. Do so carefully. Place the tank in a safe spot away from the bike and work area.

## STEP 5

Clean the bike. Using a pressure washer or garden hose clean the bike around the carburetor area and cylinder. USE CAUTION WITH HIGH PRESSURE WATER AROUND RUBBER BOOTS TO PREVENT WATER FROM ENTERING SEALED AREAS! Remove all mud, road dust and debris. DO NOT get dirt in the exposed fuel line. Washing prevents foreign matter from entering the carburetor or engine intake port. Dry the carburetor area with a rag or compressed air.

#### **DOUBLE CHECK**



At this point you should have the carburetor, cables and cylinder head completely exposed. This area should be free from dirt. The four plastic panels, seat and gas tank should be in a safe place away from the work area. Put loose hardware in a cup. Inspect the exposed area and make sure nothing is damaged. Look for frayed cables, bad hoses or damaged electrical wires. Fix, repair or replace as required.

# STEP 6

*Remove the stock carburetor.* Using the small flat wrench provided in your bike tool kit or small adjustable wrench loosen the throttle cable ends and disconnect them from the bell crank.

- a) Remove the starter enrichening lever (choke) bracket from the handle bars using a 12mm socket. Replace the handle bar bolt and tighten it. In the enrichener cable, there is a rubber boot (about 1/2 way down the cable). Pull this boot back and disconnect the enrichener cable at this point. Remove the enrichener knob, bracket and cable stub by sliding it out of the instrument cluster area. Cut or remove cable ties as required.
- b) Snake all the drain/vent hoses up towards the carb so they are free from the frame and swing arm. If there is an emission canister hose make sure that's clear.
- c) Using the 3mm allen wrench (hex key) loosen the clamping ring on the front of the carburetor (engine side). Don't back the screw all the way out just completely loosen it. Using a phillips screw driver loosen the clamping ring on the rear of the carburetor (air box side). Don't back the screw all the way out just completely loosen it. Spray WD40 on the rubber parts to help the carburetor slide out. Slide the rear clamping ring back towards the air box away from the carburetor spiquet.
- d) The carburetor should now spin and be loose. Carefully work the carburetor out of the bike from the left side. You may need to pull the air box hose off with your fingers first. You can store the OEM carburetor in the TM33 box for future reinstallation. You'll need to jockey the carburetor around a little but it will come out.

## **STEP 7**

Retract the throttle cable tension adjustment. Using the small flat wrench provided in your bike tool kit or small adjustable wrench loosen the throttle cable adjustment jam nut. This nut is located inside a rubber boot just off the throttle grip. On bikes with pull on/pull off cabling the adjustment is in the pull on cable. Set this adjustment in for maximum cable length. Leave boot off and jam nut loose.



Cable Adjuster

#### STEP 8

*Install aluminum cable spacer.* Pull the rubber throttle cable boot away from the throttle grip as shown below. Disassemble the two halves of the throttle grip using a phillips head screw driver. Free the cable ends from the nylon drum. There are two right angle black plastic sweep guides that direct the cable onto the throttle drum. Identify the one that pulls the throttle off (the forward cable). Using a heat gun or hair dryer, warm the plastic until it's soft enough to pull it off the cable sheath. Now



Aluminum Cable Spacer

with the plastic soft, pull the guide straight off the cable sheath. The guide remains on the actual cable. Install the aluminum cable spacer into the cable as shown above. You may need to warm the plastic guide again to allow the aluminum to be easily pressed into it. Reassemble the throttle grip mechanism and check for proper operation. Note there is a small tang in the throttle grip that indexes with a hole in the handle bars. Push the rubber boot back over the guides and spacer. Use a small amount of WD40 if required.

# STEP 9

Install the TM33 carburetor. For reference locate the idle adjustment screw on the bottom of the TM33's outlet side. You may need to adjust this in step 13. Clean engine inlet flange and air box hose. Spray both with WD40 to make them slippery. Using a 4mm allen wrench (hex key) remove the cable bracket from the TM33 via the single cap screw that holds the cable bracket plate to the carburetor's body. With the carburetor 90 degrees to the vertical (bell crank on top) work it onto the engine from the left side of the bike. Slip the air box hose over the inlet and position the clamping ring in the hose's groove. Do not tighten anything at this time. The carburetor needs to remain loose. Rotate the carburetor into a vertical position. You may need to pull it down slightly so the bell crank clears the electrical cable that runs under the frame rail. Refer to the left/right photos below to see the carburetor's position.

# **STEP 9 (continued)**



TM33 Right Side View



TM33 Left Side View

The photo below shows how the carburetor aligns vertically. Note the rear screw on the carburetor's black top cover just hidding under the frame boss. There should also be about 1/16" clearance between this screw and the frame boss. This allows the carburetor to vibrate in its rubber mounts without metal to metal contact. Make sure this is so then tighten both inlet and outlet clamps using the 3mm allen key (hex wrench) and phillips head screw driver respectively.



Top Cover Screw Just Under Frame Boss

# **STEP 10**

Reroute and connect throttle cables. The stock carburetor controls the throttle from the left hand side which is opposite to the TM33. This requires to throttle cables to be rerouted to the right side of the bike. Enough length is available in the stock cables to accomplish this. Refer to the photos below to see how the cables are rerouted.

# **STEP 10 (continued)**



Left Side Cable Routing


**Engine Support** 

Clutch Cable



Right Side Cable Routing

Cut existing cable ties as required and reroute the throttle cables through the frame so they come out on the right side of the carburetor just above the bell crank. On some bikes the clutch cable will interfere with the bell crank. If this happens remove the engine support with a 12mm socket and pull the clutch cable to the right side as shown above. Replace engine support bracket after rerouting the clutch cable. The clutch cable has extra protection around its sheath so make sure this is in proper position to avoid cable damage. Install the cable bracket to the TM33 using a 4mm allen wrench (hex key) and the single mounting screw and lock washer. For single cable bikes you can remove the extra cable mount block from this bracket if you desire. Hook throttle cable(s) to carburetor and tighten all jam nuts. Refer to the photo below to see how the cables connect to the TM33.



Pull Throttle On Cable

Pull Throttle Off Cable

The Bell Crank

# **STEP 10 (continued)**

Using the nylon zip ties provided in the kit, cinch down the cables as required to make sure everything is tight, not rubbing and in proper position. Set the cable length adjuster to remove any slop in the throttle grip, tighten its jam nut and replace the rubber boot. Make sure throttle snaps back to idle without drag or hesitation. Check for smooth operation of the throttle and inspect the bell crank to make sure it is able to move freely. Adjust and/or correct throttle action as necessary. While watching the bell crank move the handle bars completely left to right and right to left. Make sure not to move the throttle grip while steering. During the above steering action (lock to lock), cables shouldn't pull and the bell crank should remain stationary.

#### **STEP 11**

Install Hoses. Using the supplied hose in the kit hook up the left and right vent hoses on the TM33's aluminum barb fittings. They are located on center with the carburetor's bore on each side. These barb fittings point down towards the ground. Using the smaller hose hook up the bowl fuel drain. Fuel drain nipple is on the bottom of the bowl. Feed hoses down behind the swing arm towards the ground. Make sure to route hoses so they don't get pinched or damaged when the bike is operated. Keep them clear of the exposed clutch cable. Make sure they will drain away from the bike's frame and swing arm. Cut lengths accordingly. Remove the black fuel inlet hose from the stock carburetor and install it on the TM33's brass fuel inlet barb fitting. Make sure to use both stock squeeze clamps. WD40 can be used to help push the fuel line hose onto the TM33 since its barb fitting is slightly larger than the stock carburetor's fuel inlet.

#### **DOUBLE CHECK**



At this point you should have the TM33 carburetor installed. Throttle cabling should work properly and be cinched down with zip ties. All bolts, jam nuts and clamps should be tight. The cable spacer should be installed and all rubber boots returned. The throttle should operate smoothly with no slop or drag. The bell crank should be free to move and not touch any metal. The TM33 should be free to vibrate in its rubber mounts without any metal to metal contact. Drain hoses should be installed and free from possible cuts, wearing or pinching. Fluids should be conducted down and away from the bike.

# **Installing the TM33: (conclusion)**

#### **STEP 12**

*Install the gas tank*. Spray some WD40 on the two round rubber mounts that hold the front of the gas tank. Slide the gas tank back into position and reinstall the bracket that holds down the back of the tank. Push the fuel line hose onto the fuel petcock barb fitting. Position the small hose pinch clamp. Turn on the fuel and make sure no fuel leaks are present.

## **STEP 13**

Starting the bike. At this time the bike can be started. Pull the enrichener knob all the way out and twist the throttle a couple of times to squirt fuel into the bore. The bike should start easily and fast idle. After 15 - 30 seconds you can push the enrichener knob to the second position and let the bike warm up for a few minutes. After the bike is warm push the enrichener knob all the way in and adjust the idle speed. There is a small thumb screw that adjusts the idle speed towards the bottom of the TM33 on the left. There is also a small idle jet screw just on the underside of the TM33's outlet. If necessary use a small short screw driver to adjust this for best idle performance. Turning the screw out richens the mixture. The bike will idle best if set slightly on the rich side. Once all adjustments are made, quickly roll the throttle on to make sure the engine accelerates crisply. Keep in mind that the XT225 will run lean when cold and much richer when hot. Best performance should occur when the bike is at a stable operating temperature.

# **STEP 14** - Final Step

*Install the seat and plastic panels*. Install the seat and the four plastic panels that were removed at the beginning of this procedure. Spray some WD40 on the rubber grommets to assist in reassembly. With the seat and plastic panels in position the bike should be completely reassembled at this time and ready for normal operation. Your TM33 has been completely installed. At this time the bike can be test ridden.



# **Performance and Tuning the TM33:**



#### PERFORMANCE NOTES

The TM33 pumper carburetor includes an accelerator pump mechanism and a throttle slide which is under direct control of the throttle cables. The accelerator pump squirts a small amount of fuel directly into the intake port as soon as the throttle is moved from a closed position to slightly open. Throttle positions slightly beyond open do not actuate the accelerator pump. This is a normal design for motorcycle carburetors of this type. The TM33 does not include any accelerator pump adjustments. Timing the accelerator pump in this way helps the engine accelerate crisply from idle. By twisting the throttle slightly, the accelerator pump also primes the engine and greatly assists in cold starting.

Direct contol over the throttle slide allows the rider roll on the throttle at an appropriate rate to suit riding conditions. The engine will respond immediately to acceleration requests. It should be noted that instantly snapping the throttle wide open from idle will cause the engine to stall. This situation does not represent a jetting problem but is normal for 4 stroke engines with venturi type carburetors. Snapping the throttle "full on" opens the entire carburetor bore to an idling engine. The resultant rapid drop in the velocity of air passing through the carburetor bore prevents fuel from being drawn out of the bowl, atomized and sucked into the intake port. This sudden loss of fuel will stall the engine before it has a chance to catch up. To rapidly accelerate the engine, the throttle should be rolled on quickly. Using this technique will provide for quick snappy acceleration.

Lugging the engine (not down shifting properly) then calling for rapid acceleration may cause hesitation. Adequate RPM should be maintained to ensure proper venturi action and atomizing of fuel. This will allow for the best acceleration and performance.

Increased power and acceleration come at the expense of emissions and fuel economy. The TM33 pumper carburetor will use more fuel than the stock CV carburetor. As such it will also produce more emissions making it an illegal upgrade in those places where street legal motorcycle emissions are strictly monitored. Make sure to understand your local emissions laws and abide by them. In places where the XT225 is used off-road emissions may not be a consideration. It is your responsibility to know local emission laws and operate your bike accordingly. The TM33 kit doesn't require any permanent modifications to the bike so the stock "street legal" CV carb may be put back on the bike if required.

# **Performance and Tuning the TM33: (continued)**

#### **TUNING THE TM33**

The TM33 pumper carburetor has been jetted to work properly in 68 degrees F with a generic XT225 engine at sea level with stock exhaust. Altitude, temperature and engine conditions will play a major role in how well the TM33 performs on a specific bike. Other factors like humidity and fuel grade will also affect how the carburetor functions. In most cases adjustments will not be required but should they be necessary the information presented here will be helpful. It is suggested that these adjustments be performed by those experienced with motorcycle carburetors and repairs.

Two adjustments can be performed on the TM33 to alter its air fuel ratio allowing the carburetor to run richer or leaner. The first of these adjustments involves moving the e-clip on the jet needle which will richen or lean out the mixture over throttle ranges from 1/4 to 3/4 open. The default e-clip setting is mid position which allows two settings in either the rich or lean direction. Moving the e-clip up leans the mixture and moving it down richens the mixture. The second adjustment is to replace the main jet with a different size. A larger main jet increases fuel flow. The main jet will affect the entire throttle range but has most of its impact on 3/4 to wide open throttle.

A rich mixture is characterized by an heavy exhaust smell and excessive fuel consumption. Operating the bike in high altitudes or very hot dry weather may cause the mixture to run rich. A lean mixture is characterized by hesitation, stumbling and general poor acceleration. Before the carburetor is suspected of a poor match to the engine, make sure to eliminate other problems like ignition and/or clogged air box. Before attempting any carburetor tuning the engine should be in generally good condition and the air filter cleaned.

#### **ADJUSTING THE JET NEEDLE**

Refer to the exploded view of the TM33-8012 at the end of this manual to identify the carburetor's parts. This adjustment can be made without removing the carburetor from the bike.

**STEP 1** - Turn off the fuel petcock. Run the carburetor out of fuel. Remove the 4 plastic cowl panels. Disconnect the fuel line. Remove the seat and fuel tank to expose the carburetor. Loosen the clamps on the inlet and outlet of the carburetor. Remove the single screw that holds the throttle cable bracket to the TM33's body. Pull this bracket loose from its index pin. You do not need to remove the throttle cables.

**STEP 2** - Carefully rotate the top of the TM33 towards the left side of the bike to allow access to the top cover (2). You will need to push down on the carburetor so the bell crank clears the wiring harness. The top cover (2) and top cover screws (1) should be exposed. Remove the top cover (2).

# **Performance and Tuning the TM33: (continued)**

# ADJUSTING THE JET NEEDLE (continued)

- **STEP 3** Using a small socket remove the throttle lever bolt (58). Lift the throttle lever (58) up to draw the throttle valve (9) to its fully open position. Using a 2.5mm allen wrench (hex key) loosen the joint assembly screws (4). Remove the joint assembly (5) from the throttle valve (9).
- **STEP 4** With the joint assembly (5) clear remove the throttle valve (9) from the TM33. Remove the jet needle (8) from the throttle valve (9). Don't lose the packing washer (7).
- **STEP 5** Place the jet needle (8) down on a flat surface with the e-ring (6) split facing down. Just behind the e-ring (6), press the jet needle (8) down with your thumb to free it from the e-ring (6). Move the e-ring (6) to the desired position on the jet needle (8). Snap it into place. Put the jet needle (8) back into the throttle valve (9).
- **STEP 6** Reassemble the TM33 and put the top cover (2) back on.
- **STEP 7** Return the TM33 to its original upright position and reattach the throttle bracket.
- **STEP 8** Install fuel tank and hook up fuel line. Replace seat and plastic panels.
- **STEP 9** Test ride bike and repeat jet needle adjustments as required.

#### REPLACING THE MAIN JET

Refer to the exploded view of the TM33-8012 at the end of this manual to identify the carburetor's parts. This adjustment requires removing the carburetor from the bike. It is a good idea to clean the bike's carburetor area to prevent foreign matter from accidentally entering the engine.

- **STEP 1** Turn off the fuel petcock. Run the carburetor out of fuel. Remove the 4 plastic cowl panels. Disconnect the fuel line. Remove the seat and fuel tank to expose the carburetor. Loosen the clamps on the inlet and outlet of the carburetor. Slide the inlet clamp back towards the air box. Remove the single screw that holds the throttle cable bracket to the TM33's body. Pull this bracket loose from its index pin and remove the throttle cables from the bell crank.
- **STEP 2** Remove all the vent/drain hoses from the TM33. Place an absorbant cloth under the TM33 to catch fuel spills. Spray some WD40 on the inlet and outlet of the carburetor to reduce friction. Turn the top of the TM33 towards the left side of the bike so the bell crank is facing up. Carefully work the TM33 out of the bike.

# **Performance and Tuning the TM33: (continued)**

# REPLACING THE MAIN JET (continued)

**STEP 3** - Place the TM33 on a clean towel. Remove the single long float bowl screw (33) and three short float bowl screws (34). Carefully remove the bowl making sure not to bend the dip tube or lose the A/P plunger (44) and spring (43). Try to avoid letting gasoline contact the float bowl O-ring (29) as this will cause it to expand making reassembly difficult. If the O-ring expands, simple dry it off and let it return to its original size before attempting reassemble.

#### BE CAREFUL NOT TO DAMAGE THE FLOATS OR CHANGE THEIR ADJUSTMENT

**STEP 4** - With the main jet (27) now exposed use a large straight blade screw driver to remove it. Replace the main jet (27) with the desired size. Numbers are stamped on the jets to indicate size. Larger numbers move towards a richer mixture.

**STEP 5** - Reassemble the TM33 and install it back in the bike. Re-attach all vent/drain hoses. Tighten clamps. Connect the throttle cable and check for proper unobstructed operation. Replace the fuel tank and hook up the fuel line. Install the seat and plastic cowlings.

**STEP 6** - With the bike completely assembled turn the fuel petcock on and make sure there are no fuel leaks. Test run the bike and check for proper performance. Change main jet sizes as required to achieve desired performance.



#### **ALWAYS RIDE UNDER CONTROL**



# TM33-8012 Pumper Carb

A/a	Description	Dout Number	
<u>No.</u>		Part Number	
1.	Screw, Top Cover	CW2=0410	
2.	Top Cover	TM29/16a	
3.	Gasket, Top Cover	TM29/17	
4.	Screw, Joint Assy	703-13001	1
5.	-Joint Assy	TM29/71	
6.	E-Ring	VM20/369	
7.	Packing	VM26/315	
8.	Jet Needle	J8-5FP96-3	2
9.	Throttle Valve	832-38007-1.5	
10.	Gasket, Air Funnel	TM20/62	
11.	Hose, Vent	VM34/105	
12.	Air Funnel	TM33/32	59
13.	Screw, Air Funnel	VM38/133	58
14.	Pilot Air Screw	BS30/97-1.1	4 @ 60 @
15.	Main Air Jet	BS30/97-0.7	
16.	Spring, Idle Adjuster	730-07008	
17.	Idle Adjuster	TM33/38	5
18.	Clip, Idle Adjuster	N189.169	55
19.	Pin, Float	VM30/160	54
20.	Float Assy	859-34003	6
21.	Needle Valve Assy	N133.200-1.8	
22.	Screw, Valve Holder	VM13/216	7—— © 63
23.	O-Ring, Needle Valve	KV/10	65
24.	Filter, Needle Valve	VM18/233	8
25.	Ring (nylon), Main Jet	TM33/35	
26.	Ring (brass), Main Jet	VM18/106	66
27.	Main Jet	N100.604-127.	
28.	Pilot Jet	VM28/486-37.5	
29.	O-Ring, Float Bowl	616-94012	9
30.	Drain Screw, Float Bowl	N133.363	
31.	Float Bowl	TM33/77	
32.	Hose, Overflow	888 23043 1F	10 51
33.	Screw (long), Float Bowl	C2=0416	
34.	Screw (short), Float Bowl		50 49
35.	O-Ring, A/P Nozzle	N123.063	48
36.	A/P Nozzle	TM29/24	
37.	Plug, A/P Nozzle Pilot Screw	TM29/14	
38. 39.	Spring, Pilot Screw	N138.192 N138.187	12
39. 40.	Washer, Pilot Screw	VM12/33	42
41.	,	N133.037	41 \\
42.	O-Ring, Pilot Screw  Hose, Vent	888-25029-1E	
43.	Spring, A/P Plunger		13 25 B — 39
44.	A/P Plunger	TM29/18	
45.	Cap, A/P Rod	N150.048	
46.	Rod, A/P	TM33/46	0 44 15
47.	Bolt, A/P Lever	B30/397	
48.	Lever, A/P	VM38/212	
49.	Spring, A/P Lever	TM33/47	28 35 35 = 44
50.	-Main Body	TM33cc90/01-0	
51.	Screw,Throttle Bracket	C5=0510	17
52.	Throttle Bracket	TM33/33	
53.	Bellcrank	TM33/44	19
54.	Spring, Throttle Return	TM24/21	// 19 /
55.	Packing, Throttle Shaft	B36/95	
56.	Lever, Throttle	VM13/186	20
57.	Washer, Throttle Lever	W4=05	30
58.	Bolt, Throttle Lever	VM28/230	
59.	Spring, Linkage Lever	VM33/49	G 18 31 P
60.	Plate, Linkage Lever	VM33/45	
61.	Washer, Linkage Lever	M10/56	32))
62.	E-Ring, Linkage Lever	BSW28/70	
63.	Packing, Linkage Lever	B40i/10	□ 34 — □
64.	Choke Assy	TM33/49	<u> </u>
65.	O-Ring, Choke Assy	N138.198	e e
66.	Needle Jet	784-24111-P-8	33——