

INSTRUCTION MANUAL BTManager 2.0 for FC-200 with Windows CE5.0

64852 90190

Table of Contents

Getting Started with Bluetooth Manager	1-1
Starting Bluetooth Manager	1-1
Getting Acquainted	1-2
Using Bluetooth Manager	2-1
Discovering Devices	2-1
Adding to the List of	
Favorite Devices	2-4
Viewing Device Properties	2-6
Deleting a Device from the List	2-7
Choosing Device Accessibility	2-8
Pairing Bluetooth Devices	2-9

Notes:

Getting Started with Bluetooth Manager

This manual describes Bluetooth[®] Manager (BTManager) 2.0 used on the Topcon field controller FC-200 with the CE.Net operating system.

The BTManager utility controls the FC-200 Bluetooth module.

Starting Bluetooth Manager

To start the BTManager:

- 1. Turn on the FC-200.
- 2. Tap the Bluetooth icon in the system tray, and select **Bluetooth Manager** from the pop-up menu.



Figure 1-1. Starting Bluetooth Manager

3. If the Bluetooth transmitter is switched off (the menu item is gray), select **Turn Transmitter On** to turn on Bluetooth.

Getting Acquainted

Table 1-1 summarizes the screens and settings in BTManager,

Description	Screen
Type of devices to detect This screen displays types of devices to pair with. Once a device type is selected, the <i>Discovery</i> <i>Wizard</i> searches for those devices when you tap Next .	Type of devices to detect Image: Constraint of the second of the sec
Device List This screen displays all discovered devices of a selected type. From this list, you can choose a device to pair with and add it to your <i>List of</i> <i>Favorite Devices</i> by tapping Next .	Device List ► Device Name Address ♥ P-0168 00:03:7a:2b:42:08 ♥ Prover 166 00:03:7a:2b:42:72 Check the checkboxes next to the device that you would like to save. Check the checkboxes next to the device that you would like to save.

Table 1-1. BTManager Screens

Description	Screen
List of Favorite Devices This screen displays your preferred Bluetooth-enabled devices to pair with. Selecting a device and tapping View > Details displays detailed information about that device.	Device View Tools Help X ROVER 166 PP-0168
My Bluetooth Device This screen displays the internal FC-200 Bluetooth module information. Enabling Discoverable allows other devices to detect your FC-200. Enabling Authentication confirms the identity of other devices trying to pair with your FC-200.	My Bluetooth Device OK My My My N My N My N My Bluetooth Device N My Class (Major): Computer Class (Minor): Unclassified Device Name: WindowsCE Address: 00:03:7a:30:d0:02 Discoverable Authentication

Table 1-1. BTManager Screens (Continued)

Description	Screen
Bluetooth Device Pairing	
This screen prompts the <i>Wizard</i> to search for the device you have selected to pair with when you tap Next .	Bluetooth Device Pairing Image: Constraint of the second pairing Bluetooth Device Pairing Pairing Tap Next to begin pairing Bluetooth devices. Pairing creates a bond between the computer and your Bluetooth device. This process is only required once per Bluetooth device. Image: Second part of the second part o
About BTManager	
This screen displays version and copyright information for the BTManager.	About BtManager

Table 1-1. BTManager Screens (Continued)

Using Bluetooth Manager

Before the FC-200 can pair with another Bluetooth-enabled device, it must discover which devices are available within your coverage area. You can then add these devices to the *List of Favorite Devices*. Upon first opening the BTManager, the *List* is empty.



Figure 2-1. List of Favorite Devices

Discovering Devices

To discover other Bluetooth-enabled devices within your coverage area:

1. Tap Tools ▶ Device Discovery.



Figure 2-2. Tools menu - Device Discovery

The Discovery Wizard appears (Figure 2-1).



Figure 2-3. Discovery Wizard

2. Tap Next to display a list of device types.



Figure 2-4. Device Types

3. Choose a type of devices to discover, and tap Next.

The *Discovery Wizard* searches for Bluetooth-enabled devices in your coverage area and displays the icons of the devices it discovers on the *Device List*.

As device names and addresses are retrieved, the *Device List* updates with detailed information.



Figure 2-5. Discovered Devices

Once the *Device List* is populated, you can add any device from this list to the *List of Favorite Devices*.

Adding to the List of Favorite Devices

The *Devices List* displays all discovered Bluetooth-enabled devices in your coverage area.

To add a device from the Devices List to the List of Favorite Devices:

1. Select a device, and tap **Next**. You can choose more than one device.

Device List	
Device Name	Address
🗹 웡 PP-0168	00:03:7a:2b:42:08
🗹 🗞 ROVER 166	00:03:7a:2b:42:72
	next to the device that like to save.
< Ba	ack Next >

Figure 2-6. Select Device(s)

A confirmation message appears when the devices are successfully added to the *List of Favorite Devices*.

Finish 📃 🗾
Success!
You have added 2 new device(s). Tap Finish to exit.
< Back Finish

Figure 2-7. Devices Added

2. Tap **Finish** to exit the *Wizard* and display the *List of Favorite Devices*.

The *List of Favorite Devices* shows all devices your FC-200 is currently paired with. You can view devices by icon and name or by name and address.



Figure 2-8. Bluetooth Devices Folder - Name and Icon View

To display the list of devices by name and address, tap **View ▶ Details**.

Device View	Т	ools	Help	×
Device Name		Addr	ess	
8 ROVER 166		00:0	3:7a:2b:	42:72
🛞 PP-0168		00:0	3:7a:2b:	42:08
<				>

Figure 2-9. Bluetooth Devices Folder - Name and Address View

Viewing Device Properties

To view the properties of a device, select the device in the *List of Favorite Devices*, and tap **Device > Properties.**

The *Bluetooth Device Properties* screen displays major and minor class identifiers, the name, and address of the selected device. The screen also shows the services supported by the device. Depending on the device type, the supported services can include Limited,

Positioning, Networking, Rendering, Capturing, Object_XFER, Audio, Telephony, and Information.



Figure 2-10. Bluetooth Device Properties

Deleting a Device from the List

To delete a device from the List of Favorite Devices:

- 1. Select the device, and tap **Device** ➤ **Delete**. A confirmation message appears.
- 2. Tap **Yes** to delete the device.



Figure 2-11. Deleting a Device

Choosing Device Accessibility

To select accessibility settings for the internal FC-200 Bluetooth Module, tap **Device** ► **My Bluetooth Device**.

The *My Bluetooth Device* screen displays information about the internal FC-200 Bluetooth module and if external devices can discover/pair with it.



Figure 2-12. My Bluetooth Device

My Bluetooth Device always displays the following information:

- Class (major and minor)
- Name (Other devices use this name to identify the FC-200.)
- Address

This screen also allows you to enable the following accessibility options:

- Discoverable: allows other devices to find the FC-200
- Authentication: authenticates the identity of other devices

BTManager allows the FC-200 to connect with other Bluetoothenabled devices using serial port or dial-up services:

• SPP (Serial Port Profile): provides serial port connection with peripheral Bluetooth-enabled devices, including GPS receivers which normally do not require authentication.

• DUN (Dial-up Networking Profile): provides a standard to access dial-up services over Bluetooth. The most common scenario is connecting to a phone.

Pairing Bluetooth Devices

Pairing establishes communication between devices by exchanging PINs and addresses. Once communication is established and authentication occurs, these devices become "trusted" devices and will no longer have to authenticate for future connections. The *List of Favorite Devices* displays all of the discovered Bluetooth-enabled devices your FC-200 can pair with.

To pair with a Bluetooth-enabled device from the *List of Favorite Devices*:

1. Select the device, and tap **Device** ▶ **Pair**.



Figure 2-13. Device Menu - Pair

The *Pairing Wizard* appears to guide you through the pairing process.

2. Tap Next to continue.

The Wizard searches for the other device.



Figure 2-14. Pairing with Remote device

When the *Wizard* discovers the other Bluetooth-enabled device, you are prompted to enter a passkey (PIN) for authentication. The same passkey must be entered on both devices to establish authentication and pairing. Authentication is only required the first time the two devices pair.



Figure 2-15. Enter Passkey (PIN)

3. Enter a passkey, and then tap Next.

4. If the passkey on the remote device is changed or revoked, an error message appears. Tap **OK** to change the current passkey.

	ooth Device Pairing	
The fa ROVER	llowing device requires a passkey: \ 166	
	me Bluetooth passkey is required	
each o and ta	Win32 error	elow IV
the re Please	The operation being requested was not performed because the user has not	
Passke symbo		16
	< Back Next	: >

Figure 2-16. Change Current Passkey

A congratulation message appears when the pairing is successful.

Bluetooth Device Pairing 📃 🔀
Success!
You are now paired to the following device: ROVER 166
Tap the Finish button to exit the Wizard.
< Back Finish

Figure 2-17. Successful Pairing

5. Tap **Finish** to exit the *Wizard*.

©2007 TOPCON CORPORATION ALL RIGHTS RESERVED