

GMC[®]

GLOBAL MACHINERY COMPANY

INSTRUCTION MANUAL

2000W

Heat Gun Paint/ Stripper Kit



2 YEAR
REPLACEMENT
WARRANTY

30 DAY
SATISFACTION
GUARANTEE

• Melbourne • Perth • Auckland • Hong Kong • Shanghai
• Taipei • New York • Verona • London • Paris

HG2000K
030825 MA ED1

Contents

Warranty	2
Introduction	3
Environmental protection	3
Description of symbols	3
Specifications	3
General safety instructions	4
Safety rules for heat guns	5
Know your product	6
Accessories	6
Features	7
Variable Temperature Control	7
Temperature Indicator	7
Safety Cut Out	7
Assembling the Wire Stand	7
Unpacking	8

Full 2 Years Home Use Warranty

Whilst every effort is made to ensure your complete satisfaction with this tool, occasionally, due to the mass manufacturing techniques, a tool may not live up to our required level of performance and you may need the assistance of our service department.

This product is warranted for a 2-year period for home domestic use from the date of the original purchase. If found to be defective in materials or workmanship, the tool or the offending faulty component will be replaced free of charge with another of the same item. A small freight charge may apply.

The warranty replacement unit is only made available by returning the tool to the place of purchase with a confirmed register receipt. Proof of purchase is essential. We reserve the right to reject any claim where the purchase cannot be verified.

This warranty does not include damage or defects to the tool caused by or resulting from abuse, accidents, alterations or commercial or business use.

It also does not cover any bonus accessories unless the tool is a GMC Platinum Professional model.

Please ensure that you store your receipt in a safe place. Conditions apply to the above warranty.

If you need direction of what constitutes a free of charge warranty claim, please review the guide given on the rear of the Receipt Holder. An indication is given as to the types of claim that are permissible, and those that are not.



Dear Customer

If you require any help with your product, whether it is a Warranty claim, spare part or user information, please phone our Help Line for an immediate response. Phone 1300 880 001 in Australia or 0800 445 721 in New Zealand.

Introduction

Your new GMC power tool will more than satisfy your expectations. It has been manufactured under stringent GMC Quality Standards to meet superior performance criteria.

You will find your new tool easy and safe to operate, and, with proper care, it will give you many years of dependable service.

Caution. Carefully read through this entire Instruction Manual before using your new GMC Power Tool. Take special care to heed the Cautions and Warnings.

Your GMC power tool has many features that will make your job faster and easier. Safety, performance, and dependability have been given top priority in the development of this tool, making it easy to maintain and operate.

Environmental protection



Recycle unwanted materials instead of disposing of them as waste. All tools, hoses and packaging should be sorted, taken to the local recycling centre and disposed of in an environmentally safe way.

Description of symbols

The rating plate on your tool may show symbols. These represent important information about the product or instructions on its use.



Wear hearing protection.

Wear eye protection.

Wear breathing protection.



Double insulated for additional protection.



N380

Conforms to relevant safety standards.

Specifications

Voltage:	230–240Vac ~ 50Hz
----------	-------------------

Wattage:	2000W
----------	-------

Setting 1:	1000W
------------	-------

Setting 2:	2000W
------------	-------

Heat Setting Range:	0 - 650°C
---------------------	-----------

Setting 1:	50° - 550°C
------------	-------------

Setting 2:	50° - 650°C
------------	-------------

Insulation:	Double insulated
-------------	------------------

Weight:	0.85kg
---------	--------

General safety instructions

To use this tool properly, you must observe the safety regulations, the assembly instructions and the operating instructions to be found in this Manual. All persons who use and service the machine have to be acquainted with this Manual and must be informed about its potential hazards. Children and infirm people must not use this tool. Children should be supervised at all times if they are in the area in which the tool is being used. It is also imperative that you observe the accident prevention regulations in force in your area. The same applies for general rules of occupational health and safety.

Warning. When using power tools, basic safety precautions should always be taken to reduce the risk of fire, electric shock and personal injury. Also, please read and heed the advice given in the additional important safety instructions.

- 1. Keep the work area clean and tidy.** Cluttered work areas and benches invite accidents and injury.
- 2. Consider the environment in which you are working.** Do not use power tools in damp or wet locations. Keep the work area well lit. Do not expose power tools to rain. Do not use power tools in the presence of flammable liquids or gases.
- 3. Keep visitors away from the work area.** All visitors and onlookers, especially children and infirm persons, should be kept well away from where you are working. Do not let others in the vicinity make contact with the tool or extension cord.
- 4. Store tools safely.** When not in use, tools should be locked up out of reach.
- 5. Do not force the tool.** The tool will do the job better and safer working at the rate for which it was designed.
- 6. Use the correct tool for the job.** Do not force small tools or attachments to do the job best handled by a heavier duty tool. Never use a tool for a purpose for which it was not intended.
- 7. Dress correctly.** Do not wear loose clothing or jewellery. They can be caught in moving parts. Rubber gloves and non-slip footwear are recommended when working outdoors. If you have long hair, wear a protective hair covering.
- 8. Use safety accessories.** Safety glasses and earmuffs should always be worn. A face or dust mask is also required if the drilling operation creates dust.
- 9. Do not abuse the power cord.** Never pull the cord to disconnect the tool from the power point. Keep the cord away from heat, oil and sharp edges.
- 10. Secure the work piece.** Use clamps or a vice to hold the work piece. It is safer than using your hand and frees both hands to operate the tool.
- 11. Do not overreach.** Keep your footing secure and balanced at all times.
- 12. Look after your tools.** Keep tools sharp and clean for better and safer performance. Follow the instructions regarding lubrication and accessory changes. Inspect tool cords periodically and, if damaged, have them repaired by an authorised service facility. Inspect extension cords periodically and replace them if damaged. Keep tool handles dry, clean and free from oil and grease.
- 13. Disconnect idle tools.** Switch off the power and disconnect the plug from the power point before servicing, when changing accessories and when the tool is not in use.
- 14. Remove adjusting keys and wrenches.** Check to see that keys and adjusting wrenches are removed from the tool before switching on.
- 15. Avoid unintentional starting.** Always check that the switch is in the OFF position before plugging in the tool to the power supply. Do not carry a plugged in tool with your finger on the switch.
- 16. Use outdoor rated extension cords.** When a tool is used outdoors, use only extension cords that are intended for outdoor use and are so marked.

17. Stay alert. Watch what you are doing. Use common sense. Do not operate a power tool when you are tired.

18. Check for damaged parts. Before using a tool, check that there are no damaged parts. If a part is slightly damaged, carefully determine if it will operate properly and perform its intended function. Check for alignment of moving parts, binding of moving parts, breakage of parts, proper mounting and any other conditions that may affect the operation of the tool. A part that is damaged should be properly repaired or replaced by an authorised service facility, unless otherwise indicated in this Instruction Manual. Defective switches must be replaced by an authorised service facility. Do not use a tool if the switch does not turn the tool on and off correctly.

19. Guard against electric shock. Prevent body contact with grounded objects such as water pipes, radiators, cookers and refrigerator enclosures.

20. Use only approved parts. When servicing, use only identical replacement parts. Use an authorised service facility to fit replacement parts.

WARNING. The use of an accessory or attachment, other than those recommended in this Instruction Manual, may present a risk of personal injury.

Additional safety rules for Heat guns

- A fire may arise if the appliance is not use with care.
- Be careful when using the appliance in places where there are combustible materials, such as inflammable liquids, rags, wood shavings and the like.
- Do not apply the heat to the same place for a long time.
- Do not use in the presence of an explosive atmosphere.
- Heat may be conducted to combustible materials which are out of sight
- Place the appliance on its stand whenever you place it down and after use and allow to cool before storage;

- Never leave the appliance unattended when in use.
- Rags, cloths, cord, string, wood shavings and the like should never be left around the work area.
- Support the work properly.
- If you are interrupted when operating the appliance, complete the process and switch off before looking up.
- When using the appliance, use safety equipment including safety goggles or shield, breathing mask and protective clothing including safety gloves.

Wear goggles

Wear earmuffs

Wear a breathing mask

- Never attempt to use the appliance to dry animals, clothing or hair.
- Never use this appliance as a hair dryer.
- Always use in ventilated areas.
- Do not leave the appliance unattended when in use.
- This product is designed for light domestic use only, it is not designed for industrial purposes and whilst every care has been taken to make hot air gun safe, accidents can happen. By following the simple safety guide you can avoid accidents.

WARNING: During application the heat nozzle must be kept at least 16mm away from the work piece. This is to allow air flow.

Know your product

1. Heat Nozzle
2. Guard Sleeve
3. Body
4. LED Temperature Indicator
5. Variable Temperature Control Dial
6. Two speed rocker switch
7. Wire Stand
8. Power Cord

Accessories

9. Heat Spreader
10. Heat Reflector
11. Heat Concentrator
12. Heat Deflector
13. Paint Scraper
14. Scraper Handle Scrapers
15. Scrapers



Features:

Two Speed Rocker Switch:

The rocker switch can be adjusted to 3 positions and these are:



Position 0:
Stop/Off



Position 1:
50° - 550°C



Position 2:
50° - 650°C


Variable Temperature Control

The variable temperature control enables the temperature to be set and adjusted between 50°C and 650°C, depending upon the type of material and the work to be carried.



Temperature Indicator

The temperature indicator gives the temperature during operation. 6 LED's are placed on the box lid. Each one represents a different temperature range:



LED No:	Colour	Temperature (C)
1	Yellow	50°
2	Yellow	100°
3	Green	200°
4	Green	350°
5	Red	500°
6	Red	650°

Note: The temperature indicator gives the temperature for reference only.

Safety Cut Out

This unit is equipped with a safety cut-out device which will operate if the internal temperature gets too high. Should this feature activate, switch off the unit and wait for the unit to cool down. When the unit has cooled sufficiently normal operation can be resumed.

PLEASE NOTE: The reset time of the hot air gun's safety cut-out fuse is approximately 30 minutes, after which normal operation can resume.

Assembling the Wire Stand

For convenience, the wire stand should be set up before operating; therefore the tool can be rested when

necessary. A Phillips #1 screwdriver (not supplied) is needed during the assembly.

1. Place the wire stand to the bottom of the handle, ensuring that the ends of the stand align themselves with the holes on the handle.



2. Insert the Phillips screw on one side between the end of the stand and the hole of the handle. Use the Phillips screwdriver to secure the screw.



3. Repeat this process on the other side of the handle.

Note: Before you commence with the assembly, make sure that the plug of the unit is disconnected from the mains supply.

Unpacking

Due to modern mass production techniques, it is unlikely that your GMC Power Tool is faulty or that a part is missing. If you find anything wrong, do not operate the tool until the parts have been replaced or the fault has been rectified. Failure to do so could result in serious personal injury.

Carefully read the entire Instruction Manual before using this product.

**Before returning this product for a
Warranty Claim or any other reason
Please Call 1300 880 001 (Australia)
or 0800 445 721 (New Zealand)**

**When you make your call, please have
the following information at hand:**

- **GMC Product Type**
- **GMC Product Code**

A GMC Service Engineer will take your call and, in most cases, will be able to solve your problem over the phone.

You are welcome to use this phone-in service to make suggestions or give comments about any GMC product.

With continuing product development changes may have occurred which render the product received slightly different to that shown in this instruction manual. The manufacturer reserves the right to change specifications without notice. Note: Specifications may differ from country to country.



The GMC 777 Helpline operates from 7am to 7pm, 7 days a week (EST). This allows you to contact GMC directly with any queries and technical questions you have regarding our products.



16 Scammel Street, Campbellfield
Victoria, Australia 3061

Tel: (03) 9303 2133

Fax: (03) 9308 7822



Save this Manual for future reference.
