



Quick Start Guide

Bluetooth® Wireless Tilt Wheel Laser Mouse

GME229B
PART NO. Q1321

Package Content

- 1 Bluetooth® Wireless Tilt Wheel Laser Mouse
- 1 USB battery charging cable
- 1 Carrying pouch
- 1 Quick start guide

System Requirements

- Computer/Laptop must be Bluetooth-enabled and support the HID profile
- Operating System:
 - Windows 2000/XP/Vista
 - Mac OS X v10.3.5 or later

If the computer/laptop is currently not Bluetooth-enabled, a Bluetooth® USB adapter will be required. Refer to IOGEAR part number GBU221, GBU241W6, GBU341W6, and GBU421.

Specifications

Resolution: 400/800/1200/1600 adjustable

Mouse Report Rate: 230 report/sec

Frequency Band: 2.4 ~ 2.4835 GHz ISM Band

Interface: Bluetooth 2.0, Class II

Battery Type: Built-in 3.7V 400mA Li-Polymer Rechargeable Battery




Operating Range: 33 ft. (10m)

Pictorial Introduction

Start Here!

1. Tilt scroll wheel
2. Left click button
3. Battery low/charging/DPI indicator
4. Previous/Backward button
5. Next/Forward button
6. DPI switch button
7. Right click button

7. Right click button
8. Connect button
9. Battery charging connection
10. Power on/off switch
11. Laser sensor



Charge Battery

Plug the USB cable into the mouse and the available USB port of the computer, it will start charging. We do recommend that users charge the battery for 10 hours before using the mouse in the first time.

During charging, all 5 battery charging indicators will blink. Once the battery is fully charged, all indicators will turn off.

Note: To continuously charge the mouse via the USB cable, user's computer must be turned on or in standby mode.

Installation

1. Make sure the mouse is turned on. When you are on the go, turn the mouse off to preserve battery life.
2. To make the mouse discoverable by the computer, press the connect button on the bottom of the mouse. The blue LED will flash at the sensor hole. It means the mouse is under pairing mode.
3. Make sure that your computer is enabled for a Bluetooth device. If there is a wireless switch on the computer, be sure it is turned on.
4. Open the Bluetooth program and run the wizard to add a Bluetooth device. On most computers, the Bluetooth is found either in Control Panel or on the Start menu. Examples:
 - a. Some notebook computers: Start > Control Panel > Bluetooth Devices.
 - b. Other notebook computers: Start > All Programs > Bluetooth > Bluetooth Settings.

- c. Toshiba: Start > All Programs > Toshiba > Bluetooth > Bluetooth Settings.
- d. Macintosh: Apple > System Preferences > Bluetooth > Set Up New Device

If you are prompted for a passkey, enter “0000” (for added security), or choose no passkey. This mouse will not work with any other passkey.

Function Keys

1. **DPI Switch:** Users can change the mouse resolution by pressing DPI switch. GME229B supports 400,800,1200 & 1600 DPI. The LED indicator will show different positions to indicate the DPI value when a user presses DPI switch.
2. **Page up, Page down:** To press Page up/down button to change page of document when you are surfing website.
3. **Tilt Wheel:** No need to install any driver/software to activate the tilt wheel function. Once the connection has been set up, users can enjoy the convenience from tilt wheel.

LED indicator

There are 5 LEDs to indicate the battery capacity when power on. 5 pcs of LED all light on means battery full and 1pcs of LED light on means battery low. The LEDs will blink when charging and off when charge complete.







The LEDs show different positions to indicate the DPI you select when press DPI switch. LED1:400 dpi, LED2:800 dpi, LED3:1200 dpi, LED4:1600 dpi.

Low Battery

If the LED indicator only light on 1 LED, it means battery low. Please plug charging cable to charge.

Charging Battery

LEDs will blink when charging battery. All LEDs will turn off and stop blinking when the battery is fully charged. It will take about 2 hrs to fully charge the battery.

Indicator			
	Battery Full		400dpi
	Battery Low		800dpi
			1200dpi
			1600dpi

Warranty

WE'RE HERE TO HELP YOU! NEED ASSISTANCE SETTING UP THIS PRODUCT?

Make sure you:

1. Use the live chat at www.iogear.com to try and solve any issues you may be having with the product
2. Visit the Tech Info Library/FAQ on www.iogear.com (under the Support tab)
3. Call the 24/7 tech support line at 1-866-946-4327 (U.S. only) or 949-453-8782

Warranty Information

This product carries a 1 Year Limited Warranty. For the terms and conditions of this warranty, please go to <http://www.iogear.com/support/warranty> or call 1-866-946-4327

Register online at <http://www.iogear.com/register>

Important Product Information

Product Model _____

Serial Number _____

Contact

Address: 23 Hubble, Irvine, CA 92618 USA

Toll Free: 866-9-IOGEAR

Phone: 949-453-8782

Web site: www.iogear.com

Email: support@iogear.com

About Us



FUN

IOGEAR offers connectivity solutions that are innovative, fun, and stylish, helping people enjoy daily life using our high technology products.



GREEN

IOGEAR is an environmentally conscious company that emphasizes the importance of conserving natural resources. The use of our technology solutions helps reduce electronic waste.



HEALTH

IOGEAR supports healthy and fit lifestyles. By integrating products with the latest scientific developments, IOGEAR's solutions enhance the life of end-users.