

Breville

Breville Customer Service Centre

Australian Customers

Mail: PO Box 22
Botany, NSW, 2019
AUSTRALIA

Phone: 1300 139 798

Fax: (02) 9384 9601

Email: Customer Service:
askus@breville.com.au

New Zealand Customers

Mail: Private Bag 94411
Botany Manukau 2163
Auckland NEW ZEALAND

Phone: 0800 273 845

Fax: 0800 288 513

Email: Customer Service:
askus@breville.com.au

www.breville.com.au

Breville is a registered trademark of Breville Pty. Ltd. A.B.N. 98 000 092 928.
Copyright Breville Pty. Ltd. 2012.

Due to continued product improvement, the products illustrated/photographed
in this booklet may vary slightly from the actual product.

BWC200 Issue - E12

Breville

the Chill Control™

Instruction Booklet



BWC200



CONGRATULATIONS

on the purchase of your new
Breville Chill Control™

CONTENTS

- 4** Breville recommends safety first
- 6** Know your Breville Chill Control™
- 8** Operating your Breville Chill Control™
- 14** Care & Cleaning
- 16** Troubleshooting

At Breville we are very safety conscious. We design and manufacture consumer products with the safety of you, our valued customer foremost in mind. In addition we ask that you exercise a degree of care when using any electrical appliance and adhere to the following precautions.

IMPORTANT SAFEGUARDS

READ ALL INSTRUCTIONS BEFORE USE AND SAVE FOR FUTURE REFERENCE

- Carefully read all instructions before operation and save for future reference.
- Remove and safely discard any packaging material and promotional labels before using the Breville Chill Control™ for the first time.
- To eliminate a choking hazard for young children, remove and safely discard the protective cover fitted to the power plug of this appliance.
- Do not place the Breville Chill Control™ near the edge of a bench or table during operation.
- Do not place the appliance on or near a hot gas burner, electric element or where it could touch a heated oven.
- Do not operate the appliance on a sink or drain board.
- Ensure that the surface is level, clean and free of water.
- The Breville Chill Control™ is not intended to be operated by means of an external timer or separate remote control system.
- To protect against electric shock, do not immerse the power base, power cord or power plug in water or allow moisture to come in contact with these parts.
- Always switch the Breville Chill Control™ Off at the power outlet and unplug if the appliance is not in use, before cleaning, before attempting to move the appliance, disassembling,

assembling and when storing the appliance.

- The Breville Chill Control™ is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure they can use the appliance safely.
- The Breville Chill Control™ has been designed specifically for the purpose of filtering and chilling water and must only be used with municipally treated water. Do not attempt to filter untreated, raw water or water of unknown quality.
- Do not place the appliance directly against the wall. Ensure there is adequate airflow at the rear and sides by positioning the appliance 10cm away from the wall.
- Filter replacement is essential for the product to perform as represented and must be replaced every 8 weeks.
- Remove and empty the pre-filter tank before changing filter.
- This appliance has been designed to be used continuously.
- Do not operate without a filter in place.
- Keep the appliance and accessories clean. Follow the Care and Cleaning instructions provided on Page 14.

WARNING

Never immerse the power base, power cord or power plug in water or allow moisture to come into contact with these parts.

IMPORTANT SAFEGUARDS FOR ALL ELECTRICAL APPLIANCES

- This appliance is for household use only.
- Unwind power cord fully before use.
- Do not let power cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not use the appliance for anything other than its intended purpose as described in this instruction book. Do not use outdoors. Do not use in moving vehicles or boats.
- Close supervision is necessary when any appliance is used by or near children.
- Regularly inspect the supply cord, plug and actual appliance for any damage. Do not operate if damaged in any way or after the appliance malfunctions. Immediately cease use of the appliance and call Breville Customer Service on ph: 1300 139 798 (Australia) or ph: 0800 273 845 (New Zealand).
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid a hazard.
- Always turn the power Off and remove the plug before cleaning.
- For any maintenance other than cleaning, call Breville Customer Service on ph: 1300 139 798 (Australia) or ph: 0800 273 845 (New Zealand).
- Consult a qualified electrician if the grounding instructions are not completely understood, or if doubt exists as to whether the appliance is properly grounded.

BREVILLE ASSIST™ PLUG

The Breville Chill Control™ comes with a unique Assist™ Plug, conveniently designed with a finger hole in the power plug for easy and safe removal from the wall outlet.

For safety reasons it is recommended you plug your Breville Chill Control™ directly into its own electrical outlet on a dedicated circuit separate from other appliances. If the electrical circuit is overloaded with other appliances, your appliance may not function properly. Using in conjunction with a power strip or extension cord is not recommended.

SAVE THESE INSTRUCTIONS

KNOW

your Breville Chill Control™



- A. 2 Litre Pre-Filter Water Tank
- B. 4 Litre Filtered Water Tank
- C. Variable Temperature Slider
- D. LED Indicator
- E. Water Dispenser Lever
- F. 1 Litre Stainless Steel Cooling Reservoir

- G. BRITA® Memo - electronic cartridge exchange indicator
- H. BRITA® MAXTRA Water Filter Cartridge
- I. Extra Tall Height For Bottles

NOT SHOWN

Removable Plug - For easy cleaning
Breville Assist™ Plug

OPERATING

your Breville Chill Control™

OPERATING YOUR BREVILLE CHILL CONTROL™

BEFORE FIRST USE

Before first use, remove and safely discard all promotional labels and packing materials attached to the Breville Chill Control™.

Remove the filter cartridge from the plastic packaging and keep in a safe place. Do not re-insert the filter until (a) flushing process and (b) preparation of filter cartridge has been completed (refer to page 10).

Remove the lid, plastic plug and pre-filter tank and wash in warm soapy water. Rinse and wipe dry using new cloth. Wipe exterior of appliance with a soft damp cloth and dry thoroughly.

Place the appliance on a dry, flat level surface. Plug into 230-240V outlet and turn power On.

NOTE

Do not place the appliance directly against the wall. Ensure there is adequate airflow both at the rear and sides by positioning the appliance 10cm away from the wall.

FLUSHING THE BREVILLE CHILL CONTROL

It is important that you flush and rinse out the dispensing system before using the appliance for the first time.

Please note you should carry out these steps without the BRITA® MAXTRA cartridge in place. Plug the appliance into an appropriate electrical outlet and switch On.

1. Remove filter cartridge from the pre-filter tank and the removable plug from filter tank.
2. Fill the pre-filter tank to the maximum level with water.

3. Position the variable temperature slider to the centre.
4. Place a large container or jug under the spout.
5. Press the dispenser lever until water reaches the MIN level, then discard remaining water.
6. Repeat this process with cold tap water twice and discard.
7. Do not fill above the maximum level indicated.

NOTE

If the plastic plug is inserted while the cooling tank is empty, it will take approximately 7 minutes for the air to release from the cooling tank. During this time chilled water cannot be dispensed.

THE BRITA® MAXTRA CARBON FILTRATION PROCESS

Activated carbon reduces chlorine, metals such as lead, copper and limescale for cleaner, clearer better tasting water.

Leaves in flouride.


PREPARING THE BRITA® MAXTRA FILTER CARTRIDGE

1. Remove the filter cartridge from its wrapping.

NOTE

It is normal for the cartridge to appear moist when removed from its wrapping, this is simply condensation.

4. All 4 bars will disappear and a flashing arrow will appear to indicate the cartridge should be replaced after 8 weeks.



5. Wash and dry the pre-filter tank, and insert a new cartridge (see Preparing the Filter Cartridge on page 10).
6. To set the BRITA® Memo, see instructions on page 11.

NOTE

The BRITA® Memo is intended to be used only with BRITA® filter cartridges.

REMOVING THE FILTER CARTRIDGE

When it is time to replace the cartridge after 8 weeks use, simply lift the ring pull handle on top of the cartridge to remove.

The cartridge may be disposed of in household waste or you can contact the BRITA® consumer service for advice on Ph: 1300 557 762 for advice on recycling.

More information on the use of BRITA® filter cartridge and the BRITA® Memo can be found in the BRITA® information Guide.

CARE & CLEANING

for your Breville Chill Control™

CARE & CLEANING FOR YOUR BREVILLE CHILL CONTROL™


CARE & CLEANING

1. Switch the appliance Off and unplug the power cord from the power outlet before cleaning.
2. Remove the lid, pre-filter tank and water from the filter tank.
3. To empty the stainless steel cooling reservoir, remove the plastic plug that separates the filtered water from the cooling reservoir.
4. Turn the appliance upside down to drain any remaining water from the cooling reservoir.
5. Wipe the inside of the filter tank and cooling reservoir with a clean, damp cloth.
6. Wash the lid, pre-filter tank and plastic plug in warm soapy water using a mild detergent and dry thoroughly.
7. Wipe exterior of appliance with a soft, damp cloth.
8. Do not immerse the base in water or any other liquid

REMOVABLE PLASTIC PLUG

The Breville Chill Control™ includes a removable plastic plug that separates filtered from chilled water. As well as making the cleaning of the cooling reservoir easy, it assists in the cooling process to keep the water cool.

The plastic plug can be dismantled for cleaning. Simply squeeze the sides to release as shown below and wash with warm soapy water.



STORAGE

Ensure the Breville Chill Control™ is switched Off, all internal tanks are emptied of water and it is clean and dry before storing.

Stand the Breville Chill Control™ upright on the power base. Do not store anything on top.

Flush the appliance again before using again (see instructions on page 9)

NOTE

Do not use alkaline or abrasive cleaning agents, steel wool or scouring pads as these can damage the surface of the appliance.

Do not place any part of this appliance in a dishwasher.

TROUBLESHOOTING

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSES	WHAT TO DO
Filtered water not cold enough	• Water chiller positioned in direct sunlight	Move water chiller away from direct sunlight.
	• High ambient conditions (30°C +)	In warmer conditions, the time to chill will take longer.
	• Water Chiller too close to wall	Position water chiller min 10cm clearance away from walls.
	• Water Chiller has not been switched ON long enough.	Wait approximately 75 minutes after filling with tap water.
After filling-up 1 litre water bottle, water is not cold anymore	• Chilling tank capacity is approximately 1 litre. It takes approximately 75 minutes to chill 1 litre water from room temperature.	Wait approximately 75 minutes after dispensing large amount of chilled water.
Fan too noisy/does not switch off	• High ambient conditions (30°C +)	In warmer conditions, the time to chill will take longer.
	• Unit is running in high power mode	
How do I know the water has chilled?		The LED light will switch from WHITE to BLUE.
LED not switching from WHITE to BLUE	• Initial water temperature in chill tank is too high	Move water chiller away from direct sunlight.
	• High ambient conditions (30°C +)	In warmer conditions, the time to chill will take longer.
	• Water Chiller too close to wall	Position water chiller min 10cm clearance away from walls.
	• Water Chiller has not been switched ON long enough	Wait approximately 75 minutes after filling with tap water.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSES	WHAT TO DO
LED indicator flashing & alternating between WHITE & BLUE	<ul style="list-style-type: none"> Water Chiller is in Auto Protection Mode 	<p>Fan externally obstructed or an error with the internal electronics.</p> <p>Unplug the unit & wait a few minutes to reset the unit.</p> <p>If problem persists call Breville Customer Service 1300 139 798</p>
Water does not flow during initial flushing	<ul style="list-style-type: none"> Air lock in internal tubing 	<p>With the chilling chamber full, move slider to the middle position and use the plug like a sink plunger while holding the dispensing paddle open to clear the air lock.</p>
Flow rate of water slow	<ul style="list-style-type: none"> Not enough water in water tank 	<p>Ensure the water level is always above the MIN level for optimum flow rate.</p>
Water tank has small dark particles	<ul style="list-style-type: none"> Brita filter cartridge & unit have not been flushed 	<p>Immerse the filter cartridge in cold water and agitate to remove air bubbles.</p> <p>Flush the unit twice before each new cartridge.</p>
How can I clean the chilling chamber		<p>Remove the plastic plug in the filter tank to clean the chilling chamber.</p>
There is a flashing arrow & no bars appearing on the Brita Memo indicator	<ul style="list-style-type: none"> The Brita Filter cartridge may need to be replaced 	<p>Brita Filter Cartridge should be replaced every 8 weeks.</p>
What does the Brita Filter cartridge remove from the water?		<p>The Brita Filter reduces chlorine, metals such as lead, copper, & limescale. Leaves in flouride.</p>
Where can I purchase the Brita Filter cartridges		<p>Brita filter cartidges are available at all leading retailers or contact Brita Consumer Service Ph: 1300 557 762</p>

NOTES