




at&t

### Quick start guide

CL82101/CL82201/CL82301/CL82351/CL82401/CL82451/  
CL82501/CL82551/CL82601

**This quick start guide provides you with basic instructions only. For more complete instructions, refer to your Abridged user's manual provided in the package, or see the online Complete user's manual at [www.telephones.att.com/manuals](http://www.telephones.att.com/manuals).**


### Telephone base installation



**Caution:** Use only the power adapter provided with this product. To obtain a replacement, visit our website at [www.telephones.att.com](http://www.telephones.att.com) or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.

### Battery installation


Install the battery as shown below. Charge your handset(s) before initial use. The battery is fully charged after 10 hours of continuous charging.



1. Plug the battery connector securely into the socket inside the handset battery compartment, matching the color-coded label. Insert the supplied battery with the label **THIS SIDE UP** facing up as indicated.
2. Align the cover flat against the battery compartment, then slide it upwards until it clicks into place.
3. Charge the handset by placing it face forward in the telephone base or charger.

**Caution:** Use only the supplied rechargeable battery or replacement battery (model BT166342).

### Quick reference guide




### Handset side view



### Push to talk

- Initiate a one-to-one or one-to-group broadcast.
- Press and hold to broadcast to a group of handsets.

### Telephone base



### Initial settings

**We recommend you program your telephone system before use.**

The following are a few examples of common features to set before using the telephone. Refer to the **Handset settings** and **Answering system settings** in the Abridged user's manual or the online Complete user's manual for detailed instructions on setting all telephone features.

<b>Set date/time</b>
Set the date/time before using the answering system. 1. <b>MENU</b> -> ▼ or ▲ -> <b>Set date/time</b> -> <b>SELECT</b> . 2. ▼ or ▲ to choose month, or enter the number -> <b>SELECT</b> . 3. ▼ or ▲ to choose day, or enter the number -> <b>SELECT</b> . 4. ▼ or ▲ to choose year, or enter the number -> <b>SELECT</b> . 5. ▼ or ▲ to choose hour, or enter the number -> <b>SELECT</b> . 6. ▼ or ▲ to choose minute, or enter the number -> <b>SELECT</b> . 7. ▼ or ▲ to choose <b>AM</b> or <b>PM</b> -> <b>SELECT</b> .
<b>Record your own announcement</b>
Your outgoing announcement plays when calls are answered by the answering system. You can use the preset announcement to answer calls, or replace it with your own recorded announcement. 1. <b>MENU</b> -> ▼ or ▲ -> <b>Answering sys</b> -> <b>SELECT</b> . 2. <b>SELECT</b> to select <b>Announcement</b> . 3. ▼ or ▲ -> <b>Record annc</b> -> <b>SELECT</b> . 4. Facing the handset, record your announcement and press <b>5</b> to end recording.
<b>Number of rings</b>
You can set the answering system to answer an incoming call after 2, 3, 4, 5 or 6 rings, or toll saver. If you choose toll saver, the answering system answers a call after 2 rings if you have new messages, and after 4 rings when there are no new messages. If you want the built-in answering system instead of the voicemail to answer a call, you should set the answering system to answer a call at least 2 rings before the voicemail is set to answer. Contact your telephone service provider for information on your voicemail settings. 1. <b>MENU</b> -> ▼ or ▲ -> <b>Answering sys</b> -> <b>SELECT</b> . 2. ▼ or ▲ -> <b>Ans sys setup</b> -> <b>SELECT</b> . 3. ▼ or ▲ -> <b># of rings</b> -> <b>SELECT</b> . 4. ▼ or ▲ -> Choose among <b>2, 3, 4, 5, 6</b> or <b>Toll Saver</b> -> <b>SELECT</b> .
<b>Handset ringer volume</b>
You can set the ringer volume level to one of the six levels or turn the ringer off. 1. <b>MENU</b> -> ▼ or ▲ -> <b>Ringers</b> -> <b>SELECT</b> . 2. <b>SELECT</b> to select <b>Ringer volume</b> -> <b>SELECT</b> . 3. ▼ or ▲ to choose the desired level -> <b>SELECT</b> .
<b>Language</b>
If you want to change the display language, or you have accidentally changed the language and want to switch it back to English, follow the steps below. 1. <b>MENU</b> -> ▼ 7 times -> <b>SELECT</b> twice. 2. ▼ or ▲ to choose the desired language, or choose <b>English</b> if you want to change the display language to English -> <b>SELECT</b> .

## Telephone operation

Operation	Steps
Making a call	Press <b>\PHONE</b> or <b>☎/SPEAKER</b> -> Enter the telephone number.
On-hook dialing (predialing)	Enter the telephone number -> Press <b>\PHONE</b> or <b>☎/SPEAKER</b> to call.
Answering a call	Press <b>\PHONE</b> or <b>☎/SPEAKER</b> , or press any dialing keys ( <b>0-9</b> , <b>TONE ✕</b> or <b>#</b> ).
Ending a call	Press <b>☎OFF</b> or return the handset to the telephone base or charger.
Speakerphone	During a call, press <b>☎/SPEAKER</b> to switch between handsfree speakerphone and normal handset use.
Redial	Press <b>REDIAL</b> repeatedly to select the desired entry -> <b>\PHONE</b> or <b>☎/SPEAKER</b> to call.
Volume control	Press <b>VOLUME ▼</b> to decrease or press <b>VOLUME ▲</b> to increase the listening volume during a call.
Call waiting (Requires subscription from telephone service provider)	Press <b>\FLASH</b> to put current call on hold and to take the new call; press again to switch back and forth between calls.

## Caller ID

This product supports caller ID services offered by most telephone service providers. The telephone stores caller ID information for the last 50 incoming calls in the telephone base. This information is common to all handsets.

Missed call indicator	
When a handset is in idle mode and has new or missed calls, its screen shows <b>XX Missed calls</b> .	
You can erase the missed call indicator either by reviewing the call log one by one, or by <u>pressing and holding</u> <b>☎CANCEL</b> on the handset in idle mode.	
Review and dial a number in the call log	
1. <b>CID</b> in idle mode -> <b>▼</b> or <b>▲</b> to scroll through the list. 2. <b>\PHONE</b> or <b>☎/SPEAKER</b> to call when the desired entry is displayed.	
Caller ID announce	
When this feature is on and you have an incoming call, the handset and/or base speaks "Call from..." and the name of the caller based on the directory or caller ID information. You can turn this feature off for the base or each individual handset, or both.	
1. <b>MENU</b> -> <b>▼</b> or <b>▲</b> -> <b>Settings</b> -> <b>SELECT</b> . 2. <b>▼</b> or <b>▲</b> -> <b>Caller ID annnc</b> -> <b>SELECT</b> . 3. <b>▼</b> or <b>▲</b> to choose <b>HANDSET</b> or <b>BASE</b> -> <b>SELECT</b> . 4. <b>▼</b> or <b>▲</b> to choose <b>On</b> or <b>Off</b> -> <b>SELECT</b> .	

## Directory

The directory can store up to 50 entries, which are shared by all system handsets.

Operation	Steps
Adding an entry	1. <b>MENU</b> . 2. <b>▼</b> or <b>▲</b> -> <b>Directory</b> -> <b>SELECT</b> . 3. <b>▼</b> or <b>▲</b> -> <b>Add contact</b> -> <b>SELECT</b> . 4. Enter a telephone number up to 30 digits -> <b>SELECT</b> . 5. Enter a name up to 15 characters -> <b>SELECT</b> .
Searching/dialing an entry	1. <b>DIR</b> in idle mode. 2. Press <b>▼</b> or <b>▲</b> to browse through the directory, or press the dialing keys ( <b>0-9</b> ) to start a name search. 3. Press <b>\PHONE</b> or <b>☎/SPEAKER</b> to call.

## Answering system

About answering system and voicemail		
Your telephone has separate indicators for two different types of voice messages: those left on the built-in answering system and those left at your telephone service provider's voicemail. To listen to messages recorded on the built-in answering system, refer to the <b>Message playback</b> section below; to listen to voicemail, contact your telephone service provider for more information.		
Turn answering system on/off		
The answering system must be turned on to answer and record messages. Press <b>☎/ANSWER ON</b> on the telephone base to turn the built-in answering system on or off. When it is turned on, the <b>☎/ANSWER ON</b> light on the telephone base turns on and <b>ANS ON</b> displays on the handset.		
Message alert tone		
When this feature is on, and there is at least one new message, the telephone base beeps every 10 seconds. 1. <b>MENU</b> -> <b>▼</b> or <b>▲</b> -> <b>Answering sys</b> -> <b>SELECT</b> . 2. <b>▼</b> or <b>▲</b> -> <b>Ans sys setup</b> -> <b>SELECT</b> . 3. <b>▼</b> or <b>▲</b> -> <b>Msg alert tone</b> -> <b>SELECT</b> . 4. <b>▼</b> or <b>▲</b> -> <b>On or Off</b> -> <b>SELECT</b> .		
Call screening		
Use this feature to choose whether incoming messages can be heard over the telephone base speaker when they are being recorded. If you turn call screening on, you hear the incoming message. While monitoring an incoming message, you can answer the call by pressing <b>\PHONE</b> or <b>☎/SPEAKER</b> on the handset. 1. <b>MENU</b> -> <b>▼</b> or <b>▲</b> -> <b>Answering sys</b> -> <b>SELECT</b> . 2. <b>▼</b> or <b>▲</b> -> <b>Ans sys setup</b> -> <b>SELECT</b> . 3. <b>SELECT</b> to select <b>Call screening</b> . 4. <b>▼</b> or <b>▲</b> -> choose <b>On</b> or <b>Off</b> -> <b>SELECT</b> .		
Message playback		
<b>Using the telephone base:</b> Press <b>▶/■/PLAY</b> when the telephone base is in idle mode.		
<b>Using a handset:</b> Press <b>MENU</b> twice when the handset is in idle mode.		
Options during playback		
Feature	On the telephone base	On a handset
Adjust playback volume	Press <b>▼/VOL/▲</b>	Press <b>▼VOLUME</b> or <b>▲VOLUME</b>
Stop playback	Press <b>▶/■/STOP</b>	Press <b>5</b>
Skip to the next message	Press <b>▶▶/SKIP</b>	Press <b>6</b>
Repeat the message	Press <b>◀◀/REPEAT</b>	Press <b>4</b>
Play the previous message	Press <b>◀◀/REPEAT</b> twice	Press <b>4</b> twice
Delete the message	Press <b>X/DELETE</b>	Press <b>DELETE</b>

For more detailed instructions, please refer to the Abridged user's manual provided in your package, or for a full set of installation and operation instructions, refer to the online **CL82101/CL82201/CL82301/CL82351/CL82401/CL82451/CL82501/CL82551/CL82601 DECT 6.0 cordless telephone/answering system with caller ID/call waiting** Complete user's manual at [www.telephones.att.com/manuals](http://www.telephones.att.com/manuals).

For customer service or product information, visit our website at [www.telephones.att.com](http://www.telephones.att.com) or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.