



Quick start guide

**TL72108/TL72208/**

**TL72308/TL72408**

**5.8 GHz cordless**

**telephone/answering system**

**with caller ID/call waiting**



# Installation preparation

You must install and charge the handset battery before using the cordless handset.



**See page 2**  
for easy instructions.

If you subscribe to high-speed Internet service (Digital Subscriber Line - DSL) through your telephone lines, you must install a DSL filter between the telephone base and the telephone wall jack (see page 2). The filter will prevent noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters.

Your product may be shipped with a protective sticker covering the handset or telephone base display - remove it before use.

For customer service or product information, visit our website at **[www.telephones.att.com](http://www.telephones.att.com)** or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.

## **Avoid placing the telephone base too close to:**


- Communication devices such as: television sets, VCRs, or other cordless telephones.
- Excessive heat sources.
- Noise sources such as a window with traffic outside, motors, microwave ovens, refrigerators, or fluorescent lighting.
- Excessive dust sources such as a workshop or garage.
- Excessive moisture.
- Extremely low temperature.
- Mechanical vibration or shock such as on top of the washing machine or work bench.

# Telephone base and charger installation

If you subscribe to high-speed Internet service (Digital Subscriber Line - DSL) through your telephone lines, you must install a DSL filter between the telephone base and the telephone wall jack. The filter will prevent noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters.

Install the telephone base as shown below.

1. Plug the small end of the larger power adapter into the power jack at the bottom of the telephone base.



2. Plug one end of the telephone line cord into the telephone jack at the bottom of the telephone base.

3. Route cords through slots.

Telephone line cord

DSL filter (not included), required if you have DSL high-speed Internet service.

Telephone wall jack

Power adapter

5. Plug the other end of the telephone line cord into a telephone jack.

4. Plug the large end of the larger power adapter into a power outlet not controlled by a wall switch.

## Charger installation

1. Plug the small end of the smaller power adapter into the jack on the underside of the charger, then route the cord through the slot as shown.



2. Plug the large end of the smaller power adapter into a power outlet not controlled by a wall switch.


## IMPORTANT INFORMATION

1. Use only the power adapter supplied with this product. To order a replacement power adapter, visit our website at [www.telephones.att.com](http://www.telephones.att.com), or call **1 (800) 222-3111**. In Canada dial **1 (866) 288-4268**.
2. The power adapters are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.

## Battery installation & charging

Install the battery as shown below. After installing the battery, you can make and receive short calls, but replace the handset in the telephone base or additional charger when not in use. For optimal performance, charge the handset battery for at least 16 hours before use. When fully charged, the handset battery provides approximately five hours of talk time or three days of standby time.

If the battery is depleted, it may take approximately four minutes to charge the handset before it can resume screen display. The screen will continue to display **LOW BATTERY** until the battery has charged for approximately one hour.



### Step 1

Plug the battery securely into the plug inside the handset battery compartment, matching the color-coded label.



### Step 2

Insert the supplied battery with the label **THIS SIDE UP** facing up as indicated.



### Step 3

Align the cover flat against the battery compartment cover, then slide it upwards until it clicks into place.

### Step 4

Charge the handset by placing the handset face up in the telephone base or in the additional charger. The **CHARGE** light will be on when charging.



## IMPORTANT INFORMATION

Use only the battery supplied with this product. To order a replacement or spare battery (AT&T model 27910, part number 89-0099-00-00) or equivalent, visit our website at [www.telephones.att.com](http://www.telephones.att.com), or call **1 (800) 222-3111**. In Canada dial **1 (866) 288-4268**.

# Quick reference guide - handset

## CHARGE

On when the handset is charging in the telephone base or charger.

## CID

Press to display caller ID information.

## PHONE/FLASH

Press to make or answer a call.  
During a call, press to receive an incoming call if call waiting is activated.

## REDIAL/PAUSE

Press to view redial memory.  
While entering numbers, press and hold to insert a dialing pause.

## MUTE/REMOVE

During a call, press to mute microphone.  
While reviewing the caller ID history, press to delete an individual entry, or press and hold to clear the caller ID history. While predialing, press to delete digits.

## SPEAKER

Press to turn on the handset speakerphone.  
Press again to resume normal handset use.



Press or to scroll up or down while in menus.  
While entering names or numbers, press or to move the cursor to the left or right.

## MENU/SELECT

Press to enter the menu.  
While in the menu, press to select an item or save an entry or setting.

## DIR

Press to display directory entries.

## VOLUME ▼▲

Press the volume key on the side of the handset to adjust listening volume.  
Each press of the button increases or decreases the volume.

## OFF/CLEAR

During a call, press to hang up.  
While using menus, press to cancel an operation, back up to the previous menu, or exit the menu display.

## INT

Press to begin an intercom conversation or to transfer a call.

## Feature menu

The > symbol shows a highlighted menu item.



## Feature menu

DIRECTORY  
CALL LOG  
RINGER VOLUME  
RINGER TONE  
KEY TONE  
LANGUAGE  
CLR VOICE MAIL

## Using menus

Press or to scroll through menu items.

Press **MENU/SELECT** to select or modify a highlighted item.

Press **OFF/CLEAR** to cancel an operation, back up to the previous menu, or exit the menu display.

# Quick reference guide - telephone base

## IN USE

- On when handset is in use, when the answering system is answering an incoming call or when you are registering a handset.
- Flashes when another telephone is in use on the same line or when you are deregistering handset(s) from the telephone base.
- Flashes quickly when there is an incoming call.



## VOICEMAIL

Flashes when you have new voicemail. Voicemail is a service offered by your local telephone company, and is different from answering system messages.

## HANDSET LOCATOR

Press so that handsets will beep to locate misplaced handsets.

## Answering System Functions

### MESSAGE COUNTER

Number of messages (or during playback, message number currently playing).

### ◀/REPEAT

Press to repeat message. Press **twice** to play previous message.

### ANSWER ON

Press to turn answering system on or off.

### CLOCK

Press to review or set clock.

### SETUP

Press to hear and change setup options.

### ANNC.

Press to review or record outgoing announcement. Press again to end announcement playback or recording.



### ▶/■ PLAY/STOP

Press to start or stop message playback.

### X/DELETE

Press to delete the message currently playing. When no messages are playing, press twice to delete all old messages.

### ▶▶/SKIP

Press to skip message.

### VOLUME

Press to adjust playback volume.

### RECORD

Press to record a memo or, after pressing **ANNC.**, to record an outgoing announcement.



[www.telephones.att.com](http://www.telephones.att.com)