



INDeX 10.0

2030/50/60 User's Guide

Contents

Introduction	5
Using This Guide	5
What Features Can I Use?	5
Further Help	5
Display Phone Features	6
Introduction to Display Phones	6
Using Soft Keys and the SCROLL Key	6
On-Hook Dialling, Speaker & Answer Release	7
Tones & Ringing	7
The Phone Lamp	7
Making Calls	8
Notes on Making Calls	8
Making Internal Calls	8
Making a Page Call	8
Making External Calls	9
Redialling External Numbers	9
Making Calls from the INDeX Directory	10
Speed Dials	11
Using Speed Dials	11
Storing Personal Speed Dials	11
PIN & Account Codes	12
If ENTER ACCOUNT Appears	12
If ENTER PIN Appears	12
Roaming PIN's	12
Busy or Unanswered	13
Options If Busy or Unanswered	13
Arrange a Callback	13
Leave a Message	14
Camp On and Wait	14
Intrude	14
Monitoring a Call	14
Actions During a Call	15
Create a Conference Call	15
Using the Notepad	16
Switching to Handsfree	16
Changing the Call Volume	16
Adding Voluntary Account Codes	17
Software Release	17
Muting Calls	17
Recall	17
Answering Calls	18
Answering Normal Calls	18
Answering a Page Call	18
Answering a Message	18
Alarms - Triple Ring, Music or Recorded Message	18
Answering a Callback	19
Answering Other Extensions - Call Pickup	19
Automatic Calls - Hotline Operation	19
Automatic External Call Connection	19

Contents (Cont.)

Transfer, Park & Hold Calls	20
Transferring Calls.....	20
Holding Calls.....	20
Parking Calls.....	21
Dialling Ahead.....	21
Diverting Calls.....	22
Using Diverts.....	22
Setting the Divert Types and Personal Numbers	24
Switching Divert All On/Off.....	25
Switching No Calls On/Off.....	25
Displaying an Absence Message	26
Forwarding Calls	26
DSS Keys	27
Setting Up a DSS Key.....	27
Using DSS Keys.....	27
BLF Status Lamps.....	28
DSS Key Label.....	28
DSS Key Label Template	28
Interruptions During a Call	29
Answering a Call Waiting	29
Answering an Alert	29
Single Pips - Intrusion	29
Please Finish Call Message	29
ACD Working.....	30
ACD on 2050 Phones?.....	30
Starting ACD Working - Logging On	30
Stopping ACD Calls Temporarily - Busy.....	30
Finishing ACD Working - Logging Off.....	30
Manager-Secretary Setup	31
Planning Soft DSS Keys.....	31
Setting Up Soft DSS Keys.....	31
Changing the Soft DSS Display Mode.....	32
Changing the Soft DSS Extensions.....	32
Changing the Soft DSS Usage.....	32
Manager-Secretary Working.....	33
Using Soft DSS Keys	33
Soft DSS Key Display.....	33
Making Calls.....	33
Park Transferring Calls.....	34
Alerting a Busy Extension	34
Remotely Switching No Calls/Divert On/Off	34

Contents (Cont.)

Ringer Controls	35
Changing the Ringer Volume	35
Changing the Ringer Sound	35
Switching the Ringer On/Off.....	35
Setting a Ringer Step	36
Setting the Ringer Timeout.....	36
Other Features	37
Personal Alarms.....	37
Missed Calls.....	38
Group	38
Hot Desking.....	39
Phone Settings	40
The Phone Passcode	40
Background Music.....	40
Displaying Phone Details	41
Locking/Unlocking the Phone.....	41
Language Controls	41
Voice Manager	42
Voice Manager Functions.....	42
Listening to Voice Messages.....	42
Using Any Phone	42
Modifying Your Mailbox	43
Changing Your Temporary Greeting	43
Dial 1 Divert for Incoming Calls	44
Leaving Voice Mail Messages.....	44
System Manager Phones	45
What are System Manager Phones?	45
Night Service.....	45
Changing the Time.....	45
Unlocking a Phone	45
Changing the Date	46
Recording ACA Messages	46
Good Phone Usage	47
General Phone Usage.....	47
Answering Calls	47
Making Calls.....	47
Glossary	48
Index	49

Introduction

Using This Guide

This guide is for INDeX 2030, 2050 and 2060 telephones used on the INDeX telephone system operating under **Software Release 10.0**.

To check the Software Release of your system, press **ANSWER/RELEASE** and then **PROGRAM**. The phone displays the Software Release. Cancel the display by pressing **ANSWER/RELEASE** again.

2060 Telephone Software

This guide covers the normal telephone functions of the 2060 telephone. Details of using its TAPI driver with software on your PC is covered by a separate 2060 Software Addendum. Obtain copies from your System Manager or download them from our Internet site <http://support.avaya.com>

What Features Can I Use?

This guide covers all the features supported by the INDeX 2030, 2050 and 2060 phones. However, your phone may not be enabled to use all of the features available. If you are unsure which features you can use, contact your System Manager.

- **Network Features:**

Your phone system may be part of a network linking several sites. Where possible, it treats network calls as internal calls and offers the same features. However, this depends on the type of network link and type of system at the other end of the link. Some links may be to non-INDeX telephone systems.

Further Help

In all instances, first seek help from your System Manager. They will seek further assistance from your system's Maintainer if necessary.

System Manager on extension:

This guide is also available from our Internet site
<http://support.avaya.com>

Display Phone Features

Introduction to Display Phones

The diagram shows the main features of a display phone; the term covers INDeX 2030, 2050 and 2060 phones.



- **2060:** Phone with handsfree operation, DSS keys and BLF status lamps (see page 27). A serial socket and cable for connection to a PC is also included. Use of the 2060 software is covered by a separate 2060 Software Addendum.
- **2050:** Similar to 2060 but without a serial socket.
- **2030:** Similar to 2050 but without BLF status lamps.

Using Soft Keys and the SCROLL Key

The four lower Display Keys provide access to Soft Keys functions, e.g. Voice, Page, INDeX, etc. There are sometimes more Soft Key options available than the phone can display. When this happens, a ●-symbol appears next to the **SCROLL** key. Press **SCROLL** to display these other options.

The Soft Key displays change during calls and will also change according to your own customisation. A ●-symbol next to a display key indicates an option you can use by pressing that key. Therefore, due to the number of variations involved, this guide cannot always detail when you would have to press the **SCROLL** key to access a function.

Your System Manager can disable any one or all of the following Soft Keys: **VOICE, PAGE, ACCOUNT, RECORD, RECALL, CAMP-ON, MESSAGE, OVERRIDE and PASS.**

On-Hook Dialling, Speaker & Answer Release

On all INDeX telephones you can both dial and hear the call progress without using the handset (known as "on-hook dialling").

When answered, you can continue the call without using the handset, i.e. handsfree. You can switch between handsfree and handset working during a call.

Pressing the **ANSWER/RELEASE** key has the same effect as lifting or replacing the handset.

Tones & Ringing

The phone uses various tones and rings to indicate events. A sample of these appears below. You can alter the ringer volume, sound, switch it on/off, etc (see page 32).

Incoming Calls:

- **Repeated Single Ring:** Internal call.
- **Repeated Double Ring:** External call.
- **Repeated Triple Ring:** System or personal alarm.
- **Single Tone:** Page call (see page 18).

During Calls:

- **Repeated Double Pip:** You have set a camp on (see page 14).
- **Repeated Single Pip:** Another extension is about to intrude or has intruded on your call.

Making Calls:

- **Dial Tone:** Dial number.
- **Broken Dial Tone:** Phone on divert or no calls (see page 22).
- **Repeated Tone:** Busy number (see page 13).
- **Triple Tone:** Call diverting to external number.
- **Continuous Tone:** Number called unobtainable or set to no calls. Phone locked or barred.

The Phone Lamp

The phone uses its lamp (above the **SPEAKER** key) to show calls and messages.



Fast Flashing Lamp: Call Waiting, see page 29.



Lamp On: Message, see page 18.



Repeating Double Flash: External call.




Repeating Single Flash: Internal call.

Making Calls

Notes on Making Calls

When making calls, the display shows details about call progress. It also shows messages if you cannot make the call.

- **Call barring:**

The system can bar you from dialling particular numbers or types of number (e.g. national, international). Typically call barring increases when a phone goes into night service (when it displays a  symbol). It also changes according to time, date and day of the week. As the call barring settings vary for each site, this guide cannot fully detail their effect.

Making Internal Calls

During the call, the display shows the call progress. You can also make calls using the **•INDeX** Directory feature (see page 10) or DSS keys (see pages 27 & 30).

To dial an internal call:

1. Dial the extension number. A triple-tone means that extension is diverting calls to an external number.
2. If unanswered, your phone provides options to wait or notify the extension (see page 13). If your system has a Voice Manager attached, you can record a voice message instead (see page 44). The Voice Manager may also instruct you to dial another number to be automatically transferred to the Operator or another extension.
3. If answered, use the handset or work handsfree.
 - If your phone displays a **•RINGER** option then the called extension is set to automatically connect internal calls.
Press **•RINGER** to send a reminder ring if no one has answered the call.

Making a Page Call

You can page any INDeX phone or group. They hear the call without doing anything though you cannot hear them. They can also turn the page into a normal call (see page 18). If the phone paged is diverting calls, the page also diverts (except group pages).

To page an extension or group:

1. Press **•PAGE**. Your phone displays **PAGING**.
2. Pickup the handset or talk handsfree.
3. Dial the number or press a DSS key (see page 27).
4. If busy or unavailable, the display shows options to wait or leave a message (see page 13).
5. Speak and then press **ANSWER/RELEASE**.

Making External Calls

The system may apply call barring to some or all external numbers. You can also lock your phone (*see page 41*) or bar it by wrong passcode entry (*see page 40*).

To dial an external call:

1. Dial **9** to get an external line. Your System Manager will inform you if you need to dial a different number.
 - If "**ENTER ACCOUNT**" appears, see page 12.
 - If "**ENTER PIN**" appears, see page 12.
2. Dial the external telephone number.
 - If "**CALL BARRED**" appears check with your system manager.
3. When answered, use the handset or work handsfree.

Redialling External Numbers

You can either redial the last external number dialled, select from one of the last five external numbers dialled or save the last external number dialled. Please note that you have a maximum of five redial stores that are shared by both *save last external number* and *Notepad* numbers, e.g. Three *saved last external* numbers and two *Notepad* numbers (*see page 16*).

To redial the last external number used:

1. Press **REDIAL** to repeat the last external number used (including speed dials).

To save the last external number used:

1. Whilst making an external call, press **•SAVE**. This stops the number being removed as you make further external calls until you choose to press **•DELETE**. The dialled numbers facility stores a maximum of five numbers including both Notepad and saved last external numbers (*see page 16*).

To redial one of the last five external numbers used:

1. Press **SPEED DIAL** and then **•DIALLED** and select from the last five stored numbers (move between them by pressing the lower left and right **•** symbols). When the number you require is shown press **•CALL**.

Making Calls from the INDeX Directory

Using the INDeX Directory, your phone can display a selected entry from an index of either extensions or speed dial names plus their numbers. There are two methods of selecting entries of names and numbers from the INDeX Directory:

- **By Alpha Group**
- **By Dial by Name**

In addition, the INDeX Directory entries can be sorted either by 1st name or by last name. The particular method used and 1st or last name search is selected by your System Manager. Consult your System Manager for which method is available to you and if the sorting is by 1st or last name.

To make a call using an Alpha Group search of the INDeX:

1. Press **●INDeX** for an internal call or **SPEED DIAL** and then **●INDeX** for an external number.
2. Press the key matching the 1st letter of the name you want.
For example, to display the **L** Alpha Group, press the **JKL** key 3 times. The INDeX System displays the 1st name beginning with **L** from it's Directory entries.
 - To move through the names beginning with **L**, press the **●**-keys on the right and left of the current name.
 - To skip forward 10 names, press **●SKIP**.
 - To select another letter, press a letter key.
3. To dial the name/number shown, press **●CALL**, otherwise to exit the INDeX Directory, press **ANSWER/RELEASE**.

To make a call using Dial by Name search of the INDeX:

1. Press **●INDeX** for an internal call or **SPEED DIAL** and then **●INDeX** for an external number.
2. Press the key matching the 1st letter of the *Name* you want.
For example, to find the name **SMITH** press the **PQRS** key.
3. The INDeX System begins searching it's Directory on the first press and will display the 1st name/number immediately, in this example a name beginning with **P**. You can either:
 - Continue dialling the letters of the name, e.g. **MNO**, then **GHI**, etc. until the required name (**SMITH**) is displayed **OR**.
 - Press **CYCLE** to move onto the next alpha group of the **PQRS** key, e.g. a name beginning with **Q**. To move through the names beginning with **Q**, press the **●**-keys on the right and left of the current name.
 - To select the next letter of the alpha group of the **PQRS** key, press **CYCLE** again.
 - If **NO MATCH** is displayed, press **PREVIOUS** to go back one step or press **ANSWER/RELEASE** to cancel.
4. To dial the name/number shown, press **●CALL**, otherwise to exit the INDeX Directory, press **ANSWER/RELEASE**.

Speed Dials

Using Speed Dials

The system can store external numbers as speed dials.

- **System speed dials:** Ask your System Manager for a list.
- **Personal speed dials:** Your phone can also store up to 10 speed dials for your own use (*see below*).

To dial a system speed dial by name:

1. Use the ●**INDeX** feature (*see page 10*).

To dial a speed dial:

1. Press **SPEED DIAL**.
 - **To select a personal speed dial :** Press ●**OWN** and dial the personal speed dial store number (0 to 9) or press the matching DSS key (*the DSS keys match personal speed dials 1 to 8 (1 at the top)*).
 - **To select a system speed dial by number :** Press ●**SYSTEM** and dial the store number (100 to 899 and 9000 to 9999).
 - **To select a system speed dial by name :** Press ●**INDeX**. To enter the name *see page 10*.
 - **To select from recently dialled numbers :** Press ●**DIALLED**. See "Redialling External Numbers" on page 9.
 - If "ENTER ACCOUNT" appears, *see page 12*.
 - If "ENTER PIN" appears, *see page 12*.
2. Continue as for a normal external call (*see page 8*).

Storing Personal Speed Dials

To store a personal speed dial:

1. Press **PROGRAM** and then **SPEED DIAL**.
2. Enter your passcode (*see page 40*).
3. The display shows **0-9 OR DSS KEY**. Press the number (**0 to 9**) or DSS key under which you want to store the speed dial.

Note: DSS key 1 matches personal speed dial number 1, DSS key 2 matches personal speed dial number 2, etc.
4. The display shows the current stored number (if set). Press ●**DELETE** and dial the number.
If the number is external, add the external line access prefix to the number, this is normally 9. Your System Manager will inform you if you have to add a different prefix before external numbers.
5. When finished, press ●**DONE**.
6. Select another store or press **PROGRAM** to finish.

PIN & Account Codes

If ENTER ACCOUNT Appears

If **ENTER ACCOUNT** appears when making an external call, you must enter an account code to continue. The system checks this against its list of codes before allowing the call.

To enter an account code at any time during a call, see page 17.

To enter a forced account code:

1. Dial the account code. If you make a mistake, press **●DELETE** to delete the last digit entered.
2. When you have entered the full code, press **●DONE**.
3. If the system does not recognise the code it displays **REENTER ACCOUNT**. Repeat the entry or end the call.
4. If the code is recognised, your call can continue.

If ENTER PIN Appears

If **ENTER PIN** appears when making an external call, you must enter a PIN code to continue. When used, the PIN code's call barring settings override those of the phone from which you dial. The system checks the code against its list of codes before allowing the call.

To enter a forced PIN code:

1. Dial your **PIN** code. If you make a mistake, press **●DELETE** to delete the last digit entered.
2. When you have entered your **PIN** code, press **●DONE**.
3. If the system does not recognise the code it gives a constant tone. End your call attempt.
4. If the code is recognised, your call can continue.

Roaming PIN's

When you use a PIN code, its settings override those of the phone from which you dial. Note however that the system prefixes digits to force the call externally.

To use a roaming PIN:

1. Press **#** and enter your PIN code. If you make a mistake, press **●DELETE** to delete the last digit entered.
2. When you have entered your **PIN** code, press **●DONE**.
3. If the system does not recognise the code, your phone gives a constant tone. End your call attempt.
4. If the code is recognised, your call can continue.

Busy or Unanswered

Options If Busy or Unanswered

Your phone provides several methods for contacting an extension that is busy, not answering or set to no calls. These options work for normal, page and diverted calls.

- **Leave a Message**: Lights the lamp of the extension called. It also stores your number as a message to reply. If your system has a Voice Manager attached, you can record a voice message instead (see page 44). The Voice Manager may also instruct you to dial another number to be automatically transferred to the Operator or another extension.
- **Callback**: Rings your phone when the extension called becomes free or is next used.
- **Camp On**: Flashes the extension's lamp to warn that you are waiting. It also stops other calls interrupting you.
- **Intrude**: Forces the other extension's call into a conference with you (*not available to all phones*).
- **Monitor**: Allows you to hear the other call without interrupting it (*not available to all phones*).

Arrange a Callback

If the extension you call is busy or just rings, you can set a callback. When that extension becomes free or is next used, your phone rings. If you answer, the other extension rings. After setting a callback you can make other calls, it will not take place while you are busy. You can only arrange one callback at any time.

The Ringer Timeout sets how long a callback rings your extension before it cancels (see page 36). The system also cancels any callbacks that have not taken place after a set period (*normally 2 hours*).

To arrange a Callback:

1. Press **●CALLBACK** (the option does not appear if you already have a callback set).
2. The system ends the call.
3. Your phone shows **●CALLBACK**.

To clear the Call Back:

1. Press **●CALLBACK** again

Leave a Message

You can leave your extension number as a message for someone to call you (see page 18). If their extension has a message lamp, it lights (*supported INDeX phones*). If your call is diverted, the message goes to the extension you first called.

To leave a message:

1. Press **●MESSAGE**. Your call ends unless the extension called has already reached its limit of stored messages.

Camp On and Wait

If the extension you call is busy, you can 'camp on' and wait. This flashes the lamp on the busy extension and if it has a suitable display, shows your name, number and **CALL WAITING**. While camped on your phone gives regular pips and you cannot make or receive other calls.

To Camp On to a busy extension:

1. Press **●CAMP ON**.
2. To replace the handset without cancelling the camp on, press **SPEAKER** first.
3. To end the camp on, press **ANSWER/RELEASE** or replace the handset.

Intrude

If your phone can intrude, an **●INTRUDE** option appears when calling a busy extension. Your System Manager controls which extensions can intrude and be intruded on.

To intrude on a call:

1. Press **●INTRUDE**.
2. There is a short delay during which you and the other parties hear several short pips.
3. After the intrusion, the system gives regular pips.

Monitoring a Call

Silent monitoring lets you listen to another call without being heard. Note that there are restrictions on who can use this function (contact your System Maintainer). If your phone can use silent monitoring, a **●LISTEN** option appears.

Actions During a Call

Create a Conference Call

You have two methods of holding conference calls.

- During a call, you can add callers to create a conference.
- Alternatively, you can dial-in to a conference call being held at a pre-defined time. The numbers and passwords (optional) used for dial-in conferences are established by your System Manager. External callers can join dial-in conferences, but they must dial in to the INDeX and request a transfer to the dial-in conference.

Both types of conference calls can have up to 64 participating members.

External Lines:

If your exchange uses digital lines, you can conference several of these with internal parties. However, if your exchange uses any other type of line, you can only include one of those in a conference. Check with your System Manager for details.

To start or add to a conference:

1. During a call, press **HOLD** to hold your current call (or conference).
2. Call the new person that you want in conference.
3. If answered, ask if they wish to join a conference.
If "yes" press **●CONFER**.
If "no" and you clear down first, press **SCROLL●**, **CLEAR●** and then **HOLD** to retrieve the first call.
If "no" and called party clears down first, then press **HOLD** to retrieve the first call.
4. If unanswered, press **HOLD** to retrieve to the first call.

To exit the conference:

1. Press **ANSWER/RELEASE** or replace the handset.

To park all the conference parties:

1. Press **●PARK** (see page 21).

To split a 3-way conference:

1. Press **●SPLIT** to hold one caller and connect to another call.
2. To switch between calls, press **HOLD**.

Starting/Joining a dial-in conference:

1. To initiate a dial-in conference call, dial the conference call number and press **●SET UP**. You may be asked for a password.
*If **PASS●** is also displayed, then you can change the password.*
2. To join a dial-in conference call, dial the conference call number and press **●JOIN**. You may be asked for a password.
3. As new members join the conference, you will hear two bleeps.
4. At any time during the conference you can press **●VIEW** to display the extension number of the last member to join.
5. Tapping **●VIEW** will cycle through all of the extension numbers of the members of the conference call.
6. Press **ANSWER/RELEASE** or replace the handset to exit.

Using the Notepad

Whilst on an external call or listening to a Voice Mail message, you can store a number for future use on the Notepad. Please note that you have a maximum of five redial stores that are shared by both *save last external number* and *Notepad* numbers, e.g. Three *saved last external* numbers and two *Notepad* numbers (see page 9).

To store number on the Notepad:

1. When, with an external call in progress or whilst listening to a Voice Mail message, you wish to store another external number, press **SCROLL** and **●NOTEPAD**.
2. Key the external number (do not add the access prefix, this is automatically added when the number is recalled from storage).
3. Press **●DONE** to store the number.

To dial a number from the Notepad:

1. Press **SPEED DIAL** and then **●DIALLED** and select from the last five stored numbers (move between them by pressing the lower left and right **●** symbols). When the number you require is shown press **●CALL**.

Switching to Handsfree

You can switch between handsfree (speaker) and handset operation without interrupting the call.

To switch from the handset to speaker:

1. Press **SPEAKER**.
You can now replace the handset without ending the call.

Changing the Call Volume

You can change the caller volume during a call. The phone has separate volume levels for both the speaker and the handset.

To change the call volume:

1. During a call, press **●VOLUME**. (To change volume without making a call, lift the handset or press **ANSWER/RELEASE** first).
2. A slider appears. Adjusts this using the **●**-keys on its left (softer) and right (louder).
3. When finished, press **●DONE**.

Adding Voluntary Account Codes

You can enter an account code during any external call. If the system records the call on its call log, it includes the account code. The system checks the code against its list of valid codes (*ask your System Manager for a copy*).

To enter a voluntary account code:

1. During the call, press **●ACCOUNT**.
2. Enter an account code. If you make a mistake, press **●DELETE** to delete the last digit entered.
3. When you have entered the full code, press **●DONE**.
4. If the system does not recognise the code, the phone displays **RE-ENTER ACCOUNT**.

Software Release

Occasionally you may need to talk to someone for support about your phone or phone system. It may be useful to tell that person what software your phone system uses.


To display the software release:

1. During a call, press **PROGRAM**, the phone displays the software installed on your system. To do this without making a call, just press **ANSWER/RELEASE** first.
2. Press **SCROLL** to return to the normal display.

Muting Calls

You can stop the caller from hearing you if necessary. This feature works for both handsfree and handset calls.

To switch mute on/off:

Press **MUTE**. The -symbol disappears when muted.

Recall

Your phone system may connect to another phone system by a fixed line (tie line). If this is the case, you may occasionally need to use a 'recall' (your System Manager will advise). To do this, **●RECALL** appears when necessary. You may also use **●RECALL** to switch from Dial Ahead to sending tones on incoming calls.

Answering Calls

Answering Normal Calls

When calls arrive, the display shows information about the call before you answer. It gives a repeated double flash for external calls or a repeated single flash for internal calls. The ringer also shows the call type by a repeated single or double ring if on (see page 35).

To answer the call:

1. Lift the handset or press **ANSWER/RELEASE**.

Note: For automatic External call connection, your System Manager can set a turret to free flow mode (see page 19).

Answering a Page Call

When someone pages your phone (see page 8) or a group to which it belongs (*your phone does not have to be in group*), the system connects the page after giving a tone. You can hear the page but they cannot hear you. The display shows **PAGING** and the pager's number. If you answer a page it turns into a normal call.

To answer a page:

1. Press **ANSWER/RELEASE** and then pickup the handset or continue the call handsfree. Note that this feature can be switched off for the whole system.

Answering a Message

Other extensions can leave their number on your phone (see page 14). Your phone can store several messages. It shows **CALL FOR MESSAGE**, the caller's number and the lamp comes on. The exceptions are:

- If your own number appears, this indicates an alarm (see page 18).
- If **Message From Voice Mail** appears, this indicates that you have new voice mail (see page 42).

To answer or cancel a message:

- To view any other message, press ●**NEXT** if shown.
- To call the extension, press ●**CALL**.
- To clear the message, press ●**CANCEL**.
- At the last message, press ●**AGAIN** to repeat the list.

Alarms - Triple Ring, Music or Recorded Message

You can set a personal alarm to ring your phone (see page 37). The System Manager can also set system alarms to call a group to which you belong (*your phone does not have to be in group*). In both cases, the alarm can consist of ringing, music or a recording plus a displayed message.

To answer an alarm:

1. Press ●**CANCEL** or **ANSWER/RELEASE**.

Answering a Callback

You can arrange a callback from a busy or ringing extension (see page 13). When the callback takes place, your phone displays the call details, "CALLING" and ●CALLBACK. If you do not answer, the callback cancels after a short time (see page 36).

To answer/cancel a call back:

1. To continue the callback, press ANSWER/RELEASE.
2. To cancel the callback, press ●CALLBACK.

Answering Other Extensions - Call Pickup

You can pickup an incoming call to any other extension regardless of whether or not the other extension is in your group. In addition, your extension can store a pickup group number (see below). If an extension in your pickup group rings then the ●PICKUP option appears. You can also pickup calls using DSS (see page 27) or Soft DSS keys (see page 30).

To show and pick up any ringing phone:

1. When you hear another extension ringing, dial it's number and then press ●PICKUP.

To pick up external calls in your pickup group:

1. Press ●PICKUP to show the longest ringing call.
2. Press the ●-symbol (if shown) opposite the name to switch between details of the caller and called party.
3. To show other ringing phones, press ●NEXT (if shown).
4. To pick up the call shown, press ANSWER/RELEASE.
5. To cancel the pickup display, press ●CANCEL.
6. To repeat the list press ●AGAIN.

To set the phone's pickup group:

1. Press PROGRAM and then SCROLL. Press ●PICKUP.
2. Enter your passcode (see page 40).
3. The display shows PICKUP GROUP and the current pickup group's number (if set).
4. Press ●CANCEL and enter a new pickup group number.
5. Press ●DONE and then PROGRAM to finish.

Automatic Calls - Hotline Operation

Hotline operation allows a phone to automatically dial a number when left off-hook for a set period. Your System Manager or maintainer controls this feature.

Automatic External Call Connection

The System Manager can set a turret to free flow mode. In this mode, the system connects external calls automatically after giving a single tone (but not transferred external calls). After ending a call, the system waits 3 seconds before connecting the next call.

Transfer, Park & Hold Calls

Transferring Calls

You can transfer a call to an extension that is ringing or giving busy tone. If the call waits unanswered for too long, it may recall to your extension.

To transfer a call using hold:

1. Press **HOLD** to hold your current call.
2. Dial the extension to which you want to transfer the call.
 - **Announced transfer:** Wait to be answered.
If unanswered, press **HOLD** to retrieve to the first call.
If okay to transfer, press **ANSWER/RELEASE**.
If not okay to transfer and you clear down first, press **SCROLL●**, **CLEAR●** and then **HOLD** to retrieve the first call.
If not okay to transfer and called party clears down first, then press **HOLD** to retrieve the first call.
 - **Unannounced transfer:** Press **ANSWER/RELEASE** immediately (even if you hear ringing or busy tone).

To transfer a call using dial ahead:

1. Whilst still connected to the other party, either dial the number of the other extension or press **HOLD** and use the Directory feature (see page 10).
2. If the display shows **FREE**, press **ANSWER/RELEASE** to transfer, otherwise press **●CANCEL**.

To transfer an external call using park:

1. Press **●PARK** to park the current call. Note the line number of the call and give this to the person whom you want to unpark the call (e.g. by calling or paging them).

Holding Calls

Only the extension that holds a call can retrieve it unless they transfer the call. When you hold a call, your phone shows its details on the right of the display and the caller hears music (*if installed*). You can only hold one call.

To hold a call:

1. Press **HOLD** (Pressing **ANSWER/RELEASE** now or replacing the handset parks the call, see page 21).
2. Retrieve the call by pressing **HOLD** again or make another call (enquiry call) and then:
3. Press the **●**-symbol (if shown) opposite the name to switch the display between the current and the held call details.
 - To switch between calls, press **HOLD**.
 - To conference, press **●CONFER** (see page 15)
 - To transfer the held call, press **ANSWER/RELEASE**.

Parking Calls

You can retrieve parked calls at any other extension on the system. Your phone displays calls you parked by a flashing ●-symbol next to the line number. You can park several calls simultaneously. Calls parked and not retrieved may recall your phone after a short time.

To park an external call:

1. During the call, press ●**PARK**.

To unpark calls parked at your extension:

1. Press the display key next to the flashing ●-symbol.

To unpark a call at another extension:

1. Dial the parked call's line number (*external calls only*).

Dialling Ahead

Whilst on an incoming call you can display the status of another extension (or group) without interrupting your call.

To check the status of another extension during a call:

1. Either, press ●**INDeX** and obtain required number from the Directory by keying name (see page 10) or, if you know the number, simply dial.
2. The extension's status appears on the right-hand display; **FREE**, **BUSY** or **NU** (Number Unobtainable).
3. Dial another number or press **CANCEL**.

If the extension displayed is free:

1. For an unannounced transfer, press **ANSWER/RELEASE**.
2. To make an enquiry, press **HOLD**. This holds your current caller and rings the dial ahead extension.
3. If unanswered, press **HOLD** to retrieve your first call.
4. If answered, either press **ANSWER/RELEASE** to transfer your call or press **HOLD** again to switch between calls.

You can set your phone to always automatically hold your current call and ring the dial ahead number if it is free (rather than display **FREE**).

To select show free or ring if free:

1. Press **PROGRAM** and then **SCROLL**. Press ●**CALLFREE**.
2. Enter your passcode (see page 40).
3. To change the current setting, press ●**CHANGE**.
4. Press ●**DONE** and then press **PROGRAM** to finish.

Diverting Calls

Using Diverts

Your phone can store divert destination personal numbers for different situations, i.e. when busy, not answering and to when you wish to divert all calls. For each situation you can divert to both frequently used divert destinations as well as infrequently used destinations. The divert types are:

Divert Types

- **Divert All:** Used with the **DIVERT** key. When on, only the extension to which you diverted to can ring you.
- **Divert on Busy:** Used when your phone is on a call. When set, callers cannot set a callback or camp on.
- **Divert on No Answer:** Used after a call rings your phone for a set period (see page 36).

Divert All is only activated by pressing the **DIVERT** key. *Divert on Busy* and *Divert on No Answer* are, once set are always active. See page 23 for instructions on setting up these divert destinations. In addition, you can use either:

- **No Calls:** Stops **all** calls. Callers hear continuous tone or can be diverted to the **Divert All** number if set (see page 25).
- **Remote forward:** This feature must be permitted by the System Manager. Allows you to remotely change your **Divert All** number and switch **DIVERT** on/off (see page 26).

Divert Destinations

Divert destinations can be to your **HOME, MOBILE, DELEGATE**(secretary, etc.), **VOICE , OTHER** or a system speed dial number (see page 23). These divert destinations are known as *Personal Numbers* and can be set from your phone as frequently used or infrequently used destinations. Hence, you choose when and where you want to receive your calls.

Personal Number Divert Settings

When setting personal number diverts to Mobile/Home destinations the following general points should be considered:

- If your Home or Mobile destination is configured to divert callers on busy (i.e. to voice mail supplied by your service provider), we recommend that you activate Call Waiting (if available with your service provider), so that Personal Numbering callers can be recalled to your INDeX voice mailbox once the Personal Numbering Recall timer has expired.
- If your Home or Mobile destination is configured to divert callers on no answer, but you require unanswered Personal Numbering calls to recall to your INDeX voice mailbox, then ensure that the Personal Numbering Recall timer is lower than that of the destination no answer timer.
- Do not configure your Mobile or Home destination to divert back to your office DDI number.

Remote Setting of Personal Number Diverts

When you are away from your desk or even out of the office, you can dial the Voice Manager and set/change your Personal Number divert settings:

To access the Voice Manager:

1. If internal, dial the Voice Manager extension number.
2. If external, either dial in to your company and ask to be transfer to the Voice Manager extension or use a direct number if your company has one set up
3. When you hear the Voice Manager respond, press #.
4. Enter your mailbox ID and then your mailbox password if requested.
5. The voice manager will provide you with prompts to control the messages.

Setting the Divert Types and Personal Numbers

It is strongly recommended that you set up *Divert All* with frequently used personal number destinations. Once set these numbers will be displayed (after pressing the **DIVERT** key) as **MOBILE**, **HOME**, **DELEGATE** or **OTHER**.

You can also set your phone to divert when *Busy* or on *No Answer* (see below).

To set frequently used Divert All numbers:

1. Press **PROGRAM** and then **DIVERT**.
2. Enter your passcode (see page 40) and press **SCROLL**.
3. Press **NUMBER**. The divert destination options **MOBILE**, **HOME** or **DELEGATE** are displayed.
4. Select the first divert all destination. Press **DELETE** to remove any previous entry and then enter the required number.
Note: For **MOBILE**, and **HOME** numbers **only**, you do not have to add the line access prefix. If you are setting **OTHER** with an off switch number, you **must** add a line access number. Press **DONE** to enter the number.
5. Either select the next divert destination and repeat step 4 or press **DONE** and **SCROLL** again to set the timeout (if required). Otherwise jump to step 7.
6. Press **TIMEOUT** and select the divert all destination from the options displayed. Press **CANCEL** to remove any previous entry and then enter the time in seconds (sets the length of time that the call will ring at the active destination number before reverting to your voice mailbox). Press **DONE** and either select another divert all destination and enter a timeout or jump to step 7.
7. If a system speed dial number is required press **ALL** followed **SPEED DIAL**. Select the required system speed dial store number. Alternatively, you can press **ALL** and enter another alternative divert all number. These will be displayed as **OTHER** when the **DIVERT** key is pressed to activate divert all.
8. Press **PROGRAM** to finish.
9. To activate divert all, see page 25.

To set infrequently used Divert All numbers:

1. Press **PROGRAM** and then **DIVERT**.
1. Enter your passcode (see page 40) and press **ALL**.
2. If a system speed dial number is required press **SPEED DIAL**. Select the required system speed dial store number. Alternatively, you can enter another divert all number. When frequently used divert all destinations have been set (see above) this infrequently used number will be displayed as **OTHER** when the **DIVERT** key is pressed. Alternatively, if no frequently used divert all number have been set the only **●** will appear above **DIVERT** when divert all is switched on.
4. To activate *Divert All*, see page 25.

To set Divert on Busy or No Answer:

1. Press **PROGRAM**, **DIVERT** and enter your passcode (see page 40).
2. Select either **ON BUSY** or **NO ANS.** followed by **DELETE**.
3. Enter the required divert destination number and press **DONE**.
4. Press **PROGRAM** to finish.

These diverts, once set up, are always active. The *No Answer* divert is normally set to your voice mailbox. You can alter the time that a calls rings you before being diverted (see page 36).

Switching Divert All On/Off

Where divert destinations have been previously set (see page 23), pressing the **DIVERT** key will activate the *Divert All* feature.

To select the divert all destination:

1. Press **DIVERT** and a solid ● appears above the **DIVERT** key. All of the available divert destinations are displayed with a flashing ● beside the active divert destination.
(Press **SCROLL** if a solid ● appears next to **SCROLL** to display an additional divert destination; normally shown as **OTHER●**).
2. You can change the active divert destination by pressing the key next to ●**MOBILE**, ●**HOME**, ●**DELEGATE**, ●**VOICE** or ●**OTHER**.
3. Pressing **DIVERT** again will display the new active divert destination (with a flashing ●).

To switch divert off:

3. Press **DIVERT** and **CANCEL●**. You can activate another divert destination by pressing the required key next to ●**MOBILE**, ●**HOME**, ●**DELEGATE**, ●**VOICE** or ●**OTHER**. See steps 2 and 3 above.

Switching No Calls On/Off

Pressing **NO CALLS** switches it on or off. When on, and you lift the handset or press **ANSWER/RELEASE** you will hear a broken dial, but you can still make calls. How it works depends on if you have set a Divert All number (see page 23).

- **With a Divert All Set:** Press **NO CALLS** and ●**DIVERT**. The ●-symbol above the **NO CALLS** key stays on. All calls go to the divert number but unlike **Divert All**, even that number cannot call you. Or, press ●**REJECT** and the ●-symbol above the **NO CALLS** key flashes and callers hear continuous tone
- **With no Divert All Set:** Press **NO CALLS** and ●**REJECT**. The ●-symbol above the **NO CALLS** key flashes and callers hear continuous tone.

No Call Override

Your System Manager can set an override on selected display terminal such that, even if you have selected *No calls*, they can still ring you. If your phone has been given this facility, when you ring and extension with *No calls* set, you will see ●**MESSAGE** and ●**OVERRIDE** displayed. Hence you can either leave a message or override the *No calls* setting of the called phone.

Displaying an Absence Message

You can select an absence message to display on your phone. It then also appears on any other suitable phones that calls you (*unless you have a Divert All number in use*).

To select an absence message:

1. Press **PROGRAM** and then **●ABSENT**.
2. Enter your passcode (see page 40).
3. Press **●CHANGE** to select a message (or **●CLEAR** to cancel an existing message). For just personal text, select **CUSTOM**. Then press **●DONE**.
4. **PERSONAL TEXT?** appears. To have no personal text, press **●NONE**. To add some text press **●EDIT**. Enter text as for editing the phone name (*see page 41*).
5. When complete, press **●SET**.

Forwarding Calls

Forward allows you to **remotely** set your phone to divert. By default, the system bars remote forwarding extensions. Contact your System Manager to enable this feature.

To set a forward:

1. From another display terminal, press **PROGRAM** and then **●FORWARD**.
2. The display shows **FORWARD FROM ?**. Enter the phone number from which to forward calls from and press **●DONE**.
3. Enter the passcode of the phone from which you wish to forward calls, e.g. your passcode if you are forwarding calls from your phone. (*see page 40*).
4. The display shows **FORWARD TO ?** and the phone's current *Divert All* number (if set).
5. To change the forward, press **●CANCEL** and enter the new number for diverting all calls.
6. Press **●DONE** and then press **PROGRAM** to finish.

DSS Keys

Setting Up a DSS Key

Phones have eight DSS keys along their right-hand edge. Each can store a line, extension or group number. DSS keys allow you to dial numbers in a single key stroke and perform actions such as *Pickup*, *Unpark*, etc.

You can also use DSS keys to dial personal speed dial numbers (see page 11). In addition, certain network environments may allow you to program remote extensions under DSS keys. Consult your System Manager for details.

To set a DSS/BLF key directory number:

1. Press **PROGRAM** and then the DSS key to use.
2. Enter your passcode (see page 40).
3. The display shows the current stored number (if set).
4. Press **●CANCEL** and dial the number to store.
5. Select another DSS key or press **DONE●** and **PROGRAM** to finish.

Using DSS Keys

Once setup, you can use the DSS key for the following actions. You can also use DSS keys to dial personal speed dial numbers (see page 11).

To make internal calls:

Press the DSS key storing the extension or group number.

To make external calls:

Press the DSS key storing the line or line group number, then dial the external number.

To pickup calls:

Press the DSS key storing the ringing extension number (*fast flashing red BLF lamp*).

To unpark calls:

Press the DSS key storing the parked line number (*slow flashing green or red BLF lamp*).

To make a page call:

Press **●PAGE** and then the DSS key storing the extension or group number.

BLF Status Lamps

The DSS keys on 2050 & 2060 phones incorporate dual-colour BLF lamps. These show the status of the number stored under the DSS key.

Red BLF Lamp Signals: *Calls to/from other extensions.*

- **Slow Flash:** Call on line parked at another extension.
- **Fast Flash:** Extension ringing.
- **Long On/Short Off:** Extension or line busy.
- **Solid:** Extension or line disconnected.

Green BLF Lamp Signals: *Calls to your extension.*

- **Slow Flash:** Call on line parked at your extension.
- **Fast Flash:** External call ringing your extension.
- **Solid:** Call connected or held at your extension.

Alternate Green/Red Lamp Signal: Pilot Number.

- **Slow Flash:** Caller ringing pilot number.

DSS Key Label

Next to the DSS keys is a label. You can remove the label cover to write on the card below. You can also remove the label cover under the handset using the same method (*it has a single pin hole on the bottom edge*).

To remove the label cover:

1. Insert a fine but not sharp point (e.g. end of a paper-clip) into one pin hole. Squeeze the label to the right.
2. Repeat with the other pin hole.
3. Lift the label cover clear and remove the card insert.

To replace the label cover:

1. Replace the card insert.
2. Slide the tabs on the right-hand edge of the label cover into their slots.
3. Bow the label cover to slip the tabs on the left-hand edge of the label cover into their slots.

DSS Key Label Template

A template for printing DSS key labels exists. It can be used with Word for Windows 6 or 7. Contact your System Manager for a copy of the template, alternatively you can obtain it from the Avaya internet site <http://support.avaya.com> and/or from the CD supplied with the handset.

To use the template:

1. Copy the file **DSSKEYUK.DOT** into the Word template directory, i.e. the directory containing other **.DOT** files (this varies according to the version of Word and other Microsoft programs that you use, typically it is the **WINWORD** or **TEMPLATE** directory).
2. Start Word. Select **F**ile and then **N**ew.
3. From the list of templates select **DSSKEYUK**.
4. Follow the instructions included within the template.

Interruptions During a Call

Answering a Call Waiting

If during a call, **CALL WAITING** appears and the lamp fast flashes, then someone has 'camped on' to your phone (see page 14). Press the ●-symbol (if shown) opposite the name to switch between details of the waiting and current call.

To answer a call waiting:

1. Park (press ●**PARK**) or end your current call.
2. The waiting call rings your phone.

Answering an Alert

If **ON HOLD** appears during a call, an extension with your number set as a Soft DSS key has sent you an alert (see page 34). Press the ●-symbol (if shown) opposite the name to switch between details of the current and waiting alert call.

To switch between calls:

1. Press **HOLD**. Use the held call features (see page 20).

Single Pips - Intrusion

Single pips during a call indicate that another phone is about to intrude on your call. Once they intrude, the system gives regular reminder pips.

Please Finish Call Message

The system supports **Clearcheck**. "**PLEASE FINISH CALL**" appears when maintenance is about to start on a part of the system your phone is using. The message "**THIS TERMINAL IS OFFLINE**" appears when maintenance is in progress.

ACD Working

ACD on 2050 Phones?

Your System Manager can provide 2050 phones with some ACD functions. ACD (Automatic Call Distribution) is a process widely used in telesales, informal Call Centres, departmental Helpdesks, etc. When ACD agents log on from their phone, the system automatically starts to direct appropriate incoming calls to them if they are free.

Starting ACD Working - Logging On

To receive ACD calls you must log on.

To Log On:

1. Press ●**LOG ON**.
2. Enter your agent number. (*You may be asked to enter your passcode.*) If you make a mistake, press ●**CANCEL** and re-enter your agent number.
3. Press ●**DONE**.
4. If not recognised or already in use, either enter your number again or press ●**DONE**.
5. A solid ●-symbol above the **GROUP** keys indicates when you are available to receive ACD calls.

Stopping ACD Calls Temporarily - Busy

To temporarily stop receiving ACD calls:

1. To indicate that you are at your desk but doing other work, press **GROUP**. The flashing ●-symbol above the **GROUP** key indicates '**busy wrap up**' to the ACD system. The system can automatically cancel this after a short time.
2. To indicate that you are away from your desk, press **NO CALLS**. The flashing ●-symbol above the **NO CALLS** key indicates '**busy not available**' to the ACD system.
3. To indicate you are ready to receive ACD calls again, press the **GROUP** key. A solid ●-symbol above the **GROUP** key indicates '**ready**' to the ACD system.

Finishing ACD Working - Logging Off

To Log Off:

1. Press ●**LOG OFF**.

Manager-Secretary Setup

Planning Soft DSS Keys

The four Display Keys can be set up for Soft DSS working (see page 33). When setting up Soft DSS keys you must decide:

- **How many Soft DSS keys do you want?**
Half-line mode supports up to 4 keys. Full-line mode supports up to 2 keys but shows more information.
- **What Soft DSS key features do you want to have?**
You can use half-line mode to make calls only. You can use full-line mode to make calls, send alerts, etc.
- **What type of calls do you want to make/receive?**
When using Soft DSS keys to make a call, the usage setting of your phone and the phone called determines the type of call. The possibilities are:
 - **Standard Call:** The same as a normally dialled call.
 - **Page Call:** The extension called hears a single tone and can then hear you (you cannot hear them).
 - **Direct Call:** The extension called hears a single tone and then you can hear each other.

There are four usage settings (**Normal**, **Auto Answer**, **Voice** and **Intercom**). See page 32 to see how the different usage settings interact.

Setting Up Soft DSS Keys

To clear the Soft DSS keys after set-up, cancel all the set extensions (see page 32).

To setup Soft DSS keys:

1. Press **PROGRAM**, **SCROLL** and then **●SOFT DSS**.
2. Enter your passcode (see page 40).
3. The phone shows **NO SOFT DSS KEYS**. Press **●CHANGE** until the display mode required appears, then press **●DONE**.
4. Enter the first extension number and then press **●NEXT**. If the right-hand display is blank, you can enter another. If you have entered all the extensions, press **●DONE**.
5. Press **●USAGE**. Press **●CHANGE** until the setting required appears and then press **●DONE**.
6. Press **PROGRAM** to finish.

Changing the Soft DSS Display Mode

The display mode sets how many Soft DSS keys you can have; 4 in half-line mode or 2 in full-line mode. Note that if you change mode from half-line to full-line, you lose the last two extensions entered.

To set the Soft DSS key display mode:

1. Press **PROGRAM** and **SCROLL**. Press **●SOFT DSS**.
2. Enter your passcode (see page 40).
3. Press **●MODE**. The display shows the current mode.
4. To change mode, press **●CHANGE**.
5. Press **●DONE**. The display goes to extension entry.
6. Press **PROGRAM** to finish.

Changing the Soft DSS Extensions

The Soft DSS features only work correctly with extension numbers. Do not set lines or groups as Soft DSS keys.

To set a Soft DSS key extension:

1. Press **PROGRAM** and **SCROLL**. Press **●SOFT DSS**.
2. Enter your passcode (see page 40).
3. Press **●EXTNS.** to display the first number set.
 - To cancel the number, press **●CANCEL**.
 - To display the next number, press **●NEXT**.
 - To enter a new number, press **●NEXT** until the top-right display goes blank, then enter the number.
4. Press **PROGRAM** to finish.

Changing the Soft DSS Usage

When using Soft DSS Keys to make a call, the usage setting of the two phones determines the type of call that occurs (see diagram). The phone's usage setting affects all of its Soft DSS keys. The system treats extensions with no Soft DSS Keys as set to **NORMAL CALL**.

Usage Setting	Call Type	Usage Setting
Normal or Auto Answer	< Standard / Standard >	Normal or Auto Answer
Normal	< Page / Standard >	Voice or Intercom
Auto Answer	< Direct / Standard >	Voice or Intercom
Voice	< Page / Page >	Voice
Voice	< Page / Direct >	Intercom
Intercom	< Direct / Direct >	Intercom

To set the soft DSS key usage:

1. Press **PROGRAM** and **SCROLL**. Press **●SOFT DSS**.
2. Enter your passcode (see page 40).
3. Press **●USAGE**. The display shows the current setting.
4. To change the current usage, press **●CHANGE**.
5. Press **PROGRAM** to finish.

Manager-Secretary Working

Using Soft DSS Keys

The INDeX system supports a range of functions for users who work together, i.e. regularly call and transfer calls between each other. This is called "Manager-Secretary working". These functions can be set-up under the four Display Keys to provide Soft DSS working (see page 31 for set-up details).

The Soft DSS keys displays the name of another extension. The adjacent display key allows you to make calls to that extension plus other features. The display key's ●-symbol acts as a busy lamp to show the extension's status.

Soft DSS has two modes. In half-line mode you can set 4 Soft DSS keys. In full-line mode you can only set 2 keys but these can display more details and functions.

Soft DSS Key Display

After setting up a Soft DSS key, the ●-symbol next to the extension's name shows its status, e.g.

Alan.R • Off = Extension is free.

• Alan.R • Flashing = Extension is ringing.

• Alan.R • On = The extension is busy.

In full-line mode, the display also shows when an extension is on **DIVERT** or **NO CALLS**.

• Alan.R -)• • Set to No Calls, no divert all set.

• Alan.R -)• 204 • Set to No Calls, diverting to 204.

• Alan.R -)• 204 • Set to Divert All, diverting to 204.

Making Calls

The ●-symbol next to the Soft DSS extension name is solid when busy, flashes when ringing and not shown if free.

To make a call using a Soft DSS key:

1. Press the display key next to the extension name. The Soft DSS usage setting of your phone and the phone called determine what type of call occurs (see page 32).
2. If the extension is busy, the phone displays the same options as for normal calls (see page 13).

Park Transferring Calls

During calls, full line Soft DSS keys display **<-PARK** next to each name. Pressing the **●**-key next a **<-PARK** option, transfers and parks your caller against that extension.

To park transfer a call:

1. Note the call's line number on the display.
2. Press the **●**-key on the right of the Soft DSS name. The system transfers the call and parks it at that extension.
3. Press the **●**-key on the left of the Soft DSS name to call that extension and announce the parked caller.
4. If the Soft DSS extension does not answer or want the call, dial the line number to retrieve the parked call.

Alerting a Busy Extension

A solid **●**-symbol next to a Soft DSS key means that extension is busy. In full-line mode, you can send them an alert (*only to another display phone*). This places you on hold against their extension.

To alert the extension:

1. Press the display key on the right of the name. The display shows details of the extension's current call.
2. If **●ALERT** does not appear, the extension is busy for reasons other than a call, e.g. handset off-hook.
3. Press **●ALERT**. The display shows **HOLDING**.
4. If **●INTRUDE** appears, you can intrude on the call (*see page 14*).

Remotely Switching No Calls/Divert On/Off

In full-line mode (*see page 32*), Soft DSS keys allow you to remotely switch the extension's **NO CALLS** or **DIVERT ALL** on/off.

To switch on/off divert all or no calls:

1. Press the **●**-key on the right of the extension name.
2. If **●ALERT** appears the extension is busy. Press the **●** key on the right of the extension name again (press **●SCROLL** if necessary to redisplay the name).
3. Select the option to change; **●NO CALLS** or **●DIVERT**
4. **DIVERT** does not appear if the extension does not have a Divert All number set).
5. The Soft DSS display shows the new status.

Ringer Controls

You can change for your **OWN** phone and, if in a group, the **Group** ringer's:

- **Volume** (including the **Steps** in which the volume increases).
- **Sound** of the ringer to your own distinctive ring.
- **Timeout** period before a callback call can ring before being cancelled, the period in which your group phone rings before trying the next number and/or the time your phone rings before the system uses a divert.

In addition, for incoming **Internal** and **External** calls, you can turn the ringer off.

Changing the Ringer Volume

While altering the volume, the phone rings.

To change the ringer volume:

1. Press **PROGRAM** and then **●RINGER**.
2. Enter your passcode (*see page 40*).
3. Select from either **OWN●** or **GROUPS●**.
4. Press **●VOLUME**. The display shows a slider. Adjust this using the **●**-keys on its left (softer) or right (louder).
5. Press **DONE●** and **PROGRAM** to finish.
The ringer volume for all incoming calls is now changed.

Changing the Ringer Sound

The ringer sound contains three tones. You can adjust the 'mix' of these to achieve your own distinctive ring. While doing this the phone rings.

To change the ringer sound:

1. Press **PROGRAM** and then **●RINGER**.
2. Enter your passcode (*see page 40*).
3. Select from: **OWN●** or **GROUPS●**.
4. Press **●SOUND**. The display shows a slider. Adjust this using the **●**-keys on its left and right.
5. To select another part of the sound to adjust, press **●TONE**. This changes the slider to a different tone.
6. Press **DONE●** and **PROGRAM** to finish.

Switching the Ringer On/Off

You can switch the ringer on or off for internal and/or external calls. This does not affect the information displayed.

For internal calls you can also select **AUTO ANSWER** to connect internal calls after giving just a single tone. This feature is sometimes called "Splash calls". A similar feature can also be enabled for external calls (see "Automatic External Call Connection" on page 19).

To switch the internal or external ring on/off:

1. Press **PROGRAM** and then **●RINGER**.
2. Enter your passcode (*see page 40*).
3. Select either **●EXTERNAL** or **●INTERNAL**.
The display shows the current setting.
4. To change the ringer mode, press **●CHANGE** to select **ON**, **OFF** or **AUTO ANSWER** (*internal only*).
5. Press **DONE●** and **PROGRAM** to finish.

Setting a Ringer Step

If a call rings unanswered, the phone can increase the volume on each ring until it reaches its maximum. You can select several sizes of increase step.

To set the ringer volume step size:

1. Press **PROGRAM** and then **●RINGER**.
2. Enter your passcode (see page 40).
3. Select from: **OWN●** or **GROUPS●**.
4. Press **●STEPS**.
The display shows the current setting;
LARGE STEP, **SMALL STEP** or **NO STEP** (no increase).
5. To select another step size, press **●CHANGE**.
6. Press **DONE●** and **PROGRAM** to finish.

Setting the Ringer Timeout

The ringer timeout control several actions.

- **Callback:**
How long a callback rings you before cancelling.
- **Group hunting:**
How long calls to a group of which your phone is a member, rings your phone before trying the next member.
- **Divert on no answer:**
How long calls ring at your phone before the system uses Divert on No Answer if set.

To set the ringer timeout:

1. Press **PROGRAM** and then **●RINGER**.
2. Enter your passcode (see page 40).
3. Select from either **OWN●** or **GROUPS●**.
4. Press **●TIMEOUT**. The display shows the current setting.
5. Press **●CANCEL** and enter the new timeout in seconds. The normal value of 10 seconds is equal to 3 rings.
6. Press **DONE●** and **PROGRAM** to finish.

Other Features

Personal Alarms

You can set the phone to give you an alarm call at a set time on a particular day or type of day (e.g. weekdays). The alarm can be normal ringing, music or a system announcement. You can also add your own short text message. If your phone is busy at the set time, the alarm waits until it is free.

Your System Manager can also arrange alarms. System alarms do not wait until your phone is free. You do not have to be in group to receive a System alarm.

To set a personal alarm:

1. Press **PROGRAM** and then **ALARM**.
2. Enter your passcode (see page 40). If you have an alarm set, **CLEAR** appears below the alarm time.
3. To set the alarm type: Press **TYPE**. Press **CHANGE** until the required type of alarm appears, then press **DONE**.
4. To add or remove an alarm message:
Press **MESSAGE** and:
 - To select no message, press **NONE**.
 - To alter the message, press **EDIT**.
Enter the message text (see page 41) and then press **DONE**.
5. To set the alarm time and day: Press **SET**. Dial the alarm time in 24-hour clock format. Press the **●** symbol on either side of the day shown to select the day or days on which the alarm should occur, then press **DONE**.
6. Press **PROGRAM** to finish programming.

To clear a personal alarm:

1. Press **PROGRAM** and then press **ALARM**.
2. Enter your passcode (see page 40).
Press **CLEAR** to cancel the alarm settings.

Missed Calls

The **●MISSED** function displays the last five unanswered external calls to your phone. Note that this function only works for calls which include CLI, i.e. the caller's phone number.

Press **●MISSED** and either the name of the missed caller or the date and time of the missed call is displayed. If only the name is displayed, press **SCROLL●** to display the date and time. Use the lower left and right display keys to move between details of different calls. You can recall the displayed caller by pressing **●CALL**.

You can save a number by pressing **●SAVE**. This stops the number being removed until you press **●DELETE**. The missed calls function stores a maximum of five missed numbers including saved numbers.

Note: Unsaved missed numbers are removed once you exit the missed function.

Group

Your phone is allocated to groups by your System Supervisor and can be either one or both of the following features-

- Membership of a group or groups that you join and leave **all of** by pressing the **GROUP** key.
- Membership of a group or groups that you can select to join and leave **individually** by pressing the key next to the **GROUPS●** display.

When *in group*, you receive calls made to the **group number** (not your extension number; however you can still receive calls made to your extension number).

In addition, the group's type sets the order in which its members ring (defined by your System Manager). The types are rotary, collective, sequential and longest waiting (see "Glossary" on page 48).

When in a group, where each member rings in turn, your phone rings for the time set by its ringer timeout; you may change this timeout (see page 36). Similarly, you can change the ringer sound for group ringing (see page 35).

Going into group switches divert all or no calls off.

To join/leave a group or groups:

1. Pressing the **GROUP** key takes your phone in or out of all groups that you are a member of.
2. When *in group* (shown by a **●** symbol above the **GROUP** key) you can receive calls made to the group.

Your System Manager can inhibit use of the **GROUP** key.

To select which group you wish to join/leave:

1. Pressing the key next to the **GROUPS●** display will cause the first group you are permitted to join/leave to be displayed.
2. You may step through the available groups by pressing the key next to the displayed name (when other groups are available they are indicated by a **●** symbol next to the group name).
3. Press **●JOIN/●LEAVE** as appropriate followed by **●DONE**.

Hot Desking

Warning:

Phones being used for ACD also have log on and log off controls and should not be confused with phones being used for hot desking.

In some situations a phone may be shared by more than one person, with each person having a different extension number. This is called "hot desking".

Whilst a user is logged off, calls to them will follow their divert all settings or are re-routed by the INDeX if they have no divert set.

To Log On:

1. If the phone is displaying **NOT LOGGED ON**, press either **•LOG ON** and enter your number or **•INDeX** and select your name. You may be asked to enter your passcode (option set by your System Manager). See page 40 for details on entering and changing your passcode.
2. If the phone is displaying **LOG OFF**, press that key first and then perform step 1 as above.

Message Waiting Indication

When a voice message has been left against a logged off hot desk number, then, when logging on again, the Message Waiting Indicator will illuminate and the display will show *Message From Voice Mail*. Once logged on, you can listen to the voice message(s). See "Listening to Voice Messages" on page 42.

Phone Settings

The Phone Passcode

If the phone displays **ENTER PASSCODE**, it expects you to dial your passcode. The default passcode is 0000.

Wrong passcode entry can result in the phone becoming barred. Barred phones cannot access features requiring passcode entry. They can make external calls but only to special numbers, e.g. Emergency numbers.

To enter your passcode:

1. Dial your passcode. If you make a mistake, press ●**CANCEL** and restart entry.
2. If you enter the wrong number, the phone displays **REENTER**. Enter the passcode again or press **PROGRAM** to end programming.
3. If you enter the wrong passcode 5 times, the phone displays **THIS TERMINAL IS BARRED**. To unbar your phone contact the System Manager.

To change your passcode:

1. Press **PROGRAM** and then **SCROLL** twice. Press ●**PASS**.
2. Enter the current passcode.
3. The display shows **ENTER NEW CODE**. Enter the new passcode (all passcodes must be at least four digits).
 - To restart after a mistake, press ●**CANCEL**.

Background Music

If your system has external Music-on-Hold installed, you may be able to have it play when the phone is not in use. The phone's speaker volume controls the loudness of the music (*see page 16*).

To switch background music on/off:

1. Press **PROGRAM** and then **SCROLL**. Press ●**MUSIC**.
2. Enter your passcode (*see page 40*).
3. The display shows the **NO MUSIC** or **BACKGROUND MUSIC**.
4. To change the current setting press ●**CHANGE**.
5. Press ●**DONE** and then press **PROGRAM** to finish.

Displaying Phone Details

You can view the details of the phone's type, number and directory name on the display.

To display the phone's details:

1. Press **PROGRAM** and then press **SPEAKER**.
2. The display shows the phone's type, number and on the bottom line the phone's directory name.
3. Press **PROGRAM** to return to normal use.

Locking/Unlocking the Phone

You can lock your phone. This stops it being used to make external calls, users hear continuous tone instead. You can still make internal calls whilst locked.

To lock/unlock a phone:

1. Press **PROGRAM** and then **NO CALLS**.
2. Enter your passcode (*see page 40*).
3. The phone displays the current setting.
4. To change the current setting, press **●CHANGE**.
5. Press **●DONE** and then press **PROGRAM** to finish.

Language Controls

The system allows you to select which language to use for the phone's display.

To change the phone's display language:

1. Press **PROGRAM** and then **SCROLL** twice.
2. Press **●LANGUAGE**.
3. Press **●CHANGE** to select the language required or your system's **DEFAULT** language.
4. Then press **●DONE** and then press **PROGRAM** to finish.

Voice Manager

Voice Manager Functions

The INDeX supports a number of different Voice Managers and so the range of features/options available to you may differ. Check with your System Manager for features/options available to you.

Listening to Voice Messages

The system can include a Voice Manager to record messages in your own voice mailbox. You can use this by setting the Voice Manager number as your diverts (see page 22). Remember to check your mailbox regularly as the Voice Manager can delete messages after set periods.

To check your mailbox:

1. Press ●**VOICE** and then ●**LISTEN**.
2. The display shows **ENTER PASSCODE**. Enter your mailbox passcode (not your phone's passcode).
 - If you make an error, press ●**CANCEL** to restart.
3. Once in your mailbox, the Voice Manager tells you how many messages you have. Use the controls below.

To control your mailbox messages:

1. To rewind the message, press ●**REWIND**.
2. To fast forward the message, press ●**FFWD**.
3. To hear the next message, press ●**NEXT**.
4. To delete the message, press ●**DELETE**.
5. To hear the previous message, press ●**SCROLL** and ●**PREVIOUS**.
6. To find out when the message was left, press ●**WHEN**.
7. To copy the message to a mailbox, press ●**COPY**.
8. To save the message press **SCROLL** and then ●**SAVE**.
9. To record a number on the Notepad, press **SCROLL** twice and then **NOTEPAD●**.

Using Any Phone

You can dial the Voice Manager and check your mail when away from your desk or even out of the office. The phone you use must have MF tone dialling with * and # keys.

To access the Voice Manager:

6. If internal, dial the Voice Manager extension number.
7. If external, either dial in to your company and ask to be transfer to the Voice Manager extension or use a direct number if your company has one set up
8. When you hear the Voice Manager respond, press #.
9. Enter your mailbox ID and then your mailbox password if requested.
10. The voice manager will provide you with prompts to control the messages.

Modifying Your Mailbox

You can modify your mailbox setting for the volume, password, name you're your permanent greeting as follows:

To modify your mailbox:

1. Press **●VOICE** and then **●MODIFY** (if lines to the Voice Manager are busy, the phone shows a **●WAIT** option).
2. The display shows **ENTER PASSCODE**. Enter your mailbox passcode (*If you make an error, press **●CANCEL** to restart.*)
3. Once the Voice Manager accepts your passcode, select the feature you wish to change from **●PASSWORD, NAME●, PRM MSG●** or **●VOLUME**.
 - To alter your password, select **●PASSWORD** and follow the verbal instructions given. Do not set an obvious password such as 1234, 0000 or your extension number.
 - To alter your greeting, select **●PRM MSG**. Either **●LISTEN** to your existing greeting or press **●CHANGE** to alter your greeting. Press **FINISH●** and replace the handset or press **MENU●** to change **●NAME** or **●VOLUME**.
 - To alter your mailbox name, select **●NAME**. Either **●LISTEN** to your existing mailbox name or press **●CHANGE** to alter your mailbox name. Press **FINISH●** and replace the handset or press **MENU●** to change **●PRM MSG** or **●VOLUME**.
 - To alter your mailbox volume, select **●VOLUME** and use the keys on either side to increase/decrease the volume as required.
4. When finished, press **ANSWER/RELEASE**.

Changing Your Temporary Greeting

You can replace your mailbox greeting with a temporary one. The Voice Manager will delete it during its daily housekeeping (which normally occurs at night).

To add a temporary mailbox greeting:

1. Press **●VOICE** and then **●TEMP MSG**.
2. The display shows **ENTER PASSCODE**. Enter your mailbox passcode.
3. Once the Voice Manager accepts your passcode, it shows **●LISTEN, ●CHANGE, ●DELETE** and **●FINISH**.
4. When finished, press **ANSWER/RELEASE**.

Dial 1 Divert for Incoming Calls

If your system has the feature installed (consult your System Manager), you can set up your mailbox such that incoming calls (from MF phone only) can be instructed to dial 1 and then be diverted to a 'delegate' number of your choice.

To set up the dial 1 divert:

1. Press **PROGRAM** and then **DIVERT**.
2. The display shows **ENTER PASSCODE**.
Enter your passcode.
3. Press **SCROLL** and then **NUMBER**●
4. Select **DELEGATE**● and then **●CANCEL**.
5. Enter the extension or group number that you wish incoming calls to be diverted to
6. Press **DONE**● and **PROGRAM** to finish.
7. Record your message for incoming calls, e.g. "Sorry that I cannot take your call, either leave a message or please dial 1 to be transferred to the Operator", as either a permanent or temporary greeting as follows:
8. Press **●VOICE** and then either **PERM MSG**● OR **TEMP MSG**●.
9. The display shows **ENTER PASSCODE**.
Enter your passcode.
10. Once the Voice Manager accepts your passcode, it shows **●LISTEN**, **●DELETE, CHANGE**●, and **VOLUME**●
11. Press **CHANGE**● and record your message.
12. On completion, press **FINISH**● and press **ANSWER/RELEASE**.

Leaving Voice Mail Messages

To leave voice messages:

1. Press **●VOICE** and then **●MESSAGE**.
2. The display shows **DIAL EXTENSION** and **INDeX**●.
3. Either, enter the extension number or press **INDeX**● and use the directory to obtain the extension name/number.
4. Voice Manager plays the extension's mailbox name and gives a tone. Speak your message immediately after the tone and then press **●FINISH**.
 - To check your message, press **●REVIEW**.
 - To change the message, press **●RERECORD**.
 - To send the message if okay, press **●SEND**.
 - To cancel the message, press **ANSWER/RELEASE**.
5. If you want to leave another message, press **●NEXT**, otherwise press **ANSWER/RELEASE**

System Manager Phones

What are System Manager Phones?

The System Manager can give special 'System Manager' status to some display phones. Those phones can then access a set of extra features.

Night Service

Phones and lines on the system divide into areas. Each area links to a night service timetable. The system takes the areas in and out of night service using those timetables. Phones with System Manager status can manually switch areas between day and night service.

During night service, display phones show a crescent moon symbol at the top-right.

Other typical effects are:

- **Lines:** The system directs calls to a night desk number, answerphone extension or Voice Manager (*if installed*).
- **Phones:** The type of external call you can make becomes more restricted, e.g. no long distance calls.

To switch areas between Day & Night Service:

1. Press ●**SETUP** and then ●**SERVICE**.
2. To change all areas, press ●**ALL**.
3. To change a particular area, press ●**SELECT**. Enter the area and press ●**DONE**.
4. Press ●**CHANGE** to select **DAY** or **NIGHT SERVICE**.
5. When finished press ●**DONE**.

Changing the Time

Phones with System Manager status can alter the time set on the system and displayed on phones. The time shown is in either 12-hour or 24-hour clock format (set by the maintainer).

To set the time:

1. Press ●**SET UP** and then ●**TIME**.
2. Enter the new time in 24-hour format.
3. If entered wrongly, press ●**CANCEL** and re-enter.
4. To cancel the change press **ANSWER/RELEASE**.
6. When finished, press ●**DONE**.

Unlocking a Phone

When a user has inadvertently locked their phone, they can be unlocked from a phone with System Manager status

To unlock a phonee:

1. Press ●**SET UP**, **SCROLL** and then ●**UNLOCK**.
2. The display shows **DIAL EXTENSION** and **INDeX●**.
3. Either, enter the extension number or press **INDeX●** and use the directory to obtain the extension name/number.
3. Press ●**UNLOCK**

Changing the Date

Phones with System Manager status can alter the date set on the system and displayed on the phones. The date on phones either displays as **day:month:year** or just **day:month**. Your System Manager controls this feature.

To set the date:

1. Press **●SET UP** and then **●DATE**.
2. Enter the new date as day, month and year.
3. If entered wrongly, press **●CANCEL** and re-enter.
4. To cancel the change and exit, press **ANSWER/RELEASE**.
5. When finished, press **●DONE**.

Recording ACA Messages

Phones with System Manager status can play and record the messages used on Automatic Call Announcer (ACA) modules. Note that while using these functions, any features that use the ACA module will not run.

The system uses ACA modules in two ways. It plays to external callers waiting to be answered. It also uses them for system and personal alarms.

To play/record an ACA module:

1. Press **●SET UP** and then **●ACA MSG**. Dial the directory number of the module. If the module is locked, press **●CHANGE** to unlock it.
2. To play the current recording: Press **●PLAY** to start the module. Press **●STOP** to stop the module.
3. To select the recording source: Press **●SOURCE**. Press **●CHANGE** until the source required; **TERMINAL** (*the phone*) or **INPUT FROM EXT** (*the control cabinet jack socket*). When selected, press **●DONE**.
4. To record from the selected source: Press **●RECORD** and when the phone asks for confirmation press **●RECORD** again. Record the message and then press **●STOP**.
5. When completed, press **●SECURE** to relock the module so that it can be used.

Good Phone Usage

General Phone Usage

The phone provides a quick method of communication. However, think carefully about how you use it. Your phone manner is a key part of the company's and your image.

- Speak clearly and maintain a friendly manner.
- Position the phone within easy reach for use.
- Keep a pen and paper near the phone and use them.
- Keep a list of company and external numbers handy or use the ●**INDeX** function (see page 10).
- If you have to talk to someone else in the office during a call, inform the caller and then use **MUTE** or **HOLD**.
- Avoid giving your operator unnecessary work.
- Transfer callers yourself rather than via the operator.
- Keep your System Manager informed of changes in your department, so that they can keep your pickup groups, phone directories, etc. up to date.

Answering Calls

- Answer the phone promptly and identify yourself.
- Sound helpful and friendly.
- Get the caller's name and use it.
- Do not be bad mannered to wrong numbers, always accept the apology. Transfer the call to the correct extension if you can.
- Listen to the caller and let them know you are listening.
- If taking a message, include your name, the callers name, date, time and subject.
- If cut-off, wait for the original caller to call back.

Making Calls

- Know what you want to say, avoid rambling. If necessary, prepare key point notes before the call.
- If you get a wrong number, always apologize, it is not the other person's fault.
- If cut-off, call back as soon as possible.
- If an extension diverts to Voice Mail, leave a message. Do not hold for another person unless urgent.

Glossary

Account Codes

A code of up to 12 digits that the system outputs to its call log with call details. Codes entered are checked against up to 400 stored on the system.

Area

Each extension and line on the system belongs to one of up to 250 areas. They then follow the night service timetable linked to that area.

BLF

(Busy Lamp Field) Lamp which shows the status (busy, ringing, etc.) of a particular number. Normally associated with the number stored under a DSS key.

Call Log

The system can log calls that match set criteria, e.g. length, direction, line, extension. The log includes call details such as number, account codes, time, etc.

Camp On

A function which leaves your phone set to ring a busy extension or line as soon as it becomes free. Stops you receiving any other calls in the meantime.

Collective

A group where the system rings all the free group members at the same time.

DSS

(Direct Station Select) Keys which store line, extension or group numbers. For use when making calls, etc.

Longest Waiting

A group where the system rings the free group members in order of how long they have been free.

Manager Secretary Working

A name for functions that help one user to make and receive calls for transfer to another user.

Page

A one-way call which connects without ringing and uses the speaker of the phone(s) called. Also called a broadcast call.

Pickup Group

A group of phones within which you can pickup and answer calls ringing at member extensions.

Pilot Number

A special number used to route DDI calls on the phone system.

PIN Code

The system stores up to 400 6-digit PIN codes. Each has its own call barring and phone settings. When you use a PIN, its settings override those of the phone from which you dial.

POT

(Plain Ordinary Telephone) Also called two-wire telephones, includes fax and answer phones.

Rotary

A group where the system starts with the first free group member after the last member rung. If unanswered, the system tries the next free member and so on.

Sequential

A group where the system rings the first free group member, always starting from the front of the group. If unanswered, the system tries the next free member and shuttles between the first two free members.

Speed Dials

Speed dials store phone numbers (and sometimes account codes). The phone number can then be dialled by keying the number of the speed dial store.

Tenancy

The system divides into tenancies, each containing different extensions and lines. Calls between tenancies are normally not allowed. Tenancies sub-divide into areas.

20CC Turret Terminals

Similar to the 20 Series display phones, 20CC phones are designed for headset working in ACD (telesales) environments.

Index

- Abbreviated dialling 11
 ABSENT 26
 ACA MSG 46
 ACCOUNT 17
 Account codes
 Forced 12
 Voluntary 17
 ACD 30
 ALARM 37
 ALERT
 Answer 29
 Sending an 34
 Announcement 37
 Answer
 Alarm call 18
 An alert 29
 CALL WAITING 29
 Callback 19
 Messages 18
 Normal calls 18
 Page 18
 Auto answer 35
 Auto Answer (Soft DSS) 32
 Background music 40
 Barred phone 40
 BLF Lamps 28
 Broadcast See Page
 Busy camp on 14
 Busy not available 30
 Busy transfer 20
 Busy wrap up 30
 Call
 Barring 8
 CALL 18
 Forward 26
 Hold 20
 Make internal 8
 Park 21
 Pickup 19
 Transfer 20
 Unpark 21
 Using Soft DSS 33
 Volume 16
 CALL FOR MESSAGE . 18
 CALL WAITING 14
 Answer 29
 CALLBACK 13
 Answer 19
 Ring timeout 36
 CALLFREE 21
 CAMP ON 14
 Answer 29
 CANCEL 18
 Callback 19
 Message 18
 Change
 Date 46
 Passcode 40
 Time 45
 Clearcheck 29
 CONFER 15
 Conference 15
 Split 15
 Customise mailbox 43
 DATE 46
 Dial ahead 21
 DIALLED 9, 16
 Directory 10
 Display
 Language 41
 Name 41
 Number 41
 Soft DSS 33
 Soft DSS mode 32
 Software release 17
 DIVERT
 Divert all on/off 25
 No answer time 36
 Remote on/off 34
 Remote set 26
 Set numbers 24
 DSS Keys 27
 BLF Lamps 28
 Setup 27
 Enquiry call 20
 ENTER ACCOUNT 12
 ENTER PASSCODE 40
 ENTER PIN 12
 Exclusive hold 20
 Executive intrusion 14
 Extension number 41
 EXTERNAL 35
 Ring on/off 35
 EXTNS 32
 Follow me 26
 Forced
 Account 12
 Feed 19
 Intrusion 14
 PIN 12
 FORWARD 26
 Free flow 19
 Greeting 43
 GROUP 38
 Page 8
 Ringing timeout 36
 Groups 38
 Handsfree 16
 HOLD 20, 21
 Common hold 21
 Hot desking 39
 Hotline operation 19
 INDeX 10
 Intercom (Soft DSS) 32
 INTERNAL 35
 Make call 8
 Ring on/off 35
 INTRUDE
 Forced 14
 Polite 34
 Key label 28
 Lamp 7
 Language
 Dutch 41
 English 41
 French 41
 Swedish 41
 Language: 41
 Leave message 14
 Voice mail 44
 Letter keys 10
 LISTEN 14
 Locking a phone 41
 LOG OFF 30
 LOG ON 30
 Log on/off 39
 Mailbox
 Customise 43
 Maintenance messages 29
 Make call
 Internal 8
 Soft DSS 33
 Manners 47
 MESSAGE 44
 Answer 18
 Leave 14
 No call override 25
 Microphone On/Off 17
 MISSED 38
 Missed calls 38
 Mobile access 12
 MODE 32
 MODIFY 43
 Monitor 14
 MUSIC
 Alarm 37
 Background 40
 MUTE 17
 Name 41
 Name mailbox 43
 NEXT 18
 Night service 45
 NO CALLS 41
 Absence messages 26
 Override 25
 Remote on/off 34
 Normal call (Soft DSS) .. 32
 Not logged on 39
 Notepad 16
 Offline messages 29
 PAGE
 Answer 18
 Make 8
 PARK 15, 20, 21
 Conference 15
 Park transfer 34
 PASS 40
 Passcode
 Mailbox 43
 Phone 40
 Permanent greeting 43
 Personal alarm 37
 Personal numbers 24
 Personal speed dials 11
 Persuasive ringing 36
 Phone lamp 7
 Phone lock 41
 Phone passcode 40
 Phone usage 47
 PICKUP 19
 Pickup group 19
 PIN codes
 Forced 12
 Roaming 12
 Play ACA module 46
 PLEASE FINISH CALL . 29
 Polite intrusion 34
 Polite shutdown 29
 RECALL 17
 Record
 ACA module 46
 Temporary greeting 43, 44
 REDIAL 9, 16
 Release (software) 5, 17
 Remote divert & no calls switch 34
 Remote forward 26
 RING IF FREE 21
 Ring inward transfer 20
 Ringback 13
 RINGER 7
 AUTO ANSWER ... 35
 On/off 35
 Sound 35
 STEP size 36
 TIMEOUT 36
 VOLUME 35
 Roaming PIN 12
 Scroll 6
 SERVICE 45
 SET UP 45
 Setup mailbox 43
 SHOW FREE 21
 Shutdown 29
 Silent monitor 14
 Single tone 19
 SOFT DSS 31
 Alerting 34
 Display 33
 Display mode 32
 Divert 34
 Extensions 32
 Make call 33
 No calls 34
 Set usage 32
 Soft Keys 6
 Software level 5
 Software release 17
 SOUND 35
 SPEAKER 16, 41
 SPEED DIAL 11
 Splash calls 35
 SPLIT 15
 STEPS 36
 System alarm 37
 System Manager 5
 Phone status 45
 System speed dials 11
 Temporary greeting . 43, 44
 THIS TERMINAL IS
 BARRED 40
 THIS TERMINAL IS
 OFFLINE 29
 TIME 45
 TIMEOUT 36
 TMP MSG 43, 44
 Tones 7, 35
 Transfer (and Park) 34
 Transfer calls 20
 Unlocking a phone 41
 Unpark calls 21
 USAGE 32
 Version 17
 Voice call (Soft DSS) ... 32
 Voice Mail
 Notepad 16
 Voice Manager
 Mailbox customise . 43
 VOLUME
 Call 16
 Ringer 35
 Ringer step 36
 Voluntary account codes 17
 Wait on busy 14

Performance figures and data quoted in this document are typical, and must be specifically confirmed in writing by Avaya before they become applicable to any particular order or contract. The company reserves the right to make alterations or amendments to the detailed specifications at its discretion. The publication of information in this document does not imply freedom from patent or other protective rights of Avaya, or others.

Intellectual property related to this product (including trademarks) and registered to Lucent Technologies has been transferred or licensed to Avaya.

This document contains propriety information of Avaya and is not to be disclosed or used except in accordance with applicable agreements.

Any comments or suggestions regarding this document should be sent to "gsspublishing@avaya.com".

© Copyright 2001 Avaya
All rights reserved.

Avaya Global SME Solutions
Sterling Court
15 - 21 Mundells
Welwyn Garden City
Hertfordshire
AL7 1LZ
England

Tel: +44 (0) 1707 392200

Fax: +44 (0) 1707 376933

Email: globalsme@avaya.com

Web: <http://www.avaya.com>.