



5.8 GHz Dual Handset Call Waiting Caller ID Cordless Telephone System User's Guide

25841



EQUIPMENT APPROVAL INFORMATION

Your telephone equipment is approved for connection to the Public Switched Telephone Network and is in compliance with parts 15 and 68, FCC Rules and Regulations and the Technical Requirements for Telephone Terminal Equipment published by ACTA.

1 Notification to the Local Telephone Company

On the bottom of this equipment is a label indicating, among other information, the US number and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company.

The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

Notes

- This equipment may not be used on coin service provided by the telephone company.
- Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.
- Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.
- If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this product does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

2 Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinuance; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

LICENSING


Licensed under US Patent 6,427,009.

HEARING AID COMPATIBILITY (HAC)

This telephone system meets FCC standards for Hearing Aid Compatibility.

US NUMBER IS LOCATED ON THE CABINET BOTTOM
REN NUMBER IS LOCATED ON THE CABINET BOTTOM

WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.



INTRODUCTION

CAUTION: When using telephone equipment, there are basic safety instructions that should always be followed. Refer to the IMPORTANT SAFETY INSTRUCTIONS provided with this product and save them for future reference.

Your Call Waiting Caller ID phone stores and displays specific information, provided by your local telephone company, to subscribers of Caller ID or similar caller identification services.

Your Call Waiting Caller ID phone enables you to:

- Identify callers before you answer the phone.
- View the time and date of each incoming call.
- Record up to 40 Caller ID messages sequentially in each handset.
- Know who called while you were away.


To get the most from your new phone, we suggest that you take a few minutes right now to read through this user's guide.

IMPORTANT: In order to use all of the features of this unit, you must subscribe to either the standard Name/Number Caller ID Service or Call Waiting Caller ID Service. To know who is calling while you are on the phone, you must subscribe to Call Waiting Caller ID Service.


IMPORTANT: Because cordless phones operate on electricity, you should have at least one phone in your home that isn't cordless, in case the power in your home goes out.

IMPORTANT: You can only use one handset at a time and there is NO conference and intercom features for these units.


HANDSET LAYOUT



BASE LAYOUT




HANDSET CHARGE CRADLE LAYOUT



BEFORE YOU BEGIN


PARTS CHECKLIST

Make sure your package includes the items shown here.



TELEPHONE JACK REQUIREMENTS

To use this phone, you need an RJ11C type modular telephone jack, which might look like the one pictured here, installed in your home. If you don't have a modular jack, call your local phone company to find out how to get one installed.



DIGITAL SECURITY SYSTEM

Your cordless phone uses a digital security system to protect against false ringing, unauthorized access, and charges to your phone line.

When you place the handset in the base, the unit verifies its security code. After power outage or battery replacement, you should place the handset in the base for about 20 seconds to reset the code.

INSTALLATION NOTE: Some cordless telephones operate at frequencies that may cause or receive interference with nearby TVs, microwave ovens, and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV, microwave ovens, or VCR. If such interference continues, move the cordless telephone farther away from these appliances.


Certain other communications devices may also use the 5.8 GHz frequency for communication, and if not properly set, these devices may interfere with each other and/or your new telephone. If you are concerned with interference, please refer to the owner's manual for these devices on how to properly set channels to avoid interference. Typical devices that may use the 5.8 GHz frequency for communication include wireless audio/video senders, wireless computer networks, multi-handset cordless telephone systems, and some long-range cordless telephone systems.

INSTALLATION

IMPORTANT INSTALLATION GUIDELINES

- Avoid sources of noise and heat, such as motors, fluorescent lighting, microwave ovens, heating appliances and direct sunlight.
- Avoid areas of excessive dust, moisture and low temperature.
- Avoid other cordless telephones or personal computers.
- Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch non-insulated telephone wires or terminals, unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.

INSTALLING THE PHONE




BASE STATION

- Choose an area near an electrical outlet and a telephone wall jack (RJ11C), and place your cordless telephone on a level surface, such as a desktop or tabletop, or you may mount it on the wall.
- Install the handset battery.

CAUTION: To reduce the risk of fire or personal injury, use only the battery 5-2548, which is compatible with this unit.

NOTE: You must connect the handset battery before use.



- Plug the battery pack cord into the jack located inside the battery compartment, then place the battery pack inside the battery compartment.
- Put the battery compartment door back on.
- Plug one end of the telephone line cord into the TEL LINE jack on the bottom of the base and the other end into a modular jack.

- Set the RINGER switch (on the handset) to ON.
- Plug the AC power adaptor into the electrical outlet and the DC connector into the jack on the bottom of the base.
- Place the handset in the base cradle. The charge/in use indicator turns on, verifying the battery is charging.
- Allow the phone to charge for 16 hours prior to first use. If you don't properly charge the phone, battery performance is compromised.


CAUTION: Use only the ATLINKS USA, Inc. 5-2501 (black) power converter that came with this unit. Using other power converters may damage the unit.

NOTE: The phone is tone dial only and does not support pulse dial mode.

EXTRA CHARGING CRADLE

- Plug the AC power adaptor of the extra charging cradle into the electrical outlet.
- Install the handset battery as item 2 described above.
- Place the handset in the extra charging cradle. The charge indicator turns on, verifying the battery is charging.
- Allow the phone to charge for 16 hours prior to first use.

WALL MOUNTING



NOTE: For best results, charge the phone on a flat surface before you mount it on the wall.

- Slip the mounting holes (on the back of the base) over the wall plate posts, and slide the unit down into place. (Wall plate not included.)
- Place the handset on the base cradle.

REGISTRATION

YOU MUST REGISTER BOTH HANDSETS TO THE MAIN BASE BEFORE USE!

- 1st handset - The 1st handset being charged on the main base station will automatically register after 16 hours of charging.
- 2nd handset - After the 2nd handset has charged for 16 hours on the extra charger, place it on the main base station for 20 seconds, it will then automatically register.

NOTE: PLEASE REGISTER will show on the display if the handsets have not been registered. Once the handsets have completed registration successfully, HANDSET 1 and HANDSET 2 will show on the handset's display.

NOTE: In case of a power failure, the handsets may display UNAVAILABLE when the talk/end/call back button is pressed. You must then place both handsets on the main base cradle for 20 seconds to re-register.

SETUP

There are four programmable menus available: Language, Area Code, Ringer Tone, and Default Setting.

During programming, you may press the flash/prog button at any time to go to the next option. To exit the menu, keep the previous setting and return to the standby mode, press the *exit button.

DISPLAY LANGUAGE

- Press the flash/prog button until >1ENG 2FRA 3ESP shows in the display. 1ENG is the default.
- Use the Caller ID/vol (- or +) button or the touch-tone pad on the handset to enter your selection.
- Press flash/prog again to save.

LOCAL AREA CODE

- Press the flash/prog button until AREA CODE --- shows in the display. --- is the default.
- Use the touch-tone pad on the handset to enter your three digit area code.
- Press flash/prog again to save.

NOTE: If you make a mistake, press the del/chan button to erase a wrong number.

RINGER TONE

- Press the flash/prog button until RINGER TONE 1 shows in the display. 1 is the default.
- Use the Caller ID/vol (- or +) button or the touch-tone pad on the handset to scroll to 1, 2, or 3.
- Press flash/prog to save.

DEFAULT SETTING

- Press the flash/prog button until DEFAULT NO shows in the display. NO is the default.
- Use the Caller ID/vol (- or +) button on the handset to scroll to YES or NO.
- Press flash/prog to save. You will hear a confirmation tone.

CORDLESS PHONE BASICS

IMPORTANT: You can only use one handset at a time and there is NO conference and intercom features for these units.

CHARGE/IN USE INDICATOR

The phone is ON when the talk/end/call back indicator on the handset and the charge/in use indicator on the base is lit. The handset and base indicators flash when you receive a call.

ANSWERING A CALL

- When the phone rings, pick up either handset and press the talk/end/call back button.
- When finished, press the talk/end/call back button again or place the handset on either the base cradle or the extra charger to hang up.

MAKING A CALL

- Pick up either handset and press the talk/end/call back button. Wait for the dial tone. The call timer starts counting minutes and seconds in the display.
- Dial a telephone number.
- When finished, press the talk/end/call back button again or place the handset on either the base cradle or the extra charger to hang up.

NOTE: You can only use one handset at a time and there is no conference and intercom features for these units. UNAVAILABLE will be displayed if other handset is in talk mode.

PRE-DIALING

- Make sure the phone is OFF (not in TALK mode).
- Dial a telephone number (the number you dial shows in the display).
NOTE: If you make a mistake dialing the number, use the del/chan button to backspace and erase the wrong number, and enter the correct number.
- Press the talk/end/call back button on that handset. The number automatically dials and the call timer starts counting the minutes and seconds in the display.
- When finished, press the talk/end/call back button again to hang up.

NOTE: You may enter up to 32 pre-dial digits.

CALL TRANSFER

During an external call, you may transfer the external call to another handset.

- Press trans button on the originating handset. TRANSFERRING shows in the display. Both handsets will be paged.
- Press trans button or talk/end/call back on receiving handset to answer the call.

NOTE: To cancel the call transfer, you may press *exit button or trans button on the originating handset.

NOTE: If there is no answer within 2 minutes after transferring the call, then both handsets will be rung back (callback). If neither handset answers within 30 seconds, then the external call will be automatically dropped.

REDIAL

While the phone is ON (in TALK mode), press the redial button to redial the last number you dialed (up to 32 digits).

OR,
While the phone is OFF (in standby mode), press the redial button and then the talk/end/call back button to redial the last number.

FLASH

Use the flash/prog button to activate custom calling services such as call waiting, which are available through your local phone company.

TIP: Don't use the talk/end/call back button to activate custom calling services such as call waiting, or you'll hang up the phone.

CHANNEL BUTTON

While talking on the phone, it may be necessary for you to manually change the channel to improve reception and reduce noise or static on the line. Press and release the del/chan button to move to the next clear channel.

EXIT

Press the *exit button to cancel any command you initiated.

FINDING THE HANDSET

This feature helps locate misplaced handsets.

Press the page button on the base. The handset beeps continuously for about 2 minutes until you press the talk/end/call back button on the handset or the page button on the base.

NOTE: You may still page the handsets when the ringer is off.

RINGER SWITCH

The ringer switch is located on the side of the handset, it has two positions, ON and OFF.

VOLUME

When the phone is ON (in TALK mode) press the Caller ID/vol (- or +) button to adjust the listening level. Choose from four volume settings. VOL 1 is the lowest volume and VOL 4 is the highest volume.


MUTE

Use mute during a phone conversation to speak privately and off-line with a third party.

- Press the format/mute button. MUTE shows in the display. The party on the telephone will not hear you.
- Press the format/mute button when finished.

CALLER ID (CID)

This unit receives and displays information transmitted by your local phone company. This information can include the phone number, date, and time; or the name, phone number, date, and time. Each handset can store up to 40 calls for later review.



CALL WAITING CALLER ID

Provided you subscribe to Call Waiting Caller ID service from your phone company, you are able to see who is calling while you are on the phone when you hear the call waiting beep. The caller identification information appears in the display after you hear the tone.

- When you hear the call waiting beep in the handset receiver, press the flash/prog button to put the current call on hold and answer the incoming call.

IMPORTANT: In order to use this unit's Caller ID features, you must subscribe to either the standard Name/Number Caller ID Service or Call Waiting Caller ID Service. To know who is calling while you are on the phone, you must subscribe to Call Waiting Caller ID Service.

RECEIVING AND STORING CID RECORDS

When you receive a call, the information is transmitted by the phone company to your Caller ID telephone between the first and second ring.

When the memory is full, a new call automatically replaces the oldest call in memory. NEW appears in the display for calls received that have not been reviewed.

NOTE: Check with your local phone company regarding name service availability.

REVIEWING CID RECORDS

As calls are received and stored, the display is updated to let you know how many calls have been received.

- Press the Caller ID/vol (-) to scroll through the call records from the most recent to the oldest.

