# Model 25942 Series 5.8 GHz Cordless Handset Answering System Úser's Guide



### **Equipment Approval Information**

Your telephone equipment is approved for connection to the Public Switched Telephone Network and is in compliance with parts 15 and 68. FCC Rules and Regulations and the Technical Reguirements for Telephone Terminal Equipment published by ACTA.

#### 1 Notification to the Local Telephone Company

- On the bottom of this equipment is a label indicating, among other information, the US number and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company
- The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

- This equipment may not be used on coin service provided by the telephone company
- Party lines are subject to state tariffs, and therefore, you may not be able to use your own
- telephone equipment if you are on a party line. Check with your local telephone company. Notice must be given to the telephone company upon permanent disconnection of your
- telephone from your line • If your home has specially wired alarm equipment connected to the telephone line, ensure the
- nstallation of this product does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.
  - US Number is located on the cabinet bottom.

#### REN Number is located on the cabinet bottom

#### 2 Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinuance: (2) afford you the opportunity to correct the situation: and (3) inform you of your ht to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68. FCC Rules and Regulations.

#### Visit the GE website at: www.GE.com/phones

THOMSON

Model 259/ 00019461 (Rev. 3 Dom E) 07-40 Printed in China

Thomson In 10330 North Meridian Stree Indianapolis IN 46290 © 2007 Thomson Inc rademark(s) ® Registered Marca(s) Reaistrada(s)



### Interference Information

nis device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation

his equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. Privacy of Communications may not be ensured when using this product.

If this equipment does cause harmful interference to radio or television recention, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures

- Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference)
- Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commissio has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office. Washington, D.C. 20402. Please specify tock number 004-000-00345-4 when ordering copies.

Notice: The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

## Hearing Aid Compatibility (HAC)

nis telephone system meets FCC standards for Hearing Aid Compatibility

### Licensing

# FCC RF Radiation Exposure Statement

### bis equipment complies with ECC RE radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20

centimeters between the radiator and your body. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT **EXPOSETHIS** PRODUCT TO RAIN OR MOISTURE.

k	CAUTION: RISK OF ELECTRIC SHOCK DO NOT OPEN	
IGHTNING H AND ARROW ) WITHIN THE NGLE IS A NING SIGN TING YOU OF IGEROUS AGE" INSIDE PRODUCT.	CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFED SERVICE PERSONNEL.	THE EXCLAMATION POINT WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF IMPORTANT INSTRUCTIONS ACCOMPANYING THE PRODUCT.

SEE MARKING ON BOTTOM / BACK OF PRODUC

### Introduction



IMPORTANT: Because cordless phones operate on electricity, you should have at least one phone in your home that isn't cordless, in case the power in your home goes out.

### Before You Beain

#### Parts Checklist (for 25942xx1 model)

Make sure your package includes the items shown here.



For Model 25942xx2 there will be ONE additional handset, charge cradle, battery pack and cover than shown above

For Model 25942xx3 there will be TWO additional handsets, charge cradles, battery packs and covers than shown above.

For Model 25942xx4 there will be THREE additional handsets, charge cradles, battery packs and covers than shown above.

### **Telephone Jack Requirements**

Fo use this phone, you need an RJ11C type modular telephone iack which might look like the one pictured here installed in vour home. If you don't have a modular jack, call your local phone company to find out how to get one installed.

### Installation

### Diaital Security System

Your cordless phone uses a digital security system to protect against false ringing, unauthorized access, and charges to your phone line.

INSTALLATION NOTE: Some cordless telephones operate at frequencies that may cause or receive interference with nearby TVs, microwave ovens, and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV, microwave ovens, or VCR. If such interference continues, move the cordless telephone farther away from these appliances.

Certain other communications devices may also use the 5.8 GHz / 900 MHz frequency for communication, and, if not properly set, these devices may interfere with each other and/or your new telephone If you are concerned with interference, please refer to the owner's manual for these devices on how to properly set channels to avoid interference Typical devices that may use the 5.8 GHz frequency for communication include wireless audio/video senders, wireless computer networks, multi-handset cordless telephone systems, and some long-range cordless telephone systems.

#### Important Installation Guidelines

- Avoid sources of noise and heat, such as motors, fluorescent lighting, microwave ovens, heating appliances and direct sunlight
- Avoid areas of excessive dust, moisture and low temperature.
- Avoid other cordless telephones or personal computers.
- Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch non-insulated telephone wires or terminals, unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.

### Handset Layout



### **Base Layout**







/OLUME ( 🔺 (button) mem (memory buttonĺ

chan (channel button)

### Installing the Phone

### Installing the Handset Battery

NOTE: You must connect the handset battery before use.

CAUTION: To reduce the risk of fire or personal injury, use only the Thomson Inc. approved Nickel-Cadmium (Ni-Cd) battery model 5-2729 or Nickel-Metal Hydride (Ni-MH) battery model 5-2522, which are compatible with this unit.

1. Locate batterv and batterv door which are packaged together inside a plastic bag and are separate from the handset

2. Locate the battery compartment on the back of the handset

3. Plug the battery pack cord into the jack inside the compartment. **PLEASE REGISTER** shows in the display

NOTE: To ensure proper battery installation, the connector is keyed and can be inserted only one way.



4 Insert the battery pack

5. Close the battery compartment by pushing the door up until it snaps into place

### **Base Station**

1. Choose an area near an electrical outlet and a telephone wall jack (RJ11C), and place your cordless telephone on a level surface, such as a desktop or tabletop, or vou may mount it on the wall.



- 2 Plug one end of the telephone line cord into the TELLINE jack at the back of the base and the other end into a modular iack
- 3. Plug the AC power converter into the electrical outlet and the DC connector into the iack at the back of the base
- 4. Place the handset in the base cradle. The charge/in use indicator turns on, verifying the battery is charging. The unit will take 20 seconds to register and verify its security code. **READY** shows in the display
- NOTE: In case of a power failure, the handsets may display UNAVAILABLE when the TALK/CALL BACK button is pressed. You must then place all handsets on the main base cradle for 20 seconds to re-register
- 5. Allow the phone to charge for 16 hours prior to first use. If you don't properly charge the phone, battery performance is compromised

CAUTION: To reduce risk of personal injury, fire, or damage use only the 5-2754 (gray) or 5-2732 (black) power adaptor listed in the user's guide. This power adaptor is intended to be correctly orientated in a vertical or floor mount position.

### Wall Mounting

- 1. Turn the base ove
- 2. Attach the wall mounting pedestal by first inserting the tabs on the open edge of the pedestal into the slots on the lower portion of the bottom of the base. Then push down and snap the pedestal into place
- 3. Slip the mounting holes (on the back of the base) over the wall plate posts, and slide the unit down into place. (Wall plate not included.

NOTE : If desired, agther the extra telephone line and power adaptor cord and store inside the wall mounting pedestal

### Answering System Setup

his section shows you how to set up your answering system to receive incoming calls.

Before you begin the set up process, you must turn on the answering system. • Press the ans on/off button to turn the answering system ON and OFF.

#### The MESSAGES indicator lights when the answering system is **ON**. The indicator blinks when you have new messages.

NOTE: The answering system displays "--" when it is OFF.

### Setting the Voice Prompt Language

The default voice prompt language is English.

To change the answering system's voice prompt language, press and hold the skip button for two seconds. The unit announces "SELECCIONADO ESPANOL" (Spanish selected)

NOTE: To change to English, press and hold the skip button again for 2 seconds. The unit announces "ENGLISH SELECTED"

NOTE: In remote access mode, the system follows the selected language. The voice prompt language cannot be switched remotely.

### Voice Time/Day Stamp

- Make sure the answering system is **ON**
- 2. Press and hold the day/check button on the base to set the day of the week. 3. Press and hold the hour button on the base to set the hour (a.m. or p.m.). Example:
- 12AM, 1AM, or 12PM, 1PM.
- 4. Press and hold the min button on the base to set the minute. The time advances in 5-minute intervals, or tap and release to advance in 1 minute intervals.

### Speaker Volume

Use the speaker volume (- / +) buttons to adjust speaker volume on the base to a comfortable level. L1 is the minimum speaker volume and L8 is the maximum.

### Recording the Outgoing Announcement

For best results when recording, you should be about nine inches from the microphone, and eliminate as much backaround noise as possible.

- 1. Make sure the answering system is **ON**.
- 2. Press and hold the announce button on the base.
- 3. Begin speaking after you hear the beep.
- 4. Release the button when you finish your announcement.

NOTE: If you choose not to record an outgoing announcement, a default announcement plays instead. To return to the default announcement after you have recorded your own outgoing announcement, press the announce button and release it when you hear the beep.

#### Sample Outgoing Announcemen

"HI, THIS IS (USE YOUR NAME HERE), I CAN'T ANSWER THE PHONE RIGHT NOW, SO PLEASE LEAVE YOUR NAME. NUMBER AND A BRIEF MESSAGE AFTER THE TONE. AND I'LL GET BACK TO YOU. THANKS.'

### Reviewing the Announcement

Press and release the announce button to review your outgoing announcement.

### **Rinas to Answer**

Use the RINGS TO ANSWER switch on the back of the base to set the number of times you want the phone to ring before the answering system answers the call. You may choose 3 rings, 5 rings, or TOLL SAVER (TS).

NOTE: If you select Toll Saver (TS) the unit answers after the 3rd ring if there ARE new messages, OR the unit answers after the 5th ring if there ARE NO new messages.

## landset Setup

here are eight programmable menus available: Language, Handset Name, Area Code Ringer ON/OFF, Ringer Tone, Tone/Pulse, Transfer ON/OFF and Default Setting.

During programming, you may press the mute/menu button at any time to go to the next option. To exit the menu, keep the previous setting and return to the standby mode, press the \*EXIT/tone button.

### Display Language

1. Press the mute/menu button until > 1ENG 2FRA 3ESP shows in the display. 1ENG is the default. (ENG stands for English. FRA stands for French. ESP stands for Spanish.)

- 2. Use the CALLER ID-VOLUME (▲ or ▼ ) button or the touch-tone pad on the handset to enter your selection
- 3. Press mute/menu again to save.

### Handset Name

- 1. Press the mute/menu button until **ENTER NAME** shows in the display.
- 2. Use the touch-tone pad to enter the name (up to 15 characters). More than one letter is stored in each of the number keys. For example, to enter the name Bill Smith press the 2 key twice for the letter B Press the 4 key 3 times for the letter I. Press the 5 key 3 times for the letter L. Wait for one second. Press the 5 key 3 times for the second letter L. Press the 1 key to insert a space between the L an the S. Press the 7 key 4 times for the letter S; press the 6 key once for the letter M; press the 4 key 3 times for the letter I: press the 8 key for the letter T: press the 4 key twice for the letter H

NOTE: If you make a mistake, use the delete button to backspace and delete one character at a time

3. Press mute/menu again to save.

NOTE: If no name is entered, *READY* shows in the display.

### Local Area Code

- 1. Press the mute/menu button until **AREA CODE - -** shows in the display. - is the default.
- 2. Use the touch-tone pad on the handset to enter your three digit area code.
- 3. Press mute/menu again to save.

NOTE: If you make a mistake, press the delete button to erase a wrong number.

### **Ringer ON/OFF**

- 1. Press the mute/menu button until **RINGER** > 1 ON shows in the display. 10N is the default.
- 2. Use the CALLER ID-VOLUME ( < or ) button or the touch-tone pad on the handset to scroll to **1 ON** or **2 OFF**

#### 3. Press mute/menu to save

NOTE: If you turn the ringer off, *RINGER OFF* shows on the display.

## Ringer Tone

3 Press mute/menu to save

1 TONE is the default.

3. Press mute/menu to save

Transfer ON/OFF

3. Press mute/menu again to save.

return to the factory defaults.

Cordless Phone Basics

Charae/In Use Indicator

Default Setting

3. Press mute/menu to save.

Answering a Call

base cradle to hang up.

Making a Call

2 Dial a telephone number

base cradle to hang up.

reset the unit.

correct number.

vou dialed (up to 32 diaits)

- OR -

**Channel Button** 

Redial

Flash

1. Make sure the phone is **OFF** (not in TALK mode).

TALK/CALL BACK button to redial the last number

Pre-dialing

to scroll to 1 TONE or 2 PULSE.

**Tone/Pulse** 

and select 2 ON.

the default

#### You can choose from 3 ring tones.

- 1. Press the mute/menu button until **RINGER TONE → 01** shows in the display. 01 is the default
- 2. Use the CALLER ID-VOLUME (▲ or ) button or the touch-tone pad on the handset to select from **01** to **03**.

1. Press the mute/menu button until > 1 TONE 2 PULSE shows in the display.

2. Use the CALLER ID-VOLUME (  $\blacktriangle$  or  $\checkmark$  ) button or the touch-tone pad on the handset

In order to use the Call Transfer feature (applicable ONLY with additional handsets), you must have the Transfer ON/OFF set to ON through the menu of the transferring

1. Press the mute/menu button until **TRANSFER** > 1 OFF shows in the display. 2. Use the CALLER ID-VOLUME ( $\blacktriangle$  or  $\checkmark$ ) button or the touch tone pad on the handset

You may return handset settings to the factory default setup using this menu. 1. Press the mute/menu button until **DEFAULT** > **NO** shows in the display. NO is

2. Use the CALLER ID-VOLUME (▲ or ) button on the handset to scroll to YES or NO. NOTE: If you choose YES, all settings in the programmable menu

When the charge/in use indicator on the base is lit, the phone is **ON** or the handset is being charged. The handset visual ringer and base indicator flash when you receive a call.

1. When the phone rings, pick up the handset and press the TALK/CALL BACK button. 2. When finished, press the TALK/CALL BACK button again or place the handset on the

1. Pick up the handset and press the TALK/CALL BACK button. Wait for the dial tone. The call timer starts counting minutes and seconds in the display.

3. When finished, press the TALK/CALL BACK button again or place the handset on the

NOTE: In case of power failure, the handset may display UNAVAILABLE when the TALK/CALL BACK button is pressed. You must then place the handset on the main base for 20 seconds to

2. Dial a telephone number (the number you dial shows in the display).

#### NOTE: If you make a mistake dialing the number, use the delete button to backspace and erase the wrong number, and enter the

3. Press the TALK/CALL BACK button on that handset. The number automatically dials and the call timer starts counting the minutes and seconds in the display. 4. When finished, press the TALK/CALL BACK button again to hang up.

NOTE : You may enter up to 32 pre-dial digits.

While the phone is **ON** (in TALK mode), press the redial button to redial the last number

While the phone is **OFF** (in standby mode), press the redial button and then the

Use the flash/answerer/call waiting button to activate custom calling services such as call waiting, which are available through your local phone company.

#### TIP: Do not use the TALK/CALL BACK button to activate custom calling services such as call waiting or you'll hang up the phone.

While talking on the phone, it may be necessary for you to manually change the channel to improve reception and reduce noise or static on the line. Press and release the chan button to move to the next clear channel

Press the \*EXIT/tone button to cancel any command you initiated.

Page This feature assists in locating a misplaced handset.

Press the page button on the base. The handset beeps continuously for about 2 minutes until you press the TALK/CALL BACK button on the handset or the page button on the base

#### NOTE: You may still page the handset when the ringer is off.

#### **Ringer ON/OFF Shortcut**

Apart from the setting in the main menu, there is a shortcut to set the ringer. Make sure the phone is **OFF** (not in talk mode).

- 1. Press the #PAUSE/ringer button to go to the **RINGER ON/OFF** menu. **RINGER** > 1 ON shows in the display. 10N is the default.
- 2. Use the CALLER ID-VOLUME ( $\blacktriangle$  or  $\checkmark$ ) button or the touch-tone pad on the handset to scroll to 1 ON. or 2 OFF.
- 3. Press the #PAUSE/ringer button to save your selection. You will hear a confirmation

### Volume

When the phone is **ON** (in TALK mode) press the CALLER ID-VOLUME (  $\checkmark$  or  $\checkmark$  ) button to adjust the listening level. Choose from five volume settings. VOL 1 is the lowest volume and **VOL 5** is the highest volume.

NOTE: The phone will automatically reset VOL 5 to VOL 4 after you hang up.

#### Mute

Use mute during a phone conversation to speak privately and off-line with a third party.

- 1. Press the mute/menu button. *MUTE* shows in the display. The party on the telephone
- will not hear vou.
- 2. Press the mute/menu button when finished.

### Temporary Tone

This feature is useful only if you have pulse (rotary) service. Temporary Tone Dialing enables pulse (rotary) service phone users to access touch tone services offered by banks, credit card companies, etc. For example, when you call your bank you may need to enter your bank account number. Temporarily switching to touch tone mode allows vou to send vour number

- 1 Dial the telephone number and wait for the line to connect
- 2. When your call is answered, press the \*EXIT/tone button on the handset to temporarily change from pulse dialing to tone dialing.
- 3. Follow the automated instructions to get the information you need.
- 4. Hang up the handset and the phone automatically returns to pulse (rotary) dialing mode.

### Call Transfer (applicable only with additional handsets)

During an external call, you may transfer the external call to another handset.

- 1. Press the format/trans button on the originating handset. TRANSFERRING shows in the display. All registered handsets will be paged
- 2. Press the format/trans button or TALK/CALL BACK on receiving handset to answer

#### NOTE: To cancel the call transfer, you may press \*EXIT/tone button or the format/trans button on the originating handset.

NOTE: If there is no answer within 2 minutes after transferring the call, then the handsets will be rung back (callback). If no handset answers within 30 seconds, then the external call will be automatically dropped.

## Caller ID (CID)

IMPORTANT: In order to use this unit's Caller ID features, you must subscribe to either the standard Name/Number Caller ID Service or Call Waiting Caller ID Service. To know who is calling while you are on the phone, you must subscribe to Call Waiting Caller ID Service.

This unit receives and displays information transmitted by your local phone company. This information can include the phone number, date, and time; or the name, phone number. date. and time



### Call Waiting Caller ID

Provided you subscribe to Call Waiting Caller ID service from your phone company; if you receive an incoming call and you are already on the phone, a beep indicates the presence of a Call Waiting call on the line. Only the handset that is in use at the time of the call will display and store the Call Waiting Caller ID information.

• When you hear the call waiting beep in the handset receiver, press the flash/answerer/ call waiting button to put the current call on hold and answer the incoming call. Press flash/answerer/call waiting again to return to the original call.

### **Receiving CID Records**

When you receive a call the Caller ID information is transmitted between the first and second ring. The Caller ID information appears on the display while the phone rings, giving you a chance to monitor the information and decide whether or not to answer

### Storing CID Records (In CID Memory)

If you are not at home or cannot answer, your telephone's Caller ID memory stores the data for the 40 most recent calls you received so you can see who called while you were unavailable. When the 41st call is received, the oldest Caller ID record (1st call) is automatically deleted.

You may review the stored information at any time. Calls received since your last review show as **NEW** in the display. Calls that have not been previously reviewed but were received from the same number more than once show as **REPT** in the display.

### **Reviewing CID Records**

As calls are received and stored, the display is updated to let you know how many calls have been received. To scroll CID records

- 1. Make sure the phone is **OFF** (not in talk mode)
- 2. Press the CALLER ID-VOLUME ( ) button to review the newest CID record.
- 3. Press the CALLER ID-VOLUME ( ) button to review the oldest CID record first.

### Dialina a CID Number

- 1. Make sure the phone is **OFF** (not in TALK mode).
- 2. Use the CALLER ID-VOLUME ( $\blacktriangle$  or  $\checkmark$ ) button to display the desired record.

3. Press the TALK/CALL BACK button. The number dials automatically

NOTE: Depending on (a) how the incoming caller's phone number is formatted when it is received, and (b) whether or not you previously pre-programmed your local area code into the set up menu, you may need to adjust the format of the incoming caller's stored phone number before making the call, press the format/trans button to adjust the number, and try again

#### Available formats include:

Number of digits	Explanation	Example
Eleven digits	long distance code "1 " +3-digit area code +7-digit telephone number.	1-317-555-8888
Ten digits	3-digit area code + 7-digit telephone number.	317-555-8888
Seven digits	7-digit telephone number.	555-8888

### Storing CID Records in Internal Memory

You may also store CID information in the phone's internal memory.

NOTE: It is important that you format CID records correctly BEFORE storing in internal memory as you cannot reformat CID records stored in memory.

- 1. Make sure the phone is **OFF** (not in talk mode).
- 2. Use the CALLER ID-VOLUME ( $\blacktriangle$  or  $\checkmark$ ) button to scroll to the desired CID record.
- 3 Press the mem buttor
- 4. Use the touch-tone pad to enter a memory location (0-9) to store the number in that memory location. You will hear a confirmation tone.

NOTE: If the memory location is occupied, *REPLACE MEMO*? is displayed, and you must confirm replacement by pressing the mem

NOTE: Press the \*EXIT/tone button once to keep the previous setting (making no changes) and return to the menu.

NOTE: If the selected CID record contains any information that is nonnumeric, the unit will not allow this record to transfer to the internal user memory. The handset will display UNABLE TO STORE.

#### To Replace a Stored CID Record

- .. Repeat steps 1 through 3 in Storing CID Records in Internal Memory. After you enter the memory location, REPLACE MEMO? shows in the display.
- 2. Press the mem button again, and the new CID record replaces the old memory in that location. You will hear a confirmation tone.

### Deleting a CID Record

- 1. Make sure the phone is **OFF** (not in TALK mode).
- 2. Use the CALLER ID-VOLUME (▲ or ▼) button to display the CID record you want to delete.
- 3. Press delete. The display shows **DELETE CALL ID**?.
- 4. Press delete again to erase the record and **DELETED** shows in the display. You will hear a confirmation tone

#### NOTE: Press the \*EXIT/tone button to return to the standby mode.

### Deleting All CID Records

- 1. Make sure the phone is **OFF** (not in TALK mode
- 2. Use the CALLER ID-VOLUME ( $\blacktriangle$  or  $\checkmark$ ) button to display any Caller ID record.
- 3. Press and hold the delete button until **DELETE ALL?** shows in the display.
- 4. Press delete again to erase all records. You will hear a confirmation tone. The display shows NO CALLS.

#### NOTE: Press the \*EXIT/tone key to return to the standby mode.

#### Memory

Each handset can store up to ten 24-digit numbers with up to 15-character names in memory for quick dialing. This memory feature is in addition to the CID memory log. which stores up to 40 CID records in each handset

### Storing a Name and Number in Memory

- 1. Make sure the phone is OFF (not in TALK mode).
- 2. Press the mem button.
- 3. Press the desired memory location (0 through 9) or use CALLER ID-VOLUME (▲ or ▼ ) to scroll to the desired memory location.

#### NOTE: If the memory location is occupied, the memory location number and stored name and telephone number shows in the display. If the memory location is empty. *EMPTY* shows in the display.

4. Press the mem button again. The display shows **ENTER NAME**.

#### NOTE: If you don't want to enter the name, skip step 5.

5. Use the touch-tone pad on the handset to enter the name (up to 15 characters) and press the memory button to save. More than one letter is stored in each of the number keys. For example, to enter the name Bill Smith, press the 2 key twice for the letter B. Press the 4 key 3 times for the letter I. Press the 5 key 3 times for the letter L. Wait for one second. Press the 5 key 3 times for the second letter L. Press the 1 key to insert a space between the L and the S. Press the 7 key 4 times for the letter S; press the 6 key once for the letter M; press the 4 key 3 times for the letter I; press the 8 key for the letter T<sup>.</sup> press the 4 key twice for the letter H

#### NOTE: If you make a mistake press the delete button to backspace and erase the wrong character(s) or number(s).

- 6. Press the mem button to save the name. The display shows ENTER TEL NUMBR.
- 7. Use the touch-tone pad to enter the telephone number you want to store (up to

#### NOTE: The system treats PAUSES as delays or spaces in the dialing sequence

8. Press mem again to store the number. You will hear a confirmation tone.

#### Storing the Last Number Dialed

- 1. Repeat steps 1 through 6 in Storing a Name and Number in Memory.
- 2. Press the redial button
- 3. Press the mem button to store the number. You will hear a confirmation tone.

#### To replace an old number with a new redial number

- 1. Repeat steps 1 through 6 in Storing a Name and Number in Memory.
- 2. Press the redial button.
- 3. Press the mem button, and **REPLACE MEMO?** shows in the display.
- 4. Press the mem button again to replace the old number with the new number. You will hear a confirmation tone.

### Inserting a Pause in the Dialing Sequence of a Stored Number

If a pause is needed to wait for a dial or access tone, press the #PAUSE/ringer button to insert a delay in dialing sequence of a stored number (for example, after you dial 9 for an outside line, or to wait for a computer access tone). Pause shows in the display as a P, and each pause counts as one digit in the dialing sequence.

### Changing a Stored Number

- 1. Repeat steps 1 through 7 in Storing a Name and Number in Memory.
- 2. Press the mem button, and **REPLACE MEMO?** shows in the display.
- 3. Press the mem button to store the number. You will hear a confirmation tone.

#### Reviewing and Deleting Stored Numbers

- 1 To review stored numbers, press the mem button, and use the CALLER ID-VOLUME ( $\blacktriangle$  or  $\checkmark$ ) button to scroll to the memory location, or press the corresponding number key for a desired memory location (0-9).
- 2. When the data shows in the display, press the delete button. The display shows DELETE?.
- 3. Press delete again to delete the data. The display shows DELETED.

### Dialina a Stored Number

- 1. Make sure the phone is **ON** by pressing the TALK/CALL BACK button.
- 2. Press the mem button
- 3. Press the memory location (0-9). The number dials automatically
- OR -1. Make sure the phone is **OFF** (not in TALK mode).
- 2. Press the mem button.

- 3. Use the touch-tone pad or the CALLER ID-VOLUME (▲ or ) button to scroll to the number you want to dial
- 4. Press the TALK/CALL BACK button. The number dials automatically.

### Chain Dialing from Memory

Use this feature to make calls which require a sequence of numbers, such as calling card calls to a frequently called long distance number. Each part of the sequence is dialed from memory. The following example shows you how to use chain dialing to make a call through a long distance service:

The Number For	Memory Location	
Long distance access number	7	
Authorization code	8	
Frequently called long distance number	9	
1. Make sure the phone is <b>ON</b> (in TALK mode).		

- 2. Press the mem button and then press 7.
- 3. When you hear the access tone, press the mem button and then press 8.
- 4 At the next access tone press the mem button and then 9

#### TIP: Wait for the access tones before pressing the next mem button, or your call may not go through.

#### Answering System Operation

This section discusses the buttons and features on the answering system.

### Messaaes Indicator

e messages indicator shows you how many messages you have received, and the indicator blinks when new messages are received. The answerer must be ON in order for the messages indicator to work

NOTE : The answering system displays "- -" when it is turned off.

### Screening Calls from the Base

- L. Wait for the caller to begin leaving a message (to determine who is calling).
- 2. To speak to the caller, pick up the handset, and press the TALK/CALL BACK button.
- The answering system automatically stops recording when you activate the handset or pick up an extension phone.
- TIP: Make sure the volume on the base is set loud enough to hear your incoming calls.

#### Message Playback

The messages indicator on the base lets you know when you have messages. To play messages, press PLAY/STOP.

While a message is playing, you may do the following:

- Press PLAY/STOP to stop the message playback.
- Press and release 🕊 repeat to restart the current message; continue pressing and releasing 📢 repeat to review previous messages.
- Press and release >> skip to go to the next message.

### Memory Full

When answering system memory is full, the system answers after 10 rings, beeps and waits for you to enter the 3-digit security code. If you don't enter the security code within 7 seconds, the phone hangs up.

You should erase some messages so the answering system can record new ones.

NOTE: The unit also answers after the 10th ring if it is turned off. To access the answering system, enter your 3-digit security code after vou hear the beep.

#### Erasing Messages

You may erase messages three ways: one message at a time from the base; all messages from the base; or one message at a time from the handset or a phone in another location

- To erase one message at a time from the base:
- Press PLAY/STOP. The message plays.
- Press and release the erase button.
- To erase all reviewed messages from the base:
- Press and hold the erase button until the unit beeps.

#### To erase a message from the handset:

- Press flash/answerer/call waiting button to enter into the handset remote access operation.
- Press PLAY/STOP on the handset (the 2 button). The message plays.
- Press erase (the 0 button) to erase the message during message playback. NOTE: Erased messages cannot be restored.

### Leavina a Memo

#### Use the memo feature to leave a message.

- 1. Press and hold the memo button on the base. You must hold the button until you finish recording the memo.
- 2. Begin speaking after you hear the beep.
- 3 Release the memo button when finished

### Remote Access

#### **Cordless Handset**

- 1. Press the flash/answerer/call waiting button to access the answering
- 2. Use the corresponding handset keys just like you would use the base Answering System Setup). The button functions are located on the har example, to play messages
- Press the flash/answerer/call waiting button. The display shows ANSW
- Press 2 (PLAY/STOP)

#### Screening Calls from the Handset

Remote Access		Battery Sal	fety Precautions	Handset Sound Sign	als	Handset displays UNAVAILABLE
You may access the answering system with the cordless handset or from any tone-dial compatible telephone.		• Do not burn, disassemble, mutilate, or puncture. Like other batteries of this type,		Signal Meaning		Place the handset on the main base for re-register.
Cordless Handset			d be released which can cause injury.	A long warbling tone (with ringer on)	Signals an incoming call	<ul><li>An additional handset is in use.</li><li>Move closer to the base.</li></ul>
	button to access the answering system.		of fire or personal injury, use only the <b>Nickel-Cadmium</b> Metal Hydride (Ni-MH) battery listed in the User's Guide.	Three short beeps (several times)	Page signal	
2. Use the corresponding handset keys just like you would use the base buttons (see		<ul> <li>Keep batteries out of the reach of children.</li> </ul>		One long tone Two short beeps	Confirmation tone Error tone	Answering System Solutions Can't hear messages, beep, etc.
Answering System Setup). The button functions are located on the handset. For example, to play messages:		Remove batteries if storing over 30 days.		One beep every 7 seconds	Low battery warning	<ul> <li>Adjust speaker volume.</li> </ul>
<ul> <li>Press the flash/answerer/call waiting button. The display shows ANSWERER REMOTE.</li> </ul>		NOTE: The RBRC seal on the battery used in your Thomson Inc. product		Troubleshooting Tip		Time/Day setting is incorrect.
• Press 2 (PLAY/STOP).	5	indicates that we are participating in a program to collect and recycle the rechargeable battery (or batteries). For more information go to the RBRC web site at www.rbrc.org or call 1-800-8-BATTERY or contact a local recycling center.		Caller ID Solutions		• Set the time clock.
• When you are finished listening to	your messages, press the			<ul> <li>No display</li> <li>Fully charge (for 16 hours) or replace the battery.</li> </ul>		Answers on 10th ring
flash/answerer/call waiting button	-					• Make sure answering system is turned on.
Screening Calls from the H	Hanaset hen you can't hear the answering system.	Display Me	290023		er, make sure that the unit is connected to a	Answering system memory may be full. Erase some memory may be full.
When the answering system picks up:	nen you cun theur the unswering system.		es show the status of the phone or help you set up and use	non-switched electrical outlet. Unp plug it back in.	lug the AC power converter from the unit and	Incoming messages are incomplete
	button to access the answering system.	your phone.	es show the status of the phone of help you set up and use		display, you must be subscribed to Caller ID	<ul> <li>An extension phone may have been lifted as a message</li> <li>Answering system memory is full. Erase some message</li> </ul>
2. Listen as the caller leaves a message		ANSWERER REMOTE	Indicates the handset is accessing the answering system.	service through your local telephon		<ul> <li>You may have accidently pressed the PLAY/STOP butt.</li> </ul>
3. Press the TALK/CALL BACK button to		BLOCKED CALL	Caller information is blocked from transmission.	Caller ID incomplete		stopped the message.
answerer/call waiting button to stops	· · · · ·	BLOCKED	Caller name and number is blocked from transmission.		detects anything other than valid Caller ID I after the first ring. This message indicates the	Won't respond to remote commands
	ing System from Another	NAME/NUMBER		presence of noise on the line.	raiter the matring. This message indicates the	• You must use a tone-dial phone. This phone does not
Location	n from any touch-tone phone by entering your	DELETE ALL?	Prompt asking if you want to erase all Caller ID records.	Telephone Solutions		Make sure to enter the correct security code.
3-digit security code after you hear the		DELETE CALL ID?	Prompt asking if you want to erase the current Caller ID record that is shown on the display.	Handset can not link.		Did unit hang up? If you take no action for a period of
1. Dial the telephone number to which t		DELETE?	Prompt asking if you want to erase one of the 10 numbers	<ul> <li>If any handsets become inoperable seconds to re-register.</li> </ul>	, place it on the main base cradle for 20	Causes of Poor Reception
2. Enter the security code after you hea	ar the tone.		stored in the phone's outgoing memory.	No dial tone		Aluminum siding.
3. Follow the voice menu to use the ans		DELETED	Prompt confirming a CID record is erased.	Check or repeat installation steps		<ul> <li>Foil backing on insulation.</li> </ul>
The remote feature lets you perform the	ů – – – – – – – – – – – – – – – – – – –	EMPTY	Indicates a memory location is vacant.		onnected to a working electrical outlet.	Heating ducts and other metal construction can sh
To Poviou mossago	Press this Button	END OF LIST	Indicates there is no additional information in the Caller ID		s connected to the base unit and the modular	<ul> <li>You're too close to appliances such as microwaves,</li> <li>Atmospheria conditions such as storage storage</li> </ul>
Review message Play back messages	2	ENTER NAME	memory log. Prompt telling you to name the handset or enter a name for	phone jack?		<ul><li>Atmospheric conditions, such as strong storms.</li><li>Base is installed in the basement or lower floor of the statement of the statem</li></ul>
Stop message playback	2		one of the 10 memory locations.		phone jack and connect another phone to the n the second phone, the problem might be your	<ul> <li>Base is plugged into an AC outlet with other electro</li> </ul>
Erase message	0 (during message playback)	INCOMPLETE	Caller information is interrupted during transmission or	wiring or local service.		<ul> <li>Baby monitor is using the same frequency.</li> </ul>
Skip message	3	DATA	the phone line is excessively noisy.	<ul> <li>The handset might be out of range</li> </ul>	of the base. Move closer to the base.	<ul> <li>Handset battery is low.</li> </ul>
Turn answerer on/off Review voice menu options	7	LOW BATTERY	Indicates the handset battery is low and needs charging.	• Make sure the battery is properly ch	-	• You're out of range of the base.
	ing announcement by pressing any	NEW	Indicates call or calls have not been reviewed.	• Ensure the battery pack is installed	-	General Product Care
numbered key on the touch-to	one pad while the announcement	NO DATA	No Caller ID information was received.	<ul> <li>Did the handset beep when you pre- use indicator come on? The battery</li> </ul>	essed the TALK/CALL BACK button? Did the in may need to be charaed.	To keep your telephone working and looking good, follov
is playing. Then, you can enter answering system.	r your security code to access the	NO CALLS PAGING FRM BASE	Indicates no calls have been received.	Handset does not ring		<ul> <li>Avoid putting the phone near heating appliances a</li> </ul>
• •	· Cada	PAGING FRM BASE	Someone is paging the handset from the base. Indicates the handset needs to be registered before use.	• Make sure the ringer is set to ON, the	nis can be done through the handset setup	electrical noise (for example, motors or fluorescent
Changing the Security	ne answering system from another location is <b>1 2</b>	PRESS TALK KEY	Indicates the CID number is a Directory Dial Number (DDN)	menu Ringer Volume.		• DO NOT expose to direct sunlight or moisture.
3. You must use the handset to change the	he security code. With the phone <b>OFF</b> (not in TALK		and cannot be formatted.	<ul> <li>You may have too many extension some phones.</li> </ul>	phones on your line. Try unplugging	<ul> <li>Avoid dropping and other rough treatment to the p</li> <li>Clean with a soft cloth.</li> </ul>
mode), follow these steps:	button to display <b>ANSWERER REMOTE</b> . The	READY	Indicates the handset is registered and available for use.	<ul> <li>See solutions for "No dial tone."</li> </ul>		<ul> <li>Clean with a soft cloth.</li> <li>Never use a strong cleaning agent or abrasive point</li> </ul>
handset beeps once and announces	the Remote Access menu.	REPT	Repeat call message. Indicates that a new call from the same	You experience static, noise, or fading in	and out	the finish.
2. Press the *EXIT/tone button.			number was received more than once.	Change channels		• Retain the original packaging in case you need to s
3. Enter the new 3-digit security code.		TRANSFERRING	Indicates the call is being transferred from one handset to another.	<ul> <li>The handset may be out of range.</li> </ul>	1ove closer to the base.	Warranty Assistance
4. Press the *EXIT/tone button again. The	he unit announces the new code, pauses, beeps,	UNABLE TO DIAL	Indicates the CID or memory contents cannot be dialed.	<ul> <li>Relocate the base.</li> </ul>		If trouble is experienced with this equipment, for warran
and then announces the menu option	ons again.	UNABLE TO STORE	Indicates the CID or memory contents cannot be stored.	Charge the battery.		contact customer service at 1-800-448-0329. If the equ
Changing the Batte	ery	UNAVAILABLE	Indicates the handset is out of range.	<ul> <li>Make sure base is not plugged into household appliance.</li> </ul>	an electrical outlet with another	the telephone network, the telephone company may rec equipment until the problem is resolved.
CAUTION: To reduce the ris	sk of fire or personal injury, use only		Or an additional handset is in use. Or there has been a base power failure, in which case you	Unit beeps		Any unauthorized repairs, changes or modifications not
the Thomson Inc. approved model 5-2729 or Nickel-Me 5-2522, which are compatil	d Nickel-Cadmium (Ni-Cd) battery etal Hydride (Ni-MH) battery model ible with this unit.		must place all handsets on the main base cradle for 20 seconds to re-register.		seconds to reset the security code. If that r 16 hours.	Thomson Inc. could void the user's authority to operate to n how to obtain a replacement unit, refer to the warrar
•	in TALK mode) before you replace battery.	UNKNOWN	The incoming call is from an area not serviced by Caller ID or	• See solutions for "No dial tone."		customer service at <b>1-800-448-0329</b> . Or refer inquiries to:
		NAME/CALLER/	caller information is not sent.	Replace the battery.		Thomson Inc.
<ol><li>Remove the battery compartment do</li></ol>	oor.					
, ,	oor. battery pack and remove the battery pack from	NUMBER	System Display Messaaes	Memory dialing <ul> <li>Make sure you correctly program the</li> </ul>	ne memory location keys.	Manager, Consumer Relations P O Box 1976
<ol> <li>Disconnect the cord attached to the the handset.</li> <li>Insert the new battery pack and conr</li> </ol>		NUMBER Answering	System Display Messages	, ,		Manager, Consumer Relations P O Box 1976 Indianapolis, IN 46206
<ol> <li>Disconnect the cord attached to the the handset.</li> <li>Insert the new battery pack and conr compartment.</li> </ol>	battery pack and remove the battery pack from nect the cord to the jack inside the battery	NUMBER Answering The following me	System Display Messages essages show the status of the answering ou set up and use the system.	<ul> <li>Make sure you correctly program th</li> <li>Make sure you follow the proper did</li> <li>You may need to reprogram number</li> </ul>		Manager, Consumer Relations P O Box 1976 Indianapolis, IN 46206 Attach your sales receipt to this booklet for future refere
<ol> <li>Disconnect the cord attached to the the handset.</li> <li>Insert the new battery pack and conr compartment.</li> <li>Put the battery compartment door be</li> </ol>	battery pack and remove the battery pack from nect the cord to the jack inside the battery pack on.	NUMBER Answering The following me	essages show the status of the answering	<ul> <li>Make sure you correctly program th</li> <li>Make sure you follow the proper did</li> <li>You may need to reprogram number battery replacement.</li> </ul>	aling sequence.	Manager, Consumer Relations P O Box 1976 Indianapolis, IN 46206 Attach your sales receipt to this booklet for future refere
<ol> <li>Disconnect the cord attached to the the handset.</li> <li>Insert the new battery pack and conr compartment.</li> <li>Put the battery compartment door be 6. Place handset in the base to charge.</li> </ol>	battery pack and remove the battery pack from nect the cord to the jack inside the battery	NUMBER Answering The following me system or help ye	essages show the status of the answering ou set up and use the system.	<ul> <li>Make sure you correctly program th</li> <li>Make sure you follow the proper did</li> <li>You may need to reprogram number battery replacement.</li> </ul>	aling sequence.	Manager, Consumer Relations P O Box 1976 Indianapolis, IN 46206 Attach your sales receipt to this booklet for future referen product was purchased or received as a gift. This inform should be required during the warranty period.
<ol> <li>Disconnect the cord attached to the the handset.</li> <li>Insert the new battery pack and conr compartment.</li> <li>Put the battery compartment door be</li> <li>Place handset in the base to charge. (for 16 hours) prior to first use or whete the the set of the the test of test of the test of test of</li></ol>	battery pack and remove the battery pack from nect the cord to the jack inside the battery pack on. Allow the handset battery to properly charge	NUMBER Answering The following me system or help ye 0-59	essages show the status of the answering ou set up and use the system. Indicates the total number of messages.	<ul> <li>Make sure you correctly program the</li> <li>Make sure you follow the proper did</li> <li>You may need to reprogram number battery replacement.</li> <li>Out of range</li> <li>Move closer to the base.</li> </ul>	aling sequence. Pers into memory after a power outage or	Manager, Consumer Relations P O Box 1976 Indianapolis, IN 46206 Attach your sales receipt to this booklet for future referer product was purchased or received as a gift. This inform should be required during the warranty period. Purchase date
<ol> <li>Disconnect the cord attached to the the handset.</li> <li>Insert the new battery pack and conr compartment.</li> <li>Put the battery compartment door be</li> <li>Place handset in the base to charge. (for 16 hours) prior to first use or whete the the set of the the test of test of</li></ol>	battery pack and remove the battery pack from nect the cord to the jack inside the battery back on. Allow the handset battery to properly charge then you install a new battery pack. If you do	NUMBER Answering The following me system or help ye 0-59	essages show the status of the answering ou set up and use the system. Indicates the total number of messages. The voice time/day stamp needs to be set.	<ul> <li>Make sure you correctly program the</li> <li>Make sure you follow the proper dide</li> <li>You may need to reprogram number battery replacement.</li> <li>Out of range</li> <li>Move closer to the base.</li> <li>Reset the battery. Unplug the batter</li> </ul>	aling sequence.	Manager, Consumer Relations P O Box 1976 Indianapolis, IN 46206 Attach your sales receipt to this booklet for future referen product was purchased or received as a gift. This informa should be required during the warranty period.

Phone with tone service dials out in pulse mode

• Make sure phone is in tone dialing mode

Make sure phone is in pulse dialing mode.

Phone won't dial out with pulse service

announcement.

Answering system memory is full.

Answering system is being accessed remotely from another location.

The system is recording a memo or an

F (blinkina)

Six bars

(blinking)

LA (Line Access)

#### in base for re-register.

/ be full. Erase some messages.

been lifted as a message is received.

ull. Erase some messages.

ed the PLAY/STOP button during playback and

. This phone does not support pulse (rotary) dialing.

action for a period of time, it automatically hangs up.

eception

tal construction can shield radio signals.

es such as microwaves, stoves, computers, etc

- ment or lower floor of the house. utlet with other electronic devices

nd looking good, follow these guidelines:

heating appliances and devices that generate , motors or fluorescent lamps).

uah treatment to the phone.

agent or abrasive powder because this will damage

g in case you need to ship the phone at a later date.

quipment, for warranty information, please -448-0329. If the equipment is causing harm to one company may require that you disconnect the

s or modifications not expressly approved by s authority to operate this product. For instructions init, refer to the warranty included in this guide or call

ooklet for future reference or iot down the date this d as a gift. This information will be valuable if service

### Limited Warranty

What your warranty covers:

Defects in materials or workmansh

For how long after your purchase:

• One year from date of purchase The warranty period for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first

#### What we will do:

• Provide you with a new or, at our option, a refurbished unit. The exchange unit is under warranty for the remainder of the original product's warranty period.

#### How you get service:

- Properly pack your unit. Include any cables, etc., which were originally provided with the product. We recommend using the original carton and packing materials.
- "Proof of purchase in the form of a bill of sale or receipted invoice which is evidence that the product is within the warranty period, must be presented to obtain warranty service." For al firms, proof of first rental is also required. Also print your name and address and a description of the defect. Send via standard UPS or its equivalent to Thomson Inc
  - 11721 B Alameda Ave Socorro. Texas 7992
- Insure your shipment for loss or damage. Thomson Inc. accepts no liability in case of damage
- A new or refurbished unit will be shipped to you freight prepaid.

#### What your warranty does not cover:

- Customer instruction. (Your Owner's Manual provides information regarding operating instructions and user controls. Any additional information, should be obtained from your doalor
- Installation and setup service adjustments.
- Batteries
- Damage from misuse or neglect. Products which have been modified or incorporated into other products
- Products purchased or serviced outside the USA. Acts of nature, such as but not limited to lightning damage

### Product Registration:

• Please complete and mail the Product Reaistration Card packed with your unit. It will make it easier to contact you should it ever be necessary. The return of the card is not required for warrantv coveraae.

#### Limitation of Warranty

- THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY THOMSON INC. ITS AGENTS OF EMPLOYEES SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS MADDANITV
- REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER THOMSON INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THI SCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS O THE STATE OF INDIANA. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY MPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE

#### How state law relates to this warranty:

- Some states do not allow the exclusion nor limitation of incidental or consequential damage or limitations on how long an implied warranty lasts so the above limitations or exclusions may not apply to you.
- This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.
- If you purchased your product outside the USA:

• This warranty does not apply. Contact your dealer for warranty information.

### Accessory Information

DESCRIPTION	MODEL NO.
Handset Replacement Battery	5-2729 (Ni-CD)
Handset Replacement Battery	5-2522 (Ni-MH)
Power adaptor	5-2754 (gray)
Power adaptor	5-2732 (black)
Optional/Additional handset cradle	5-2751 (gray)
Optional/Additional handset cradle	5-2771 (black)

To place order, have your Visa, MasterCard, or Discover Card ready and call toll-free 1-800-338-0376. A shipping and handling fee will be charged upon ordering. We are required by law to collect appropriate sales tax for each individual state, country, and locality to which the merchandise is being sent. Items are subject to availability. Prices are subject to change without notice.

### Instructions For Additional Handset(s)

IMPORTANT: You can only use one handset at a time and there is NO conference and intercom features for these units. If the TALK/ CALL BACK button is pressed on one handset while another handset is in use, UNAVAILABLE shows on the display.

### Parts Checklist

Make sure your package includes the items shown here.



### Installing the Handset Battery

NOTE: You must connect the handset battery before use.



CAUTION: To reduce the risk of fire or personal injury, use only the Thomson Inc. approved Nickel-Cadmium (Ni-Cd) battery model 5-2729 or Nickel-Metal Hydride (Ni-MH) battery model 5-2522, which are compatible with this unit.

1. Locate battery and battery door which are packaged together inside a plastic bag and are separate from the handset.

- 2. Locate the battery compartment on the back of the handset.
- 3. Plug the battery pack cord into the jack inside the compartment.

#### NOTE: To ensure proper battery installation, the connector is keyed and can be inserted only one way.

- 4. Insert the battery pack.
- 5. Close the battery compartment by pushing the door up until it snaps into place.
- 6. Place the handset in the base to charae.

### **Extra Charging Cradle**

. Plug the AC power converter of the extra charging cradle into the electrical outlet.



- 2. Place the handset in the extra charging cradle. The charge indicator turns on, verifying the battery is charging.
- 3. Allow the phone to charge for 16 hours.

### Registration

YOU MUST REGISTER THE HANDSET TO THE MAIN BASE BEFORE USE

After the optional handset has charged for 16 hours on the extra charger, place it on the main base station for 20 seconds, it will then automatically register

NOTE: PLEASE REGISTER shows on the display if the handset has not been registered. Once a handset has completed registration successfully, READY will show on the handset's display.

NOTE: In case of a power failure, the handsets may display UNAVAILABLE when the TALK/CALL BACK button is pressed. You must then place all handsets on the main base cradle for 20 seconds to re-register.