

#### FCC REGISTRATION INFORMATION

Your telephone equipment is registered with the Federal Communications Commission and is in compliance with parts 15 and 68 FCC Rules and Regulations.

Notification to the Local Telephone Company

On the bottom of this equipment is a label indicating, among other information, the FCC Registration number and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide

this information to your telephone company. The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact

- vour local telephone company. • This equipment may not be used on coin service provided by the
- Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.
- Notice must be given to the telephone company upor ection of your telephone from your line Rights of the Telephone Company
- Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1)

you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and The telephone company may make changes in its communications

facilities, equipment, operations of procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to

> ATLINKS USA, Inc 10330 North Meridian Str Indianapolis, IN 46290 © 2000 ATLINKS USA, Inc. Trademark(s) ® Registered Marca(s) ® Registrada(s

#### INTRODUCTION

Your Caller ID phone stores and displays specific information, provided by your local telephone company, to subscribers of Caller ID or similar caller identification services. You must subscribe to one of these services in

Your Caller ID phone enables you to:

- Identify callers before you answer the phone
- · View the time and date of each incoming call.
- Handset records 40 Caller ID records sequentially.
- Know who called while you were away

To get the most from your new phone, we suggest that you take a few minutes right now to read through this user's

**IMPORTANT:** In order to use this unit, you must subscribe to either the standard Name/Number Calle ID Service or Caller ID with Call Waiting Service. To know who is calling while you are on the phone, you must subscribe to Caller ID with Call Waiting Service.

**IMPORTANT:** Because cordless phones operate on electricity, you should have at least one phone in your nome that isn't cordless, in case the power in your ome goes out.





# BEFORE YOU BEGIN

# PARTS CHECKLIST

Make sure your package includes the items shown here









Mounting bracket





Remote Caller ID box Anchors and screws

# MODULAR JACK REQUIREMENTS

You need an RJ11 type modular jack, which is the most common type of phone jack and might look like the one pictured here. If you don't have a modular jack, call your local phone company to find out how to get one



**INSTALLATION NOTE:** Some cordless telephones operate at frequencies that may cause interference to nearby TVs and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV or VCR. If such interference continues, move the cordless telephone farther away from the TV or VCR.

#### DIGITAL SECURITY SYSTEM


Your cordless phone uses a digital security system to provide protection against false ringing, unauthorized access, and charges to your phone line.

When you place the handset in the base, the unit verifies its security code. After a power outage or battery replacement, you should place the handset in the base for about 20 seconds to reset the code.

# INSTALLATION

#### **DESKTOP INSTALLATION**

NOTE: For desktop charging only, the handset is able to charge facing up or down.



- 1. Place the handset in the base.
- 2. Raise the base antenna
- 3. Plug the power supply cord into an AC outlet. The CHARGE/IN USE indicator comes on indicating that the battery is charging

Allow the phone to charge for 12 hours before using the first time. If you don't charge the phone properly (for 12 hours) when you first set up the phone, performance of the battery will be


- 4. After charging, connect the telephone line cord to the wall iack.
- 5. Set the RINGER switch on the handset to ON.

**NOTE**: The phone automatically defaults to touchtone dialing. To change to pulse (rotary) dialing, see "Tone/Pulse Dialing". If you don't know which type of service you have, check with the phone company.

#### WALL MOUNT INSTALLATION


Because it is necessary to charge the handset for 12 hours prior to connecting the phone for use the first time, it is better to leave the unit on a flat surface during initial charge before attempting to hang it on the wall

- 1. Remove the handset hook; turn it upside down, and put it back in the slot. You need to do this so the handset doesn't fall out of the base when it is on the wall.
- 2. Set the RINGER switch on the handset to ON.
- Place the handset in the base.
- 4. Plug the power supply into the base and then into an



The CHARGE/IN USE indicator comes on indicating that the battery is charging.

> Allow the phon to charge for 12 hours before using the first time. If vou don't charge the phone properly (for 12 hours) when vou first set up the performance of the battery will be




After charging. plua telephone line cord into the wall jack and store excess phone cord in wall mount bracke 6 Attach the wall mount bracket by inserting the two tabs

- at the top and then snapping the tab at the bottom into Y. Slip the mounting holes over the wall plate posts and
- slide the unit down firmly into place. (Wall plate not included.) Raise the base antenna.

NOTE: The phone automatically defaults to touchtone dialing. To change to pulse (rotary) dialing, see "Tone/Pulse Dialing". If you don't know which type of service you have, check with the phone company

# CALLER ID BOX INSTALLATION



Required Equipment: Drill, 3/16" Drill Bit, Phillips Head

- 1. Determine a suitable location for the unit which is visible from various locations. Be sure the unit is close to an AC outlet, unless you intend to operate the unit
- 2. Locate the mounting template. A guide for the size of the remote unit is included.
- 3. Fold the template along the horizontal dashed line.
- 4. Place the template on the wall, and make sure the horizontal dashed line (folded line) is level. You might want to do this visually only, but a level will work best.
- 5. On the wall, mark the locations shown on the template for holes and drill a 3/16" diameter hole, at least one
- 6. Press one of the plastic anchors into each of the holes and place one screw in each of the anchors. Turn the screw until the head of the screw is 1/8" above the surface of the wall
- 7. Slip the mounting holes on the remote unit over the screw heads, and slide the unit firmly into place.


# POWERING THE UNIT

Your Caller ID box uses an AC power supply or 8 C-size alkaline batteries for receiving caller ID records.

IMPORTANT: You will have a limited amount of time to replace the batteries before the memories are lost. Please read the instructions before replacing the batteries and have the batteries ready to be inserted beforehand.

To use the power supply, plug one end of the power supply into the power jack on the back of the Caller ID box and the other end into an AC outlet.

# BATTERY INSTALL




- Remove the screw on the bottom of the Caller ID unit. and open the battery door.
- 2. Insert 8 C-size batteries as shown on the diagram.
- 3. Replace the battery compartment door securely and

NOTE: If the low battery icon appears in the display, you need to replace the batteries. It is important that you replace the batteries as soon as possible to aintain Caller ID operation.

**IMPORTANT:** If you are not going to use the telephone for more than 30 days, remove the batteries because they may leak and damage the unit.

CAUTION: Use only the ATLINKS USA 5-2497 power supply that came with this unit. Using other power supplies may damage the unit.

# CORDLESS PHONE BASICS



## RECEIVING A CALL

- 1. Check the display to see who is calling.
- 2. Press the TALK button. the phone beens

# Making a Call

To make a call, press the TALK button before you dial and press it again to hang up.

## REDIAL

While the phone is on, press the REDIAL button to redial the last number you dialed (up to 32 digits). If you get a busy signal, and want to keep dialing the number, just press REDIAL again (you don't have to turn the phone off and back on).

## FLASH

Use the FLASH button to activate custom calling services such as call waiting or call transfer, which are available through your local phone company.

TIP: Don't use the TALK button to activate custom calling services such as call waiting, or you'll hang up the phone.

#### CHANNEL BUTTON

While talking, you might need to manually change the channel in order to get rid of static. Press and release the CHANNEL button to advance to the next clear channel.

# TEMPORARY TONE

This feature enables Pulse (rotary) service phone users to access touch-tone services offered by banks, credit card companies, etc., by pressing the TONE button to temporarily make the phone touch-tone compatible. To get information about your bank account, for example, you

- 1. Call the bank's information line.
- 2. Press the TONE button (\*) after your call is answered.
- 3. Follow the voice instructions to complete your transaction
- 4. Hang up when finished. The phone returns to Pulse (rotary) service.

# FINDING THE HANDSET

This feature helps to locate a misplaced handset.

Press the PAGE button on the base. The handset beeps continuously for about 2 minutes or until you press any button on the handset. You can also press PAGE again to

NOTE: The ringer does not have to be on for this feature to work.

## RINGER SWITCH

The RINGER switch must be ON for the handset to ring during incoming calls.

# TONE/PULSE DIALING

This adjustment allows you to select tone (touch-tone) or pulse (rotary) mode dialing. The phone is automatically set for touch-tone use.

# TONE

- 1. Make sure the phone is OFF
- 2. Press and hold the CHANNEL button for 2 seconds until the phone beeps
- 3. Press TONE\*

## REVIEWING RECORDS

- As calls are received and stored, the display is updated to
- let you know how many calls have been received
- Press the arrow down button to scroll through the call records from the most recent to the oldest
- Press the arrow up button to scroll through the call
- records from the oldest to the newest
- the phone is **OFF**. Then press REDIAL. To dial the number, press REDIAL again. The number dials automatically.

## DELETING RECORDS

shown in the display or all records.

# DELETING THE CURRENT RECORD

- 2. Use the arrow buttons to display the desired Caller ID CHARGE/IN USE indicator
  - 3. Press DELETE. The display shows ERASE CALL ID?
  - 4. Press DELETE again to erase the record.

#### Make sure the phone is OFF.

2. Use the arrow buttons to display the desired Caller ID.

- 3. Press and hold DELETE. The display shows ERASE ALL?
- 4. Press DELETE again to erase all records

# DIALING A CALLER ID NUMBER

- 1. Make sure the phone is OFF.
- 2. Use the arrow buttons to display the desired Caller ID record.
- 3. Press CALL BACK. The number dials automatically.

# CHANGING THE NUMBER FORMAT

The FORMAT button lets you change the format of the service from your phone company, you are able to see who displayed number. The available formats are as follows.

3-digit area code + 7-digit telephone

**7-digit** 7-digit telephone number.

long distance code "1" + 3-digit area code + 11-digit 7-digit telephone number.

- . Use the arrow buttons to scroll to the number you want to call back. 2. If the number will not dial as shown, press the FORMAT
- button. Repeat if necessary, until the correct number of digits are shown 3. Press CALL BACK. The number dials automatically.
- **NOTE:** To clear the local area code, press and hold CHANNEL until AREA CODE appears. Then enter

# **MEMORY**

Store up to ten 24-digit numbers in memory for guick dialing. This memory feature is in addition to the 40 Caller ID records that can be stored in the Caller ID memory log.

## STORING A NUMBER IN MEMORY

- 1 Make sure the phone is OFF
- 2 Press the MEMORY huttor
- 3. Press the memory location number (0-9).
- 4. Press MEMORY again. The display shows ENTER

**NOTE:** If you don't want to enter the name, skin step 5

5. Use the keypad to store a name (up to 15 characters). More than one letter or character is stored in each of the number keys. For example, to enter Joe Smith. press 5 for J: press 6 three times for O: press 3 two times for E; press 1 to enter a space before you start entering the last name; press 7 four times for S; press 6 for M; press 4 three times for I; press 8 for T; and 4 two times for H.

in the same number key, you must press FORMAT between the letters. For example, if you enter Barb press 2 two times for B: press FORMAT: press 2 for A: 7 three times for R: and 2 two times for R You need to press FORMAT between the B and the A since they are stored within the same number key.

If you're using two letters consecutively that are stored

(up to 24 digits). To add a pause, See "Inserting a Pause

memory label provided You will also be able to view

- 7. Use the keypad to enter the number you want to store
  - 9. Record whose number is stored in the location on the

Use the same procedure to change a stored number as you do to store a number-vou're just replacing the phone

# **DIALING A STORED NUMBER**

- 1. Make sure the phone is **ON** by pressing the TALK
  - location. The number dials automatically.
- 1. Make sure the phone is OFF.
- 2. Press MEMORY. 3. Use the arrow buttons to scroll through the numbers
- stored in memory until the desired number is shown. 4. Press CALL BACK. The numbers dials automatically.

**IMPORTANT:** If you make test calls to emergency numbers stored in memory, remain on the line and briefly explain the reason for the call to the dispatcher Also, it's a good idea to make these calls in off-peak hours, such as early morning or late evening.

# INSERTING A PAUSE IN THE DIALING SEOUENCE

Press the REDIAL button to insert a delay in the dialing sequence of a stored telephone number when a pause is needed to wait for a dial tone (for example after you dial 9 for an outside line, or to wait for a computer access tone). Each pause counts as 1 digit in the dialing sequence.



#### PULSE 1. Make sure the phone is OFF.

VOICE MESSAGING

messaging service and you

subscribe to it, the CHARGE

indicate there is a message

after the message has been

CALLER ID FEATURES

This unit receives and displays information transmitted by

your local phone company. This information can include

number, date, and time. The unit can store up to 40 calls

10:51 A.M. 8/11 NEW CALL # 25

CALLER ID WITH CALL WAITING

Provided you subscribe to Caller ID with Call Waiting

is calling when you hear the call waiting beep. The caller

identification information appears in the display after you

• Press the FLASH button to put the current person on

hold so that you can answer the incoming call.

IMPORTANT: In order to use this unit, you must

subscribe to either the standard Name/Number Caller

ID Service or Caller ID with Call Waiting Service. To

know who is calling while you are on the phone, you

must subscribe to Caller ID with Call Waiting Service

When you receive a call, the information is transmitted by

When the memory is full, a new call automatically replaces

the oldest call in memory. NEW appears in the display for

**NOTE:** Check with your local phone company

the phone company to your Caller ID telephone between

RECEIVING AND STORING CALLS

calls received that have not been reviewed.

regarding name service availability

the first and second ring.

3175554231

SMITH JOHN

the phone number, date, and time; or the name, phone

waiting. It stops flashing

Provided your phone

company offers voice

IN USF indicator on the

base flashes when the

phone is not in use to

reviewed.

for later review.

VOLUME

- 2. Press and hold the CHANNEL button for 2 seconds until
- 3. Press #

The VOLUME buttons control the volume of the handset's

# To display the last Caller ID record reviewed, make sure

Use the DFI FTF button to erase the record currently

## 1. Make sure the phone is OFF.

- 6. Press MEMORY. The display shows ENTER TEL NUMBR. DELETING ALL RECORDS
  - in the Dialing Sequence". 8. Press MEMORY again to store the number.

# CHANGING A STORED NUMBER

the name and number in the display

number with a different one.

2. Press MEMORY. 3. Press the number (0-9) for the desired memory

## REVIEWING AND DELETING STORED NUMBERS

- 1. Press MEMORY, then use the arrow keys to view the
- 2. While the entry is displayed, press DELETE to delete the entry. The display shows ERASE MEMO?
- 3. Press DELETE a second time to delete the entry.

#### CHAIN DIALING FROM MEMORY


Use this feature to make calls which require a sequence of numbers such as using a calling card for a frequently called long distance number. Basically, you dial each part of the sequence from memory. The following example shows how you can use chain dialing to make a call through a long distance service:

The Number For	Memory Location
Long distance access number	7
Authorization code	8
Frequently called long distance	number 9

- 1. Make sure the phone is ON
- 2. Press MEMORY and then press 7.
- 3. When you hear the access tone, press MEMORY and then press 8.
- 4. At the next access tone, press MEMORY and then 9.

**TIP:** Wait for the access tones before pressing the next memory button, or your call might not go through.

# CALLER ID BOX BASICS



MENU bu	utton		DELETE button	
TIME MO	DDE		CALLER ID MODE	
DATE	TIME	82.3F	GEORGE ANDERSO	ΊŊ
12/31	12:20	#CRLL	317-555-4231	# (
,		32 NE⊎	12/30 12:25 <sup>Aft</sup>	5

# REMOTE UNIT IDENTIFICATION CODE SET UP

- 1. Place the remote Caller ID box next to the base.
- 2. Press and hold the MENU button on the box for 3 seconds. The display shows SET CODE.
- 3. Within 10 seconds, press and hold the PAGE button on the base for 3 seconds
- 4. The base will automatically send the ID code to the remote Caller ID box. The display shows ID SET and the unit confirms with a tone.
- 5. The display will then return to the default display.

# SETTING THE LCD CONTRAST

- 1. Press the MENU button. The display shows 1-SET
- 2. Use the arrow buttons to increase or decrease the contrast.
- 3. The default setting is 2.
- 4. Press the MENU button again to save the selection and proceed to the next step.

# SETTING THE RINGER ON/OFF

- 1 The display shows 2-SET RINGER
- 2. Use the arrow buttons to turn the ringer ON or OFF. The nger icon will not display if the ringer is OFF.
- 3. Press the MENU button again to save the selection and

#### SETTING THE TIME/DATE

- 1 The display shows 3-SETTIME
- 2. The first digit for the month will begin to blink.
- 3. Use the arrow buttons to increase or decrease the
- 4. Press DELETE to set the date.
- 5. The first digit for the day will begin to blink.
- 6. Use the arrow buttons to increase or decrease the day.
- 7. Press DELETE again to set the time. The hour "12" will start blinking.
- 8. Use the arrow buttons to increase or decrease the hour.
- 9. Press DELETE again to set the minute. The minute "00" will start blinking
- 10. Use the arrow buttons to increase or decrease the
- 11. Press the MENU button again to save the selection and proceed to the next step.

NOTE: The time and date will be automatically saved the Caller ID box if an incoming call with Caller ID nformation is received.

# SETTING THE TEMPERATURE DISPLAY °C/F

- 1. The display shows 4 SETTEMP. The default setting is °E
- 2. Use the arrow buttons to change from °C and °F.
- 3. Press the MENU button again to save the selection and return to stand-by mode.

#### DISPLAY IN STANDBY

When not in use, the display shows the date, time, room temperature and total number of new calls.

# DISPLAY DURING RINGING

- If the remote Caller ID box is operating on battery power, the display will only show information when a Caller ID call comes in.
- While in standby mode, if no caller ID message is received during an incoming call, the display shows NO
- Caller ID information will be displayed for several seconds after a call is received

# DISPLAY IN ON STATE

- If the remote caller ID box is plugged into an AC outlet, the display waits for Caller ID data from the base.
- The Caller ID display format will be the same as the Caller ID received during ringing.

## CALLER'S NUMBER/NAME DISPLAY

When you receive a call, the caller's number, name and date/time of call will be stored in the Caller ID memory. Up to 99 Caller-ID records can be stored in the remote unit. When the memory is full, the oldest calls are deleted to make room for newer calls.

 The icon NFW displays when a new Caller ID record is received or that record is not viewed during standby.

# REVIEW CALLER ID RECORDS

As calls are received and stored, the display is updated to let you know how many calls have been received.

- To review the Caller ID records, press either of the arrow buttons.
- The display shows END OF LIST when end of list is

#### ERASE CALLER ID RECORD

#### To erase a single Caller ID record:

- 1. Use the arrow buttons to select any stored record.
- 2. Press DELETE button. The display will show ERASE
- 3. Press DELETE button again to erase the entry.

#### To Erase All Caller ID records:

- 1. Use the arrow buttons to select any stored record
- 2. Press and hold DELETE button for 3 seconds. The display shows FRASF ALL ?
- 3. Press DELETE button again to erase all stored records

# VOICE MESSAGE WAITING **NOTIFICATION**

Provided your phone company offers voice messaging service and you subscribe to it, this feature allows callers to leave messages while you talk on the phone or if you are unable to answer the call. A Waiting Icon will display if you have a voice mail message. The icon will not display after the message has been reviewed

# LOW BATTERY NOTIFICATION

The low battery displays whenever there is low battery or when no batteries are installed.

#### ANNOUNCING CALLS IN MEMORY

Press the arrow buttons simultaneously to announce all the Caller ID records (from latest to oldest) with all Name/ Number/Date/Time information.

# HEADSET AND BELT CLIP **OPERATION**

# CONNECTING A HEADSET TO THE HANDSET

For hands free conversation, connect the headset (optional) to the HEADSET jack as shown. The handset receiver and microphone are disabled when the headset is connected

#### comfortably on top of your head and over your ear Move the microphone to approximately 2 to 3 inches from your mouth

Adjust the headset to resi

 Press the TALK button to answer or place a call before using the headset.

# CONNECTING THE BELT CLIP


on each side of the · Attach the belt clip by inserting the sides of

the belt clip into the

slots. Snap the ends of

the belt clip into place.

There are two slots, one



# CHANGING THE BATTERY

Make sure the telephone is **OFF** before you replace battery.

- 1. Remove the battery compartment 2 Disconnect the cord attached to
- the battery pack and remove the battery pack from the handset. 3. Insert the new battery pack and
- connect the cord into the jack inside the handset. 4. Put the battery compartmen
- door back on. Place handset in the base to charge. If you don't charge the handset battery properly (for 12 hours) when you first set up the phone and/or when you install a new battery pack, the battery's long-term performance will be

# BATTERY SAFETY PRECAUTIONS

- Do not burn, disassemble, mutilate, or puncture. Like other batteries of this type, toxic materials could be released which can cause injury
- To reduce the risk of fire or personal injury, use only the battery listed in the User's Guide.
- . Keep batteries out of the reach of children
- · Remove batteries if storing over 30 days.



NOTE: The RBRC seal on the battery used in your ATLINKS USA product dicates that we are participating in a rogram to collect and recycle Nickel Cadmium batteries throughout the United States. Please call 1-800-8-BATTERY for information or

# GENERAL PRODUCT CARE

To keep your telephone working and looking good, follow these guidelines:

- Avoid putting the phone near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose to direct sunlight or moisture.
- · Avoid dropping the handset, as well as other rough treatment to the phone.
- · Clean the phone with a soft cloth.
- · Never use a strong cleaning agent or abrasive powder because this will damage the finish.
- · Retain the original packaging in case you need to ship the phone at a later date.
- · Periodically clean the charge contacts on the handset and base with a clean pencil eraser.

# Causes of Poor Reception

- Aluminum siding
- Foil backing on insulation
- · Heating ducts and other metal construction can shield radio signals
- You're too close to appliances such as microwaves. stoves, computers, etc.
- Atmospheric conditions, such as strong storms
- Base is installed in the basement or lower floor of the
- Base is plugged into an AC outlet with other electronic
- Baby monitor is using the same frequency
- · Handset battery is low.

FRASE ALL?

You're out of range of the base

# Message Indicators

The following indicators show the status of a message or of the unit.

ROR	Caller information has been interrupted during transmission or the phone is excessively noisy.
TER NAME	Prompt telling you to enter a name for one of the 10 memory locations.

Prompt asking if you want to erase all

	Caller ID records.
RASE CALL ID?	Prompt asking if you want to erase the current Caller ID record that is shown on the display.

ERASE MEMO? Prompt asking if you want to erase one of the 10 numbers stored in the phone's outgoing memory. FND OF LIST Indicates there is no additional

information in the Caller ID memory NEW Indicates call or calls have not been

UNKNOWN The incoming call is from an area not serviced by Caller ID or the information was not sent

PAGING YOU Someone has pressed the PAGE button on the base. BLOCKED

The person is calling from a number that has been blocked from transmission. Repeat call message. Indicates that a

new call from the same number was received more than once. NO DATA No Caller ID information was received

Indicates the time is morning.

Indicates the time is afternoon

Memo record is being displayed on the handset. CALL Caller ID record is being displayed on the handset Indicates a memory record number.

# TELEPHONE

TROUBLESHOOTING TIPS

Solution

Caller ID Error Message • The unit displays this

line.

Is battery fully charged?

Try replacing the battery.

• If you are using AC power,

make sure that the unit is

switched electrical outlet.

Disconnect the unit from

the plug and plug it in

• Did you order Caller ID

telephone company?

message if it detects

Caller ID information

anything other than valid

during the silent period

after the first ring. This

message indicates the

presence of noise on the

service from your local

connected to a non-

CALLER ID

Problem

No Display

#### Problem Solution No dial tone Check installation: Is the base power cord

outlet? - Is the telephone line cord connected to the base unit and the wall iack?

connected to a working

- Disconnect the base from the wall jack and connect another phone to the same iack. If there is no dial tone in the second phone, the problem might be your wiring or local service.
- Is the handset out of range of the base? • Make sure the battery is
- properly charged (12 hours). • Is the battery pack
- installed correctly? • Did the handset beep when you pressed the TALK button? Did the CHARGE/ IN USE indicator come on? The battery may need to be charged.
- Dial tone is OK, but Make sure the tone/ can't dial out pulse setting is programmed correctly.
- Handset does not ring Make sure the RINGER
  - switch on the handset is turned to ON. You may have too many extension phones on you line. Try unplugging some
  - phones • See solutions for "No dial

#### noise, or fading in and out

Unit beeps

- You experience static, Change channels
  - Is handset out of range?
  - Move closer to the base. · Does the base need to be relocated?
  - Charge battery. Make sure base is not plugged into an outlet with
  - another household appliance.

#### • Place handset in base for 20 seconds to reset the security code. If that doesn't work, charge

battery for 12 hours. • Clean charging contacts on handset and base with a soft cloth, or an eraser.

Replace battery.

correctly?

memory location keys

• Did you follow proper

• Make sure the tone/pulse

setting is programmed

dialing sequence?

- See solutions for "No dial
- Did you program the
- correctly. • Did you reprogram LIMITED WARRANTY numbers into memory after power outage or

# battery replacement?

# HANDSET/CALLER ID BOX SOUND **S**IGNALS

Memory Dialing

710111110	
Signal	Meaning
A long warbling tone with ringer on)	Signals an incoming call
One short beep, one ong beep (several times)	Page signal
ne short beep	Key beep signal
hree short beeps	Error signal
our short beeps	Low battery warning

Confirmation tone

# Two long beeps SERVICE

The FCC requires this product to be serviced only by the manufacturer or its authorized service agents. In accordance with FCC requirements, changes or modifications not expressly approved by ATLINKS USA could void the user's authority to operate this product. For instructions on how to obtain service, refer to the warranty included in this user's guide or contact Consumer Information at 1-800-448-0329.

Attach your sales receipt to the booklet for future reference or jot down the date this product was purchased or received as a gift. This information will be valuable if service should be required during the warranty period. Purchase date Name of store

#### Interference Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any nterference received, including interference that may cause

This equipment has been tested and found to comply with the hits for a Class B digital device, pursuant to Part 15 of the FCC les. These limits are designed to provide reasonable protection

against harmful interference in a residential installation This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation

If this equipment does cause harmful interference to radio or television recention, which can be determined by turning the requipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna (that is, the antenna)

- or radio or television that is "receiving" the interference
- Regrient or relocate and increase the separation between the nmunications equipment and receiving antenna
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is
- Consult the dealer or an experienced radio/TV technician for

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering conies.

#### What your warranty covers:

What we will do:

- Any defect in materials or workmanship.
- For how long after your purchase One year.
- (The warranty period for rental units begins with the first rental or 45 days from date of shipment to the rental firm, which

#### The exchange unit is under warranty for the remainder of the original product's warranty period

How to make a warranty claim: Properly pack your unit. Include any cables, etc., which were originally provided with the product. We recommend using the

• Provide you with a new or, at our option, a refurbished unit.

original carton and packing materials. Include evidence of purchase date such as the bill of sale. Also print your name and address and a description of the defect. Send via standard UPS or its equivalent to:

# Thomson Consumer Electronics, Inc. 11721 B Alameda Ave.

- Socorro, Texas 79927 Pay any charges billed to you by the Exchange Center for service not covered by the warranty.
- Insure your shipment for loss or damage. Thomson accepts no liability in case of damage or loss en route to Thomson.

# A new or refurbished unit will be shipped to you freight

Installation and set-up service adjustments

What your warranty does not cover: Customer instruction, (Your Owner's Manual provides information regarding operating instructions

For additional information, ask your dealer.)

Products which have been modified or incorporated into other

- Damage from misuse or neglect
- Products purchased or serviced outside the USA. · Acts of nature, such as but not limited to lightning damage.
- **Product Registration:**  Please complete and mail the Product Registration Card packed with your unit. It will make it easier to contact you should it ever be necessary. The return of the card is not required for

#### How state law relates to this warranty:

warranty coverage.

 This warranty gives you specific legal rights, and you may have other rights which vary from state to sta If you purchased your product outside the USA:

# This warranty does not apply. Contact your dealer for warranty

#### (OR CALL 1-800-338-0376 FOR ACCESSORIES ONLY) CATALOG NO. PRICE\* QTY. TOTAL (white) (black)

#### 5-2462 5-2463 \$4.95 5-2444 5-2425 \$36.35 Headset 5-2461 \$14.95 Replacement battery

Accessory Order Form

#### For credit card purchase

name on the Master Card

My card expires:

Your complete charge card number, its expiration date and your signature are necessary to process all charge card orders.

Copy your complete account number from your ${\bf VISA}$ card.														
My card expires:														

Copy your complete account number from you

ı		Г		Г	1 [					١ſ			П	
ï					Ш					Ш				
ı	_	•		_	-					٠.			_	
ı	Copy the number above your													

**Authorized Signature** \*Prices are subject to change without notice. Total Merchandise.

We are required by law to collect the appropriate sales tax for each individual state county, and localify to which the merchandise is being sent. Duties will apply for shipments to Canada.

applicable, we will ship a superseding model \$5.00 Shipping/Handling.

made payable to Thomson Consumer Electronics, Inc. to:

- 1	Total / Wildert Ellologoa
- 1	
	M :: 1 6 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
	Mail order form and money order or check (in U.S. currency)

Mail Order Departmen

Daytime Phone Number (

P.O. Box 8419

Total Amount Enclosed

- 1	NUIKS, FA 17373-0413		
	Name		
- 1	Address	Ant.	

State

Please make sure that this form has been filled out completely