



Swimwatch Model: SW202

USER MANUAL

EN

INTRODUCTION

Thank you for selecting this Swimwatch (SW202). This is a specially designed watch for swimming purpose, and is equipped with automatic lap counter, stroke counter, calorie counter, exercise timer and memory function.

CONTROL BUTTONS



1. or : Activate backlight; lock / unlock keypad
2. (SWIM) : Enter Swimming Mode; start / stop exercise timer; immediate exit; decrease values
3. MEM : Enter Memory Mode; view memory record; increase values
4. SET : Enter Setting Mode; move to next page or setting option

LCD



1. or : Indicates battery power is low
2. STYLE : Indicates swimming style is displayed
3. Displays mode banners and numerical values
4. : Indicates keypad is locked
5. : 12/24 hour clock
6. STROKES : Indicates the number of strokes is displayed
7. : Indicates beep tone is Off
8. : Indicates alarm is On
9. : Smart indicator to press the button for toggling or for decreasing values
10. : Press to exit
11. : Indicates SET is pressed and held
12. : Indicates there is a following page
13. M : Pool length unit
14. KCAL : Calorie unit
15. KG LB : Weight unit (Pounds / Kilograms)
16. : Press to view the record contents in Memory Mode
17. : Smart indicator to press the button for toggling or for increasing values
18. : Indicates exercise timer is displayed
19. : Indicates you are in Memory Mode

GETTING STARTED

ACTIVATE WATCH (FIRST-TIME USE ONLY)

Press and hold any key until the screen is activated.

SET TIME AND USER DATA

To effectively use the watch for calculating calorie burned (based on stroke frequency, exercise time and user body weight), you are advised to set the time and your user data in the Setup Mode. Refer to Setup Mode in this manual.

MAIN MODE

The Main Mode is the default display mode, which displays the current time and date.

SETUP MODE

In the Setup Mode, you can set the user's weight, time, date, alarm On/Off and alarm time, and beep tone On/Off.

1. Press SET to enter Setup Mode.
2. Wait for the screen to appear.



3. Press and hold SET to set values in each setting option (or press SET once to skip to the next setting option). Press MEM to increase values or to decrease values. The setting options in sequence are:
 - Weight - weight unit, weight value
 - Time - 12/24 format, hour and minute
 - Date - year, month-day/day-month format, month and day
 - Alarm - alarm On/Off (press MEM to toggle), hour and minute
 - Beep - beep tone On/Off (press MEM to toggle)
4. Press SET to confirm.

IMPORTANT

- Set the time and your user data after every battery replacement.
- Re-set the user data when used by a different user.

REMARK

Press anytime to return to Main Mode.

SPECIFICATIONS

Real time clock	12 / 24 format with hour / minute
Lap measurement range	0 – 999 laps
Stroke measurement range	0 – 9 999 strokes
Exercise timer range	99:59'59"
Calorie measurement range	0 – 9 999 kcal
Body weight range	20 – 225 kg (44 – 495 lb)
Power	1 x CR2032 lithium battery
Operating temperature	0°C to 40°C (32°F to 104°F)
Storage temperature	-20°C to 60°C (-4°F to 140°F)

PRECAUTIONS

To ensure you use your product correctly and safely, read these warnings and the entire user manual before using the product:

- Use a soft, slightly moistened cloth. Do not use abrasive or corrosive cleaning agents, as these may cause damage. Use lukewarm water and mild soap to clean the device thoroughly after each training session. Never use the product in hot water or store it when wet.
- Do not subject the product to excessive force, shock, dust, temperature changes, or humidity. Never expose the product to direct sunlight for extended periods. Such treatment may result in malfunction.
- Do not tamper with the internal components. Doing so will terminate the product warranty and may cause damage. The main unit contains no user-serviceable parts.
- Do not scratch hard objects against the LCD display as this may cause damage.
- Take precautions when handling all battery types.
- Remove the batteries whenever you are planning to store the product for a long period of time.
- When replacing batteries, use new batteries as specified in this user manual.
- The pool lengths available are 25m and 50m.
- The swimming styles available are:

- Except in swimming, press anytime to return to Main Mode; the watch will also return to Main Mode if idled for 30 seconds.
- The backlight function will not operate if or is displayed.
- To toggle keypad lock On or Off:
 - Press and hold for 2 seconds. indicates keypad is locked.

- The swimming styles available are:



CALIBRATION MODE

The watch must be calibrated when it is to be used by a different user or used in a different setting (different swimming style and pool length).

1. Press to enter Calibration Mode and wait for the screen to appear.
2. Press MEM to select the swimming style (Freestyle, Backstroke, Breaststroke, Butterfly).
3. Press SET to confirm.

4. Press MEM to select pool length (25 m or 50 m).
5. Press SET to confirm.

6. The watch will prompt you to swim 1 lap (a lap means swimming from one end of the pool back again to the opposite end of the pool).
7. Press and start swimming immediately. Do not wait for a while before swimming.

8. After completing 1 lap, press immediately to stop. Do not press for a while before pressing.
9. Press SET to retry, or to return to Main Mode.

10. Press SET to retry, or to return to Main Mode.

11. If calibration is successful:
 - Press SET to go to Swim Mode and start swimming, or press to return to Main Mode.

12. If calibration fails:
 - Press to go to Main Mode.

13. Press SET to go to Main Mode.

14. Press to return to Main Mode.

15. Press to return to Main Mode.

16. Press to return to Main Mode.

17. Press to return to Main Mode.

18. Press to return to Main Mode.

19. Press to return to Main Mode.

20. Press to return to Main Mode.

21. Press to return to Main Mode.

22. Press to return to Main Mode.

23. Press to return to Main Mode.

24. Press to return to Main Mode.

25. Press to return to Main Mode.

26. Press to return to Main Mode.

27. Press to return to Main Mode.

28. Press to return to Main Mode.

29. Press to return to Main Mode.

USE IN THE WATER

The SW202 is water-resistant up to 50 meters (164 feet).

Rain	Showering (Warm/Cool Water Only)	Light Swimming	Shallow Water	Snorkeling/Diving	Deep Water Diving
OK	OK	OK	OK	NO	

- Due to printing limitations, the displays shown in this manual may differ from the actual display.
- The contents of this manual may not be reproduced without the permission of the manufacturer.

NOTE The technical specifications for this product and the contents of the user manual are subject to change without notice.

NOTE Features and accessories will not be available in all countries. For more information, please contact your local retailer.

ABOUT OREGON SCIENTIFIC

Visit our website (www.oregonscientific.com) to learn more about Oregon Scientific products. If you're in the US and would like to contact our Customer Care department directly, please visit:
www2.oregonscientific.com/service/support.asp

For international inquiries, please visit:
www2.oregonscientific.com/about/international

EU-DECLARATION OF CONFORMITY

Hereby, Oregon Scientific, declares that this Swimwatch (Model: SW202) is in compliance with EMC directive 89/336/CE. A copy of the signed and dated Declaration of Conformity is available on request via our Oregon Scientific Customer Service.



Montre de Natation Modele : SW202

MANUEL DE L'UTILISATEUR

FR

INTRODUCTION

Nous vous remercions d'avoir sélectionné la montre de natation (SW202). Cette montre est particulièrement conçue pour la natation, équipée d'un compteur automatique de tour, de courses, de calories, compteur d'entraînement et fonction mémoire. Reportez-vous au Mode Réglage de ce manuel.

MODE PRINCIPAL

Le mode principal est le mode d'affichage par défaut, il affiche l'heure et la date actuelle.

MODE REGLAGE

Dans le Mode Réglage, vous pouvez régler le poids de l'utilisateur, activer/désactiver l'alarme, définir l'heure, et la date, l'heure de l'alarme, activer ou désactiver le bip.

1. Appuyez et maintenez pour entrer dans le mode Réglage et attendez que l'écran apparaît.
2. Attendez que l'écran apparaît.

3. Appuyez sur SET pour entrer dans le mode réglage.
4. Appuyez sur MEM pour sélectionner la longueur de la piscine (25 m ou 50 m).
5. Appuyez sur SET pour valider.

6. La montre vous invitera à parcourir 1 tour (on appelle 1 tour faire un aller-retour de piscine en nageant).
7. Appuyez sur et commencez à nager immédiatement.

8. Après avoir parcouru 1 tour, appuyez immédiatement pour arrêter. N'attendez pas pour appuyer sur SET.
9. Si l'étalement est réussi :
 - Appuyez sur SET pour entrer dans le mode principal.
 - Appuyez sur pour revenir à n'importe quel moment pour revenir au Mode Principal.

10. Appuyez sur SET pour valider.

IMPORTANT

- N'oubliez pas d'étailler la montre après une réinitialisation ou chaque changement de pile.
- Rappelez-vous de régler l'heure et les données utilisateurs après avoir remplacé la pile.
- Régler une seconde fois les données de l'utilisateur si la montre est utilisée par quelqu'un d'autre.

REMARQUE Appuyez sur à n'importe quel moment pour revenir au Mode Principal.

MODE NATATION

La montre enregistre les 7 derniers relevés d'entraînement. Chaque relevé contient le style de nage, la distance totale, le compte de tour total, le temps d'entraînement et les calories consommées.

1. Appuyez sur MEM pour entrer dans le mode mémoire.
2. Attendez que l'écran apparaît.

3. Appuyez plusieurs fois sur SET pour sélectionner le relevé à visualiser.
4. Appuyez plusieurs fois sur MEM pour visualiser les 3 pages du relevé sélectionné et revenir à la page des relevés.

La montre alternera également pendant trois secondes les pages, mais vous elle ne reviendra pas à la page des relevés. Appuyez sur MEM pour revenir.

REMARQUE Appuyez sur à n'importe quel moment pour revenir au Mode Principal.

Pour réinitialiser les relevés :

Vous ne pouvez pas réinitialiser les relevés manuellement. La montre est conçue pour réinitialiser automatiquement les relevés.

ETEINDRE L'ALARME

Appuyez sur n'importe quelle touche. Si elle n'est pas désactivée, elle s'activera à nouveau à la même heure le lendemain.

RETRÔ-ECLAIRAGE ET VERRUILLAGE DES TOUCHES

