



ST29-12U1 12.1" Liquid Crystal Display TV

This Guide is designed as a reference to help you start using your LCD TV quickly. Please Refer to the User's Manual for more detailed installation and safety instructions.

Front View




Rear View



Note : Install the display unit using a mounting device. For details , refer to the operating instructions supplied with your mounting device .

Making Connections


Connecting to Antenna/Cable TV



1. Connect one end of the VHF/UHF (Antenna) or CATV cable to ANT Jack (VHF/UHF IN Jack) on the back of the TV.
2. Connect the other end of the VHF/UHF (Antenna) or CATV cable to the Antenna or CATV socket.


Connecting to a VCR, VCD, DVD Player, or Gaming Device

1. The illustration presented here shows you how to connect your TV to a VCR, VCD, DVD player or gaming device.



2. The cables are color-coded (black, red, white, and yellow). Connect each color-coded cable to the appropriate connector on your device.

Connecting the Power Adapter



1. Connect the power cord to the power adapter as illustrated.
2. Plug the power adapter connector into the DC-IN input jack on the rear panel of the TV.
3. Insert the three-pronged plug at the other end of the power cord into a power outlet.

A/V and Channel Setup


Watching Broadcast or Cable TV

1. After you have made the appropriate power and source connections, press the power button to turn on your television.
2. Press the **SOURCE** button to select TV.
3. Press the **MENU** button to open the OSD menu.
4. Use the **CH ▼** button to select "TV".
5. Press the **VOL +** button to enter "TV MENU".
6. Press the **VOL +** button to enter "TV/CATV".
7. Press the **VOL +** button to select "TV" (broadcast TV) or "CATV" (cable TV).



Selecting A/V Sources

1. Make sure your TV is turned on and a device such as a DVD player is connected.
2. Press the **SOURCE** button on the control panel to select different source signals. The channel number, "AV1" or "AV2" appears on the screen.



Auto Channel Setup

Please follow the instructions by using the control panel.

1. Press the **MENU** button to enter the OSD menu.
2. Use the **CH ▼** button to select "TV".
3. Press **VOL +** button into the "TV MENU".
4. Press **CH ▼** button until the "AUTO PROGRAM" feature is selected.
5. Press **VOL +** to begin "AUTO PROGRAM".
6. Your television will begin automatically memorizing the available channels.

Auto Program

