

TV/Display Setup Guide

HP Digital Entertainment Center



Use this guide, before powering on, to set up your HP Digital Entertainment Center to work with your TV or display.

Setting Up Your TV/Display for the First Time

Adjusting Video

Video Troubleshooting

Video Out Information

Important Notes — *Please read this.*



The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

HP assumes no responsibility for the use or reliability of its software on equipment that is not furnished by HP.

This section contains proprietary information that is protected by copyright. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of HP.

Hewlett-Packard Company
P.O. Box 4010
Cupertino, CA 95015-4010
USA

Copyright © 2005 Hewlett-Packard Development Company, L.P.

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited. Apparatus Claims of U.S. Patent Nos. 4,631,603, 4,577,216, 4,819,098, and 4,907,093 licensed for limited viewing uses only.

Microsoft and Windows are U.S. Registered trademarks of Microsoft Corporation.

HP supports lawful use of technology and does not endorse or encourage the use of our products for purposes other than those permitted by copyright law.

The information in this document is subject to change without notice.

Table of Contents

Before You Begin.....	1
Overview	1
Setting Up Your TV/Display for the First Time	2
TV/Display Setup	2
Preparing your system	2
After you first turn on your system	3
Adjusting Video	4
Starting the TV/Display Setup Wizard	4
Resize adjustment availability.....	4
TV/Display Setup Wizard	5
HDTV Overscan Compensation	12
Adjust Composite Video and S-video Screen Size.....	13
Desktop Video Adjustments	14
Video Troubleshooting.....	15
Check video.....	15
Video Out Connection Types.....	16
Common Video Out Problems	16
Blank screen	17
Oversized screen.....	18
Undersized screen with black border	19
Screen flashes	19
Screen flickers	20
Unreadable screen text.....	20
DTV channel has audio but no video.....	20
Sleep mode.....	20
No video after power on sequence.....	21
Keyboard does not work	21

Troubleshooting Composite and S-video	21
No video after changing the Video Out connection	22
Troubleshooting Component Video	23
Check component video	23
Component video troubleshooting chart	24
DVD does not play or an error appears on screen	24
Blank screen (blue, black, or distorted)	25
Correcting an extended blank screen with component video out	25
Wrong colors or erratic video on screen	29
Line at bottom of the screen	29
Troubleshooting DVI	30
Blank screen after powering up and during initial startup with DVI	30
Recovering your system with DVI or DVI/HDMI	30
Blurred screen text	30
Video Out Information	32
TV/Display Types	32
Video Out Formats	32
Display resolution/format	33
Scanning system	33
Aspect ratio	33
Display Image Size	34
Overscan	34
Cropping	34
Panning	34
Important Notes	35
Plasma TV/Display Image Retention	35

Before You Begin

Use this guide to set up your HP Digital Entertainment Center to send a quality image to your TV or display. Keep this information with your HP Digital Entertainment Center documentation for future reference.

This guide contains the latest information about setting up your HP Digital Entertainment Center and supplements some information in the *Start Here* booklet and *User's Guide* that was included with your HP Digital Entertainment Center. It also includes troubleshooting problems and solutions. Refer to the HP Digital Entertainment Center *Start Here* booklet or *User's Guide* for additional installation information.

Refer to <http://www.hp.com/support> for additional information and software updates.

Overview

You can use the TV/Display setup wizard and desktop utilities provided to do the following:

- Select the Video Out connection
- Select the TV output format (480i, 480p, etc.)
- Size the video image to your TV screen

First you run the TV/Display Setup Wizard. Then, you can fine tune the picture using a desktop program.

The following table shows the major processes you need to set up your HP Digital Entertainment for optimum viewing. Choose the section that most closely matches your setup condition:

Section	Usage	See
Setting Up Your TV/Display First Time Setup	Do this procedure before you apply power to your HP Digital Entertainment Center for the first time. Select your type of TV/Display and perform the appropriate step-by-step procedure.	"Setting Up Your TV/Display" on page 2.
Adjusting Video A TV/Display setup wizard adjusts the screen size	Run the TV/Display setup wizard at any time to improve the picture on your TV/Display. The wizard adjusts the screen display to your preference.	"Adjusting Video" on page 4.
Video Troubleshooting Problems and Solutions	Check this section if you have a problem viewing the HP Digital Entertainment Center image on your TV/Display. Select the problem and corresponding solution that most closely matches your condition.	"Video Troubleshooting" on page 15.
Video Out Information How your system works with video	Read this section for additional information on how your HP Digital Entertainment Center works with video.	"Video Out Information" on page 32.
Important Notes Contains critical information!	Important Notes contain critical information you need to operate your system properly.	"Important Notes" on page 35.

Setting Up Your TV/Display for the First Time

This section describes how to connect your HP Digital Entertainment Center to a TV or display the first time you power on. Your HP Digital Entertainment Center Video connects to many different types of TV/Displays. After you connect the TV/Display to your HP Digital Entertainment Center, set up your HP Digital Entertainment Center for the correct TV type for optimum viewing.

IMPORTANT: Read this before you turn on the HP Digital Entertainment Center. Follow the steps carefully. Your TV/Display may require settings and configurations different than those listed in the following procedures. The HP Digital Entertainment Center Video Out requires specific configurations for certain TV/Display types and resolutions. This setup procedure is advanced. Knowledge of video concepts and computer terms is helpful. For more information on TVs and video in general, see "Video Out Information" on page 32.

TV/Display Setup

Perform these steps, in order, to power on, setup, and configure your HP Digital Entertainment Center for optimum viewing on a TV/Display:

Preparing your system

- 1 Complete the full connection of the HP Digital Entertainment Center back panel as described in the *Start Here* booklet and *User's Guide*. **Do not turn power on yet.**
- 2 Check the back of the TV/Display for the input connection types.
- 3 Choose a connector on the HP Digital Entertainment Center back panel Video Out and corresponding cable that attaches to your TV. Connect only one display for setup:

Video Out	Usage	HDTV notes
Video (composite) 	Use composite video if your TV/Display has only a composite video input.	For TV connection information, refer to the <i>User's Guide</i> .
S-video 	Use S-video if your TV/Display has composite video and S-video inputs.	
Component (Y, Pb, Pr) 	Use component video if the TV/Display has composite video, S-video, and component video inputs for a higher-quality image.	Content protected commercial DVDs will not play at HDTV resolutions of 720p or 1080i.
VGA 	Use VGA for a high-quality image. VGA is primarily for monitors, but your TV/Display or video projector may also have a VGA connection.	HP recommends using VGA or DVI Video Out connections for a high-quality HDTV image.
DVI 	Use DVI for a high-quality image. You can also connect DVI out to the TV/Display HDMI input using an adapter cable (purchased separately).	

- 4** Turn on the TV/Display power. Turn power on to all other connected audio and video devices.
- 5** Determine the formats that the TV/Display supports. For example: 480i, 480p, 720p, or 1080i.
 - Refer to your TV/Display documentation.
 - You may also find the TV supported format on the TV cabinet, or on the OSD (onscreen display).
 - Specifications for your TV model may also be available on the Web.
- 6** Set the TV/Display input to match the HP Digital Entertainment Center video cable input.
- 7** Make sure that the following items are connected and installed on your HP Digital Entertainment Center:
 - AC power source
 - TV source
 - Internet connection
 - Keyboard (Pull the battery tab.)
 - Remote control (Insert the Batteries.)
 - Audio Out
 - Video Out
- 8** Turn on the HP Digital Entertainment Center for the first time by pressing the On/Standby power button.

After you first turn on your system

- 1** Wait for the Windows® Welcome screen to appear. Click **Next** to set up your system. Do not turn off your system.

NOTE: The screen may flash on occasion. This occurs only during setup or setting changes and does not affect performance.

- 2** Complete the initial Windows® setup wizard. Use the keyboard and follow the onscreen instructions. You hear music if the audio is connected. Click **Finish**.
- 3** After a countdown and a blank screen, Windows restarts automatically. **Do not turn off your system** during this one time process.
- 4** After the HP Digital Entertainment Center restarts, use the TV/Display Setup Wizard to optimize your TV/Display. Follow the onscreen instructions. See “TV/Display Setup Wizard” on page 5.
- 5** Complete the Required Media Center setup wizard. Follow the onscreen instructions and answer any questions as required, to set up Internet and network connections.
- 6** Complete the Optional Media Center setup wizard. Follow the onscreen instructions. (You may skip sections that do not apply to your setup and change the settings at a later time using Media Center.)
 - Configure tuners, TV signal, and Television Program Guide information.
 - Select and adjust Media Center display settings.
 - Set up speakers.
 - Teach the HP Digital Entertainment Center to control your cable TV or satellite receiver set-top box.
- 7** Refer to the *User’s Guide* to complete the audio settings. Use this guide for the video settings.

Begin using your HP Digital Entertainment Center.

NOTE: See “Adjusting Video” on page 4 and run the TV/Display Setup Wizard again if the picture is not satisfactory after you have completed the setup procedure. See “Video Troubleshooting” on page 15 if you can’t see a picture.

Adjusting Video

This section contains important information about how to improve picture quality on your TV/Display when setting up your HP Digital Entertainment Center.

- TV/Display Setup Wizard
- Desktop Video Adjustments
- HDTV Overscan Compensation
- Adjust Composite Video and S-video Screen Size

Starting the TV/Display Setup Wizard

The TV/Display Setup Wizard adjusts the screen display to your preference. Start the TV/Display Setup Wizard using one of the following methods:

- First-time setup** The first time you power on your Digital Entertainment Center connected to a monitor or TV display, the TV/Display Setup Wizard appears.
- Display Wizard icon on the desktop** Double-click the **nVidia Display Wizard** icon on the desktop. The setup wizard appears. Do not run the TV/Display Setup Wizard with Media Center running.
- Inside Media Center** Press the Media Center button. Then select **More Programs, HP Settings, Video Settings**, and then **Display/Connection Wizard**. The setup wizard appears.
- On the desktop** Right-click the **Desktop** to access screen resize and graphics fine tuning adjustments (not using the wizard).

Resize adjustment availability

You can resize the display if your TV/Display has the correct connection type and format. Use the following table to determine how to, and if you can, resize your screen image, based on your connection type and format:

Format	Composite	S-video	Component	VGA	DVI
480i	Can resize using desktop (Page 14)	Can resize using desktop (Page 14)	Cannot resize picture	Can adjust Screen resolution (Page 14)	Cannot resize picture (Format not supported for some TVs with DVI.)
480p	Format not supported	Format not supported	Cannot resize picture	Can adjust Screen resolution (Page 14)	Cannot resize picture
720p	Format not supported	Format not supported	Can resize using wizard (Page 5)	Can adjust Screen resolution (Page 14)	Can resize using wizard for TVs only (Page 5)
1080i	Format not supported	Format not supported	Can resize using wizard (Page 5)	Can adjust Screen resolution (Page 14)	Can resize using wizard for TVs only (Page 5)

NOTE: For a TV with PC monitor capabilities, connected to DVI, see “Desktop Video Adjustments” on page 14.

TV/Display Setup Wizard

Use this wizard to adjust your display settings. This procedure is an example only and may vary depending on your TV/Display type, supported formats, and Video Out connections. You may have to perform the procedure more than once to optimize the image. The wizard runs automatically, after you first turn on the HP Digital Entertainment Center, and after you complete the initial Windows setup wizard.

Some tasks on the HP Digital Entertainment Center require that you leave Media Center and use the Windows XP desktop. Some messages and dialogs on the desktop may be difficult to read on some TVs. Lowering the display resolution can make messages and dialogs easier to read by enlarging the text.


To optimize the HP Digital Entertainment Center video image on your TV/Display using the TV/Display Setup Wizard, do the following:

- 1** Before you begin, verify that the TV/Display is:
 - Properly connected to the HP Digital Entertainment Center.
 - Turned on.
 - Set to input connected to the HP Digital Entertainment Center.
 - Set to normal mode (not letter-box, wide, or re-sized).
- 2** Press the Media Center button on the remote control or keyboard.
- 3** Click **More Programs, HP Settings**, and then **Video Settings**.

NOTE: You can also double-click the nVidia Display Wizard icon on the desktop. For additional ways to start the display setup, see "Starting the TV/Display Setup Wizard" on page 4.


- 4** Click **Display/Connection Wizard**. The TV/Display Setup Wizard appears.

**Follow the
onscreen
instructions.**



- 5 Verify that the video equipment is properly connected to the HP Digital Entertainment Center and the TV/Displays are turned on. Click **Next**.
- 6 Select your connection type and click **Next**.

Component Video Out shown.



- 7 Do the following for your Video Out connection type and connected cable.

Video Out	Action
Video (composite) 	Skip this step. Go to step 8.
S-video 	
Component (Y, Pb, Pr)   	

Step 7 (continued)


VGA 

Follow the onscreen instructions. Click **Next**.




DVI 

Follow the onscreen instructions. Click **Next**.



Step 7 (continued)


Accept the End Users License Agreement. Click **Next**.



8 Select the screen resolution definition type that is supported by your TV/Display. Click **Next**.


NOTE: This step may not change the settings on some TV/Displays connected to DVI. The native display resolution is selected by the wizard automatically. Click **Next**.

Your settings may vary.



9 Verify that the settings that you have selected are correct. Click **Preview**. The new video settings display.

Your settings may vary.




10 The system prompts for confirmation. The screen may flicker for a few seconds while the settings change.

- Click **Next** to apply the settings.

Or


- If the new setting is not correct, wait for 15 seconds. Do NOT click or press any key during this time. The previous screen reappears. Click back to return to the *Select the HDTV mode* screen in Step 8 and select a format (mode) that is supported by your TV/Display.

Your screen image may vary.




- 11** Do one of the following, depending on the video connection type and format (See the table on page 4):
- If the Resize screen appears, go to the next step.
- Or
- If the Resize screen does not appear, go to step 15.
- 12** To resize the viewable area of the TV/Display screen, click **Resize**.

Change the screen size.



- 13** Adjust the screen size to fit your display. If your display shows a larger image than the screen and the edges are missing, click the "in" arrow button to make the screen smaller. Click **Save Settings** to apply the settings.

Your screen image may vary.



14 Click **Next** at the Resize screen.

15 Click **Finish**.

16 To improve the screen size fit or if you could not resize the screen, do one of the following, depending on video connection type and format (see the table on page 4):

Video Out	Action
Video (composite) 	
S-video 	See "Adjust Composite Video and S-video Screen Size" on page 13.
Component (Y, Pb, Pr) 	For formats: <ul style="list-style-type: none">• 480i, 480p: You cannot resize the screen. <i>Or</i>• 720p or 1080i: See "HDTV Overscan Compensation" on page 12. DVD playback: Your commercial DVD may not playback at 720p or 1080i formats, due to copy protection measures. Change the format to 480i or 480p. See "DVD Does Not Play or an Error Appears on Screen" on page 24.
VGA 	You can resize the screen using the Screen resolution window. See "Desktop Video Adjustments" on page 14.
DVI 	<ul style="list-style-type: none">• 480i, 480p: You cannot resize the screen. <i>Or</i>• 720p, 1080i: If you are using a TV, see "HDTV Overscan Compensation" on page 12. <i>Or</i>• For a TV with PC monitor capabilities, see "Desktop Video Adjustments" on page 14. <i>Or</i>• See "Blurred screen text" on page 30 if you have trouble reading the screen text.

HDTV Overscan Compensation

You cannot use HDTV Overscan Compensation for 480i or 480p formats. This procedure may not be available with DVI, depending on your display type.

Set underscan



After you have set up Media Center, you can set the display for Underscan to show the entire Windows desktop on the screen.

To optimize the screen size for HDTV resolutions above 480p:

- 1 Close Media Center.
- 2 Right click the desktop, select **nVidia Display**, and click **Overscan Compensation** in the dialog box. The HDTV Overscan Compensation window opens.

NOTE: This screen may vary or not appear, depending on the type of TV/Display and video connection.

- 3 Select **Underscan** to fit the entire desktop on the screen. Click **Apply**.
- 4 You can also adjust the screen size manually.
 - a Click the **Overscan Compensation** button.
 - b Click and drag the sliding bars to adjust the width and height of your display, and then click OK. Click **OK**. The Display Settings window opens.



- 5 Click the **OK** button to apply the changes.




- 6 When the HP Digital Entertainment Center image appears on the TV screen, click **Yes** to keep the setting. You have 15 seconds to accept this new setting before it reverts to the previous setting. If the new setting is not correct, wait for 15 seconds and the previous screen displays.
- 7 Click the **OK** button to save changes and close the window.

NOTE: Your screen image should be correctly sized at this point. If your picture in DVI is not satisfactory, see "Blurred screen text" on page 30.

Adjust Composite Video and S-video Screen Size

You can adjust the composite video and S-video display using the desktop. To optimize the HP Digital Entertainment Center video image so it fits your TV screen with S-video and video (composite) connections:

- 1 Close or minimize Media Center.
- 2 Right-click the desktop, select **nVidia Display, TV, TV Settings**, and then **Device Adjustments**. The Device Adjustments window opens.
- 3 Click the buttons inside the TV image to increase or decrease the screen size.
- 4 Click the buttons around the edges to center the screen position.
- 5 Click the **OK** button to save the changes. Click the **OK** button close the window.



NOTE: To solve S-video and composite Video Out problems relating to the HP Digital Entertainment Center, see "Video Troubleshooting" on page 15.

Desktop Video Adjustments


You can use this procedure if composite, S-video, VGA, or DVI Video Out is connected. Do **NOT** use this procedure if component video out is connected (see "TV/Display Setup Wizard" on page 5).

If the display setup wizard does not provide an optimized video image or you cannot resize the TV/Display picture, do the following:

- 1 Right-click the desktop, click **nVidia Display** in the dialog box, and then click **TV (model)** or **nView Display Settings**.
- 2 Select **Screen Resolutions & Refresh Rates** from the left-side list. The window appears.
- 3 Adjust the Screen resolution and Monitor settings (Screen refresh rate) as required.
- 4 Click **Apply**.
- 5 Click **Yes** to keep the setting. You have 15 seconds to accept this new setting before it reverts to the previous setting. If the new setting is not correct and the screen goes black, wait for 15 seconds and the previous screen displays. If the screen stays black for an extended time, turn off the TV and then turn it on.
- 6 Click **OK** to close the Display Properties window.

CAUTION: Be careful when changing settings. The HP Digital Entertainment Center Video Out requires specific configurations for certain TV/Display types and resolutions. This setup procedure is advanced.

NOTE: If your picture in DVI is not satisfactory, see "Blurred screen text" on page 30, or if you have a monitor connected to the HP Digital Entertainment Center in DVI and are experiencing problems. If you see black borders or overscan and panning, set the slider bar back to the previous resolution or rerun the TV/Display Setup Wizard to optimize the video image. See "TV/Display Setup Wizard" on page 5. Follow the onscreen instructions.



Video Troubleshooting

This section contains important information about troubleshooting problems that may occur with your HP Digital Entertainment Center while setting up Video Out to your TV or display.

Check video

Check Video Out before you begin to troubleshoot. Do the following steps in order:

- 1** Turn off the TV/Display.
- 2** Turn off the HP Digital Entertainment Center by pressing and holding the On/Standby power button for 4 seconds. The On/Standby button should be dark and not lit amber or blue.
- 3** Check the cables. Make sure that they are completely plugged in the correct connectors. Refer to the *Start Here* booklet and *User's Guide*. Reconnect the cables, as required.
- 4** Turn on the TV/Display.
- 5** Set the TV/Display input to match the HP Digital Entertainment Center Video Out cable input. For example: "Component 1."
- 6** Turn on the HP Digital Entertainment Center by pressing the On/Standby power button. Wait 1 to 2 minutes. The video image appears.
- 7** Check your screen. Do one of the following:
 - If you can see the HP Digital Entertainment Center image on your TV/Display properly, stop here.
Or
 - If you can see a video image on your TV/Display and the problem is not resolved, use the TV/Display Setup Wizard to optimize the video image. See "TV/Display Setup Wizard" on page 5. Follow the onscreen instructions. You should complete this procedure before troubleshooting.
Or
 - If you cannot see a video image on your TV/Display or the problem is not resolved, your video problem may be common to all Video Out types. See "Common Video Out Problems" on page 16.
Or
 - Your video problem may be specific to the Video Out type you have connected. See the "Video Out Connection Types" table that follows. Use the chart to correct the condition.
Or
 - You can also try another video connection. Repeat this procedure and change the cables at step 3.

NOTE: Make sure that you have updated software. Refer to: <http://www.hp.com/support>

Video Out Connection Types

Use the following table to identify troubleshooting problems that may occur by Video Out connection type.

Your HP Digital Entertainment Center back panel has the following Video Out connectors:

Connector	Usage	Problem: See
Video (composite) 	SDTV — Use composite video if your TV/Display has only a composite video input.	"Troubleshooting Composite and S-video" on page 21.
S-video 	SDTV — Recommended for standard TVs.	
Component (Y, Pb, Pr) 	EDTV — Use component video, for a higher-quality image, only if your TV/Display has just composite video, S-video, and component video inputs.	"Troubleshooting Component Video" on page 23.
VGA 	HDTV — Use VGA video for a high-quality image, if your TV/Display has VGA video connections. Use VGA also for monitors. Your video projector may also have a VGA video connection.	"Desktop Video Adjustments" on page 14.
DVI 	HDTV — Use DVI video, for the highest-quality image, if your TV/Display has DVI video connections. Recommended for High-Definition-capable TV/Displays.	"Troubleshooting DVI" on page 30.

Common Video Out Problems

The following problems are general issues that can appear on your screen with any HP Digital Entertainment Center Video Out connection type. Select the problem that most closely fits your condition:

- Blank screen
- Oversized screen
- Undersized screen with black border
- Screen flashes
- Screen flickers
- Unreadable screen text
- DTV channel has audio but no video
- Sleep mode
- No video after power on sequence
- Keyboard does not work

Before troubleshooting, use the TV/Display Setup Wizard. See "TV/Display Setup Wizard" on page 5 for a basic adjustment of Video Out display settings. Follow the onscreen instructions.

Blank screen

Problem: Your TV/Display screen is blue or black after you turn on the HP Digital Entertainment Center for an extended time.

Solution: To see an image of the HP Digital Entertainment Center video on your TV screen:

- 1 Check the video setup. See "Check video" on page 15.
- 2 If you still can't see an image of the HP Digital Entertainment Center video on your TV screen, check your video connection type:

Connector	Problem: See
Video (composite) 	"Troubleshooting Composite and S-video" on page 21.
S-video 	
Component (Y, Pb, Pr) 	"Troubleshooting Component Video" on page 23.
VGA 	"Check video" on page 15.
DVI 	"Troubleshooting DVI" on page 30.

Problem: Your TV/Display screen is off after the HP Digital Entertainment Center resumes from Standby.


Solution: Turn on the TV. Select the correct TV input.

IMPORTANT: Turn on the TV/Display and make sure you have connected a video cable before powering on the HP Digital Entertainment Center. If you do not see a picture, turn on the TV/Display, connect a video cable, and then turn off and start the HP Digital Entertainment Center. You must do this because the HP Digital Entertainment Center detects the video out cable connections at turn on only.

Oversized screen

If the picture edges are not visible, the image is overscanned. This condition is common when connecting a computer to a TV. *Overscan* is when the video image size is greater than the TV/Display screen. In an overscan condition, the edges of the video image that are not visible on the TV/Display screen are *cropped*.

Panning allows you to see the edges of the video image and can be a corrective action for overscan. See "Aspect ratio" on page 33 for additional information. See the following for overscan problems and solutions:



Left: Video image is cropped.

Right: Video image is full screen, not cropped.

Problem: Desktop video image edges are not visible. Your TV/Display might show only the center of the video image, not the edges. This problem may occur if you change video formats or TV/Displays.

Solution: If you want to see a full image, or cannot move the cursor off the screen to see hidden areas of the video image, optimize the HP Digital Entertainment Center video image so it fits your TV screen:

Do one of the following:

- If your TV connects to the HP Digital Entertainment Center using a component video connection, use the TV/Display Setup Wizard. See "TV/Display Setup Wizard" on page 5. Follow the onscreen instructions.

Or

- Perform the HDTV Overscan Compensation procedure and Set underscan. See "HDTV Overscan Compensation" on page 12.

Or

- If your TV connects to the HP Digital Entertainment Center using a composite or S-video connection, see "Adjust Composite Video and S-video Screen Size" on page 13.

To increase or decrease the size of your HDTV desktop, do the following:

- 1** Press Media Center on the remote control or keyboard.
- 2** Click **More Programs, HP Settings**, and then **Video Settings**.
- 3** Click **Resize Desktop** and **Resize Desktop**.
- 4** Adjust the screen size to fit your display. If your display shows a larger image than the screen and the edges are missing, click the "in" arrow button to make the screen smaller. Click **Save Settings** to apply the settings.
- 5** Click **Back** to return to Media Center.

NOTE: To access hidden buttons if the edge areas of your desktop video image are not visible, move the mouse pointer in the direction of the missing area, the whole desktop moves, or pans, to follow your mouse pointer movement.

Undersized screen with black border

Problem: Some TVs may display a small desktop image that does not fill the entire TV screen. The Windows desktop on your TV/Display screen may show a black border around it (shown right).

Solution: If you observe a small screen, use the TV/Display Setup Wizard to remove the black border and optimize Video Out display settings. See "TV/Display Setup Wizard" on page 5. Follow the onscreen instructions.

Problem: A DVD or video on your TV or display screen shows a black border around the entire image (shown right).

Solution: To remove the black border and optimize the video image, use the nVidia Display Wizard. See "TV/Display Setup Wizard" on page 5. Follow the onscreen instructions.

Problem: A DVD or video on your TV or display screen shows black bars above and below the video image. If your DVD or video appears in a 16:9 aspect ratio, and your TV/Display has a 4:3 aspect ratio, you see black above and below the video image (shown right).

Solution: This is a normal part of the video image for your TV/Display. Check the DVD title page for TV format aspect ratio options. Select 4:3 aspect ratio if available. While playing the DVD, press more info on the remote control, select **Zoom**, click **OK** to select the best zoom option.

Problem: A DVD or video on your TV or display screen shows black bars on the left and right of the video image. If your DVD or video appears in a 4:3 aspect ratio and your TV/Display has a 16:9 aspect ratio, you will see black on the left and right of the video image (shown right).

Solution: This is a normal part of the video image for your TV/Display. Check the DVD title page for TV format aspect ratio options. Select 16:9 aspect ratio if available. While playing the DVD, press more info on the remote control, select **Zoom**, click **OK** to select the best zoom option.

Screen flashes




Problem: You may see the screen flash when:

- You turn on or restart the HP Digital Entertainment Center. (The screen flash may occur and continue until the initial startup completes and the Media Center or desktop appears.)

Or

- You select the Display Settings, open the Display Properties, or use the screen adjustment option. (The screen flash may occur and continue until you close the window.) This type of screen flash occurs normally and appears while the operating system obtains and processes display resolution information.

Solution: Wait until the flash disappears. Some TV/Displays may flash for several seconds to stabilize.



Screen flickers

Problem: You see a slight flicker of white text and borders and your system is set to a 480i or a 1080i (interlaced) format. See “Scanning system” on page 33 for more information.

Solution: Change to a progressive scan format, such as 480p or 720p using the TV/Display Setup Wizard. See “TV/Display Setup Wizard” on page 5. Follow the onscreen instructions.

Unreadable screen text

Problem: You have trouble reading the text.

Solution: Modify the desktop text to a larger size for easier reading on the screen with one of the following procedures.

Enlarging screen text

If the desktop text size is too small, adjust the desktop icon text size on the HP Digital Entertainment Center:

- 1 Right-click with the mouse cursor in the Windows desktop.
- 2 Click **Properties**.
- 3 Click the **Appearance** tab.
- 4 Select **Large or Extra Large fonts** from the Font size drop-down menu.
- 5 Click **Apply**.
- 6 Click **OK** if you can read the text better.

Magnifying screen text

If you cannot read the text on the screen:

- 1 Press Ctrl and Esc together, press R, type *magnify*, and then press Enter.
- 2 A separate window displays a magnified portion of your screen. The magnified image is centered on your cursor. Move your cursor to view screen areas.
- 3 Click on the Microsoft® Magnifier window to change the magnification level and size of the magnification window size, as required, in the dialog box.
- 4 Press the Alt+X keys to exit.

DTV channel has audio but no video

Problem: Some DTV channels may display a black screen, but still play audio.

Solution: If the RF signal is low, the signal strength of the channel is probably weak. Adjust the antenna position or change to another channel.

Sleep mode

Problem: The HP Digital Entertainment Center may sometimes not wake up from Standby mode to record programs.

Solution: Make sure that the HP Digital Entertainment Center is set to go into Standby and not turn off. Click **Start, Control Panel, Performance and Maintenance**, and then **Power Options**. Enable System standby mode. The HP Digital Entertainment Center wakes from standby to record.

No video after power on sequence

Problem: Some TV/Displays may display a blank screen because of the sequence in which you turn on and turn off the HP Digital Entertainment Center and the TV/Display.

Solution: You must connect the Video Out cables to the HP Digital Entertainment Center and to the TV/Display, before you apply power to the HP Digital Entertainment Center.

When you turn on the TV, make sure that it is set to the proper input setting. Turn off the HP Digital Entertainment Center and then the TV before you change the cable connection to the TV. Afterwards, be sure to turn on the TV, set it to the proper input setting, and then turn on the HP Digital Entertainment Center.

Keyboard does not work

Problem: The keyboard loses sync with the HP Digital Entertainment Center, or has never connected.

Solution: Do the following:

- 1** Check the keyboard operation. Press a key, the green LED should light on the upper right corner of the keyboard.
If it does not light, check the batteries. Make sure the shipping tab is removed from the battery door on the bottom of the keyboard. Retest the keyboard.
- 2** Turn off the HP Digital Entertainment Center by pressing and holding the On/Standby power button for 4 seconds. The On/Standby button should be dark and not lit amber or blue.
- 3** Turn on the HP Digital Entertainment Center by pressing the On/Standby power button. Wait 1 to 2 minutes. The video image reappears.
- 4** Test the keyboard. Go to the next step if it still doesn't work.
- 5** Briefly press the Keyboard Connect button on the HP Digital Entertainment Center front panel, behind the left door. The button flashes, indicating the system is ready to connect (sync) with the keyboard.
- 6** Press the red Keyboard Connect button once on the bottom of the keyboard. The front panel Keyboard Connect button flashes and stops, indicating a successful sync.
- 7** Test the keyboard. If it still doesn't work:
 - Check the batteries for correct installation.
 - Remove interference sources that may interfere with transmission such as 49 MHz cordless phones, 49 MHz toy remote controls, or metal shelves or furniture.
 - Move the HP Digital Entertainment Center to another location and retest.

Troubleshooting Composite and S-video

This section contains important information about correcting problems that you may encounter with your HP Digital Entertainment Center composite and S-video setup.

You can adjust the display for composite and S-video using:

- The display wizard. See "TV/Display Setup Wizard" on page 5.
- Or
- The desktop. See "Desktop Video Adjustments" on page 14.

No video after changing the Video Out connection

Problem: Some TV/Displays may display a blank screen after you change the Video Out from S-video to composite video.

- When you turn on the TV, make sure that it is set to the proper input setting.
- Turn off the HP Digital Entertainment Center and then the TV before you change the cable connection to the TV. Afterwards, be sure to turn on the TV, set it to the proper input setting, and then turn on the HP Digital Entertainment Center.

Solution: If you have previously connected S-video Video Out to the TV, and then changed the cable connection to composite Video Out and can't see an image, do the following:

- 1** Turn off the HP Digital Entertainment Center by pressing and holding the On/Standby power button for 4 seconds. The On/Standby button should be dark and not lit amber or blue.
- 2** Turn off the TV/Display.
- 3** Remove the Video Out cable connection you just made (composite).
- 4** Reconnect the Video Out cable from the HP Digital Entertainment Center to the TV using your previous connection (S-video).
- 5** Turn on the TV/Display.
- 6** Switch the TV/Display input to the proper input setting (S-video).
- 7** Turn on the HP Digital Entertainment Center by pressing the On/Standby power button.
- 8** When you see the Media Center window, either close it or minimize it. Press Alt + F4 together on the keyboard to close it.
- 9** Right-click with the mouse cursor in the Windows desktop, select **nVidia Display**, and then click **TV**. A window opens.
- 10** Click the left mouse button, and select **TV Settings**. The Properties window displays.
- 11** Click the arrow for the drop-down list in **Video Out format**, and choose **Auto-Select**.
- 12** Click **OK**, and click **OK** again to confirm.
- 13** Turn off the HP Digital Entertainment Center.
 - In Media Center, click the **Shut Down** icon and select **Shut Down**.

Or

 - On the desktop, click **Start** on the taskbar, click **Turn Off Computer**, and click **Turn Off**.

The On/Standby button should be dark and not lit amber or blue.
- 14** Turn off the TV.
- 15** Remove the Video Out cable connection you just made (S-video).
- 16** Connect the composite Video Out cable from the HP Digital Entertainment Center to the TV.
- 17** Turn on the TV.
- 18** Switch the TV/Display input to the composite video input setting.
- 19** Turn on the HP Digital Entertainment Center by pressing the On/Standby power button. Wait 1 to 2 minutes. The video image reappears.

Troubleshooting Component Video

This section contains important information about correcting problems that you may encounter with your HP Digital Entertainment Center Component Video Setup.

The component video connections are the green, blue, and red connectors, labeled Y, Pb, Pr, on  your HP Digital Entertainment Center back panel. These three connectors combine to form a quality Video Out. (They do not transfer audio.) There are several types of Component Video Outs. The HP Digital Entertainment Center supports YPbPr Component Video Out only.

Component Video Out requires specific configurations for certain display types and resolutions. You can adjust the display for component video using:

- The display wizard. See “TV/Display Setup Wizard” on page 5.

Or

- See “HDTV Overscan Compensation” on page 12.

Check component video

To check component video before you begin:

- 1** Turn off the TV/Display.
- 2** Turn off the HP Digital Entertainment Center by pressing and holding the On/Standby power button for 4 seconds. The On/Standby button should be dark and not lit amber or blue.
- 3** Check the cables. Make sure that they are completely plugged in and that the green, blue, and red colors match on both ends.

Green: Y, Blue: Pb, Red: Pr 

- 4** Remove all other video out cables from the HP Digital Entertainment Center back panel, such as composite video (yellow) and S-video cables.
 - 5** Turn on the TV/Display.
 - 6** Check the TV/Display input switch. For example “Component 1.”
 - 7** Turn on the HP Digital Entertainment Center by pressing the On/Standby power button. Wait 1 to 2 minutes. The video image should reappear.
 - 8** Check your screen:
 - If you can see a distorted video image on your TV/Display while connected using component video, check that the cable plugs are matched to the green, blue, and red connectors. See “Wrong Colors or Erratic Video on Screen” on page 29.
- Or
- If you can see a video image on your TV/Display while connected using component video, use the TV/Display Setup Wizard to optimize the component video image. See “TV/Display Setup Wizard” on page 5. Follow the onscreen instructions. You should complete these procedures before troubleshooting.
- Or
- If you cannot see a video image on your TV/Display while connected using component video or the problem is not resolved, use the following chart to correct the condition.

Component video troubleshooting chart

Problem: You cannot see a video image on your TV/Display that is satisfactory, while using the HP Digital Entertainment Center that is connected with component video out.

Solution: Select the condition and corresponding procedure that most closely matches your problem when connected to Component Video Out:

Problem	Screen image	Solution: See
DVD does not play	A DVD error message on screen, or an extended blank screen, indicates that your DVD will not play. Your commercial DVD might not play video when connected to Component Video Out at 720p or 1080i.	"DVD Does Not Play or an Error Appears on Screen" on page 24.
Blank screen	No video image. Screen is blue, black, or very distorted. Component Video Out may not work because the output setting remains at an unsupported format. For example, 480p format is set on a standard-definition TV that does not support a 480p format. Some displays may not accept 720p format.	"Blank screen (blue, black, or distorted)" on page 25. After inserting a DVD, see "DVD Does Not Play or an Error Appears on Screen" on page 24.
	No video image after you have changed the Video Out cable connection to the TV.	"Check component video" on page 23.
Wrong colors or erratic video	The screen displays wrong colors or erratic video, after Media Center optimizes your display.	"Wrong Colors or Erratic Video on Screen" on page 29.


DVD does not play or an error appears on screen

Content-protected commercial DVD playback requires 480i or 480p format settings when component video is connected. This applies to most retail movie DVDs. DVDs may not play after your TV/Display settings are optimized because of copy protection that is built into commercial DVDs.

Problem: You might see a blank screen or an error message indicating that your DVD will not play, after you insert it into the drive and select play.

Solution: To play a commercial DVD video, in component video, in Media Center, if you see an error message or blank screen:

- 1 Press Stop on the remote control.
- 2 Press Media Center on the remote control or keyboard.
- 3 Click **More Programs, HP Settings**, and then **Video Settings**.



4 Do one of the following:

- Click **DVD Mode (480p)**. (Select this mode only if your TV supports 480p mode.)

Or

- Click **Display/Connection Wizard**. Follow the onscreen instructions to set the 480i format. The screen may flash as the settings are applied.

NOTE: Select 480p mode only if your TV supports 480p progressive scan mode. If your TV does not support 480p mode, set 480i mode and play the DVD.

5 Press Media Center on the remote control or keyboard.

6 Click **Play DVD**.

7 After playing the commercial DVD video in component video, use the TV/Display Setup Wizard to return the desktop image and Media Center to a higher-resolution format. See “TV/Display Setup Wizard” on page 5. Follow the onscreen instructions.

Blank screen (blue, black, or distorted)

Problem: Some TV/Displays may display a blank screen after initial setup in component video. You may see a dark, blue, or distorted screen.

Solution: If your TV/Display shows these conditions, or is too difficult to use, see the following table:

Blank Screen for:	Solution:
1 to 2 minutes after you first turn on your system during initial setup.	No action is required. CAUTION: Do NOT restart your HP Digital Entertainment Center until the screen indicates that setup is complete.
About 30 seconds after restarting.	No action is required. Do NOT restart your HP Digital Entertainment Center. Wait for the display to reappear.
More than 4 minutes after you first turn on your system.	You might see the Microsoft Windows logo, and then the screen remains blank. Your television and HP Digital Entertainment Center may have mismatched screen resolution. The HP Digital Entertainment Center Video Out format may not be supported by the connected TV/Display. After any system restart, see “Correcting an extended blank screen with component video out” on page 25.

Correcting an extended blank screen with component video out

Follow the steps carefully. If you observe a blank or distorted screen for more than 3 minutes in component video, do the following:

- Video checklist.
- Connect another Video Out.
- Adjust the video image.
- Reconnect to component video.

Video checklist

To check video:

- 1 Turn off the TV/Display.
- 2 Turn off the HP Digital Entertainment Center by pressing and holding the On/Standby power button for 4 seconds. The On/Standby button should be dark and not lit amber or blue.
- 3 Check the cables. Make sure that they are completely plugged in and that the green, blue, and red colors match.


Green: Y, Blue: Pb, Red: Pr 

- 4 Remove all other Video Out cables from the HP Digital Entertainment Center back panel.
 - 5 Turn on the TV/Display.
 - 6 Check the TV/Display input switch. For example "Component 1."
 - 7 Turn on the HP Digital Entertainment Center by pressing the On/Standby power button. Wait 1 to 2 minutes. The video image reappears.
 - 8 Check the screen.
 - If you can see the video image, optimize the HP Digital Entertainment Center video image so it fits your TV screen, use the TV/Display Setup Wizard. See "TV/Display Setup Wizard" on page 5. Follow the onscreen instructions.
- Or
- If you cannot see the video image, see the next section "Connect another video out."

Connect another Video Out

To temporarily change Video Out such as DVI, VGA, S-video, or composite video (any output other than component video):

- 1 Turn off the TV/Display.
- 2 Turn off the HP Digital Entertainment Center by pressing and holding the On/Standby power button for 4 seconds. The On/Standby button should be dark and not lit amber or blue.
- 3 Disconnect the component video cable from the HP Digital Entertainment Center back-panel Video Out.
- 4 Connect another Video Out, such as DVI, VGA, S-video, or composite video cable to the HP Digital Entertainment Center back-panel Video Out.



NOTE: If your TV/Display can accept DVI or VGA video, connect DVI or VGA video, for a higher-quality image.

- 5 Turn on the TV/Display.
- 6 Switch the TV/Display input to the DVI, VGA, S-video, or composite video input.
- 7 Turn on the HP Digital Entertainment Center by pressing the On/Standby power button.
 - a Wait 1 to 2 minutes. The video image reappears.
 - b Do not restart your HP Digital Entertainment Center.

Adjust the video image

To adjust the video settings:

- 1 Optimize the video image so it fits your TV screen. Use the TV/Display Setup Wizard. See "TV/Display Setup Wizard" on page 5. Follow the onscreen instructions.
- 2 Select one of the following for your permanent Video Out connection:

Video Out	Options
Video (composite) 	Stop here. <i>Or</i>
S-video 	See the next section to reconnect to component video, and then adjust the video image.
Component (Y, Pb, Pr) 	See the next section to reconnect to component video, and then adjust the video image.
VGA 	Stop here. <i>Or</i> Use VGA video to start up your system and leave it connected.
DVI 	Stop here. <i>Or</i> Use DVI video to start up your system and leave it connected.

Reconnect to component video

To reconnect to component video:

- 1 Turn off the TV/Display.
- 2 Turn off the HP Digital Entertainment Center.
 - In Media Center, click the **Shut Down** icon and select **Shut Down**.
 - Or*
 - On the desktop, click **Start** on the taskbar, click **Turn Off Computer**, and click **Turn Off**.

The On/Standby button should be dark and not lit amber or blue.

- 3 Remove the temporary Video Out cable.
- 4 Reconnect Component Video Out. Green: Y, Blue: Pb, Red: Pr   
- 5 Turn on the TV/Display.
- 6 Switch the TV/Display input to the component video input. For example "Component 1."
- 7 Turn on the HP Digital Entertainment Center by pressing the On/Standby power button. Wait 1 to 2 minutes. The video image reappears.
- 8 Check the screen.
 - If you can see the video image, optimize the HP Digital Entertainment Center video image so it fits your TV screen, see "TV/Display Setup Wizard" on page 5. Follow the onscreen instructions.
 - Or*
 - If you cannot see the video image, re-connect the most recent video input that worked, and use it for your permanent video connection. You may have to reload the NVIDIA GeForce 6600 Driver software to continue to use component video. To uninstall and reinstall the driver application, see the next section "Reload the graphics driver."

Reload the graphics driver

To reload the graphics driver to correct a blank or distorted screen in component video:

- 1 Connect another video out. See page 27.
- 2 Click **Control Panel, Add or Remove Programs**.
- 3 Select **NVIDIA Drivers, Remove**. Click **Yes** and **Yes** to erase saved nView profiles.
- 4 Click **Yes** to restart the HP Digital Entertainment Center.
- 5 After the system restarts, click **OK** at the Media Center video card error message.
- 6 Close Media Center.
- 7 Click **Control Panel, All programs, PC Help and Tools, HP Application Recovery**. The Application and Driver Recovery window appears.
- 8 Select **Driver Installation** to reinstall the drivers shipped with the HP Digital Entertainment Center and click **Next**.
- 9 Select **NVIDIA Graphics Driver** and click **Install**. The driver installs. Click **Cancel**.
- 10 Reconnect to component video. See page 28.

Wrong colors or erratic video on screen

Problem: During the Media Center optional setup, if your display uses a component video connection, the wizard may change the display color depth and show wrong colors or erratic video. This may occur if you select a resolution that is not supported by your TV/Display. The component video cables might not be plugged in correctly.

Solution: If the colors look wrong, or the video seems erratic, do the following:

- 1 See "Check component video" on page 23.
- 2 See "Correcting an extended blank screen with component video out" on page 25.

Line at bottom of the screen

Problem: The TV/Display shows a line below the image during DVD playback.




Solution: While playing the DVD, click **More Info, Zoom**. Select the zoom that best fits your screen.

Troubleshooting DVI

This section contains important information about troubleshooting problems that may occur with your HP Digital Entertainment Center DVI Video Out Setup, especially when you connect a DVI cable to your HDTV.

This section also applies to connecting DVI with an HDMI adapter cable.



Blank screen after powering up and during initial startup with DVI

Problem: After powering up and during initial startup, if your HP Digital Entertainment Center is connected to DVI Video Out, you may notice that the TV/Display screen is: dark, blue, distorted, cropped, or inside dark borders.


Solution: If your HDTV displays these conditions, or is too difficult to use, see the following table:

Blank screen for:	Action:
1 to 2 minutes after you first turn on your system during initial setup.	No action is required. CAUTION: Do not restart your HP Digital Entertainment Center until the screen indicates that setup is complete.
About 30 seconds after restarting.	No action is required. Do not restart your HP Digital Entertainment Center. Please wait for the display to reappear.

Recovering your system with DVI or DVI/HDMI

Problem: On some TVs you do not see a blue and white HP logo screen that shows the function key F10=System Recovery selection. You cannot perform recovery or certain activities in DVI.

Solution: Change your Video Out connection to VGA; recover your system; and then reconnect the DVI connection.



NOTE: Make sure that you have updated software. Refer to: <http://www.hp.com/support>

Blurred screen text


Problem: The text is not well defined on a flat panel TV with DVI. The display is in TV mode. This condition can occur if your HP Digital Entertainment Center was connected to component video and you have changed to DVI.

Solution: Use this procedure if you have a monitor or a TV with monitor resolution settings connected to the HP Digital Entertainment Center with DVI and see blurry screen text. To change the TV/Display from TV mode to monitor mode, do the following:

- 1 Right-click the desktop, click **nVidia Display** in the dialog box, and then click **TV** (model).
- 2 Select **nView Display Settings** (or **TV Settings**) from the left-side list. The window appears.

- 3** Click **Device Settings** and then uncheck **Treat digital display as HDTV**. Click **Apply**.
- 4** Select **Native** and then click **Apply** (Accept even though you see a slight overscan). Click **OK**.
- 5** Select **Screen Resolutions and Refresh Rates** from the left-side list. The window appears.
- 6** Uncheck **Show standard HDTV formats** in the lower left corner of the window. Click **Yes** to remove HDTV custom timings pop-up
- 7** Adjust the slider bar to select the native screen resolution of your TV/Display. Click **Apply**.
If you do not know your native screen resolution, repeat this step until your text is clear with minimal overscan. Write down your native screen resolution.
- 8** Click **OK** to close the window.
- 9** For the best picture, set your monitor to the native resolution using Screen Resolution and Refresh Rates. See "Desktop Video Adjustments" on page 14.

CAUTION: Be careful when changing settings. The HP Digital Entertainment Center Video Out requires specific configurations for certain TV/Display types and resolutions. This setup procedure is advanced.



Video Out Information

This section contains background information and descriptions of Video Out operation relating to the HP Digital Entertainment Center. Refer to the *User's Guide* for connection information from HP Digital Entertainment Center to the TV/Display.

TV/Display Types

The following table represents typical TV formats. Choose the type that most closely matches your TV/Display: Your TV/Display model may vary.

TV type	Aspect ratio	Screen size (diag)	Format	Inputs
Standard (traditional)	4:3	13 to 27 inches	480i	Composite S-video
Standard (progressive scan)	4:3	19 to 27 inches	480i	S-video Composite
			480i 480p	Component
EDTV Flat-panel or CRT	4:3 or 16:9 Widescreen format	42+ inches	480i (SDTV mode)	Composite S-video
			480i 480p 720p	Component VGA DVI HDMI (with adapter)
HDTV Flat-panel or CRT, or other	4:3 or 16:9 Widescreen format	42+ inches	480i (SDTV mode)	Composite S-video
			480i (EDTV mode) 480p (EDTV mode) 720p 1080i	Component VGA DVI HDMI (with adapter)

Video Out Formats

Video Out formats consist of:

- Display resolution: such as 480i or 720p format.
- Scanning system: i = interlaced scan @ 30 Hz refresh rate, or p = progressive scan @ 60 Hz refresh rate.
- Aspect ratio: 4:3 or 16:9.

Display resolution/format

Display resolution refers to the number of pixels on your TV/Display screen. The following table shows pixels that correspond to standard Video Out formats:

Format	4:3 aspect ratio	16:9 aspect ratio
480i, 480p	640 by 480 pixels	853 by 480 pixels
720p	960 by 720 pixels	1280 by 720 pixels
1080i	1440 by 1080 pixels	1920 by 1080 pixels

For example, 640 by 480 pixels refers to the size of the screen. 640 is the width of the screen, and 480 is the height of the screen, in pixels.

The HP Digital Entertainment Center does not support 1080p, but most 1080p TV/Displays support 1080i.

Many TV/Displays specify a *native* resolution which is recommended by the display manufacturer. You may have to adjust the HP Digital Entertainment Center to use the native resolution. Your display resolution setup may vary by TV/Display type.

To optimize the HP Digital Entertainment Center video image so it fits your TV screen with component video connections:

- Use the TV/Display Setup Wizard. See “TV/Display Setup Wizard” on page 5.

Or

- “HDTV Overscan Compensation” on page 12.

Or

- To adjust your display, see “Desktop Video Adjustments” on page 14.

Scanning system

Interlaced or progressive refers to the scanning system. Interlaced scan formats are 30 Hz. Progressive scan formats are 60 Hz. 30 Hz or 60 Hz is the screen refresh rate. The *screen refresh rate* is the rate at which a monitor or television can redraw the screen from top to bottom.

NOTE: NTSC Component Video Out refreshes the screen approximately 30 times per second (30 Hz) when using interlaced formats, and 60 times per second (60 Hz) when using progressive scan formats.

In an interlaced format, the TV/Display screen shows every odd line at one scan of the screen and then follows that up with the even lines in a second scan. Since there are 30 frames shown per second, the screen shows one half of the frame every 60th of a second. For smaller TV/Display screens, this is less noticeable. As TV/Display screens get larger, the problem with interlacing is the potential for a flickering display. Progressive scan formats eliminate flicker.

Aspect ratio

The aspect ratio refers to the ratio of the width to the height of the display screen. 720p and 1080i are typically 16 x 9 widescreen aspect ratios. 480i and 480p are typically 4 x 3 aspect ratios, the standard TV screen.

Display Image Size

Your screen may show a larger image (*Overscan*), which may *Pan* when you move the cursor past the edge of the screen. The large screen size may *Crop* the video image so the edges appear to be missing. This condition is common when connecting a computer to a TV because most TVs introduce an overscan of five to fifteen percent.

To optimize the HP Digital Entertainment Center video image so it fits your TV screen, use the TV/Display Setup Wizard. See "TV/Display Setup Wizard" on page 5. Follow the onscreen instructions.

Overscan

In this illustration, "2" shows the (light blue) edges of the Media Center video image that are not visible on the TV/Display screen. The text above the screen is cropped.



1 TV viewing area 2 Full video image

Cropping

Cropping is the condition when the edges of the video image are not visible on the TV/Display screen. The screen cursor disappears when moved past the edge of the screen, if panning is not enabled.

The drawback of the 640 x 480 (Low) resolution setting is that desktop pop-up windows may be cropped in 480i and 480p resolutions. Pop-up windows may not be able to display the bottom portion of the window, depending on the height of the window, where the OK, Cancel, and Apply buttons are located.



Pop-up window showing lower buttons

Panning

Panning allows you to see hidden areas of the video image by moving the cursor to the edges of the screen. Move the cursor to the edges of the screen to reveal the hidden areas. When you move the cursor, the screen image moves. Media Center may not allow panning to access the hidden screen areas. The Windows desktop allows panning. The screen cursor disappears when moved past the edge of the screen, if panning is not enabled.

Important Notes

Plasma TV/Display Image Retention

A stationary image on your plasma TV/Display may retain the image on the screen if left on for prolonged periods. To avoid image retention, follow these guidelines:

- Always use a screen saver from your HP Digital Entertainment Center display settings.
- Avoid keeping a stationary (unmoving) image on the screen for extended periods. Stationary images include but are not limited to:
 - The Media Center user interface or PC desktop
 - Still image/photo or video paused for prolonged periods
- Use low-contrast colors for desktop background images.
- Reduce brightness to around 50 percent.
- After displaying any still image, play back a video in the Wide or Full screen setting for over three times longer than the previous still image.

www.hp.com



Printed in



5 9 9 1 - 4 0 4 1