Owner's Operating Manual

CRYSTAL

CR-26HD CR-32HDi

High-Definition, Liquid-Crystal Display (LCD) Panels with Wide\/ision[™]



THE WORLD'S FINEST HOME THEATER PRODUCTS™

ONE YEAR LIMITED WARRANTY

For LCD Displays

Congratulations on your purchase of a Runco video product and welcome to the Runco family! We believe Runco produces "The World's Finest Home Theater Products." With proper installation, setup and care, you should enjoy many years of unparalleled video performance.

This is a LIMITED WARRANTY as defined in the Magnuson-Moss Warranty Act. Please read it carefully and retain it with your other important documents.

WHAT IS <u>COVERED</u> UNDER THE TERMS OF THIS LIMITED WARRANTY:

SERVICE LABOR: Runco will pay for service labor by a Runco Authorized Service Center when needed as a result of a manufacturing defect for a period of one (1) year from the effective date of delivery to the end user.

PARTS: Runco will provide new or rebuilt replacement parts for the parts that fail due to defects in materials or workmanship for a period of one (1) year from the effective date of delivery to the end user. Such replacement parts are then subsequently warranted for the remaining portion (if any) of the original warranty period.

WHAT IS <u>NOT COVERED</u> UNDER THE TERMS OF THIS LIMITED WARRANTY:

Image retention on LCD display panels is specifically excluded from coverage under this Limited Warranty. Image retention or staining of an image is the result of misuse of the product and therefore cannot be repaired under the terms of this Limited Warranty.

Normal viewing material such as television/satellite broadcasts, videotape or DVDs (not put into pause for extended periods of time) will not cause damage to your display under normal conditions. Many DVD players are also equipped with screen savers for this reason.

TO AVOID IMAGE RETENTION (Burn-in): Please ensure that still images are not left on your LCD display panel. Also ensure that images displayed in the 4:3 aspect ratio mode (black or gray stripes, but no picture information is present on the left and right edges of the screen) are used as infrequently as possible. This will prevent permanent retention on your LCD display panel, which can be seen permanently under certain conditions once burn-in has occurred.

The types of images to avoid include video games, still images and computer screens with stationary tool bars and icons. (This is why computers are equipped with screen savers – to prevent still images from burning into the monitor's phosphors after being displayed continuously for an extended period of time).

This Limited Warranty only covers failure due to defects in materials and workmanship that occur during normal use and does not cover normal maintenance. This Limited Warranty does not cover cabinets or any appearance items; failure resulting from accident, misuse, abuse, neglect, mishandling, misapplication, faulty or improper installation or setup adjustments; improper maintenance, alteration, improper use of any input signal; damage due to lightning or power line surges, spikes and brownouts; damage that occurs during shipping or transit; or damage that is attributed to acts of God. In the case of remote control units, damage resulting from leaking, old, damaged or improper batteries is also excluded from coverage under this Limited Warranty.

CAUTION: THIS LIMITED WARRANTY ONLY COVERS RUNCO PRODUCTS PURCHASED FROM RUNCO AUTHORIZED DEALERS. ALL OTHER PRODUCTS ARE SPECIFICALLY EXCLUDED FROM COVERAGE UNDER THIS LIMITED WARRANTY. MOREOVER, DAMAGE RESULTING DIRECTLY OR INDIRECTLY FROM IMPROPER INSTALLATION OR SETUP IS SPECIFICALLY EXCLUDED FROM COVERAGE UNDER THIS LIMITED WARRANTY. IT IS IMPERATIVE THAT INSTALLATION AND SETUP WORK BE PERFORMED ONLY BY AN AUTHORIZED RUNCO DEALER TO PROTECT YOUR RIGHTS UNDER THIS WARRANTY. THIS WILL ALSO ENSURE THAT YOU ENJOY THE FINE PERFORMANCE OF WHICH YOUR RUNCO PRODUCT IS CAPABLE WHEN INSTALLED AND CALIBRATED BY RUNCO AUTHORIZED PERSONNEL.

RIGHTS, LIMITS AND EXCLUSIONS:

Runco limits its obligations under any implied warranties under state laws to a period not to exceed the warranty period. There are no express warranties. Runco also excludes any obligation on its part for incidental or consequential damages related to the failure of this product to function properly. Some states do not allow limitations on how long an implied warranty lasts, and some states do not allow the exclusion or limitation of incidental or consequential damages. So the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

EFFECTIVE WARRANTY DATE:

This warranty begins on the effective date of delivery to the end user. For your convenience, keep the original bill of sale as evidence of the purchase date.

IMPORTANT – WARRANTY REGISTRATION:

Please fill out and mail your warranty registration card. It is imperative that Runco knows how to reach you promptly if we should discover a safety problem or product update for which you must be notified.

CONTACT A RUNCO AUTHORIZED SERVICE CENTER TO OBTAIN SERVICE:

Repairs made under the terms of this Limited Warranty covering your Runco video product will be performed at the location of the product, during usual working hours, providing location of product is within normal operating distance from a Runco Authorized Service Center. In some instances it may be necessary for the product to be returned to the Runco factory for repairs. If, solely in Runco's judgment, location of product to be repaired is beyond normal operating distance of the closest Runco Authorized Service Center, or the repair requires the unit be returned to the Runco factory, it is the owner's responsibility to arrange for shipment of the product for repair. These arrangements must be made through the selling Runco Dealer. If this is not possible, contact Runco directly for a Return Authorization number and shipping instructions. Runco will return product transportation prepaid in the United States, unless no product defect is discovered. In that instance, shipping costs will be the responsibility of the owner.

COPYRIGHT AND TRADEMARKS:

© Copyright 2007 Runco International. This document contains proprietary information protected by copyright, trademark and other intellectual property laws. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer.

Reflection, Enhanced GEN3, DHD, Vivix, Virtual Cinema, CineWide, AutoScope, O-Path, CinOptx, LiveLink, CSMS, SuperOnyx and VirtualWide are trademarks of Runco International. All other trademarks and registered trademarks used in this document are the property of their respective owners.

Runco International products are manufactured under one or more of the following patents: US. Patent 6755540 and Other Patents Pending.

ADDITIONAL INFORMATION:

To locate the name and address of the nearest Runco Authorized Service Center, or for additional information about this Limited Warranty, please call or write:

RUNCO INTERNATIONAL, INC. Attn: Customer Service Department 2900 Faber Street Union City, CA 94587 Ph: (510) 324-7777 Fax: (510) 324-9300 Toll Free: (800) 23-RUNCO

RUNCO VIDEO-PRODUCT INFORMATION RETAIN THIS INFORMATION FOR YOUR RECORDS

Model Purchased		Date	
Serial Number			
Runco Authorized Dealer Name			
Address			
City	State/Province	_	Postal Code
Phone	Fax		

Safety Precautions

Thank you for your purchase of this quality Runco product! It has been designed to provide you with the quality of video that is expected in a home theater. For the best performance, please read this manual carefully as it is your guide through the menus and operation.



WARNING

This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.

This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

CAUTION

To turn off main power, be sure to remove the plugs from power outlets. The power outlet socket should be installed as near to the equipment as possible, and should be easily accessible.

WARNING

TO PREVENT FIRE OR SHOCK HAZARDS, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE. ALSO DO NOT USE THIS UNIT'S POLARIZED PLUG WITH AN EXTENSION CORD RECEPTACLE OR OTHER OUTLETS, UNLESS THE PRONGS CAN BE FULLY INSERTED. REFRAIN FROM OPENING THE CABINET AS THERE ARE HIGH-VOLTAGE COMPONENTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

WARNING

This equipment has been tested and found to comply with the limits for a Class 'B' digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the Installation Manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area may cause harmful interference, in which case the user will be required to correct the interference at his own expense.

DOC Compliance Notice

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Please read and follow the safety precautions listed below to ensure the equipment is free from damage, and to ensure that no injury will occur as a result of improper use.

- Do not insert any object, especially metal or liquids, into the LCD display.
- Do not place any objects containing water or any other liquid on top of the LCD display.
- Do not place the units in direct sunlight, near heaters or in extremely dusty or humid locations.
- Do not install this system outdoors or otherwise exposed to the elements.
- Do not place heavy objects on top of the LCD display.
- If the power cord is damaged or frayed in any way, electrical shock and/or fire may result. Do not place objects on the power cord, and keep the cord away from heat-emitting devices. Should the power cord become damaged in any way, please contact your Runco Dealer for a replacement cord.
- Do not remove the cover of the LCD display for any reason. If any problems arise with the unit, please contact a Runco Dealer or Runco International for service. Removing the covers will void the warranty.

Table of Contents

ON	NE YEAR LIMITED WARRANTY	iii
Sa	fety Precautions	vi
1.	Introduction	1
	About This Manual	1
	Target Audience	1
	If You Have Comments About This Manual	1
	Textual and Graphic Conventions	1
	Using This Manual	2
	Description, Features and Benefits	3
	Key Features and Benefits	3
	Parts List	4
2.	Controls and Functions	5
	Crystal Series LCD Display at a Glance	5
	Controls and Indicators	5
	Crystal Series LCD Display Inputs and Outputs	6
	Crystal Series LCD Display Remote Control	8
3.	Installation	
	Remote Control	
	Battery Installation	
	Notes on Remote Control Operation	
	Quick Setup	14
	Installation Considerations	
	Wall-Mounting the Crystal Series LCD Display	
	Ambient Light	
	Other Considerations	
	Connections to the Crystal Series LCD Display	
	Rear Connector Access	16
	Connecting the Crystal Series LCD Display to Source Components	16
	MONITOR OUT Connection	20
	Connecting Headphones	20
	RS-232 Controller Connection	21

4.	Operation	23
	Turning on the Power	23
	Changing the OSD Language	23
	Setting the PC Display Properties	24
	Using the On-Screen Menus	25
	Main Menu	27
	Source	27
	Aspect Ratio	27
	Picture Adjust	29
	Audio	
	Channel	34
	Timer	34
	Setup	35
	ISF Calibration	38
	Using Picture-In-Picture (PIP)	41
	Changing the PIP Position	42
	Changing the PIP Size	43
	Changing the PIP Aspect Ratio	43
	Changing the PIP Image Mode	43
	Swapping the Main and PIP Images	44
	Swapping the Main and PIP Audio Programs	44
	Stereo Sound/SAP	45
5.	Maintenance and Troubleshooting	47
	Troubleshooting Tips	47
6.	Serial Communications	49
	RS-232 Connection and Port Configuration	49
	Serial Command Syntax	49
7.	Specifications	53
	Crystal Series LCD Display Specifications	53
	Crystal Series LCD Display Dimensions	54
	Computer/Video Signal Compatibility	56

List of Figures

2-1. Crystal Series LCD Display Controls and Indicators	5
2-2. Crystal Series LCD Display Rear-Panel Inputs and Outputs	6
2-3. Crystal Series LCD Display Remote Control	8
3-1. Antenna/Cable TV Connection	16
3-2. DVI Connections	17
3-3. Analog RGB Connections	18
3-4. Component Video Connections	19
3-5. Composite and S-Video Connections	19
3-6. Monitor Output Connections	20
3-7. Connecting Headphones	20
3-8. RS-232 Control System Connection	21
4-1. Crystal Series LCD Display OSD Menu Structure	26
4-2. Typical PLUGE Pattern for Adjusting Brightness	29
4-3. Typical Gray Bar Pattern for Adjusting Contrast	30
4-4. Typical Color Bar Pattern for Adjusting Color Saturation and Tint	31
4-5. Typical Test Pattern for Adjusting Sharpness	32
4-6. Crystal Series LCD Display Splash Screen	40
7-1. CR-26HD Dimensions	54
7-2. CR-32HDi Dimensions	55

Notes:

1. Introduction

This Owner's Manual describes how to install, set up and operate the Runco CR-26HD and CR-32HDi LCD Displays. Throughout this manual, the Runco CR-26HD and CR-32HDi LCD Displays are referred to simply as the "Crystal Series LCD Display."

Runco has prepared this manual to help home theater installers and end users get the most out of the Crystal Series LCD Display.

Runco has made every effort to ensure that this manual is accurate as of the date it was printed. However, because of ongoing product improvements and customer feedback, it may require updating from time to time. You can always find the latest version of this and other Runco product manuals on-line, at www.runco.com.

Runco welcomes your comments about this manual. Send them to techpub@runco.com.

Text Conventions: The following conventions are used in this manual, in order to clarify the information and instructions provided:

- Remote control button identifiers are set in upper-case bold type; for example, "Press **EXIT** to return to the previous menu."
- Computer input (commands you type) and output (responses that appear on-screen) is shown in monospace (fixed-width) type; for example: "To change the aspect ratio to Letterbox, type [S4E0002."
- All keys with functional names are initial-capped, set in bold type and enclosed in angle brackets. These keys are the following: <Enter>, <Spacebar>, <Control>, <Esc> and <Tab>.
- **<Enter>** indicates that you may press either the RETURN or ENTER key on your computer keyboard if it has both keys.

In addition to these conventions, underlining, boldface and/or italics are occasionally used to highlight important information, as in this example:



A carriage return **must** be used after each command or string.

1.1 About This Manual

< Target Audience

- If You Have Comments About This Manual...
- Textual and Graphic Conventions

Graphic Conventions: These symbols appear in numerous places throughout the manual, to emphasize points that you must keep in mind to avoid problems with your equipment or injury:



TIPS highlight time-saving short cuts and helpful guidelines for using certain features.



NOTES emphasize text with unusual importance or special significance. They also provide supplemental information.



CAUTIONS alert users that a given action or omitted action can degrade performance or cause a malfunction.

WARNINGS appear when a given action or omitted action can result

in damage to the equipment, or possible non-fatal injury to the user.





DANGER appears when a given action can cause severe injury or death.

1.2 Using This Manual

Use the following table to locate the specific information you need in this manual.

If you need	Turn to page:
Information about obtaining service	iv
General information about the CR-26HD and CR-32HDi LCD Displays	3
Installation instructions	13
First-time configuration instructions	23
Advanced configuration instructions	38
Troubleshooting tips	47
Specifications for the CR-26HD and CR-32HDi LCD Displays	53

Runco presents the high performance CR-26HD and CR-32HDi LCD Displays, perfect for those who demand our award-winning flat panel performance in a more intimate size than we offer with our larger plasma monitors. The Crystal Series LCD Displays are ideal for close-in viewing where picture quality remains a high priority, but larger displays cannot be accommodated.

The Crystal Series LCD Display CR-26HD and CR-32HDi LCD Displays incorporate the superb Vivix[™] digital video processing that produces outstanding picture quality with a wide range of both standard and high definition source material. In addition, the handsome, gloss black-finish television is engineered with ISF[™] calibration standards for the purest video performance.

The CR-26HD and CR-32HDi LCD Displays also feature a built-in ATSC tuner that receives terrestrial DTV broadcasts, in addition to an advanced, 185 channel, cable-ready NTSC stereo tuner. The Crystal Series LCD Display offers PIP, PBP, closed captioning, Parental Control (V-Chip) functionality and multi-language support. The display includes an integrated stereo audio system incorporating surround sound technology with two-way speakers and generous power amplification.

The advanced TFT active-matrix LCD display panel offers 1366 x 768 resolution and includes Runco's discrete aspect ratio control with VirtualWide™ mode to fill the 16:9 screen with standard 4:3 images without loss of picture quality. Also included are discrete source, aspect ratio and power selection and an RS-232 interface for whole house or automated control system integration.

The Crystal Series LCD Display is multimedia ready, with simple computer connections making gaming, Internet browsing and other computer activities quick and easy.

The Crystal Series LCD Display offers these key features and benefits:

- Native Resolution: 1366 x 768 (16:9 Native Aspect Ratio)
- Multiple Aspect Ratios with VirtualWide™ Mode
- Less than 4 inches thin
- DVI Input with High-bandwidth Digital Content Protection (HDCP)
- Built-in HDTV Tuner
- Exceptional detail and artifact-free video enhancement
- Runco video processing with 3:2 film detection circuitry

1.3 Description, Features and Benefits

Key Features and Benefits

- *Parts List* ➤ Your Crystal Series LCD Display is shipped with the following items. If any items are missing or damaged, please contact your Runco dealer or Runco Customer Service at (800) 23-RUNCO.
 - CR-26HD or CR-32HDi LCD Display (with Table Stand)
 - Remote Control Unit and two (2), AAA-size batteries
 - AC Power Cord
 - Warranty information and registration card
 - Runco CR-26HD/CR-32HDi Owner's Operating Manual (this document)

Optional Accessories:

• Wall Mount kit

Controls and Functions

2.1 Crystal Series LCD Display at a Glance

Figure 2-1 shows the locations of the Crystal Series LCD Display controls and indicators. <a>Controls and Indicators




Figure 2-1. Crystal Series LCD Display Controls and Indicators

- 1. TV/AV Button (Input Source Selection)
- 2. MENU Selection Button
- 3. Volume Adjustment Buttons
- 4. Channel Selection Buttons
- 5. Remote Control Sensor
- 6. Power Button
- 7. Power Indicator

Lights red to indicate that the Crystal Series LCD Display is in standby mode; lights green to indicate normal operation; flashes green when the Crystal Series LCD Display receives a signal from the remote control.

8. Speakers

Crystal Series LCD Display > Inputs and Outputs

Figure 2-2 shows the locations of the Crystal Series LCD Display inputs and outputs.




Figure 2-2. Crystal Series LCD Display Rear-Panel Inputs and Outputs

1. INPUT 2 S-Video Input

Standard S-Video input for connecting a DVD player, satellite receiver or Super VHS (S-VHS) VCR.

2. INPUT 2 Audio Input

3. INPUT 2 Composite Video Input

Standard composite video input for connecting a VCR, camcorder, laser disc player or other composite video source.

- 4. Headphone Jack
- 5. Main Power Switch (CR-32HDi only)
- 6. **Power Input (100 to 240 VAC)** Connect the Crystal Series LCD Display to power here.
- 7. **RGB HD**

A 15-pin VGA connection to a personal computer. The Crystal Series LCD Display automatically detects the signal resolution.

8. DVI/Computer Input (Digital)

HDCP-compliant digital video input for connecting a DVD player, personal computer or HD tuner with a DVI or HDMI output.



For best results, do not run your DVD player in progressive mode.

9. Audio Input (RGB/DVI)

Connect the audio output from your RGB or DVI source here.

10. ATSC DTV Input

75-ohm coaxial input for connecting a TV antenna or CATV system to the digital TV tuner.

11. INPUT 3 Component Video (RCA connectors)

Standard-definition (480i/576i) or high-definition (720p/1080i), YPrPb component input. This is the input for component video from sources such as DVD players.

12. INPUT 3 Composite Video Input

13. INPUT 3 Audio Input

Connect the audio output from your Input 3 source here.

14. INPUT 1 COMPOSITE VIDEO INPUT

15. INPUT 1 Audio Input

Connect the audio output from your Input 1 source here.

16. INPUT1 S-Video Input

17. RS-232 CONTROL PORT

A male, 9-pin D-sub connector for interfacing with a PC or home theater automation/control system.

18. MONITOR-OUT (Audio)

19. MONITOR-OUT (Composite Video)

2.2 Crystal Series LCD Display Remote Control

Figure 2-3 shows the Crystal Series LCD Display remote control, and the paragraphs that follow describe its functionality.




Figure 2-3. Crystal Series LCD Display Remote Control

1. OFF / ON

Use these buttons to turn the Crystal Series LCD Display on or off.

2. Numeric Buttons

Use these buttons to enter TV channel numbers or menu pass codes. Use the **100** button to enter channel numbers above 99. Use the – button to enter DTV sub-channel numbers.

3. TIMER OFF Button

Press this button to set the sleep timer. Press it repeatedly to scroll through the available options (Off, 10, 30, 60, 120 or 180 minutes).

4. Source Selection Buttons:

INPUT 1

Press this button to switch to Input 1.

INPUT 2

Press this button to switch to Input 2.

INPUT 3

Press this button to switch to Input 3.

DVI

Press this button to switch to the Digital Video input.

RGB HD

Press this button to switch to the RGB HD input.

тν

Press this button to switch to the Antenna/DTV/CATV input.



Input 1 and Input 2 have both S-Video and composite video connectors. Input 3 has both component and composite video connectors.

To specify which connection type you are using – or to switch from one to the other if equipment is connected to both – use the Input Selection menu under Setup (refer to **Input Selection** on page 37).

5. Memory Preset Buttons:

CUST

Press to recall settings for the current input from the "Custom" memory preset.

ISF NT (Night)

Press to recall settings for the current input from the "ISF Night" memory preset.

ISF DAY

Press to recall settings for the current input from the "ISF Day" memory preset.

6. Aspect Ratio Selection Buttons:

ANA (Anamorphic)

For 16:9 DVDs or HDTV program material.

4X3 (Standard 4:3)

The input signal is scaled to fit 4:3 display mode in the center of the screen.

LETBOX (Letterbox)

Image in letterbox format is enlarged to fit 16:9 full screen display and the upper/lower portions are "blanked off."

VWIDE (VirtualWide)

4:3 image is enlarged NON-linearly in horizontal direction to fit 16:9 full screen display.

7. Arrow Buttons (\blacktriangle , \blacktriangleleft , \blacktriangledown , \blacktriangleright)

Use these buttons to select items or settings, adjust settings, change TV channels or adjust sound volume.

ENTER

Press to select a highlighted menu item or confirm a changed setting.

8. **MENU**

Press this button to access the on-screen display (OSD) controls, or to exit the current menu and return to the previous one.

9. **EXIT**

Press this button to hide the OSD controls, or display program information (when available) if the OSD controls are already hidden.

10. Picture-In-Picture (PIP) Function Buttons

ASPECT (D)

Press to change the aspect ratio of the PIP window from 4:3 to 16:9 or vice versa.

SIZE ()

Press to choose from three PIP window sizes.

POSITION (B)

Press to choose the PIP window position (top left, top right, bottom left or bottom right corner).

PIP (□)

Press to change the PIP mode (picture-in-picture, picture-by-picture or off).

P.MODE (Nak)

Press to recall settings for the PIP input from either the "ISF Night" or "ISF Day" memory preset.

S.SWAP

Press to switch between the main and PIP audio programs.

SWAP

Press to swap the main and PIP windows.

TV/AV Đ

Press to switch to a different PIP video source.

11. Sound Control Buttons:

S.MODE

Press this button repeatedly to scroll through the available Equalizer presets (CUSTOM, STANDARD, MUSIC, FILM or SPEECH).

SURRND (Surround)

Press this button to turn Surround Mode on or off.

MTS/SAP (Multichannel Television Sound/Second Audio Program)

Press this button repeatedly to scroll through the available MTS settings (MONO, STEREO, SAP or Mono+SAP).

MUTE

Press this button to mute the audio output.

12. Favorite Channel Selection Buttons

Use these buttons to select stored favorite channels. To store favorite channels, select Favorite Channel from the Channel menu (described in Section 4).

Notes:

3. Installation

		3.1 Remote Control
To install batterie	s in the remote control:	 Battery Installation
1. Slide the bat	tery cover in the direction of the arrow and remove it.	
	luded batteries. Ensure that the polarities correctly match the \oplus and \ominus ide the battery compartment.	
3. Slide the bat	tery cover back on until it snaps into place.	
Note	1. Do not mix an old battery with a new one or different types of batteries.	
	2. If you will not use the remote control for a long time, remove the batteries to avoid damage from battery leakage.	
• Do not drop th	ne remote control or expose it to moisture or high temperature.	✓ Notes on Remote Control
	ontrol may malfunction under a fluorescent lamp. If that occurs, move the way from the fluorescent lamp.	Operation
	It there is nothing obstructing the infrared beam between the remote e IR receiver on the LCD display.	
A	The signal from the remote control can be reflected by walls or	



other surfaces.

- If the effective range of the remote control decreases, or it stops working, replace the batteries with new ones.
- Ambient conditions may possibly impede the operation of the remote control. If this happens, point the remote control at the LCD display and repeat the operation.

3.2 Quick Setup

Table 3-1 gives a quick overview of the Crystal Series LCD Display installation process. The sections following this one provide detailed instructions.



Installation should be performed by a qualified custom video installation specialist.

Table 3-1. Installation Overview

Step	Procedure	For Details, refer to page	
1	Mount the Crystal Series LCD Display on a wall (optional)	15	
2	Connect signal sources to the Crystal Series LCD Display	16	
3	Connect external controller to RS-232 port (optional)	21	
4	Apply power to the Crystal Series LCD Display	23	
5	Change the OSD language	23	
6	If using the Crystal Series LCD Display with a PC, adjust PC display properties	24	
7	Display calibration: adjust the following for each input ; save settings when finished: • Brightness • Contrast • Color level • Tint • Input position	27 through 37	

Proper installation of your Crystal Series LCD Display will ensure the highest possible picture quality. Whether you are installing the Crystal Series LCD Display temporarily or permanently, you should take the following into account to ensure that it performs optimally.

You can either place the Crystal Series LCD Display on a table or in an entertainment center, or mount it on a wall.

If you do decide to wall-mount the Crystal Series LCD Display, ensure that the wall-mount bracket is installed according to the instructions included with it. The wall must be capable of supporting a redundant weight factor three (3) times the weight of the display, or be reinforced.

Runco recommends that this be done by a custom installation specialist.



Use only the Runco-approved wall-mount kit designed for your display.

In general, minimize or eliminate light sources directed at the display. Contrast ratio in your images will be noticeably reduced if light directly strikes the display, such as when a shaft of light from a window or floodlight falls on the image. Images may then appear washed out and less vibrant.

Other considerations and tips that can help improve your installation:

- Keep the ambient temperature constant and below 35°C (95°F). Keep the display away from heating and/or air conditioning vents. Changes in temperature may cause drifts in the display circuitry, which may affect performance.
- Keep the Crystal Series LCD Display away from devices that radiate electromagnetic energy such as motors and transformers. Common sources of these include slide projectors, speakers, power amplifiers and elevators.

3.3 Installation **Considerations**

 Wall-Mounting the Crystal Series LCD Display

- Ambient Light
- Other Considerations

3.4 Connections to the Crystal Series LCD Display

Proceed as follows to connect the Crystal Series LCD Display to your video sources, external controller(s) – if present – and AC power.

When connecting your equipment:

- Turn off all equipment before making any connections.
- Use the correct signal cables for each source.
- Ensure that the cables are securely connected. Tighten the thumbscrews on connectors that have them.
- Use the left audio input when connecting mono audio sources.
- **Rear Connector Access** To access the left rear connector panel, push down on the plastic clip holding the cover in place. Then, pull firmly on the cable access cover to open it.
 - Connecting the Crystal Series LCD Display to Source Components

 Connect your video sources to the Crystal Series LCD Display as shown and described in the sections that follow.

Antenna/Cable TV Connection: Connect your antenna or cable television source to the ANT jack on the rear of the Crystal Series LCD Display; see Figure 3-1.




Figure 3-1. Antenna/Cable TV Connection

DVI Connections: The Crystal Series LCD Display has a DVI input for connecting a DVD player, DTV decoder, personal computer or any other device with a DVI or HDMI output. Connect such devices as shown in Figure 3-2.



Use the DVI inputs whenever possible. This ensures the highest video quality because the signal is carried in the digital domain throughout the entire signal path, from source component output into the display.



This Crystal Series LCD Display supports the VESA Display Data Channel (DDC) standard. This standard provides "Plug and Play" capability; the display and a VESA DDC-compatible computer communicate their setting requirements, allowing for quick and easy setup.

In order for Plug and Play to work correctly, you must turn on the display before you turn on the connected computer.




Figure 3-2. DVI Connections

RGB Connections: The Crystal Series LCD Display has an RGB input for connecting a personal computer; see Figure 3-3.




Figure 3-3. Analog RGB Connections



- 1. Refer to **Computer/Video Signal Compatibility** on page 56 for a list of computer signals compatible with the Crystal Series LCD Display. Use with signals other than those listed may cause some functions not to work.
- 2. Some Macintosh computers may require a Macintosh video adapter. Contact your nearest authorized service center or dealer.
- 3. This Crystal Series LCD Display may not be able to display images from notebook computers in simultaneous (CRT/LCD) mode. Should this occur, switch the notebook computer to "CRT only" mode. If you are unsure how to do this, refer to your notebook computer's user manual.

Component Video Connections: If you have a DVD player or DTV decoder with a component (YPbPr) output, connect it to INPUT 3 of the Crystal Series LCD Display as shown in Figure 3-4.




Figure 3-4. Component Video Connections

Composite/S-Video Connections: The Crystal Series LCD Display has two (2) S-Video and three (3) composite video inputs for connecting a VCR, camcorder, laser disc player or DVD player; see Figure 3-5.




Figure 3-5. Composite and S-Video Connections

MONITOR OUT > Connection

The Crystal Series LCD Display has a monitor out feature for connecting a second VCR or other auxiliary equipment. Connect the MONITOR OUT audio and video jacks to the audio and video inputs of the VCR or other equipment as shown in Figure 3-6.

You can route either the main or picture-in-picture (PIP) source signal to the monitor outputs. For more information, refer to *Monitor Out* on page 37.




Figure 3-6. Monitor Output Connections

Connecting Headphones You can connect a set of headphones to the Crystal Series LCD Display to watch a program without disturbing others. Connect them to the headphone output located at INPUT 2; see Figure 3-7.





Figure 3-7. Connecting Headphones

Use a "null-modem" RS-232 cable with a 9-pin female connector to connect a PC or home theater control/automation system (if present) to the RS-232 port on the Crystal Series LCD Display; see Figure 3-8.

 RS-232 Controller Connection

For more information about using this connection, refer to **Serial Communications** on page 49.

(Left Side)





Notes:

4. Operation


- Turn on your source components. 1.
- 2. Plug the female end of the power cord into the AC receptacle on the rear of the Crystal Series LCD Display (AC 100V ~ 240V).
- З. Connect the other end to your AC power source.
- Turn on the main power switch at the rear of the display (CR-32HDi only). 4.
- 5. The power indicator lights red to indicate that the Crystal Series LCD Display is in "standby" mode.
- 6. Press the **ON** button on the remote control to turn on the display (or press the power button on the front of the display). The power indicator flashes for a few seconds, then lights solid green.
- 7. After a brief warm-up period (approximately 10 seconds), the Crystal Series LCD Display will display an image.

The Crystal Series LCD Display OSD language is initially set to English, but can also display the menus in French, Spanish, Portuguese or German. To change the OSD language:

- 1. Press MENU.
- 2. Select Setup from the Main Menu.
- Select **OSD Language** from the Setup Menu. З.
- Press ▲ or ▼ to highlight the desired language and press ENTER. The change takes 4. effect immediately.

4.1

4.2 **Changing the OSD** Language




Turning on the Power

4.3 Setting the PC Display Properties


To maximize image quality when using the Crystal Series LCD Display with a personal computer, you may need to adjust the display properties of your PC video card. To do this:

1. Choose Settings from the Windows Start menu and click on "Control Panel."



- 2. Double click on the **Display** icon.
- 3. Click the **Settings** tab on the display dialog box.
- 4. Adjust the resolution to 1024x768 pixels.

5. Click the **Advanced** button and click the **Monitor** tab on the dialog box. Set the vertical frequency to 60Hz and click **OK**.



Plug and Play Monitor and NVidia Riva TNT2 Properties
General Adapter Monitor Troubleshooting Color Management Monitor Type LCD Properties
Monitor Settings
Refresh Frequency:
60Hz ✓ Hide modes that this monitor cannot display. Unchecking this box will allow you to set your display to modes that this monitor cannot display correctly. This may lead to an unusable display and/or damaged hardware.
OK Cancel Apply



- 1. The maximum available resolution and vertical frequency is 1024x768 at 75Hz or the maximum supported by your video card, whichever is lower. You can get the best picture at 1024x768/60Hz.
- 2. The Crystal Series LCD Display supports 24-bit color (16,777,216 possible colors).

To use the on-screen menus:

- 1. Press **MENU** to display the Main Menu.
- 2. To select a menu item, use the up- or down-arrow buttons (▲, ▼) on the remote control to highlight it.
- 3. Press **ENTER** or the right-arrow button (▶) to access that menu.
- 4. Use the up- or down-arrow buttons (▲, ▼) to select the setting you want to change. Then, press **ENTER** or the right-arrow button (►).
- 5. Press the right- or left-arrow button (\triangleleft , \triangleright) to change that setting.
- 6. To return to the previous menu, press **MENU**.

The Crystal Series LCD Display OSD menus are arranged hierarchically, as shown in Figure 4-1. Depending on the selected input source and/or signal characteristics, some menu options may not be available.

4.4 Using the On-Screen Menus

	TV				English, Français,	1
	Input 1	1		OSD Language	Español, Português or Deutsch	
Source	Input 2					_
	Input 3				Auto Adjust H. Position	_
	DVI	-			H. Position	_
	RGB			PC Mode Adjust	V. Position H. Size	_
	Anamorphic				H. Size Phase	_
Aspect Ratio	Standard					_
Азрест напо	Letterbox				Factory Preset Display (On/Off),	_
	VirtualWide			Caption	Mode, CC On Mute	
	Brightness				(Yes/No)	
	Contrast				Parental Lock	
	Color	0 100	Setup		(On/Off), TV Rating,	
	Tint		Octup	Parental Control	Movie Rating, Unrated	
	Sharpness			Parentai Control	(Allow/Block),	
Picture Adjust	Color Temp.	5400, 6500, 8500 or Custom			Change PIN (default is 0000)	
-	Backlight	0, 5, 10, 15, 20, 100		Letterbox Mode	Standard or Cinema	
	Save Settings (not available on RGB input)	Custom			Fill Input 1/Input 2: Video or S-Video	-
	Restore Settings (not available on	Custom, ISF Day, ISF Night		Input Selection	Input 3: Video or Component	
	RGB input)	ç	ISF Calibration	Monitor Out	Main or PIP: Video	
	Balance	L10, L9, L8 0 R8, R9, R10		Overscan (not available on RGB	H. Overscan, H. Shift, V. Overscan,	
	Equalizer	Standard, Music, Film, Speech or Custom		input)	V. Shift	
Audio	Surround	(On/Off)		Picture Adjust White Balance	Brightness	=
	Surround	English, Français,			Contrast	0 100
	Audio Language	Español or Português			Color	
	TV Speaker	(On/Off)			Tint	_
		AIR			Sharpness	E400,0E00,0E00,
	Auto Tuning	CABLE (STD / IRC / HRC)			Color Temp.	5400, 6500, 8500 or Custom
Channel		Return			Backlight	0, 5, 10, 15, 20, 100
	Add/Erase Favorite Channel	_			Save Settings (not available on RGB input)	ISF Night, ISF Day, Custom
	Time	12:00 AM - 11:59 PM			R/G/B Gain	
Timer	0.7	Enable/Disable, Time,			R/G/B Offset	
	On Timer	Channel, Volume		Blue Enable	(Enable/Disable)	
	Off Timer	Enable/Disable, Time		DNR	0, 10, 20, 100	
	Sleep Timer	Off, 10, 30, 60, 120 or		Gamma	2.0, 2.2 or 2.4	
	Time Zone	180 minutes Eastern, Central,		Baud Rate	115200, 19200, 9600 or 2400	-
		Mountain or Pacific		Comr	Command Ack	(On/Off)
				Factory Reset		1
				Splash Duration	0, 1, 2, 3, 60 secs.]

Figure 4-1. Crystal Series LCD Display OSD Menu Structure

The Main Menu is the starting point for accessing all Crystal Series LCD Display functions.

(The ISF Calibration menu is not accessible until you enter a passcode.)


< Main Menu

Runco CR-26HD
Source
Aspect Ratio
Picture Adjust
Audio
Channel
Timer
Setup
ISF Calibration

From the Main Menu, select Source to choose a video signal source.

The active source is indicated by a green square (\blacksquare) to its left; in the example at right, TV is the active source.

< Source




To change the aspect ratio (size and shape) of the projected image, select Aspect Ratio from the Main Menu and press **ENTER**. Select the appropriate aspect ratio for the type of program material being viewed; refer to Table 4-1.

The currently-selected aspect ratio is indicated by a green square (\blacksquare) to its right; in the example at left, Anamorphic is selected.



The aspect ratio selection persists until you change it. (It is not saved independently for each input.)

✓ Aspect Ratio



Aspect Ratio	Remote Control Key	Description		
Anamorphic	ANA	Active Image Area	Select Anamorphic to view 16:9 DVDs and HDTV programs in their native aspect ratio. 4:3 images are stretched horizontally to fit a 16:9 screen.	
Standard	4X3	4:3 Image on 16:9 Screen (Display)	Standard 4:3 scales the input signal to fit in the center of the 16:9 screen. 4:3 is the aspect ratio used by computer monitors, standard television programming and most VHS video cassettes.	
Letterbox	LET BOX	4:3 Image on 16:9 Display (Letterbox aspect ratio)	In Letterbox mode, the image is stretched vertically; the top and bottom portions are "blanked off." Letterbox is best suited for viewing LaserDisc movies or non-anamorphic DVDs on a 16:9 screen.	
VirtualWide	VWIDE		VirtualWide scales a 4:3 image NON-linearly (more on the sides than in the center) to fit a 16:9 screen.	

Table 4-1. Aspect Ratio Settings

Use the controls in the Picture Adjust menu to calibrate your Crystal Series LCD Display for optimum picture quality.

The Crystal Series LCD Display has been designed to incorporate setup and calibration standards established by the Imaging Science Foundation (ISF). The ISF has developed carefully crafted, industry-recognized standards for optimal video performance and has implemented a training program for technicians and installers to use these standards to obtain optimal picture quality from Runco video display devices. Accordingly, Runco recommends that setup and calibration be performed by an ISF-certified installation technician.

All signal types require separate processing. Therefore, you need to calibrate each input separately.



When you change a picture quality setting, save the change to a preset afterwards. Otherwise, the change will be lost when a different input is selected. (Picture quality settings are saved for each input and **resolution** separately.) For information about saving settings, refer to **Save Settings (not available for RGB input)** on page 33.

Although it may be possible to obtain satisfactory picture quality using the naked eye and regular program material, Runco recommends using the following calibration tools for best results:

- External test pattern source Ovation Multimedia, Digital Video Essentials or AVIA test DVD or equivalent.
- A blue filter (provided with many test DVDs), for color level and tint adjustments.

Connect your test pattern source to the input that you are calibrating and proceed as follows. **Perform the adjustments in the order listed here.**

Brightness: On your external test pattern source, select a PLUGE pattern. (PLUGE is an acronym for "Picture Line-Up Generation Equipment.") Figure 4-2 shows a typical PLUGE pattern.




Figure 4-2. Typical PLUGE Pattern for Adjusting Brightness

Picture Adjust

Picture Adjust	
Brightness	
Contrast	
Color	
Tint	
Sharpness	
Color Temp.	
Backlight	
Save Settings	
Restore Settings	

PLUGE patterns vary but generally consist of some combination of black, white and gray areas against a black background. The example above includes two vertical bars and four shaded boxes.

Select Brightness from the Picture Adjust menu. Using the left- and right-arrow ($\blacktriangleleft \triangleright$) buttons, adjust the brightness so that:

- The darkest black bars disappear into the background.
- The dark gray areas are barely visible.
- The lighter gray areas are clearly visible.
- The white areas are a comfortable level of true white.
- The image contains only black, gray and white (no color).

Contrast: On your external test pattern source, select a stepped, gray-bar pattern like the one shown in Figure 4-3.




Figure 4-3. Typical Gray Bar Pattern for Adjusting Contrast

Select Contrast from the Picture Adjust menu. Using the left- and right-arrow ($\triangleleft \triangleright$) buttons, adjust the contrast to a point just below which the white rectangle starts to increase in size.



Brightness and contrast controls are interactive. A change to one may require a subtle change to the other in order to achieve the optimum setting. **Color Saturation:** On your external test pattern source, select a color bar pattern like the one shown in Figure 4-4.





Figure 4-4. Typical Color Bar Pattern for Adjusting Color Saturation and Tint

Select Color from the Picture Adjust menu. While looking at the color bar pattern through a blue filter, adjust the color saturation level until the outermost (gray and blue) color bars appear to be a single shade of blue:



Tint: Tint or "hue" is essentially the ratio of red to green in the color portion of the image. When tint is decreased, the image appears redder; when it is increased the image appears greener. To set the tint, select Tint from the Picture Adjust menu. While looking at the color bar pattern through a blue filter, adjust the tint level until the cyan and magenta color bars (on either side of the green bar) appear to be a single shade of blue.



Like the brightness and contrast controls, the color and tint controls are interactive. A change to one may require a subtle change to the other in order to achieve the optimum setting. **Sharpness:** "Sharpness" is the amount of high-frequency detail in the image. To adjust sharpness, select Sharpness from the Picture Adjust menu and press **ENTER**. On your external test pattern source, select a pattern like the one shown in Figure 4-5. Adjust as needed, looking for white edges around the transitions from black to gray and different sized lines in the "sweep" patterns at the top and bottom. Lower the sharpness setting to eliminate them.




Figure 4-5. Typical Test Pattern for Adjusting Sharpness

Color Temperature: To adjust the color temperature, select Color Temp. from the Picture Adjust menu and press **ENTER**. (Color temperature defines the "color of gray.") The choices are 5400K, 6500K, 8500K and Custom. The default setting, 6500K, is appropriate for most situations. Higher settings produce a "bluer" picture; lower ones impart a reddish hue to the image.

Backlight: The Backlight control changes the apparent brightness of the displayed image. Its effect is similar to that of a lamp intensity control on a projector.

Save Settings (not available for RGB input): The Crystal Series LCD Display lets you save image quality settings for each input and supported resolution to a preset. You can recall this preset at a later time by simply pressing a button on the remote control or using the Restore Settings menu command (see below).

You should save changes to any of the following settings to a preset; otherwise they will be lost when a new input source or resolution is selected:

- Brightness
- Contrast
- Color saturation
- Tint
- Sharpness
- Gamma
- Color temperature and white balance

Restore Settings (not available for RGB input): To recall a preset, choose Restore Settings from the Picture Adjust menu and select "Custom," "ISF Day" or "ISF Night." Or, use the corresponding buttons on the remote control.

To adjust the Crystal Series LCD Display audio settings, select Audio from the Main Menu and press **ENTER**.

Balance: To adjust the left/right speaker balance, select Balance from the Audio Menu and press **ENTER**. Use the left- and/or right-arrow buttons to make one channel louder than the other.

Equalizer: The Crystal Series LCD Display has a five-band graphic equalizer that you can use to boost or cut certain audio frequencies. To use it, select Equalizer from the Audio menu and press **ENTER**. Select one of four equalizer presets – Standard (flat), Music, Film or Speech – or select Custom to create your own according to taste. The five frequency bands are 100, 300, 1000, 3000 and 10,000 Hertz (Hz).

Surround: The Crystal Series LCD Display has a "surround sound" mode that simulates a multi-channel sound system. To use the surround mode, select Surround from the Audio menu and set it to On.



When Surround is set to On, the graphic equalizer is disabled.

Audio Language: Some digital TV broadcasts provide audio soundtracks in multiple languages. If you are watching such a program, select Audio Language from the Audio menu to choose a soundtrack language: English, Français, Español or Português.

TV Speaker: To disable the internal speakers, select TV Speaker from the Audio menu, set it to Off and press **ENTER**. The effect is similar to using the **MUTE** button, except that the Crystal Series LCD Display "remembers" this setting if you turn off the display, then turn it back on.

< Audio



Channel 🍗

Channel Auto Tuning Add/Erase Favorite Channel To set up the Crystal Series LCD Display channel tuner, select TV as the source. Then, select Channel from the Main Menu and press **ENTER**.

Auto Tuning: To have the Crystal Series LCD Display automatically detect available TV or CATV channels, select Auto Tuning and press **ENTER**.

- Off-Air Channels: If you are using an off-air antenna, select AIR and press ENTER again. The Crystal Series LCD Display searches all channel frequencies and adds a channel to its memory when it detects a signal on that channel frequency. (This may take a few minutes.)
- CATV Channels: If you are using cable, select CABLE and press ENTER. Then, select STD and press ENTER again. The Crystal Series LCD Display searches all channel frequencies and adds a channel to its memory when it detects a signal on that channel frequency. (This may take a few minutes.) If Auto Tuning fails to detect any CATV channels, select HRC or IRC and try again. (STD, HRC and IRC refer to different sets of frequencies used by cable television providers. IRC stands for "Incrementally Related Carrier;" HRC stands for "Harmonically Related Carrier.")

Add/Erase: If Auto Tuning fails to detect a channel, select Add/Erase from the Channel menu, then select Add to add it to the channel list. To erase the currently-selected channel from the available channel list, select Add/Erase from the Channel menu, then select Erase.

Favorite Channel: You can specify up to four channels as "favorite" channels that can be accessed by pressing a single button on the remote, instead of manually entering the channel number. To do this, select Favorite Channel from the Channel menu and press **ENTER**.

Use the up- or down-arrow button to select the memory location in which you want to store the favorite channel. Then, use the left- or right-arrow button to specify the channel number.

To recall a favorite channel, press the corresponding button on the remote control (FC1, FC2, FC3 or FC4).

Timer 🕨

Timer Time On Timer Off Timer Sleep Timer Time Zone To set the Crystal Series LCD Display internal clock or configure the on/off timers, select Timer from the Main Menu and press **ENTER**.

Time: To set the Crystal Series LCD Display internal clock, select Time from the Timer menu and press **ENTER**. Use the up- or down-arrow button to select either the hour of the day or the minute of the hour to set. Then, use the left- or right-arrow buttons to set that component of the time. When finished, press **MENU**.

On Timer: Use the On Timer to turn the Crystal Series LCD Display on at a specific time of day. You can also specify a channel and a volume level.

Off Timer: Use the Off Timer to turn the Crystal Series LCD Display off at a specific time of day.

Sleep Timer: Use the Sleep Timer to turn off the Crystal Series LCD Display after a specified interval.

To set the Sleep Timer:

• Select Sleep Timer from the Timer menu and press **ENTER**. Use the right- or left-arrow button to select 10, 30, 60, 120 or 180 minutes. Then, press **MENU**.

– OR –

• Press the **TIMER OFF** button on the remote control repeatedly to select the desired timer interval.

Time Zone: To set the local (North American) time zone, select Time Zone from the Timer menu and press **ENTER**. Use the up- or down-arrow button to select Eastern, Central, Mountain or Pacific. Press **ENTER** to confirm your selection.

Use the controls in the Setup menu to perform advanced image quality adjustments and access various other Crystal Series LCD Display features.

OSD Language: Select OSD Language from the Setup menu and press **ENTER**. Then, use the up- or down-arrow buttons to select the OSD language (English, French, Spanish, Portuguese or German). Press **ENTER** again to confirm your selection.

PC Mode Adjust: To improve the quality of projected images from a computer or other VESA-compliant, RGB source, select PC Mode Adjust and press **ENTER**.

• Auto Adjust: Auto Adjust automatically adjusts settings to optimize computer images. To execute Auto Adjust on command, select Auto Adjust and press **ENTER**.



Auto Adjust may take some time to complete, depending on the characteristics of the incoming signal.

- H Position: Use the up- or down-arrow buttons (▲, ▼) to highlight H Position. Then, use the right-arrow button (▶) to shift the image to the right; use the left-arrow button (◀) to shift the image to the left.
- V Position: Use the up- or down-arrow buttons (▲, ▼) to highlight V Position. Then, use the right-arrow button (►) to shift the image up; use the left-arrow button (◀) to shift the image down.
- H Size: Use the up- or down-arrow buttons (▲, ▼) to highlight H Size. Then, use the right-arrow button (►) to increase the width; use the left-arrow button (◀) to decrease it.
- **Phase:** Adjust the phase if the image shows shimmer or "horizontal" noise. Pixel phase adjusts the phase of the pixel sampling clock relative to the incoming signal. The effect of this control is similar to that of a tracking control on a VCR.

For best results, use a good test pattern such as a smooth gray consisting of a clear pattern of black and white pixels, or a similar "half on, half off" graphic image. (You may notice that you can stabilize the image at more than one point. Use either setting in this case.)

To restore the factory-default Position, Size and Phase settings, select Factory Preset and press **ENTER**.

< Setup

Setup	
OSD Language	
PC Mode Adjust	
Caption	
Parental Control	
Letterbox Mode	
Input Selection	
Monitor Out	
Overscan	

Caption: Select Caption from the Setup menu to control the display of closed captions when watching programs that contain them.

- **Display:** Select On or Off to control the display of closed captions.
- **Mode:** Select one of four captioning modes: CC1, CC2, CC3 or CC4. CC1 usually contains the native-language captions; if a program is captioned in more than one language, those captions are carried on CC2, CC3 or CC4.

The Crystal Series LCD Display also supports "text mode" captioning; to use this feature, select Text1, Text2, Text3 or Text4. The text modes, instead of displaying a few lines of captions somewhere on the picture, take over all or half of the screen to display scrolling text information. (The text modes are seldom used today, so most of the time there is no information there to see.) The text field is sometimes used for embedding Internet data (called Interactive TV Links, or ITV Links) in the captions.

• **CC On Mute:** To have the Crystal Series LCD Display show captions when the audio output is muted, set this option to Yes.

Parental Control: To block the display of television programs or movies based on their ratings, select Parental Control from the Setup menu and press **ENTER**. Enter the default Personal Identification Number (PIN) – **0000** – and press **ENTER** again.

- **Parental Lock:** This is the "master switch" for the parental controls. Set it to On on Off.
- **TV Rating:** Select TV Rating from the Parental Control menu to block television programs carrying a given rating, to prevent children from watching programs that are deemed inappropriate. These ratings and content labels have been established by the United States Federal Communications Commission (FCC) to help parents and other caregivers determine if a program is suitable for young viewers.

To block programs carrying a given rating, use the up- or down-arrow to select a rating. Then, press the right-arrow button to require the PIN code to be entered to view a program with that rating. A lock icon () appears to indicate that the restriction is active.

Table 4-2 describes the TV ratings and content categories. For more information, visit http://www.fcc.gov/parents/parent_guide.html.

Rating/Category	Description
TV-MA	Mature Audience Only - graphic violence, explicit sexual content and/or offensive language.
TV-14	Parents strongly cautioned - intense violence, sexual situations, coarse language and/or suggestive dialogue.
TV-PG	Parental guidance suggested - violence, sexual situations, coarse language and/or suggestive dialogue.
TV-G	General audience - suitable for children and adults.
TV-Y7	Children 7 and up.
TV-Y	Suitable for all children.
FV	Fantasy violence or cartoon violence.
D	Sexual dialogue.

Table 4-2. FCC Ratings and Content Categories

Table 4-2. FCC Ratings and Content Categories (continued)

Rating/Category	Description	
L	Offensive language	
S	Sexual content	
V	Violence	

• **Movie Rating:** Select Movie Rating from the Parental Control menu to block movies carrying a given rating, to prevent children from watching movies that are deemed inappropriate. These ratings have been established by the Motion Picture Association of America (MPAA) to help parents and other caregivers determine if a movie is suitable for young viewers.

To block movies carrying a given rating, press the right-arrow button to require the PIN code to be entered to view a movie with that rating. A lock icon () appears to indicate that the restriction is active.

For more information on movie ratings, please visit http://www.mpaa.org/movieratings/.

- **Unrated:** To allow or block access to unrated content, select Unrated from the Parental Control menu and select Allow or Block. Press **ENTER** to confirm your choice.
- **Change PIN:** The default PIN for accessing the parental controls or bypassing content restrictions is **0000**. Runco recommends changing this to something less obvious.

Letterbox Mode: Select Letterbox Mode from the Setup menu to change the appearance of movies in Letterbox format.

When you select Standard, the original Letterbox format of the source is maintained. Black bars appear above and below the active image area.

When you select Cinema Fill, a 2.35 image is stretched vertically in both directions to fill a 16:9 display.

Input Selection: Input 1 and Input 2 have both S-Video and composite video connectors. Input 3 has both component and composite video connectors.

To specify which connection type you are using – or to switch from one to the other if equipment is connected to both – select Input Selection from the Setup menu and press **ENTER**.

Monitor Out: If you have equipment connected to the MONITOR OUT, select Monitor Out from the Setup menu to route either the main or PIP audio/video signals to that output.

Overscan (not available for RGB input): Overscan pushes the outside edge of the active picture area of the video signal out beyond the edge of the display area.

Some television programs are produced based on the assumption that older television sets may not display the outer edges of the broadcast picture area. Overscan effectively trims away these inactive, outer edges and enlarges the remaining portion of the image to fill the display area.

Use the on-screen slidebars to set the desired amount of horizontal and vertical overscan, as well as horizontal and vertical image shift.

These settings only affect 480i source material. For HDTV, DVDs and other video sources, Overscan is generally not necessary or desirable.

ISF Calibration >

ISF Calibration

Picture Adjust
White Balance
Blue Enable
DNR
Gamma
Baud Rate
Command Ack

Command Ack

Factory Reset

Splash Duration

Use the ISF Calibration menu to perform advanced picture quality adjustments. **This menu should be used by ISF-certified technicians only.**



You must enter a passcode to access the ISF Calibration menu.

Picture Adjust: The controls in this menu are identical to those in the main Picture Adjust menu, but are accessible only by entering the ISF Calibration menu passcode. This makes it possible to restore the picture quality settings to what they were when the Crystal Series LCD Display was installed, simply by recalling the "ISF Night" or "ISF Day" preset.

- Brightness: Refer to Brightness on page 29.
- Contrast: Refer to Contrast on page 30.
- Color: Refer to Color Saturation on page 31.
- Tint: Refer to *Tint* on page 31.
- Sharpness: Refer to Sharpness on page 32.
- Color Temp.: Refer to Color Temperature on page 32.
- Backlight: Refer to Backlight on page 32.
- Save Settings: For each input and supported resolution, the Crystal Series LCD Display lets you save image quality settings as presets that you can recall at a later time. You can create up to three presets designated "Custom," "ISF Day" and "ISF Night" per input and resolution.

You should save changes to any of the following settings to a preset; otherwise they will be lost when a new input source or resolution is selected:

- Brightness
- Contrast
- Color saturation
- Tint
- Sharpness
- Gamma
- Color temperature and white balance

To save image settings to a preset, select Save Settings from the ISF Calibration menu and select "Custom," "ISF Day" or "ISF Night."

White Balance: To remove any trace of color from the white areas of the projected image, choose White Balance from the Picture Adjust menu and press **ENTER**.

- **Gain:** Use the Gain controls to correct color imbalances in the bright areas of the image. A good way to do this is to use a test pattern consisting mostly of solid white areas, such as an 80 IRE "window" pattern. If the white areas contain traces of red, green or blue, decrease the Gain for that color.
- **Offset:** Use the Offset controls in the White Balance sub-menu to correct color imbalances in the dark areas of the image. A good way to do this is to use a test pattern consisting mostly of dark gray areas, such as a 30 IRE "window" pattern. If the gray areas contain traces of red, green or blue, decrease the Offset for that color.



Any white balance adjustments you make here are automatically stored as a "Custom" color temperature.

Blue Enable: Blue Enable removes all red and green color information from the image, simulating a blue filter. You can use it instead of a blue filter when performing color and tint adjustments.

DNR: To apply Digital Noise Reduction (DNR) to the input signal, select DNR from the ISF Calibration menu. Noise reduction is useful for clearing up noisy RGB images such as those from a PC. Adjust as desired using the left- or right-arrow buttons, keeping in mind that reducing noise (which reduces high frequencies) may also "soften" the image.


Gamma: The Gamma control determines how gray shades are displayed between minimum input (black) and maximum input (white) for all signals. A good gamma setting helps to optimize blacks and whites while ensuring smooth transitions for the "in-between" values utilized in other grays.

Unlike brightness and contrast controls, Gamma allows you to lighten or darken the overall tone of your images without changing the extremes. All images will be more vibrant while still showing good detail in dark areas.

The default Gamma setting of 2.4 is appropriate for most typical home theater environments.

Baud Rate: Select Baud Rate from the ISF Calibration menu to set the data transfer rate of the Crystal Series LCD Display's RS-232 SERVICE port. (This setting must match the data rate of the device connected to the RS-232 input.)

Command Ack: The Command Ack setting enables or disables the echo of serial commands at the source. When set to on, commands sent from the serial controller (PC or control/automation system) are logged and/or displayed on-screen. If this is not desired, set Command Ack to Off.



Factory Reset: To reset all Crystal Series LCD Display settings to their factory defaults, select Factory Reset from the ISF Calibration menu and press **ENTER**. *This command is not undoable. Use it with caution!*

Splash Duration: Use Splash Duration to control how long the Crystal Series LCD Display splash screen remains on-screen after power-up; see Figure 4-6. To prevent this screen from appearing, set the Splash Duration to 0.



Figure 4-6. Crystal Series LCD Display Splash Screen



Runco CR-26HD/CR-32HDi Owner's Operating Manual


The PIP window appears inside the main image

window.

To use PIP, press the **PIP** $((\square))$ button.

Press **PIP** again to switch to side-by-side PIP mode.

Press **PIP** again to turn PIP off.



SIZE


ASPECT

POSITION

PIP

•





Press the **TV/AV** button (()) to select a PIP signal source. For each source, Table 4-3 shows which of the other sources are available as a PIP source.

in	PIP	тv	INPUT1	INPUT2		INPUT3	PC	
Main	FIF	IV	INFOIT	INFUIZ	VIDEO	COMPONENT	RGB	DVI
	TV	Х	Х	Х	Х	Х	Х	Х
	INPUT1	Х	Х	Х	Х	0	0	0
	INPUT2	Х	Х	Х	Х	0	0	0
Γ3	VIDEO	Х	Х	Х	Х	Х	0	0
INPUT3	COMPO- NENT	Х	0	0	Х	Х	Х	0
РС	RGB	Х	0	0	0	Х	Х	0
ā	DVI	Х	0	0	0	0	0	Х

Table 4-3. Available Main and PIP Source Combinations


Notes:


1. "O" means that that source is available as a PIP source when that input is selected; "X" means that it is not.

2. The Crystal Series LCD Display cannot display the same source in both the main and PIP windows, nor can it display RGB and component video simultaneously.


Changing the PIP > Position

To change the PIP window position, press the **POSITION** (()) button on the remote control repeatedly until the window is in the desired position.






To change the PIP window size, press the **SIZE** (()) button on the remote control repeatedly to achieve the desired window size.



Changing the PIP Size



To change the aspect ratio of the PIP window from 4:3 to 16:9 or vice versa, press the **ASPECT** (()) button on the remote control.

Refer to Table 4-1 for more information about aspect ratios.

To recall settings for the PIP input from either the "ISF Night" or "ISF Day" memory preset, press the **P.MODE** $((\neg \Box \land))$ button on the remote control.


Choose ISF Day when there is a lot of ambient light. Select ISF Night when there is low ambient light or at night.


To customize the ISF memory presets, refer to *ISF Calibration* on page 38.



- Changing the PIP Aspect Ratio
- SPECT SIZE POSITION PIP
- Changing the PIP Image Mode

- Swapping the Main and > 7 PIP Images b
- To swap the main and PIP images, press the **SWAP** button on the remote control.





- Swapping the Main and PIP Audio Programs
- To swap the main and PIP audio programs, press the **S.SWAP** button on the remote control.

ASPECT	SIZE	POSITION	PIP
P.MODE	S.SWAP	SWAP	TV/AV
	\bigcirc		\bullet

The Crystal Series LCD Display supports Multichannel Television Sound (MTS), the broadcast audio standard that allows transmission of both stereo and Secondary Audio Program (SAP) content.

4.6 Stereo Sound/SAP

The SAP is usually a foreign-language translation. However, it can also be used for other purposes such as Described Video Services (DVS), which provide descriptive narration of key visual elements in programs for the benefit of the visually impaired.

You can select sound options (Mono, Stereo, SAP or Mono+SAP) depending on the broadcast signal by pressing the **MTS/SAP** button on the remote control.

- Choose Stereo for channels that are broadcasting in stereo.
- Choose Mono for channels that are broadcasting in mono, or if you are having difficulty receiving a stereo signal.
- Choose SAP to listen to the Secondary Audio Program.
- Choose **Mono+SAP** to listen to both the primary and secondary audio programs (for example, when a program has a DVS audio track).

Table 4-4 summarizes the audio broadcast modes supported by the Crystal Series LCD Display.

Table 4-4. Compatibility with Stereo and SAP Audio Broadcasts

Broadcast Mode	Receive Mode					
Broaucast Mode	Mono	Stereo	SAP	Mono+SAP		
Mono	Mono	Mono	Mono	Mono		
Stereo	Mono	Stereo	Mono	Stereo		
Mono+SAP	Mono	Mono	SAP	Mono+SAP		
Stereo+SAP	Mono	Stereo	SAP	Mono+SAP		



S.MOD

MTS/SAP

FC3

FC2

MUTE

FC4

Notes:

5. Maintenance and Troubleshooting

Table 5-1 provides some general guidelines for troubleshooting problems you may encounter with the Crystal Series LCD Display. If you encounter an issue not described here, please contact your Runco dealer or Runco Technical Support.

5.1 Troubleshooting Tips

Table 5-1. Troubleshooting Chart

Symptom	Possible Cause(s)	Solution
The display does not turn on after initial installation.	 The Crystal Series LCD Display is not plugged in or the AC outlet is not active. The remote control batteries have run out. 	 Ensure that the Crystal Series LCD Display is plugged in and that the AC outlet is active. Replace the batteries.
The display is on, but there is no picture or sound.	 Incorrect source selection. Source component is not turned on. Source component is connected incorrectly or not at all. 	 Select the correct source. Turn on the source component. Check video and/or audio connections to source component.
Picture is okay, but there is no sound.	Audio output is muted.Volume setting is too low.	Press the MUTE button on the remote control.Turn up the volume.
Image is too bright and/or lacks definition in the bright areas of the image.	Contrast is set too high.	Lower the contrast setting.
Image appears "washed out" and/or dark areas appear too bright.	Brightness is set too high.	Lower the brightness setting.
Black or white dots appear on all channels or a specific channel.	 Antenna or cable TV source is connected incorrectly or not at all. 	• Check the antenna or cable TV connection.
	 Broadcast signal is weak. 	 If using an off-air antenna, adjust its position or location.
Colors in the image are swapped; for example, reds appear blue or vice versa.	The Red/Pr, Green/Y or Blue/Pb outputs from the source are connected to the wrong inputs on the Crystal Series LCD Display.	• Ensure that the source outputs are connected to the correct Crystal Series LCD Display input.

Symptom	Possible Cause(s)	Solution
RGB images appear "noisy."	 Clock and Phase settings need adjustment. 	 Manually adjust Clock and Phase settings, or perform an Auto-Adjust (refer to <i>PC</i> <i>Mode Adjust</i> on page 35).
"Out of range" appears on-screen.	• The resolution and frequency of the video card in the computer are not compatible with the Crystal Series LCD Display.	 Select a compatible resolution and vertical frequency (refer to <i>Computer/Video Signal</i> <i>Compatibility</i> on page 56).
The image is too large or too small.	 Image size needs adjusting. 	 Adjust the image size (refer to <i>PC Mode Adjust</i> on page 35).
Poor broadcast sound quality.	• The sound quality of a stereo broadcast may be unstable in an area with a weak signal.	• Use the MTS/SAP button on the remote control to select mono.

6. Serial Communications

To interface the Crystal Series LCD Display with a home theater automation/control system or a PC running terminal emulation software, connect it to your control system or PC as shown in Figure 3-8.

Configure the RS-232 controller or PC serial port as follows: no parity, 8 data bits, 1 stop bit and no flow control. Set the baud rate to match that of the Crystal Series LCD Display RS-232 port; the default baud rate is 115200.

Table 6-1 lists the RS-232 command set. All commands are in ASCII format. A carriage return is not required after a command.

When you send a valid command, the Crystal Series LCD Display executes it and acknowledges it with a right-bracket character (]) followed by the four-digit numeric code you sent; for example,] 0002. When you send an invalid command, the Crystal Series LCD Display ignores it and returns -N/A instead of the four-digit code.

6.1 RS-232 Connection and Port Configuration

6.2 Serial Command Syntax

Table 6-1. Serial Commands

Command			Description		
[S3A	0###	Set audio volume to ### (=000-100)		
Exampl	e: [S34	40075 s€	ts volume to 75		
[+3A		Audio volume up		
[-3A		Audio volume down		
[S4A	000#	Main input selection 0=TV 1=Input1 2=Input2 3=Input3 5=DVI 6=RGB		
Exampl	Example: [S4A0006 selects RGB				
[S4E	000#	Aspect ratio selection 0=Standard (4x3) 1=VirtualWide 2=Letterbox 3=Anamorphic		
Example: [S4E0002 selects Letterbox					
[S4F	0101	Select Composite Video for Input1		
		0102	Select S-Video for Input1		
		0201	Select Composite Video for Input2		
		0202	Select S-Video for Input2		

Command			Description
		0301	Select Composite Video for Input3
		0303	Select Component Video for Input3
Examp	ole: [S4]	F0101 se	elects Composite video for Input1
]	S4G	000#	PIP Input selection 0=TV 1=Input1 2=Input2 3=Input3 5=DVI 6=RGB
Examp	ole: [S40	30003 se	elects Input3
[SAB	000#	Power on/off control 0=standby, 1=on
Examp	ole: [SAI	30001 tu	rns unit on
[SBA	000#	Picture mode selection 0=Custom 1=ISF Night 2=ISF Day
Examp	ole: [SBI	A0001 se	elects ISF Night
[SCA	000#	Caption on/off 0=off 1=on
Examp	ole: [SCI	40000 tu	rns caption off
[+CB		TV channel up
[-CB		TV channel down
]	SCC	000#	Favorite channel selection 1=FC1 2=FC2 3=FC3 4=FC4
Examp	ole: [SCO	20002 se	elects favorite channel 2
[SDA	000#	Set PIP mode 0=OFF 1=PIP 2=PBP
Examp	ole: [SDI	A0002 se	elects PBP
[SDB	000#	Set PIP size 0=small 1=medium 2=large
Examp	ole: [SDI	30001 se	elects medium PIP size

Table 6-1. Serial Commands (continued)

Table 6-1. Serial Commands (continued)

The following serial commands are meant to emulate buttons on the remote control. Each button has its own serial command, so effectively it is as if you were using the IR remote only you'll be doing so via serial commands. These commands provide active OSD responses just like the IR remote.						
return is right-bra	necessa acket (]) ⁻	ry. The re followed k	th [key followed by the four-digit number of the button. No carriage sponse you receive from the unit if the command is valid will be a by the four-digit numeric code you sent. (For example, the 'ON' com- response will be] 0015). All commands are in ASCII.			
[key	0002	OFF			
		0015	ON			
[key	0004	Number 1			
		0005	Number 2			
		0006	Number 3			
		0008	Number 4			
		0009	Number 5			
		0010	Number 6			
		0012	Number 7			
		0013	Number 8			
		0014	Number 9			
		0017	Number 0			
		0035	Number 100			
		0023	Number "–"			
[key	0001	TIMER OFF			
[key	0105	INPUT1			
		0027	INPUT2			
		0028	INPUT3			
		0102	DVI			
		0101	RGB HD			
		0019	TV			
[key	0003	CUSTOM			
		0062	ISF NIGHT			
		0031	ISF DAY			
[key	0040	ANAMORPHIC			

	Commar	d	Description
		0043	4X3
		0039	LETTERBOX
		0126	VIRTUALWIDE
[key	0007	Right-Arrow key
		0016	Down-Arrow key
		0018	Up-Arrow key
		0011	Left-Arrow key
		0046	ENTER
[key	0026	MENU
[key	0100	EXIT
[key	0063	PIP ASPECT RATIO
		0047	PIP SIZE
		0034	PIP POSITION
		0032	PIP
		0037	P.MODE
		0052	S.SWAP
		0033	SWAP
		0036	TV/AV
[key	0053	S.MODE
		0054	SURROUND
		0024	MTS/SAP
		0091	MUTE
[key	0057	FAVORITE CHANNEL 1
		0045	FAVORITE CHANNEL 2
		0044	FAVORITE CHANNEL 3
		0055	FAVORITE CHANNEL 4

Table 6-1. Serial Commands (continued)

7. Specifications

Table 7-1 lists the Crystal Series LCD Display specifications.

Table 7-1. Crystal Series LCD Display Specifications

Native Resolution:	1366 x 768 WXGA
Screen Size:	CR-26HD = 26 in. (diagonal) CR-32HDi = 32 in. (diagonal)
Screen Aspect Ratio:	16:9
Available Aspect Ratios:	4:3, Letterbox, 16:9 Anamorphic, VirtualWide™
DTV Compatibility:	480i/p, 576i/p, 720p, 1080i
ISF Settings:	Yes
Contrast Ratio:	1000:1
Data/Graphics Compatibility:	Up to 1024 x 768
Imagix Processing:	3:2 pull down
Inputs:	Multiple input combinations with up to (3) Composite, (2) S-Video, (1) Component, (1) DVI w/HDCP, (1) RGB (15-pin D-sub), (1) RS-232, (4) Audio (stereo RCA pairs), (1) RF Antenna
Outputs:	(1) Composite, (2) Audio (stereo RCA pair, 3.5-mm stereo mini jack for headphones)
Audio System:	10W RMS x 2, L/R two-way Integrated Speaker System
Tuner:	NTSC/ATSC Stereo (PAL as monitor only), HDTV Ready, PIP/PBP, Parental Control (V-Chip), Closed Caption
Discrete IR Control:	Source, power and aspect ratios
Power Requirements:	100 to 240 VAC, 50/60Hz
Power Consumption:	CR-26HD = 130W CR-32HDi = 180W
Operating Environment:	40°F to 95°F (5°C to 35°C); 20% to 80% humidity (non-condensing)
Dimensions:	CR-26HD = see Figure 7-1 CR-32HDi = see Figure 7-2
Weight:	CR-26HD = 26.46 lbs. (12 kg) CR-32HDi = 50.71 lbs. (23 kg)
Regulatory Approvals:	Complies with FCC, UL
Limited Warranty:	One (1) year parts and labor from the date of delivery to the end user.

Specifications are subject to change without notice.

7.1 Crystal Series LCD Display Specifications

7.2 Crystal Series LCD Display Dimensions

Figure 7-1 and Figure 7-2 show the Crystal Series LCD Display dimensions.




Figure 7-1. CR-26HD Dimensions




Figure 7-2. CR-32HDi Dimensions

7.3 Computer/Video Signal Compatibility


The Crystal Series LCD Display can display video signals from a variety of computer sources via its RGB and DVI inputs.

Table 7-2 lists the signal types that are compatible with the Crystal Series LCD Display, and indicates which of those are VESA standards.

Vertical Horizontal Signal Type Mode Frequency (Hz) Frequency (kHz) 720x240 15.75 SD 60i 59.94 SD 720x480 60p 59.94 31.50 HD 1280x720 60.00 44.90 60p HD 1920x1080 60i 60.00 33.70 VESA 720x400 85 85.00 37.90 VESA 720x350 85 85.00 37.90 IBM 720x400 70 70.10 31.50 IBM 720x350 70 70.10 31.50 VESA 720x480 59.94 31.50 60 MAC 720x480 67 66.70 35.00 VESA 720x480 72 72.80 37.80 VESA 720x480 75 75.00 37.50 VESA 720x480 85 85.00 43.60 VESA 800x600 56 56.25 35.20 VESA 800x600 60 60.30 37.90 VESA 800x600 72 72.20 48.70 46.90 VESA 800x600 75 75.00 VESA 800x600 85 85.10 53.70 75 49.70 MAC 832x624 74.50 VESA 48.40 1024x768 60 60.00 60.00 48.70 MAC 1024x768 60 VESA 1024x768 70 70.10 56.50 IBM 1024x768 72 72.10 57.50 VESA 1024x768 75 75.00 60.00 MAC 1024x768 75 75.00 60.00 VESA 1024x768 85 85.00 68.70

Table 7-2. Computer/Video Signal Compatibility Chart

Note: The Crystal Series LCD Display may not be able to display images from notebook computers in simultaneous (CRT/LCD) mode. Should this occur, switch the notebook computer to "CRT only" mode. If you are unsure how to do this, refer to your notebook computer's user manual.



Runco International • 2900 Faber Street • Union City, CA 94587 • Ph (510) 324-7777 / (800) 23RUNCO / Fax (510) 324-9300