

# 3-Button Garage Door Remote Control


Model MK-318-1  
Model MK-318-2  
Model MK-318

## 1. INTRODUCTION

Thank you for your purchase of Skylink® Remote, Model MK-318-1/MK-318-2/MK-318.

The following items are included in this package:

- One of MK-318 series Remotes
- Lithium Battery CR-2032 (Installed)
- User's Instructions



There are one or two or three buttons on transmitter, each button can be programmed to control Skylink garage door receiver Smart Button™ GB-318 or Skylink garage door opener directly.

Follow one or more instructions below in Section 2 to program transmitter MK-318 to the receiver or receivers you want to control.


## 2a. PROGRAM TRANSMITTER TO RECEIVER GB-318

You need to do the programming in order to add the transmitter - remote control to a receiver.

Refer to the receiver Smart Button™ GB-318 user's instruction to set up the unit. Smart Button™ GB-318 can learn up to 10 remote controls.

To program the transmitter to the receiver, follow the instructions below:

1. Press the learn button on the side of the Smart Button™ GB-318.
2. Once the learn button is pressed, the LED will flash quickly. Release the learn button.
3. Within 30 seconds, press any one of the 3 buttons on the transmitter that you want to program to the receiver.
4. Once the remote control is programmed, the LED will flash slowly, in the same way as it flashes in standby mode.
5. You may now operate the garage door opener with this new remote control.
6. To program this transmitter to control another receiver, repeat process (1) to (4) to program another button on the remote control.




## 2b. PROGRAM A TRANSMITTER TO THE SKYLINK® GARAGE DOOR OPENER - EQ SERIES

You need to do the programming in order to add the transmitter to a Skylink® Garage Door Opener.

Skylink® Garage Door Opener can learn up to 16 remote controls.

To program the transmitter to the Garage Door Receiver, follow the instructions below:

1. Press the LEARN/SET button once on the garage door opener.
2. Once the LEARN/SET button is pressed, the LEARN LED will flash. You may release the LEARN/SET button.
3. Within 30 seconds, press any one of the 3 buttons on the transmitter that you want to program to the receiver.
4. Once the transmitter is programmed, the LEARN LED will turn off.
5. You may now operate the garage door opener with this new transmitter.
6. To program a transmitter to control another garage door opener, repeat process (1) to (4) to program another button on the transmitter.



## 2c. PROGRAM A TRANSMITTER TO THE SKYLINK® GARAGE DOOR OPENER - IQ SERIES

To program the transmitter to the Skylink® IQ series Garage Door Opener, please follow the user's instruction from the Garage Door Opener.

## 3. TROUBLE SHOOTING

*Q: What can I do if the door opener does not react after I press the button on the transmitter ?*

- A: - Ensure when the button on the transmitter is pressed, the red light on the transmitter comes on. Otherwise, check if the battery is inserted properly.
- Make sure the correct button on the transmitter is pressed.
  - Ensure the wires that were previously connected to the wall mounted door control are not loose.
  - Ensure the transmitter has been programmed to the receiver. Refer to section 2 for how to program a transmitter to the receiver.

## 4. BATTERY

3 Volt lithium battery (CR 2032) (included).

It is time to change the battery when the red LED on the transmitter does not turn on when either button is pressed.

## 5. FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

### WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## 6. WARRANTY

If, within one year from date of purchase, this product should become defective (except battery), due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase and a Return Authorization are required.

## 7. CUSTOMER SERVICE

If you would like to

- find out the up-to-date specifications
- know more about features and applications
- download documents, i.e. user's instructions
- order Skylink products

or if you have difficulty getting products to work, please:

1. visit our FAQ section at [www.skylinkhome.com](http://www.skylinkhome.com), or
  2. email us at [support@skylinkhome.com](mailto:support@skylinkhome.com), or
  3. call our toll free at 1-800-304-1187 from Monday to Friday, 9 am to 5 pm EST.
- Fax (800) 286-1320

## CUSTOMER SERVICE

17 Sheard Avenue, Brampton, Ontario, Canada L6Y 1J3  
Email: [support@skylinkhome.com](mailto:support@skylinkhome.com)  
<http://www.skylinkhome.com>  
P/N: 101Z993-001  
Patent Pending  
©2010 SKYLINK GROUP