

VXI LIMITED WARRANTY

1. VXI warrants that your CP100 headset will be free from defects in material and workmanship for two years from the date of purchase. If, during the first two years from the date of purchase, your CP100 headset fails to work due to a defect in material or workmanship, VXI will repair or replace the product, at its election, free of charge. Without proof of purchase, the warranty period begins on the date of manufacture.
2. The foregoing limited warranty does not cover equipment failure attributable to accident, improper operation, misuse, abuse, or any cause other than defects in the materials or workmanship of VXI's products.
3. VXI's obligations under this warranty are limited to repair or replacement (at our option) of any defective part returned to VXI, freight prepaid. Returned products require a Return Authorization that may be obtained by calling customer service at 1-800-742-8588.
4. THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not permit the exclusion of implied warranties and the foregoing exclusions may not apply to you.
5. In no event shall VXI be responsible for any other damages whatsoever, including direct, indirect, special, incidental, consequential, or other damages for breach of this or any other warranty, express or implied.
6. Products returned to VXI for in-warranty, freight prepaid and with proper Return Authorization, will be return shipped to the customer at VXI's expense.

For customer service, please call:


VXI Corporation

1-800-742-8588 or 603-742-2888

Technical support is available on our web site at: www.vxiparrott.com

vxiparrott CP100 HEADSET

For cordless or mobile phones



VXI CORPORATION


One Front Street, Rollinsford, NH 03869

603-742-2888 Toll free 1-800-742-8588

email: info@vxiparrott.com website: www.vxiparrott.com

COMPONENTS

1. Adjustable headband
2. T-Bar
3. Receiver / ear cushion
4. Flexible microphone boom
5. Noise canceling microphone
6. 2.5mm connector
7. Express Disconnect™
8. Microphone boom swivels for left or right side wear




OPERATION

1. CONNECT HEADSET TO YOUR CORDLESS OR MOBILE PHONE


For cordless or mobile phones with a compatible 2.5mm jack, insert the 2.5mm plug directly into the headset jack on the phone.

For mobile phones requiring an adapter, insert the 2.5mm plug into the headset jack on the adapter.




2. CHOOSE A SIDE FOR THE MICROPHONE

Determine which side of your head you would prefer to locate the microphone. Swivel the microphone boom as shown.



3. MICROPHONE ADJUSTMENT

Position the microphone so it is located one finger-width from the corner of your mouth just below your bottom lip. The microphone has the word TALK or a painted dot printed on it (under the cushion). Be sure that this mark is facing your mouth.



4. USING THE EXPRESS DISCONNECT



To quickly disconnect the headset from the lower cord, simply grasp both sides of the Express Disconnect (avoid pulling on the cord) and pull them apart.

To reconnect the headset to the lower cord again, take note of the markings on either side of the connectors. Match up the markings and push the two sides of the connector firmly together again.

For customer assistance, please call VXI at 1-800-742-8588 or visit our website at www.vxiparrott.com.