

Avaya one-X[™] Deskphone Value Edition 1603/1603SW IP Telephone User Guide

16-601444 Issue 1 July 2007

Contents

Notices	. 3
Introduction to the 1603 IP Telephone Overview	5
About LEDs About Icons About Paper Labels	7
About logging in to your telephone Logging in to your telephone Logging out of your telephone	8
Making a Call	. 8
Redialing a number	. 8
Answering a Call	. 8
Muting a Call	
Putting a Call on Hold	. 9
Transferring a Call	. 9
About Conference Calls Making a conference call Adding a person on hold to a conference call Putting a conference call on hold	9 9
Dropping the last person added to a conference call	10
Getting Your Messages	
About Bridged Appearances and Shared Lines	10 11
About Advanced Telephone Features	11
About the Avaya Menu Adjusting the brightness or contrast of the display Changing the ring pattern Turning button click sounds on and off Turning error tones on or off Turning visual alerting on or off Setting Automatic Gain Control Changing the language Viewing Network Information	 11 12 12 12 12 12 13
Index	15

Notices

© Avaya Inc.

All Rights Reserved.

Notice

While reasonable efforts were made to ensure that the information in this document was complete and accurate at the time of printing, Avaya Inc. can assume no liability for any errors. Changes and corrections to the information in this document may be incorporated in future releases.

Note:

Using a cell, mobile, or GSM phone, or a two-way radio in close proximity to an Avaya IP Phone might cause interference.

For full legal page information, please see the complete document, Avaya Legal Page for Hardware Documentation, Document number 03-600759.

To locate this document on our website, simply go to http://www.avaya.com/support and search for the document number in the search box.

Documentation disclaimer

Avaya Inc. is not responsible for any modifications, additions, or deletions to the original published version of this documentation unless such modifications, additions, or deletions were performed by Avaya. Customer and/or End User agree to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands, and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation to the extent made by the Customer or End User.

Link disclaimer

Avaya Inc. is not responsible for the contents or reliability of any linked Web sites referenced elsewhere within this documentation, and Avaya does not necessarily endorse the products, services, or information described or offered within them. We cannot guarantee that these links will work all of the time and we have no control over the availability of the linked pages.

Warranty

Avaya Inc. provides a limited warranty on this product. Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this product, while under warranty, is available through the following Web site:

http://www.avaya.com/support

Copyright

Except where expressly stated otherwise, the Product is protected by copyright and other laws respecting proprietary rights. Unauthorized reproduction, transfer, and or use can be a criminal, as well as a civil, offense under the applicable law.

Avaya support

Avaya Inc. provides a telephone number for you to use to report problems or to ask questions about your product. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site:

http://www.avaya.com/support

Introduction to the 1603 IP Telephone

The 1603 IP telephone is a multiline IP telephone for use with an Avaya call processing system. The 1603 IP telephone puts convenient features and capabilities at your fingertips, including a Conference, Transfer, Hold, and Redial button and a menu of options and settings to customize your phone.

Not all features described in this user guide may be available on your telephone. If you find that a feature is not available, contact your system administrator.

Overview



Name	Description
Message Waiting Indicator	An illuminated red light in the upper-right corner of your phone indicates you have voicemail messages waiting. If Visual Alerting is enabled, this light flashes when you receive an incoming call.
Phone Display	There are two lines in the phone display. The phone display presents calling or called party identification, user options, and other information relevant to using the phone.
Avaya Menu	Press the A button to access the Avaya menu. Press the A button twice to exit the Avaya menu. The Avaya menu provides options that allow you to customize phone settings, select the display language, view network information, and log out.
Redial	Press Redial to dial the last number you dialed.
Hold	Press Hold to put the active call on hold.
Conference	Press Conference to add another party to an existing call.
Transfer	Press Transfer to transfer a call to another number.
Drop	Press Drop to drop the active call. While on a conference call, press Drop to drop the last person added to the conference call.
Volume	Press + or - on the volume button while active on the handset or speaker to adjust the volume. To adjust the volume of the ringer, press + or - on the volume button while the handset and speaker are inactive.
Mute	Press Mute to mute a call in progress. To take a call off mute, press Mute again.
Speaker	Press Speaker to use the speakerphone. To take a call off speakerphone, lift the handset.
Feature Buttons and Call/Line Appearance Buttons	There are 3 buttons that can be programmed by the system administrator as either call/line appearance buttons or feature buttons. Press a call/line appearance button to make or answer a call or resume a call on hold. Press a labeled feature button to enable or disable that feature. Typically two buttons are administered as call/ line appearance buttons and one button is administered as a feature button. The feature button provides access to an Avaya call management system feature that has been administered for your extension. The green LED next to the feature button indicates if the feature is currently on or off. If the light is on, the feature is on. For more information about Avaya call management system features, see About Advanced Telephone Features.

1603 IP Telephone Button/Feature Descriptions

About LEDs

Each call/line appearance button and feature button has two LEDs, one green and one red, to indicate the status of the call/line appearance or feature. The status is identified by whether the LED is turned on, off, or blinking as described in the following tables.

Table	1. Call/Line	Appearance	Button LEDs
-------	--------------	------------	--------------------

LED	Description
Steady green	Call/line appearance is active.
Slow blinking green	Call/line appearance is ringing.

LED	Description
Fast blinking green	Call/line appearance is on hold.
Steady red	Call/line appearance is in use by you.
Off	Call/line appearance is available.

Table 2. Feature Button LEDs

LED	Description
Steady green	Feature is active.
Blinking green	Feature is pending (request is being processed and not immediately available).
Off	Feature is not active.

About Icons

Icons are provided in the phone display to indicate the state of a call and navigation choices. The icons that appear in the phone display are described in the following table.

Table	3.	Icons	in	the	Telep	hone	Display
-------	----	-------	----	-----	-------	------	---------

lcon	Description
C	Call is active.
J	Call is on hold.
J	Call is on soft hold (when using Conference or Transfer feature).
	Incoming call is ringing.
0	Conference is active.
C	Conference is on hold.
•	Scroll left for other options.
	Scroll right for other options.
\$	Scroll up or down for other options.

About Paper Labels

Next to each call/line appearance button and feature button is a paper label. The label identifies the call/line appearance number or the feature that has been programmed on the button by your system administrator. You can remove the labels if you want to change a label or write on a blank one. Printed labels are also available for your telephone. See your system administrator for more information.

About logging in to your telephone

Logging in and out maintains your personal options if you share a telephone with other users or if you want to use the same extension from another phone. Logging out also prevents unauthorized use of your telephone during an absence.

Logging in to your telephone

Log in from the initial screen that prompts you for your extension.

- 1. Enter your extension.
- 2. Press **#** to select **OK**.
- 3. Enter your password.
- 4. Press # to select OK.

Logging out of your telephone

- 1. Press the **A** button.
- 2. Press **#** to scroll to Log Out.

Note:

Log Out is not available if you are on a call.

- 3. Press * to select Log Out.
- 4. Press * again to confirm.

Making a Call

If you are not on a call, simply dial the number you want to call.

- 1. Lift the handset, press Speaker, or select an available line.
- 2. Dial the number you want to call.

Redialing a number

Press Redial to call the last number dialed.

Answering a Call

When you receive an incoming call, the incoming call is usually selected automatically. However, if you are already on a call or if you receive more than one incoming call at a time, you may need to select the call you want to answer manually.

Answer an incoming call in the following ways:

- If you are not on another call, lift the handset, or press the call/line appearance button whose green LED flashes for the incoming call, or press Speaker to answer using the speakerphone.
- If you are on another call, press the call/line appearance button whose green LED flashes for the incoming call.
 - Note:

If the Auto Hold (Communication Manager) feature is enabled by your system administrator, you can answer another call without first putting an active call on hold. If Auto Hold is not enabled, you must put your active call on hold before answering the incoming call; otherwise, you will drop the active call when you answer the other one.

Muting a Call

If a call is on mute and you switch between the handset, headset, or speakerphone, the mute will be turned off. When the Mute button light is on, the call is muted.

- 1. Press the **Mute** button during a call so that the other person cannot hear you.
- 2. Press the Mute button again to unmute the call.

Putting a Call on Hold

1. Press **Hold** to put your active call on hold.

Note:

The blinking green LED next to the call/line appearance button indicates the call is on hold.

- 2. To resume the call, do one of the following:
 - If there is more than one call on hold, press the call/line appearance button to resume the call.
 - If there is only one call on hold, press the **Hold** button or the call/line appearance button to retrieve the call.

Transferring a Call

- 1. If the call you want to transfer is not your active call, press the call/line appearance button for the call you want to transfer.
- 2. Press Transfer.
- 3. Dial the telephone number.
 - Note:

To transfer the call to a call that is on hold, press the call/line appearance button for the call that is on hold.

4. Press Transfer again or hang up to complete the transfer.

About Conference Calls

You can use conference calls to speak with up to three people in different locations on the same call. Additional conferencing options may be available through Expanded Meet-Me Conferencing. Contact your system administrator for more information about this feature.

Making a conference call

- 1. While active on a call, press Conference.
- 2. Dial the telephone number.
- 3. Press **Conference** to add the person to the existing call.

Adding a person on hold to a conference call

1. While active on a call, press **Conference**.

You hear a dial tone.

- 2. Press the call/line appearance button of the call on hold.
- 3. Press Conference again to add the person to the conference call.

Putting a conference call on hold

When you put a conference call on hold, the other parties can still talk to each other.

1. Press **Hold** during a conference call.

Note:

The blinking green LED next to the call/line appearance button indicates the conference is on hold.

2. Press Hold to resume the conference call.

Dropping the last person added to a conference call

While active on a conference call, press Drop.

Getting Your Messages

A red light on the upper right-hand corner of your telephone indicates when you have messages waiting. Your messages are an administered function. Contact your system administrator with any questions.

Logging into your voice mail

- 1. To log in to your voice mail, follow the instructions provided by your system administrator.
- 2. Once you are logged in, follow the voice prompts from your voice mail system.

About Bridged Appearances and Shared Lines

Your phone may show a bridged appearance on the display screen in addition to your own lines. A bridged appearance typically belongs to someone else, but bridging allows you to see if that line is in use, answer calls on that line, or join a call in progress on that line from your telephone. You can also make outgoing calls on a bridged appearance when it is not in use.

Depending on how your telephone system is configured, your phone may show shared line appearances on the display screen in addition to your own lines. A shared line appearance is a line that is shared among multiple users. You can answer a call, join a call in progress, and make an outgoing call on a shared line appearance. The procedures to answer, join, and make a call on a shared line appearance are similar as those for a bridged appearance. But instead of using another person's line, you are using a shared line.

Answering a call on a bridged appearance

To answer a call on a bridged appearance, press the call/line appearance button associated with the bridged appearance. **Note:**

The ringing bridged appearance will be selected automatically if there are no other active calls. If the ringing appearance is displayed, you can answer by picking up the handset or by pressing the **Speaker** button. If you are on another call when a call comes in to a bridged

appearance, you may have to select the ringing appearance button (just like for an incoming call to a primary line).

Joining a call on a bridged appearance

To join an existing call on a bridged appearance, press the call/line appearance button associated with the bridged appearance.

Making an outgoing call on a bridged appearance

When you make a call on a bridged appearance, you are using another person's line. The caller ID may show the call as coming from you or coming from the person whose line you are using. If you have any questions about how the name or extension displays to the person you are calling, contact your system administrator.

- 1. Press the call/line appearance button associated with the bridged appearance.
- 2. Dial the telephone number.

About Advanced Telephone Features

Avaya call management systems provide many advanced telephone features such as Call Forwarding, Send All Calls, Abbreviated Dial buttons, and Extension to Cellular. One of these features can be assigned by your system administrator to the feature button on your telephone.

The feature button label identifies the feature that has been assigned for your telephone. For more information about the feature administered for your telephone, and for other features that are available for your extension, contact your system administrator.

About the Avaya Menu

You can use the Avaya Menu to adjust and customize phone settings, select the display language, view network settings, and log out. To access the Avaya Menu, press the **A** button. To exit the Avaya Menu, press the **A** button twice.

The Avaya Menu has five sub-menus:

- Screen—lets you adjust the display brightness and contrast and turn visual alerting on and off.
- **Sounds**—lets you select your ringing pattern, turn button click sounds on and off, and turn error tones on and off.
- Advanced—lets you select the display language, set automatic gain control on the handset and speaker, or initiate a manual backup/restore if you have a backup/ restore file server. See your system administrator for more information.
- **Network Information**—shows a summary of network-related parameters for your phone, such as IP parameters and Quality of Service.
- Log Out—lets you log out of your telephone to prevent unauthorized use during your absence.

Note:

The sub-menus that appear depend on how your extension was administered. Some submenus may not be available.

Adjusting the brightness or contrast of the display

- 1. Press the **A** button.
- 2. Press # to continue.
- 3. Press * to select Screen.
- 4. Press **#** to scroll to Bright or Contrast.
- 5. Press or + on the volume button to adjust the brightness or contrast.

Changing the ring pattern

- 1. Press the **A** button.
- 2. Press **#** to scroll to Sounds.
- 3. Press * to select Sounds.
- 4. Press or + on the volume button to select a ring type.

Note:

You hear each ring type when you select them.

Turning button click sounds on and off

- 1. Press the A button.
- 2. Press # to scroll to Sounds.
- 3. Press * to select Sounds.
- 4. Press **#** to select Next.
- 5. Press or + on the volume button to turn button click sounds on and off.

Turning error tones on or off

- 1. Press the **A** button.
- 2. Press # to scroll to Sounds.
- 3. Press * to select Sounds.
- 4. Press # to scroll to Error Tones.
- 5. Press or + on the volume button to turn error tones on or off.

Turning visual alerting on or off

When the Visual Alerting option is turned on, incoming calls cause the LED in the top right corner of the phone to flash. You can turn Visual Alerting on or off.

- 1. Press the **A** button.
- 2. Press # to continue.
- 3. Press * to select Screen.
- 4. Press # to scroll to Visual Alert.
- 5. Press or + on the volume button to turn visual alerting on or off.

Setting Automatic Gain Control

Automatic Gain Control helps to maintain a constant audio level by automatically increasing or decreasing the gain depending upon the signal level. For high level signals, the gain is reduced and for low level signals, the gain is increased.

- 1. Press the **A** button.
- 2. Press # to scroll to Advanced.
- 3. Press * to select Advanced.
- 4. Press # to select AGCHandset or AGCSpeaker.
- 5. Press or + on the volume button to turn automatic gain control on or off.

Changing the language

- 1. Press the **A** button.
- 2. Press # to scroll to Advanced.
- 3. Press * to select Advanced.
- 4. Press # to scroll to Language.
- 5. Press * to select Language.
- 6. Press # to scroll to the desired language.

Note:

Other languages may be available. Contact your system administrator.

- 7. Press * to save your selection.
- 8. Press 4 to confirm or 6 to cancel.

Viewing Network Information

- 1. Press the **A** button.
- 2. Press # to scroll to Network Info.
- 3. Press * to select Network Info.
- 4. Press # to scroll to Audio Info, IP Info, QOS, Interfaces, or Miscellaneous.
- 5. Press * to view information for the item you selected.

Viewing Network Information

<u>6</u>

Index

Α

Advanced Telephone Features features commonly administered 11	
Automatic Gain Control	
setting	<u>13</u>
Avaya Menu	
about	<u>11</u>
brightness or contrast	<u>12</u>
button click sounds	<u>12</u>
changing language	<u>13</u>
error tones	<u>12</u>
log out	. <u>8</u>
network information	<u>13</u>
ring pattern	<u>12</u>
setting automatic gain control	13
visual alerts	12

В

Bridged appearances	
answering	<u>10</u>
Bridged appearancess	
about	<u>10</u>
Bridged Calls	
joining	<u>11</u>
Button Click Sounds	
turning on and off	<u>12</u>

С

Call/line appearance button LEDs	
about	. 6
Conference Calls	
about	. <u>9</u>
adding a person on hold	. <u>9</u>
dropping the last person	<u>10</u>
making	. <u>9</u>
putting a call on hold	

	_
D	
Display	
adjusting brightness	<u>12</u>
adjusting contrast	<u>12</u>

Ε

Error Tones	
turning off	<u>12</u>

F

Feature button LEDs	
about	

about.....

Η

Hold		9
conference calls	1	0

I

Icons in telephone display	
about	7
Incoming Calls	
answering	8
transferring	
-	

L

Language		
changing	. 1	3
LEDs		
about		<u>6</u>
Logging in to your telephone	<u>7</u> ,	8
Logging out of your telephone		7

Μ

Messages	
retrieving	10
Muting Calls	<u>9</u>

Ν

Network Information	
viewing	<u>13</u>

0

Outgoing calls	
making a call	8
making a call on a bridged appearan	ce
	11
redialing a number	8

Ρ

Paper Labels about	7
R	
Redial	8
Ring Pattern	
changing <u>1</u>	2

S

Shared lines about	<u>10</u>
т	_
Telephone display icons about	7
Transfer	9
v	

####