

STERL-TRONIC MODEL 10424-GX  
TEMPERATURE CONTROL UNIT  
SERVICE AND INSTRUCTION MANUAL

STERLING, INC.  
5200 West Clinton Avenue  
Milwaukee, Wisconsin 53223

## Please note that our address and phone information has changed. Please reference this page for updated contact information.



These manuals are obsolete and are provided only for their technical information, data and capacities. Portions of these manuals detailing procedures or precautions in the operation, inspection, maintenance and repair of the products may be inadequate, inaccurate, and/or incomplete and shouldn't be relied upon. Please contact the ACS Group for more current information about these manuals and their warnings and precautions.

### Parts and Service Department

The ACS Customer Service Group will provide your company with genuine OEM quality parts manufactured to engineering design specifications, which will maximize your equipment's performance and efficiency. To assist in expediting your phone or fax order, please have the model and serial number of your unit when you contact us. A customer replacement parts list is included in this manual for your convenience. ACS welcomes inquiries on all your parts needs and is dedicated to providing excellent customer service.

#### For immediate assistance, please contact:

- North, Central and South America, 8am – 5pm CST +1 (800) 483-3919 for drying, conveying, heating and cooling and automation. For size reduction: +1 (800) 229-2919.  
North America, emergencies after 5pm CST (847) 439-5855  
**North America email: [acsuscanadacustserv@corpemail.com](mailto:acsuscanadacustserv@corpemail.com)**
- Mexico, Central & South America  
**Email: [acslatinamericacustserv@corpemail.com](mailto:acslatinamericacustserv@corpemail.com)**
- Europe, Middle East & Africa +48 22 390 9720  
**Email: [acseuropecustserv@corpemail.com](mailto:acseuropecustserv@corpemail.com)**
- India +91 21 35329112  
**Email: [acsindiacustserv@corpemail.com](mailto:acsindiacustserv@corpemail.com)**
- Asia/Australia +86 512 8717 1919  
**Email: [acsasiacustserv@corpemail.com](mailto:acsasiacustserv@corpemail.com)**

### Sales and Contracting Department

Our products are sold by a worldwide network of independent sales representatives. Contact our Sales Department for the name of the sales representative nearest you.

Let us install your system. The Contract Department offers any or all of these services: project planning; system packages including drawings; equipment, labor, and construction materials; and union or non-union installations.

#### For assistance with your sales or system contracting needs please Call:

North, Central and South America +1 (262) 641-8600 or +1 (847) 273-7700 Monday–Friday, 8am–5pm CST

Europe/Middle East/Africa +48 22 390 9720

India +91 21 35329112

Asia/Australia +86 512 8717 1919

#### Facilities:

ACS offers facilities around the world to service you no matter where you are located. For more information, please visit us at [www.acscorporate.com](http://www.acscorporate.com)

United States:

#### ACS Schaumburg – Corporate Offices

1100 E. Woodfield Road  
Suite 588  
Schaumburg, IL 60173  
Phone: + 1 847 273 7700  
Fax: + 1 847 273 7804

#### ACS New Berlin – Manufacturing Facility

2900 S. 160<sup>th</sup> Street  
New Berlin, WI 53151  
Phone : +1 262 641 8600  
Fax: + 1 262 641 8653

Asia/Australia:

#### ACS Suzhou

109 Xingpu Road SIP  
Suzhou, China 215126  
Phone: + 86 8717 1919  
Fax: +86 512 8717 1916

Europe/Middle East/Africa:

#### ACS Warsaw

Ul. Działkowa 115  
02-234 Warszawa  
Phone: + 48 22 390 9720  
Fax: +48 22 390 9724

India

#### ACS India

Gat No. 191/1, Sandbhor Complex  
Mhalunge, Chakan, Tal Khed,  
Dist. Pune 410501, India  
Phone: +91 21 35329112  
Fax: + 91 20 40147576

MODEL 10424-GX

INDEX PAGE

DESCRIPTION

INSTALLATION

ELEMENTARY WIRING DIAGRAM - D682-06111

FLOW SCHEMATIC, PANEL LAYOUT, BILL OF MATERIAL - D682-06110

OPERATION

TROUBLE SHOOTING

STERLCO PUMP FORM MP-1

CONTROLLER INSTRUCTION (FENWAL)

CONTACTOR ----- SQUARE "D" #8903

DISCONNECT SWITCH - SQUARE "D" #9422

STARTER, MOTOR ---- SQUARE "D" #8536

PRESSURE SWITCH --- A-B #836T

SOLENOID VALVES --- ASCO #8210, 8222 and 8262

RELAY ----- SQUARE "D" #8501

PARTS LIST #594

WARRANTY PAGE

MODEL NO.

SUFFIX LETTER

HORSEPOWER PUMP

10424

B

1/2 H.P.

---

C

3/4 H.P.

---

D

1 H.P.

---

E

1-1/2 H.P.

---

F

2 H.P.

---

G

3 H.P.

MODEL 10424-GX

DESCRIPTION

This unit is a two zone, high capacity, water-circulating temperature control system. The unit is a completely portable design with full sheet metal cabinet, with service doors, large casters and power cable with plug.

HEATING - Each zone is provided by a 4500 watt electric immersion heater, 3 phase low-watt density, of the flanged type. The heater is energized through a 3 pole relay, upon demand by the temperature controller.

PUMPING - For each zone is provided by a straight centrifugal pump, bronze-fitted, 3450 RPM.

COOLING - Is accomplished by the direct injection method which blends cooling water directly into the circulating system under carefully controlled thermostatic conditions. This method of cooling provides for a very great cooling capacity and allows the user to make very efficient use of his cooling water. Because the total amount of cooling water entering the system is directed through the work area by employment of a check valve.

THERMOSTATIC CONTROL of the system is maintained by a controller with heating and cooling output. The single-set controller energizes either the heater or the cooling, and indicates system temperature.

WATER PROTECTION has been provided in the form of a pressure switch. The pressure switch will keep the unit from operating until it has been sufficiently pressurized by the user's water supply. This will help to protect the heater and the pump seal from damage through operation without water. This switch is adjustable.

**NOTE: IF THIS UNIT IS TO BE OPERATED TO 300° F., THE PRESSURE SWITCH SHOULD BE ADJUSTED TO A MINIMUM OF 60 PSI.**  
This will assure the unit of having sufficient pressure at that temperature to eliminate possibilities of internal boiling.

## MODEL 10424-GX

### INSTALLATION

The unit should be placed into position at the press. The user's manifolds for raw water and drain should be brought to the back of the unit.

DELIVERY AND RETURN connections are located at the rear of the unit. If the water must travel some considerable distance to the work area, the piping should be kept the same size as that of the connections in order to minimize losses in flow resulting from fluid resistance.

WATER SUPPLY AND DRAIN are located at the rear of the unit. If 300° F. water temperatures are to be maintained, a minimum of 60 psig pressure must be maintained on the water supply line to each zone, from the user's water supply. If the water temperatures will not exceed 250° F. then the user need only provide a 25 psig minimum water supply pressure. The importance of these pressure/temperature relationships cannot be OVERLY STRESSED and the user must supply a sufficient water supply pressure.

Back pressure from the drain, if any, should not approach or exceed the pressure of the water supply, since in large measure the cooling capacity of the unit is directly related to the difference in pressure between the water supply and drain.

ELECTRIC POWER is brought to the unit through the power cable which is supplied with it. This cable is fitted with a Russell & Stoll plug for quick attachment to a corresponding outlet at the press. A ground line is brought out from each zone through the cable and power plug and the user should exercise care to insure that a safe and secure ground connection is made.

THE UNIT should be rolled into position and service connections installed. Water supply and drain connections are attached and the delivery and return connections should be made. With the disconnect switch "OFF", the user should attach the power-cable to the power supply connection at the press.

MODEL 10424-GX

OPERATION

After all the water supply, drain, electrical, and delivery and return connections have been made, the following steps should be taken to place the unit into service.

- 1.) Turn on the electrical power at the disconnect switch of the unit.
- 2.) Turn on the water supply to provide water for each zone. This should remain open and under sufficient pressure (see installation instructions) at all times. The drain line should also be open and should remain so.
- 3.) Set each thermostat at approximately 100° F.
- 4.) Hold the vent button of each zone for at least 45 seconds in order that all entrapped air be expelled to the drain and a steady flow of water to the drain established. This should be done one zone at a time, NOT ALL AT ONCE.
- 5.) After air purge, the start button should be pushed. If the water supply connections to the press and mold allow sufficient pressure, the unit will continue to run when the start button is released. The green pilot light will indicate whether or not the pump is running. MOTOR ROTATION SHOULD BE CHECKED IMMEDIATELY and corrected immediately if necessary. If the motor does not continue to run when the start button is released, the user should check to be sure that the water supply is turned on.
- 6.) Set the thermostat for the desired operating temperature. The unit will operate automatically and continuously from this point.

STERLING, INC.

SPARE PARTS LIST

MODEL 10424-GX

<u>PART NO.</u>	<u>DESCRIPTION</u>
729-00072	Contactor, Immersion Heater
724-00168	Controller, Thermostat
728-00009	Disconnect Switch
728-00014	Operating Mechanism
725-00539	Fuse, Control
725-00603	Sol. Fuse
725-00546	Fuse, Main
725-00547	Fuse, Motor
722-00048-01	Heater, Electric Immersion (4.5KW @ 480V)
037-00074	Gauge, Pressure
720-09012	Motor, Electric
715-03005	Pilot Light
C605-00086-03	Pump & Motor Ass'y Complete
721-03001	Push Button, STOP
721-03003	Push Button, START
714-00050	Relay
726-00105	Starter, Motor Control
603-00025-03	Strainer, "Y" w/Screen
733-00015	Switch, Pressure
704-00048	Transformer, Control
044-00138	Valve, Safety Pressure Relief
732-00017	Valve, Solenoid w/Coil (1")
732-00056	Valve, Solenoid w/Coil (1/4")
717-00027	Switch, Selector
732-00065	Valve, Solenoid w/Coil (1-1/2")