




Optical Wireless Rechargeable

Model #: OM5000WR



User's Manual



User's Record:

To provide quality customer service and technical support, it is suggested that you keep the following information as well as your store receipt and this user's manual.

Date of Purchase:

Model Number:

Serial Number:

Product Rev Number (located below the UPC on the package):



Package Contents:

Your new Mouse will ship with the following items.

- Optical Wireless Mouse
- USB Receiver/Recharger
- 4 AAA Ni-MH Rechargeable Batteries
- User's Manual
- Warranty Information

System Requirements:

Please be sure that you meet all of the system requirements below to avoid difficulties during installation.

- IBM PCs or 100% Compatibles
- Windows® ME, 2000, XP
- Available USB Port


System Specifications:

Your new Mouse complies with the following specifications.

- 400dpi
- USB Interface

Installation:


NOTE: The pictures shown in the User's Manual are for demonstration purposes only. Your computer or product may look slightly different.



1. Remove the **Battery Compartment Cover** on the back of your Mouse.
2. Install two of the enclosed Ni-MH rechargeable AAA batteries into your Mouse following the battery orientation guide printed in the battery bay of your mouse, and then replace the cover back onto your Mouse.
3. Turn on your computer and wait for it to load.
4. Plug the **Wireless USB Receiver** into an available USB port on your computer. Your mouse will establish a connection with the receiver and is ready to be used. If a connection is not established, there might be a high level of surrounding interference, press the **Connect** button on the back of the **Wireless USB Receiver**, and then press the **Connect** button on the back of your Mouse.
5. Your computer will detect your Mouse and the necessary drivers will be installed automatically.
6. Your Mouse is now ready to be used.


Using the Battery Charger:

1. Remove the **Battery Compartment Cover** on the back of the **Wireless USB Receiver**.
2. Install two Ni-MH rechargeable AAA batteries into the **Wireless USB Receiver** following the battery orientation guide in the battery bay.
3. Replace the cover back onto the **Wireless USB Receiver**.



4. Turn on your computer and connect the **Wireless USB Receiver** into an available USB port on your computer, the **Wireless USB Receiver** will begin charging the installed Ni-MH rechargeable batteries.
5. There are two LED indicators on the **Wireless USB Receiver**:

LED	Status	Description
Connection LED	Off	No Battery Installed/Battery Is Fully Charged
	Solid Red	Inactive/Mouse Not Detected
	Flashing Red	Mouse Detected and It Is Active
	Blinking Red	Scanning Mouse Connection
Battery Charging LED	Solid Red	Charging Battery





FCC Information:

FCC

This equipment has been tested and found to comply with limits for Class B digital device pursuant to Part 15 of Federal Communications Commission (FCC) rules.

FCC Compliance Statement

These limits are designed to provide reasonable protection against frequency interference in residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed or used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in television reception, which can be determined by turning the equipment off and on. The user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected to.



CAUTION!

The Federal Communications Commission warns the user that changes or modifications to the unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



Warranty Information:



Gear Head, LLC warrants that this product shall be free from defects in materials and workmanship for the reasonable lifetime of the product. If the product is defective, Gear Head, LLC's sole obligation under this warranty shall be at its election, subject to the terms of this warranty, to repair or replace any parts deemed defective. This warranty is for the exclusive benefit of the original purchaser and is not assignable or transferable. THIS WARRANTY IS MADE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, AND ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE TERMS OF THIS WARRANTY, UNLESS OTHERWISE PROHIBITED BY LAW.

Exclusions

To the fullest extent permitted by law, Gear Head, LLC expressly disclaims and excludes from this warranty any liability for damages, including but not limited to general, special, indirect, incidental, consequential, aggravated, punitive or exemplary damages, and economic loss (even if Gear Head™ is informed of their possibility), third party claims against you, including for any loss or damages, and claims or damages related to loss of, or, damage to, your records or data. This warranty does not apply to any product the exterior of which has been damaged or defaced. This warranty will be voided by misuse, improper physical environment, improper repair, acts of God, war or terror, commercial use, and improper service, operation or handling.

Technical Support

Gear Head™ provides Technical Support Monday - Friday from 9:00 am – 5:30 pm Eastern Time. Before calling, please make sure you have available the Model # (located on the front page of your User's Manual) and information regarding your computer's operating system.

Please contact our technicians at
1-866-890-7115

Return Merchandise for Service

Any claim under this warranty must be made in writing to Gear Head, LLC, at the address provide by our technician, within 30 days after the owner discovers the circumstances giving rise to any such claim, and must include a copy of this warranty document, a receipt or copy of your invoice marked with the date of purchase, and the original packaging. You may obtain service by calling the technician for a Return Merchandise

Authorization (RMA) number. The RMA number must be prominently displayed on the outside of the shipping carton and the package must be mailed to Gear Head™ postage prepaid.