# IEEE802.11b 11Mbps CompactFlash Card

**Quick Installation Guide** 

M73-APO01-560

### **REGULATORY STATEMENTS**

#### FCC Certification

The United States Federal Communication Commission (FCC) and the Canadian Department of Communications have established certain rules governing the use of electronic equipment.

#### Part15, Class B

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interface, and
- 2) This device must accept any interface received, including interface that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful or television reception, which can interference to radio be determined by turning off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

#### CAUTION:

- To comply with FCC RF exposure compliance requirements, a separation distance of at least 20 cm must be maintained between the antenna of this device and all persons.
- 2) This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

# SOFTWARE INSTALLATION FOR WINDOWS CE3.0

Connect your PDA to your PC. Make sure you have the Microsoft ActiveSync Utility installed on your PC to make an active connection.

**Caution: DO NOT** insert the Wireless CompactFlash Card into the PDA **BEFORE** installing the configuration utility.

- 1. Insert the device driver CD into the CD-ROM drive.
- 2. Open the WINCE3.0 folder.



3. Inside the WINCE3.0 folder, click on **PrismForPocketCE**.

For Handheld PC users: Please select PrismForHandHeldCE.

SWINCE3.0			×
Eile Edit View Favorites Tools H	elp		1
↓ Back • → • 🔁   🖓 Search 🖓 F	olders 🎯 History 📴	ლX თ ⊞•	
Address 🗀 WINCE3.0		• @	Go
WINCE3.0	PrismForHand HeldCE	mForPocke tCE	
PrismForPocketCE Application			
Modified: 7/24/2002 2:03 PM			
Size: 4.97 MB			
Attributes: (normal)			
<u>.</u>			Þ
Type: Application Size: 4.97 MB	4.97 MB	Ry Computer	

4. Click Next to continue.

Wireless Network Setup v1.00	.09	×
	Welcome to the InstallShield Wizard for PRISM 11Mbps Wireless LAN for Windows CE 3.0 The InstallShield® Wizard will install PRISM 11Mbps Wireless Lield® Wizard will install PRISM 11Mbps Continue, click Next.	
	Cancel	

5. Click OK.



6. Click Finish.

Wireless Network Setup v1.00.09	
	InstallShield Wizard Complete Setup has finished installing PRISM 11Mbps Wireless LAN for Windows CE 3.0 on your computer. You can now use the control part al paplet on your Windows CE device to configure your network settings.
	K Back Finish Cancel

7. You can now insert the Wireless CompactFlash Card into the PDA. Then use the **Settings** on your Windows CE to configure the network settings.

### HARDWARE INSTALLATION

#### For PDA

Insert the Wireless CF card into the Windows CE-based PDA by aligning the Wireless CF card toward the CF slot.



#### For Notebook PC

- **Note**: This section is only for users who had CF to PCMCIA Adapter. Please refer to the manual for more details.
- Plug the Wireless CF card into the PCMCIA Adapter. The Wireless CF card is then turning into a conventional PCMCIA type II PC Card.
- Align the PC Card toward the PC Card slot with brand label facing upward, as shown below.



# NETWORK CONNECTION FOR WINDOWS CE3.0

Once the driver has been installed, you must make some changes to your network settings.

1. Go to Start → Settings → Connections. Click on Network Adapters.



2. Highlight PRISM 11Mbps Wireless LAN Adapter, click Properties.



#### 3. • Use server-assigned IP address

If your network supports DHCP, select Use server-assigned IP address. The IP address and other information will be automatically assigned. Then click ok.

🎊 Settings	<b>4</b> € 1	:36 😡
PRISM 11Mpbs Wireless	LAN Ada	pter
• Use server-assigned If	o address	5
O Use specific IP addres	s	
IP address: ,		
Subnet mask: ,		
Default gateway:,		
IP Address Name Servers		

#### ⊙ Use server-assigned IP address

If your network does not support DHCP, select Use specific IP address. You may need to enter the IP address and other information. When you have finished entering settings, click OK.

🎢 Settings 📢 1:37 🚱
PRISM 11Mpbs Wireless LAN Adapter
O Use server-assigned IP address
Use specific IP address
IP address:
Subnet mask:
Default gateway:
IP Address Name Servers

If you forget to click **OK**, your settings will not take effect!

 A message as below may appear saying you must remove and re-insert the Wireless CompactFlash Card to have the changes take affect. Click OK.



# CONFIGURATION UTILITY FOR WINDOWS CE3.0

After installing the Wireless CompactFlash Card's driver successfully, go to Start  $\rightarrow$  Programs. Click on PRISM Settings, the Network Status icon will appear in the task bar.



### Network Status Icon & Icon Menu

### The Status Icon

Icon	Link Status
4	Green indicates a strong link.
1	Yellow indicates a weak link.
4	Red indicates no or a very poor link.

### Icon Menu

After clicking on the icon, the icon menu as displayed below will prompt you to configure the Wireless CompactFlash Card.



Items	Description
Wireless Radio On	These two items allows you
Wireless Radio Off	to enable or disable the
	wireless radio.
Remove Status Icon	Removes the Utility icon
	from the PDA's system
	tray. Each time you power
	on your PDA, the icon will
	reappear.
Wireless Network	Clicking these items will
Status	launch the Wireless
Advanced	Settings window, as
Configuration	described below.
WEP Encryption	
Version	
Information	

All settings are categorized into 5 tabs:

Link

Configuration

Encryption

Site Survey

### About

### Link

The **Link** tab provides you the status of the Wireless CompactFlash Card.

🖅 PRISM Set	tings	<b>4</b> € 1:21
State: Associa	ted - 00:E0:98	:9F:D3:24
Current Channel	: 10	Disable Radi
Current Tx Rate	11 Mb/sec	<u>R</u> escan
[Throughput (by	tes/sec)	3
Tx: 0	Rx:	335
L Link Quality:	Excellent (10	0%)
Signal Strength:	Excellent (10	0%)

Item	Description
State	It displays the connection state of the Wireless CompactFlash Card with the wireless network.

Item	Description
Current Channel	It displays the selected channel that is currently used. (There are 14 channels available, depends on the country.)
Enable Radio / Disable Radio	Click this button to enable/disable the wireless radio. The Wireless CompactFlash Card will connect/disconnect with the wireless network.
Rescan	Search for all available networks. Clicking on the button, the device will start to rescan.
Current Tx Rate	It displays the current transfer rate.
Throughput	It displays the transferring (Tx) and receiving (Rx) data rate in bytes per second.
Link Quality	It displays the link quality of the connection between the Wireless CompactFlash Card and the Access Point or Peer-to-Peer type it connects.
Signal Strength	It displays the signal strength of the connection between the Wireless CompactFlash Card and the Access Point or Peer-to-Peer type it connects.

# Configuration

The **Configuration** tab allows to set parameters for the Wireless CompactFlash Card.

🎊 PRISM Set	tings	<b>4</b> € 1:22 (	b
Profile Name:	Default		]
Network <u>N</u> ame:	any		]
Network <u>T</u> ype:	Access Point	•	]
Peer-to-Pee	Fully Au	tomatic 👻	]
Defaults	Undo	Apply	
Link Configurati	on Encryption	Site Sur	ļ

Item	Description
Profile	Saves values for all previous setting parameters. The <b>default</b> values
Name	contain the parameters configured at installation. Once the demands for switching between different networking environments are required, you can also set the additional profiles to eliminate the configuration time. To save the current parameters, highlight the Profile field, type a new name, and click on the <b>[Apply]</b> button.
Network Name	A specific name shared among connected Wireless CompactFlash Card, Access Points and other wireless stations on the wireless network. The name must be identical for all devices and points attempting to connect to the same network. The default name is <b>ANY</b> . To change the Network Name, simply enter a new name in the field.

Item	Description		
Network Type	It displays the type of BSS. Access Point: allows the Adapter to communicate with a wired network which employing an Access Point. Peer-to-Peer: allows PC-to-PC, station-to-station communication without employing an Access Point.		
Peer-to-Peer Channel	To communicate with other Wireless CompactFlash Card, you must specify the same channel. Click the up and down arrow at the right of the Peer-to-Peer Channel to set the desired channel.		
Transmit Rate Default	It displays the current transmit rate. 1Mb, 2Mb, Auto 1 or 2 Mb, 5.5Mb, 11Mb or Fully Automatic) Clicks the button to restore to the		
Undo	default settings. Click Undo to ignore the previous setting.		
Apply	Click <b>Apply</b> to activate the settings.		
ok	Click <b>OK</b> to save your changes.		

### Encryption

**WEP (Wired Equivalent Privacy)** encryption can be used to ensure the security of your wireless network.

A PRISM Settings	◀€ 1:23	•
Encryption (WEP):	Disabled	-
Create Keys with Pas	sphrase	
Pa <u>s</u> sphrase:		10
Create Keys Manually	5	
Alphanumeric		
Hexadecimal		18
Key <u>1</u> :		
Key <u>2</u> :		
Key <u>3</u> :		10
Key <u>4</u> :		
∐se WEP Key: 1 ▼	Apply	/
Link Configuration End	cryption Site Sur	4

Item	Description
Encryption (WEP)	WEP is a data privacy mechanism based on a 64-bit/128-bit shared key algorithm. Under the drop-down box, you can choose to have WEP encryption <b>Disabled</b> , 64 bit, or 128 bit.
Create Keys with Passphrase	A Passphrase can be entered to generate four keys used for WEP. For the easiest configuration, the Passphrase method is recommended.
Create Keys Manually	These four fields can be used to enter WEP keys manually. The method is required to match the keys of other wireless devices on the existing network.
<ul> <li>Alphanumeric: 5 characters</li> </ul>	Click Alphanumeric if you are using an alphanumeric phrase.
• Hexadecimal: 10 digits (0-9, A-F)	Click Hexadecimal if you are using a hexadecimal number.

Key 1: Key 2: Key 3: Key 4:	This setting is the configuration key used in accessing the wireless network via WEP encryption.
Use WEP Key	The default key field can be used for specifying which of the four encryption keys to transmit data on the wireless network.
Apply	Click <b>Apply</b> to activate the settings.

🏂 PRISM Settings	<b>4</b> € 1:23 🚯
Encryption (WEP):	64 bit 👻
Create Keys with <u>Pa</u> Passphrase:	ssphrase
<ul> <li>Create Keys Manual</li> <li>Alphanumeric: 5</li> <li>Hexadecimal: 10</li> </ul>	ly: characters digits (0-9, A-F)
Key <u>1</u> : Key <u>2</u> : Key 3:	
Key <u>4</u> :	
Link Configuration E	ncryption Site Sur

You must use the same value/phrase and WEP key settings for all wireless computers in order for the wireless network to function well.

# Site Survey

The **Site Survey** tab shows all the available Access Points or Peer-to-Peer types and their features.

🔊 PRISM Settings	<b>∢</b> € 1:23 0
Available Networks:	click Connect.
testID5 Pattern 123 KKID10	Rescan Connect
Site Information Network Name: ALBERT-104 BSSID: 00-E0-98-9F-D3-24 Channel: 10 Network Type: Access Point WEP Encryption: NO Signal Level: -54 dBm	
Configuration Encryption Sit	e Survey

Item	Description		
Network Name	The name must be identical for all devices and points attempting to connect to the same network.		
BSSID	A set of wireless stations is referred to as a Basic Service Set (BSS). Computers in a BSS must be configured with the same BSS ID.		
Channel	It shows the selected channel that is currently used.		
Network Type	It displays the type of BSS. Access Point: allows the Adapter to communicate with a wired network which employing an Access Point. Peer-to-Peer: allows PC-to-PC, station-to-station communication without employing an Access Point.		

Item	Description		
WEP Encryption	It displays the status of WEP Encryption.		
Signal Level	It displays the signal strength of the connection between the Wireless CompactFlash Card and the Access Point it connects.		
Rescan	Search for all available networks. Clicking on the button, the device will start to rescan and list all available sites.		
Connect	To connect with a new access point, highlights the desired one in the left list box and clicks on the <b>Connect</b> button. Wait a while and the selected one will be marked as a current used access point.		

### About

The **About** tab shows the information and version of the Configuration Utility.

🎊 PRISN	1 Settings	◀€ 1:24	•
Yir PR	eless Corporatio ISM Wireless LAN	n I	
Copyright (	2001 Wireless	Corporation	
Network D	river —		-
Version:	1.07.37		
Date:	Jul 12 2002		
Configura	tion Utility ——		10
Version:	1.07.37		
Date:	Jul 12 2002		
Software	Suit ———		
Version:	1.00.09		
Date:	Jul 12 2002		
NIC Firmw	are —		
Version:	1.04.02.1 00.0	0.00.F1.F1.F1	
Encryption	Site Survey A	bout	