

SpeedStream[®]

Wireless PCI Adapter

User's Manual



Model SS1024

SIEMENS

Part No. 007-0314-001

Regulatory compliance

FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

IMPORTANT NOTE:

Federal Communications Commission (FCC) Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

CE Mark Warning

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

About this manual

This User's Manual describes how to install and operate your SpeedStream Wireless PCI Adapter. Please read this manual before you install the product.

This manual includes the following topics:

- Product description and features.
- Hardware installation procedure.
- Software installation procedure.
- FAQ

© 2002 Efficient Networks, Inc. A Siemens Company. All rights reserved. Efficient Networks, its logos and SpeedStream are registered and unregistered trademarks of Efficient Networks, Inc. Siemens and the Siemens logo are trademarks of Siemens AG, Germany. All other trademarks are held by their respective companies. Efficient Networks reserves the right to make changes to product specifications at any time without notice.

All trademarks and trade names are the properties of their respective owners.

Table of Contents

Regulatory compliance.....	2
About this manual	3
Chapter 1 - Introduction	5
Features	5
What is Wireless LAN?	6
Wireless LAN Modes	6
Notes on Wireless LAN Configuration.....	7
Chapter 2 - Hardware Installation.....	8
Package Contents	8
System Requirements for the Adapter	8
Install the PCI Adapter	8
LED Indicators	9
Connecting the adjustable Antenna to the Adapter	10
Chapter 3 – Driver Installation for Windows	11
Driver installation for Windows® 95 OSR2	11
Driver installation for Windows® 98.....	14
Driver installation for Windows® 2000.....	17
Driver installation for Windows® Me.....	21
Driver installation for Windows® NT4.0.....	23
Driver installation for Windows® XP.....	27
Chapter 4 – Installing and Using the Wireless Utility	29
Installation in Windows	29
Firmware Upgrade	32
Using Wireless Utility In Windows XP	33
Use Windows Wireless Network Configuration	33
Use SpeedStream Wireless LAN Utility	36
Use SpeedStream Wireless LAN Utility In Windows 95, 98, 2000, NT 4.0 and Me	39
Configuring the SpeedStream Wireless PCI Adapter	40
Chapter 5 – Installing Network Protocols	44
Installing the Network Protocols for Windows 98 and Millennium	44
Appendix A – FAQ	47
Appendix B – Specifications	48

Chapter 1 - Introduction

Thank you for purchasing the SpeedStream Wireless PCI Adapter. This high-speed SpeedStream Wireless PCI Adapter provides you with an innovative wireless networking solution. The Adapter is easy to set up and use. With this innovative wireless technology, you can share files and printers on the network—without inconvenient wires!

The Adapter is a network Adapter with a rate of 1, 2, 5.5, and 11 Mbps operating in the ISM band using Direct Sequence Spread Spectrum (DSSS) transmission implementing the IEEE 802.11b standard. This Adapter provides Device Drivers for Windows Operating Systems. It also provides tools for the configuration of the Adapter. The tool, as well as the installation steps of the plug-and-play procedure for the Windows operating systems, is described in this document.

Features

The SpeedStream Wireless PCI Adapter offers compliance with the IEEE 802.11b specification. This feature allows the adapter to communicate with other wireless devices that support the standard. Features of the Adapter are:

- **Uses 2.4GHz frequency band, which complies with worldwide requirement**
- **Wireless interface following the IEEE 802.11b standard**
- **Using PCI interface**
- **Enciphering/deciphering of wireless data by the implementation of the WEP algorithm**
- **Wire-free access to networked resources from anywhere beyond the desktop**
- **Allows users to move between Access Points without resetting their connection reconfiguration**
- **Delivers data rates up to 11 Mbps**
- **Supports 11, 5.5, 2, and 1 Mbps rates**
- **Provides SpeedStream Wireless PCI Adapter Configuration utility**
- **The Adapter uses external Antenna with LEDs indicating Power and Link**
- **Supports most popular operating systems**

What is Wireless LAN?

Wireless Local Area Network (WLAN) systems offer a great number of advantages over traditional wired systems. WLANs are flexible and easy to setup and manage. They are also more economical than wired LAN systems.

Using radio frequency (RF) technology, WLAN transmit and receive data through the air. WLAN combine data connectivity with user mobility. For example, users can roam from a conference room to their office without being disconnected from the LAN.

Using WLAN, users can conveniently access-shared information, and network administrators can configure and augment networks without installing or moving network cables.

WLAN technology provides users with many convenient and cost saving features:

- **Mobility:** WLAN provide LAN users with access to real-time information anywhere in their organization, providing service opportunities that are impossible with wired networks.
- **Ease of Installation:** Installation is easy for novice and expert users alike, eliminating the need to install network cables in walls and ceilings.
- **Scalability:** WLAN can be configured in a variety of topologies to adapt to specific applications and installations. Configurations are easily changed and range from peer-to-peer networks suitable for a small number of users to full infrastructure networks of thousands of users roaming over a broad area.

Wireless LAN Modes

Wireless LANs can be configured in one of two ways:

Ad-hoc Networking	Also known as a peer-to-peer network, an ad-hoc network is one that allows all workstations and computers in the network to act as servers to all other users on the network. Users on the network can share files, print to a shared printer, and access the Internet with a shared modem. However, with ad-hoc networking, users can only communicate with other wireless LAN computers that are in the wireless LAN workgroup, and are within range.
Infrastructure Networking	Infrastructure networking differs from ad-hoc networking in that it includes an access point. Unlike the ad-hoc structure where users on the LAN contend the shared bandwidth, on an infrastructure network the access point can manage the bandwidth to maximize

	<p>bandwidth utilization.</p> <p>Additionally, the access point enables users on a wireless LAN to access an existing wired network, allowing wireless users to take advantage of the wired network's resources, such as Internet, email, file transfer, and printer sharing.</p> <p>Infrastructure networking has the following advantages over ad-hoc networking:</p> <ul style="list-style-type: none">• Extended range: each wireless LAN computer within the range of the access point can communicate with other wireless LAN computers within range of the access point.• Roaming: the access point enables a wireless LAN computer to move through a building and still be connected to the LAN.• Wired to wireless LAN connectivity: the access point bridges the gap between wireless LANs and their wired counterparts.
--	---

Notes on Wireless LAN Configuration

When configuring a wireless LAN (WLAN), be sure to note the following points:

- Optimize the performance of the WLAN by ensuring that the distance between access points is not too far. In most buildings, WLAN Adapters operate within a range of 100 ~ 300 feet, depending on the thickness and structure of the walls.
- Radio waves can pass through walls and glass but not metal. If there is interference in transmitting through a wall, it may be that the wall has reinforcing metal in its structure. Install another access point to circumvent this problem.
- Floors usually have metal girders and metal reinforcing struts that interfere with WLAN transmission.

This concludes the first chapter. The next chapter deals with the hardware installation of the Adapter.

Chapter 2 - Hardware Installation

This chapter covers installation of your SpeedStream Wireless PCI Adapter in a PCI slot of a desktop PC.

Package Contents

Please make sure that items below are included in the package.


- ✓ SpeedStream Wireless PCI Adapter with adjustable antenna
- ✓ CD containing drivers and documentation
- ✓ Quick Start Guide
- ✓ Product Registration / Extended Warranty card
- ✓ Safety and Certifications / Software License and Warranty

System Requirements for the Adapter

- Operating System: Microsoft Windows 95/98/ME/2000/NT4.0/XP
- Desktop PC with CD-ROM drive
- One free PCI slot
- Pentium-Class 90MHz or higher

Install the PCI Adapter


NOTE: These instructions apply to most desktop computers. For detailed information on inserting a PCI Adapter into your desktop PC, consult the desktop PC User's Manual.



The SpeedStream Wireless PCI Adapter

1. Turn off the computer, unplug the power cord and remove the computer's cover.
2. Pick a free PCI expansion slot and remove the protective bracket.
3. Insert the Adapter into the slot until it is fully seated.
4. Secure the adapter bracket with the screw from step 2.
5. Replace the computer's cover.
6. Reconnect the power cord and turn on the computer.

LED Indicators




Side view of the PCI Adapter from bracket.

The following table describes the meaning of LED indicators:

LED	MEANING
POWER	Indicates that the Adapter is powered on (solid green).
LINK	Indicates link status. The LED lights up (solid green) while the wireless connection is linked. If the LED is blinking green, the adapter is searching for possible wireless connection.

Connecting the adjustable Antenna to the Adapter

After installing the Adapter in the computer, connect the external Antenna to the Adapter using the SMA connector. Hold the antenna in the desired position and turn the lock nut clockwise until snug (do not over tighten the nut). To adjust the antenna direction, turn the nut counter clockwise one full turn, adjust the antenna then re-tighten the nut.



After hardware installation is complete, proceed to Chapter 3 to install the drivers on different Operating Systems.

Chapter 3 – Driver Installation for Windows

The following sections cover SpeedStream Wireless PCI Adapter driver installation for the Windows Operating Systems.

Note: You must install the hardware before you begin to install the drivers.

Driver installation for Windows[®] 95 OSR2

Follow the steps below to install the SpeedStream Wireless PCI Adapter drivers for Windows 95 OSR2.


1. Insert the SpeedStream Wireless PCI Adapter into the PCI slot of the desktop PC as directed and power on the computer. (Refer to Chapter 2 – Hardware installation.)
2. After Windows 95 OSR2 detects the SpeedStream Wireless PCI Adapter, the *Update Device Driver Wizard* window appears. Clicks **Next** to continue the installation.



3. Windows searches for the driver and the following screen appears:




4. Click **Other Locations** to bring up the following window:




5. Type **I:Win95** where **I** is your CD-ROM drive letter, then click **OK**. The following screen appears:



6. Click **Finish** to continue. Windows may prompt you the following window to ask you insert the disk.



7. Click **OK** to continue.



8. Again type **I:\WIN95**: where **I** is your CD-ROM drive letter and click **OK**.

*NOTE: If you did not install the Windows 95 OSR2 from your hard drive, Windows will prompt you to input the path to the Windows 95 CD-ROM. Follow the instructions on your screen, and then click **OK** to continue.*

The system will then start to install the Wireless utility automatically. Proceed to Chapter 4 for installation procedure details.

Driver installation for Windows[®] 98

Follow the steps below to install the SpeedStream Wireless PCI Adapter drivers for Windows 98.

1. Insert the SpeedStream Wireless PCI Adapter into the PCI slot of the desktop PC as directed and power on the computer. (Refer to Chapter 2 – Hardware installation.)
2. After Windows detects the SpeedStream Wireless PCI Adapter, the *Add New Hardware Wizard* window appears. Click **Next** to continue the installation.



3. A screen appears prompting you to select an installation method. Select **Search for the best driver for your device. (Recommended)** and click **Next** to continue.



4. Ensure that the **CD-ROM drive** is selected. Insert the driver CD-ROM into your CD-ROM drive and click **Next** to continue.



5. The following screen appears showing the driver search result. Click **Next** to continue the installation.



6. Windows 98 copies files to your hard disk. The following screen will appear to inform you when the software installation has finished. Click **Finish** to complete the installation.



7. The following screen will ask you to restart your computer to complete the installation. Click **Yes** to reboot. The system will then start to install the Wireless utility automatically. Proceed to Chapter 4 for installation procedure details.



*NOTE: In most cases, Windows will automatically copy all of the files needed for networking. If Windows asks you for the files and prompts you to input the path to the files, follow the instructions on your screen, and then click **OK** to continue.*

Driver installation for Windows[®] 2000

Follow the steps below to install the SpeedStream Wireless PCI Adapter drivers for Windows 2000.


1. Insert the SpeedStream Wireless PCI Adapter into the PCI slot of the desktop PC as directed and power on the computer. (Refer to Chapter 2 – Hardware Installation.)
2. After Windows 2000 detects the SpeedStream Wireless PCI Adapter, the *Found New Hardware Wizard* window appears. Click **Next** to start the installation.




3. A screen appears prompting you to select an installation method. Select **Search for a suitable driver for my device (recommended)** and click **Next** to continue.




4. Ensure that the **CD-ROM driver** is selected and insert the driver CD-ROM into your CD-ROM drive and click **Next** to continue.




5. The following screen appears showing the driver search result. Click **Next** to continue the installation.



6. The following screen appears. Click **Yes** to continue.



7. Windows has finished installing software for the device. Click **Finish** to complete the installation.




The system will then start to install the Wireless utility automatically. Proceed to Chapter 4 for installation procedure details.

Driver installation for Windows Me

Follow the steps below to install the SpeedStream Wireless PCI Adapter drivers for Windows Me.


1. Insert the SpeedStream Wireless PCI Adapter into the PCI slot of the desktop PC as directed and power on the computer. (Refer to Chapter 2 – Hardware Installation.)
2. After Windows Me detects the SpeedStream Wireless PCI Adapter, the *Add New Hardware Wizard* window appears. Select **Automatic search for a better driver (Recommended)** and insert the driver CD-ROM into CD-ROM drive and click **Next** to continue.



3. The system will find the setup files and follow the instruction to copy files to your hard disk. The following screen will appear when the software installation has finished. Click **Finish** to complete the installation.



The following screen will ask you to restart your computer. Click **Yes** to reboot. The system will then start to install the Wireless utility automatically. Proceed to Chapter 4 for installation procedure details.



*NOTE. : In most cases, Windows will automatically copy all of the files needed for networking. If Windows asks you for the files and prompts you to input the path to the files, follow the instructions on your screen, click **OK** to continue.*


Driver installation for Windows[®] NT4.0

This installation procedure assumes that you have installed the network component on your computer.


To check whether the network component has been installed, double click the **Network** icon in the **Control Panel**. If it has not been installed, refer to the Windows NT 4.0 installation guide for instructions on installing the component.

Follow the steps below to install the driver.


1. Insert the SpeedStream Wireless PCI Adapter into the PCI slot of the desktop PC as directed and power on the computer. (Refer to Chapter 2 – Hardware installation.)
2. Log in to NT 4.0 as **Administrator**.
3. Double click the **Network** icon in the **Control Panel**, and select the **Adapters** tab as shown in the following screen. Click **Add** to add a new adapter and **OK** to continue.




4. The following screen appears. Click **Have Disk** to continue.




5. The following screen appears. Type **I:\ WinNT40** where **I** is your CD-ROM drive letter. Insert the driver CD-ROM, and click **OK** to continue.



6. After finding the installation file, the *Select OEM Option* window is displayed as follows. Select **Siemens SpeedStream Wireless PCI** and click **OK** to continue.




7. You are returned to the *Network* window. Click **Close** to exit the *Network* window.




8. The Microsoft TCP/IP properties window appears. Select “*Specify an IP address*” or select “*Obtain an IP address from a DHCP Server*” and click **OK** to continue.



9. The following window appears. Please read the description and click **Yes** to continue if you will be using a dynamic IP address.




The following window appears. Click **Yes** to reboot the system. The system will then start to install the Wireless utility automatically. Proceed to Chapter 4 for installation procedure details.



Driver installation for Windows® XP

Follow the steps below to install the SpeedStream Wireless PCI Adapter drivers for Windows XP.


1. Insert the SpeedStream Wireless PCI Adapter into the PCI slot of the desktop PC as directed and power on the computer. (Refer to Chapter 2 – Hardware installation.)
2. After Windows XP detects the SpeedStream Wireless PCI Adapter, the *Found New Hardware Wizard* window appears. Select **Install the software automatically [Recommended]** and insert the driver CD-ROM into CD-ROM drive and click **Next** to continue.



3. Click **Continue Anyway** to continue the installation.



4. Click **Finish** to complete the installation



The system will then start to install the Wireless utility automatically. Proceed to Chapter 4 for installation procedure details.


Chapter 4 – Installing and Using the Wireless Utility

The following sections cover the SpeedStream Wireless PCI Adapter utility installation and configuration.


Installation in Windows

After you have installed the device driver, the system will start to install the SpeedStream Wireless LAN Utility. Follow the steps below to install the utility.


1. Once you see the following screen, click **Next** to continue.




- The screen will show you the default destination chosen by the utility. Click **Next** to continue or click the **Browse** button to select an alternate destination.




- The following screen will add program icons to the Program Folder. You may type a new folder name or select one from the existing folders list. Click **Next** to continue or click **Back** to review or change any settings.




4. The following screen shows the current settings, click **Next** to continue or click **Back** to change the **Destination Folder** in step 3.



5. The following screen shows you the Setup program's progress.




6. Click **Finish** to complete the installation.



Firmware Upgrade

After you have installed the utility, the firmware upgrade screen will appear if the firmware of the card is old or not suitable for running on your environment.

1. Once you see the following screen, click **OK** to continue.



2. The Utility has finished upgrading firmware for the device. Click **OK** to complete the upgrade.



You will then see the SpeedStream Wireless LAN Utility icon in the Windows taskbar

or system tray near the time:

Using the Wireless Utility In Windows XP




SpeedStream Wireless LAN Utility

There are two ways to configure SpeedStream Wireless PCI Adapter. One is SpeedStream Wireless LAN Utility; the other one is Windows Wireless Network Configuration.

Using the Windows Wireless Network Configuration

1. Right-Click the wireless icon and **Exit** SpeedStream Wireless LAN Utility.




2. Click the Windows Wireless Network Configuration icon.




Windows Wireless Network Configuration

3. Click the **Advanced** button.



4. Select "Use Windows to configure my wireless network settings" and click **OK**.




- Click the Windows Wireless Network Configuration icon again to open the Windows Wireless Network Configuration.



Windows Wireless Network Configuration

- Select *SpeedStream* and click the **Connect** button.




- The Windows Wireless Network Configuration will be enabled. Click the Windows Wireless Configure icon again.




Windows Wireless Network Configuration is enabled

- Click **Properties** to start the Windows Wireless Network Configuration.



Using the SpeedStream Wireless LAN Utility

- Exit the SpeedStream Wireless LAN Utility.




- Click the Windows Wireless Network Configuration icon.




Windows Wireless Network Configuration

3. Click the **Advanced** button.



4. **Do not** select "Use windows to configure my wireless network settings"; click **OK**.



5. Select **Start -> All Programs -> SpeedStream Wireless PCI**; click **SpeedStream**

Wireless LAN Utility to restart the SpeedStream Wireless LAN Utility.




6. The SpeedStream Wireless LAN Utility will appear, Double-click the icon to open the configuration utility.



SpeedStream Wireless LAN Utility



7. Click the **Re-Scan** button to start the SpeedStream Wireless LAN Utility. (Refer to *Configuring the SpeedStream Wireless PCI Adapter.*)



Using the SpeedStream Wireless LAN Utility In Windows 95, 98, 2000, NT 4.0 and Me




SpeedStream Wireless LAN Utility icon

Icon	Meaning
	Green: indicates a connection is linked to a wireless network.
	Red: indicates that the wireless LAN card is looking for an available access point.


Double-click the icon to open the SpeedStream Wireless LAN Utility. (Refer to *Configuring the SpeedStream Wireless PCI Adapter.*)

Configuring the SpeedStream Wireless PCI Adapter


1. This screen shows you the status of your current connection. Click **Re-Scan** to search for a wireless connection (the adapter will search for the connection automatically when it is activated).




2. Select the “**Configuration**” tab. The **profile** setting allows you to save configurations in different profiles for different working environments. The default profile will contain the initial configuration setting when you install the Card. Under the **Operating Mode** drop-box, you may choose either Infrastructure or Ad-Hoc. The Infrastructure mode allows a wireless adapter to communicate with a wired network employing an Access Point, while the Ad-Hoc mode allows wireless-to-wireless, peer-to-peer communication. If you choose Infrastructure, the **SSID** should have the same name as the Access Point. If you choose **Ad-Hoc**, all clients should share the same **SSID** name. You may also select which **Transfer Rate** you wish to use: **1**, **2**, **5.5**, **11Mbps** or **Auto Rate**. Under **Power Saving Mode**, you can select **Enabled** to allow your adapter to go to sleep mode while the adapter doesn't detect any data transmission. Or select **Disabled** to make the adapter never go to sleep mode. Click **Apply** to save the settings.




3. Select the “**Site Survey**” tab. The list on the adjacent screen shows you available Access Points and their features. Click on the desired Access Point, then click **Connect** to connect or **Search** to search for more Access Points. Click **OK** when you are finished.




- Click on the “**Encryption**” tab. Under the drop-box, you can choose to have WEP encryption **Disabled, 64-Bit, or 128-Bit**. Wired Equivalent Privacy (WEP) is an encryption scheme used to protect wireless data communication. The Disabled setting prevents the sharing of data with other computers on the WEP network. For data sharing to be enabled, select the level of encryption desired, either 64 or 128-bit.



- Select the “**Advanced**” tab. You can choose the **fragmentation threshold** to define the maximum data frame size your adapter will transmit. When the packet error rate is high, you may set the threshold value to transmit shorter frames. You may select **RTS/CTS threshold** to define when will your adapter send out RTS/CTS frames to reserve bandwidth for transmission. By using the RTS/CTS function, you may request bandwidth from AP to allow you have better chance to send out your data. For the **Security**, it's only applicable while WEP is enabled. For the **Authentication Type**, the current supported algorithms are Open System, Shared Key, and Auto. The algorithm will be invoked when associated to Access Point. To associate to the desired Access Point you must set the same algorithm as the one of the desired Access Point. When select Auto mode, the driver can auto detect the Authentication Type of the Access Point you are going to associate. You can also select **Preamble Type**, which is for framing synchronization. The possible settings are Long and Short. The setting must be the same as the setting of the Access Point you are going to associate.



6. The **“About”** tab shows you copyright and version information about the driver, the configuration utility, and the firmware. Click **OK** to complete the configuration.




Chapter 5 – Installing Network Protocols

Protocols are necessary for computers to be recognized on your network. Windows 2000 users need to check their Windows User Guide for protocol installation.


Installing the Network Protocols for Windows 98 and Millennium

1. From the **Start** Menu, select **Settings** and bring up the **Control Panel**. From the Control Panel, double-click on the **Network** icon.




Note: Before adding any network protocols, verify that the protocol is not already installed. Never install duplicate protocols.


2. Select *Siemens SpeedStream Wireless PCI* from the list and click the **Add** button.



3. Highlight **Protocol** and click the **Add** button.



4. Select **Microsoft** from the list of “Manufacturers” and **TCP/IP** from the list of “Network” Protocols” and click the **OK** button to complete the installation.



Appendix A – FAQ

1. What is the IEEE 802.11 standard?

- The IEEE 802.11 is a wireless LAN industry standard, and the objective of IEEE 802.11 is to make sure that different manufactures' wireless LAN devices can communicate to each other.

2. What is WEP?

- As described in the IEEE 802.11 standard, WEP (Wired Equivalent Privacy) is a data privacy mechanism based on a 40 bit shared key algorithm.

3. My desktop PC cannot recognize the Wireless Network PCI Adapter.

- Check that the Adapter is inserted into the PCI slot of your desktop PC properly (check this when the PC is powered off).
- Also make sure that the PCI controller is enabled in the BIOS of your desktop PC.
- Try installing the card in a different PCI slot.

4. In Infrastructure mode, my desktop PC cannot communicate with the other PCs on the network.

- First, make sure that the SSID is the same as the others PCs.
- Check if WEP is enabled on the Access Point, if it is, set your Adapter's WEP setting the same as that of the Access Point.
- Also check the Access Point's Authentication Type and Preamble Type to ensure those settings match.

5. In ad-hoc mode, my desktop PC cannot communicate with the others PCs on the network.

- Make sure the SSID and the Channel settings are the same as the other wireless stations.
- Check if WEP settings are the same on all wireless stations.
- Check the **Network Properties**, make sure proper protocol is installed and **File and Printer Sharing** is enabled.

Appendix B – Specifications

Standards:	IEEE 802.11b PCI Local Bus 2.1 Compliant
Channels:	11 Channels (US, Canada) 13 Channels (Europe) 14 Channels (Japan)
Antenna:	Dipole antenna with reversed SMA Connector
Frequency:	2.4 to 2.4835GHz (Industrial Scientific Medical Band)
Data Rate:	up to 11Mbps
Operating Ranges:	Indoor (varies depends on the environment): Up to 50M @ 11Mbps Up to 80M @ 5.5Mbps Outdoor (varies depends on the environment): Up to 150M @ 11Mbps Up to 300M @ 5.5Mbps
Temperature:	Operating: 0° ~ 55° C Storage: -25° ~ 70° C
Humidity:	10% to 90% (non-condensing)