



**Sprint Mobile Broadband
USB Modem
by Sierra Wireless
AirCard[®] 595U**



www.sprint.com

© 2007 Sprint Nextel. All rights reserved. SPRINT and other trademarks are trademarks of Sprint Nextel.

Table of Contents

Welcome to Sprint	i
Introduction	ii
Section 1: Basics of Your USB Modem	1
1A. Introducing the Sprint Mobile Broadband USB Modem	3
Your Sprint Mobile Broadband USB Modem	4
CDMA Networks	4
One Touch Activation	5
Package Contents	6
Care and Maintenance	6
About This Guide	7
1B. Getting Started With Your USB Modem	8
Getting Started	9
System Requirements	9
The USB Modem Software	11
1C. Getting Help	12
Visiting the Sprint Web Site	13
Contacting Sprint Customer Service	13
Troubleshooting	13
Section 2: Installing the USB Modem on a Windows Computer	15
2A. Installing the Software on a Windows Computer	17
Getting Started	18
2B. Inserting and Removing the USB Modem	21
Inserting the USB Modem	22
Removing the USB Modem	22
2C. Setting Up Service (Windows)	23
Activating and Using Sprint Service	24
Preactivated USB Modem	24
Non-preactivated USB Modem: One Touch Activation	25
Non-preactivated USB Modem: Activation Wizard	25
Data Provisioning (IOTA)	27

Section 3: Using the USB Modem on a Windows Computer	29
3A. Your USB Modem: The Basics	31
Sprint Connection Manager	32
Starting Sprint Connection Manager	32
Starting Sprint Connection Manager Automatically	33
Sprint Connection Manager Window	33
Connection States (Mobile Broadband Window)	38
GPS Status (GPS Receiver Window)	41
System Tray Connection States	42
Determining the Type of Coverage	43
Attaching an External Antenna	43
Sprint Location Services	43
Powering the USB Modem On and Off	45
Controlling the Sprint Connection Manager Window	46
Launching a Sprint Power Vision or Sprint Vision Connection	50
Viewing the Amount of Data Transferred	53
Ending a Connection	54
Online Help	54
Displaying Your Phone Number	55
Security	55
Accessing Links	58
Uninstalling the Sprint Connection Manager Software	59
3B. Menu Options	60
Sprint Connection Manager Menu	61
System Tray Menu	63
3C. Changing Sprint Connection Manager Settings	64
Settings Window	65
General Settings	66
Sprint Mobile Broadband Settings	68
Sprint Location Services Settings	71
3D. Tools	74
Viewing the Connection History	75
Viewing Alerts	76
Running Diagnostics	77
Updating the Software	79
About Sprint Mobile Broadband	80

3E. Frequently Asked Questions (Windows)	81
What is Sprint Connection Manager?	83
If the connection is “always on,” am I always being billed?	83
How fast is the connection with Sprint Connection Manager?	83
How can I optimize my settings to achieve the fastest speeds and conserve data when accessing my corporate network?	84
Can I connect to a dial-up account like AOL or EarthLink?	84
Once I connect to the network, how do I access my corporate network through a VPN?	84
Why won't my laptop go into hibernation mode when using my Sprint Mobile Broadband USB Modem?	84
What is LBS?	84
What is GPS?	85
What is enhanced Local Search?	85
How do I get the enhanced Local Search feature?	85
Where do I find the enhanced Local Search feature?	85
How do I use the enhanced Local Search feature?	86
Where can I use GPS?	86
What is GPS User Plane?	86
What is GPS Control Plane?	86
How do I enable/disable GPS?	87
Will GPS work when Privacy is set to ON?	87
Can I use Sprint Location Services if I have enabled NDIS?	87
Do I need a GPS subscription to use GPS?	87
Location-Based Services limitations	88
What GPS mode options are supported?	88
What is GPS Basic?	88
What is GPS Premium?	89
What is the difference between GPS Basic and GPS Premium?	89
What is a GPS application?	89
What is NMEA?	90
How do I configure a GPS application to use my GPS-capable device?	90
When do I need to use NMEA?	90
How do I start and stop NMEA?	91
How do I configure my NMEA port?	91

3F. Troubleshooting Tips (Windows)	92
Problems, Causes, and Solutions	93
GO Button Is Unavailable	94
Searching for Service	94
Cannot Connect to the Network	95
PWR LED Goes Off and On, and Then Stays Red	95
Sprint Location Services Aren't Working or Don't Seem to Be Available	96
Could Not Prepare Data Services	97
Unable to Prepare Data Services	97
Sprint Connection Manager Stops Working After Upgrading Windows	97
Section 4: Installing and Using the USB Modem on a Mac	99
4A. Installing and Using the Software on a Mac Computer	101
Getting Started	102
Installing the Software on a Mac	103
Installing the Drivers	105
USB Modem Activation and Provisioning	107
Connecting to the Sprint Network	110
Icons and Text in Watcher Lite	110
Menu Options	111
Attaching an External Antenna	111
Removing Your USB Modem	112
Sprint Service Areas	112
Manage Your Account Online	112
Troubleshooting Tips (Mac)	113
Frequently Asked Questions	114
Section 5: Technical Specifications and Regulatory Information	117
5A. Technical Specifications	119
LED Operation	120
Radio Frequency and Electrical Specifications	121
Software Specifications	122
Environmental Specifications	123
Mechanical Specifications	123

5B. Regulatory Information	124
Regulatory Notices	125
Patents	127
Trademarks	128
Copyright	128
Limitation of Liability	129
Additional Information and Updates	129
Section 6: Safety Information and Terms & Conditions	131
6A. Safety and Notices	133
Important Notice	134
Safety and Hazards	134
6B. Terms and Conditions	135
Subscriber Agreement/General Terms and Conditions of Services	136
Section 7: Glossary and Index	153
7A. Glossary	155
7B. Index	159

Welcome to Sprint

We are committed to bringing you the best wireless technology available, and we built our network right from the start, so no matter where you are on the network, all your services will work the same.

When it comes to mobile connectivity, the Sprint Mobile Broadband USB modem offers more freedom than ever before. No wires, no cables, just access to your data when you need it. The power of the Internet and company data is truly at your fingertips.

This guide will familiarize you with our technology and with Sprint Connection ManagerSM software with enhanced Local Search (for Windows computers), Watcher[®] Lite software (for Mac computers), and your new Sprint Mobile Broadband USB modem through simple, easy-to-follow instructions.

Welcome and thank you for choosing Sprint.

Introduction

This User's Guide introduces you to Sprint service and all the features of your new wireless Sprint Mobile Broadband USB modem. It's divided into seven sections:

- ♦ **Section 1: Basics of Your USB Modem**
- ♦ **Section 2: Installing the USB Modem on a Windows Computer**
- ♦ **Section 3: Using the USB Modem on a Windows Computer**
- ♦ **Section 4: Installing and Using the USB Modem on a Mac**
- ♦ **Section 5: Technical Specifications and Regulatory Information**
- ♦ **Section 6: Safety Information and Terms & Conditions**
- ♦ **Section 7: Glossary and Index**

Throughout the guide, you'll find tips that highlight special shortcuts and timely reminders to help you make the most of your USB modem and services.

The Table of Contents and Index will help you locate specific information quickly. The Sprint Connection Manager software (for Windows) includes extensive online help to guide you through the steps to use each feature.

You'll get the most out of your new Sprint Mobile Broadband USB modem if you read each section of this document. However, if you'd like to get right to a specific feature, simply go to that page. Follow the instructions in that section and you'll be ready to use your USB modem in no time.

Tip:	You can view this guide online or print it to keep on hand. If you're viewing it online, simply click a topic in the Table of Contents, a page number in the Index, or any page or section reference. The PDF automatically displays the appropriate page.
-------------	--

Basics of Your USB Modem



Introducing the Sprint Mobile Broadband USB Modem

In This Section

- ◆ Your Sprint Mobile Broadband USB Modem
 - ◆ CDMA Networks
 - ◆ One Touch Activation
 - ◆ Package Contents
 - ◆ Care and Maintenance
 - ◆ About This Guide
-

This section introduces the basic features and functions of your Sprint Mobile Broadband USB modem, what is included with your USB modem, and how to use this guide to get you started.

Your Sprint Mobile Broadband USB Modem

The Sierra Wireless AirCard® 595U USB modem is a dual-band wireless USB modem. It enhances the functionality of your mobile or desktop computing devices by adding wireless data.

This USB modem allows you to do the following (subject to feature availability), without using a landline network or phone:

- Easily activate your account (One Touch Activation)
- Connect to the Internet, VPNs, and corporate networks
- Send and receive large email messages
- Use Sprint Location Services (Windows® only)
- Conduct Internet-based videoconferencing
- Access streaming real-time media
- Play games online

Your Sprint Mobile Broadband USB modem fits into a USB slot (available on most notebook and desktop computers).

CDMA Networks

The USB modem operates over a type of wireless network called CDMA (Code Division Multiple Access).

To use the USB modem, you need an account that gives you access to the CDMA network. Some features described in this manual may not be available with your account. For details of the services and accounts available, contact Sprint (page 13).

There are CDMA networks that operate in the frequency bands supported by the USB modem throughout North America. However, each service provider operates a network that covers a limited geographical area within the overall CDMA coverage area.

The fee for service may be higher when you are roaming (connecting to a network other than Sprint).

Sprint has “roaming” agreements with other service providers, so that you can get service outside of the coverage area of the network. (There may be additional charges for roaming service.)

CDMA technology provides a variety of connectivity features, depending on your Sprint account (actual speed depends on the network conditions):

- 1xEV-DO Rev. A (Sprint Power VisionSM) supports Internet connections with data rates up to 3.1 Mbps (downlink from the network) and 1.8 Mbps (uplink to the network). Average data rates are 600 kbps - 1.4 Mbps (downlink from the network) and 350-500 kbps (uplink to the network).
- 1xEV-DO Rev. 0 (Sprint Power Vision) supports Internet connections with data rates up to 2.4 Mbps (downlink from the network) and 153 kbps (uplink to the network). Average data rates are 400-700 kbps (downlink from the network) and 40-80 kbps (uplink to the network).
- 1X (Sprint Vision) supports Internet connections with data rates up to 153 kbps. Average data rates are 40-80 kbps.

Tip: More information about CDMA networks is available on the CDMA Development Group Web site, www.cdg.org.

Tip: For pointers on optimizing your settings, see “How can I optimize my settings to achieve the fastest speeds and conserve data when accessing my corporate network?” on page 84.

One Touch Activation

Where supported by the network, One Touch Activation (IOTA 2.4) lets you easily activate your USB modem. When prompted, you simply click “**Yes**” to indicate that you’d like the network to autoprogram your USB modem. If this is successful, you are ready to connect to the network.

Package Contents

Your Sprint Mobile Broadband USB modem package contains the following components:

- Sprint Mobile Broadband USB modem by Sierra Wireless (Model AirCard 595U)
- Rechargeable modem battery
- USB extension cable
- Getting Started guide
- Installation CD containing the Sprint Connection Manager software (for Windows computers) and the Watcher Lite software (for Mac computers), warranty information, and this document

Care and Maintenance

As with any electronic device, the USB modem must be handled with care to ensure reliable operation. Follow these guidelines in using and storing the USB modem:

- The USB modem should fit easily into your USB slot. Forcing the USB modem into a slot may damage the connector pins.
- Protect the USB modem from liquids, dust, and excessive heat.
- When not installed in your computer, store the USB modem in a safe place.
- Remove the USB modem before storing or transporting your computer.
- When inserting or removing the USB modem, always grip it by the sides rather than the end, as this prevents damage to the USB modem.
- To avoid the risk of explosion, use the same battery model when replacing the battery. Properly dispose of the used battery.
- The USB modem's USB connector is adjustable to three positions. Do not force the hinge past the last position—this may break the connector. For more information, see the picture on page 19.
- Do not use the USB modem with a handheld computer; it is designed only for notebook or desktop computers running Windows Vista, Windows XP, Windows 2000, or Mac OS X.

- Do not handle or operate the USB modem while driving or operating a vehicle. Doing so may distract you from properly operating the vehicle. In some states and provinces, operating communication devices while in control of a vehicle is a criminal offense.

About This Guide

This user's guide is designed to provide you with all the information you need to install and use your USB modem by Sierra Wireless (AirCard 595U).

Note:	The comprehensive Getting Started guide that comes with the Sprint Mobile Broadband USB modem should be sufficient for most installations.
--------------	--

- **Section 1** (which you are reading) gives you an overview of the USB modem (AirCard 595U).
- **Section 2** provides step-by-step instructions for installing the USB modem and Sprint Connection Manager software on a Windows computer (page 15).
- **Section 3** provides step-by-step instructions on using the USB modem on a Windows computer (page 29).
- **Section 4** provides step-by-step instructions for installing and using the USB modem on a Mac computer (page 99).
- **Section 5** provides electrical, radio frequency, and other parameters of the USB modem for those who require technical information, as well as regulatory information (page 117).
- **Section 6** provides important safety and liability information and the Terms and Conditions of use for the Sprint Mobile Broadband USB modem (page 131).
- **Section 7** include a glossary (page 155) and index (page 159).

Getting Started With Your USB Modem

In This Section

- ◆ Getting Started
 - ◆ System Requirements
 - ◆ The USB Modem Software
-

This section describes the basics of getting started with your USB modem, and how to look after your USB modem.

Getting Started

CAUTION:	Do not insert the USB modem into the USB slot until you have installed and run the software, and the software displays “No device.”
-----------------	---

Before you begin using your USB modem, you must:

1. Check that your computer has the system requirements listed below (“System Requirements”).
2. Install the Sprint Connection Manager software (for Windows) or the Watcher Lite software (for the Mac), located on the installation CD, onto your computer. See page 18 (Windows) or page 102 (Mac).
3. Start the software.
4. Insert the battery into the USB modem, and insert the USB modem into your computer; this installs the drivers for the USB modem.
5. Charge the battery for approximately two hours.
6. Activate your Sprint account and configure the USB modem to use your account (unless the USB modem has been preactivated). See page 24 (Windows) or page 107 (Mac).

System Requirements

The Sprint Mobile Broadband USB modem is supported on:

- Windows Vista.
- Windows XP with Service Pack 2.
- Windows 2000 with Service Pack 4 and high encryption support. (See “High Encryption Requirements (Windows)” on page 10.)
- Mac OS X version 10.4 or newer. For instructions on installing and using the software, see “Installing and Using the Software on a Mac Computer” on page 101.

To install and run the USB modem and accompanying Sprint Connection Manager software on a Windows computer, you will need the minimum system resources shown in the following table.

USB slots	One USB slot. (If your computer's USB slot is vertical, use the USB extension cable. Do not use the USB modem or USB extension cable in a USB hub or in a USB slot on a keyboard.)
Optical drive	CD-ROM
Memory	32 MB
Disk space	32 MB

High Encryption Requirements (Windows)

Depending on your configuration, an IOTA (Internet Over The Air) session may automatically start as part of the installation/activation process. IOTA requires high-security 128-bit encryption to establish a secure Internet connection to the CDMA network. (For more information, see "Data Provisioning [IOTA]" on page 27.)

If you are running Windows Vista or Windows XP, your computer should already include high-security 128-bit encryption.

If you are running Windows 2000 with Internet Explorer

1. Ensure you have installed the Windows 2000 High Encryption Pack: in Internet Explorer, select **Help > About Internet Explorer**.

If you see "Cipher Strength: 128-bit," then the High Encryption Pack is installed. Proceed to step 2.

If the High Encryption Pack is not installed, download and install it (www.microsoft.com/windows2000/downloads/recommended/encryption).

2. If your version of Internet Explorer is earlier than 5.5, download and install the latest version (www.microsoft.com/windows/ie/downloads).

If you are running Windows 2000 with Netscape Communicator

Ensure your version of Netscape Communicator is 4.7 or higher.

To verify that your version supports 128-bit encryption:

1. In Navigator, select **Help > About Navigator**.

– or –

In Netscape Communicator, select **Help > About Communicator**.

2. See the section “Contains encryption software from RSA Data Security, Inc.”

If the next paragraph states “This version supports U.S. security,” you have 128-bit security.

If the paragraph states that you have International security, you have 40-bit security. Download a version that supports 128-bit security.

The USB Modem Software

The Sprint Mobile Broadband USB modem comes with the following software:

- Sprint Connection Manager, which allows you to manage the USB modem’s actions and monitor your connections on a Windows computer
- Watcher Lite, which allows you to manage the USB modem’s actions and monitor your connections on a Mac computer
- The driver software that forms the interface between the USB modem and your Windows or Mac operating system

Before you insert the USB modem for the first time, you must install and then run the Sprint Connection Manager (Windows) or Watcher Lite (Mac) software. The driver software is installed the first time you insert the USB modem into your computer.

Detailed instructions are provided beginning on page 18 (for Windows) and page 102 (for Mac).

Getting Help

In This Section

- ♦ Visiting the Sprint Web Site
 - ♦ Contacting Sprint Customer Service
 - ♦ Troubleshooting
-

This section describes where you can find more information on Sprint services, options, and troubleshooting problems you have encountered.

Visiting the Sprint Web Site

Stop by www.sprint.com and log on to get up-to-date information on Sprint services, options, and more.

You can also:

- Review coverage maps.
- Access your account information.
- Add additional options to your service plan.
- Purchase accessories.
- Check out frequently asked questions.
- And more.

Contacting Sprint Customer Service

You can reach Sprint Customer Service by:

- Logging on to your account at www.sprint.com.
- Calling us toll-free at **1-888-788-4727** (business use) or **1-888-715-4588** (personal use).
- Writing to us at Sprint Customer Service, P.O. Box 8077, London, KY 40742.

Troubleshooting

The Online Help for Sprint Connection Manager on your Windows computer (see page 54) includes descriptions of most common error messages. Look in the Contents under Troubleshooting.

For help with other problems:

- See “Troubleshooting Tips (Windows)” on page 92 or “Troubleshooting Tips (Mac)” on page 113.
- Consult the Sierra Wireless Web site at www.sierrawireless.com, where you will find an extensive knowledge base that can be searched to address most problems, and the Installation Troubleshooting wizard (in the Support & Download section).
- Contact Sprint as noted above.

Installing the USB Modem on a Windows Computer



Installing the Software on a Windows Computer

In This Section

Getting Started

This section explains how to install your Sprint Connection Manager software on a Windows computer.

The process may vary, depending on the version of Windows that you are running.

(If you're using your USB modem on a Mac computer, see "Installing and Using the Software on a Mac Computer" on page 101.)

Getting Started

Note:	For comprehensive instructions on installing the Sprint Connection Manager software and activating the USB modem, see the Getting Started guide.
--------------	--

Before you can use your USB modem, you must first install the USB modem's software and configure the USB modem for your computer. The installation process consists of:


- **Software installation** - Installing the Sprint Connection Manager software on your computer (described in this section).
- **Insertion of the rechargeable battery into the USB modem**
- **USB modem insertion and driver installation** - Starting the Sprint Connection Manager software and inserting the USB modem, which automatically installs the drivers on your computer.
- **USB modem activation and provisioning** - Activating your Sprint account and configuring the USB modem to use your account. (See "Setting Up Service [Windows]" on page 23.)

CAUTION:	Do not insert the USB modem into your computer's USB slot before installing the software.
-----------------	---

Note:	<p>Windows Vista and Windows 2000 users: You must log in with administrative privileges to install the software and drivers.</p> <p>Windows XP users: You may need to log in with administrative privileges, depending on your Windows configuration.</p> <hr/> <p>Before beginning the installation process, it is recommended that you close all open applications.</p>
--------------	---


To install the software on your computer:

1. If the installation CD is not already in your CD-ROM drive, insert it.
The CD should autostart.
If the CD does not autostart, select **Start > Run** and enter **d:\SCMInstaller.exe**, where **d** is the drive letter of your CD-ROM drive.
2. Use the **Next** and **Back** buttons to navigate through the wizard, noting the following:
 - You must select **I accept the terms in the license agreement** to indicate your acceptance of the terms of the license agreement to proceed with the installation.

- Use the default settings for the Destination Folder unless you have special requirements and an advanced understanding of computer configuration. (The Destination Folder dictates where the software is installed.)
3. When the “Installation Complete!” window is displayed, click **Finish**.
 4. Run Sprint Connection Manager.
(Double-click the program’s icon [] on your desktop.)
 5. Wait for Sprint Connection Manager to start up and display “No device...”.
 6. Slide the front panel off the USB modem.
 7. Hold the battery so that the side with two white arrows faces up and the gold contact points on the end of the battery line up with the gold contact points on the USB modem. Insert the battery into the USB modem.

Warning: To avoid the risk of explosion, use the same battery model when replacing the battery. Properly dispose of the used battery.


8. Slide the front panel onto the USB modem until the panel clicks into place.
9. Slide the lever on the bottom of the USB modem in the direction indicated by the triangle to release the USB modem's USB connector.
10. Adjust the USB connector to the desired angle. (The USB connector is adjustable to three positions—approximately 90, 135, and 160 degrees. Do not force the hinge past the last position—this may break the connector.)



11. Gripping both sides of the USB modem, insert it into your computer’s USB slot. Alternatively, you can attach the USB extension cable to your computer’s USB slot, and then connect the USB modem to the USB extension cable.

Note: If your computer’s USB slot is vertical, use the USB extension cable. Do not insert the USB modem or USB extension cable into a USB hub or a USB slot on a keyboard.

Warning: If the orientation of your computer's USB slot or the thickness of your computer are such that pressure is applied to the USB modem's end or side (as shown by the red circles in the drawings below), you may damage the USB modem or your computer. In such cases, do not insert the USB modem directly into your computer's USB slot; use the USB extension cable instead.



Windows detects the USB modem and installs the drivers for it. This may take a few minutes. Once completed, Sprint Connection Manager should display “Disconnected” (if your USB modem is preactivated) or the “One Touch Activation” window, or automatically start the Activation Wizard.

The PWR LED is lit.

12. Allow the battery to charge for approximately two hours before closing the window or making a selection in it.

Note: If you have an older version of Sprint Connection Manager and are experiencing problems during installation, use the Add/Remove Programs Utility (see page 59) to remove the older version of Sprint Connection Manager. Then reinstall the current version of Sprint Connection Manager from the Installation CD.

13. If your USB modem is preactivated or if you have activated it at the time of purchase, proceed to “Preactivated USB Modem” on page 24.
14. Proceed to “Non-preactivated USB Modem: One Touch Activation” on page 25 if your USB modem has not been activated.

Inserting and Removing the USB Modem

In This Section

- ♦ Inserting the USB Modem
 - ♦ Removing the USB Modem
-

This section describes how to properly insert the USB modem and remove it from your computer.

Inserting the USB Modem

To insert the USB modem into a notebook or desktop computer:

- ▶ Holding the USB modem by its sides, insert it into the USB slot of your computer.

Alternatively, you can attach the USB extension cable to your computer's USB slot, and then connect the USB modem to the USB extension cable.

Note:	If your computer's USB slot is vertical, use the USB extension cable. Do not insert the USB modem or USB extension cable into a USB hub or a USB slot on a keyboard.
--------------	--

When you insert the USB modem into a Windows computer, the following should occur:

- The first time the USB modem is inserted, Windows detects the USB modem and installs the drivers for it. This may take a few minutes. Once completed, Sprint Connection Manager should display "Disconnected." To connect to the network, click **GO** in the **Mobile Broadband** window.
- If sound effects are enabled, the computer beeps.

The USB modem is powered as soon as you insert it.

Removing the USB Modem

IMPORTANT!	When inserting or removing your USB modem, always grip the USB modem by its sides, as this prevents damage to the USB modem.
-------------------	--

To remove the USB modem:

1. Exit Sprint Connection Manager if it is open (page 49).
2. Remove the USB modem from your computer's USB slot by gripping both sides of the USB modem and pulling straight out.

Setting Up Service (Windows)

In This Section

- ♦ **Activating and Using Sprint Service**
 - ♦ **Preactivated USB Modem**
 - ♦ **Non-preactivated USB Modem: One Touch Activation**
 - ♦ **Non-preactivated USB Modem: Activation Wizard**
 - ♦ **Data Provisioning (IOTA)**
-

This section walks you through setting up service for your Sprint Mobile Broadband USB modem after you have installed the Sprint Connection Manager software (page 18) and inserted the USB modem.

Activating and Using Sprint Service

Before using your USB modem, you must have a Sprint wireless network account set up. The process of setting up an account is called activation.



When the USB modem is inserted and Sprint Connection Manager is started, it will detect whether the USB modem has been configured with an account (“preactivated”). If it has not, the “One Touch Activation” window or the Activation Wizard starts automatically.

Preactivated USB Modem

If you received your USB modem in the mail or purchased it at a Sprint Store, it probably has already been activated.

To prevent unauthorized use, preactivated USB modems may have been set with a security lock. If so, Sprint Connection Manager displays the message “Device locked.”

To unlock your USB modem:


1. Click the  icon. (If is not visible, in the **Mobile Broadband** window click  to expand Sprint Connection Manager.)
2. In the Enter User Lock Code window, enter your four-digit lock code, and click **OK**. For security purposes, the code is not visible as you type.

Tip:	If you can't recall your lock code, try using the last four digits of your USB modem's phone number (MDN). If this doesn't work, call Sprint Customer Service at 1-888-788-4727 (business use) or 1-888-715-4588 (personal use).
-------------	--

After unlocking your preactivated USB modem, it is ready for use. See “Using the USB Modem on a Windows Computer” on page 29.

Non-preactivated USB Modem: One Touch Activation

If the “One Touch Activation” window has been displayed, click **Yes** to indicate that you’d like to have the network autoprogram your USB modem.



Sprint Connection Manager will display “Updating User Profile.”

If One Touch Activation is successful, Sprint Connection Manager will then display “Disconnected,” after which you are ready to connect to the network (click **GO**). To learn about using the software, see “Using the USB Modem on a Windows Computer” on page 29.

If One Touch Activation was not successful, a message window is displayed. To activate your USB modem, use the Activation Wizard (see the next section).

Non-preactivated USB Modem: Activation Wizard

If your USB modem is not preactivated, please see the Getting Started guide included with your USB modem.

Note:	If you successfully activated your USB modem through the “One Touch Activation” window (page 25), skip these steps and go directly to “Using the USB Modem on a Windows Computer” on page 29.
--------------	---

The Activation Wizard will guide you through the activation process.

To set up your account, you will be contacting Sprint.

Before you call Sprint, have these things ready:

- A phone
- Your USB modem
- The city and state where the USB modem will be primarily used
- A pen and paper to write down your account information. Your package includes a printed Getting Started guide, where you can record this information.

When you call Sprint, Sprint Customer Service will help you select your service plan and guide you through the activation process. They will also provide you with this information:

- Your USB modem's activation code (gives you access to configure the account)
- Your USB modem's phone number (MDN)
- Your USB modem's MSID (Mobile System ID) code, used for WLNP (Wireless Local Number Portability) and to determine whether you are "home" or "roaming"

Stepping Through the Activation Wizard

If the Activation Wizard has not started automatically:

1. Ensure the USB modem is inserted, and Sprint Connection Manager is running. If Sprint Connection Manager is not running, select:
(Windows Vista or Windows XP) **Start > All Programs > Sprint > Sprint Mobile Broadband (Sierra)**.
(Windows 2000) **Start > Programs > Sprint > Sprint Mobile Broadband (Sierra)**.
Sprint Connection Manager should display "Disconnected."
2. If Sprint Connection Manager displays "Device locked," unlock the USB modem (page 57).
3. If Sprint Connection Manager displays "Device powered off," power the USB modem on (page 40).
4. Start the Activation Wizard: select **MENU > Settings > Sprint Mobile Broadband - Sierra Wireless > Activation Wizard**.

Once the Activation Wizard is running:

1. To begin activation of the USB modem, click **Next**.
2. Call Sprint at the appropriate phone number listed on the screen. Click **Next**.
3. Give the account representative your ESN (Electronic Serial Number) or MEID (Mobile Equipment Identifier) number as displayed by the Activation Wizard. Enter the activation code provided by the account representative and click **Next**.
4. Enter the phone number (no spaces or hyphens) and, if not the same value as the phone number, the MSID value given by the account representative, and then click **Next**.
A confirmation window will be displayed.
5. Confirm with the service representative that the information is correct. If it is, click **Yes**. If it isn't, click **No**, and re-enter the information.

6. Click **Finish** to close the Activation Wizard.
7. Wait a few moments for the USB modem to automatically reset. Depending on your configuration, an IOTA session may automatically start. (See “Data Provisioning [IOTA]” on page 27.)

After Sprint sets up your account on the network, your USB modem should be configured and ready for use. To learn about using the software, see “Using the USB Modem on a Windows Computer” on page 29.

Data Provisioning (IOTA)

IOTA (Internet Over The Air), supported by some service providers (including Sprint), is an automated feature to perform account setup for you by making a connection to the CDMA network and using a secure Internet connection to download account parameters to your USB modem. To make this secure connection, IOTA requires that your computer support 128-bit encryption. (See “High Encryption Requirements (Windows)” on page 10.)

Depending on your configuration, the first time Sprint Connection Manager detects the activated USB modem, an IOTA session may automatically start, during which status messages (“Updating User Profile...”) are displayed.

After this first activation, there may be changes to your account that require updating the parameters in the USB modem. If this is needed:

1. In the Device Info & Diagnostics window (page 77), click **Update Data Profile**. (If this button is not displayed, remove and reinsert the USB modem.)
2. In the IOTA Provisioning window, click **Yes**.

Your USB modem then retrieves the updates to your data services account. Once the updates are successful, Sprint Connection Manager is displayed (“Disconnected”). You can now connect to the network.

Using the USB Modem on a Windows Computer



Your USB Modem: The Basics

In This Section

- ◆ Sprint Connection Manager
 - ◆ Starting Sprint Connection Manager
 - ◆ Starting Sprint Connection Manager Automatically
 - ◆ Sprint Connection Manager Window
 - ◆ Connection States (Mobile Broadband Window)
 - ◆ GPS Status (GPS Receiver Window)
 - ◆ System Tray Connection States
 - ◆ Determining the Type of Coverage
 - ◆ Attaching an External Antenna
 - ◆ Sprint Location Services
 - ◆ Powering the USB Modem On and Off
 - ◆ Controlling the Sprint Connection Manager Window
 - ◆ Launching a Sprint Power Vision or Sprint Vision Connection
 - ◆ Viewing the Amount of Data Transferred
 - ◆ Ending a Connection
 - ◆ Online Help
 - ◆ Displaying Your Phone Number
 - ◆ Security
 - ◆ Accessing Links
 - ◆ Uninstalling the Sprint Connection Manager Software
-

Sprint Connection Manager


Sprint Connection Manager is the application that allows you to manage and monitor, on your Windows computer, the high-speed Sprint Power Vision (1xEV-DO) and Sprint Vision (1X) connection to the Sprint network. You use Sprint Connection Manager to:



- Determine your signal strength and other network connection parameters (page 33).
- Initiate data calls (page 50).
- Access Sprint Location Services (page 43).
- View call statistics (page 75) and messages (page 38).
- Customize features and options (page 65).

Tip:	Without running Sprint Connection Manager, you can make a data connection simply by starting whatever application you want to use (such as your Web browser or email application). Prerequisites: you must have previously selected, in Sprint Connection Manager, Enable Network Adapter (NDIS) (page 69). However, to make use of other features of the USB modem (including Sprint Location Services), you must run Sprint Connection Manager.
-------------	--

Starting Sprint Connection Manager

To start Sprint Connection Manager:

1. Ensure the USB modem is inserted into your computer's USB slot.
2. Double-click the program's icon () on your desktop, or, from the **Start** menu on your Windows desktop, select:
(Windows Vista or Windows XP) **All Programs > Sprint > Sprint Mobile Broadband (Sierra)**.
(Windows 2000) **Programs > Sprint > Sprint Mobile Broadband (Sierra)**.

When Sprint Connection Manager is running, it places an icon () in the system tray, usually at the right end of the taskbar. If Sprint Location Services are supported and enabled, then a second icon () is displayed in the system tray. (See page 42.)

Tip:	You can also set Sprint Connection Manager to launch automatically whenever Windows starts. (See "Starting Sprint Connection Manager Automatically" on page 33.)
-------------	--

Starting Sprint Connection Manager Automatically

To set Sprint Connection Manager to start automatically whenever Windows starts:


- ▶ From the General option in the Settings window (page 66), select **Launch when Windows starts**.

Note: Changes to this setting apply only after you restart Windows.


Tip: You can also set the connection to launch automatically whenever available. (See “**GO automatically when ready**” on page 69.) These settings provide an “always-on” connection, as long as you have network coverage.

Sprint Connection Manager Window


If Sprint Location Services and the **GPS Receiver** window are not supported or not enabled (page 72), then only the **Mobile Broadband** window is displayed:





If Sprint Location Services and the **GPS Receiver** window are supported and enabled, then the **GPS Receiver** window is additionally shown below the **Mobile Broadband** window:












Mobile Broadband Window




The text and icons in the **Mobile Broadband** window indicate the connection state (page 38), and, when disconnected, whether the USB modem is locked  or unlocked  (page 55).

The **Mobile Broadband** window may display, depending on the connection state, some of the following icons:

	<p>CDMA network signal strength, indicated by the number of bars.</p> <p>The ToolTip indicates the type of coverage you have (for example, 1X and/or 1xEV-DO), and the signal strength, in dBm.</p>
	<p>You are roaming. Roaming charges may apply.</p> <p>Note: Sprint Location Services may not be available when roaming.</p> <p>If this icon is flashing, you are in a non-preferred roaming area, and you may not be able to complete your calls.</p> <p>Tip: You can change the roaming option ("Roam Mode;" for example, to disable roaming, select Sprint), and also enable the Roam Guard feature (from the Sprint Mobile Broadband Settings window; page 68).</p>
	<p>1xEV-DO Rev. A transmit/receive icon: a data connection is active.</p> <p>The up arrow is animated (for example: ) when data is being transmitted to the network.</p> <p>The down arrow is animated (for example: ) when data is being received from the network.</p>

	<p>1xEV-DO Rev. 0 transmit/receive icon: a data connection is active.</p> <p>The up arrow is animated (for example: ↑↓) when data is being transmitted to the network.</p> <p>The down arrow is animated (for example: ↓↑) when data is being received from the network.</p>
	<p>1xEV-DO (Rev. 0 and Rev. A) transmit/receive icon: the data connection is dormant. The up and down arrows are gray.</p>
	<p>1X transmit/receive icon: a data connection is active.</p> <p>The up arrow is black and animated when data is being transmitted to the network.</p> <p>The down arrow is black and animated when data is being received from the network.</p>
	<p>1X transmit/receive icon: the data connection is dormant. The up and down arrows are gray.</p>







GPS Receiver Window



The text and icons in the **GPS Receiver** window indicate the following (described in the table that follows):

- GPS status
- GPS/Privacy status
- Satellite status
- Location information (when the **GPS Receiver** window is expanded)










The **GPS Receiver** window may display, depending on the GPS/Privacy status and satellite status, some of the following icons and text. The icons' ToolTips in Sprint Connection Manager provide more information.

	<p>Privacy is on (you have not accepted the Privacy Consent Agreement). Sprint Location Services are not available.</p> <p>To use Sprint Location Services, in the Sprint Location Services settings window, select Enable Location Services.</p>
	<p>Privacy is off. GPS is available. For the status of GPS, see the satellite status icon (described below).</p>
	<p>GPS is available, but off. The satellite and the vertical bars are not colored.</p> <p>To use GPS, click GO in the GPS Receiver window.</p>
	<p>GPS is on, but not usable (searching for satellites). The vertical bars are not colored.</p> <p>The ToolTip indicates the number of satellites.</p>
	<p>GPS is on and is usable, but with lower accuracy. The vertical bars are colored.</p> <p>The ToolTip indicates the number of satellites acquired.</p>
	<p>GPS is on and is usable, with better accuracy. The vertical bars are colored.</p> <p>The ToolTip indicates the number of satellites acquired.</p>
Latitude	Latitude, in decimal degrees. For example, -17.123°
Longitude	Longitude, in decimal degrees. For example, 23.023°
HEPE	Accuracy (horizontal/vertical precision), in feet.
Speed	Current speed, in miles per hour.

Satellites	Number of satellites used in the current GPS fix.
Altitude	Altitude, in feet.
Last fix	Date/time that the GPS values were last acquired.
GPS Port	The current NMEA port. (For information on NMEA, see “What is NMEA?” on page 90.) This information is useful when configuring a GPS application to use your GPS-capable device (page 90).
Heading	Current direction, in degrees.

Common items

Sprint Connection Manager may display, depending on the settings of your USB modem, the following buttons and text:

- **Menu** or the  button — Displays the Sprint Connection Manager menu (page 61).
-  (upper right corner of the window) — Minimizes Sprint Connection Manager (page 49).
-  — Exits Sprint Connection Manager (page 49).
-  (**Mobile Broadband** window) — Expands the **Mobile Broadband** window (page 46) and displays the amount of data transferred (when Connected), or, when disconnected, the lock status of your USB modem (locked  or unlocked ).
-  (Displayed when the **Mobile Broadband** window is expanded) — Hides the amount of data transferred and the lock status of your USB modem (page 46).
- **GO (Mobile Broadband window)** — Starts the Sprint Power Vision or Sprint Vision connection (page 50).
- **Stop (Mobile Broadband window)** — Ends the data connection (visible when a connection is established; page 54); also ends the NMEA output.
-  (**GPS Receiver** window) — Expands the **GPS Receiver** window (page 46) and displays location information.
-  (Displayed when the **GPS Receiver** window is expanded) — Hides the location information.

- **GO** (GPS Receiver window) — Starts the NMEA output (page 91).
- **Stop** (GPS Receiver window) — Ends the NMEA output.

Connection States (Mobile Broadband Window)


The **Mobile Broadband** window can display various connection and interaction states, including:

- No device
- Initializing
- Updating User Profile... (See “Data Provisioning [IOTA]” on page 27.)
- Searching for service...
- Disconnected
- Connecting
- Connected
- Connected to NDIS
- Device locked
- Device powered off

Note: The system tray icon also indicates the connection state (page 31).

No device

Sprint Connection Manager did not detect the USB modem. The **GO** button is unavailable.



Insert the USB modem. If it is already inserted, remove and reinsert it; wait a few moments. If this message is still displayed, uninstall (page 59) and reinstall Sprint Connection Manager, or contact Sprint (page 13).

Initializing

Sprint Connection Manager is attempting to establish communication with the USB modem.


Searching for service...

Sprint Connection Manager is determining whether 1X or 1xEV-DO service is available. If this message persists, see page 94.

Disconnected

Sprint Connection Manager is ready to make a connection to the network or to use Sprint Location Services. The **GO** button is available; the signal strength icon (📶) and the roaming icon (🌐) (if you're roaming) are visible. If the **Mobile Broadband** window is expanded, the lock icon (🔒 or 🔓) is visible.

To connect to the network, click **GO**.



Connecting


Sprint Connection Manager is establishing a connection to the network.

Connected

The connection is established. In addition to the signal strength icon (📶) and the roaming icon (🌐) (if you're roaming), the transmit/receive icon (📡 for 1xEV-DO Rev. A; 📶 for 1xEV-DO Rev. 0; 📶 for 1X) is also displayed.

If you expand the **Mobile Broadband** window (📶), the amount of data transferred is shown. (See note on page 53.)

To end the connection, click **Stop**.




Connected to NDIS

This message applies only if **Enable Network Adapter (NDIS)** (page 69) has been selected. For a description, see “Connected” (above).


Device locked

The USB modem is locked, so that others cannot use the USB modem and your account. To use most of the features, you must unlock the USB modem (page 57).



Device powered off

The USB modem has been powered off (through **Menu > Power Off Modem**). To use the USB modem, select **Menu > Power On Modem**.



For more information, see “Powering the USB Modem On and Off” on page 45.

GPS Status (GPS Receiver Window)

The **GPS Receiver** window displays the GPS status:

- OFF
- Validating
- Searching
- Acquired

OFF

GPS is not available or is turned off.

To use GPS:

1. Ensure the USB modem is not powered off and the **GPS Receiver** window is displayed.
 - ▶ If the **GPS Receiver** window is not displayed, in Sprint Connection Manager select **MENU > Settings > Sprint Location Services**, and then select **Enable Location Services** and **Display GPS Receiver**. (If Privacy Consent Agreements are displayed, you must read and accept them.)
2. Click **GO** in the **GPS Receiver** window.

Tip:	You can turn off the display of the Privacy Consent Agreements (from the Sprint Location Services settings window; page 71).
-------------	--

If the **GPS Receiver** window still displays “OFF,” ensure **Network Mode** (page 69) is set to **Automatic** or **1X Only**, and (subject to change) ensure that you are in the network coverage area (not roaming).

Validating

The network is authenticating your wireless or GPS subscription.

Searching


Sprint Connection Manager is searching for satellites.





Acquired

Satellites have been acquired and location coordinates are available for use (and displayed in the **GPS Receiver** window [page 36]).

NMEA output is being generated. (For information on NMEA, see “What is NMEA?” on page 90.)


System Tray Connection States


Sprint Connection Manager has an associated icon () that appears in the system tray. The icon reflects the connection state.

	Sprint Connection Manager is not ready to connect to the network. Your USB modem is either locked (“Device locked”; page 40), not detected (“No device”; page 38), or powered off (“Device powered off”; page 40).
	Disconnected — Sprint Connection Manager is ready to make a connection to the network (page 39), or Connecting — Sprint Connection Manager is making a connection to the network (page 39).
	Connected — Connection is established to the network; data transfer is in progress (page 39).
	Dormant — Connection is established, but no data transfer is taking place.

Clicking the system tray icon toggles between displaying and minimizing Sprint Connection Manager.


Right-clicking the icon displays the shortcut menu (page 63).



If Sprint Location Services are supported and enabled, then a second icon () is displayed in the system tray. The ToolTip indicates GPS and satellite status.

Determining the Type of Coverage

The ToolTip over the signal strength indicator (📶) indicates the type of coverage you have (for example, 1X [synonym of 1xRTT] or 1xEV-DO):



Tip: The type of coverage is also displayed in the lower left part of the Device Info & Diagnostics window under “Network Service” (page 78).

Attaching an External Antenna

You can improve the signal strength by attaching an external antenna (sold separately).

To attach an external antenna:

1. Remove the USB modem from your computer (page 22).
2. Flip open the rubber tab on the side of the USB modem.
3. Hold the antenna cable by the connector (end) part, and carefully insert the connector part of the cable into the corresponding connector on the USB modem.
4. Reinsert the USB modem into your computer (page 22).

Sprint Location Services

Sprint Location Services (Location & Search Services) allow you to query the network for information on points of interest that are near your current location. The network automatically determines your current location. All you have to do is specify the type of business that you are looking for (for example, a restaurant or hotel).


For limitations related to Sprint Location Services, see “Location-Based Services limitations” on page 88.

To use Sprint Location Services:

1. Ensure that, in the settings for Sprint Location Services (page 71), you have selected **Enable Location Services** and, if you will be using GPS applications, **Display GPS Receiver**, and you have accepted the Privacy Consent Agreement(s).
2. In Sprint Connection Manager, click **Menu > Location & Search Services**.

Note: If the menus and windows (page 43 and page 71) related to Sprint Location Services are unavailable in Sprint Connection Manager, see “Sprint Location Services Aren’t Working or Don’t Seem to Be Available” on page 96.

If the GPS fix is successful or if data from a recent GPS fix is available, then the Sprint Nextel Location & Search window is displayed. The bottom part of the window displays location information (latitude and longitude) of your USB modem, and the time that the location information was acquired.



3. From the Location & Search window, enter or select the type of item you want to find. If you've previously entered search items, a drop-down list displays the last five items you've entered. Click **Go**.

If more than a preconfigured period of time has elapsed since the last time you've submitted a location search, a window is displayed asking whether you want to get an updated (GPS) position fix. (Depending on your account, you may be charged for each position fix or after you have performed a certain number of fixes.) If your current location is different from where you submitted your last location search, click **Yes**.

Note:	Sprint Connection Manager uses your computer's default Web browser to display the results of Sprint Location Services.
--------------	--

Your Web browser opens and displays the results of your search query. In the search results of some mapping and search services, you can right-click your location to get additional information—for example, driving instructions.

From the Location & Search window, you can submit additional searches.

From the Settings window, you can specify the settings for Sprint Location Services (page 71).

Powering the USB Modem On and Off


If you are using your USB modem in an aircraft, hospital, or other environment where the USB modem may cause interference, you can power the USB modem off (without removing it from your USB slot), and still use other functions of your computer.

This also allows you to conserve your notebook computer's battery and charge the USB modem's battery.

To power the USB modem off:

1. Close any active data connection (page 54).
2. Select **MENU > Power Off Modem**.

When the USB modem is powered off, the menu option switches to **Power On Modem**, the **Mobile Broadband** window displays the message “Device powered off,” and the **GPS Receiver** window displays “OFF.”




To power the USB modem on:


- ▶ Select **MENU > Power On Modem**.

Controlling the Sprint Connection Manager Window

Expanding Sprint Connection Manager


The **Mobile Broadband** window and, if supported and enabled (page 72), the **GPS Receiver** window each have two views: compact and expanded.

To expand Sprint Connection Manager, click  in the appropriate window.


To change back to the compact view, click .



Mobile Broadband Window

Compact view:




Expanded view:




When expanded, the **Mobile Broadband** window also displays the amount of data transferred during the current connection, and (only when disconnected) the lock state of the USB modem (locked  or unlocked ).

GPS Receiver Window

Compact view:



Expanded view:



When expanded, the **GPS Receiver** window displays location information (described in the table on page 36.)

Minimizing Sprint Connection Manager

To save space on your screen for other programs, you can minimize Sprint Connection Manager:

- ▶ Click  (in the upper right corner of Sprint Connection Manager).

– or –

Click the Sprint Connection Manager icon  in the system tray.

– or –

Right-click the system tray icon and select **Close Sprint Mobile Broadband**.

You can use the system tray icon to monitor the connection state (page 42).

Tip:	You can set Sprint Connection Manager to start minimized. (See “ Start in system tray ” on page 67.)
-------------	---

Tip:	You can prevent Sprint Connection Manager from being covered up by other windows by setting Always on top (page 67).
-------------	---

Restoring Sprint Connection Manager

To restore Sprint Connection Manager when it is minimized:

- ▶ Click the Sprint Connection Manager icon  in the system tray.

– or –


Right-click the system tray icon and select **Open Sprint Mobile Broadband**.

Exiting Sprint Connection Manager

To exit Sprint Connection Manager:

- ▶ In Sprint Connection Manager, select **Menu > Exit**, or click the  button,

– or –

Right-click the Sprint Connection Manager icon  in the system tray and select **Exit** from the shortcut menu.

If **Enable Network Adapter (NDIS)** (page 69) has not been selected and a connection is in progress, a window is displayed asking whether you want to disconnect the call. To end the connection and close Sprint Connection Manager, you must click **Yes**.

Sprint Connection Manager closes, and the Sprint Connection Manager icons disappear from the system tray.

Note: If **Enable Network Adapter (NDIS)** (page 69) has been selected, after exiting Sprint Connection Manager you are still connected to the network (data may still be transferred). To manage the connection, use the Windows network connection icon in the system tray.

Launching a Sprint Power Vision or Sprint Vision Connection

To launch a connection:

- ▶ Click **GO** in the **Mobile Broadband** window. (If **GO** is unavailable, see “GO Button Is Unavailable” on page 94.)

Note: A connection is automatically established if you select **Menu > Location & Search Services** or click **GO** in the **GPS Receiver** window.

When the connection is successfully established, the network welcome screen appears (unless you have turned off the welcome screen display; see “**Always show Welcome Screens**” on page 69).



The **Mobile Broadband** window displays “Connected” or “Connected to NDIS” (page 39).

You can now use your Web browser, perform data transfers, and so on.

The connection is “active” when data transmission is occurring. If data transmission stops for a period of time (determined by the network), the connection becomes “dormant.” When you resume data traffic, the connection becomes active.

To monitor the status of the connection, you can use the text (page 38) and icons (page 33) in the **Mobile Broadband** window, and the icon in the system tray (page 42). You can also view the amount of data transferred (page 53).

Tip:


You can optionally specify which application to automatically launch when the connection is established. (See “Auto-launch upon Network Connection” on page 52.)

You can also set the connection to launch automatically whenever available. (See “**GO automatically when ready**” on page 69.) If the connection is lost, it is restarted automatically. If you also set Sprint Connection Manager to launch automatically (see “**Launch when Windows starts**” on page 67), this can provide an “always-on” connection, as long as you have network coverage.

You can have a connection established automatically—without running Sprint Connection Manager—simply by starting whatever application you want to use (such as your Web browser or email application). Select **Enable Network Adapter (NDIS)** (page 69). However, Sprint Connection Manager and its icon in the system tray won’t be available for you to monitor the status of the connection. Sprint Location Services also won’t be available.

Roam Guard

The Roam Guard feature, when enabled, displays a warning message if you are roaming and a data connection is established or about to be established. The message reminds you that roaming rates may apply.



From warning message window, you can:

- Turn off the warning message for this data session only (“Do not ask again during this data session.”).
- Continue with the data connection (“Roam”), in which case you may be subject to roaming rates.
- End the data connection (“Cancel”).

Note:	This feature is available only if Roam Mode is set to Automatic (from the Sprint Mobile Broadband option in the Settings window; page 68).
--------------	--

To turn on the Roam Guard feature:

1. From the Sprint Mobile Broadband option in the Settings window, ensure **Roam Mode** is set to **Automatic**.
2. From the **Roam Guard** drop-down list, select **Always Ask**.

To permanently turn off the Roam Guard feature:

- ▶ From the **Roam Guard** drop-down list, select **Never Ask**.

Auto-launch upon Network Connection

You can optionally specify which application to automatically launch when a Sprint Power Vision or Sprint Vision connection is established.

To specify which application to automatically launch:

1. Ensure Sprint Connection Manager is running and not locked (page 56).
2. Ensure that your USB modem is not powered off (page 40).
3. Select **MENU > Settings > Sprint Mobile Broadband - Sierra Wireless**.
4. Select **Auto Launch**.
5. In the Auto-Launch Options window, select one of the following:
 - **None** — Do not auto-launch any application.
 - **Website** — Auto-launch Internet Explorer. In the URL field, specify the Web site (such as <http://www.sierrawireless.com>) you want to view on connection.
 - **Microsoft VPN (PPTP) Connection** — Auto-launch a Windows VPN connection. Type in the address of the VPN connection, or select the VPN connection from the drop-down list.
 - **Application (VPN client, etc.)** — Auto-launch an installed VPN program, or any other program. Enter the program path in the field, or use the Browse button to locate the program.


The changes are applied the next time you launch a connection.

Note: This feature functions only when Sprint Connection Manager is running.


Viewing the Amount of Data Transferred

Note: Even though the number of bytes sent and received is displayed while the connection is running, this is not necessarily the actual amount of data being transmitted across the network. **Do not use this information to estimate billing.**
If **Enable Network Adapter (NDIS)** (page 69) has been selected, after exiting Sprint Connection Manager you are still connected to the network. Data may still be transferred.


To view the number of bytes sent and received during the current connection:

- ▶ If the **Mobile Broadband** window is not expanded, click the  button.

The number of bytes sent and received during the current connection is displayed to three significant digits (for example, 581 kb, 1.23 Mb, or 1.81 Mb).



Once you end the connection, all numbers reset to zero.

To hide this information, click the  button in the **Mobile Broadband** window.

Ending a Connection

To end a connection:

- ▶ In the **Mobile Broadband** window, click **Stop**.

This ends your data connection, and also your GPS connection, if it is open.

Note:	The Stop button in the GPS Receiver window ends only your GPS connection; data may still be transferred.
--------------	--

If **Enable Network Adapter (NDIS)** (page 69) has not been selected and you exit Sprint Connection Manager while a connection is in progress, a window opens asking whether you want to disconnect the call. Click **Yes** to end the connection and exit Sprint Connection Manager. (See “Exiting Sprint Connection Manager” on page 49.)

If **Enable Network Adapter (NDIS)** has been selected, manually disconnecting will leave the USB modem disconnected. It will not reconnect until you remove and reinsert the USB modem.


If **GO automatically when ready** (page 69) has been selected, manually disconnecting will leave the USB modem disconnected. It will not reconnect until one of the following occurs:

- You make a connection through Sprint Connection Manager
- A GPS fix is successfully acquired after you initiate Sprint Location Services (page 43)
- You restart Sprint Connection Manager

Online Help

Sprint Connection Manager includes extensive online help to provide operating hints and step-by-step instructions for getting the most from your USB modem.

With Sprint Connection Manager running, you can access online help in several ways:

- Press <F1> when Sprint Connection Manager is the active window.
- From the Sprint Connection Manager window, select **MENU > Help**.
- Right-click the system tray icon () and select **Help**.

The help file has a table of contents and an index.

Displaying Your Phone Number

You can view your phone number in the Device Info & Diagnostics window (**Menu > Device Info & Diagnostics**).

Security

When it is disconnected, you can lock your USB modem so that others cannot use it to access your account. A four-digit lock code is needed to unlock the USB modem.

You can set the USB modem to lock:

- Whenever Sprint Connection Manager is started (page 57).
— or —
- Immediately (without restarting Sprint Connection Manager) — useful if you are lending your USB modem and computer or leaving your computer for a short time (page 56).

Initial Lock Code

The initial lock code value is determined by your service provider.

For service provider configurations that do not require account activation, a default lock code is set at the factory to a value determined by the service provider. For assistance, contact Sprint (page 13).

Configurations that use the Activation Wizard or IOTA set the initial lock code to the last four digits of your account phone number whenever a new phone number is activated.

After activation, you can change the lock code (page 58) from the initial value to any four-digit code you choose.

Note:	The security lock code is reset to the last four digits of the phone number whenever an account is activated. This may change a custom value you have set.
--------------	--

When the USB Modem Is Locked

When the USB modem is locked, you can:

- Unlock the USB modem (page 57).
- Power off the USB modem (page 45).



When the USB modem is locked, you cannot:

- Make data connections (the **GO** button is unavailable).
- Use Sprint Location Services.
- Run the Activation Wizard.

Locking the USB Modem

Warning: If you forget the lock code, you will not be able to use the USB modem until you receive assistance from Sprint.

To lock the USB modem immediately:




1. End any active connection. (You can lock the USB modem only when it is disconnected; page 39.)
2. If the **Mobile Broadband** window is not expanded, click  to expand it.
3. Click the  icon.
4. In the Enter User Lock Code window, enter the lock code, and click **OK**.

When the USB modem is locked, the **Mobile Broadband** window displays “Device locked,” and the lock icon is now . The **GO** button is unavailable.

Tip: You can also set the USB modem to be locked upon startup of Sprint Connection Manager, as described next.

Locking upon Sprint Connection Manager Startup

To set the USB modem to lock as soon as Sprint Connection Manager starts up:



1. End any active connection. (You can lock the USB modem only when disconnected; see page 39.)
2. If the **Mobile Broadband** window is not expanded, click  to expand it.
3. Click the lock icon ( or , depending on the current lock status).
4. In the Enter User Lock Code window, enter the lock code, and select **Relock modem when program exits**.
5. Click **OK**.


Note:	This setting takes effect only after you exit and restart Sprint Connection Manager.
--------------	--

Unlocking the USB Modem

When the USB modem is locked, the **Mobile Broadband** window displays “Device locked,” and the lock icon is .

To unlock the USB modem:

1. If the **Mobile Broadband** window is not expanded, click  to expand it.
2. Click the  icon.
3. In the Enter User Lock Code window, enter the lock code, and click **OK**.

When the USB modem is unlocked, the **Mobile Broadband** window no longer displays “Device locked,” and the lock icon is .


Changing the Lock Code

Warning: If you forget the lock code, you will not be able to use the USB modem until you receive assistance from Sprint.

To change the lock code:

1. In the Sprint Mobile Broadband settings window (page 68), click **User Lock Change**.

The Change User Lock Code window is displayed:

The image shows a Windows-style dialog box titled "Change User Lock Code". It has a blue title bar with a close button (X) in the top right corner. The main area is light beige and contains three input fields. The first field is labeled "Current Code" and has a single vertical line in it. The second field is labeled "New Code" and is empty. The third field is labeled "Re-enter" and is empty. Below the input fields are two buttons: "OK" and "Cancel".

2. Enter the current lock code.
3. Enter a new four-digit lock code.
4. Enter the new lock code for confirmation.
5. Click **OK**.

Accessing Links

For your convenience, Sprint Connection Manager includes links to Sprint products and services. To access these links:

1. In Sprint Connection Manager, click **Menu**.
2. Select **Links**.

Note: You cannot add or remove links from the **Links** menu. To add or remove links, use your Web browser.

Uninstalling the Sprint Connection Manager Software

To remove the Sprint Connection Manager software from your computer, use the Add/Remove Programs utility built into your Windows operating system.

1. Exit Sprint Connection Manager (page 49).
2. Remove the USB modem. (See “Removing the USB Modem” on page 22.)
3. Select **Start > Control Panel** and select:
(Windows Vista) **Programs and Features**.
(Windows XP or Windows 2000) **Add/Remove Programs**.

The Windows Add/Remove Programs utility will start. Be sure the Change or Remove Programs feature is selected (default).

4. From the list, select **Sprint Mobile Broadband (Sierra)**, and click **Remove** or **Uninstall**.


Menu Options


In This Section

- ◆ **Sprint Connection Manager Menu**
 - ◆ **System Tray Menu**
-


This chapter describes each menu option you may encounter while using your Sprint Mobile Broadband USB modem and the Sprint Connection Manager software on your Windows computer.

Sprint Connection Manager Menu

Clicking **Menu** or the  button, located in the upper left corner of Sprint Connection Manager, displays the Sprint Connection Manager menu.



Note: Depending on your configuration and settings, not all menu options may be shown or enabled as described here.

Tip: You can also display the menu by positioning the cursor over the **Menu** text or the  button and then pressing the spacebar or Enter key on your keyboard. To hide the menu, press **Esc**, or click outside the menu.


The following table describes the menu options:

Menu Item	Description
Links	Access links to Sprint products and services. See “Accessing Links” on page 58.
Power Off Modem	Power off your USB modem. See “Powering the USB Modem On and Off” on page 45.
Location & Search Services	Query the network for information on points of interest that are near your current location. See “Sprint Location Services” on page 43.

Menu Item	Description
Alert Log	View a record of all alerts (for example, connection errors) that have been received while establishing and maintaining connections. See “Viewing Alerts” on page 76.
Connection History	View a record of connections established using your USB modem (unavailable if the Connection History is empty, or if Keep Connection History [page 67] is not selected). See “Viewing the Connection History” on page 75.
Device Info & Diagnostics	View information about your USB modem and run diagnostic tests. See “Running Diagnostics” on page 77.
Software Updates	Retrieve updates for Sprint Connection Manager and your USB modem. See “Updating the Software” on page 79.
Help	Display the online Help, which has operating hints and step-by-step instructions for getting the most from your USB modem. See “Online Help” on page 54.
About Sprint Mobile Broadband	Display brief information about the Sprint Connection Manager software. To close the window, click anywhere inside it. See “About Sprint Mobile Broadband” on page 80.
Settings	Change the settings for Sprint Connection Manager. Contains submenu items: <ul style="list-style-type: none"> ● General: See “General Settings” on page 66. ● Sprint Mobile Broadband - Sierra Wireless: See “Sprint Mobile Broadband Settings” on page 68. ● Sprint Location Services: See “Sprint Location Services Settings” on page 71.
Exit	Exits Sprint Connection Manager.

System Tray Menu

When you right-click the system tray icon () , a shortcut menu is displayed:



The following table describes the menu options:

Menu Item	Description
Open/Close Sprint Mobile Broadband	Minimize Sprint Connection Manager (Close), or restore (Open) if Sprint Connection Manager is minimized.
Help	Display the online Help.
About Sprint Mobile Broadband	Display brief information about the Sprint Connection Manager software. To close the window, click anywhere inside it.
Exit	Exit Sprint Connection Manager.

Changing Sprint Connection Manager Settings

In This Section

- ◆ **Settings Window**
 - ◆ **General Settings**
 - ◆ **Sprint Mobile Broadband Settings**
 - ◆ **Sprint Location Services Settings**
-

This chapter describes settings you can change to customize Sprint Connection Manager.

Settings Window

Note:	This feature is temporarily unavailable if you have powered off the USB modem (page 45).
--------------	--

From the Settings window, you can specify the settings for Sprint Connection Manager.


1. In Sprint Connection Manager, click **Menu**.
2. Select **Settings**.
3. From the drop-down list, select one of the following categories of settings:
 - General (general behavior of Sprint Connection Manager; page 66)
 - Sprint Mobile Broadband - Sierra Wireless (behavior of your Sprint Power Vision or Sprint Vision connection; page 68)
 - Sprint Location Services (page 71)
4. Make the appropriate changes to the settings (described in the following pages).
5. To change other settings, repeat steps 3 and 4.
6. Click **OK**.

Note:	Changes to the setting Launch when Windows starts apply only after you restart Windows. Changes to the setting Start in system tray apply only after you exit and restart Sprint Connection Manager.
--------------	--

Tip:	You can also access the Settings window from the Connection History window (page 75): click File > Settings .
-------------	---

General Settings

From the General option in the Settings window, you can specify settings that affect the general behavior of Sprint Connection Manager.




The following table describes the options:

Menu Item	Description
Play sound effects	Play a clicking sound whenever an action is made in Sprint Connection Manager.
Always on top	Keep Sprint Connection Manager visible on your screen regardless of which applications are open.
Start in system tray	Have Sprint Connection Manager start (minimized) in the system tray on startup. (See “Restoring Sprint Connection Manager” on page 49.)
Keep Connection History	Have Sprint Connection Manager keep a log of your data connections (page 75).
Launch when Windows starts	Have Sprint Connection Manager start automatically when Windows starts. Tip: You can also set the Sprint Power Vision or Sprint Vision connection to launch automatically whenever available (see “ GO automatically when ready ” on page 69). These settings provide an “always-on” connection, as long as you have network coverage.
Check for updates once per month	Have Sprint Connection Manager automatically check for software updates (page 79).
Check Now	Check for software updates immediately. Note: During the software update, Sprint Connection Manager will close. Before you initiate the software update, finish any Web browsing, data transfers, and so on.

Note:	Changes to the setting Launch when Windows starts apply only after you restart Windows. Changes to the setting Start in system tray apply only after you exit and restart Sprint Connection Manager.
--------------	--

Sprint Mobile Broadband Settings

From the Sprint Mobile Broadband option in the Settings window, you can change the behavior of your Sprint Power Vision or Sprint Vision connection.




The following table describes the options:

Menu Item	Description
Always show Welcome Screens	Display a welcome screen upon a successful connection to the network.
GO automatically when ready	<p>Automatically connect to the network after Sprint Connection Manager starts, or whenever Sprint Connection Manager loses the network connection.</p> <p>To select GO automatically when ready, ensure that Enable Network Adapter (NDIS) (below) is not selected.</p> <p>Tip: You can also set Sprint Connection Manager to start automatically (see “Launch when Windows starts” on page 67). These settings provide an “always-on” connection, as long as you have network coverage.</p> <p>You can have a connection established automatically, without having to run Sprint Connection Manager. Ensure that GO automatically when ready is not selected, and select Enable Network Adapter (NDIS) (below).</p>
Enable Network Adapter (NDIS)	<p>Make a connection automatically, without running Sprint Connection Manager—simply by starting whatever application you want to use (such as your Web browser or email application).</p> <p>To select Enable Network Adapter (NDIS), ensure that GO automatically when ready (above) is not selected.</p> <p>Note: Sprint Location Services are available only when Sprint Connection Manager is running.</p>
Network Mode: Automatic	Attempt a Sprint Power Vision (1xEV-DO) connection and, if not successful, attempt the slower Sprint Vision (1X) connection.
Network Mode: 1xEV-DO Only	<p>Attempt only a Sprint Power Vision (1xEV-DO) connection.</p> <p>Note: Sprint Location Services may not be supported. When in an area that has only Sprint Vision (1X) coverage, you won’t be able to connect to the network.</p>

Menu Item	Description
Network Mode: 1X Only	<p>Attempt only a Sprint Vision (1X) connection (even when you have Sprint Power Vision [1xEV-DO] coverage, which provides faster data transmission speeds).</p> <p>Note: When in an area that has only Sprint Power Vision (1xEV-DO) coverage, you won't be able to connect to the network.</p>
Roam Mode: Sprint	<p>Disable roaming when you are not in the network coverage area. You will be able to connect only when you are in the network coverage area.</p>
Roam Mode: Automatic	<p>Allow roaming when you are not in the network coverage area.</p> <p>Note: Roaming rates may apply. Roam Guard (page 51) can remind you of this.</p>
Roam Mode: Roam Only	<p>Allow only roaming.</p> <p>Note: Roaming rates may apply. Roam Guard (page 51) can remind you of this. Sprint Location Services may not be available.</p>
Roam Mode: Roam Guard	<p>Display a warning message when you are about to establish a data connection while roaming. For more information, see "Roam Guard" on page 51.</p> <p>Available only if Roam Mode is set to Automatic (page 70).</p> <p>Note: If you proceed with the data connection, roaming rates may apply.</p>
Activation Wizard	<p>Used only when activating a USB modem, or when changing your USB modem's phone number (page 25).</p>
User Lock Change	<p>Change the security lock code of the USB modem (page 58).</p>
Auto Launch	<p>Optionally specify which application to automatically launch when a connection is established.</p> <p>See "Auto-launch upon Network Connection" on page 52.</p>


Sprint Location Services Settings

From the Sprint Location Services option in the Settings window, you can change the behavior of Sprint Location Services. (For more information on Sprint Location Services, see page 43.)



The following table describes the options:

Menu Item	Description
Enable Location Services	Turn on support (by your USB modem) for Sprint Location Services. Note: To use Sprint Location Services, your account must also be configured appropriately. If you are unable to use Sprint Location Services, see “Sprint Location Services Aren’t Working or Don’t Seem to Be Available” on page 96 or contact Sprint Customer Service (page 13).
Display GPS Receiver	Show or hide the GPS Receiver window (page 46).
Display GPS Welcome	Display a welcome window whenever you initiate Sprint Location Services.
Display 'Location & Search Services' on the menu	Show or hide the Sprint Connection Manager menu item that displays the Sprint Nextel Location & Search window. For more information on this window, see “Sprint Location Services” on page 43.
Do not show NMEA Privacy Consent	Prevent a Privacy Consent Agreement window from appearing every time you use NMEA. For more information, see “What is NMEA?” on page 90 and “When do I need to use NMEA?” on page 90.
Do not show Privacy Consent for 'Location & Search Services'	Prevent a Privacy Consent Agreement window from appearing every time you use the Location & Search Services menu.
Microsoft Live MapQuest Yahoo! Maps Google Maps	Specify which mapping and search service (for example, Microsoft® Live, or Google™ Maps) your Web browser uses for Sprint Location Services. Some mapping and search services may have data that is more current or accurate than that of other mapping and search services.

Menu Item	Description
Test GPS	<p>Verify that your USB modem is able to obtain data for Sprint Location Services:</p> <ol style="list-style-type: none"> 1. Ensure that Network Mode (from the Sprint Mobile Broadband Settings window; page 68) is set to Automatic or 1X Only. (Sprint Location Services may not be available if Network Mode is set to 1xEV-DO Only.) 2. Ensure you are in the network coverage area (not roaming). 3. Click Test GPS. <p>The results (including the number of satellites, latitude, longitude, and elevation information) are displayed to the right of the Test GPS button.</p> 

Tools


In This Section

- ♦ **Viewing the Connection History**
 - ♦ **Viewing Alerts**
 - ♦ **Running Diagnostics**
 - ♦ **Updating the Software**
 - ♦ **About Sprint Mobile Broadband**
-

This chapter describes various features you can use to view information about the Sprint Mobile Broadband USB modem and the Sprint Connection Manager software on your Windows computer.

Viewing the Connection History

Connection History displays a record of connections established using your USB modem. You can sort records by connection name to easily distinguish between personal and business usage.



From this window you can also access the Settings window (page 65) (**File > Settings**).

Note: For connections to be recorded, **Keep Connection History** must be enabled (page 67).

To view the Connection History:

1. In Sprint Connection Manager, click **Menu**.
2. Select **Connection History**.

To sort the entries:

- ▶ Click the button that contains the title of the column you want to sort by. (You can reverse the sort order by clicking the button again.)

— or —

Click an option under the **Sort** menu.

To export the entries to a text file:

1. Select **File > Export**.
2. Specify a file name and path.
3. Click **Save**.

To copy one or more entries:

1. Select the entries. (Click a single entry, or hold down CTRL or SHIFT and click to select multiple entries; to select all entries, select **Edit > Select All.**)
2. Select **Edit > Copy.**
3. Paste the entries (for example, into a text file or email message).

To delete all entries:


- ▶ Click the **Clear** button.

To delete one or more entries:

1. Select the entries. (Click a single entry, or hold down CTRL or SHIFT and click to select multiple entries.)
2. Select **Edit > Delete.**

Viewing Alerts

The Alert Log displays a record of all alerts (for example, connection errors) that have been received while establishing and maintaining connections. You can use the Alert Log to help isolate and resolve connection issues.



To view the Alert Log:

1. In Sprint Connection Manager, click **Menu.**
2. Select **Alert Log.** (This menu option is unavailable if the alert log is empty.)

To sort the entries:

- ▶ Click the button that contains the title of the column you want to sort by. (You can reverse the sort order by clicking the button again.)
— or —
Click an option under the **Sort** menu.

To export the entries to a text file:

1. Select **File > Export**.
2. Specify a file name and path.
3. Click **Save**.

To copy one or more entries:

1. Select the entries. (Click a single entry, or hold down CTRL or SHIFT and click to select multiple entries; to select all entries, select **Edit > Select All**.)
2. Select **Edit > Copy**.
3. Paste the entries (for example, into a text file or email message).

To delete all entries:

- ▶ Click the **Clear** button.

To delete one or more entries:

1. Select the entries. (Click a single entry, or hold down CTRL or SHIFT and click to select multiple entries.)
2. Select **Edit > Delete**.

Running Diagnostics

To identify problems when connecting to the network, use the Device Info & Diagnostics window. Device Info & Diagnostics evaluates issues with your USB port, port configuration, network signal strength, Sprint Connection Manager, and more. Once the program runs a diagnostics check, it recommends solutions.


The program also displays information such as your phone number.

Results of the diagnostics can be shared with a Sprint Customer Service Specialist, to assist that person with troubleshooting.

To access the Device Info & Diagnostics window:

1. Ensure the USB modem is inserted.
2. In Sprint Connection Manager, click **Menu**.
3. Select **Device Info & Diagnostics**.

The tests automatically start when the window opens.



From the Device Info & Diagnostics window, you can view system information (page 79) and save the system information to an RTF (Rich Text Format) file.

From the Device Info & Diagnostics window, you can also update parameters in your USB modem:

- ▶ Click **Update Data Profile**. (If this button is not displayed, remove and reinsert the USB modem.)

Displaying System Information

The System Information window displays:

- **System Parameters:** Information about your computer hardware and software.
- **Installed Files:** Files related to Sprint Connection Manager.
- **Device Info & Diagnostics:** Information about the USB modem (including its phone number), and results of various tests.

To display system information:

1. Select **Menu > Device Info & Diagnostics**.
2. In the Device Info & Diagnostics window, click **System Information**.

To save the information to a file (for example, if you are requested to send the report to your service provider representative):

1. In the System Information window, click **Create Report**.
2. Specify a file name and path.
3. Click **Save**.

Updating the Software

From time to time, Sprint may release updates for Sprint Connection Manager and your USB modem. These updates may add features or improve network performance.

Note:	During the software update, Sprint Connection Manager will close. Before you initiate the software update, finish any Web browsing, data transfers, and so on.
--------------	--

To update the software:

1. Ensure you have a network connection.
2. In Sprint Connection Manager, click **Menu**. Select **Software Updates**.

— or —

From the General option in the Settings window (page 65), click **Check Now**.

You can also set the software to automatically check for updates once a month:

1. In Sprint Connection Manager, click **Menu** and then select **Settings**.
2. Select **Check for updates once per month**.

About Sprint Mobile Broadband

The About Sprint Mobile Broadband window displays information about the Sprint Connection Manager software.

To display this window:

- ▶ In Sprint Connection Manager, click **Menu** and then select **About Sprint Mobile Broadband**.

— or —

Right-click the Sprint Connection Manager icon () in the system tray and, from the shortcut menu, select **About Sprint Mobile Broadband**.

To close this window, click anywhere inside it.

Tip:	To display more information, you can run diagnostics (page 77).
-------------	---

Frequently Asked Questions (Windows)

In This Section

- ◆ What is Sprint Connection Manager?
- ◆ If the connection is “always on,” am I always being billed?
- ◆ How fast is the connection with Sprint Connection Manager?
- ◆ How can I optimize my settings to achieve the fastest speeds and conserve data when accessing my corporate network?
- ◆ Can I connect to a dial-up account like AOL or EarthLink?
- ◆ Once I connect to the network, how do I access my corporate network through a VPN?
- ◆ Why won't my laptop go into hibernation mode when using my Sprint Mobile Broadband USB Modem?
- ◆ What is LBS?
- ◆ What is GPS?
- ◆ What is enhanced Local Search?
- ◆ How do I get the enhanced Local Search feature?
- ◆ Where do I find the enhanced Local Search feature?
- ◆ How do I use the enhanced Local Search feature?
- ◆ Where can I use GPS?
- ◆ What is GPS User Plane?
- ◆ What is GPS Control Plane?
- ◆ How do I enable/disable GPS?
- ◆ Will GPS work when Privacy is set to ON?
- ◆ Can I use Sprint Location Services if I have enabled NDIS?
- ◆ Do I need a GPS subscription to use GPS?
- ◆ Location-Based Services limitations

- ♦ **What GPS mode options are supported?**
 - ♦ **What is GPS Basic?**
 - ♦ **What is GPS Premium?**
 - ♦ **What is the difference between GPS Basic and GPS Premium?**
 - ♦ **What is a GPS application?**
 - ♦ **What is NMEA?**
 - ♦ **How do I configure a GPS application to use my GPS-capable device?**
 - ♦ **When do I need to use NMEA?**
 - ♦ **How do I start and stop NMEA?**
 - ♦ **How do I configure my NMEA port?**
-

What is Sprint Connection Manager?

Sprint Connection Manager is software that lets you connect to the Sprint Power Vision or Sprint Vision network. Sprint Connection Manager takes advantage of the increased data speeds offered by the Sprint Mobile Broadband Network.

If the connection is “always on,” am I always being billed?

No. The connection to the network goes dormant after a period of inactivity, but the connection can be re-established faster than having to reconnect. Billing occurs only when data is passed across the network.

How fast is the connection with Sprint Connection Manager?

The Sprint Mobile Broadband Network allows you to connect to the Internet at speeds of up to 3.1 Mbps (1xEV-DO Rev. A), 2.4 Mbps (1xEV-DO Rev. 0), or 144 kbps (1X). Average connection speeds are:

- For 1xEV-DO Rev. A: between 600 kbps and 1.4 Mbps downlink from the network, and between 350 and 500 kbps uplink to the network;
- For 1xEV-DO Rev. 0: between 400 and 700 kbps downlink from the network, and between 40 and 80 kbps uplink to the network;
- For 1X: between 40 and 80 kbps.

These speeds are faster than dial-up connection speeds.

How can I optimize my settings to achieve the fastest speeds and conserve data when accessing my corporate network?

Depending on your corporate email client, you can optimize your settings by doing the following:

- Work in “offline” mode, and connect only when you need to send or receive email.
- Remove the Preview Pane, or use the AutoPreview for headers only.
- Save attachments to a desktop folder and then open from that folder, rather than opening the attachment directly from the message.

For more information, see the user documentation of your email client.

Can I connect to a dial-up account like AOL or EarthLink?

No. The software does not support dial-up connections.

Once I connect to the network, how do I access my corporate network through a VPN?

Once you complete a wireless connection, you may need to launch an extranet client provided by your company and supply the appropriate user name and password to gain access. For support, contact your company help desk.

Why won't my laptop go into hibernation mode when using my Sprint Mobile Broadband USB Modem?

If you're using Windows 2000, you need to upgrade to Service Pack 4 from www.microsoft.com.

What is LBS?

LBS (Location-Based Services) is used to provide enhanced Local Search functionality via internet mapping services. For more information, see “What is enhanced Local Search?” on page 85.

What is GPS?

GPS stands for Global Positioning System, which is a system that uses a series of 24 geosynchronous satellites to provide location data.

GPS satellites transmit signals to equipment on the ground. GPS receivers passively receive satellite signals, but do not transmit.

Various GPS standards exist for the User Plane and Control Plane. For more information, see “What is GPS User Plane?” and “What is GPS Control Plane?” on page 86.

What is enhanced Local Search?

Enhanced Local Search is a quick, easy method to run, via Sprint Connection Manager, local search queries to find locations and directions to locations and businesses.

The enhanced Local Search feature uses LBS and allows you to search for Sprint Nextel stores, restaurants, banks, hotels, and so on, outdoors and (with GPS Premium) indoors. For more information, see “What is GPS Premium?” on page 89.

How do I get the enhanced Local Search feature?

The enhanced Local Search feature works only with GPS-capable data cards and the latest version of Sprint Connection Manager. The feature is available at no additional charge in the latest version of Sprint Connection Manager.

Note:	Sprint Location Services may not be supported if Network Mode is set to 1xEV-DO Only . To use Sprint Location Services, ensure Network Mode is set to Automatic or 1X Only . Sprint Location Services are not supported if you're roaming (subject to change).
--------------	---

Where do I find the enhanced Local Search feature?

In Sprint Connection Manager, select **Menu > Location & Search Services**.

How do I use the enhanced Local Search feature?

When running Sprint Connection Manager, select **Menu > Location & Search Services**. Some predefined, most frequently used queries are listed. There is also an option to run your own custom query; if you've previously entered search items, a drop-down list displays the last five items you've entered.

Where can I use GPS?

GPS works wherever there is both Sprint CDMA network access and GPS access.

Note:	In some locations where CDMA network access is available, GPS may not be available at this time. For the latest on service available by location, refer to Sprint Nextel Coverage maps.
--------------	---

What is GPS User Plane?

GPS User Plane is the ability to execute GPS requests at the subscriber level on the USB modem. In other words, the User Plane allows you to submit location-related queries to the network.

Compare to GPS Control Plane (see below).

What is GPS Control Plane?

GPS Control Plane is the ability to execute GPS requests at the network (server) level.

Compare to GPS User Plane (see above).

How do I enable/disable GPS?

By default, Sprint Location Services are disabled.

To enable Sprint Location Services:

1. In the Sprint Location Services settings window, select **Enable Location Services**.
2. If you will be using the **GPS Receiver** window (page 35), select **Display GPS Receiver**.

Tip:	To prevent Privacy Consent Agreements from appearing every time you use NMEA or the Location & Search Services menu, select Do not show NMEA Privacy Consent and Do not show Privacy Consent for 'Location & Search Services' .
-------------	---

Will GPS work when Privacy is set to ON?

No. Setting Privacy to ON [by not accepting the Consent Privacy Agreement(s)] means you do not want your USB modem to be discoverable; thus, GPS is not enabled/started on the USB modem.

Tip:	An icon in the GPS Receiver window indicates the GPS/Privacy status (page 36).
-------------	---

Can I use Sprint Location Services if I have enabled NDIS?

Yes. Sprint Location Services/GPS services are supported, whether or not you have selected **Enable Network Adapter (NDIS)**.

Do I need a GPS subscription to use GPS?

For GPS Basic, you do not need a GPS subscription.

For GPS Premium, you need a GPS subscription.

For more information on GPS Basic and GPS Premium, see “What is GPS Basic?” and “What is GPS Premium?” on page 89.

Location-Based Services limitations

To acquire a location fix, you must be connected to the Sprint network, (subject to change) not roaming, and, for the initial fix, in 1X coverage.

If you're outside with a clear view of the sky, the USB modem uses MS-Based position location technology. Weather conditions may affect your ability to get a clear view of the satellites and thus to acquire a GPS fix. MS-Based GPS (Basic) is for outdoor use only.

Note:	Location-Based Services use Advanced Forward Link Trilateration (AFLT). AFLT is a type of device-based position location technology. Unlike A-GPS, AFLT does not use GPS satellites to determine location. Instead, the device takes measurements of signals from nearby cellular base stations (towers) and reports the time/distance readings back to the network; the readings are then used to triangulate an approximate location of the device. In general, at least three surrounding base stations are required to get an optimal position fix. AFLT accuracy may vary, depending on the geometry of the cell towers in your location.
--------------	---

What GPS mode options are supported?

GPS on a Sprint data card works like any other GPS device. Sprint provides two types of GPS mode: GPS Basic, and GPS Premium.

For more information, see “What is GPS Basic?” and “What is GPS Premium?” on page 89.

Note:	Sprint Location Services may not be supported if Network Mode is set to 1xEV-DO Only or (subject to change) if you are roaming. To use Sprint Location Services, ensure Network Mode is set to Automatic or 1X Only , and ensure that you are in the network coverage area (not roaming).
--------------	--

What is GPS Basic?

Sprint GPS Basic supports GPS outdoors. Your USB modem requires an unobstructed view of GPS satellites (in the sky), and, like any other GPS device, might not perform well within forested areas or near tall buildings.

Sprint GPS Basic is based on GPSOne™ standards and uses Location-Based Services for the first, fast, GPS fix. GPS coordinate values are made available to applications via a local GPS NMEA Com port.

See also “What is NMEA?” on page 90 and “What is the difference between GPS Basic and GPS Premium?” on page 89.

What is GPS Premium?

Note: At the time of this software release, this GPS mode option is not yet available.

GPS Premium supports GPS outdoors (as does GPS Basic) and additionally indoors (where no GPS satellites are available).

To use GPS Premium, you need a GPS subscription.

What is the difference between GPS Basic and GPS Premium?

GPS Basic is for outdoor use — similar to the capability of a regular GPS device.

GPS Premium is an enhanced GPS capability that allows GPS to be used indoors and outdoors. To use GPS Premium, you need a GPS subscription.

What is a GPS application?

A GPS application is an application that uses NMEA data to get regular location coordinate updates and values typically displayed in an application. (For more information on NMEA, see “What is NMEA?” [below].)

Examples of GPS applications are Microsoft Streets & Trips, and Microsoft MapPoint.

What is NMEA?

NMEA stands for “National Marine Electronics Association.”

NMEA 0183 is a standard protocol used by GPS devices to send and receive data.

NMEA output is composed of various strings. Sprint GPS data cards support the following strings:

- \$GPGGA
- \$GPRMC
- \$GPGSA
- \$GPGSV

See also “When do I need to use NMEA?”, “How do I start and stop NMEA?”, and “How do I configure my NMEA port?”, starting on page 90.

How do I configure a GPS application to use my GPS-capable device?

To configure a GPS application to use your GPS-capable device:

1. Start GPS NMEA (page 91).
2. Note the “GPS Port” value displayed in the expanded **GPS Receiver** window (page 35).
3. Configure your GPS application to use the same port. For help, see the documentation of the GPS application.

When do I need to use NMEA?

You need to use NMEA only when using a GPS application that uses an NMEA output stream. For more information, see “What is a GPS application?” on page 89.

Note:	To ensure the best data performance of your USB modem, it’s recommended that you not activate the NMEA stream unless you are going to use it.
--------------	---

How do I start and stop NMEA?

Note:	To ensure the best data performance of your USB modem, it's recommended that you not activate the NMEA stream unless you are going to use it.
--------------	---

To start NMEA output:

1. Click **GO** in the **GPS Receiver** window (page 35).
2. Read and accept the Privacy Consent Agreement.

Tip:	You can turn off the display of the NMEA Privacy Consent Agreement (from the Sprint Location Services settings window)
-------------	--

To stop NMEA output, you have several options:

- In the **GPS Receiver** window, click **Stop**.
- In the **Mobile Broadband** window, click **Stop**.
- Exit Sprint Connection Manager.
- If you have started the GPS application before you started NMEA output: exit the GPS application.

How do I configure my NMEA port?

At the time of this software release, you cannot specify which port Windows uses for NMEA output. Windows automatically uses the next available port.

You can, however, configure the GPS application to use the NMEA Com port that Windows is using (page 90).

Troubleshooting Tips (Windows)

In This Section

- ◆ **Problems, Causes, and Solutions**
 - ◆ **GO Button Is Unavailable**
 - ◆ **Searching for Service**
 - ◆ **Cannot Connect to the Network**
 - ◆ **PWR LED Goes Off and On, and Then Stays Red**
 - ◆ **Sprint Location Services Aren't Working or Don't Seem to Be Available**
 - ◆ **Could Not Prepare Data Services**
 - ◆ **Unable to Prepare Data Services**
 - ◆ **Sprint Connection Manager Stops Working After Upgrading Windows**
-

This section helps you diagnose and solve common problems you may experience while using your Sprint Mobile Broadband USB modem and the Sprint Connection Manager software on a Windows computer.

Problems, Causes, and Solutions

When properly installed, the Sprint Mobile Broadband USB modem is a highly reliable product.

Most problems are caused by one of these issues:

- Network coverage is not available (because of your “Network Mode” settings [page 68], or because you are outside the network, or because of an account or network problem).
- The drivers were not properly installed because of a problem with your computer’s USB slot.
- System resources required by the USB modem are being used by other devices.

Tips when troubleshooting problems with your USB modem and software:

- Ensure your USB modem is inserted, not locked (page 56), and not powered off (page 40).
- Ensure the PWR LED is green.
- To determine the connection status, use the icons in the system tray (page 42), and icons in the **Mobile Broadband** window (page 34) and **GPS Receiver** window (page 36), and messages in the **Mobile Broadband** window (page 38) and **GPS Receiver** window (page 41).
- The alert log might indicate the nature of the problem (page 76).
- Run diagnostic tools supplied with Sprint Connection Manager (page 77).
- Check the Frequently Asked Questions (Windows) (page 81).
- Use the resources listed in “Getting Help” (page 12).
- If Sprint Connection Manager stopped working after you’ve upgraded to a different version of Windows, see “Sprint Connection Manager Stops Working After Upgrading Windows” on page 97.

If, after reading this section, you are unable to resolve a problem, please visit www.sprint.com or contact Sprint Customer Service. (See “Getting Help” on page 12.)

GO Button Is Unavailable

Ensure the USB modem is properly inserted, not locked (page 56), and not powered off (page 40).

If the **Mobile Broadband** window displays “Searching for service” for a long period of time (for example, several minutes), see “Searching for Service” below.

If **Roam Mode** is set to **Sprint**, ensure you are in the network coverage area (not roaming), or change the setting (page 70). (You may be subject to roaming rates.)

Searching for Service

If the **Mobile Broadband** window displays “Searching for service” for a long period of time (for example, several minutes), try one of the following:

- Try reorienting your computer, or try adjusting the angle of the USB modem’s USB connector (see the picture on page 19).
- If you are inside a building or near a structure that may be blocking the signal, change the position or location of your computer.
- If **Roam Mode** is set to **Sprint**, ensure you are within the network coverage area, or change the Roam Mode setting. (You may be subject to roaming rates.)
- If **Roam Mode** is set to **Roam Only**, ensure you are roaming, or change the Roam Mode setting.
- If **Network Mode** is set to **1X Only**, and only 1xEV-DO coverage is available, either move to an area that has 1X coverage, or change the setting to **Automatic** or **1xEV-DO Only**. **Note:** With the setting **1xEV-DO Only**, Sprint Location Services may not be supported.
- If **Network Mode** is set to **1xEV-DO Only**, and only 1X coverage is available, either move to an area that has 1xEV-DO coverage, or change the setting to **Automatic** or **1X Only**.
- Check with Sprint — a network or account problem may be preventing the USB modem from obtaining service.

Cannot Connect to the Network

If you're having problems connecting, or there's no Sprint Power Vision (1x-EVDO) coverage in your area, set **Network Mode** to **1X Only** and try to establish a connection.

If the connection is dropped as soon as it is established:

- ▶ Charge the battery for at least 30 minutes if the PWR LED is red. (If the connection still gets dropped as soon as it is established, continue with the following steps.)

– or –

1. Select:
(Windows Vista) **Start > Control Panel > Network and Sharing Center > Manage Network Connections**
(Windows XP) **Start > Control Panel > Network Connections**
(Windows 2000) **Start > Settings > Control Panel > Network and Dial-Up Connections**
2. Right-click **Sprint Mobile Broadband - Sierra Wireless**, and select **Properties**.
3. Select:
(Windows Vista) **Options**, and select **PPP Settings**.
(Windows XP) **Networking** tab, and select **Settings**.
4. Ensure that "Enable LCP Extensions" is selected and "Negotiate multi-link for single link connections" is **not** selected.
5. Click **OK**.

PWR LED Goes Off and On, and Then Stays Red

This situation may occur under extreme usage conditions when you're transmitting data in a coverage area with a weak signal.

1. Wait until the PWR LED turns green.
 2. Resume your connection.
- ▶ If the PWR LED still goes off, and then comes on again and stays red, charge the battery for at least 30 minutes.

Sprint Location Services Aren't Working or Don't Seem to Be Available

If Sprint Location Services aren't working or don't seem to be available, check whether you have, in the Settings window (page 65), a **Sprint Location Services** option in the drop-down list.

- ▶ If the drop-down list does not have the **Sprint Location Services** option, then your account, your USB modem, or both are not configured to support Sprint Location Services; contact Sprint Customer Service (page 13).

– or –

1. Select the **Sprint Location Services** option from the drop-down list and ensure that **Enable Location Services** and **Display 'Location & Search Services' on the menu** are selected. (If a Privacy Consent Agreement is displayed, you must read and accept it.)
2. If you will be using NMEA, select **Display GPS Receiver**. (For more information on NMEA, see “What is NMEA?” on page 90.)
3. Ensure that **Network Mode** (in the Sprint Mobile Broadband settings window) is set to **Automatic** or **1X Only**. (Sprint Location Services may not be available if **Network Mode** is set to **1xEV-DO Only**.)
4. Ensure you are in the network coverage area (not roaming). For the initial fix, you must be in 1X coverage.
5. To verify that your USB modem is able to obtain data for Sprint Location Services, in the Sprint Location Services settings window, click **Test GPS**.
6. If the results show the number of satellites and valid latitude, longitude, and elevation information, then check that the GPS application (for example, street mapping application) is configured to use the correct port. (The port number that the GPS application should use is displayed in the **GPS Receiver** window [page 35].)

For help on checking which port the GPS application is configured to use, see the documentation of the GPS application.

7. If the GPS application is configured to use the correct port, but the application doesn't seem to be reporting correct results, then there may be a problem with the GPS application.

Could Not Prepare Data Services

See “Unable to Prepare Data Services” (page 97).

Unable to Prepare Data Services

Note: The message may appear as “**Could not prepare data services. Please contact...**”

The USB modem was unable to access the IOTA server to obtain data account parameters for you. This may be because the signal strength is poor or because the IOTA server is not responding.

- Confirm you have sufficient signal strength. Try the actions listed for “Searching for Service” (page 94).
- Contact Sprint for assistance (page 13).

This message may indicate that your system does not support 128-bit encryption for high-security access to data provisioning. You will not be able to complete the activation of data services until you upgrade your system’s security. (See “High Encryption Requirements [Windows]” on page 10.)

Sprint Connection Manager Stops Working After Upgrading Windows

Note: After the following steps, any changes you made to Sprint Connection Manager settings will be lost; you will have to reapply the changes.

If you’ve upgraded Windows, and Sprint Connection Manager stopped working:

1. Uninstall Sprint Connection Manager (page 59).
2. Reinstall Sprint Connection Manager (page 17).

Installing and Using the USB Modem on a Mac



Installing and Using the Software on a Mac Computer

In This Section

- ◆ Getting Started
 - ◆ Installing the Software on a Mac
 - ◆ Installing the Drivers
 - ◆ USB Modem Activation and Provisioning
 - ◆ Connecting to the Sprint Network
 - ◆ Icons and Text in Watcher Lite
 - ◆ Menu Options
 - ◆ Attaching an External Antenna
 - ◆ Removing Your USB Modem
 - ◆ Sprint Service Areas
 - ◆ Manage Your Account Online
 - ◆ Troubleshooting Tips (Mac)
 - ◆ Frequently Asked Questions
-

This section explains how to install and use your Watcher Lite software and Sprint Mobile Broadband USB modem on a Mac computer.

Getting Started

Before you can use your USB modem, you must first install the USB modem's software and configure the USB modem for your computer. The installation process consists of:

- **Software installation** - Installing the Watcher Lite software on your Mac computer.
- **Insertion of the rechargeable battery into the USB modem**
- **USB modem insertion and driver installation** - Starting the Watcher Lite software and inserting the USB modem, which automatically installs the drivers on your computer.
- **USB modem activation and provisioning** - Activating your Sprint account and configuring the USB modem to use your account.

For technical support issues, please contact Apple. If you can't recall your lock code, contact Sprint Customer Service.

CAUTION:	Do not insert the USB modem into your computer's USB slot before installing the software.
-----------------	---

Note:	As part of the installation process you will be prompted to restart your computer; save any open documents.
--------------	---

The Sprint Mobile Broadband USB modem is supported on a MacBook™, MacBook Pro, PowerBook® G4, Power Mac® G5, or desktop iMac computer running Mac OS X version 10.4 or newer.

To check your version, from the Apple menu (🍏) choose **About This Mac**. If your version is earlier than 10.4, then:

- Visit www.apple.com/downloads/macosx/apple for upgrading instructions.
- or —

1. In Finder™, choose **Go > Applications > System Preferences**.
2. Double-click the System Preferences icon.
3. Double-click **Software Update**.
4. Click **Check Now**.

If your USB modem has not been activated, you may also need access to a telephone.

The software and drivers are on the CD included in your package. (To get the latest drivers and software, you can always go to www.sprint.com/downloads.)

Note: The Mac software (Watcher Lite) currently does not support Sprint Location Services.

Installing the Software on a Mac

To install the Watcher Lite software on your Mac computer:

1. If your USB modem has not yet been activated, ensure you are in the network coverage area (not roaming).
2. Insert the installation CD into your CD-ROM drive.
3. On the Mac desktop, double-click the Watcher Lite CD icon:




4. In the WL... Finder window, double-click **INSTALLER.dmg**.
5. In the Sierra Wireless Watcher Lite Finder window, double-click **SierraWirelessWatcherLiteInstall.mpkg**.
6. In the Welcome to the Sierra Wireless Watcher Lite Installer window, click **Continue**.



7. In the “Select a Destination” window, choose a destination volume. A green vertical arrow indicates which volume(s) you can install the software onto. If more than one volume has a green vertical arrow, select the volume that has the active operating system.




8. Click **Continue**.
9. In the “Easy Install on ...” window, click **Install**.




10. If the Authenticate window appears, enter your Mac user name and password, and then click **OK**.
11. In the window with the message that you will have to restart your computer, click **Continue Installation**.

12. Click **Restart**.



13. After your computer restarts, run Watcher Lite: in Finder, choose **Go > Applications > Sierra Wireless Watcher**.

Watcher Lite should start:



Installing the Drivers


To install the drivers on your Mac computer:

1. Slide the front panel off the USB modem.
2. Hold the battery so that the side with two white arrows faces up and the gold contact points on the end of the battery line up with the gold contact points on the USB modem. Insert the battery into the USB modem.

Warning: To avoid the risk of explosion, use the same battery model when replacing the battery. Properly dispose of the used battery.

3. Slide the front panel onto the USB modem until the panel clicks into place.

4. Slide the lever on the bottom of the USB modem in the direction indicated by the triangle to release the USB modem's USB connector.
5. Adjust the USB connector to the desired angle. (The USB connector is adjustable to three positions—approximately 90, 135, and 160 degrees. Do not force the hinge past the last position—this may break the connector.)





6. Gripping both sides of the USB modem, insert it into your computer's USB slot.

IMPORTANT!	When inserting or removing your USB modem, always grip the USB modem by its sides, as this prevents damage to the USB modem.
-------------------	--

Alternatively, you can attach the USB extension cable to your computer's USB slot, and then connect the USB modem to the USB extension cable.

Note:	If your computer's USB slot is vertical, use the USB extension cable. Do not insert the USB modem or USB extension cable into a USB hub or a USB slot on a keyboard.
--------------	--

Warning:	If the orientation of your computer's USB slot or the thickness of your computer are such that pressure is applied to the USB modem's end or side (as shown by the red circles in the drawings below), you may damage the USB modem or your computer. In such cases, do not insert the USB modem directly into your computer's USB slot; use the USB extension cable instead.
-----------------	---



When the USB modem is properly inserted, the PWR LED is lit, and the USB modem's battery starts to charge.

7. If the New Port Detected window appears, click **Continue**.



8. If the Authenticate window appears, enter your Mac user name and password, and then click **OK**.

Watcher Lite displays a status message or the “Device Not Activated” window.

9. Allow the battery to charge for approximately two hours before closing the window or making a selection in it.

USB Modem Activation and Provisioning

After you have charged the battery for approximately two hours, use the following table to determine your next actions:

Text/window displayed	Description/next action
“Disconnected”	<p>Your USB modem is preactivated. You are ready to connect to the network (in Watcher Lite, click Connect).</p> <ul style="list-style-type: none"> ▶ Proceed to “Connecting to the Sprint Network” on page 110.
“Device is Locked”	<p>Your USB modem is preactivated. Unlock the USB modem:</p> <ol style="list-style-type: none"> 1. If the Unlock Device window is not displayed: from the Extras item on the Sierra Wireless Watcher menu, choose Unlock Device. 2. In the Unlock Device window, enter the lock code (PIN), and click OK. <ul style="list-style-type: none"> ▶ If you can’t recall your lock code, try using the last four digits of your USB modem's phone number. If this doesn’t work, call Sprint Customer Service at 1-888-788-4727 (business use) or 1-888-715-4588 (personal use). 3. Proceed to “Connecting to the Sprint Network” on page 110.

Text/window displayed	Description/next action
“Device Not Activated” window	<p>Your USB modem is not activated.</p> <ul style="list-style-type: none"> ▶ Click Yes to indicate that you’d like to activate your USB modem. Watcher Lite will display “Updating User Profile.” <p>If provisioning is successful, Watcher Lite displays “Disconnected,” after which you are ready to connect to the network (click Connect). Proceed to “Connecting to the Sprint Network” on page 110.</p> <p>– or –</p> <p>If the Data Provisioning window displays “Provisioning failed,” use the Activation Assistant (below).</p>
“Not activated”	<p>Your USB modem is not activated.</p> <ul style="list-style-type: none"> ▶ Use the Activation Assistant (below).

Activation Assistant

The Activation Assistant will guide you through the activation process if your USB modem is not preactivated.

Note:	If you close the Activation Assistant before finishing the USB modem activation, you can start the Activation Assistant later (from the Extras item on the Sierra Wireless Watcher menu, choose Activation).
--------------	---

To set up your account, you will be contacting Sprint.

Before you call Sprint, have these things ready:


- A phone
- Your USB modem
- The city and state where the USB modem will be primarily used
- A pen and paper to write down your account information. Your package includes a printed Getting Started guide, where you can record this information.

When you call Sprint, Sprint Customer Service will help you select your service plan and guide you through the activation process. They will also provide you with this information:

- Your USB modem's activation code (gives you access to configure the account)
- Your USB modem's phone number (MDN)
- Your USB modem's MSID (Mobile System ID) code, used for WLNP (Wireless Local Number Portability) and to determine whether you are "home" or "roaming"

To activate your USB modem and account:

1. From the Extras item on the Sierra Wireless Watcher menu, choose **Activation**.
2. In the Activation Assistant window, click **Continue**.



3. Call Sprint at the appropriate number displayed in the Activation Assistant.
4. Follow the instructions of the account representative to activate your USB modem.

After Sprint sets up your account on the network, your USB modem is activated.

5. To complete the activation process, enter the information (from the account representative) into the fields on the screen.
6. From the **Extras** item on the Sierra Wireless Watcher menu, choose **Data provisioning**.
7. In the Data Provisioning window, click **OK**.

The USB modem then retrieves the updates to your account. Watcher Lite will display "Updating User Profile," then "Disconnected," after which you are ready to connect to the network (click **Connect**). Proceed to the next section ("Connecting to the Sprint Network").

Connecting to the Sprint Network

To connect to the Sprint network:

- ▶ In Watcher Lite, click **Connect**.

Once you're connected to the network, Watcher Lite shows the amount of time you've been connected, and the amount of data received (Rx) and transmitted (Tx).



To end your network connection:

- ▶ In Watcher Lite, click **Disconnect**.

Icons and Text in Watcher Lite

Depending on the USB modem and connection state, Watcher Lite may display some of the following icons and text:

Icon/text	Description
	CDMA network signal strength, indicated by the number of bars.
	You are not in coverage.
	You are in 1X and 1xEV-DO Rev. 0 coverage.
	You are in 1X and 1xEV-DO Rev. A coverage.
	You are in 1X coverage.
	You are in 1xEV-DO Rev. 0 coverage.
	You are in 1xEV-DO Rev. A coverage.
	You are roaming. Roaming charges may apply.
	You are in the network coverage area (not roaming).

Icon/text	Description
Disconnected	Ready to connect to the network. To connect, in Watcher Lite click Connect .
Connected	Connected to the network.
No device detected	Ensure the USB modem is properly inserted into your computer.
Not activated	To use your USB modem, you must activate it. ▶ Use the Activation Assistant (page 108).
Device is Locked	From the Extras item on the Sierra Wireless Watcher menu, choose Unlock Device .
Rx	Amount of data received from the network.
Tx	Amount of data transmitted to the network.

Menu Options

From the **Extras** item on the Sierra Wireless Watcher menu, you can:

- Activate your USB modem (page 108)
- Provision your USB modem (page 109)
- Lock/unlock your USB modem (page 107)
- View information about the USB modem
- View, configure, and use the data and VPN connections available on your computer (for example, WWAN)

Attaching an External Antenna

You can improve the signal strength by attaching an external antenna (sold separately).

To attach an external antenna:

1. Remove the USB modem from your computer (page 112).
2. Flip open the rubber tab on the side of the USB modem.

3. Hold the antenna cable by the connector (end) part, and carefully insert the connector part of the cable into the corresponding connector on the USB modem.
4. Reinsert the USB modem into your computer.

Removing Your USB Modem

To remove the USB modem from your Mac:

1. End your network connection, as described in “Connecting to the Sprint Network” on page 110.
2. Remove the USB modem from your computer’s USB slot by gripping both sides of the USB modem and pulling straight out.

IMPORTANT!

When inserting or removing your USB modem, always grip the USB modem by its sides, as this prevents damage to the USB modem.

Sprint Service Areas

Interested in where you can use your new USB modem? Check out the most up-to-date coverage maps at www.sprint.com.

Manage Your Account Online

With Sprint Customer Service, you can visit www.sprint.com to manage your Sprint account.

Once you sign on, you can:

- View the details of your Sprint service plan.
- Find out how much data you have used and how many megabytes are remaining in your plan.
- View your current and previous three months’ invoices.
- Make a payment.
- Find out about Sprint products and services.

Troubleshooting Tips (Mac)

When properly installed, the Sprint Mobile Broadband USB modem is a highly reliable product.

Most problems are caused by one of these issues:

- Network coverage is not available (because you are outside the network, or because of an account or network problem).
- The drivers were not properly installed because of a problem with your computer's USB slot.

Tips when troubleshooting problems with your USB modem and software:

- Ensure your USB modem is inserted, and not locked (page 107).
- Ensure the PWR LED is green.
- Check the Frequently Asked Questions (page 114).
- Use the resources listed in “Getting Help” (page 12).

If, after reading this section, you are unable to resolve a problem, please visit www.sprint.com or contact Sprint Customer Service. (See “Getting Help” on page 12.)

“Connect” Button Is Unavailable

Note:	In some cases, the Connect button can establish a connection to the network, even if the button seems unavailable.
--------------	---

If nothing seems to happen when you click the button, ensure the USB modem is properly inserted, and not locked. If Watcher Lite displays “Device Is Locked,” see page 107.

Searching for Service

If Watcher Lite displays “Searching for service” for a long period of time (for example, several minutes), try one of the following:

- Try reorienting your computer, or try adjusting the angle of the USB modem's USB connector (see the picture on page 106).
- If you are inside a building or near a structure that may be blocking the signal, change the position or location of your computer.
- Check with Sprint — a network or account problem may be preventing the USB modem from obtaining service.

Cannot Connect to the Network

If the connection is dropped as soon as it is established, charge the battery for at least 30 minutes if the PWR LED is red.

PWR LED Goes Off and On, and Then Stays Red

This situation may occur under extreme usage conditions when you're transmitting data in a coverage area with a weak signal.

1. Wait until the PWR LED turns green.
2. Resume your connection.
 - ▶ If the PWR LED still goes off, and then comes on again and stays red, charge the battery for at least 30 minutes.

Frequently Asked Questions

What is Watcher Lite?

Watcher Lite is software that lets you connect to the Sprint Power Vision or Sprint Vision network. Watcher Lite takes advantage of the increased data speeds offered by the Sprint Mobile Broadband Network.

Does the Watcher Lite software support LBS?

No. The Watcher Lite software does not support LBS (Location-Based Services).

If the connection is “always on,” am I always being billed?

No. The connection to the network goes dormant after a period of inactivity, but the connection can be re-established faster than having to reconnect. Billing occurs only when data is passed across the network.

How fast is the connection with Sprint Connection Manager?

The Sprint Mobile Broadband Network allows you to connect to the Internet at speeds of up to 3.1 Mbps (1xEV-DO Rev. A), 2.4 Mbps (1xEV-DO Rev. 0), or 144 kbps (1X). Average connection speeds are:

- For 1xEV-DO Rev. A: between 600 kbps and 1.4 Mbps downlink from the network, and between 350 and 500 kbps uplink to the network;
- For 1xEV-DO Rev. 0: between 400 and 700 kbps downlink from the network, and between 40 and 80 kbps uplink to the network;
- For 1X: between 40 and 80 kbps.

These speeds are faster than dial-up connection speeds.

How can I optimize my settings to achieve the fastest speeds and conserve data when accessing my corporate network?

Depending on your corporate email client, you can optimize your settings by doing the following:

- Work in “offline” mode, and connect only when you need to send or receive email.
- Remove the Preview Pane, or use the AutoPreview for headers only.
- Save attachments to a desktop folder and then open from that folder, rather than opening the attachment directly from the message.

For more information, see the user documentation of your email client.

Once I connect to the network, how do I access my corporate network through a VPN?

Once you complete a wireless connection, you may need to launch an extranet client provided by your company and supply the appropriate user name and password to gain access. For support, contact your company help desk.

Can I connect to a dial-up account like AOL or EarthLink?

No. The software does not support dial-up connections.

Technical Specifications and Regulatory Information



Technical Specifications

In This Section

- ◆ LED Operation
 - ◆ Radio Frequency and Electrical Specifications
 - ◆ Software Specifications
 - ◆ Environmental Specifications
 - ◆ Mechanical Specifications
-

This section describes the LED and various specifications of your Sprint Mobile Broadband USB modem.

LED Operation

Your USB modem has two LED lights. The LEDs operate as follows:

LED	State	Indicates
Data	Off	The USB modem has no power. The USB modem may not be completely inserted into the computer, the computer may be in suspend mode (Windows) or sleep mode (Mac); this mode powers down the USB modem.
	Solid green	The USB modem has power, has found a signal, and is ready to connect.
	Green, blinking slowly	The USB modem is powering up, or no service is available. See “Searching for Service” on page 94 (if you’re running Windows), or “Searching for Service” on page 113 (if you’re running Mac).
	Green, blinking rapidly	The USB modem is sending or receiving data.
PWR	Off	The USB modem has no power. The USB modem may not be completely inserted into the computer, the computer may be in suspend mode (which powers down the USB modem), or, if you’re running Windows, you have powered the USB modem off (page 45).
	Red	The USB modem has power; the battery is low. Charge the battery by inserting the USB modem into the USB slot of your computer. Alternatively, connect the USB modem to the USB extension cable, and attach the USB extension cable to your computer.
	Green	The USB modem has power; the battery is charged.

Radio Frequency and Electrical Specifications

Approvals	<p>Compliant with:</p> <p>IS-2000 Release 1.0 (CDMA (1X), IS-707-A Data, IS-856 (CDMA 1xEV-DO), IS-866, IS-878, IS-890, CDMA Development Group</p> <p>FCC (ID: N7N-MC5725U)</p> <p>Industry Canada (ID: 2417C-MC5725U)</p>
Voltage	+5.0 Vdc from USB slot
Current	<p>Maximum: 500 mA (from USB port)</p> <p>Typical data call current (talk mode), at 3.3 V:</p> <p style="padding-left: 40px;">285 mA (1X)</p> <p style="padding-left: 40px;">295 mA (1xEV-DO)</p> <p>Standby: 2.75 mA (1xEV-DO/IS-2000 hybrid mode), at 3.3 V</p>
Transmitter power	200 mW (+23 dBm)
Transmit	<p>PCS: 1805 to 1870 MHz</p> <p>Cellular: 824 to 849 MHz</p>
Receive	<p>PCS: 1715 to 1780 MHz</p> <p>Cellular: 868 to 894 MHz</p> <p>GPS: 1575.42 MHz</p>
Channel spacing	1.25 MHz
Frequency stability	±150 Hz

Software Specifications

CDMA specification	IS-2000 Release 0
Data service	IS-707A
SMS (IS-637)	Not supported
FAX	Not supported
IOTA	Supported
OTASP (IS-683A, IS-683B, IS-683C)	Supported
OTAPA	Supported
PRL (preferred roaming list)	Supported
Authentication	Supported
Voice	Not supported
NAM	Single
E911	Not supported
Position Location	Supported on Windows only (Mobile Station based)
TTY/Accessibility	Not supported
Mobile IP	Supported

Environmental Specifications

Operating temperature	-10 to +60°C
Storage temperature	-20 to +85°C
Humidity	85%, non-condensing
Vibration	Random vibration, 10 to 1000 Hz, nominal 6G RMS in each of 3 mutually perpendicular axes. Test duration of 60 minutes for each axis, for a total test time of 3 hours (non-operating).
Drop	1 m on concrete on each of 6 faces, 2 times

Mechanical Specifications

Dimensions (W x L x H)	39 mm x 93 mm x 20 mm
Power button	Not supported
Headset jack	Not supported
LED	Red/green

Regulatory Information

In This Section

- ♦ **Regulatory Notices**
 - ♦ **Patents**
 - ♦ **Trademarks**
 - ♦ **Copyright**
 - ♦ **Limitation of Liability**
 - ♦ **Additional Information and Updates**
-

This section contains important regulatory notices about your Sprint Mobile Broadband USB modem, and also patent and other information.

Regulatory Notices

The design of the AirCard 595U USB modem complies with U.S. Federal Communications Commission (FCC) and Industry Canada (IC) guidelines respecting safety levels of radio frequency (RF) exposure for portable devices, which in turn are consistent with the following safety standards previously set by Canadian, U.S. and international standards bodies:

- ANSI / IEEE C95.1-1999, *IEEE Standard for Safety Levels with Respect to Human Exposure to Radio Frequency Electromagnetic Fields, 3kHz to 300 GHz*
- National Council on Radiation Protection and Measurements (NCRP) Report 86, 1986, *Biological Effects and Exposure Criteria for Radio Frequency Electromagnetic Fields*
- Health Canada, Safety Code 6, 1999, *Limits of Human Exposure to Radio frequency Electromagnetic Fields in the Frequency Range from 3 kHz to 300 GHz*
- International Commission on Non-Ionising Radiation Protection (ICNIRP) 1998, *Guidelines for limiting exposure to time-varying electric, magnetic, and electromagnetic fields (up to 300 GHz)*

FCC ID: N7N-MC5725U

CAUTION: The AirCard 595U USB modem has been tested for compliance with FCC/IC RF exposure limits in the laptop computer(s) configurations with a horizontal USB slot and can be used in laptop computers with substantially similar physical dimensions, construction, and electrical and RF characteristics. This USB modem must not be colocated or operated in conjunction with any other antenna or transmitter. Use of this device in any other configuration may exceed the FCC RF Exposure compliance limit. **Note:** If this USB modem is intended for use in any other portable device, you are responsible for separate approval to satisfy the SAR requirements of Part 2.1093 of FCC rules.

WARNING (EMI) - United States FCC Information - This equipment has been tested and found to comply with the limits for a class B computing device peripheral, pursuant to Parts 15, 22, and 24 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

This device complies with Part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

CAUTION: Any changes or modifications not expressly approved by Sprint Communications Company L.P. could void the user's authority to use the equipment.

WARNING (EMI) - Canada: This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the interference causing equipment standard entitled "Digital Apparatus," ICES-003 of the Department of Communications.

Cet appareil numérique respecte les limites de bruits radioélectriques applicables aux appareils numériques de Classe B prescrites dans la norme sur le matériel brouilleur: "Appareils Numériques," NMB-003 édictée par le ministre des Communications.

If you have purchased this product under a United States Government contract, it shall be subject to restrictions as set forth in subparagraph (c)(1)(ii) of Defense Federal Acquisitions Regulations (DFARs) Section 252.227-7013 for Department of Defense contracts, and as set forth in Federal Acquisitions Regulations (FARs) Section 52.227-19 for civilian agency contracts or any successor regulations. If further government regulations apply, it is your responsibility to ensure compliance with such regulations.

Patents

Portions of this product are covered by some or all of the following US patents:

5,515,013	5,629,960	5,845,216	5,847,553	5,878,234
5,890,057	5,929,815	6,169,884	6,191,741	6,199,168
6,339,405	6,359,591	6,400,336	6,516,204	6,561,851
6,643,501	6,653,979	6,697,030	6,785,830	6,845,249
6,847,830	6,876,697	6,879,585	6,886,049	6,986,171
6,985,757	7,023,878	7,053,843	7,106,569	7,145,267
7,200,512	D442,170	D459,303		

and other patents pending.

Licensed by QUALCOMM Incorporated under one or more of the following United States patents and/or their counterparts in other nations:

QUALCOMM®
3G CDMA

4901307	5056109	5101501	5109390	5228054
5267261	5267262	5337338	5414796	5416797
5490165	5504773	5506865	5511073	5535239
5544196	5568483	5600754	5657420	5659569
5710784	5778338			

Manufactured or sold by Sierra Wireless or its licensees under one or more patents licensed from InterDigital Group.

Trademarks

SPRINT and other trademarks are trademarks of Sprint Nextel.

AirCard® and “Heart of the Wireless Machine”® are registered trademarks of Sierra Wireless. Watcher® is a trademark of Sierra Wireless, registered in the European Community.

Sierra Wireless, the Sierra Wireless logo, and the red wave design are trademarks of Sierra Wireless.

Windows® is a registered trademark of Microsoft Corporation.

Mac OS is a trademark of Apple Inc., registered in the U.S. and other countries.

QUALCOMM® is a registered trademark of QUALCOMM Incorporated.

All other trademarks are property of their respective owners.

Copyright

©2007 Sprint Nextel. All rights reserved. No reproduction in whole or in part without prior written approval. SPRINT and other trademarks are trademarks of Sprint Nextel.

©2007 Sierra Wireless. All rights reserved.

Document 2130934 Revision 1.0

Limitation of Liability

The information in this manual is subject to change without notice and does not represent a commitment on the part of Sierra Wireless. SIERRA WIRELESS AND ITS AFFILIATES SPECIFICALLY DISCLAIM LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS OR REVENUE OR ANTICIPATED PROFITS OR REVENUE ARISING OUT OF THE USE OR INABILITY TO USE ANY SIERRA WIRELESS PRODUCT, EVEN IF SIERRA WIRELESS AND/OR ITS AFFILIATES HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY.

Notwithstanding the foregoing, in no event shall Sierra Wireless and/or its affiliates aggregate liability arising under or in connection with the Sierra Wireless product, regardless of the number of events, occurrences, or claims giving rise to liability, be in excess of the price paid by the purchaser for the Sierra Wireless product.

Additional Information and Updates

For up-to-date product descriptions, documentation, application notes, firmware upgrades, troubleshooting tips, and press releases, visit:

www.sierrawireless.com

Safety Information and Terms & Conditions



Safety and Notices

In This Section

- ♦ Important Notice
 - ♦ Safety and Hazards
-

This section describes important guidelines regarding your Sprint Mobile Broadband USB modem.

Important Notice

Because of the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the Sprint Mobile Broadband USB modem by Sierra Wireless (AirCard 595U) CDMA modem are used in a normal manner with a well-constructed network, they should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. SPRINT SPECTRUM L.P. accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the Sprint Mobile Broadband USB modem by Sierra Wireless (AirCard 595U) CDMA modem, or for failure of the Sprint Mobile Broadband USB modem by Sierra Wireless (AirCard 595U) to transmit or receive such data.

Safety and Hazards

Do not operate the Sprint Mobile Broadband USB modem by Sierra Wireless (AirCard 595U) in areas where blasting is in progress, where explosive atmospheres may be present, near medical equipment, life support equipment, or any equipment which may be susceptible to any form of radio interference. In such areas, the Sprint Mobile Broadband USB modem by Sierra Wireless (AirCard 595U) **MUST BE POWERED OFF**. It can transmit signals that could interfere with this equipment.

Do not operate the Sprint Mobile Broadband USB modem by Sierra Wireless (AirCard 595U) in any aircraft, whether the aircraft is on the ground or in flight. In aircraft, the Sprint Mobile Broadband USB modem by Sierra Wireless (AirCard 595U) **MUST BE POWERED OFF**. When operating, it can transmit signals that could interfere with various onboard systems.

The driver or operator of any vehicle should not operate the Sprint Mobile Broadband USB modem by Sierra Wireless (AirCard 595U) while in control of a vehicle. Doing so will detract from the driver or operator's control and operation of that vehicle. In some jurisdictions, operating such communications devices while in control of a vehicle is an offense.

To avoid the risk of explosion, use the same battery model when replacing the battery. Properly dispose of the used battery.

Terms and Conditions

In This Section

- ◆ **Subscriber Agreement/General Terms and Conditions of Services**
-

This section contains the terms and conditions of service for your Sprint Mobile Broadband USB modem.

Subscriber Agreement

General Terms and Conditions of Services

Please note these terms may not be the most current version. A current version of the terms is available at our Web site or upon request.

Para solicitar esta literatura en español, por favor visitar a www.sprint.com.

Basic Definitions

In this document: (1) “we,” “us,” “our” mean Sprint Solutions, Inc. and its affiliates doing business as Sprint or Sprint PCS; (2) “you,” “your,” “customer,” and “user” mean an account holder or user with us; (3) “Device” means any phone, device, accessory or other product we sell to you or that is active on your account with us; and (4) “Service” means our offers, rate plans, options, wireless services or Devices on your account with us.

The Subscriber Agreement

The Subscriber Agreement (“Agreement”) is a contract under which we provide and you accept our Services. In addition to these Terms and Conditions of Service (“Ts&Cs”), there are several parts to the Agreement, including, but not limited to, the detailed plan or other information on Services we provide or refer you to during the sales transaction, and any confirmation materials we may provide you. It is important that you carefully read all of the terms of the Agreement.

Services Covered By These Ts&Cs & Additional Terms

These Ts&Cs apply to our standard wireless Services and any other Service we offer you that references these Ts&Cs. Different terms will apply to most business accounts. Additional terms will apply when you use certain Services, typically those you can access online (for example, picture/video Services, online forums, etc.). Additional terms will also apply if you activate Services as part of a bundle with another company’s services (for example, cable services, home phone services, etc.). The additional terms for bundled Services may either modify or replace certain provisions in these Ts&Cs, including terms relating to activation, invoicing/payment, and disputing charges. Also, a different dispute resolution provision may apply to services provided by another company (the dispute resolution provisions in this Agreement still apply to our Services). You will be provided details on any additional terms with your selection of any bundled Service.

Our Policies

Services are subject to our business policies, practices and procedures (“Policies”), including, but not limited to, our Privacy Policy and Acceptable Use Policy and Visitor Agreement – both available at our Web site. You agree to all of our Policies when you use our Services. Our Policies are subject to change at anytime with or without notice.

When You Accept The Agreement

You must have the legal capacity to accept the Agreement. You accept the Agreement when you do any of the following: (a) sign a contract with us on paper or electronically; (b) accept Agreement through an oral or electronic statement; (c) attempt to or in any way use the Services; (d) pay for the Services; or (e) open any package or start any program that says you are accepting the Agreement when doing so. **If you don’t want to accept the Agreement, don’t do any of these things.**

Term Commitments & Early Termination Fees

Many of the Services (for example, rate plans and Device discounts) that we offer require you to maintain certain Services with us for a minimum term, usually 1 or 2 years (“Term Commitment”). **You will be charged a fee (“Early Termination Fee”) for each line of Service that you terminate early (i.e., prior to satisfying the Term Commitment) or for each line of Service that we terminate early for good reason (for example, violating the payment or other terms of the Agreement).** Early Termination Fees are a part of our rates. Your exact Term Commitment and Early Termination Fee may vary based on the Services you select and will be disclosed to you during the sales transaction. **Carefully review any Term Commitment and Early Termination Fee requirements prior to selecting Services.** After you have satisfied your Term Commitment, your Services continue on a month-to-month basis without any Early Termination Fee, unless you agree to extend your Term Commitment or agree to a new Term Commitment – for example, by accepting a new rate plan or upgrading your Device. As explained directly below, there are instances when you will not be responsible for an Early Termination Fee for terminating Services early.

When You Don’t Have To Pay An Early Termination Fee

You aren’t responsible for paying an Early Termination Fee when terminating Services: (a) provided on a month-to-month basis; (b) consistent with our published trial period return policy; or (c) in response to a materially adverse change we make to the Agreement as described directly below.

Our Right To Change The Agreement & Your Related Rights

We may change any part of the Agreement at any time, including, but not limited to, rates, charges, how we calculate charges, or your terms of Service. We will provide you notice of material changes, and may provide you notice of non-material changes, in a manner consistent with this Agreement (see “Providing Notice Under This Agreement” paragraph). Except as provided below, if a change we make to the Agreement is material and has a material adverse effect on you, you may terminate each line of Service materially affected without incurring an Early Termination Fee only if you: (a) call us within 30 days after the effective date of the change; and (b) specifically advise us that you wish to cancel Services because of a material change to the Agreement that we have made. If you do not cancel Service within 30 days of the change, an Early Termination Fee will apply if you terminate Services before the end of any applicable Term Commitment.

Our Right To Suspend Or Terminate Services

We can, without notice, suspend or terminate any Service at any time for any reason, including, but not limited to: (a) late payment; (b) exceeding an Account Spending Limit (“ASL”); (c) harassing/threatening our employees or agents; (d) providing false information; (e) interfering with our operations; (f) using/suspicion of using Services in any manner restricted by or inconsistent with the Agreement; (g) breaching the Agreement, including our Policies; (h) providing false, inaccurate, dated or unverifiable identification or credit information, or becoming insolvent or bankrupt; (i) modifying a Device from its manufacturer specifications; or (j) if we believe the action protects our interests, any customer’s interests or our network.

Your Ability To Change Services & When Changes Are Effective

You typically can change Services upon request. In some instances, changes may be conditioned on payment of an Early Termination Fee or certain other charges, or they may require you to accept a new Term Commitment. Changes to Services are usually effective at the start of your next full invoicing cycle. If the changes take place sooner, your invoice may reflect pro-rated charges for your old and new Services.

Your Right To Terminate Services

You can terminate Services at any time by calling us and requesting that we deactivate all Services. You’re responsible for all charges billed or incurred prior to deactivation. If Services are terminated before the end of your invoicing cycle, we

won't prorate charges to the date of termination and you won't receive a credit or refund for any unused Services. **Except as provided above, you must also pay us an Early Termination Fee for each line of Service that you terminate early.**

Credit Checks & Credit Information

We agree to provide you Services on the condition you have and maintain satisfactory credit according to our standards and policies. You agree to provide information we may request or complete any applications we may provide you to facilitate our review. We rely on the credit information you furnish, credit bureau reports or other data available from commercial credit reference services, and other information (such as payment history with us) to determine whether to provide or continue to provide you Services. The Services we offer you can vary based on your credit history. We may at any time, based on your credit history, withdraw or change Services, or place limits or conditions on the use of our Services. You agree to provide us updated credit information upon request. We may provide your payment history and other account billing/charge information to any credit reporting agency or industry clearinghouse.

Account Spending Limits ("ASL")

An ASL is a temporary or permanent limit (typically based on credit history, payment history, or to prevent fraud) we place on the amount of unpaid charges you can accumulate on your account, regardless of when payment on those charges is due. We reserve the right to determine which charges count towards an ASL. If you have an ASL, we may suspend your Services without prior notice if your account balance reaches the ASL, even if your account is not past due. We may impose or increase an ASL at any time with notice. An ASL is for our benefit only and should not be relied on by you to manage usage.

Deposits & Returning Deposits

We may at any time require a deposit, as a guarantee of payment, for you to establish or maintain Service ("Deposit"). By providing us a Deposit, you grant us a security interest for all current or future amounts owed to us. We may change the Deposit at any time with notice. You can't use a Deposit to make or delay payments. The Deposit, the length of time we hold the Deposit, and changes to the Deposit are determined based on your credit history, payment history and other factors. Unless prohibited by law, we may mix Deposits with our other funds and it won't earn interest and we reserve the right to return the Deposit as a credit on your invoice at anytime. If your Services are terminated for any reason, we may keep and apply your Deposit to any outstanding charges. We'll send any

remaining portion of Deposit to your last known address within 90 days after your final invoice – if it is returned to us, we will forward it on to the appropriate state authorities to the extent required by law.

Restrictions On Using Services

You can't use our Services: (a) to transmit content/messages that are, or in any manner that is, illegal, fraudulent, threatening, abusive, defamatory, or obscene; (b) in a way that could cause damage or adversely affect our customers, reputation, network, property or Services; (c) to communicate any unsolicited commercial voice, text, SMS, or other message; (d) to infringe on the copyright of another, or upload or transmit any "virus", "worm", or malicious code; or (e) in any way prohibited by the terms of our Services, the Agreement or our Policies.

Your Device, Number & E-mail Address; Caller ID

We don't manufacture any Device we might sell to you or that is associated with our Services, and we aren't responsible for any defects, acts or omissions of the manufacturer. **The only warranties on your Device are the limited warranties given to you by the manufacturer directly or that we pass through.** Your Device is designed exclusively for use on our network and in other coverage areas we make available to you. It will not accept wireless service from another carrier. Except for any legal right you may have to port/transfer your phone number to another carrier, you have no and cannot gain any (for example, through publication, use, etc.) proprietary, ownership or other rights to any phone number, identification number, e-mail address or other identifier we assign to you, your Device or your account. We'll notify you if we decide to change or reassign them.

Porting/Transferring Phone Numbers

We don't guarantee that number transfers to or from us will be successful. If you authorize another carrier to transfer a number away from us, that is considered a request by you to us to terminate all of the Services associated with that number. You're responsible for all charges billed or incurred prior to deactivation and for any applicable Early Termination Fees.

Coverage; Where Your Device Will Work

Our coverage maps are available at our stores and at our Web site. The specific network coverage you get will depend on the radio transmissions your Device can pick up and Services you've chosen. **Our coverage maps provide high level estimates of our coverage areas when using Services outdoors under optimal conditions.**

Coverage isn't available everywhere. Estimating wireless coverage and signal strength is not an exact science. There are gaps in coverage within our estimated coverage areas that, along with other factors both within and beyond our control (network problems, software, signal strength, your Device, structures, buildings, weather, geography, topography, etc.), may result in dropped and blocked connections, slower data speeds, or otherwise impact the quality of Service. Services that rely on location information, such as E911 and GPS navigation, depend on your Device's ability to acquire satellite signals (typically not available indoors) and network coverage.

Roaming

"Roaming" typically refers to coverage on another carrier's network that we make available to you based on our agreements with other carriers. These agreements may change from time to time and roaming coverage is subject to change. Your ability to receive roaming coverage depends on the radio transmissions your Device can pick up. You can pick up roaming coverage both within and outside our network coverage areas. Your Device will generally indicate when you're roaming. Depending on your Services, separate charges or limits on the amount of minutes used while roaming may apply. Certain Services may not be available or work the same when roaming (including data Services, voicemail, call waiting, etc.).

About Data Services & Content

Our data Services and your Device may allow you to access the internet, text, pictures, video, games, graphics, music, email, sound and other materials ("Data Content") or send Data Content elsewhere. Some Data Content is available from us or our vendors, while other Data Content can be accessed from others (third party Web sites, games, ringers, etc.). We make absolutely no guarantees about the Data Content you access on your Device. **Data Content may be: (1) unsuitable for children/minors; (2) unreliable or inaccurate; or (3) offensive, indecent or objectionable. You're solely responsible for evaluating the Data Content accessed by you or anyone on your account. We strongly recommend you monitor data usage by children/minors.** Data Content from third parties may also harm your Device or its software. To protect our network, Services, or for other reasons, we may place restrictions on accessing certain Data Content (such as certain Web sites, applications, etc.), impose separate charges, limit throughput or the amount of data you can transfer, or otherwise limit or terminate Services. If we provide you storage for Data Content you have purchased, we may delete the Data Content with notice or place restrictions/limits on the use of storage areas. You may not be able to make or receive voice calls while using data Services.

Specific Terms & Restrictions On Using Data Services

In addition to the rules for using all of our other Services, unless we identify the Service or Device you have selected as specifically intended for that purpose (for example, wireless routers, Data Link, etc.), you can't use our data Services: (1) with server devices or host computer applications, or other systems that drive continuous heavy traffic or data sessions; and (2) as a substitute or backup for private lines or frame relay connections. We reserve the right to limit or suspend any heavy, continuous data usage that adversely impacts our network performance or hinders access to our network. If your Services include unlimited Web or data access, you also can't use your Device as a modem for computers or other equipment, unless we identify the Service or Device you have selected as specifically intended for that purpose (for example, with "phone as modem" plans, Sprint Mobile Broadband card plans, wireless router plans, etc.).

Activation & Miscellaneous Charges

Based on our Policies, we may charge activation, prepayment, reactivation, program or other fees to establish or maintain Services. Certain transactions may also be subject to a charge (for example, convenience payment, changing phone numbers, handset upgrades, etc.). You will be provided notice of these types of fees before we complete the requested transaction.

Account & Service Charges; Pro-rating; Unused Minutes

You are responsible for all charges associated with your account and the Services on your account, no matter who uses the Services. Charges include, but are not limited to, the monthly recurring charges, usage charges, taxes, surcharges and fees associated with your Services. These charges are described or referred to during the sales transaction, in our marketing materials, and in confirmation materials we may send to you.

How We Calculate Your Charges For Billing Purposes

Regular Voice Calls: We round up partial minutes of use to the next full minute. Time starts when you press "Talk" or your Device connects to the network and stops when you press "End" or the network connection otherwise breaks. You're charged for all calls that connect, even to answering machines. You won't be charged for unanswered calls or if you get a busy signal. For incoming calls answered, you're charged from the time shortly before the Device starts ringing until you press "End" or the network connection otherwise breaks. If charges vary depending on the time of day that you place or receive calls (e.g., Nights and

Weekend plans), you're charged for the entire call based on the rate that applies to the time period in which the call starts.

iDEN Walkie-Talkie Charges: Charges for walkie-talkie calls are billed to the person who starts the call and calculated by multiplying the duration of the call by the applicable rate and number of participants. You're charged at least 6 seconds of airtime for each call you start; subsequent communications in the same call are rounded up to and billed to the next second. Time begins when you press any button to start a walkie-talkie call and ends approximately 6 seconds after completion of a communication to which no participant responds – subsequent walkie-talkie communications are considered new calls. Depending on your plan, nationwide, international or group walkie-talkie calls may use the local walkie-talkie minutes in your plan and result in additional charges. Responses to call alert transmissions are treated as new walkie-talkie transmissions even when responding within 6 seconds of receiving the alert.

Data Usage: Unless we specifically tell you otherwise, data usage is measured in bytes, kilobytes and megabytes – not in minutes/time. 1024 bytes equals 1 kilobyte ("KB"), and 1024 KB equals 1 megabyte. Bytes are rounded up to kilobytes, so you will be charged at least 1 KB for each data usage session ("data session"). Rounding occurs at the end of each data session, and sometimes during a data session. Depending on your data Services, usage may be charged against an allowance or on a fixed price per KB. If you are charged on a fixed price per KB, any fractional cents will be rounded up to the next cent. You are charged for all data directed to your Device's internet address, including data sessions you did not initiate and for incomplete transfers. As long as your Device is connected to our data network, you may incur data charges. Examples of data you will be charged for includes the size of a requested file or Data Content (game, ringer, etc.), Web page graphics (logos, pictures, banners, advertisement, etc.), additional data used in accessing, transporting and routing the file on our network, data from partial or interrupted downloads, re-sent data, and data associated with unsuccessful attempts to reach Web sites or use applications. These data charges are in addition to any charges for the Data Content itself (game, ringer, etc.). Data used and charged to you will vary widely, even between identical actions or data sessions. Estimates of data usage – for example, the size of downloadable files – are not reliable predictors of actual usage. Your bill won't separately list the number of KB attributed to a specific action/data session.

Your Bill

Your bill provides you notice of your charges. It reflects monthly recurring charges (usually billed one bill cycle in advance) and usage/transaction specific charges (usually billed in the bill cycle in which they're incurred). Some usage charges, such as those that depend on usage information from a third party, may be billed in subsequent bill cycles and result in higher than expected charges for that month. Bill cycles and dates may change from time to time. **Your bill may also include other important notices (for example, changes to this Agreement, to your Service, legal notices, etc.).** Your paper bill may not include individual call detail. Your call detail is available online. Paper bills with call detail may be subject to an additional charge. If you choose internet billing, you will not receive paper bills.

Your Payments; Late Fees

Payment is due in full as stated on your bill. If we do not receive payment in full by the date specified on your bill, a late payment charge, which may be charged at the highest rate permissible by law, may be applied to the total unpaid balance. We may also charge you any costs we pay to a collection agency to collect unpaid balances from you. If we bill you for amounts on behalf of a third party, payments received are first applied to our charges. You may be charged additional fees for certain methods of payment. We may charge you, up to the highest amount permitted by law, for returned checks or other payments paid by you and denied for any reason by a financial institution. Acceptance of payments (even if marked "paid in full") does not waive our right to collect all amounts that you owe us. We may restrict your payment methods to cashier's check, money order, or other similar secure form of payment at any time for good reason.

Taxes & Government Fees

You agree to pay all federal, state and local taxes, fees and other assessments that we're required by law to collect on the Services we provide you and remit to the government. These charges may change from time to time without advance notice. If you're claiming any tax exemption, you must provide us with a valid exemption certificate. Tax exemptions generally won't be applied retroactively.

Surcharges

You agree to pay the surcharges, fees and other charges that we assess to recoup our government costs or costs of complying with certain government programs ("Surcharges"). **Surcharges aren't taxes or government mandated charges; they're charges we choose to collect from you. Surcharges are subject to change, sometimes on**

a monthly or quarterly basis. Examples of Surcharges include, but are not limited to: Universal Service Fund, E911, Federal Programs Cost Recovery, Federal Wireless Number Pooling and Portability, and gross receipts charges. We will make efforts to provide you notice of any changes to Surcharges in a manner consistent with this Agreement (see “Providing Notice Under This Agreement” paragraph). However, since most Surcharges are based on amounts set by the government or based on government formulas, it will not always be possible to provide advance notice of new Surcharges or changes in the amount of existing Surcharges. Information on Surcharges is provided during the sales transaction and is available at our Web site.

Disputing Charges - You Must Still Pay Undisputed Charges

Any dispute to a charge on your bill must be made within 60 days of the date of the bill that initially contained the charge. Disputes can only be made by calling or writing us as directed on your invoice or elsewhere. You accept all charges not properly disputed within the above time period – undisputed charges must still be paid as stated on your bill.

Protecting Our Network & Services

We can take any action to: (1) protect our network, our rights and interests, or the rights of others; or (2) optimize or improve the overall use of our network and Services. Some of these actions may interrupt or prevent legitimate communications and usage – for example, message filtering/blocking software to prevent SPAM or viruses, limiting throughput, limiting access to certain Web sites, applications or other Data Content, etc. For additional information on what we do to protect our customers, network, Services and equipment, see our Acceptable Use Policy and Visitor Agreement at our Web site.

Your Privacy

You agree to the terms of our Privacy Policy, available at our Web site, when you use our Services. This policy may change from time to time, so review this policy with regularity and care. Among other things, the policy includes important information on what information we collect about you, how we use that information, and with whom we share that information (for example, to provide you certain Services, to protect our rights and interests, to respond to legal process, to facilitate a merger, etc.). Also, to ensure the quality of our Services and for other lawful purposes, we may also monitor or record calls between us (for example, your conversations with our customer service or sales departments).

If you do not agree with the terms of our Privacy Policy, do not purchase or use our Services.

Location Based Services

Our network generally knows the location of your Device when it is outdoors and turned on. By using various technologies to locate your Device, we can provide enhanced emergency 911 services, and optional location-sensitive services provided by us or a third party. Environmental factors (such as structures, buildings, weather, geography, landscape, and topography) can significantly impact the ability to access your Device's location information and use of location-sensitive services. The terms and conditions of any location-sensitive service that you purchase from us may provide more information about how location information is used and disclosed. Use of some of location-sensitive services may require network coverage. **If any Device on your account uses a location-sensitive service, you (the account holder) must clearly and regularly notify the actual user of your Device that their location may be tracked or discovered.** For additional information on location-sensitive services, see our Privacy Policy at our Web site.

911 Or Other Emergency Calls

Public Safety Officials advise that when making 911 or other emergency calls, you should always be prepared to provide your location information. Unlike traditional wireline phones, depending on a number of factors (e.g., whether your Device is GPS enabled, where you are, whether local emergency service providers have upgraded their equipment, etc.), 911 operators may not know your phone number, your location or the location of your Device. In certain circumstances, an emergency call may be routed to a state patrol dispatcher or alternative location set by local emergency service providers. Enhanced 911 service ("E911"), where enabled by local emergency authorities, uses GPS technology to provide location information. Even when available, however, E911 does not always provide accurate location information. If your Device is indoors or for some other reason cannot acquire a satellite signal, you may not be located. Some Devices have a safety feature that prevents use of the keypad after dialing 911 – you should follow voice prompts when interacting with emergency service providers employing IVR systems to screen calls.

If Your Device Is Lost or Stolen

Call us immediately if your Device is lost or stolen because you may be responsible for usage charges before you notify us of the alleged loss or theft. You agree to

cooperate if we choose to investigate the matter (provide facts, sworn statements, etc.). We may not waive any Early Termination Fees if you choose to terminate Services as a result of loss or theft of your Device.

Disclaimer of Warranties

WE MAKE NO REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED, INCLUDING (TO THE EXTENT ALLOWED BY LAW) ANY IMPLIED WARRANTY OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE CONCERNING YOUR SERVICES (INCLUDING YOUR DEVICE). WE DON'T PROMISE UNINTERRUPTED OR ERROR-FREE SERVICES AND DON'T AUTHORIZE ANYONE TO MAKE WARRANTIES ON OUR BEHALF.

You Agree We Are Not Responsible For Certain Problems

You agree that neither we nor our vendors, suppliers or licensors are responsible for any damages resulting from: (a) anything done or not done by someone else; (b) providing or failing to provide Services, including, but not limited to, deficiencies or problems with a Device or network coverage (for example, dropped, blocked, interrupted calls/messages, etc.); (c) traffic or other accidents, or any health-related claims relating to our Services; (d) Data Content or information accessed while using our Services; (e) an interruption or failure in accessing or attempting to access emergency services from a Device, including through 911, Enhanced 911 or otherwise; (f) interrupted, failed, or inaccurate location information services, (g) information or communication that is blocked by a spam filter, or (h) things beyond our control, including acts of God (for example, weather-related phenomena, fire, earthquake, hurricane, etc.), riot, strike, war, terrorism or government orders or acts.

You Agree Our Liability Is Limited - No Consequential Damages.

TO THE EXTENT ALLOWED BY LAW, OUR LIABILITY FOR MONETARY DAMAGES FOR ANY CLAIMS YOU MAY HAVE AGAINST US IS LIMITED TO NO MORE THAN THE PROPORTIONATE AMOUNT OF THE SERVICE CHARGES ATTRIBUTABLE TO THE AFFECTED PERIOD. UNDER NO CIRCUMSTANCES ARE WE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR SPECIAL DAMAGES OF ANY NATURE WHATSOEVER ARISING OUT OF OR RELATED TO PROVIDING OR FAILING TO PROVIDE SERVICES IN CONNECTION WITH A DEVICE, INCLUDING, BUT NOT LIMITED TO, LOST PROFITS, LOSS OF BUSINESS, OR COST OF REPLACEMENT PRODUCTS AND SERVICES.

DISPUTE RESOLUTION

We Agree To First Contact Each Other With Any Disputes

We each agree to first contact each other with any disputes and provide a written description of the problem, all relevant documents/information and the proposed resolution. You agree to contact us with disputes by calling or writing us as instructed on your invoice. We will contact you by letter to your billing address or on your Device.

Instead Of Suing In Court, We Each Agree To Arbitrate Disputes

We each agree to finally settle all disputes (as defined and subject to any specific exceptions below) only by arbitration. In arbitration, there's no judge or jury and review is limited. However, just as a court would, the arbitrator must honor the terms and limitations in the Agreement and can award the same damages and relief, including any attorney's fees authorized by law. The arbitrator's decision and award is final and binding, with some exceptions under the Federal Arbitration Act ("FAA"), and judgment on the award may be entered in any court with jurisdiction. We each also agree as follows:

(1) **"Disputes" are any claims or controversies against each other related in any way to our Services or the Agreement, including, but not limited to, coverage, Devices, privacy, or advertising, even if it arises after Services have terminated** – this includes claims you bring against our employees, agents, affiliates or other representatives, or that we bring against you.

(2) If either of us wants to arbitrate a dispute, we agree to send written notice to the other providing a description of the dispute, previous efforts to resolve the dispute, all supporting documents/information, and the proposed resolution. Notice to you will be sent to your billing address and notice to us will be sent to: General Counsel; Arbitration Office; 2001 Edmund Halley Drive VARESP0513-502; Reston, Virginia 20191. We agree to make attempts to resolve the dispute. If we cannot resolve the dispute within forty-five (45) days of receipt of the notice to arbitrate, then we may submit the dispute to formal arbitration.

(3) The FAA applies to this Agreement and arbitration provision. We each agree the FAA's provisions, not state law, govern all questions of whether a dispute is subject to arbitration.

(4) The arbitration will be administered by the National Arbitration Forum ("NAF") under its arbitration rules. If any NAF rule conflicts with the terms of the Agreement, the terms of the Agreement apply. You can obtain procedures, rules, and fee information from the NAF at 1-800-474-2371 or www.adrforum.com.

(5) Unless we each agree otherwise, the Arbitration will be conducted by a single neutral arbitrator and will take place in the county of your last billing address. The federal or state law that applies to the Agreement will also apply during the arbitration.

(6) **We each agree not to pursue arbitration on a classwide basis. We each agree that any arbitration will be solely between you and us (not brought on behalf of or together with another individual's claim). If for any reason any court or arbitrator holds that this restriction is unconscionable or unenforceable, then our agreement to arbitrate doesn't apply and the dispute must be brought in court.**

(7) We each are responsible for our respective costs relating to counsel, experts, and witnesses, as well as any other costs relating to the arbitration. However, we will cover any arbitration administrative or filing fees above: (a) \$25 if you are seeking less than \$1,000 from us; or (b) the equivalent court filing fees for a court action in the appropriate jurisdiction if you are seeking \$1,000 or more from us.

Exceptions To Our Agreement To Arbitrate Disputes

Either of us may bring qualifying claims in small claims court. In addition, this arbitration provision does not prevent you from filing your dispute with any federal, state or local government agency that can, if the law allows, seek relief against us on your behalf.

No Class Actions

TO THE EXTENT ALLOWED BY LAW, WE EACH WAIVE ANY RIGHT TO PURSUE DISPUTES ON A CLASSWIDE BASIS; THAT IS, TO EITHER JOIN A CLAIM WITH THE CLAIM OF ANY OTHER PERSON OR ENTITY, OR ASSERT A CLAIM IN A REPRESENTATIVE CAPACITY ON BEHALF OF ANYONE ELSE IN ANY LAWSUIT, ARBITRATION OR OTHER PROCEEDING.

No Trial By Jury

TO THE EXTENT ALLOWED BY LAW, WE EACH WAIVE ANY RIGHT TO TRIAL BY JURY IN ANY LAWSUIT, ARBITRATION OR OTHER PROCEEDING.

Indemnification

You agree to indemnify, defend and hold us harmless from any claims arising out of your actions, including, but not limited to, failing to provide appropriate notices regarding location-sensitive services (see “Location Based Services” paragraph), or violating this Agreement, any applicable law or regulation or the rights of any third party.

Providing Notice To Each Other Under The Agreement

Except as the Agreement specifically provides otherwise, you must provide us notice by calling or writing us as instructed on your invoice. We will provide you notice in your bill, correspondence to your last known billing address, to any fax number or e-mail address you’ve provided us, by calling you on your home phone or Device, by voice message on your Device or home phone, or by text message on your Device.

Other Important Terms

Subject to federal law or unless the Agreement specifically provides otherwise, this Agreement is governed solely by the laws of the state encompassing the area code assigned to your Device, without regard to the conflicts of law rules of that state. If either of us waives or doesn’t enforce a requirement under this Agreement in an instance, we don’t waive our right to later enforce that requirement. Except as the Agreement specifically provides otherwise, if any part of the Agreement is held invalid or unenforceable, the rest of this Agreement remains in full force and effect. This Agreement isn’t for the benefit of any 3rd party except our corporate parents, affiliates, subsidiaries, agents, and predecessors and successors in interest. You can’t assign the Agreement or any of your rights or duties under it. We can assign the Agreement. The Agreement and

the documents it incorporates make up the entire agreement between us and replaces all prior written or spoken agreements – you can't rely on any contradictory documents or statements by sales or service representatives. The rights, obligations and commitments in the Agreement that, by their nature, would logically continue beyond the termination of Services (including, but not limited to, those relating to billing, payment, 911, dispute resolution, no class action, no jury trial), survive termination of Services.

© 2007 Sprint Nextel. All rights reserved. No reproduction in whole or in part without prior written approval. SPRINT and other trademarks are trademarks of Sprint Nextel. iDEN is a trademark of Motorola, Inc.

Glossary and Index



Glossary

1X

One Times Radio Transmission Technology (the “one times” refers to the frequency spectrum). Also known as Sprint Vision. Supports Internet connections with data rates up to 153 kbps. Actual speed depends on the network conditions. Compare to 1xEV-DO.

1xEV-DO

A high-speed standard for cellular packet data communications. Also known as Sprint Power Vision.

1xEV-DO Rev. A supports Internet connections with data rates up to 3.1 Mbps (downlink from the network) and 1.8 Mbps (uplink to the network). Average data rates are 600 kbps - 1.4 Mbps (downlink from the network) and 350-500 kbps (uplink to the network).

1xEV-DO Rev. 0 supports Internet connections with data rates up to 2.4 Mbps (downlink from the network) and 153 kbps (uplink to the network). Average data rates are 400-700 kbps (downlink from the network) and 40-80 kbps (uplink to the network)

Actual speed depends on the network conditions. Compare to 1X.

bps

bits per second—The actual data speed over the transmission medium.

broadband

High-speed wireless services optimized for data. Sprint Mobile Broadband is the next evolutionary step for the Sprint Power Vision Network.

CDMA

Code Division Multiple Access—A wideband spread spectrum technique used in digital cellular, personal communications services, and other wireless networks. Wide channels (1.25 MHz) are obtained through spread spectrum transmissions, thus allowing many active users to share the same channel. Each user is assigned a unique digital code, which differentiates the individual conversations on the same channel.

dBm

decibels relative to 1 milliwatt

dormant

The network switches the data connection into dormant mode if there is no traffic on the connection for some time. When you resume data traffic, the high-speed data connection becomes active.

The data connection may also go dormant while a GPS fix is being acquired.

ESN

Electronic Serial Number—The unique serial number assigned to the USB modem for cellular network use. Either the ESN or MEID is on the label on the USB modem (under the battery), and is also displayed in the Device Info & Diagnostics window (page 77). See also MEID.

FCC

Federal Communications Commission—The U.S. federal agency that is responsible for interstate and foreign communications. The FCC regulates commercial and private radio spectrum management, sets rates for communications services, determines standards for equipment, and controls broadcast licensing. Consult www.fcc.gov.

fix

GPS location information obtained from the network.

GPS

Global Positioning System—A system that uses a series of 24 geosynchronous satellites to provide location data.

HEPE

Horizontal Estimated Position Error—Relates to GPS accuracy.

IS

Interim Standard—After receiving industry consensus, the TIA forwards the standard to ANSI for approval.

kbps

kilobits per second—Actually 1000, not 1024, as used in computer memory size measurements of kilobytes.

LAN

Local Area Network

LED

Light Emitting Diode—A semiconductor diode that emits visible or infrared light.

Mbps

Megabits per second

MEID

Mobile Equipment Identifier—The unique second-generation serial number assigned to the Sprint Mobile Broadband USB modem for cellular network use. Either the MEID or ESN is on the label on the USB modem (under the battery), and is also displayed in the Device Info & Diagnostics window (page 77). Compare to ESN.

MHz

megahertz—One million cycles per second

PCS

Personal Communications Services—A cellular communication infrastructure.

roaming

A wireless subscriber is in an area where service is obtained from a wireless service provider other than Sprint. This may be subject to roaming charges. Sprint Location Services may not be available.

Sprint Connection Manager

Software that allows you to manage the Sprint Mobile Broadband USB modem's actions and monitor your connections on a Windows computer.

Sprint Mobile Broadband

High-speed wireless services optimized for data. Sprint Mobile Broadband is the next evolutionary step for the Sprint Power Vision Network.


Sprint Power Vision


Sprint's advanced multimedia third generation services available on the network. See 1xEV-DO.

Sprint Vision

Sprint's advanced multimedia third generation services available on the network. See 1X.

system tray

Usually located in the bottom right of the screen (near the clock). When Sprint Connection Manager is running, it places an icon  in this area, which you can use to monitor the connection state (page 42). If you right-click the icon, a shortcut menu is displayed (page 63):




TIA

Telecommunications Industry Association—A standards-setting trade organization, whose members provide communications and information technology products, systems, distribution services, and professional services in the United States and around the world. Consult www.tiaonline.org.

ToolTip

Text that displays when you position the mouse pointer over an area of the screen (for example, over an indicator).



VPN

Virtual Private Network

WAN

Wide Area Network

Watcher Lite

Software that allows you to manage the Sprint Mobile Broadband USB modem's actions and monitor your connections on a Mac computer.

Index

Symbols

\$GPGGA, 90
\$GPGSA, 90
\$GPGSV, 90
\$GPRMC, 90

Numerics

1-888-715-4588 (Sprint Customer Service), 13
1-888-788-4727 (Sprint Customer Service), 13
1X Only (Network Mode) (Windows), 70
1X, 1xEV-DO
 description, 5
 amount of data transferred (Mac), 111
 amount of data transferred (Windows), 53
 application to automatically launch upon network connection (Windows), 52
 automatically connecting when ready (Windows), 69
 cannot connect (Mac), 114
 cannot connect (Windows), 95
 connecting (Mac), 110
 connecting (Windows), 50
 coverage, determining (Mac), 110
 coverage, determining (Windows), 43
 dormant indicator (Windows), 35
 ending a connection (Mac), 110
 ending a connection (Windows), 54
 icons (Mac), 110
 icons (Windows), 34
 roaming indicator (Mac), 110
 roaming indicator (Windows), 34
 transmit/receive indicator (Windows), 35
 warning when roaming (Windows), 51
1xEV-DO Only (Network Mode) (Windows), 69
2000, Windows, 9
3G. See 1X, 1xEV-DO.

A

About Sprint Mobile Broadband, 80
accessibility, 122
accessories, 13
account
 accessing, 13
 charges, 142
 setting up (Mac), 107

 setting up (Windows), 24
Account Spending Limits (ASL), 139
accuracy, GPS (Windows only), 36
"Acquired" message (Windows only), 41
activating the USB modem
 Mac, 107
 Windows, 24
activation
 Mac, 107
 Windows, 24
Activation Assistant (Mac), 108
activation code
 Mac, 109
 Windows, 26
Activation Wizard (Windows)
 overview, 24
 Activation Wizard button, 70
Activation, One Touch, 5, 25
Advanced Forward Link Trilateration (AFLT) (Windows only), 88
AFLT (Advanced Forward Link Trilateration) (Windows only), 88
agreement, subscriber, 136
aircraft
 hazards warning, 134
 powering the USB modem off in (Windows only), 45
Alert Log (Windows), 76
alerts (Windows), 76
altitude (Windows only), 37
Always Ask (Roam Guard) (Windows), 52
always on
 billing, 83
 set (Windows), 33
Always on top (Windows), 67
Always show Welcome screens (Windows), 69
Always-on connection, 51
amount of data transferred
 Mac, 111
 Windows, 53
antenna, adjusting
 Mac, 106
 Windows, 19
antenna, external, attaching
 Mac, 111
 Windows, 43
AOL, 84
application, GPS (Windows only)
 configuring, 90

- definition, 89
- approvals, 121
- arbitration of disputes, 148
- ASL (Account Spending Limits), 139
- assistance
 - online Help (Windows only), 54
 - Sprint Customer Service, 13
 - Sprint Web site, 13
- authentication, 122
- auto-launch Sprint Connection Manager, 33
- Auto-launch upon network connection (Windows), 52
- Automatic (Network Mode) (Windows), 69
- Automatic (roaming option) (Windows), 70
- automatically connecting to network (Windows), 69
- automatically starting Sprint Connection Manager, 33
- AutoPreview, 84

B

- battery
 - warning (Mac), 105
 - warning (Windows), 19
 - charging (Mac), 107
 - charging (Windows), 20
 - inserting into USB modem (Mac), 105
 - inserting into USB modem (Windows), 19
 - replacing, 6
- behavior when the USB modem is locked (Windows), 56
- bill, 144
- billing, and always on, 83
- blasting — hazards warning, 134
- bookmarks (Windows), 58
- business usage (Windows), 75

C

- call duration
 - Mac, 110
 - Windows, 75
- cannot connect to the network
 - Mac, 114
 - Windows, 95
- care and maintenance, 6
- caution, 125
- CDMA
 - networks, 4
 - roaming - description, 4
 - signal strength indicator (Mac), 110

- signal strength indicator (Windows), 34
- specification, 122
- changing the lock code (Windows), 58
- channel spacing, 121
- charges
 - disputing, 145
 - possible charges, 142
- charging the battery
 - Mac, 107
 - Windows, 20
- Check for updates once per month (Windows), 67
- Check Now button (Windows), 67
- Clear Log (Windows), 76
- Close Sprint Connection Manager, 49
- Close Sprint Mobile Broadband (Windows), 49
- compact view (Windows)
 - GPS Receiver window, 48
 - Mobile Broadband window, 47
- conditions and terms of service, 135
- Connect button (Mac)
 - unavailable, 113
 - usage, 110
- "Connected" message (Windows), 39
- connected icon (Windows), 42
- "Connected to NDIS" message (Windows), 40
- "Connecting" message (Windows), 39
- connecting icon (Windows), 42
- connecting to the network (Mac), 110
- connecting to the network (Windows)
 - automatically, 69
 - manually, 50
- connection (Mac)
 - amount of data transferred, 111
 - cannot connect, 114
 - ending, 110
 - launching, 110
 - states, 110
- connection (Windows)
 - 1X or 1xEV-DO (Network Mode), 70
 - alert log, 76
 - Always-on, 51
 - amount of data transferred, 53
 - application to automatically launch upon network connection, 52
 - automatically connecting when ready, 69
 - cannot connect, 95
 - diagnostics, 77

- ending, 54
- history, 75
- issues, 76
- launching, 50
- Network Mode, 70
- states (GPS Receiver window), 41
- states (Mobile Broadband window), 38
- states (system tray), 42
- warning when roaming, 51
- Connection History (Windows), 75
- Connection Manager
 - Mac. See Watcher Lite.
 - Windows. See Sprint Connection Manager.
- connection states (Mac), 110
- connection states (Windows)
 - GPS Receiver window, 41
 - Mobile Broadband window, 38
 - system tray, 42
- Consent Agreement (Windows), 72
- content, data, 141
- contents of package, 6
- Control Plane, GPS (Windows only), 86
- "Could not prepare data services" message (Windows), 97
- coverage
 - disclaimer, 140
 - maps, 13
 - type, determining (Mac), 110
 - type, determining (Windows), 43
- Create Report (Windows), 79
- current direction (Windows only), 37
- current speed (Windows only), 36
- current, electrical, 121
- customer support, 13

D

- data content, 141
- Data LED, 120
- data profile (Windows), 27
- data provisioning
 - Mac, 107
 - Windows, 27
- data speeds, 83
- data transferred, amount of
 - Mac, 111
 - Windows, 53
- data usage, charges, 143
- default connection (Windows), 50
- definitions, glossary, 155

- deleting Sprint Connection Manager, 59
- deposits, 139
- Device Info & Diagnostics (Windows), 77
- "Device is Locked" message (Mac), 107
- "Device Locked" message (Windows), 40
- "Device Not Activated" window (Mac), 108
- "Device powered off" message (Windows only), 40
- diagnostics (Windows), 77
- dial-up account, 84
- dimensions, 123
- direction, current (Windows only), 37
- disclaimer
 - network coverage, 140
 - Sprint Location Services (Windows only), 146
 - warranties, 147
- Disconnect button (Mac), 110
- "Disconnected" message
 - Mac, 107
 - Windows, 39
- disconnected icon (Windows), 42
- disconnecting
 - Mac, 110
 - Windows, 54
- disk space required, 10
- Display GPS Receiver (Windows only), 72
- Display GPS Welcome (Windows only), 72
- Display Location & Search Services on the menu (Windows only), 72
- dispute resolution, 148
- disputing charges, 145
- Do not show NMEA Privacy Consent (Windows only), 72
- Do not show Privacy Consent for Location & Search Services (Windows only), 72
- document number, 128
- dormant icon (Windows)
 - Mobile Broadband window, 35
 - system tray, 42
- driver installation
 - Mac, 105
 - Windows, 22
- drop test, 123
- dropped connection
 - Mac, 114
 - Windows, 95

E

- E911, 122

- early termination fee, 137
- editing (Windows)
 - Sprint Connection Manager settings, 65
 - Sprint Power Vision/Sprint Vision connection, 68
- electrical specifications, 121
- electromagnetic emissions warning
 - Canada, 126
 - USA (FCC), 125
- electronic serial number (ESN) (Windows), 26
- elevation information (Windows only), 73
- EMI warning
 - Canada, 126
 - USA (FCC), 125
- emissions, electromagnetic, warning
 - Canada, 126
 - USA (FCC), 125
- Enable Location Services (Windows only), 72
- Enable Network Adapter (NDIS) (Windows), 69
- encryption - required for IOTA (Windows), 10
- ending a connection
 - Mac, 110
 - Windows, 54
- ending NMEA (Windows only), 91
- enhanced Local Search (Windows only)
 - definition, 85
 - obtaining this feature, 85
- environmental specifications, 123
- error messages - viewing (Windows), 76
- error, position (HEPE) (Windows only), 36
- ESN (electronic serial number) (Windows), 26
- EV-DO. See 1X, 1xEV-DO.
- exiting Sprint Connection Manager, 49
- expanded view (Windows)
 - GPS Receiver window, 48
 - Mobile Broadband window, 47
- expanding Sprint Connection Manager, 46
- explosion risk if incorrect battery used
 - Mac, 105
 - Windows, 19
- external antenna, attaching
 - Mac, 111
 - Windows, 43

F

- FAQ (Frequently Asked Questions)

- Mac, 114
- Windows, 81
- favorites (Windows), 58
- fax, 122
- FCC
 - compliance, 125
 - EMI warning, 125
 - ID, 125
- fees
 - early termination, 137
 - government, 144
 - late, 144
- firmware upgrades, 129
- fix, last (Windows only), 37
- forgot the lock code, 56
- frequencies, transmit and receive, 121
- frequency stability, 121
- Frequently Asked Questions (FAQ)
 - Mac, 114
 - Windows, 81

G

- General options in Settings window (Windows), 66
- general terms and conditions of services, 136
- global positioning system (GPS) (Windows only). See GPS, Sprint Location Services, and also the FAQ chapter (Windows).
- glossary, 155
- GO automatically when ready (Windows), 69
- GO button (Windows)
 - GPS Receiver window, 38
 - Mobile Broadband window, 50
 - unavailable, 94
- Google Maps (Windows), 72
- government fees, 144
- \$GPGGA, 90
- \$GPGSA, 90
- \$GPGSV, 90
- \$GPRMC, 90
- GPS (Windows only)
 - See also Sprint Location Services, and also the FAQ chapter (Windows).
 - accuracy, 36
 - application, 89, 90
 - Control Plane, 86
 - definition, 85
 - disclaimer, 146

- enable/disable, 72, 87
- GPS Basic, 88
- GPS Premium, 89
- GPS Receiver window, 35
- icon in system tray, 42
- limitations, 88
- Privacy, 87
- subscription, 87
- Test GPS, 73
- User Plane, 86
 - where can I use it?, 86
- GPS Basic (Windows only), 88
- GPS Control Plane (Windows only), 86
- GPS Port (Windows only), 37
- GPS Premium (Windows only), 89
- GPS Receiver window
 - compact view, 48
 - diagram with callouts, 35
 - expanded view, 48
 - icons, 36
 - show/hide, 72
 - text displayed in, 41
- GPS status (Windows only)
 - icons, 36
 - text, 41
- GPS Testing (Windows only), 73
- GPS User Plane (Windows only), 86
- GPSONe (Windows only), 88

H

- hard drive space required, 10
- hardware requirements, 10
- hazards, 134
- heading (Windows only), 37
- headset jack, 123
- Help
 - overview, 13
 - alert log (Windows), 76
 - contact number, 13
 - device info and diagnostics (Windows), 77
 - diagnostics (Windows), 77
 - frequently asked questions (FAQ) (Mac), 114
 - frequently asked questions (FAQ) (Windows), 81
 - menu options (Mac), 111
 - menu options (Windows), 60
 - online Help (Windows only), 54
 - Sprint Customer Service, 13
 - Sprint.com, 13
 - tests (Windows), 77

- troubleshooting (Mac), 113
- troubleshooting (Windows), 92
- HEPE (Horizontal Estimated Position Error) (Windows only), 36
- hibernation mode (Windows), 84
- high encryption (Windows), 10
- history, connection (Windows), 75
- Horizontal Estimated Position Error (HEPE) (Windows only), 36
- hospital, powering the USB modem off in (Windows only), 45
- humidity, 123

I

- icons (Mac), 110
- icons (Windows)
 - GPS Receiver window, 36
 - Mobile Broadband window, 34
 - system tray, 42
- indemnification, 150
- indicators (Mac), 110
- indicators (Windows)
 - GPS Receiver window, 36
 - Mobile Broadband window, 34
 - system tray (Windows), 42
- information, system (Windows), 77
- initial lock code (Windows), 55
- "Initializing" message (Windows), 39
- inserting the USB modem
 - Mac, 106
 - Windows, 22
- installation
 - overview, 8
 - installed files (Windows), 79
 - Mac, 102
 - Windows, 10
- interference, 45
- Internet Explorer, auto-launch (Windows), 52
- Internet Over The Air (Windows), 27
- invoice, requesting a copy of, 13
- IOTA 2.4 (One Touch Activation), 5, 25
- IOTA (Internet Over The Air) (Windows)
 - "Unable to prepare data services" message, 97
 - description, 27
 - IOTA Provisioning window, 27
 - One Touch Activation (IOTA 2.4), 5, 25

K

- Keep Connection History (Windows), 67

knowledge base, 13

L

last fix (Windows only), 37

late fees, 144

latitude (Windows only), 36, 73

Launch when Windows starts, 67

LBS (Location-Based Services) (Windows only). See Sprint Location Services.

LEDs (lights), 120

liability, limitation of, 129

life support equipment — hazards warning, 134

lights (LEDs), 120

Limitation of Liability, 129

limitations, Sprint Location Services (Windows only), 88

links, access (Windows), 58

Location & Search Services. See Sprint Location Services.

Location information (Windows only), 36

Location-Based Services (LBS) (Windows only). See Sprint Location Services.

lock code (Windows)

overview, 55

lock code - warning, 56

lock code (Windows)

changing, 58

initial lock code, 55

lock USB modem (Windows)

immediately, 56

upon startup, 57

locked USB modem (Mac), 111

locked USB modem (Windows)

behavior when the USB modem is locked, 56

changing the lock code, 58

initial lock code, 55

unlocking the USB modem, 57

log (Windows)

alert, 76

connection, 75

longitude (Windows only), 36, 73

lost device, 146

M

Mac OS X

system requirements, 102

See also Watcher Lite.

maintenance, 6

making a connection (Mac)

connecting to the network, 110

amount of data transferred, 111

cannot connect, 114

making a connection (Windows)

1X or 1xEV-DO (Network Mode), 70

always on, 69

amount of data transferred, 53

application to automatically launch upon network connection, 52

automatically, 69

cannot connect, 95

connecting to the network, 50

Network Mode, 70

map services (Windows only), 72

Mapping and Search Service (Windows only), 72

MapQuest (Windows), 72

maps, coverage, 13

mechanical specifications, 123

medical equipment — hazards warning, 134

MEID (Mobile Equipment Identifier) (Windows), 26

memory required, 10

Menu (Windows)

all options, 60

About Sprint Mobile Broadband, 80

Alert Log, 76

Connection History, 75

Device Info & Diagnostics, 77

Exit, 54

Links, 58

Location & Search Services, 44

Menu button, 37

Settings, 65

Software Updates, 79

system tray menu, 63

Menu button (Windows only), 37

menu options (Mac), 111

menu options (Windows)

Location & Search Services menu, 44

Sprint Connection Manager menu, 60

system tray menu, 63

messages - viewing (Windows), 76

messaging, text (SMS), 122

Microsoft Live (Windows), 72

Microsoft VPN (PPTP) Connection (Windows), 52

minimizing Sprint Connection Manager

- immediately, 49
- on startup, 67
- minus sign (-) in Sprint Connection Manager, 46
- miscellaneous charges, 142
- Mobile Broadband window
 - description of icons, 34
 - diagram with callouts, 34
 - expanded view, 47
- Mobile Equipment Identifier (MEID) (Windows), 26
- Mobile IP, 122
- Mobile System ID (MSID)
 - Mac, 109
 - Windows, 26
- MS-Based position location technology (Windows only), 88, 122
- MSID (Mobile System ID)
 - Mac, 109
 - Windows, 26
- N**
- NAM, 122
- NDIS (Windows)
 - "Connected to NDIS" message, 40
 - Enable Network Adapter (NDIS), 69
- network
 - See Sprint network.
- network adapter (NDIS) (Windows), 69
- Network Mode (Windows), 69
- Never Ask (Roam Guard) (Windows), 52
- NMEA (Windows only)
 - configuring the port, 91
 - definition, 90
 - starting, 91
 - stopping, 91
 - when to use, 90
- "No device" message (Windows), 38
- "No device detected" message (Mac), 111
- non-preactivated USB modem
 - Mac, 108
 - Windows, 25
- non-preferred roaming area (Windows), 34
- "Not activated" message (Mac), 108
- notices
 - regulatory, 125
 - safety, 133
- number of satellites (Windows only), 73
- O**
- "OFF" message (Windows only), 41

- on top, always (Windows), 67
- One Touch Activation (IOTA 2.4), 5, 25
- online Help (Windows only), 54
- operating systems supported, 9
- operating temperature, 123
- optimizing performance, 84
- OTAPA, 122
- OTASP, 122
- P**
- package contents, 6
- patents, 127
- payments, 144
- performance, improving, 84
- personal usage (Windows), 75
- phone number (Windows)
 - during Activation Wizard, 26
 - Sprint Mobile Broadband USB modem, 55
- phone number, transferring, 140
- planes
 - hazards warning, 134
 - powering the USB modem off in (Windows only), 45
- Play sound effects (Windows), 67
- plus sign (+) in Sprint Connection Manager, 46
- port configuration (Windows), 77
- porting/transferring phone numbers, 140
- position error (HEPE) (Windows only), 36
- position location (Windows only), 122
 - See also Sprint Location Services, and also the FAQ chapter (Windows).
- power button, 123
- powering the USB modem on and off (Windows only), 45
- Power Vision, Sprint (1xEV-DO). See 1X, 1xEV-DO.
- power, transmitter, 121
- powered off (Windows only), 40, 45
- PPTP - Microsoft VPN (PPTP) Connection (Windows), 52
- preactivated USB modem
 - Mac, 107
 - Windows, 24
- preferred roaming list, 122
- Preview Pane, 84
- privacy (Windows)
 - Consent Agreement (Sprint Location Services), 72

- GPS not available, 87
- icon (GPS Receiver window), 36
- privacy, terms, 145
- PRL, 122
- problems, 92, 113
- products, Sprint (Windows), 58
- profile - data (Windows), 27
- properties of connection, changing (Windows), 68
- pro-rating charges, 142
- provisioning
 - Mac, 107
 - Windows, 24, 27
- "Provisioning failed" message (Mac), 108
- PWR LED, 120

Q

questions. See troubleshooting.

R

- radio frequency (RF) specifications, 121
- receive frequencies, 121
- Receiver, GPS (Windows)
 - compact view, 48
 - diagram with callouts, 35
 - expanded view, 48
 - icons, 36
 - show/hide, 72
 - text displayed in, 41
- records of connection history (Windows), 75
- regulatory
 - information, 124
 - notices, 125
- Relock modem when program exits (Windows), 57
- removing
 - hardware (Mac), 112
 - hardware (Windows), 22
 - software (Sprint Connection Manager), 59
- report lost or stolen device, 146
- report of system information (Windows), 79
- requirements, system
 - Mac, 102
 - Windows, 9
- resolution of disputes, 148
- restoring Sprint Connection Manager, 49
- restrictions on using services, 140
- returning deposits, 139
- RF (radio frequency) specifications, 121
- Roam Guard (Windows), 51

- Roam Mode (Windows), 70
- Roam Only (roaming option) (Windows), 70
- roaming
 - description, 4
 - display warning message (Windows), 51
 - indicator (Mac), 110
 - indicator (Windows), 34
 - PRL, 122
 - settings (Windows), 70
- RSSI (signal strength)
 - Mac, 110
 - Windows, 34, 77
- Running Diagnostics (Windows), 77

S

- Safety and Hazards, 134
- satellites (Windows only)
 - number of, 36, 73
 - status, 36
- Search Services (Windows only). See Sprint Location Services.
- "Searching for service" message
 - Mac, 113
 - Windows, 39, 94
- security (Mac)
 - unlocking the USB modem, 107
- security (Windows)
 - overview of user lock, 55
 - warning, 56
 - behavior when the USB modem is locked, 56
 - changing the lock code, 58
 - high encryption - required for IOTA, 10
 - IOTA - high encryption requirement, 10
 - lock USB modem immediately, 56
 - lock USB modem upon startup, 57
 - unlocking the USB modem, 57
- service
 - conditions of, 135
 - coverage, determining (Mac), 110
 - coverage, determining (Windows), 43
 - restrictions on using, 140
 - roaming indicator (Mac), 110
 - roaming indicator (Windows), 34
 - "Searching for service" message (Mac), 113
 - "Searching for service" message (Windows), 94
- service charges, 142
- Service Packs, Windows, 9
- service plan, adding options, 13

- services, Sprint (Windows), 58
- Settings window (Windows)
 - overview, 65
 - General, 66
 - Sprint Location Services, 71
 - Sprint Mobile Broadband, 68
- short text messaging (SMS), 122
- shortcut menu (Windows), 63
- show Welcome screens (Windows), 69
- signal strength
 - diagnostic tests (Windows), 77
 - indicator (Mac), 110
 - indicator (Windows), 34
- sleep mode (Mac), 120
- SMS, 122
- software (Mac)
 - components, 11
 - icons, 110
 - installing, 101
 - messages, 110
- software (Windows)
 - components, 11
 - installing, 17
 - lock USB modem immediately, 56
 - lock USB modem upon startup, 57
 - menu options, 60
 - minimizing, 49
 - minimizing on startup, 67
 - removing, 59
 - restore minimized, 49
 - uninstalling, 59
 - unlocking the USB modem, 57
 - updating, 79
 - upgrading Windows, 97
 - user lock, 55
 - version information, 80
 - Windows, upgrading, 97
- software specifications, 122
- Software Updates (Windows), 79
- sound effects, play (Windows), 67
- specifications
 - environmental, 123
 - mechanical, 123
 - radio frequency and electrical, 121
 - software, 122
- speed, current (Sprint Location Services) (Windows only), 36
- speeds, data transmission, 83
- Sprint (roaming option) (Windows), 70
- Sprint Connection Manager
 - overview, 32
 - 1X or 1xEV-DO connection (Network Mode), 70
 - About Sprint Mobile Broadband, 80
 - amount of data transferred, 53
 - application to automatically launch upon network connection, 52
 - automatically connecting when ready, 69
 - cannot connect, 95
 - closing, 49
 - configuring, 65
 - expanding Sprint Connection Manager, 46
 - frequently asked questions (FAQ), 81
 - GPS Receiver window, 35
 - icons, 34
 - icons (GPS Receiver window), 36
 - icons (Mobile Broadband window), 34
 - icons (system tray), 42
 - links, 58
 - menu options, 60
 - minimizing, 49
 - minimizing on startup, 67
 - Mobile Broadband window, 34
 - Network Mode, 70
 - removing, 59
 - restoring, 49
 - security features, 55
 - settings, 65
 - Sprint Location Services, 43
 - starting, 32
 - starting automatically, 33
 - stopped working after Windows upgrade, 97
 - system tray menu, 63
 - uninstalling, 59
 - updating, 79
 - upgrading Windows, 97
 - version information, 80
 - window overview, 33
 - Windows upgrade, 97
- Sprint Connection Manager settings
 - 1X or 1xEV-DO connection (Network Mode), 70
 - changing, 65
 - General, 66
 - Sprint Location Services, 71
 - Sprint Mobile Broadband, 68
- Sprint Connection Manager stopped working after I've upgraded to a different version of Windows, 97
- Sprint Customer Service, 13
- Sprint Location Services (Windows only)

- See also GPS, and also the FAQ chapter (Windows).
- definition of LBS (Location-Based Services), 84
- disclaimer, 146
- display Location & Search Services on the menu, 72
- enable/disable, 72, 87
- frequently asked questions, 85
- GPS Receiver window, 35
- icon in system tray, 42
- icons, 36
- limitations, 88
- Location & Search Services menu, 44
- Privacy, 87
- settings, 71
- subscription, 87
- Test GPS, 73
- text in GPS Receiver window, 41
- troubleshooting, 96
- using, 43
- Sprint Mobile Broadband USB modem
 - inserting (Mac), 106
 - inserting (Windows), 22
 - phone number (Windows), 55
 - removing (Mac), 112
 - removing (Windows), 22
- Sprint network
 - 1X or 1xEV-DO connection (Network Mode) (Windows), 70
 - always on connection (Windows), 69
 - amount of data transferred (Mac), 111
 - amount of data transferred (Windows), 53
 - application to automatically launch upon network connection (Windows), 52
 - automatically connecting when ready (Windows), 69
 - availability status (Windows), 77
 - cannot connect (Mac), 114
 - cannot connect (Windows), 95
 - CDMA wireless network, description, 4
 - connecting (Mac), 110
 - connecting (Windows), 50
 - coverage, determining (Mac), 110
 - coverage, determining (Windows), 43
 - coverage, disclaimer, 140
 - frequently asked questions (FAQ) (Mac), 114
 - frequently asked questions (FAQ) (Windows), 81
 - roaming indicator (Mac), 110
 - roaming indicator (Windows), 34
 - roaming options (Windows), 70
 - signal strength indicator (Mac), 110
 - signal strength indicator (Windows), 34
 - Sprint Location Services (Windows only), 43
 - Sprint Power Vision (1xEV-DO). See 1X, 1xEV-DO.
 - Sprint products and services (Windows), 58
 - Sprint roaming (Windows), 70
 - Sprint Vision
 - 1X or 1xEV-DO connection (Network Mode) (Windows), 70
 - Always show Welcome screens (Windows), 69
 - amount of data transferred (Mac), 111
 - amount of data transferred (Windows), 53
 - application to automatically launch upon network connection (Windows), 52
 - automatically connecting when ready (Windows), 69
 - cannot connect (Mac), 114
 - cannot connect (Windows), 95
 - connecting (Mac), 110
 - connecting (Windows), 50
 - coverage, determining (Mac), 110
 - coverage, determining (Windows), 43
 - disconnecting (Mac), 110
 - disconnecting (Windows), 54
 - ending a connection (Mac), 110
 - ending a connection (Windows), 54
 - Network Mode (Windows), 70
 - settings (Windows), 68
 - warning when roaming (Windows), 51
 - See also 1X, 1xEV-DO.
- Sprint Web site, 13
- Sprint, contacting, 13
- sprint.com, 13
- standby current, 121
- Start in system tray (Windows), 67
- starting a connection (Mac), 110
- starting a connection (Windows)
 - application to automatically launch upon network connection, 52
 - automatically connecting when ready, 69
 - immediately, 50
 - specify 1X or 1xEV-DO connection (Network Mode), 70
 - warning when roaming, 51
- starting NMEA (Windows only), 91

- starting Sprint Connection Manager
 - automatically, 33
 - manually, 32
- status information (Windows), 77
- status of connection (Mac), 110
- status of connection (Windows)
 - GPS Receiver window, 41
 - Mobile Broadband window, 38
 - system tray, 42
- stolen device, 146
- Stop button (Windows)
 - GPS Receiver window, 38
 - Mobile Broadband window, 54
- stopping NMEA (Windows only), 91
- storage temperature, 123
- subscriber agreement, 136
- subscription, GPS (Windows only), 87
- support, 13
- surcharges, 144
- suspend mode (Windows), 120
- system information (Windows), 77, 79
- System Parameters (Windows), 79
- system requirements
 - Mac, 102
 - Windows, 9
- system tray (Windows)
 - connection states, 42
 - icons, 42
 - menu, 63
 - shortcut menu, 63
 - start in, 67
- T**
 - taskbar icon (Windows)
 - shortcut menu, 49
 - taxes, 144
 - technical specifications, 119
 - technical support, 13
 - telephone number of USB modem (Windows), 55
 - temperature (operating, and storage), 123
 - termination fee, 137
 - Terms and Conditions, 135
 - terms and definitions (glossary), 155
 - Test GPS (Windows only), 73
 - tests, diagnostic (Windows), 77
 - text messaging (SMS), 122
 - trademarks, 128
 - transferred data, amount of
 - Mac, 111
 - Windows, 53
 - transferring phone numbers, 140
 - transmission speeds, 83
 - transmit frequencies, 121
 - transmit/receive icon (Windows), 34, 35
 - transmitter power, 121
 - trilateration (Windows only), 88
 - troubleshooting (Mac)
 - common causes of problems, 113
 - Connect button is unavailable, 113
 - contact information, 13
 - frequently asked questions (FAQ), 114
 - "Searching for service" message, 113
 - troubleshooting (Windows)
 - common causes of problems, 93
 - alert log, 76
 - cannot connect, 95
 - contact information, 13
 - "Could not prepare data services" message, 97
 - frequently asked questions (FAQ), 81
 - GO button is unavailable, 94
 - run diagnostic tests, 77
 - "Searching for service" message, 94
 - Sprint Connection Manager stopped working after Windows upgrade, 97
 - Sprint Location Services, 96
 - Troubleshooting wizard, 13
 - "Unable to prepare data services" message, 97
 - wizard, 13
 - Troubleshooting wizard (Windows), 13
 - TTY, 122
 - type of coverage, determining
 - Mac, 110
 - Windows, 43
- U**
 - uninstalling Sprint Connection Manager, 59
 - unlocking the USB modem (Mac), 107
 - unlocking the USB modem (Windows)
 - initial lock code, 55
 - instructions, 57
 - Update Data Profile (Windows), 27
 - updates, checking for latest, 129
 - updating the software (Windows), 79
 - "Updating User Profile..." message
 - Mac, 108, 109
 - Windows, 27
 - upgrading Windows, 97

- URL to automatically launch upon network connection (Windows), 52
- URLs - favorites (Windows), 58
- USB modem, powering off (Windows only), 45
- USB port (Windows), 77
- user lock (Mac)
 - unlocking the USB modem, 107
- user lock (Windows)
 - overview, 55
 - warning, 56
 - changing the lock code, 58
 - lock USB modem immediately, 56
 - lock USB modem upon startup, 57
 - unlocking the USB modem, 57
- User Lock Change button (Windows), 70
- User Plane, GPS (Windows only), 86

V

- "Validating" message (Windows), 41
- vehicle, operating
 - hazards warning, 134
- version information (Windows), 80
- version of this document, 128
- vibration, 123
- views of Sprint Connection Manager, 46
- Vision. See Sprint Vision, and 1X, 1xEV-DO.
- Vista, Windows, 9
- voice support, 122
- voltage, 121
- VPN (Mac)
 - accessing your corporate network through a VPN, 115
- VPN (Windows)
 - accessing your corporate network through a VPN, 84
 - specifying a VPN program to automatically launch upon network connection, 52

W

- warning
 - electromagnetic emissions (EMI) — Canada, 126
 - electromagnetic emissions (EMI) — USA (FCC), 125
 - explosion risk if incorrect battery used (Mac), 105
 - explosion risk if incorrect battery used (Windows), 19
 - lock code, regarding, 56

- roaming, display message (Windows), 51
- warranties, disclaimer of, 147
- warranty, 6
- Watcher Lite
 - frequently asked questions (FAQ), 114
 - icons, 110
 - installing, 101
 - messages, 110
 - troubleshooting, 113
- weak signal
 - Mac, 113
 - Windows, 94
- Web site - Sprint.com, 13
- Web site (Windows)
 - automatically launch upon network connection, 52
 - favorites, 58
- Welcome screen, always show (Windows), 69
- Windows
 - auto-launch Sprint Connection Manager, 67
 - upgrading, 97
 - versions supported, 9
- Wireless Local Number Portability (WLNP)
 - Mac, 109
 - Windows, 26
- wizard (Mac) - Activation Assistant, 108
- wizard (Windows)
 - Activation Wizard, 24
 - Troubleshooting, 13
- WLNP (Wireless Local Number Portability)
 - Mac, 109
 - Windows, 26
- www.sprint.com, 13

X

- XP, Windows, 9

Y

- Yahoo! Maps (Windows), 72