# ZyXELAG-100

802.11a/b/g Wireless CardBus Adapter

## Quick Start Guide

Version 1.0 October 2004



### **Important Note**

#### Federal Communications Commission (FCC) Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

For operation within  $5.15 \sim 5.25 \text{GHz}$  frequency range, it is restricted to indoor environment, and the antenna of this device must be integral.

#### ZyXEL AG-100 Quick Start Guide

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **IMPORTANT NOTE:**

#### **FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This device complies with FCC RF Exposure limits set forth for an uncontrolled environment, under 47 CFR 2.1093 paragraph (d)(2).

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## 1. Installation Requirements

Before installation, make sure you have a computer with the following:

- Pentium II 300MHz or above
- A minimum of 20 MB available hard disk space
- 32MB RAM (64MB Recommended)
- A CD-ROM drive
- A CardBus (PCMCIA Type II) slot
- Windows XP/2000/ME/98 SE
- Windows 98 SE users may need the Windows 98 SE CD

## 2. ZyXEL Utility and Hardware Installation

The installation procedures are similar for all supported Windows versions. Windows XP screen shots are shown unless otherwise specified.



#### DO NOT insert the ZyXEL AG-100 at this point.

1. Insert the support CD into the CD-ROM drive on your computer. The installation program will automatically run. If it does not, locate and double-click **setup.exe** on the support CD.

**2.** Click **Install Utility** to start installation.




- **3.** Client utility and driver will be automatically installed.
- **4.** You will be prompted to insert your ZyAIR Adapter.



- **5.** Locate an available CardBus slot on the computer.
- 6. With the pin connectors facing the slot and the LED side facing up, slide the ZyXEL AG-100 into the slot. The LEDs turn on if the ZyXEL AG-100 is properly inserted.





- 7. Windows will automatically install and configure the AG-100
- **8.** After installation is complete, a new icon will appear in your system tray.



**9.** Double click the icon to configure your wireless adapter.

If the ZyXEL Utility icon displays, the ZyXEL AG-100 is installed properly. Refer to the *User's Guide* to configure the ZyXEL AG-100.

## **LED Display**



The following table describes the LEDs on the ZyXEL AG-100.

LED	COLOR	STATUS	DESCRIPTION
PWR	Green	On	The ZyXEL AG-100 is receiving power.
		Off	The ZyXEL AG-100 is not receiving power.
LINK	Green	On	The ZyXEL AG-100 is connected.
		Blinking	The ZyXEL AG-100 is receiving or sending data.
		Off	The ZyXEL AG-100 has no connection.

## **Troubleshooting**

PROBLEM	CORRECTIVE ACTION	
Windows does not	Make sure the ZyXEL AG-100 is properly inserted into the	
auto-detect the ZyXEL AG-100.	CardBus slot and then restart your computer. Once the computer has restarted, check the status of the LEDs on the ZyXEL AG-100.	
	Perform a hardware scan by clicking <b>Start</b> , <b>Settings</b> , <b>Control Panel</b> and then double-click <b>Add/Remove Hardware</b> . (Steps may vary depending on Windows version). Follow the on-screen instructions to search for the ZyXEL AG-100 and install the driver.	
	Check for possible hardware conflicts. In Windows, click <b>Start</b> , <b>Settings</b> , <b>Control Panel</b> , <b>System</b> , <b>Hardware</b> and then click <b>Device Manager</b> . Verify the status of the ZyXEL AG-100 under <b>Network Adapter</b> . (Steps may vary depending on the Windows version).	
	Install the ZyXEL AG-100 in another computer. If the error persists, there may be a hardware problem. In this case, please contact ZyXEL customer support at 800-978-7222 or on the web at http://www.us.zyxel.com.	