2103/2103c/2103g Modem Module

Installation and Operation Guide





Foreword

This instruction manual is designed to help you gain a thorough understanding of the operation of the equipment. Teledyne Isco recommends that you read this manual completely before placing the equipment in service.

Although Teledyne Isco designs reliability into all equipment, there is always the possibility of a malfunction. This manual may help in diagnosing and repairing the malfunction.

If the problem persists, call or e-mail the Teledyne Isco Technical Service Department for assistance. Simple difficulties can often be diagnosed over the phone.

If it is necessary to return the equipment to the factory for service, please follow the shipping instructions provided by the Customer Service Department, including the use of the **Return Authorization Number** specified. **Be sure to include a note describing the malfunction.** This will aid in the prompt repair and return of the equipment.

Teledyne Isco welcomes suggestions that would improve the information presented in this manual or enhance the operation of the equipment itself.

Teledyne Isco is continually improving its products and reserves the right to change product specifications, replacement parts, schematics, and instructions without notice.

Contact Information

Customer Service

Phone: (800) 228-4373 (USA, Canada, Mexico)

(402) 464-0231 (Outside North America)

Fax: (402) 465-3022

Email: IscoCSR@teledvne.com

Technical Service

Phone: (800) 775-2965 (Analytical)

(800) 228-4373 (Samplers and Flow Meters)

Email: IscoService@teledyne.com

Return equipment to: 4700 Superior Street, Lincoln, NE 68504-1398

Other Correspondence

Mail to: P.O. Box 82531, Lincoln, NE 68501-2531

Email: IscoInfo@teledyne.com

Web site: www.isco.com

2103 Modem Module

Table of Contents

Section	Section 1 Introduction			
1.2 1.3 1.4	Introduction 1-1 Product Description 1-1 Identifying Module Components 1-2 Safety Symbols and Hazard Alerts 1-6 Technical Service 1-7			
Section	on 2 Installation and Operation			
2.2	Unpacking Instructions 2- Safety 2- Installation 2- 2.3.1 Latches - Locking and Unlocking 2- 2.3.2 Communication Connectors 2- 2.3.3 Stacking Modules 2-			
2.4	Telephone Line Connection (2103 only). 2-5 2.4.1 Modem Cable Connection 2-6 2.4.2 Connection Without the Modem Cable 2-6			
2.5	Connecting to Flowlink			
	Pushed Data Capability			
3.2	Overview 3-3 3.1.1 Data Retrieval 3-3 3.1.2 Text Messaging 3-3 3.1.3 Stacking / Compatibility 3-3 3.1.4 Cellular Service 3-4 Antenna Options 3-2 3.2.1 Connecting the Antenna 3-2			
	Connecting to Flowlink			
	Overview 4-1 4.1.1 Data Retrieval 4-1 4.1.2 Text Messaging 4-1 4.1.3 Stacking / Compatibility 4-1			
4.3	SIM Card			
	Connecting to Flowlink			

Section	on 5 Modbus Protocol
	Introduction 5-1 Operation 5-1 5.2.1 Establishing Communication 5-2 5.2.2 Module Addressing 5-2
$5.4 \\ 5.5$	5.2.2 Module Addressing 5-2 Configurations 5-3 Glossary of Terms 5-4 Common Acronyms 5-5 Register Specifications 5-6
Section	on 6 Maintenance
6.2	Maintenance Overview 6-1 6.1.1 Cleaning 6-1 Maintenance Kit 6-1 Desiccant 6-2
6.4	6.3.1 Replacing the Desiccant 6-2 6.3.2 Reactivating the Desiccant 6-2 Hydrophobic Filter 6-3 O-Rings 6-3
6.6	How to Obtain Service
Appe	ndix A Replacement Parts
	Replacement Parts
	How to Order
	General Accessories
Appe	ndix C Material Safety Data Sheets
C.1	Overview
List	of Figures
1-2 1-3 1-4	2103 Modem Components - Top View1-22103 Modem Components - Bottom View1-32103 Communication Connector Pins1-52103 Modem Cable Connector1-6
$\frac{2-2}{2-3}$	Connecting the Modem Cable2-52103 Modem Cable Connector2-5Flowlink Connect Screen2-6Resolution Screen2-7
2-5 2-6 2-7	Measurements Screen2-7Site Info Screen2-8Setting dialout phone numbers and alarm conditions2-8
$\frac{2-9}{3-1}$	TAP Service Parameters2-9Data Storage tab2-102103C magnetic mount antenna3-22103C buried antenna3-2
3-3	Protective connector shell pieces for the in-street antenna

3-5	Antenna connected to the 2103C modem	. 3-4
3-6	6 Wireless Power Control screen	. 3-5
3-7	Wireless Power Schedule screen	. 3-5
4-1	Accessing the SIM card on the bottom of the module	. 4-2
	Inserting the SIM card into the module	
4-3	3 2103G with a magnetic mount antenna	. 4-3
4-4	2103G with an in-street antenna	. 4-3
4-5	Protective connector shell pieces for the in-street antenna	. 4-4
4-6	6 Connecting an antenna to the 2103G	. 4-4
4-7	Antenna connected to the 2103G modem	. 4-5
4-8	8 Wireless Power Control screen	. 4-6
4-9	Wireless Power Schedule screen	. 4-6
		5 2
5-1	Configuration Example (Direct Connection Shown)	. 5-5
5-1	Configuration Example (Direct Connection Shown)	. ა-ა
		. ฮ-ฮ
	of Tables	. ט-ט
List	of Tables	
$\frac{List}{\frac{1}{1}}$	of Tables 2103 Modem Module Components - Top View	. 1-2
List	of Tables 2103 Modem Module Components - Top View	. 1-2 . 1-3
List 1-1 1-2 1-3	of Tables 2103 Modem Module Components - Top View	. 1-2 . 1-3 . 1-4
List 1-1 1-2 1-3 1-4	2103 Modem Module Components - Top View	. 1-2 . 1-3 . 1-4
List 1-1 1-2 1-3 1-4	2103 Modem Module Components - Top View 2 2103 Modem Module Components - Bottom View 3 2103 Modem Module Technical Specifications 4 Specifications – 2191 Battery Module	. 1-2 . 1-3 . 1-4 . 1-4
1-1 1-2 1-3 1-4 1-5	2103 Modem Module Components - Top View 2103 Modem Module Components - Bottom View 3 2103 Modem Module Technical Specifications 3 Specifications - 2191 Battery Module 3 2103 Communication Connector Pins (2103 only)	. 1-2 . 1-3 . 1-4 . 1-4
1-1 1-2 1-3 1-4 1-5	cof Tables 2103 Modem Module Components - Top View 2103 Modem Module Components - Bottom View 32103 Modem Module Technical Specifications 325 Specifications - 2191 Battery Module 32103 Communication Connector Pins	. 1-2 . 1-3 . 1-4 . 1-5 . 5-6

2103 Modem Module

Section 1 Introduction

1.1 Introduction

This instruction manual is designed to help you gain a thorough understanding of the operation of the 2103, 2103C, and 2103G Modem Modules. Teledyne Isco recommends that you read this manual completely before placing the equipment into service.

Information in this manual pertains to the 2103 phone line modem and the 2103C and 2103G cellular modems, except for the sections specific to one method of communication or the other.

For information specific to the setup and operation of the 2103C CDMA Cellular Modem, refer to Section 3, 2103C Cellular Modem Module.

For information specific to the setup and operation of the 2103G GSM Cellular Modem, refer to Section 4, 2103G Cellular Modem Module.

1.2 Product Description

The 2103 Modem is a portable data interrogation unit designed to transmit data from Isco's 2100 Series flow modules, which measure parameters of open channel flow streams. It works in conjunction with Isco's *Flowlink* software.

The 2103 Modem can be located anywhere within a stack of up to three other 2100 Series networked modules, using the same locking mechanism that connects the 2100 Series modules to each other. The 2103 is compatible with Isco's 2150 Area Velocity flow module, 2110 Ultrasonic flow module, 2101 Field Wizard, and 2102 wireless module. It is powered by Isco's 2191 battery module.

All enclosures are rated NEMA 4X, 6P(IP68). The permanently sealed enclosures are designed to meet the environmental demands of many sewer flow monitoring applications. All connections between modules, sensors, and communication cables lock in place. The locking mechanisms strongly secure the components and ensure a watertight seal.

1.3 Identifying Module Components

Figures 1-1 and 1-2 identify the key components of the 2103 Modem Module. $\,$



Figure 1-1 2103 Modem Components - Top View




Figure 1-2 2103 Modem Components - Bottom View

Table 1-3 2103 Modem Module Technical Specifications		
Dimensions	Length = 10.5 inches (26.7 cm) Width = 7.5 inches (19 cm) Height = 2.9 inches (7.4 cm)	
Weight	2 lbs. (.9 Kg)	
Material	High-impact molded polystyrene	
Enclosure	NEMA 4X, 6P, IP68 (2103), IP67 (2103c)	
Power	6.6 to 16.6 VDC, 141 mA typical at 12 VDC, 0.41 mA standby	
Operating Temperature	-4° to 140°F (-20° to 60°C)	
Storage Temperature	-40° to 140°F (-40° to 60°C)	
Typical Battery Life	291 days*	
Modulation Standards Supported (2103 only)	Bell 103, Bell 212, V.21, V.22, V.22 bis, V.23, V.32, V.32 bis, V.34	
Communication Speeds Supported	300, 1200, 2400, 4800, 7200, 9600, 12000, 14400, 16800, 19200, 21600, 24000, 26400, 28800, 31200, 33600 bps	
Error Correction Standards Supported	V.42 LAPM, MNP-2, MNP-4, MNP-10	
Data Compression Standards Supported	V.42 bis, MNP-5	

^{*} Actual battery life will vary depending upon configuration. The figure given assumes interrogation with Flowlink 4.13 once a week, with a site configuration of a 2103, 2150, and 2191 (using Energizer 529 batteries) and a connection speed of 33600 baud. The 2150 was configured to record level, velocity, flow rate every 15 minutes, total flow, and battery voltage every 24 hours.

	Table 1-4 Specifications – 2191 Battery Module		
Size (I	H×W×D)	$6.0 \times 9.6 \times 7.6$ in.	$15.2\times24.4\times19.3~\text{cm}$
Weigh	t (without batteries)	3.2 lbs.	1.4 kg
Materi	als	ABS plastic, stainless steel	
Enclos	sure (self-certified)	NEMA 4X, 6P	IP68
Batter	ies	6V alkaline lantern or lead-acid	lantern, quantity 2
Capac	city		
_	Alkaline Lantern Batteries	25 Ahrs	
	Lead-acid Lantern Batteries	5 Ahrs	




Table 1-5 2103 Communication Connector Pins (2103 only)			
Pin	Name	Description	
Α	LONA	Neuron differential transceiver Data A	
В	LONB	Neuron differential transceiver Data B	
С	VIN+	Positive power supply voltage input (+12 VDC nominal)	
D	VIN-	Negative power supply voltage input (0 VDC nominal)	
Е	RCVUP	PC data receiver inverted input	
F	XMTUP	PC data transmit inverted output	
G	Key	Aligns connector pins	

Figure 1-3 2103 Communication Connector Pins




Figure 1-4 2103 Modem Cable Connector

1.4 Safety Symbols and Hazard Alerts

This icon identifies a general hazard and is accompanied with details about the hazard. The instruction manual identifies the hazardous condition and any steps necessary to correct the condition. The manual presents this information in one of two ways:

A CAUTION

Cautions identify a potential hazard, which if not avoided, may result in minor or moderate injury. This category can also warn you of unsafe practices, or conditions that may cause property damage.

! WARNING

Warnings indicate potentially hazardous conditions. If you do not avoid these risks, they could cause you death or serious injury.

1.5 Technical Service

Although Teledyne Isco designs reliability into all of its equipment, there is always the possibility of a malfunction occurring. You can use this manual to help in diagnosing and repairing any malfunctions. If the malfunction persists, call or write the Teledyne Isco Technical Service Department for assistance:

Teledyne Isco Inc.
Technical Service Department
P.O. Box 82531
Lincoln, NE 68501
800-228-4373 or 402-464-0231
FAX: 402-465-3001

e-mail: IscoService@teledyne.com

Simple difficulties can often be diagnosed over the phone. If it is necessary to return the equipment to the factory for service, please follow the shipping instructions provided by the Technical Service Department, including the use of the Return Authorization Number specified. Be sure to include a note describing the malfunction. This will aid in the prompt repair and return of the equipment.

2103 Modem Module

Section 2 Installation and Operation

2.1 Unpacking Instructions

When the system arrives, inspect the contents for any damage. If there is damage, contact the delivery company and Teledyne Isco (or its agent) immediately.

! WARNING

If there is any evidence that any items may have been damaged in shipping, do not attempt to install the unit. Please contact Teledyne Isco (or its agent) for advice.

Teledyne Isco, Inc. Customer Service Dept. P.O. Box 82531 Lincoln, NE 68501 USA

Phone: (800) 228-4373 Outside USA & Canada call: (402) 464-0231

FAX: (402) 465-3022

E-mail: IscoCSR@teledyne.com

When you unpack the system, check the items against the packing list. If any parts are missing, contact the delivery company and Teledyne Isco's Customer Service Department. When you report missing part(s), please indicate them by part number. In addition to the main packing list, there may be other packing lists for various sub-components.

It is recommended that you retain the shipping cartons as they can be used to ship the unit in the event that it is necessary to transport the system.

Please complete the registration card and return it to Teledyne Isco, Inc.

2.2 Safety

⚠ WARNING

Avoid hazardous practices! If you use these instruments in any way not specified in this manual, the protection provided by the instruments may be impaired; this will increase your risk of injury.

! WARNING

The installation and use of this product may subject you to hazardous working conditions that can cause you serious or fatal injuries. Take any necessary precautions before entering a worksite. Install and operate this product in accordance with all applicable safety and health regulations, and local ordinances.

The 2100 Series components are often installed in confined spaces. Some examples of confined spaces include manholes, pipelines, digesters, and storage tanks. These spaces may become

hazardous environments that can prove fatal for those unprepared. These spaces are governed by OSHA 1910.146 and require a permit before entering.

2.3 Installation

Follow the instructions below to install your 2103 Modem. Most of these instructions are similar for the 2103C and 2103G, but if you have one of those modules, read Section 3 or 4 for additional installation information.

2.3.1 Latches - Locking and Unlocking

Latches must be operated to stack and unstack the modules in a Series 2100 stack. The mechanisms are the same for the 2103 Modem and other 2100 Series modules. Detailed instructions with photos can be found in your 2150 instruction manual.

Take a moment to familiarize yourself with operating the latches. You must unlock the latch to place the module on top of another module in a stack. The latch is unlocked by pushing in the latch release on the right side of the module. To lock the latch, push in the latch on the left side of the module.

CAUTION

The latch can be damaged by applying too much force. Never press on both sides at the same time. Do not force the latch if it is obstructed. While some degree of pressure must be applied to slide the latch, the ends of the latches should never bend more than ¹/₈".

✓ Note

Latches will "click" when they are fully locked and unlocked.

2.3.2 Communication Connectors

Connecting the 2103 Modem module involves uncapping and capping communication connectors. When a communication connector is not in use, the connector should always be capped. The cap will seal the connector to prevent corrosion, and will improve communications.

When a communication connector is in use, store the cap on the holder next to the connector. The communication connector will be sealed by its mating connector.

Detailed instructions and photos can be found in your 2150 or 2110 instruction manual.

A CAUTION

Caps **PUSH ON** and **PULL OFF**. Do not rotate the caps to remove them from the connectors.

✓ Note

For modules to correctly stack and lock together, protective caps between the modules must be stored on the holders.

2.3.3 Stacking Modules

The 2103 Modem Module can be located anywhere within a stack of up to three 2100 Series networked modules. It will draw its power from the battery module located in the stack.

To connect the 2103 with a 2100 Series module, refer to the following instructions.

- 1. On the top of the 2100 Series module, remove the cap and stow it on the holder. This exposes the communication connector on the module.
- 2. Inspect the module's communication connector. It should be clean and dry. Damaged O-rings must be replaced.
- 3. Unlock the 2103's latch by pressing in on the latch release (right side).
- 4. Underneath the 2103, remove the cap from the lower communication connector and stow it in the holder.
- 5. Lock the latch. Locking the latch correctly seats and aligns the lower cap in its holder.
- 6. Position the 2103 over the 2100 Series module. Align the connectors and lower the 2103 onto the other module.
- 7. Unlock the 2103's latch by pressing in on the latch release (right side).
- 8. Firmly press the modules together and lock the 2103's latch (left side).

The communications indicator will blink during the start-up routine to indicate the 2103 is operating.

2.4 Telephone Line Connection (2103 only)

The FCC (Federal Communications Commission) governs communications over telephone lines. Your local telephone company will provide you with the line between the 2103 Modem and your computer. Contact them for connection information.

The 2103 Modem is in compliance with FCC part 68 rules. However:

✓ Note

In tests conducted by the Communication Certification Laboratory, the 2103 Modem did not pass conducted RF testing on telephone line at 5 MHz, 3V RMS. For details, see international standard EN 61000-4-6.

In the event of this failure, the modem may be subject to disconnection.

Accordingly, the FCC requires the following information be published:



The 2103 Modem is designed to be used on standard device telephone lines. It connects to the telephone by means of a standard jack called the USOC RJ-11C. Connection to telephone-company-provided coin service (central office implemented systems) is prohibited, and connection to party lines

service is subject to state tariffs.

Changes in Attestation Procedure for Plugs and Jacks

Isco Inc. attests that the network interface plugs or jacks used on this equipment comply with and will continue to comply with the mechanical requirements specified in Part 58, sub-part F, specifically the dimensions, tolerances and metallic plating requirements. The compliance of these connectors will be assured by purchase specifications and incoming inspection. Documentation of such specifications and/or inspections will be provided to the FCC within 30 days of their request for the same.

Telephone Company Procedures

The goal of the telephone company is to provide you with the best service it can. In order to do this, it may occasionally be necessary for them to make changes in their equipment, operations or procedures. If these changes might affect your service or the operation of your equipment, the telephone company will give you notice, in writing, to allow you to make any changes necessary to maintain uninterrupted service.

In certain circumstances, it may be necessary for the telephone company to request information from you concerning the equipment which you have connected to your telephone line. Upon request of the telephone company, provide the FCC registration number and the ringer equivalence number (REN); both of these items are listed on the equipment label. The sum of all the RENs on your telephone lines should be less than five in order to assure proper service from the telephone company. In some cases, a sum of five may not be usable on a given line. Consult your telephone provider.

If Problems Arise: If any of your telephone equipment is not operating properly, you should immediately remove it from your telephone line, as it may cause harm to the telephone network. If the telephone company notes a problem, they may temporarily discontinue service. When practical, they will notify you in advance of this disconnection. If advance notice is not feasible, you will be notified as soon as possible. When you are notified, you will be given the opportunity to correct the problem and will be informed of your right to file a complaint with the FCC. Contact your local telephone service provider if you have any questions about your phone line.

In the event repairs are needed on the 2103 Modem, they should be performed by Teledyne Isco Inc. or its authorized representative. For information, contact the Teledyne Isco Customer Service Department at (800) 228-4373 or (402) 464-0231.

2.4.1 Modem Cable Connection

After you have installed the 2103 on the stack, you need to attach the modem cable so the module can be connected to a phone line.

Remove the connector cap from the 5-pin circular modem cable connector on the right hand side of the 2103. Attach the modem cable to the connector (Figure 2-1), and then connect the other end of the modem cable to a standard telephone jack (USOC RJ-11C).




Figure 2-1 Connecting the Modem Cable

2.4.2 Connection Without the Modem Cable

If desired, the 2103 can be connected to a standard telephone line by attaching the telephone line cable to a connector that mates with the 2103's 5-pin circular modem cable connector (Figure 2-2). Be sure that you have a water tight seal on your wire connections.

For your reference, the modem cable uses a 5-pin amphenol socket, MS3106A-5S.




Figure 2-2 2103 Modem Cable Connector

2.5 Connecting to Flowlink

After the 2103 is installed and the modem cable connected, you need to establish that there is a modem at the site, by configuring the module in Isco's Flowlink software.

✓ Note

The 2103 Modem requires Flowlink 4.13 or later. Earlier versions do not support the modem.

Open Flowlink and go to the connect screen (Figure 2-3) by either selecting it from the pull down menu or clicking on the Quick Connect icon.




Figure 2-3 Flowlink Connect Screen

Make sure the Type is Direct, and click on the 2100 Instrument icon to connect. The system will detect a new modem module, and will display the Network Resolution screen (Figure 2-4).




Figure 2-4 Resolution Screen

Select the appropriate action on the screen to add the new modem module and then click OK. When the module has been added to the system, you will see the Measurements Screen (Figure 2-5).





Figure 2-5 Measurements Screen

✓ Note

If you are using a 2103c or 2103G, you need to set up a Wireless Power Control schedule at this point. For those instructions, refer to Sections 3-3 or 4-5.



Click on the Site Info tab to display that screen (Figure 2-6).

Figure 2-6 Site Info Screen

Select Modem under the Connection Information section. Enter the phone number to be used by the modem to connect to the site. Click Apply (F9) to apply the changes.

2.5.1 Setting Up Text Messaging

To program the 2103 for text messaging, you must have the Telocator Alphanumeric Protocol (TAP) server number and parameter settings of your cell phones and/or pagers.

1. Make sure you are connected to the site, and select the Dialout Alarms tab (Figure 2-7).




Figure 2-7 Setting dialout phone numbers and alarm conditions

- 2. In the Phone Number list box, type the contact telephone numbers. These must be valid TAP access numbers. You must enter at least one number; you can enter as many as five. When an alarm condition is triggered, the system will try dialing each phone number in the list.
 - a. To find this number, and the communications parameter settings, consult with your pager service, or go to http://www.avtech.com/Support/TAP/index.htm
 or to

http://www.notepage.net/tap-phone-numbers.htm.

b. With either online location, click the letter corresponding with the first letter of the name of your service provider. You will advance to a screen that shows your service provider, the access number, and parameter values (Figure 2-8).




Figure 2-8 TAP Service Parameters

- 3. For each phone number entered, enter a Pager ID, which is the phone number of the cell phone or pager that will receive the text message. (The ID will come from your pager service.)
- 4. You have the option of entering a password of up to six characters in length.
- 5. In the Comm field, select 7E1 or 8N1for the communications control specification (your pager service has this information).
- 6. You must enter a message to be sent to the pager. In the field labeled Message, type the outgoing text message (maximum of 32 characters).
- 7. Under "Alarm condition", select the desired alarm parameter from the drop-down list, then define the alarm conditions.
- 8. Click the Apply button or press F9 when you are done, to update the module's settings.

2.6 Pushed Data Capability

The module can automatically send data to a designated server running Isco Flowlink Pro software, using 1xRTT packet-switched data transmission (2103c), GPRS packet-switched data transmission (2103G), or a land line modem (2103). The user-specified primary data transmission interval (5 minutes to 24 hours) can automatically change to a secondary interval when specific site conditions occur at the monitoring site. An Oracle® or Microsoft® SQL database is required to use this feature. Contact the factory for additional information.

To use the data push capability, you need to make sure you are connected to the modem module, and then select the Data Storage tab (Figure 2-9).




Figure 2-9 Data Storage tab

Click on the Pushed Data button to set up a schedule for the data to be pushed to Flowlink Pro.

Detailed Flowlink instructions are beyond the scope of this manual. Flowlink's operating instructions are available in a Windows Help format. You can access the help topics for an active window by clicking on its *Help* button or by pressing F1 on your computer's keyboard. You can also access Help topics by selecting Help from the Flowlink menu.

2103 Modem Module

Section 3 2103C Cellular Modem Module

3.1 Overview The 2103C Modem (part #68-2000-033 with a magnetic mount

antenna; part #68-2000-030 with an in-street antenna) is a portable data retrieval unit designed to transmit data from Isco's

2100 Series open channel flow modules.

3.1.1 Data Retrieval Using a computer running Isco's Flowlink® software, you can

call up your monitoring site to configure the flow module settings

and retrieve flow data.

Detailed operating instructions are available in Flowlink in a Windows Help format, and in the flow module's Installation and

Operation Guide.

3.1.2 Text Messaging Using CDMA technology, the 2103C is capable of digital text mes-

saging to up to 5 text capable cellular phones or pagers when a

programmed alarm condition occurs.

Consult the Flowlink Help files and Installation and Operation

Guide for details on programming alarm conditions.

3.1.3 Stacking / The 2103C can be located anywhere within a stack of 2100 Series modules, or used remotely, powered by an Isco 2191 battery

modules, or used remotely, powered by an Isco 2191 battery module. The 2103C is compatible with Isco's 2150 Area Velocity flow module, 2110 Ultrasonic flow module, 2101 Field Wizard,

and 2102 Wireless module.

3.1.4 Cellular Service The 2103C only works in a CDMA cellular service area for CSD

operation.

Not all CDMA service areas have 1xRTT service. See your local

CDMA service provider for service availability.

3.2 Antenna Options

One of 2 antenna types is included with your system, also specified when ordering:

• The **external, magnetic mount** antenna (part #68-2000-032) is 3 inches tall and has a 6 foot cable. This antenna is for general use, and is especially desirable when the system is stored within an enclosure.



Figure 3-1 2103C magnetic mount antenna

• The **external, in-street** antenna (part #68-2000-031) is 4" in diameter and 1.75" tall, with a 10 foot long cable. It is used primarily in manhole applications.

The antenna is buried next to the manhole, in a hole bored into the pavement, at a depth leaving the top of the antenna flush with the street.

A connecting hole is drilled through the manhole collar for the antenna's cable. To complete the installation, fill the holes in with cement.



Figure 3-2 2103C buried antenna

3.2.1 Connecting the Antenna

The antennas are connected to the $2103\mathrm{C}$ using the connector on the right hand side of the module.

The two types of antennas use a protective connector shell on the end of the cable to protect the end connector from the elements. On the magnetic mount antenna, this connector shell is installed at the factory. If you order an in-street antenna, the shell is left off to make it easier to install the buried antenna.

When you are ready to connect the in-street antenna to the 2103C modem, you will need to assemble the connector shell onto the end of the cable. The pieces of the connector shell are shown in Figure 3-3. An instruction sheet (P/N 60-2003506) is shipped with the antenna, and shows you the assembly steps.




Figure 3-3 Protective connector shell pieces for the in-street antenna

To connect an antenna to the 2103C, twist the protective connector shell (Figure 3-4) to loosen its components. Slide the components down the cable to reveal the gold connector end.




Figure 3-4 Connecting an antenna to the 2103C

When the gold SMA connector is tightly attached to the modem, slide the connector shell forward. Press down on the metal latch on the side of the modem and push the connector shell onto the modem, as shown in Figure 3-5.



Figure 3-5 Antenna connected to the 2103C modem.

✓ Note

When any communication connector is not in use, it should always be capped. The cap will seal the connector to prevent corrosion, prevent moisture from entering the unit, and improve communications.

✓ Note

For the transmitter to comply with FCC Maximum Permissible Exposure (MPE) regulations, the antenna needs to be located a minimum of 30 centimeters (12 inches) from the human body.

3.3 Connecting to Flowlink

The instructions for connecting to Flowlink that are in Section 2-5 apply to the 2103°C. However, for the 2103°C, you will also need to set up a Wireless Power Control schedule.

Select the Wireless Power Control tab (Figure 3-4) and click on the Set Wireless Schedule button to set up a schedule.




Figure 3-6 Wireless Power Control screen

In the Wireless Schedule screen (Figure 3-5), enter the type of schedule and its start and stop times. Press OK when done.




Figure 3-7 Wireless Power Schedule screen

2103 Modem Module

Section 4 2103G Cellular Modem Module

4.1 Overview

The 2103G Modem (part #68-2000-042 with a magnetic mount antenna; part #68-2000-041 with an in-street antenna) is a portable data retrieval unit designed to transmit data from Isco's 2100 Series open channel flow modules.

4.1.1 Data Retrieval

Using a computer running Isco's Flowlink® software, and the appropriate cellular service, you can call up your monitoring site to configure the flow module settings and retrieve flow data.

Detailed operating instructions are available in Flowlink in a Windows Help format, and in the flow module's Installation and Operation Guide.

4.1.2 Text Messaging

Using GSM technology, and with the appropriate SIM card, the 2103G is capable of digital text messaging to up to 5 text capable cellular phones or pagers when a programmed alarm condition occurs.

Consult the Help files and Installation and Operation Guide for details on programming alarm conditions.

4.1.3 Stacking / Compatibility

The 2103G can be located anywhere within a stack of 2100 Series modules, or used remotely, powered by an Isco 2191 battery module. The 2103G is compatible with Isco's 2150 Area Velocity flow module, 2110 Ultrasonic flow module, 2101 Field Wizard, and 2102 Wireless module.

4.2 SIM Card

The data transmission capabilities of the 2103G are dependent upon the type of service plan you have through your cell phone service provider. The service parameters, or provider, can be changed by simply replacing the Subscriber Information Module (SIM) card in your 2103G. Check with your service provider to verify what data transmission technologies are available for your use.

To access the SIM card slot, turn the 2103G module over. On the bottom is a round metal cover that, when unscrewed, provides access to the card (Figure 4-1).



Figure 4-1 Accessing the SIM card on the bottom of the module

It's easiest to insert the SIM card if you set the module on its side (Figure 4-2) and push the card into its slot as shown. To remove the card from its slot, push on it and it will pop out enough that you can grasp the end and pull it out.



Figure 4-2 Inserting the SIM card into the module

After inserting the card, slide the internal lock (next to the slot for the SIM card) to the locked position, to make sure the SIM card stays in place. Then reinstall the metal cover on the bottom of the module.

4.3 Antenna Options

One of 2 antenna types is included with your system, also specified when ordering:

• The **external, magnetic mount** antenna (part #68-2000-047) is 6 feet long and 5 inches tall. This external antenna is for general use, and is especially desirable when the system is stored within an enclosure.



Figure 4-3 2103G with a magnetic mount antenna

• The **external**, **in-street** antenna (part #68-2000-031) is 10 feet long, and used primarily in manhole applications.

The antenna is buried next to the manhole, in a hole bored into the pavement, at a depth leaving the top of the antenna flush with the street.

A connecting hole is drilled through the manhole collar for the antenna's cable. To complete installation, fill the holes in with cement.



Figure 4-4 2103G with an in-street antenna

4.3.1 Connecting the Antenna

The antennas are connected to the 2103G using the connector on the right hand side of the module.

The two types of antennas use a protective connector shell on the end of the cable to protect the end connector from the elements. On the magnetic mount antenna, this connector shell is installed at the factory. If you order an in-street antenna, the shell is left off to make it easier to install the buried antenna.

When you are ready to connect the in-street antenna to the 2103G modem, you will need to assemble the connector shell onto the end of the cable. The pieces of the connector shell are shown in Figure 4-5. An instruction sheet (P/N 60-2003506) is shipped with the antenna, and shows you the assembly steps.




Figure 4-5 Protective connector shell pieces for the in-street antenna

To connect an antenna to the 2103G, twist the protective connector shell (Figure 4-6) to loosen its components. Slide the components down the cable to reveal the gold connector end.




Figure 4-6 Connecting an antenna to the 2103G

When the gold SMA connector is tightly attached to the modem, slide the connector shell forward. Press down on the metal latch on the side of the modem and push the connector shell onto the modem, as shown in Figure 4-7.



Figure 4-7 Antenna connected to the 2103G modem.

✓ Note

When any communication connector is not in use, it should be capped. The cap will seal the connector to prevent corrosion, prevent moisture from entering the unit, and improve communications.

✓ Note

For the transmitter to comply with FCC Maximum Permissible Exposure (MPE) regulations, the antenna needs to be located a minimum of 30 centimeters (12 inches) from the human body.

4.4 Connecting to Flowlink

The instructions for connecting to Flowlink that are in Section 2-5 apply to the 2103G. However, for the 2103G, you may also need to set up a Wireless Power Control schedule.

⋈ Note

This section only applies to CSD operation, and requires the appropriate cellular service and SIM card.

Select the Wireless Power Control tab (Figure 4-6) and click on the Set Wireless Schedule button to set up a schedule.




Figure 4-8 Wireless Power Control screen

In the Wireless Schedule screen (Figure 4-7), enter the type of schedule and its start and stop times. Press OK when done.




Figure 4-9 Wireless Power Schedule screen

4.5 Setting Up The Access Point Name

You may need to set up the access point that your cellular service uses.

✓ Note

This section only applies to GPRS operation, and requires the appropriate cellular service and SIM card.

The access point information is available from your service provider.

- 1. From your Windows desktop, start the HyperTerminal program (located under Accessories, Communication).
- 2. Make sure the 2103G is powered on, and that HyperTerminal is disconnected. Select the COM port you will direct connect to.
- 3. Configure the COM port to: **38400 bps, 8 data bits, no parity, no stop bits, no flow control**. Click OK.
- 4. Click on the phone icon to connect, and enter 3 or 4 question marks (?).
- 5. At the > prompt, enter **sp** and press Return.
- 6. At the > prompt, enter **18** and press Return.
- 7. At the **DPUSH>** prompt, enter **apn** and press Return. This will display the current setting for the access point name
- 8. If you need to change the access point name, at the > prompt, enter **apn** "name of access point" and press Return.
- 9. You will be informed that the phone network information has been updated.
- 10. Cycle power to the modules.

There are several commands that can be used in HyperTerminal. The **>dcfg** command will show what IP address you should be using. The **>dsp** command shows the network type (GSM) and the access point name.

Section 5 Modbus Protocol

Sections 5.1 through 5.5 give an overview of the basic capabilities and operation of Modbus protocol as it applies to Isco 2100 Series flow modules.

For a Glossary of Terms and Common Acronyms, see sections 5.4 and 5.5.

For Modbus technical specifications, turn to section 5.6.

5.1 Introduction

Modbus is a simple command/response mechanism to read from and write to specific memory locations called *registers*. A register is a holding place for a piece of digital information within the equipment. There are three standard protocols for Modbus: Modbus RTU, Modbus TCP/IP, and Modbus ASCII. The Isco 2100 Series devices use Modbus ASCII protocol, the metho (vwssme)-4.6d0 asemoe flexib@commuhniaction

 $.47.9 (\ Modb) \\ 586 (u) - 5.4 (s34.2 (\) \\ TJ \\ 1453601 \ 0 \ TD \\ 0.1642 \ Tc \\ 0.0$

Modbat10.7(ionius)6(in)-5.2dependwin

By accessing these registers you can obtain the current value of whatever parameter you desire. The reading(s) can then be displayed or stored wherever you designate as a destination; for example, a process control computer.

✓ Note

Level, flow, velocity, and temperature data is stored in metric units only.

Not all registers are limited to read-only data storage. You can also use some registers for control purposes. For example, by writing a "1" value to register 24 ("Identify Module" register), you will tell a 2100 module to light the LED on the front of the module.

5.2.1 Establishing Communication

There are several different communications protocols supported in the 2100 series that require auto-baud rate detection. Because of this, each time a modbus connection is made, the module uses a polling mechanism to repeatedly send a command until a response is received. It may take up to 20 command retries before the module has identified the baud rate and a response is received.

5.2.2 Module Addressing

When connecting to a site via a Modbus OPC server, you use a dedicated line of communication to that module or stack from the OPC server, which can be a dedicated communications cable (direct connection) or a dedicated phone number (modem).

When you are using a direct connection, you are dedicating a specified COM port on the computer, and that COM port determines the site to which you are connecting.

When you are using a modem, the dedicated line is defined by the site's phone number.

If you connect more than one 2100 Series module at a site, the Modbus OPC server, while using the shared communication line for all of the modules within the network, must have some way to differentiate between the modules. When sending a command to a specific module, the command has an address field. This allows the server software to talk to, as well as control, the specified module, while ignoring other modules in the same stack or site.

Each module capable of Modbus Protocol communication will automatically create its own specific ASCII address within the site, using:

- The model numbers of the modules
- The user-defined module names

5.3 Configurations

A variety of configurations can be made with Modbus, either through direct connection or through a modem.

In the example shown in Figure 5-1, you are direct-connecting a server PC to two individual 2150s through Modbus, using the COM ports on the OPC Server, which are directly connected to the remote 2150s.

Connection to the module is made through the RS-232 communication port on the top of the module.

✓ Note

For low power operation, we recommend connecting the module(s) to the computer using the straight-through cable (Isco part number 60-5314-529), which consumes less power, instead of our standard interrogation cable.

In Figure 5-1, the OPC Server PC must have two COM ports. Modbus requires one COM port each, for direct connection of each 2150.




Figure 5-1 Configuration Example (Direct Connection Shown)

The operation sequence for the example above can be summarized in the following steps:

2150:

- 1. 2150s take readings from probes.
- 2. 2150s store readings (level, velocity, flow rate, etc.) in their specified registers.

Process Control:

- 3. The user requests data through Process Control.
- Process Control asks the OPC server to gather information.

- 5. OPC connects to the 2150 stack through the cable (direct connection), takes register data from the specified 2150, and populates the OPC server's holding index.
- 6. Process Control takes data from the OPC server's holding index and gives data to the user.

Note that Process Control can be either manual or automated in this example, and that the OPC server and Process Control may be located physically on the same computer.

5.4 Glossary of Terms

ASCII – Short for American Standard Code for Information Interchange, ASCII is a code that represents English characters with numbers. Most computers represent text with ASCII code, making it possible for one computer or device to share data with another.

2100 modules support Modbus ASCII protocol.

Dedicated Line – A telecommunications path reserved for communication between two specified points and not shared among multiple points.

Modbus Protocol - Modbus Protocol is a messaging structure used to establish master-slave/client server communications between intelligent devices. Modbus is a simple command/response mechanism to read from and write to registers.

OPC – OPC (OLE for Process Control) means open connectivity via open (free for use) standards. It is a series of software standards specifications that fill a need in automation (like printer drivers did for Windows), acting as a translator for data transmission and process control.

The specification defines a standard set of objects, interfaces, and methods for use in process control and manufacturing automation applications to facilitate interoperability. There are hundreds of OPC Data Access servers and clients.

Registers – Registers are locations in memory that have specific data stored for retrieval or are used for control functions. A register is a holding place for a piece of digital information within the equipment. The definition of what is contained and where (the registry number, or address) is decided by the manufacturer (in this case Teledyne Isco).

SCADA – SCADA (Supervisory Control And Data Acquisition) is a computer system for gathering and analyzing real-time data. SCADA systems are used to monitor and control plant operation, or equipment in industries such as telecommunications, water and waste control, energy, oil and gas refining, and transportation.

The SCADA system transfers the information (for example, where a leak has occurred in a pipeline), back to a central site, alerting the home station of the leak, performing necessary analysis and control (such as determining if the leak is critical), and displaying the information in a logical and organized manner.

SCADA systems can be relatively simple, such as one that monitors the environmental conditions of a small office building, or very complex, such as a system that monitors all the activity in a nuclear power plant or a municipal water system.

5.5 Common Acronyms

ASCII - American Standard Code for Information Interchange

DCS – Distributed Control Systems

MTU - Master Terminal Unit

OPC - Object Linking and Embedding (OLE) for Process Control

PLC - Programmable Logic Controller

RTU - Remote Terminal Unit

SCADA - Supervisory Control And Data Acquisition

TCP/IP - Transmission Control Protocol/Internet Protocol

5.6 Register Specifications

All numbers in the Modbus registers are stored most significant byte first. If the polling device has a byte ordering of least significant byte first (an Intel-based PC, for example), the bytes will need to be reversed after they are received.

The Modbus ASCII address is used to index the data by modules.

Modbus ASCII address 1 contains information related to the site. The first register contains a 16-bit integer count of the number of modules that have data to report. The maximum number of modules that can be supported is 4.

Modbus ASCII addresses 2 through the number of modules plus 1 contain data from the individual modules.

The Modbus ASCII addresses will be sorted by the model number, and then by module name, which is entered by the user through Flowlink. This allows the user to control the ordering of the addresses and easily predict what data will be in specific registers.

Every measured parameter has a corresponding status and measurement time that are updated with each measurement.

The maximum number of supported measurements from all modules in the system is 28.

The Modbus registers are assigned within 30 seconds after the 2100 module is powered up. To conserve power for the users who do not use Modbus communications, no Modbus registers will be updated with sensor readings until a Modbus master communicates with the 2100 module.

The register definitions for the Site Information device (Modbus ASCII address 1) are in Table 5-1 below:

Table 5-1 Modbus ASCII Address 1 Register Definitions				Definitions
Register Number(s)	Name	Data type	Units	Read/Write
1	Number of modules (N) (1-4)	16 bit integer	None	Read
2-20	Site name	38-byte string	None	Read

The register definitions for the individual modules (Modbus ASCII addresses 2-(N+1)) are in Table 5-1 below:

Table 5-2	2 Modbus ASCII Addre	ss 2-(N+1) Regis	ster Definition	IS
Register Number(s)	Name	Data Type	Units	Read/Write
1-4	Model number	8-byte string	None	Read
5-23	Module name	38-byte string	None	Read
24 ¹	Identify module	16 bit integer	None	Read/Write
25 ²	Take reading flag	16 bit integer	None	Read/Write
26 ³	Update interval	16 bit integer	Seconds	Read/Write
27 ⁴	Active flag 1	16 bit field	None	Read
28	Active flag 2	16 bit field	None	Read
29	Active flag 3	16 bit field	None	Read
30	Active flag 4	16 bit field	None	Read
40,41	Level	4-byte float	Meters	Read
42	Level status code ⁵	16-bit integer		Read
43-52	Level time record	Time ⁶		Read
55,56	Velocity	4-byte float	Meters/second	Read
57	Velocity status code	16-bit integer		Read
58-63	Velocity time record	Time		Read
70,71	Flow	4-byte float	Cubic Meters/sec	Read
72	Flow status code	16-bit integer		Read
73-78	Flow time record	Time		Read
85,86	Flow 1	4-byte float	Cubic Meters/sec	Read
87	Flow 1 status code	16-bit integer		Read
88-93	Flow 1 time record	Time		Read
100,101	Volume	4-byte float	Cubic Meters	Read
102	Volume status code	16-bit integer		Read
103-108	Volume time record	Time		Read
115,116	Volume 1	4-byte float	Cubic Meters	Read

Table 5-2 Modbus ASCII Address 2-(N+1) Register Definitions (Continued) Register Number(s) Name Data Type Units Read/Write

- (1) A write to the Identify module register will cause the module to perform the identify operation which may be a steady LED for a few seconds or a beep in the Field Wizard.
- (2) Setting the Take Reading flag to 1 will cause the module to update the registers with current data readings. It will be set to zero when the readings have all been updated. This may be used to initiate readings and poll for when they are ready to be read. It may take up to 50 seconds to update all the readings, depending upon the flow conditions. Setting the Take Reading flag to 2 causes an automatic, 15 second update of readings when a Modbus master is polling the 2100.
- (3) The Update Interval specifies an interval in seconds that the registers are automatically updated. It defaults to zero, which indicates that no automatic updating will occur.
- (4) The Active Flag (1-4) bit fields specify what fields/registers are active in the list. This provides support for a maximum of 64 fields. For example, if bit 0 of register 27 is set, the Level (registers 40,41) is active. If bit 1 of register 27 is set, then the Velocity (registers 55,56) is active. If bit 0 of register 28 is set, the Analog channel 7 (registers 265,266) is active.
- (5)A non-zero status code indicates a measurement problem.
- (6) Time is represented in a series of registers: Order is from lowest address to highest Seconds (0-59), Minutes (0-59), Hours (0-23), Days (1-31), Month (1-12) and Year (1977-2099).

Hours (0-23), Days (1-31), Month (1-12) and Year (1977-2099).				
117	Volume 1 status code	16-bit integer		Read
118-123	Volume 1 time record	Time		Read
130,131	Voltage	4-byte float	Volts	Read
132	Voltage status code	16-bit integer		Read
133-138	Voltage time record	Time		Read
145,146	Temperature	4-byte float	Degrees Celsius	Read
147	Temperature status code	16-bit integer		Read
148-153	Temperature time record	Time		Read
160,161	Internal Temp	4-byte float	Degrees Celsius	Read
162	Internal Temp status code	16-bit integer		Read
163-168	Internal Temp time record	Time		Read
175,176	Analog channel 1	4-byte float	0-100 percent	Read
177	Analog channel 1 status code	16-bit integer		Read
178-183	Analog channel 1 time record	Time		Read
190,191	Analog channel 2	4-byte float	0-100 percent	Read
192	Analog channel 2 status code	16-bit integer		Read
193-198	Analog channel 2 time Record	Time		Read
205,206	Analog channel 3	4-byte float	0-100 percent	Read
207	Analog channel 3 status code	16-bit integer		Read
208-213	Analog channel 3 time record	Time		Read
220,221	Analog channel 4	4-byte float	0-100 percent	Read
222	Analog channel 4 status code	16-bit integer		Read
223-228	Analog channel 4 time record	Time		Read
235,236	Analog channel 5	4-byte float	0-100 percent	Read
237	Analog channel 5 status code	16-bit integer		Read

Table 5-2 Modbus ASCII Address 2-(N+1) Register Definitions (Continued)				itinued)
Register Number(s)	Name	Data Type	Units	Read/Write
238-243	Analog channel 5 time record	Time		Read
250,251	Analog channel 6	4-byte float	0-100 percent	Read
252	Analog channel 6 status code	16-bit integer		Read
253-258	Analog channel 6 time record	Time		Read
265,266	Analog channel 7	4-byte float	0-100 percent	Read
267	Analog channel 7 status code	16-bit integer		Read
268-273	Analog channel 7 time record	Time		Read
280,281	Analog channel 8	4-byte float	0-100 percent	Read
282	Analog channel 8 status code	16-bit integer		Read
283-288	Analog channel 8 time record	Time		Read

Table 5-3 Measurement Parameters by Model Number*			
2108	2110	2150, 2151	
Analog channel 1	Level	Level	
Analog channel 2	Flow	Velocity	
Analog channel 3	Volume	Flow	
	Voltage	Flow 1	
	Temperature	Volume	
		Volume 1	
		Voltage	
		Temperature	
	2108 Analog channel 1 Analog channel 2	2108 Analog channel 1 Analog channel 2 Analog channel 3 Volume Voltage	

Section 6 Maintenance

6.1 Maintenance Overview


This section explains the maintenance requirements of the 2103 Modem.

The 2103 Modem is designed to perform reliably in adverse con-

6.3 Desiccant

The 2103 Modem uses desiccant to protect the internal components from moisture damage. The cartridge is filled with indicating silica gel, which is blue or yellow when dry. As the desiccant becomes saturated, the color changes from blue to pink, or from yellow to green. Replace the desiccant before the entire length of the cartridge turns pink or green.

6.3.1 Replacing the Desiccant



To replace the silica gel desiccant:

- 1. Hold the cartridge upright with the collar at the top.
- 2. As shown in the margin, push the collar off the cartridge.
- 3. Empty the saturated silica gel beads or granules.
- 4. Fill the tube with new (Isco P/N 099-0011-03) or reactivated (see section 3.3.2) silica gel desiccant.
- 5. Press the collar onto the tube.
- 6. Slide the cartridge into the 2103 Modem. Tighten the collar to seal the cartridge in place.



6.3.2 Reactivating the Desiccant

Silica gel beads and granules of desiccant can be reactivated.

! CAUTION

Desiccant may produce irritating fumes when heated. Observe the following precautions:

- Use a vented oven in a well ventilated room.
- Do not remain in the room while the regeneration is taking place.
- Use the recommended temperature. Avoid heating the desiccant at higher than recommended temperatures.

There is the potential of irritating fumes coming from the desiccant during reactivation. Because of this, we urge you to use caution, and to heat the desiccant in a well ventilated room. Material Safety Data Sheets are in the back of this manual.

The desiccant's ability to remove moisture may lessen with each saturation/reactivation cycle, resulting in a need for more frequent service. After several cycles, the desiccant may no longer be effective as it saturates too quickly. At this point, replace the desiccant.

Silica gel

To reactivate the silica gel desiccant, pour the spent desiccant into a heat resistant container. Never heat the cartridge assembly; it will melt. Heat the silica gel in a *vented convection oven* at 212° to 350°F (100° to 175°C) for two to three hours, or until the blue or yellow color returns. Allow the desiccant to cool and store it in an airtight container until ready for use.

6.4 Hydrophobic Filter

If the 2103 Modem module is submerged, a hydrophobic filter prevents water from entering the desiccant cartridge. Any amount of water will plug the filter and it must be replaced so the case will be reliably ventilated.



To remove the hydrophobic filter, grasp the filter and pull it from the desiccant cartridge collar. The filter is only held in place by its friction fitting; rocking it back and forth while pulling may help. Firmly press the replacement filter (Isco P/N 60-2005-003) in place.

If the hydrophobic filter frequently requires replacement, you should consider relocating the modules so they are better protected. Alternatively, replace the existing hydrophobic filter with the extension accessory package included with your unit. Follow the instructions above to remove and replace the filter. Locate the other end of the tubing in a dry location and secure it.

6.5 O-Rings

The communication connectors on the top and bottom of the 2103 Modem contain O-rings that need periodic lubrication and replacement. The maintenance kit described in section 3.2 contains O-rings and silicone lubricant.

Whenever you replace the O-rings, or have removed them from the connectors for some reason, you should lubricate the O-rings by applying lubricant around the circumference of the ring.

✓ Note

Do not use petroleum-based lubricants. Petroleum-based lubricants will cause the O-ring to swell and eventually deteriorate. Aerosol silicone lubricant sprays often use petroleum based propellants. If you are using an aerosol spray, allow a few minutes for the propellant to evaporate before proceeding.

6.6 How to Obtain Service

The internal components of the 2103 Modem are not user-serviceable. The case is completely sealed to protect the internal components. To repair the unit, the case must be broken open and replaced. If you think your module requires repair, contact Isco's Technical Service Department.

Corresponding with a Teledyne Isco Technical Service Representative can often resolve the problem without the need to return the item. If the difficulty cannot be resolved you will be issued a Return Authorization Number (RAN) and information on returning it to the factory.

Appendix A Replacement Parts

A.1 Replacement Parts

Replacement parts are called out in the following pages. Refer to the call-out in the adjacent table to determine the part number for the item.

Replacement parts can be purchased by contacting Teledyne Isco's Customer Service Department.

Teledyne Isco, Inc.

Customer Service Department P.O. Box 82531 Lincoln, NE 68501 USA


Phone: (800) 228-4373


 $(402)\ 464-0231$

FAX: (402) 465-3022

E-mail: IscoInfo@teledyne.com

A.1.1 2103 Replacement Parts







RI	EPLACEMENT	PARTS LIST 602002154 SHEET: 3 OF 3 REV: C DATE: 0125
ITEM	Isco, Inc.	
NO.	PART NUMBER	DESCRIPTION
1	602004060	DESICCANT ASSEMBLY
2	602004012	PLUG ASSY, MALE CONN(INCL'S ITEM 6)
3	231514920	SCREW, PH, SELF TAP, #6-19 X 5/8 SS
4	602003019	CLIP, NODE
5	231310140	SCREW, PH, SELF TAP, #4 X 3/8 SST
6	202100669	O RING, .669ID .79 XSECT, SILICONE
7	233010400	WASHER, FLAT, #4, SST
8	231514310	SCREW, PH, #4-40 X 5/8 SST
9	603113032	GASKET, CONNECTOR CAP
10	602005004	CAP, CONNECTOR MODIFIED
11	602005003	FILTER, INLINE AIR, FOR 25mm TUBING
12	609005001	STRAP, CONNECTOR CAP, MOD
13	201900102	BALL, .125 D SST
14	203011602	SPRING, .022 Ø WIRE, .31 FREE LG
15	692003190	LATCH, LARGE
16	602003022	HOLD, LATCH
17	231611108	SCREW, PH, SELF TAP, #4 X 1/2 SST
18	602004013	PLUG ASSY. FEM CONN (INCL'S ITEM 6)
19	692003189	LATCH, SMALL
20	601113011	SPACER


A-4

A.1.2 2103c Replacement Parts




SHEET | OF 5






R	EPLACEMENT TELEDYNE ISCO, I	\(\frac{1}{2}\)
ITEM NO.	PART NUMBER	DESCRIPTION
	201900102	BALL .125 DIAMETER 316 SST
2	203011602	COMPRESSION SPRING, .022 DIAMETER WIRE, .31 FREE LENGTH
3	692003190	LARGE LATCH
4	231311206	SCREW, SELF TAP #6 X 3/8, PAN HEAD, PHILLIPS, SST
5	202100669	O RING, .669 ID, .079 CROSS SECTION, BUNA-N RUBBER
6	602004013	PLUG ASSEMBLY FEMALE CONNECTOR (includes item 5)
7	231611108	SCREW, SELF TAP, #4 X 1/2, PAN HEAD PHILLIPS, SST
8	602003022	LATCH HOLD
9	692003189	SMALL LATCH
10	602004016	DESICCANT ASSEMBLY (includes items 21 thru 27)
	602004033	PLUG ASSEMBLY, FEMALE PROBE (includes items 5, 14, 19, and 20)
12	602003019	NODE CLIP
13	231514920	SCREW, SELF TAP, 6-19 X 5/8 TORX, PAN HEAD, SST
4	231310140	SCREW, SELF TAP, #4 X 3/8, PAN HEAD PHILLIPS, SST
15	602004012	CAP ASSEMBLY, MALE CONNECTOR
16	602003018	CONNECTOR CLIP
17	203011105	COMPRESSION SPRING, .026 DIAMETER WIRE, .31 FREE LENGTH
18	236410408	PIN, SPRING, I/16 X I/2 LONG SST
19	602003076	PLUG, FEMALE PROBE
20	692003172	CABLE, FEMALE PROBE PLUG
21	602005003	AIR FILTER MODIFICATION, IN-LINE
22	602004264	DESICCANT CAP ASSEMBLY
23	692203300	FRIT, .620 DIA.
24	202500017	O-RING, .676 ID, .070 CROSS SECTION, BUNA-N RUBBER
25	692203301	FRIT, .670 DIA.
26	602003046	DESICCANT TUBE
NOTE:	 For current prices and qu This list is subject to c 	uotations on parts, contact Isco Service Department. Change without notice.

R	EPLACEMENT	PARTS LIST	6020031 SHEET: 5	
	TELEDYNE ISCO,	INC.	REV: C DATE:	06233
ITEM NO.	PART NUMBER	DESCRIPTION		
27	602003074	CAP PLUG MODIFICATION, DESICCANT		
NOTE:	 For current prices and q This list is subject to 	uotations on parts, contact Isco Service Depart change without notice.	ment.	





Appendix B Accessories

B.1 How to Order

Accessories can be purchased by contacting Teledyne Isco's Customer Service Department.

Teledyne Isco, Inc.

Customer Service Dept.

P.O. Box 82531

Lincoln, NE 68501 USA

Phone: (800) 228-4373

(402) 464-0231

FAX: (402) 465-3022

E-mail: IscoInfo@teledyne.com

B.2 General Accessories

Instruction Manual	69-2003-180
Flowlink for Windows software	(call for part number)
Modem Cable for 2103	60-3214-020
Maintenance Kit	60-2039-001
Silica Gel Desiccant	099-0011-03
Hydrophobic Filter	60-2005-003
Tubing, 10' Silicone	60-2003-104
3" Magnetic Mount Antenna for 2103C	68-2000-032
5" Magnetic Mount Antenna for 2103 G	68-2000-047
$In\text{-}Street \ (Buried) \ Antenna \dots \dots \dots$	68-2000-031

Appendix C Material Safety Data Sheets

C.1 Overview

This appendix to the manual provides Material Safety Data Sheets for the desiccant used by the 2103 Modem.

Teledyne Isco cannot guarantee the accuracy of the data. Specific questions regarding the use and handling of the products should be directed to the manufacturer listed on the MSDS.

Material Safety Data Sheet

Indicating Silica Gel

Identity (Trade Name as Used on Label)

Manufacturer :	MULTISORB TECHNOLOGIES, INC. (formerly Multiform Desiccants, Inc.)	MSDS Number*: M75
Address:	325 Harlem Road Buffalo, NY 14224	CAS Number*:
Phone Number	(For Information): 716/824-8900	Date Prepared: July 6, 2000
Emergency Pho Number:	one 716/824-8900	Prepared By*: G.E. McKedy

Section 1 - Material Identification and Information

Components - Chemical Name & Common Names (Hazardous Components 1% or greater; Carcinogens 0.1% or	%*	OSHA PEL	ACGIH TLV	OTHER LIMITS RECOMMENDE
greater) Silica Gel SiO ₂	98.0	6mg/m ³ (total dust)	10mg/m ³ (total dust)	D
Cobalt Chloride	>2.0	0.05mg/m ³ (TWA cobalt metal dust & fume)	.05mg/m³′ (Cobalt, TWA)	
Non-Hazardous Ingredients				
TOTAL	100			

Section 2 - Physical/Chemical Characteristics

Boiling N/A	Specific Gravity 2.1
Point	$(H_20 = 1)$
Vapor Pressure N/A (mm Hg and Temperature	Melting N/A Point
Vapor N/A Density (Air =1)	Evaporation Rate N/A (=1)
Solubility Insoluble, but will adsorb moistur in Water	Water Not reactive, but will adsorb moisture. Reactive
Appearance Purple crystals, no odor.	

Section 3 - Fire and Explosion Hazard Data

Flash Point and	N/A	Auto-Ignition	N/A	Flammability Limits in	N/A	LEL	UEL	
Methods Used		Temperature		Air % by Volume				
Extinguisher Dry chemical, carbon dioxide and foam can be used. Media								
Special Fire Water will generate heat due to the silica gel which will adsorb water and liberate heat. Fighting Procedures								
Unusual Fire and Explosion Hazards When exposed to water, the silica gel can get hot enough to reach the boiling point of water. Flooding with water will reduce the temperature to safe limits.						g with		

Section 4 - Reactivity Hazard Data

STABILITY	Conditions	Moisture and high humidity environments.			
□Stable	To Avoid	incidate and high nationally children.			
Unstable					
Incompatibility	Water.				
(Materials to Avoid)					
Hazardous	Carbon dioxide, carbon monoxide, water				
Decomposition					
Products					
HAZARDOUS POLYMERIZATION		Conditions None.			
☐May Occur		To Avoid			

^{*}Optional

Indicating Silica Gel

					Page 2			
Section 5 - Hea	alth Hazard Da	ta						
PRIMARY ROUTES OF ENTRY	☐Inhalation ☐Skin Absorption	☐Ingestion ☐Not Hazardous	CARCINOGEN LISTED IN	□NTP □IARC Monog	□OSHA graph □Not Listed			
HEALTH HAZARDS								
	Chronic F	Prolonged inhalation	may cause lung da	mage.				
Signs and Symptoms of Exposure	Drying and irritation	n.						
Medical Conditions Generally Aggravated I	Asthma	a.						
	AID PROCEDURES - S	eek medical assistance	e for further treatment	observation and supp	oort if necessary.			
	with water for at least			,				
	affected area with so							
Inhalation Remov	ve affected person to	fresh air.						
Ingestion Drink a	at least 2 glasses of v	vater.						
Section 6 - Co	ntrol and Prote	ctive Measure	s					
Respiratory Protection (Specify Type)	Use NIOSH appro	ved dust mask or res	spirator.					
Protective Lig Gloves	ght cotton gloves.		Eye Protection	Safety glasses.				
VENTILATION TO BE USED	Local Exhaust		Mechanical (Gene	eral)	Special			
	Other (Specify)	1						
Other Protective Clothing and Equipmer	None.							
Hygienic Work Practices		Avoid contact with s	kin, eyes and cloth	ing.				
Section 7 - Pre	ecautions for S	afe Handling a	nd Use/Leak	Procedures				
	_							
Steps to be Taken if M	aterial Sweep or v	acuum up and place	the spilled material	l in a waste disposal	container. Avoid raising dust.			
Spilled Or Released Waste Disposal	Dispose in an appr	oved landfill accordi	ng to federal, state	and local regulations	S.			
Methods	· · · · · · · · · · · · · · · · · · ·							
Precautions to be	Cover promptly to	avoid blowing dust.	Wash after handli	ng.				
Taken In Handling and								
Other Precautions and Hazards	/or Special	Keep in sealed conta	iners away from mo	oisture. The silica ge	el will readily adsorb moisture.			
nazaius								

^{*}Optional



MATERIAL SAFETY DATA SHEET

Effective Date March 8, 2005 MSDS Number M163

Section 1 – Product and Company Information

Product Name: Silica gel, indicating, yellow

Product Use: Desiccant, absorbent **Grades:** Silica gel, indicating

Synonyms: Amorphous silica gel, SiO₂, silicon dioxide (amorphous)

Company; Multisorb Technologies, Inc.

Street Address: 325 Harlem Road

City, State, Zip, Country: Buffalo, NY 14224-1893 USA

Telephone Number: (716) 824 8900 [USA] Monday - Friday (8:00 - 5:00 EDT)

Fax Number: (716) 824 4091 [USA]

Website / E-Mail: multisorb.com

Section 2 – Composition / Information on Ingredients

Component Name CAS Number % by Weight

Synthetic amorphous silica gel (SiO₂) 112926-00-8 100

Phenolphthalein 77-09-08 100 ppm

While this material is not classified, this MSDS contains valuable information critical to the safe handling and proper use of this product. This MSDS should be retained and available for employees and other users of this product.

Section 3 – Hazard Identification

Emergency Overview: A yellow bead or granular material that poses little or no immediate hazard.

This material is not combustible.

Potential Health Effects:

Eyes: Dust and or product may cause eye discomfort and irritation seen as tearing and reddening.

Skin: The product dust may cause drying of the skin. Silica gel may get hot enough to burn skin

when it adsorbs moisture rapidly. Use an excess of water to cool the silica gel.

Ingestion: Material is not toxic and will pass through the body normally.

Inhalation: Slight irritation is possible but none is expected.

Medical Effects Generally Aggravated by Exposure: Respiratory ailments.

Chronic Effects/Carcinogenity: May cause eye, skin and mucous membrane irritation and drying.

Section 4 – First Aid Measures

Eyes: Rinse the eyes well with water while lifting the eye lids. If irritation persists, consult a

physician.

Skin: Wash affected area with soap and water.

Ingestion: Ingestion is unlikely, this material will pass through the body normally.

Inhalation: Remove the affected person to fresh air and get medical attention if necessary.

Notes to Physician: Not applicable

Section 5 – Fire Fighting Measures

Flammable Properties: Not flammable

Flash Point: Not applicable Method: Not applicable

Flammable Limits: Not flammable

Lower Flammability Limit: Not applicable

Upper Flammability Limit: Not applicable

Autoignition Temperature: Not applicable

Hazardous Combustion Products: Not applicable

Extinguishing Media: Use extinguishing media that is appropriate for the surrounding fire. Silica gel is

not combustible.

Fire Fighting Instructions: Not combustible

Unusual Fire and Explosion Hazards: None

Section 6 – Accidental Release Measures

Spill: Sweep or vacuum up and place the spilled material in a waste disposal container. Avoid raising dust.

Wash with soap and water after handling.

Section 7 – Handling and Storage

Handling: Avoid raising dust and minimize the contact between worker and the material. Practice

good hygienic work practices.

Storage: Store in a cool, dry location. Keep in sealed containers away from moisture. The silica gel

will readily adsorb moisture.

Section 8 – Exposure Controls/Personal Protection

Engineering Controls: Use exhaust ventilation to keep the airborne concentrations below the exposure

limits.

Respiratory Protection: Use NIOSH approved respirator when the air quality levels exceed the TLV's.

Skin Protection: Light gloves will protect against abrasion and drying of the skin.

Eye Protection: Safety glasses.

Component Name	Exposure Limits			
	OSHA PEL	ACGIH TLV	Other Recommended	
			Limits	
Silica gel	TWA 20 mppcf (80 mg / m ³ % SiO ₂)	TWA 10 mg / m ³	NIOSH REL TWA 6 mg / m ³ IDLH 3000 mg / m ³	
Phenolphthalein	Not Applicable	Not Applicable	Not Applicable	

Section 9 – Physical and Chemical Properties

Appearance: Yellow beads or granules Vapor Density: Not applicable

Odor: None **Boiling Point:** 4046° F (2230° C)

Physical State: Solid bead **Melting Point:** 3110° F (1710° C)

PH: Not applicable Solubility: Insoluble in water

Vapor Pressure: Not applicable Specific Gravity: 2.1

Section 10 – Stability and Reactivity

Stability: Stable

Conditions to avoid: Moisture and high humidity environments.

Incompatibility: Water, fluorine, oxygen difluoride, chlorine trifluoride

Hazardous Decomposition Products: None

Hazardous Polymerization: Will not occur

Section 11 - Toxicological Information

This product and its components are not listed on the NTP or OSHA Carcinogen lists.

Animal Toxicology Tests for DOT Hazard classification

(Tests Conducted on finely ground silica gel)

1 - hour LC_{50} (rat) > 2 mg / 1

48 - hour oral LD₅₀ (rat) est. > 31,600 mg / kg

48 - hour dermal LD_{50} (rabbit) est. \geq 2,000 mg / kg

Considered an ocular irritant

Human Toxicology Silica gel is a synthetic amorphous silica not to be confused with crystalline silica. Epidemiological studies indicate low potential for adverse health effects. In the activated form, silica gel acts as a desiccant and can cause a drying irritation of the mucous membranes and skin in cases of severe exposure. Multisorb Technologies Inc. knows of no medical conditions that are abnormally aggravated by exposure to silica gel. The primary route of entry is inhalation of dust.

Section 12 - Ecological Information

Not known to have any adverse effect on the aquatic environment. Silica gel is insoluble and non-toxic.

Section 13 – Disposal Information

Disposal Information If this product as supplied becomes a waste, it does not meet the criteria of a hazardous waste as defined under the Resource Conservation and Recovery Act (RCRA) 40 CFR 261. Materials of a hazardous nature that contact the product during normal use may be retained on the product. The user of the product must identify the hazards associated with the retained material in order to assess the waste disposal options. Dispose according to federal, state and local regulations.

Section 14 – Transportation Information

U.S. Department of Transportation Shipping Name: Not classified as a hazardous material. Not regulated.

Section 15 – Regulatory Information (Not meant to be all inclusive - selected regulations represented)

TSCA Listed: Yes

DSL/NDSL (Canadian) Listed: Yes

OSHA: TWA 20 mppcf (80 mg / m³ % SiO₂) for Silica gel

NIOSH: REL TWA 6 mg/m³ IDLH 3,000 mg/m³ for silica gel

Animal tests conducted in 1976 - 1978. 18 month exposure at 15 mg/m 3 showed silica deposition in respiratory macrophages and lymph nodes, minimum lung impairment, no silicosis.

ACGIH: TLV - 10 mg / m³ for Silica gel

DOT: Not classified as a hazardous material.

Section 16 – Other Information

HMIS - Hazardous Materials Identification System

HMIS Rating		
Health	0	
Flammability	0	
Reactivity	0	

0 - minimal hazard, 1 - slight hazard, 2 - moderate hazard, 3 - serious hazard, 4 - severe hazard

This MSDS was prepared by: George E. Mckedy

Senior Applications Development Specialist

Multisorb Technologies, Inc.

This data and recommendations presented in this data sheet concerning the use of our product and the materials contained therein are believed to be correct but does not purport to be all inclusive and shall be used only as a guide. However, the customer should determine the suitability of such materials for his purpose before adopting them on a commercial scale. Since the use of our products is beyond our control, no guarantee, expressed or implied, is made and no responsibility assumed for the use of this material or the results to be obtained therefrom. Information on this form is furnished for the purpose of compliance with Government Health and Safety Regulations and shall not be used for any other purposes. Moreover, the recommendations contained in this data sheet are not to be construed as a license to operate under, or a recommendation to infringe, any existing patents, nor should they be confused with state, municipal or insurance requirements, or with national safety codes.

DECLARATION OF CONFORMITY



Application of Council Directive: 89/336/EEC – The EMC Directive

73/23/EEC - The Low Voltage Directive

Manufacturer's Name: Teledyne Isco, Inc.

Manufacturer's Address: 4700 Superior, Lincoln, Nebraska 68504 USA

Mailing Address: P.O. Box 82531, Lincoln, NE 68501

Equipment Type/Environment: Laboratory Equipment for Light Industrial/Commercial Environments

Trade Name/Model No: 2103 Modem Module

Year of Issue: 2001

Standards to which Conformity is Declared: FCC part is Sub part B, IC ES-003, En 55022:1998, EN 55024:1998 EMC

Requirements for Information Technology Equipment

EN 60950 Safety Requirements for Information Technology Equipment

FCC Part 68

Standard	Description	Severity Applied	Performance Criteria
EN61000-4-2	Electrostatic Discharge	Level 2 - 4kV contact discharge Level 3 - 8kV air discharge	A A
EN61000-4-3	Radiated RF Immunity	80 MHz to 1000MHz 80% AM at 1kHz Level 1 – 10V/m	А
EN61000-4-4	Electrical Fast Transient	Level 1 – 1kV on I/O lines	Α
EN61000-4-5	Surge on I/O Lines	1kV common mode, 0.5KV differential mode	А
*EN61000-4-6	Conducted RF on I/O lines	150 kHz to 80 MHz, 3V rms, 80% modulated	*C
CISPR11/ EN 55011	RF Emissions	Group 1, Class A Industrial, Scientific, and Medical Equipment	

^{*} Between 5 and 7 mega Hz the modem will inadvertently disconnect from the computer. A manual reconnection procedure is required to restablish a connection.

We, the undersigned, hereby declare that the design of the equipment specified above conforms to the above Directive(s) and Standards as of July 1, 2001.

William Foster USA Representative

TELEDYNE ISCO
A Teledyne Technologies Company

William Foster

Director of Engineering Teledyne Isco, Inc. 4700 Superior Street Lincoln, Nebraska 68504

Phone: (402) 464-0231 Fax: (402) 464-4543

> 60-2002-156 Rev. B

DECLARATION OF CONFORMITY



Application of Council Directive: 89/336/EEC - The EMC Directive

73/23/EEC - The Low Voltage Directive

Manufacturer's Name: Teledyne Isco, Inc.

Manufacturer's Address: 4700 Superior, Lincoln, Nebraska 68504 USA

Mailing Address: P.O. Box 82531, Lincoln, NE 68501

Equipment Type/Environment: Laboratory Equipment for Light Industrial/Commercial Environments

Trade Name/Model No: 2191 Battery Module

Year of Issue: 2001

Standards to which Conformity is Declared: EN 61326-1998 EMC Requirements for Electrical Equipment for

Measurement, Control, and Laboratory Use

EN 61010-1 Safety Requirements for Electrical Equipment for Measurement,

Control and Laboratory use.

Standard	Description	Severity Applied	Performance Criteria
EN61000-4-2	Electrostatic Discharge	Level 2 - 4kV contact discharge Level 3 - 8kV air discharge	ВВ
EN61000-4-3	Radiated RF Immunity	80 MHz to 1000MHz 80% AM at 1kHz Level 1 – 10V/m	В
EN61000-4-4	Electrical Fast Transient	Level 1 – 1kV on I/O lines	В
EN61000-4-5	Surge on I/O Lines	1kV common mode, 0.5KV differential mode	В
EN61000-4-6	Conducted RF on I/O lines	150 kHz to 80 MHz, 3V rms, 80% modulated	В
CISPR11/ EN 55011	RF Emissions	Group 1, Class A Industrial, Scientific, and Medical Equipment	

We, the undersigned, hereby declare that the design of the equipment specified above conforms to the above Directive(s) and Standards as of July 1, 2001.

William Foster USA Representative

TELEDYNE ISCO
A Teledyne Technologies Company

William Foster

Director of Engineering Teledyne Isco, Inc. 4700 Superior Street Lincoln, Nebraska 68504

Phone: (402) 464-0231 Fax: (402) 464-4543

> 60-2002-158 Rev A

Warranty		
	Warranty	

DECLARATION OF CONFORMITY



Application of Council Directive: 2004/108/EC -The EMC Directive

2002/96/EC - The WEEE Directive

Manufacturer's Name: Teledyne Isco, Inc.

Manufacturer's Address: 4700 Superior, Lincoln, Nebraska 68504 USA

Mailing Address: P.O. Box 82531, Lincoln, NE 68501

Equipment Type/Environment: Laboratory Equipment for Light Industrial/Commercial Environments:

Trade Name/Model No: 2103G

Year of Issue: 2007

Standards Conformity is Declared: EN61326-1:2006 EMC Requirements for Electrical Equipment for

Measurement, Control, and Laboratory Use

Standard	Description	Severity Applied	Performance Criteria
EN61000-4-2	Electrostatic Discharge	Level 2 - 4kV contact discharge Level 3 - 8kV air discharge	A A
EN61000-4-3	Radiated RF Immunity	80 MHz to 1000MHz 80% AM at 1kHz Level 1 – 1V/m	А
CISPR11/ EN 55011	RF Emissions	Group 1, Class A Industrial, Scientific, and Medical Equipment	

I, the undersigned, hereby declare that the design of the equipment specified above conforms to the above Directive(s) and Standards as of April 20, 2007.

William Foster USA Representative

TELEDYNE ISCO
A Teledyne Technologies Company

William Foster

Director of Engineering Teledyne Isco, Inc. 4700 Superior Street Lincoln, Nebraska 68504

Phone: (402) 464-0231 Fax: (402) 464-4543

60-2002-504

Teledyne Isco One Year Limited Factory Service Warranty *

Teledyne Isco warrants covered products against failure due to faulty parts or workmanship for a period of one year (365 days) from their shipping date, or from the date of installation by an authorized Teledyne Isco Service Engineer, as may be appropriate.

During the warranty period, repairs, replacements, and labor shall be provided at no charge. Teledyne Isco's liability is strictly limited to repair and/or replacement, at Teledyne Isco's sole discretion.

Failure of expendable items (e.g., charts, ribbon, tubing, lamps, glassware, seals, filters, fittings, and wetted parts of valves), or from normal wear, accident, misuse, corrosion, or lack of proper maintenance, is not covered. Teledyne Isco assumes no liability for any consequential damages.

This warranty does not cover loss, damage, or defects resulting from transportation between the customer's facility and the repair facility.

Teledyne Isco specifically disclaims any warranty of merchantability or fitness for a particular purpose.

This warranty applies only to products sold under the Teledyne Isco trademark and is made in lieu of any other warranty, written or expressed.

No items may be returned for warranty service without a return authorization number issued from Teledyne Isco.

The warrantor is Teledyne Isco, Inc. 4700 Superior, Lincoln, NE 68504, U.S.A.

In the event of instrument problems, always contact the Teledyne Isco Service Department, as problems can often be diagnosed and corrected without requiring an on-site visit. In the U.S.A., contact Teledyne Isco Service at the numbers listed below. International customers should contact their local Teledyne Isco agent or Teledyne Isco International Customer Service.

Return Authorization

A return authorization number must be issued prior to shipping. Following authorization, Teledyne Isco will pay for surface transportation (excluding packing/crating) both ways for 30 days from the beginning of the warranty period. After 30 days, expense for warranty shipments will be the responsibility of the customer.

Shipping Address: Teledyne Isco, Inc. - Attention Repair Service

4700 Superior Street Lincoln NE 68504 USA

Mailing address: Teledyne Isco, Inc.

PO Box 82531

Lincoln NE 68501 USA

Phone: Repair service: (800)775-2965 (lab instruments)

(800)228-4373 (samplers & flow meters)

Sales & General Information (800)228-4373 (USA & Canada)

Fax: (402) 465-3001

Email: iscoservice@teledyne.com Web site: www.isco.com



^{*} This warranty applies to the USA and countries where Teledyne Isco Inc. does not have an authorized dealer. Customers in countries outside the USA, where Teledyne Isco has an authorized dealer, should contact their Teledyne Isco dealer for warranty service.