

2.4GHz 802.11g Wireless Bridge

User Guide

SMC2586W-G

Copyright

Information furnished by SMC Networks, Inc. (SMC) is believed to be accurate and reliable. However, no responsibility is assumed by SMC for its use, nor for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of SMC. SMC reserves the right to change specifications at any time without notice.

Copyright © 2004 by
SMC Networks, Inc.
38 Tesla
Irvine, California 92618
All rights reserved.

Trademarks

SMC is a registered trademark; and EliteConnect is a trademark of SMC Networks. Other product and company names are trademarks or registered trademarks of their respective holders.

Limited Warranty Statement:

SMC Networks, Inc. ("SMC") warrants its products to be free from defects in workmanship and materials, under normal use and service, for the applicable warranty term. All SMC products carry a standard 90-day limited warranty from the date of purchase from SMC or its Authorized Reseller. SMC may, at its own discretion, repair or replace any product not operating as warranted with a similar or functionally equivalent product, during the applicable warranty term. SMC will endeavor to repair or replace any product returned under warranty within 30 days of receipt of the product. The standard limited warranty can be upgraded to a Limited Lifetime* warranty by registering new products within 30 days of purchase from SMC or its Authorized Reseller. Registration can be accomplished via the enclosed product registration card or online via the SMC Web site. Failure to register will not affect the standard limited warranty. The Limited Lifetime warranty covers a product during the Life of that Product, which is defined as the period of time during which the product is an "Active" SMC product. A product is considered to be "Active" while it is listed on the current SMC price list. As new technologies emerge, older technologies become obsolete and SMC will, at its discretion, replace an older product in its product line with one that incorporates these newer technologies. At that point, the obsolete product is discontinued and is no longer an "Active" SMC product. A list of discontinued products with their respective dates of discontinuance can be found at: http://www.smc.com/index.cfm?action=customer_service_warranty.

All products that are replaced become the property of SMC. Replacement products may be either new or reconditioned. Any replaced or repaired product carries either a 30-day limited warranty or the remainder of the initial warranty, whichever is longer. SMC is not responsible for any custom software or firmware, configuration information, or memory data of Customer contained in, stored on, or integrated with any products returned to SMC pursuant to any warranty. Products returned to SMC should have any customer installed accessory or add-on components, such as expansion modules, removed prior to returning the product for replacement. SMC is not responsible for these items if they are returned with the product.

Customers must contact SMC for a Return Material Authorization number prior to returning any product to SMC. Proof of purchase may be required. Any product returned to SMC without a valid Return Material Authorization (RMA) number clearly marked on the outside of the package will be returned to customer at customer's expense. For warranty claims within North America, please call our toll-free customer support number at (800) 762-4968. For further information about warranty claims outside North America, please visit www.smc.com and choose the link to your region.

Customers are responsible for all shipping charges from their facility to SMC. SMC is responsible for return shipping charges from SMC to customer.

WARRANTIES EXCLUSIVE:

IF AN SMC PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, CUSTOMER'S SOLE REMEDY SHALL BE REPAIR OR REPLACEMENT OF THE PRODUCT IN QUESTION, AT SMC'S OPTION. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SMC NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE OR USE OF ITS PRODUCTS. SMC SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.

LIMITATION OF LIABILITY:

IN NO EVENT, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), SHALL SMC BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE, LOSS OF BUSINESS, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF ITS PRODUCTS, EVEN IF SMC OR ITS AUTHORIZED RESELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES OR THE LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR CONSUMER PRODUCTS, SO THE ABOVE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, WHICH MAY VARY FROM STATE TO STATE. NOTHING IN THIS WARRANTY SHALL BE TAKEN TO AFFECT YOUR STATUTORY RIGHTS.

- * SMC will provide warranty service for one year following discontinuance from the active SMC price list. Under the limited lifetime warranty, internal and external power supplies, fans, and cables are covered by a standard one-year warranty from date of purchase.

SMC Networks, Inc.
38 Tesla
Irvine, CA 92618

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: To assure continued compliance, (example - use only shielded interface cables when connecting to computer or peripheral devices). Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be collocated or operating in conjunction with any other antenna or transmitter.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Industry Canada - Class B

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the interference-causing equipment standard entitled "Digital Apparatus," ICES-003 of Industry Canada.

Cet appareil numerique respecte les limites de bruits radioelectriques applicables aux appareils umeriques de Classe B prescrites dans la norme sur le material brouilleur: "Appareils Numeriques," NMB-003 edictee par l'Industrie.

EC Conformance Declaration CE 0560 (!)

SMC contact for these products in Europe is:
SMC Networks Europe,
Edificio Conata II,
Calle Frutuós Gelabert 6-8, 2o, 4a,
08970 - Sant Joan Despí,
Barcelona, Spain.

This RF product complies with R&TTE Directive 99/5/EC. For the evaluation of the compliance with this Directive, the following standards were applied:

- Electromagnetic compatibility and radio spectrum matters (ERM)
EN300 328-1 (2001-12)
EN300 328-2 (2001-12)
- Electromagnetic Compatibility (EMC) Standard for radio equipment and services
EN301 489-1
EN301 489-17
- Safety Test
EN60950

Safety Compliance

Wichtige Sicherheitshinweise (Germany)

1. Bitte lesen Sie diese Hinweise sorgfältig durch.
2. Heben Sie diese Anleitung für den späteren Gebrauch auf.
3. Vor jedem Reinigen ist das Gerät vom Stromnetz zu trennen. Verwenden Sie keine Flüssigoder Aerosolreiniger. Am besten eignet sich ein angefeuchtetes Tuch zur Reinigung.
4. Die Netzanschlussteckdose soll nahe dem Gerät angebracht und leicht zugänglich sein.
5. Das Gerät ist vor Feuchtigkeit zu schützen.
6. Bei der Aufstellung des Gerätes ist auf sicheren Stand zu achten. Ein Kippen oder Fallen könnte Beschädigungen hervorrufen.
7. Die Belüftungsöffnungen dienen der Luftzirkulation, die das Gerät vor Überhitzung schützt. Sorgen Sie dafür, daß diese Öffnungen nicht abgedeckt werden.
8. Beachten Sie beim Anschluß an das Stromnetz die Anschlußwerte.
9. Verlegen Sie die Netzanschlußleitung so, daß niemand darüber fallen kann. Es sollte auch nichts auf der Leitung abgestellt werden.

10. Alle Hinweise und Warnungen, die sich am Gerät befinden, sind zu beachten.
11. Wird das Gerät über einen längeren Zeitraum nicht benutzt, sollten Sie es vom Stromnetz trennen. Somit wird im Falle einer Überspannung eine Beschädigung vermieden.
12. Durch die Lüftungsöffnungen dürfen niemals Gegenstände oder Flüssigkeiten in das Gerät gelangen. Dies könnte einen Brand bzw. elektrischen Schlag auslösen.
13. Öffnen Sie niemals das Gerät. Das Gerät darf aus Gründen der elektrischen Sicherheit nur von autorisiertem Servicepersonal geöffnet werden.
14. Wenn folgende Situationen auftreten, ist das Gerät vom Stromnetz zu trennen und von einer qualifizierten Servicestelle zu überprüfen:
 - a. Netzkabel oder Netzstecker sind beschädigt.
 - b. Flüssigkeit ist in das Gerät eingedrungen.
 - c. Das Gerät war Feuchtigkeit ausgesetzt.
 - d. Wenn das Gerät nicht der Bedienungsanleitung entsprechend funktioniert oder Sie mit Hilfe dieser Anleitung keine Verbesserung erzielen.
 - e. Das Gerät ist gefallen und/oder das Gehäuse ist beschädigt.
 - f. Wenn das Gerät deutliche Anzeichen eines Defektes aufweist.
15. Stellen Sie sicher, daß die Stromversorgung dieses Gerätes nach der EN 60950 geprüft ist. Ausgangswerte der Stromversorgung sollten die Werte von AC 7,5-8V, 50-60Hz nicht über oder unterschreiten sowie den minimalen Strom von 1A nicht unterschreiten. Der arbeitsplatzbezogene Schalldruckpegel nach DIN 45 635 Teil 1000 beträgt 70dB(A) oder weniger.

Table of Contents

1. Introduction	10
1.1 Overview	10
1.2. FeaturesPackage Contents	10
1.3 Features	10
1.4 LED Definitions	13
2. First-Time Installation and Configuration	14
2.1 Selecting a Power Supply Method	14
2.2 Mounting the SMC2586W-G on a Wall	15
2.3 Preparing for Configuration	16
2.4 Configuring the SMC2586W-G	17
2.5 Deploying the SMC2586W-G	24
3. Using Web-Based Management	25
3.1 Overview	25
3.2 Viewing Status	27
3.3 General Operations	29
3.4 Configuring TCP/IP Related Settings	36
3.5 Configuring IEEE 802.11b/g-Related Settings	38
3.6 Configuring Advanced Settings	48
4. EliteConnect Management Utility	53
4.1 Introduction	53
4.2 Tutorial	55
4.3 Using SMC EliteConnect™ Management Utility	63
Appendix A: Default Settings	88
Appendix B: Troubleshooting	89
Appendix C : Distances and Data Rates	92
Appendix D: Technical Specification	93

1. Introduction

1.1 Overview

The SMC2586W-G is a versatile device that can be configured to be in one of the 3 operational modes—Access Point, Bridge Master, and Bridge Slave—for various wireless bridging applications. With the convenient Web-based user interface, a network administrator can easily and clearly manage the SMC2586W-G.

1.2 Features Package Contents

- SMC2586W-G
- User Guide
- CD ROM
- 2 dBi Antenna
- R-SMA/RP-TNC Adapter
- Cat 5 Cable
- 12V AC Adapter (EU-type or UK type plug adapter available with models shipping to Europe)

1.3 Features

• IEEE 802.11b/g Compliant

Operational modes.

- **Access Point.** The AP enables IEEE 802.11 Stations (STAs) to automatically associate with it via the standard IEEE 802.11 association process. In addition, the IEEE 802.11 WDS (Wireless Distribution System) technology can be used to manually establish wireless links between two APs or between an AP and a Bridge Master.
- **Bridge Master.** Use this mode to provide the Bridge Master functionality of the SMC2682W. The Bridge Master mode is designed to work in those networks where SMC2682W Wireless Bridge Slaves are already installed. The Bridge Master enables Bridge Slaves to automatically associate with it. It also enables IEEE 802.11 Stations, which are on the same LAN as the Bridge Master, to automatically associate with it via the standard IEEE 802.11 association process. In addition, the IEEE 802.11 WDS (Wireless Distribution System) technology can be used to manually establish wireless links between two Bridge Masters or between a Bridge Master and an AP.
- **Bridge Slave.** Use this mode to provide the Bridge Slave functionality of the SMC2682W. The Bridge Slave mode is designed to work in those networks where SMC2682W Wireless Bridge Masters are already installed.

- **64-bit and 128-bit WEP (Wired Equivalent Privacy).** For wireless data encryption.
- **IEEE 802.1x/RADIUS.** When the SMC2586W-G is in Access Point mode, it can be configured to authenticate wireless users and distribute encryption keys dynamically by IEEE 802.1x Port-Based Network Access Control and RADIUS (Remote Authentication Dial-In User Service).
- **WPA (Wi-Fi Protected Access).** The SMC2586W-G supports the new WPA standard. Both WPA-PSK (Pre-Shared Key) mode and full WPA mode are supported. WPA is composed of TKIP (Temporal Key Integrity Protocol) and IEEE 802.1x and serves as a successor to WEP for better WLAN security.
- **Enabling/disabling SSID broadcasts.** When the SMC2586W-G is in AP or Bridge Master mode, the administrator can enable or disable the SSID broadcasts functionality for security reasons. When the SSID broadcasts functionality is disabled, an STA or Bridge Slave cannot associate with the AP or Bridge Master with an ANY network name (SSID, Service Set ID); the correct SSID has to be specified on the STA or Bridge Slave.
- **MAC-address-based access control.** When the SMC2586W-G is in AP or Bridge Master mode, it can be configured to block unauthorized STAs or Bridge Slaves based on MAC (Media Access Control) addresses. The ACL (Access Control List) can also be downloaded from a TFTP server.
- **Transmit power control.** Transmit power of the SMC2586W-G can be adjusted to control the area of coverage.
- **Wireless client isolation.** When the SMC2586W-G is in AP or Bridge Master mode, wireless-to-wireless traffic between STAs can be blocked so that the STAs cannot see each other. This capability can be used in hotspots applications to prevent wireless hackers from attacking other wireless users' computers.
- **Link integrity.** When the SMC2586W-G is in AP or Bridge Master mode and the Ethernet LAN interface is detected to be disconnected from the wired network, all currently associated wireless clients (STAs and Bridge Slaves) are disassociated by the SMC2586W-G and no wireless client can associate with it thereafter.
- **Associated wireless clients status.** Showing the status of all wire

less clients (STAs and Bridge Slaves) that are associated with the SMC2586W-G.

- **Detachable antenna.** The SMC2586W-G antenna can be replaced with SMC high-gain antennas for long operating range.
- **DHCP client.** The SMC2586W-G can automatically obtain an IP address from a DHCP server.
- **DHCP server.** The SMC2586W-G can automatically assign IP addresses to computers or other devices by DHCP (Dynamic Host Configuration Protocol).
 - **Static DHCP mappings.** The administrator can specify static IP address to MAC address mappings so that the specified IP addresses are always assigned to the hosts with the specified MAC addresses.
 - **Showing current DHCP mappings.** Showing which IP address is assigned to which host identified by a MAC address.
- **Packet Filtering.** The SMC2586W-G provides Layer 2, Layer 3, and Layer 4 filtering capabilities.

Firmware Tools

- **Firmware upgrade.** The firmware of the SMC2586W-G can be upgraded via the following methods:
 - **TFTP-based.** Upgrading firmware by TFTP (Trivial File Transfer Protocol).
 - **HTTP-based.** Upgrading firmware by HTTP (HyperText Transfer Protocol).
- **Configuration backup.** The configuration settings of the SMC2586W-G can be backed up to a file via TFTP or HTTP.
- **Configuration reset.** Resetting the configuration settings to factory-default values.

Management

- **Web-based management** for configuring and monitoring SMC2586W-G via a Web-Browser.
 - **Single administrator logon.** Only one administrator can log on to the SMC2586W-G for management purposes at a time.

- **SNMP.** SNMP (Simple Network Management Protocol) MIB I, MIB II, IEEE 802.1d, and Private Enterprise MIB are supported.
- **UPnP.** The SMC2586W-G responds to UPnP discovery messages so that a Windows XP user can locate the SMC2586W-G in My Network Places and use a Web browser to configure it.
- **Telnet.** The SMC2586W-G can be managed by Telnet.
- **System log.** For system operational status monitoring.
 - **Local log.** System events are logged to the on-board RAM of the SMC2586W-G and can be viewed using a Web browser.
 - **Remote log by SNMP trap.** Systems events are sent in the form of SNMP traps to a remote SNMP management server.
 - **Remote log by BSD Syslog.** Systems events are sent in the form of BSD Syslog (RFC3164) to a remote Syslog server.
- **Power over Ethernet.** Supplying power to an SMC2586W-G over an Ethernet cable using optional SMCPWR-INJ3 Power Injector (IEEE 802.3af compliant). This feature facilitates large-scale wireless LAN deployment.
- **Hardware Watchdog Timer.** If the firmware gets stuck in an invalid state, the hardware watchdog timer will detect this situation and restart the SMC2586W-G. This way, the SMC2586W-G can provide continuous services.

1.4 LED Definitions

There are several LED indicators on the SMC2586W-G. They are defined as follows:

- **ALV:** Alive. Blinks when the SMC2586W-G is working normally.
- **RF:** IEEE 802.11b/g interface activity
- **LAN:** Ethernet LAN interface activity
- **PWR:** Power

2. First-Time Installation and Configuration

2.1 Selecting a Power Supply Method

The SMC2586W-G can be powered by either the supplied power adapter or the optional SMCPWR-INJ3 EliteConnect™ Power Injector. The SMC2586W-G automatically selects the suitable power depending on your decision.

To power the SMC2586W-G by the supplied power adapter:

1. Plug the power adapter to an AC socket.
2. Plug the connector of the power adapter to the power jack of the SMC2586W-G.

NOTE: This product is intended to be power-supplied by a Listed Power Unit, marked "Class 2" or "LPS" and output rated "12V DC, 1.25 A minimum" or equivalent statement.

NOTE: Units shipping to Europe will have a EU-type or UK-type plug adapter added separately. The plug adapter simply needs to be inserted over the US type plug to conform to EU or UK power specifications.

To power the SMC2586W-G by SMCPWR-INJ3 Power Injector:

1. Connect the power cord cable from power outlet to the SMCPWR-INJ3 power connector.




Fig. 1. Connecting the power cord cable to SMCPWR-INJ3.

2. Check the "POWER" LED: if system is normal, the LED will be on (Green light); otherwise, the "POWER" LED will be off.
3. Connect the Ethernet cable (RJ-45 Category 5) from Ethernet Hub/Switch to the "DATA IN" port of SMCPWR-INJ3 Power Injector.
4. Connect another Ethernet cable (RJ-45 Category 5) from "POWER & DATA OUT" port of the SMCPWR-INJ3 Power Injector to the SMC2586W-G Wireless Bridge.




Fig. 2. Connecting Ethernet cables to SMC2586W-G.

5. Check the “ACTIVE” LED: if power is successfully fed into the SMC2586W-G, the “ACTIVE” LED will be on (Red light); otherwise, the “ACTIVE” LED will be off.
6. If the electricity current is over the normal condition ($I_o \pm 1.0$ A), the “ACTIVE” LED will flash (Red light).

NOTE: SMC2586W-G is specially designed for “SMC2586W-G EliteConnect™ 2.4GHz 802.11g Wireless Bridge. The use of SMC2586W-G with other Ethernet-ready devices that are not compliant to IEEE802.3af may cause damage to the devices.

2.2 Mounting the SMC2586W-G on a Wall

The SMC2586W-G is wall-mountable.

1. Stick the supplied sticker for wall-mounting.
2. Use a 7.0mm drill to drill a 25mm-deep hole at each of the cross marks.
3. Plug in a supplied plastic conical anchor in each hole.
4. Screw a supplied screw in each plastic conical anchor for a proper depth so that the SMC2586W-G can be hung on the screws.
5. Hang the SMC2586W-G on the screws.




Fig. 3. Mounting the SMC2586W-G on a wall.

2.3 Preparing for Configuration

To configure an SMC2586W-G, a managing computer with a Web browser is needed. For first-time configuration of an SMC2586W-G, an Ethernet network interface card (NIC) should have been installed in the managing computer. For maintenance configuration of a deployed SMC2586W-G, either a wireless computer or a wired computer can be employed as the managing computer.

NOTE: If you are using the browser, Opera, to configure an SMC2586W-G, click the menu item File, click Preferences... click File types, and edit the MIME type, text/html, to add a file extension“.sht” so that Opera can work properly with the Web management pages of the SMC2586W-G.

Since the configuration/management protocol is HTTP-based, you have to make sure that the IP address of the managing computer and the IP address of the managed SMC2586W-G are in the same IP subnet (the default IP address of SMC2586W-G is 192.168.2.50 and the default subnet mask is 255.255.255.0.) [DHCP Client is enabled by default. It will default to 192.168.2.50 if there is no DHCP server available on the network.]

Connecting the Managing Computer and the SMC2586W-G

To connect the managing computer and the SMC2586W-G for the first-time, you have two choices as illustrated in Fig. 4




Fig. 4. Connecting a managing computer and an SMC2586W-G via Ethernet. You can use either a cross-over Ethernet cable (included in the package) or a switch/hub with 2 straight-through Ethernet cables.

NOTE: One connector of the Ethernet cable must be plugged into the LAN Ethernet port of the SMC2586W-G for configuration.

Changing the TCP/IP Settings of the Managing Computer

Use the Windows Network Control Panel Applet to change the TCP/IP settings of the managing computer, so that the IP address of the computer and the IP address of the SMC2586W-G are in the same IP subnet. Set the IP address of the computer to 192.168.2.xxx (the default IP address of the SMC2586W-G is 192.168.2.50) and the subnet mask to 255.255.255.0.) [DHCP Client is enabled by default. It will default to 192.168.2.50 if there is no DHCP server available on the network.]

TIP: You can use SMC2586W-G Scan Utility on the CD-ROM to scan for all the SMC2586W-Gs on the network. Double-click a scanned SMC2586W-G to launch the Web browser to manage the SMC2586W-G. Note that this utility does not discover the SMC2682W.

NOTE: On Windows 2000/XP, SMC2586W-G Scan Utility can only be run by a user with administrator privilege.

NOTE: For some versions of Windows, the computer needs to be restarted for the changes of TCP/IP settings to take effect.


2.4 Configuring the SMC2586W-G

The 2586W-G is DHCP client enabled by default. If there is a DHCP server on your network it will get a DHCP address from your server. If there is no DHCP server available the 2586W-G will default to 192.168.2.50 IP address.

TIP: For maintenance configuration of an SMC2586W-G, the SMC2586W-G can be reached by its host name using a Web browser. For example, if the SMC2586W-G is named "AP", you can use the URL "http://AP" to access the Web-based management interface of the SMC2586W-G.

Entering the User Name and Password

To log onto the Web based management interface, you will be prompted to enter the user name and password. For first time configuration, use the default user name "admin" and default password "smcadmin", respectively. And then click Log On.

A screenshot of a web-based login form. At the top, it says "Please type your user name and password." Below this, there are two input fields: "User name:" and "Password:". At the bottom left, there is a blue button labeled "Log On".

Please type your user name and password.	
User name:	
Password:	
Log On	

Fig. 5 Entering the user name and password.

NOTE: It is strongly recommended that the password be changed to other value for security reasons. On the start page, click the General, Password link to change the value of the password (see Section 3.3.1 for more information).

TIP: Since the Status page shows the current settings and status of the SMC2586W-G, it can be saved or printed within the Web browser for future reference.

SMC Networks **Web-Based Network Management**

[Home](#) [Status](#) [General](#) [TCP/IP](#) [IEEE 802.11](#) [Advanced](#) [Log Off](#)

Restart You can click **Restart** to restart the AP

Access Point Settings and Info	
Model	SMC2586W-G
BIOS/Firmware Version	SMC2586W-G v1.2/1.0.0 U
Operational Mode	Access Point
MAC Address (BSSID)	00-09-92-00-B2-14
System Up Time (hr:min:sec)	0:27:10
TCP/IP Settings	LAN Interface Get from the DHCP server.
Wireless Settings	- Regulatory domain: FCC (U.S.) - Channel number: 6 - Network name (SSID): SMC - Data rate: Auto - Transmit power: High - Security mode: Open System - AP functionality: Enabled - Policy: Mixed - SSID broadcasts: Enabled - Wireless client isolation: Disabled - MAC-address-based access control: Disabled - Link integrity: Disabled - Reference host: 0.0.0.0

Fig. 6. The Status page.

Step 1: Selecting an Operational Mode

- ⑥ **Access Point / Bridge**
Use this mode to provide both Access Point and Bridging Functionality. The Bridge function is supported through Wireless Distribution System (WDS). The WDS function can support up to 6 bridge links.
- Bridge Master and Bridge Slave**
These 2 modes can be used when you want to use both the SMC2682W and SMC2586W-G in the same bridging environments. If you are setting up a bridge configuration using all SMC2586W-G's use the [Access Point / Bridge] mode above and configure your Bridge connections using WDS.
- **Bridge Master**
Use this mode to provide the Master Bridge functionality of the SMC2682W. In this mode, the SMC2586W-G can also act as an Access Point to the wireless clients located on the same network as the Bridge Master.
- **Bridge Slave**
Use this mode to provide Slave Bridge functionality of the SMC2682W, in this mode the SMC2586W-G will not work as an Access Point.

Fig. 7. Operational modes settings.

The SMC2586W-G supports 3 operational modes for meeting various wireless connectivity requirements:

- **Access Point (AP).** The AP mode enables IEEE 802.11 Stations (STAs) to automatically associate with it via the standard IEEE 802.11 association process. In addition, the IEEE 802.11 WDS (Wireless Distribution System) technology can be used to manually establish wireless links between two APs or between an AP and a Bridge Master.
- **Bridge Master (BM).** Use this mode to provide the Bridge Master functionality of the SMC2682W. The Bridge Master mode is designed to work in those networks where SMC2682W Wireless Bridge Slaves are already installed. The Bridge Master enables Bridge Slaves to automatically associate with it. It also enables IEEE 802.11 Stations, which are on the same LAN as the Bridge Master, to automatically associate with it via the standard IEEE 802.11 association process. In addition, the IEEE 802.11 WDS (Wireless Distribution System) technology can be used to manually establish wireless links between two Bridge Masters or between a Bridge Master and an AP.
- **Bridge Slave (BS).** Use this mode to provide the Bridge Slave functionality of the SMC2682W. The Bridge Slave mode is designed to work in those networks where SMC2682W Wireless Bridge Masters are already installed.
In any mode, the SMC2586W-G forwards packets between its Ethernet interface and wireless interface for wired hosts on the Ethernet side and wireless host(s) on the wireless side.
There are 2 types of wireless links between two SMC2586W-Gs or between an SMC2586W-G and another wireless device.
- **WDS.** This type of wireless link is specified in the IEEE 802.11 standard for communication between two IEEE 802.11 APs. Wireless packets transmitted along the WDS link comply with the IEEE 802.11 WDS (Wireless Distribution System) format at the link layer.
- **BM-BS.** This type of wireless link is used in the SMC2682W for providing LAN-to-LAN bridging services. To establish this type of wireless link between two SMC2682W, one SMC2682W must be in Bridge Master (BM) mode and the other must be in Bridge Slave (BS) mode. The SMC2586W-G provides this type of wireless link for backward compatibility with the SMC2682W.

The relationships among the operational modes and the wireless link types are shown in the following table:

	AP	BM	BS
AP	WDS	WDS	
BM	WDS	WDS	BM-BS
BS		BM-BS	

Table 1. Operational modes vs. wireless link types.

From the table, a WDS link can be establish between two APs, a BM-BS link can be established between a Bridge Master and a Bridge Slave, but no wireless link can be established between a Bridge Slave and an AP.

Select an operational mode and click **Save** at the bottom of this page, and then you are brought back to the start page.

Step 2: Configuring TCP/IP Settings

Method of obtaining an IP address: Obtain from a DHCP Server ▼

IP address:

Subnet mask:

Default gateway:

Host name:

Domain (DNS suffix):

Fig. 8. TCP/IP settings.

Go to the **TCP/IP Addressing** section to configure IP address settings. The IP address can be manually set or automatically assigned by a DHCP server on the LAN (Default: DHCP client enabled). If you are manually setting the **IP address**, **Subnet mask**, and **Default gateway** settings, set them appropriately, so that they comply with your LAN environment. In addition, you can specify the **Host name** and **Domain (DNS suffix)** of the SMC2586W-G.

When you are finished, click **Save** at the bottom of this page, and then you are brought back to the start page.

Step 3: Configuring IEEE 802.11 Settings

AP functionality:	Enabled ▾
Policy:	Mixed ▾
Regulatory domain:	FCC (U.S.)
Channel number:	6 ▾
Network name (SSID):	SMC
Data rate:	Auto ▾
Transmit power:	High ▾

Fig. 9. IEEE 802.11g communication settings.

Go to the **IEEE 802.11, Communication** section in the Web-based Management user interface to configure IEEE 802.11g-related communication settings, including **Channel number** and **Network name (SSID)**.

The number of available RF channels depends on local regulations.

NOTE: The Regulatory domain setting of the SMC2586W-G sold in the U.S. and Canada is not configurable. It's set to FCC by default. As a result, only channels from 1 to 11 are available.

NOTE: For two SMC2586W-Gs or one wireless client computer and one SMC2586W-G to establish a wireless link, both devices must be configured with the same channel number and SSID.

If the SMC2586W-G was configured to be in AP or Bridge Master mode, and you want to use WDS to establish inter-SMC2586W-G wireless links, configure the WDS settings.

Port Enabled	Peer MAC Address
1 ☐	00-02-6F-01-62-C5
2 ☐	
3 ☐	
4 ☐	
5 ☐	
6 ☐	

Fig. 10. Wireless Distribution System settings.

To enable a WDS link:

1. Specify the MAC address of the AP or bridge at the other end of the WDS link.
2. Select the corresponding Enabled check box.

For example, assume you want two SMC2586W-Gs with MAC addresses 00-02-65-01-62-C5 and 00-02-65-01-62-C6 to establish a WDS link between them. On SMC2586W-G 00-02-65-01-62-C5, set the peer MAC address of port 1 to 00-02-65-01-62-C6 and on SMC2586W-G 00-02-65-01-62-C6, set the peer MAC address of port 1 to 00-02-65-01-62-C5.

3. When you are finished, click Save at the bottom of this page. You will be brought back to the Status page.

TIP: Plan your wireless network and draw a diagram, so that you know how the SMC2586W-G is connected to other peer APs or wireless bridges by WDS.




Fig. 11. Sample wireless bridge network topology.

WARNING: Do not let your network topology consist of wireless bridges, Ethernet switches, Ethernet links, and WDS links that form a *loop*. If there are any loops that exist, packets will circle around the loops and network performance will be seriously degraded.




Fig. 12. Network topology containing a loop.

Step 4: Reviewing and Applying Settings

Restart

Cancel

The settings have been changed. Click **Restart** to restart the access point for the settings to take effect.

Access Point Settings and Info	
Model	SMC2586W-G
BIOS/Firmware Version	SMC2586W-G v1.2/1.0.0 U
Operational Mode	Access Point
MAC Address (BSSID)	00-09-92-00-B2-14
System Up Time (hr:min:sec)	0:42:04
TCP/IP Settings	LAN Interface Get from the DHCP server.
	• Regulatory domain: FCC (U.S.) • Channel number: 11 • Network name (SSID): SMC • Data rate: Auto • Transmit power: High • Security mode: Open System

Fig. 13. Settings changes are highlighted in red.

On the start page, you can review all the settings you have made. Changes are highlighted in red. If they are OK, click Restart for the new settings to take effect.

NOTE: It takes about 7 seconds for the SMC2586W-G to complete its restart process.

NOTE: If you decide not to change settings of the SMC2586W-G, be sure to log off by clicking the Log Off button on the left menu. This way another administrator can log on to the device to do configuration and management. If you do not click the Log Off button or have not interacted with the Web management interface for a period of time specified by the Web admin idle timeout setting (5 minutes by default), you'll be automatically logged off by the device.

2.5 Deploying the SMC2586W-G

After the settings have been configured, deploy the SMC2586W-G to the field application environment. Connect the SMC2586W-G to an Ethernet LAN through an Ethernet switch/hub.

If external high-gain directional antennas are needed, it may be difficult to align the antennas. Here are some suggestions for antenna alignment.

To adjust the alignments of a pair of SMC high-gain antennas:

1. Connect each SMC2586W-G to a computer via Ethernet.
2. Configure the data rate of each SMC2586W-G to the lowest value, 1Mbps.
3. Fix the alignment of the antenna on one side.
4. Adjust the alignment of the antenna on the other side by using response time information obtained from PINGing (run PING.exe) the “fixed-side” computer.
5. Fine-tune the alignment of the antenna until you get the best response time.
6. Increase the data rate of each SMC2586W-G simultaneously until an optimal workable data rate is reached. You may not be able to use the highest data rate, 54Mbps, because of the distance and the gain of the antennas. Fig. 14 illustrates the idea.




Fig. 14. Adjusting alignments of external directional antennas.

TIP: As an alternative, the Link Monitor function can be used for antenna alignment. Just configure SMC2586W-G 1 to Bridge Slave mode and SMC2586W-G 2 to Bridge Master mode. On Computer 1, use a Web browser to connect to SMC2586W-G 1 and go to the Status, Link Monitor page, and then monitor the signal strength and link quality values when adjusting the antenna posture of SMC2586W-G 1. Larger values means better wireless connectivity.

Linking Quality :	10 %
Signal Strength :	25 %

3. Using Web-Based Management

3.1 Overview




Fig.15 The Start page.

Menu Structure

The left side of the start page contains a menu for you to carry out commands. Here is a brief description of the hyperlinks on the menu:

- **Home.** For going back to the start page.
- **Status.** Status information.
 - **Wireless Clients.** The status of the wireless clients (STAs and Bridge Slaves) currently associated with the SMC2586W-G.
 - **DHCP Mappings.** Current IP-MAC address mappings of the built-in DHCP server.
 - **System Log.** System events log.
 - **Link Status (Slave mode)**
- **General.** Global operations.
 - **Operational Mode.** Operational mode settings.
 - **Password.** For gaining rights to change the settings of the SMC2586W-G.
 - **Firmware Tools.** For upgrading the firmware of the SMC2586W-G, backing up and restoring configuration, and configuration reset of the SMC2586W-G.
- **TCP/IP.** TCP/IP-related settings.

- **Addressing.** IP address settings for the SMC2586W-G to work with TCP/IP.
- **DHCP Server.** Settings for the DHCP (Dynamic Host Configuration Protocol) server on the SMC2586W-G.
- **IEEE 802.11.** IEEE 802.11g-related settings.
 - **Communication.** Basic settings for the IEEE 802.11g interface of the SMC2586W-G to work properly with wireless clients.
 - **Security.** Security settings for authenticating wireless users and encrypting wireless data.
- **Advanced.** Advanced settings of the SMC2586W-G.
 - **Packet Filters.** Ethernet Type Filters, IP Protocol Filters, and TCP/UDP Port Filters settings.
 - **Management.** UPnP, System Log, and SNMP settings.

Log Off Command




Fig. 16 Log Off.

There is a **Log Off** button at the bottom left hand side of the menu for you to log off from the Web management interface. Another administrator can only log in to perform management tasks after you log off.

Save, Save & Restart, and Cancel Commands



Fig. 17. Save, Save & Restart, and Cancel.

There are three buttons - **Save**, **Save & Restart**, and **Cancel** - at the bottom of each page. Clicking **Save** stores the settings changes to the memory of the SMC2586W-G and brings you back to the start page. Clicking **Save & Restart** stores the settings changes to the memory of the SMC2586W-G and restarts the SMC2586W-G immediately for the settings to take effect. Clicking **Cancel** discards any settings changes and brings you back to the start page. If you click **Save**, the start page will reflect the fact that the configuration settings have been changed by showing two buttons—**Restart** and **Cancel**. In addition, changes are highlighted in red. Clicking **Cancel** discards all the changes. Clicking **Restart** restarts the SMC2586W-G for the new settings to take effect.

Restart
Cancel

The settings have been changed. Click **Restart** to restart the access point for the settings to take effect.

Access Point Settings and Info	
Model	SMC2586W-G
BIOS/Firmware Version	SMC2586W-G v1.2/1.0.0 U
Operational Mode	Access Point
MAC Address (BSSID)	00-09-92-00-B2-14
System Up Time (hr:min:sec)	0:42:04
TCP/IP Settings	LAN Interface Get from the DHCP server.
	- Regulatory domain: FCC (U.S.) - Channel number: 11 - Network name (SSID): SMC - Data rate: Auto - Transmit power: High - Security mode: Open System

Fig. 18 Settings have been changed.

Home and Refresh Commands



Fig. 19 Home and Refresh.

At the bottom of each status page shows read-only information and two buttons—**Home** and **Refresh**. Clicking **Home** brings you back to the start page. Clicking **Refresh** updates the shown status information.

3.2 Viewing Status

Associated Wireless Clients

Wireless Clients Status						
No.	MAC Address	IP Address	Name	Tx Bytes	Rx Bytes	Last Activity Time
1	00-90-48-00-40-94	192.168.168.226		7521	1162	00h:01m:56s

Fig. 20 Status of associated wireless clients.

On this page, the status information of each associated client (STA or Bridge Slave), including its MAC address, IP address, user name, number of bytes it has send, number of bytes it has received, and the time of its last activity, is shown.

Current DHCP Mappings

DHCP Mapping Table			
No.	MAC Address	IP Address	Type
1	00-90-4B-00-B9-BD	192.168.168.214	Static
2	00-BB-DE-AD-BE-EF	192.168.168.224	In use
3	00-90-4B-00-40-94	192.168.168.226	Dynamic
4	00-40-01-43-1D-E8	192.168.168.230	In use

Fig. 21 Current DHCP mappings.

On this page, all the current static or dynamic DHCP mappings are shown. A DHCP mapping is a correspondence relationship between an IP address assigned by the DHCP server and a computer or device that obtains the IP address. A computer or device that acts as a DHCP client is identified by its MAC address.

A static mapping indicates that the DHCP client always obtains the specified IP address from the **DHCP server**. You can set static DHCP mappings in the Static DHCP Mappings section of the DHCP Server configuration page (see Section 3.4.2). A dynamic mapping indicates that the DHCP server chooses an IP address from the IP address pool from the **DHCP Server** configuration page.

System Log

Model:	SMC2586W-G
BIOS/Firmware version:	SMC2586W-G v1.2/1.0.0 U RC6
Operational mode:	Access Point
Current time:	Tuesday, February 03, 2004 4:42:10 PM

Tuesday, February 03, 2004 3:33:09 PM	Set LAN IP address --> 192.168.169.18 by DHCP client.
Tuesday, February 03, 2004 3:33:11 PM	SYSTEM START UP!
Tuesday, February 03, 2004 3:33:11 PM	Wireless LAN interface initializes success.
Tuesday, February 03, 2004 3:33:11 PM	Mac address --> 00-09-92-00-B2-14
Tuesday, February 03, 2004 3:33:11 PM	LAN IP address will get by DHCP client.
Tuesday, February 03, 2004 3:33:11 PM	Set Primary DNS IP address --> 192.168.168.1.

Fig. 22 System log.

System events are recorded in the memory of the SMC2586W-G. The logged information is useful for troubleshooting purposes. The system events are divided into several categories, and you can select which categories of events to log. See Section 3.6 System Log for more information.

Linking Quality :	10 %
Signal Strength :	25 %

When the SMC2586W-G is in Bridge Slave mode, you can use the Link Monitor status page to monitor the link quality and signal strength sensed by its RF module. Larger values means better wireless connectivity to its associated Bridge Master. This feature is especially useful when you are aligning a pair of directional antennas for long range bridging applications. Refer to Section 2.5 for more information about antenna alignment.

NOTE: The values are updated every 20 seconds.

3.3 General Operations

Selecting an Operational Mode

Access Point / Bridge

Use this mode to provide both Access Point and Bridging Functionality. The Bridge function is supported through Wireless Distribution System (WDS). The WDS function can support up to 6 bridge links.

Bridge Master and Bridge Slave

These 2 modes can be used when you want to use both the SMC2682W and SMC2586W-G in the same bridging environments. If you are setting up a bridge configuration using all SMC2586W-G's use the [Access Point / Bridge] mode above and configure your Bridge connections using WDS.

Bridge Master

Use this mode to provide the Master Bridge functionality of the SMC2682W. In this mode, the SMC2586W-G can also act as an Access Point to the wireless clients located on the same network as the Bridge Master.

Bridge Slave

Use this mode to provide Slave Bridge functionality of the SMC2682W, in this mode the SMC2586W-G will not work as an Access Point.

Fig. 23. Operational modes settings.

The SMC2586W-G supports 3 operational modes for meeting various wireless connectivity requirements:

- **Access Point (AP).** The AP mode enables IEEE 802.11 Stations (STAs) to automatically associate with it via the standard IEEE 802.11 association process. In addition, the IEEE 802.11 WDS (Wireless Distribution System) technology can be used to manually establish wireless links between two APs or between an AP and a Bridge Master.
- **Bridge Master (BM).** Use this mode to provide the Bridge Master functionality of the SMC2682W. The Bridge Master mode is designed to work in

those networks where SMC2682W Wireless Bridge Slaves are already installed. The Bridge Master enables Bridge Slaves to automatically associate with it. It also enables IEEE 802.11 Stations, which are on the same LAN as the Bridge Master, to automatically associate with it via the standard IEEE 802.11 association process. In addition, the IEEE 802.11 WDS (Wireless Distribution System) technology can be used to manually establish wireless links between two Bridge Masters or between a Bridge Master and an AP.

- **Bridge Slave (BS).** Use this mode to provide the Bridge Slave functionality of the SMC2682W. The Bridge Slave mode is designed to work in those networks where SMC2682W Wireless Bridge Masters are already installed.

In any mode, the SMC2586W-G forwards packets between its Ethernet interface and wireless interface for wired hosts on the Ethernet side and wireless host(s) on the wireless side.

There are 3 types of wireless links between two SMC2586W-Gs or between an SMC2586W-G and another wireless device.

- **STA-AP.** This type of wireless link is specified in the IEEE 802.11 standard for communication between an IEEE 802.11 Station (STA) and an IEEE 802.11 Access Point (AP). An STA is usually a client computer (PC or PDA) with a WLAN network interface card (NIC).
- **WDS.** This type of wireless link is specified in the IEEE 802.11 standard for communication between two IEEE 802.11 APs. Wireless packets transmitted along the WDS link comply with the IEEE 802.11 WDS (Wireless Distribution System) format at the link layer.
- **BM-BS.** This type of wireless link is propriety and was used in the legacy SMC2682W for providing LAN-to-LAN bridging services. To establish this type of wireless link between two SMC2682W, one SMC2682W must be in Bridge Master (BM) mode and the other must be in Bridge Slave (BS) mode. The SMC2586W-G provides this type of wireless link for backward compatibility with the SMC2682W.

The relationships among the operational modes and the wireless link types are shown in the following table:

Table 2. Operational modes vs. wireless link types.

	AP	BM	BS
AP	WDS	WDS	
BM	WDS	WDS	BM-BS
BS		BM-BS	

From the table, a WDS link can be establish between two APs, a BM-BS link can be established between a Bridge Master and a Bridge Slave, but no wireless link can be established between a Bridge Slave and an AP.

NOTE: If you'll deploy a number of SMC2586W-Gs, and several operational modes are involved in your deployment, keep the following limitations in mind.




Fig. 24 Connectivity Limitation.

In Fig. 24 packets from STA cannot reach X, and vice versa.

Changing Password

Old password:	****
New user name:	admin
New password:	*****
New password again:	*****

Fig. 25 Password.

On this page, you can change the user name and password for the rights to modify the configuration of the SMC2586W-G. The new password must be typed twice for confirmation.

Managing Firmware

Firmware management protocol:	HTTP
-------------------------------	-----------------------------------

Fig. 26 Firmware management protocol setting.

Firmware management operations for the SMC2586W-G include firmware upgrade, configuration backup, configuration restore, and configuration reset. Firmware upgrade, configuration backup, and configuration restore can be achieved via HTTP or TFTP. The HTTP-based way is suggested because it's more userfriendly. However, due to different behavior of different Web

browser types and versions, HTTP-based firmware management operations may not work properly with some Web browsers. If you cannot successfully perform HTTP-based firmware management operations with your Web browser, try the TFTP-based method.

Upgrading Firmware by HTTP

The screenshot shows a web form titled "Firmware Upgrade". It contains a text input field labeled "Firmware file name:" followed by a "Browse..." button. Below the input field is a blue button labeled "Upgrade".

Fig. 27 Firmware upgrade by HTTP.

To upgrade firmware of the SMC2586W-G by HTTP:

1. Click **Browse** and then select a correct firmware .bin file. The firmware file path will be shown in the **Firmware file name** text box.
2. Click Upgrade to begin the upgrade process.

Backing up and Restoring Configuration Settings by HTTP


The screenshot shows a web form titled "Configuration Backup". It contains a blue button labeled "Back Up".

Fig. 28 Firmware backup by HTTP.

To back up configuration of the SMC2586W-G by HTTP:

1. Click **Back Up**.
2. You'll be prompted to open or save the configuration file. Click **Save**.
3. The configuration file is named **SMC2586W-G_Backup.hex**. Don't change the configuration file name in the **Save As** dialog box. Select a folder in which the configuration file is to be stored. And then, click **Save**.

NOTE: The procedure may be a little different with different Web browsers.


The screenshot shows a web form titled "Configuration Restore". It contains a text input field labeled "Configuration file name:" followed by a "Browse..." button. Below the input field is a blue button labeled "Restore".

Fig. 29 Configuration restore by HTTP.

To restore configuration of the SMC2586W-G by HTTP:

1. Click **Browse** and then select a correct configuration .hex file. You have to make sure the file name is the SMC2586W-G_Backup.hex. The file path will be shown in the **Configuration file name** text box.
2. Click **Restore** to upload the configuration file to the SMC2586W-G.

Upgrading Firmware by TFTP

TFTP server IP address:	192.168.0.19
Max number of retries:	30
Timeout:	10 sec.

Fig. 30 TFTP server settings.

When using TFTP as the firmware management protocol, you can configure settings for the SMC2586W-G's TFTP client to communicate with a TFTP server. If the TFTP client does not get a response from the TFTP server within a period specified by the Timeout setting, it will resend the previous request. The **Max number of retries** setting specifies the maximum number of resend before the TFTP client stops communicating with the TFTP server.

The SMC2586W-G Installation CD includes a TFTP server program (**TftpSrvr.exe**) for firmware upgrade. Run this program on the computer which serves as a TFTP server.



Fig. 31 Firmware upgrade by TFTP.

To upgrade firmware of the SMC2586W-G by TFTP:

1. Use a computer that will serve as a TFTP server and as a managing computer to trigger the upgrade process.
2. Connect the computer and one of the LAN Ethernet switch port with a standard Ethernet cable.
3. Configure the IP address of the computer so that the SMC2586W-G and the computer are in the same IP subnet.
4. Run the TFTP Server utility on the computer. Specify the folder in which the firmware files reside.
5. On the computer, run a Web browser and click the **General, Firmware Tools** hyperlink.

6. Choose **TFTP** as the **Firmware management protocol**.

7. Specify the IP address of the computer, which acts as a TFTP server. If you don't know the IP address of the computer, open a Command Prompt from the computer running the TFTP server, and type IpConfig, then press the **Enter** key.

8. Trigger the firmware upgrade process by clicking **Upgrade**.




Fig. 32 TFTP Server.

NOTE: After the dialog box of the TFTP server program appears, be sure to specify the folder that the downloaded firmware files reside.

NOTE: Make sure the **Accept read requests** check box of TFTP Server is selected.

NOTE: The LAN IP address of the SMC2586W-G and the IP address of the TFTP server must be in the same IP subnet for TFTP to work.

NOTE: It is highly recommended that the TFTP server and the to-be-upgraded SMC2586W-G be connected by Ethernet and on the same LAN.

NOTE: After the firmware is upgraded, be sure to delete the contents of the Web browser cache, so that the Web management pages can be shown correctly.

NOTE: A failed upgrade may corrupt the firmware and cause the SMC2586W-G to fail to restart. When this occurs, call for technical support.

TIP: If you want to remotely upgrade the firmware of a deployed SMC2586W-G from the In-ternet, adjust the **Timeout** and **Max no. of retries** settings of TFTP Server for remote TFTP upgrade to succeed.

Backing up and Restoring Configuration Settings by TFTP



Fig. 33. Configuration backup/restore.

To back up configuration of the SMC2586W-G by TFTP:

1. Use a computer that will serve as a TFTP server and as a managing computer to trigger the backup process.
2. Connect the computer and one of the LAN Ethernet switch port with a standard Ethernet cable.
3. Configure the IP address of the computer so that the computer and the SMC2586W-G are in the same IP subnet.
4. Run the TFTP Server utility on the computer. Select the **Accept write requests** check box, and specify the folder to which the configuration settings of the SMC2586W-G will be saved.
5. On the computer, run a Web browser and click the **General, Firmware Tools** hyperlink.
6. **Choose TFTP as the Firmware management protocol.**
7. Within the **Configuration Backup/Restore** section, specify the IP address of the computer, which acts as a TFTP server. If you don't know the IP address of the computer, open a Command Prompt, and type `IpConfig`, then press the Enter key.
8. Trigger the backup process by clicking **Back Up**. The backup file is named `SMC2586W-G_Backup.hex`.

NOTE: Remember to select the **Accept write requests** check box of TFTP Server.

To restore configuration of the SMC2586W-G by TFTP:

1. Use a computer that will serve as a TFTP server and as a managing computer to trigger the restoring process.
2. Connect the computer and one of the LAN Ethernet switch port with a standard Ethernet cable.
3. Configure the IP address of the computer so that the computer and the SMC2586W-G are in the same IP subnet.
4. Run the TFTP Server utility on the computer. Specify the folder in which

the configuration backup file resides. A configuration backup file is named SMC2586W-G_Backup.hex.

5. On the computer, run a Web browser and click the **General, Firmware Tools** hyperlink.

6. Choose **TFTP** as the **Firmware management protocol**.

7. Within the **Configuration Backup/Restore** section, specify the IP address of the computer, which acts as a TFTP server. If you don't know the IP address of the computer, open a Command Prompt from the computer running the TFTP server, and type IpConfig, then press the **Enter** key.

8. Trigger the restoring process by clicking **Restore**. The SMC2586W-G will then download the configuration backup file from the TFTP server.

NOTE: Make sure the file is a valid configuration backup file for the SMC2586W-G.

TIP: If you want to remotely back up or restore configuration from the Internet, adjust the **Timeout** and **Max no. of retries** settings of TFTP Server for remote TFTP configuration backup/restore to succeed.

Resetting Configuration to Factory Defaults




Fig. 34 Configuration reset.

Click on the **Reset** button to reset the device configuration to factory defaults.

3.4 Configuring TCP/IP Related Settings

Addressing

Method of obtaining an IP address:	Obtain from a DHCP Server ▼
IP address:	
Subnet mask:	
Default gateway:	
Host name:	SMC2586W-G
Domain (DNS suffix):	

Fig. 35 TCP/IP settings.

The IP address of the SMC2586W-G can be manually set (**Set Manually**) or automatically assigned by a DHCP server on the LAN (**Obtain from a DHCP Server - enabled by default**). If you are manually setting the **IP address**, **Subnet mask**, and **Default gateway** settings, set them appropriately, so that they comply with your LAN environment. In addition, you can specify the **Host name** and **Domain (DNS suffix)** of the SMC2586W-G.

DHCP Server

Functionality:	Enabled ▾
Default gateway:	192.168.2.1
Subnet mask:	255.255.255.0
Primary DNS server:	192.168.2.1
Secondary DNS server:	
First allocatable IP address:	192.168.2.2
Allocatable IP address count:	20

Fig. 36 Basic DHCP server settings.

The SMC2586W-G can automatically assign IP addresses to client computers by DHCP. In this section of the management page, you can specify the **Default gateway**, **Subnet mask**, **Primary DNS server**, and **Secondary DNS server** settings that will be sent to a client at its request. Additionally, you can specify the first IP address that will be assigned to the clients and the number of allocatable IP addresses.

NOTE: There should be only one DHCP server on the LAN; otherwise, DHCP would not work properly. If there is a DHCP server on the LAN already, disable the DHCP server functionality of the SMC2586W-G.

NOTE: By default the DHCP server function is disabled.

DHCP Mappings

Enabled	Desc.	MAC Address	IP Address
☐	Bill	00-22-32-5D-80-02	192.168.0.203
☐			
☐			
☐			
☐			
☐			
☐			
☐			
☐			
☐			

Fig. 37 Static DHCP mappings.

IP addresses of servers are often static so that clients could always locate the servers by the static IP addresses. By using **Static DHCP Mappings**, you can ensure that a host will get the same IP address when it requests one from the DHCP server. Therefore, instead of configuring the IP address of an intranet server manually, you can configure the server to obtain an IP address by DHCP and it is always assigned the same IP address.

To always assign a static IP address to a specific DHCP client:

1. Specify the MAC address of the DHCP client and the IP address to be assigned to it. Then, give a description of this mapping.
2. Select the corresponding Enabled check box.

3.5 Configuring IEEE 802.11b/g-Related Settings

Communication

Basic IEEE 802.11b/g-related communication settings include **AP functionality**, **Regulatory domain**, **Channel number**, **Network name (SSID)**, **Data rate**, and **Transmit power**.

AP functionality:	Enabled
Policy:	Mixed
Regulatory domain:	FCC (U.S.)
Channel number:	6
Network name (SSID):	SMC
Data rate:	Auto
Transmit power:	High

Fig. 38 Basic IEEE 802.11b/g communication settings.

For specific needs such as configuring the SMC2586W-G as a wireless LAN-to-LAN bridge, the AP functionality can be disabled, so that no wireless client can associate with the SMC2586W-G. (This will only work while the SMC2586W-G bridges are configured in AP/WDS mode, if you are using Master/Slave mode and disable the AP functionality on the Master no wireless clients or bridge slaves will be able to connect.)

Since the IEEE 802.11g-based SMC2586W-G is also IEEE 802.11b compatible, you can configure the Policy setting to meet your backwards compatibility needs. If the SMC2586W-G is used in an environment in which all wireless clients are IEEE 802.11b-based, set Policy to b only. If all the wireless clients are IEEE 802.11g-based, set Policy to g only. For maximum flexibility, set Policy to Mixed. This mode enables SMC2586W-G to support both IEEE 802.11b- and IEEE 802.11g-based wireless clients.

The number of available RF channels depends on local regulations; therefore you have to choose an appropriate regulatory domain to comply with local regulations. The SSID of a wireless client computer and the SSID of the SMC2586W-G must be identical for them to communicate with each other.

NOTE: The **Regulatory domain** setting of the SMC2586W-G sold in the U.S. and Canada is not configurable. It's set to FCC by default. As a result, only channels from 1 to 11 are available.

If there is RF interference, you may want to reduce the Data rate for more reliable wireless transmission. In most cases, leave the setting to Auto.

The transmit power of the RF module of the SMC2586W-G can be adjusted so that the RF coverage of the SMC2586W-G can be changed.

Link Integrity

Functionality:	Disabled ▾
Reference host:	0.0.0.0

Fig. 39 Link integrity settings.

When the SMC2586W-G is in AP or Bridge Master mode and the Ethernet LAN interface is detected to be disconnected from the wired network, all currently associated wireless clients (STAs and Bridge Slaves) are disassociated by the SMC2586W-G and no wireless client can associate with the SMC2586W-G. The detection mechanism is based on pinging the IP address specified in Reference host.

Wireless Distribution System




Fig. 40 Wireless Distribution System.

Traditionally, access points are connected by Ethernet. By IEEE 802.11 Wireless Distribution System (WDS), APs can communicate with one another wirelessly. For example, in Fig. 40, AP 2 acts as an access point for the notebook computers and it forwards packets sent from the notebook computers to AP 1 through WDS. Then, AP 1 forwards the packets to the Ethernet LAN. Packets destined for the notebook computers follow a reverse path from the Ethernet LAN through the APs to the notebook computers. In this way, AP 2 plays a role of “AP repeater”.



Fig. 41 LAN-to-LAN bridging.

By WDS, two or more LAN segments can be connected wirelessly. As illustrated in Fig. 41, a pair of wireless LAN-to-LAN bridges is used to connect two LAN segments. Since the SMC2586W-G is WDS-enabled, it can be used as a wireless bridge even when it is in AP mode.

NOTE: An SMC2586W-G can have up to 6 WDS links to other APs or wireless bridges.

Port	Enabled	Peer MAC Address
1	☐	00-02-6F-01-62-C5
2	☐	
3	☐	
4	☐	
5	☐	
6	☐	

Fig. 42 Wireless Distribution System settings.

To enable a WDS link:

3. Specify the MAC address of the AP or bridge at the other end of the WDS link.

4. Select the corresponding **Enabled** check box.

For example, assume you want two SMC2586W-Gs with MAC addresses 00-02-65-01-62-C5 and 00-02-65-01-62-C6 to establish a WDS link between them. On SMC2586W-G 00-02-65-01-62-C5, set the peer MAC address of port 1 to 00-02-65-01-62-C6 and on SMC2586W-G 00-02-65-01-62-C6, set the peer MAC address of port 1 to 00-02-65-01-C5.

TIP: Plan your wireless network and draw a diagram, so that you know how an AP is connected to other peer APs or wireless bridges by WDS.

TIP: Plan your wireless network and draw a diagram, so that you know how a bridge is connected to other peer bridges by WDS. See the following figure for an example network-planning diagram.




Fig. 43 Sample wireless bridge network topology.

WARNING: Do not let your network topology consist of wireless bridges, Ethernet switches, Ethernet links, and WDS links that form a loop. If there are any loops that exist, packets will circle around the loops and network performance will be seriously degraded.




Fig. 44 Network topology containing a loop.

Security

IEEE 802.11b/g security settings include **SSID broadcasts**, **Security mode**, **IEEE 802.11 Authentication algorithm**, **WEP keys**, **MAC-Address-Based Access Control**.

Basic

SSID broadcasts:	Enabled
Wireless client isolation:	Disabled
Security mode:	Static WEP
Authentication algorithm:	Auto
Key length:	64 Bits
Selected key:	Key 1
Key 1:	*****
Key 2:	*****
Key 3:	*****
Key 4:	*****

Fig. 45 Basic IEEE 802.11g security settings.

For security reasons, it's highly recommended that the security mode be set to options other than Open System. When the security mode is set to Open System, no authentication or and data encryption will be performed. Additionally, you can disable the SSID broadcasts functionality so that a wireless client (STA or Bridge Slave) with an "ANY" SSID cannot associate with the SMC2586W-G.

Wireless Client Isolation is a feature for the SMC2586W-G in AP or Bridge Master mode to block wireless-to-wireless traffic between STAs so that the STAs cannot see each other. This feature is useful for WLANs deployed in public places. This way, hackers have no chance to attack other wireless users in a hotspot.

When the **Wireless client isolation** setting is set to wireless clients (STAs) associated to this SMC2586W-G, which acts as an AP, cannot see each other, and wireless-to-wireless traffic between the STAs is blocked.

When the setting is set to All APs in This Subnet, traffic among wireless users of different SMC2586W-Gs in the same IP subnet is blocked. The behaviors are illustrated in the following figures.




Fig. 46 Behavior of the “This AP Only” wireless client isolation option.




Fig. 47 Behavior of the “All APs on This Subnet” wireless client isolation option.

As illustrated in Fig. 46 when AP 1 and AP 2 are using the “This AP Only” option, AP1 blocks wireless traffic between STA 1 and STA 2, while wireless traffic between STA 2 and STA 3, which are associated with different APs, is still allowed. If the “All APs in This Subnet” option is used as shown in Fig. 47, AP 1 and AP 2 communicates with each other via an inter-AP protocol to share their STA association information to block wireless traffic among all the STAs.

There are up to 7 security modes:

- **Open System.** No authentication, no data encryption.
- **Static WEP.** WEP (Wired Equivalent Privacy) keys must be manually configured.
- **Static TKIP (WPA-PSK).** Only TKIP (Temporal Key Integrity Protocol) mechanism of WPA (Wi-Fi Protected Access) is enabled. In this mode, you have to specify the Pre-shared key, which will be used by the TKIP engine as a master key to generate keys that actually encrypt outgoing packets and decrypt incoming packets.

NOTE: The number of characters of the Pre-shared key setting must be at least between 8 and can be up to 63.

- **IEEE 802.1x EAP without Encryption (EAP-MD5).** The IEEE 802.1x functionality is enabled and the user-name/password-based EAP-MD5 authentication is used. No data encryption.
- **IEEE 802.1x EAP with Static WEP (EAP-MD5).** The IEEE 802.1x functionality is enabled and the user-name/password-based EAP-MD5 authentication is used. Data encryption is achieved by static WEP.
- **IEEE 802.1x EAP with Dynamic WEP (EAP-TLS, EAP-TTLS, PEAP).** The IEEE 802.1x functionality is enabled and dynamic WEP key distribution authentication (EAP-TLS, EAP-TTLS, or PEAP) is used. Data encryption is achieved by dynamic WEP.
- **IEEE 802.1x EAP with Dynamic TKIP (WPA).** This is a full WPA mode, in which both the TKIP and IEEE 802.1x dynamic key exchange mechanisms are enabled. The SMC2586W-G is highly secured in this mode.

In the above security modes, a back-end RADIUS (Remote Authentication Dial-In User Service) server is needed if IEEE 802.1x functionality is enabled. See Section 3.5.3 for more information about IEEE 802.1x and RADIUS.

According to the IEEE 802.11 standard, WEP can be used for authentication and data encryption. Normally, Shared Key authentication is used if WEP data encryption is enabled. In rare cases, Open System authentication may be used when WEP data encryption is enabled. The Authentication algorithm setting is provided for better compatibility with wireless client computers

with various WLAN network adapters. There are three options available, including Open System, Shared Key, and Auto.

When WEP is enabled by a security mode, the Key length can be specified to be 64 Bits or 128 Bits. The Selected key setting specifies the key to be used as a send-key for encrypting traffic from the local device side to the remote device side. All 4 WEP keys are used as receive-keys to decrypt traffic from the remote device side to the local device side.

NOTE: Each field of a WEP key setting is a hexadecimal number from 0-9, A-F. For example, when the security mode is Static WEP and the key length is 64 Bits, you could set Key 1 to "00012E3ADF".

MAC-Address-Based Access Control

The screenshot shows a configuration window for MAC-Address-Based Access Control. At the top, 'Functionality' is set to 'Enabled' in a dropdown menu. Below it, 'Access control type' has two radio buttons: 'inclusive' (which is selected) and 'exclusive'. There is an empty text box for adding a MAC address, followed by an 'Add' button. Below this, the 'MAC address format' is displayed as '00-02-DD-30-03-1E'. At the bottom, there is a table with two columns: 'MAC Address' and 'Delete'. The table contains two entries: '00-50-C2-01-96-4D' and '00-09-92-01-02-55', each with a corresponding 'Delete' button.

MAC Address	Delete
00-50-C2-01-96-4D	Delete
00-09-92-01-02-55	Delete

Fig. 48 MAC-address-based access control settings.

With MAC-Address-Based Access Control, you can specify the wireless clients (STAs or Bridge Slaves) that are permitted or not permitted to associate with the SMC2586W-G. When the table type is set to inclusive, entries in the table are permitted to associate with the SMC2586W-G. When the table type is set to exclusive, entries in the table are not permitted to associate with the SMC2586W-G.

NOTE: MAC-address-based access control is only available when the SMC2586W-G is in AP or Bridge Master mode.

To deny wireless clients' access to the wireless network:

1. Select Enabled from the **Functionality** drop-down list.
2. Set the Access control type to exclusive.
3. Specify the MAC address of a wireless client to be denied access, and then click Add.
4. Repeat Step 3 for each other wireless client.

To grant wireless clients' access to the wireless network:

1. Select Enabled from the **Functionality** drop-down list.

2. Set the **Access control type** to **inclusive**.

3. Specify the MAC address of a wireless client to allow access, and then click **Add**.

4. Repeat Step 3 for each other wireless client.

To delete an entry in the access control table:

- Click **Delete** next to the entry.

NOTE: The size of the access control table is 64.

TFTP server IP address:	192.168.0.125
MAC ACL file name:	MacAcl.txt
Download	

Fig. 49 MAC ACL download settings.

Instead of manually entering MAC addresses to the access control table one by one, you can prepare a text file that contains all the MAC addresses and put it on a TFTP server, and then download the MAC ACL (Access Control List) file from the TFTP server to the SMC2586W-G. Fig. 50 shows the contents of a sample ACL file.

```
00-11-22-33-44-50
00-11-22-33-44-51
00-11-22-33-44-52
00-11-22-33-44-53
00-11-22-33-44-54
00-11-22-33-44-55
00-11-22-33-44-56
00-11-22-33-44-57
00-11-22-33-44-58
00-11-22-33-44-59
00-11-22-33-44-5a
00-11-22-33-44-5b
00-11-22-33-44-5c
00-11-22-33-44-5d
00-11-22-33-44-5e
00-11-22-33-44-5f
00-11-22-33-44-60
```

Fig. 50 Sample MAC ACL file.

To download a MAC ACL file from a TFTP server:

1. Specify the IP address of the TFTP server in the **TFTP server IP address** text box.

2. Specify the name of the MAC ACL file on the TFTP server in the **MAC ACL file name** text box.

3. Click **Download**.

IEEE 802.1x/RADIUS

IEEE 802.1x Port-Based Network Access Control is a new standard for solving some security issues associated with IEEE 802.11, such as lack of user-based authentication and dynamic encryption key distribution. With IEEE 802.1x, a RADIUS (Remote Authentication Dial-In User Service) server, and a user account database, an enterprise or ISP (Internet Service Provider) can manage its mobile users' access to its wireless LANs. Before granting access to a wireless LAN supporting IEEE 802.1x, a user has to issue his or her user name and password or digital certificate to the backend RADIUS server by EAPOL (Extensible Authentication Protocol Over LAN). The RADIUS server can record accounting information such as when a user logs on to the wireless

LAN and logs off from the wireless LAN for monitoring or billing purposes. The IEEE 802.1x functionality of the access point is controlled by the security mode (see Section 3.5.2.1). So far, the wireless access point supports two authentication mechanisms—EAP-MD5 (Message Digest version 5), EAP-TLS (Transport Layer Security). If EAP-MD5 is used, the user has to give his or her user name and password for authentication. If EAP-TLS is used, the wireless client computer automatically gives the user's digital certificate that is stored in the computer hard disk or a smart card for authentication. And after a successful EAP-TLS authentication, a session key is automatically generated for wireless packets encryption between the wireless client computer and its associated wireless access point. To sum up, EAP-MD5 supports only user authentication, while EAP-TLS supports user authentication as well as dynamic encryption key distribution.




Fig. 51 IEEE 802.1x and RADIUS.

SMC2586W-G supports IEEE 802.1x and can be configured to communicate with two RADIUS servers. When the primary RADIUS server fails to respond, SMC2586W-G will try to communicate with the secondary RADIUS server. You can specify the length of timeout and the number of retries before communicating with the secondary RADIUS server after failing to communicate with the primary RADIUS server.

An IEEE 802.1x-capable wireless access point and its RADIUS server(s) share a secret key so that they can authenticate each other. In addition to its IP address, a wireless access point can identify itself by an NAS (Network Access Server) identifier. Each IEEE 802.1x-capable wireless access point must have a unique NAS identifier.

Primary RADIUS server:	192.168.168.220
Secondary RADIUS server:	
Authentication port:	1812
Accounting port:	1813
Timeout (sec.):	5
Max number of retries:	3
Shared key:	*****
Identifier of this NAS:	AP1

Fig. 52 IEEE 802.1x/RADIUS settings.

3.6 Configuring Advanced Settings

Packet Filters

The SMC2586W-G provides layer 2 (Ethernet Type Filters), layer 3 (IP Protocol Filters), and layer 4 (TCP/UDP Port Filters) filtering capabilities. The configuration processes for the filters are similar.

Functionality: whether this filtering capability is enabled or disabled.

Policy for matched packets: how a matched packet is processed—discard or pass.

To enable a filtering rule: select the check box to the left of the rule.

Ethernet Type Filters

Functionality:	Disabled
Policy for matched packets:	Discard
Name	Number
☒ RARP	0x8035
☐ ARP	0x0806
☐ NetBUI	0xF0F0
☐ Novell IPX	0x8138
☐ IPX 802.3	0x00FF

Fig. 53 Ethernet type filters settings.

The Ethernet type field of the MAC (Media Access Control) header of a packet incoming from the WLAN or Ethernet interface is inspected for filtering. In a rule, specify the hex-decimal Ethernet type number and give the rule a name.

IP Protocol Filters

Functionality:	Disabled				
Policy for matched packets:	Discard				
Protocol Number	Source Address	Subnet Mask	Destination Address	Subnet Mask	
☒ 0x01	192.168.0.3	255.255.255.255	192.168.0.5	255.255.255.255	
☐ 0x02	0.0.0.0	0.0.0.0	0.0.0.0	0.0.0.0	
☐ 0x06	0.0.0.0	0.0.0.0	0.0.0.0	0.0.0.0	
☐ 0x11	0.0.0.0	0.0.0.0	0.0.0.0	0.0.0.0	
☐ 0x62	0.0.0.0	0.0.0.0	0.0.0.0	0.0.0.0	

Fig. 54 IP protocol filters settings.

The protocol, source address, and destination address fields of a packet incoming from the WLAN or Ethernet interface is inspected for filtering. In a rule, specify the hexadecimal protocol number, source IP address range (Source IP Address AND Source Subnet Mask), and destination IP address range (Destination IP Address AND Destination Subnet Mask).

A source (destination) IP address range is determined by performing an AND operation on the source (destination) IP address field and the source (destination) subnet mask field. For example, if the source IP address field is 192.168.0.1 and the source subnet mask field is 255.255.255.0, the result source IP address range is 192.168.0.0 to 192.168.0.255.

TCP/UDP Port Filters

Functionality:	Disabled	
Policy for matched packets:	Discard	
Destination Port	Protocol	Application Name
☒ 80	TCP	HTTP
☐ 0	TCP	
☐ 0	TCP	
☐ 0	TCP	
☐ 0	TCP	

Fig. 55 TCP/UDP port filters settings.

The destination port field the TCP or UDP header of a packet incoming from the WLAN or Ethernet interface is inspected for filtering. In a rule, specify the decimal **Destination Port**, **Protocol** type (TCP/UDP), and the name of the higher-level protocol (**Application Name**).

Management

☐ Telnet management
Web admin idle timeout (min.): 5

Fig. 56 Basic management settings.

The SMC2586W-G can be managed by Telnet. This functionality can be either enabled or disabled.

As the SMC2586W-G allows only one administrator to log on for management, you have to log off before another can log on. If you forget to log off or have not interacted with the Web management interface for a period specified by the Web admin idle timeout setting (de-fault: 5 minutes), you'll be automatically logged off by the SMC2586W-G.

UPnP


Functionality:	Enabled
Device friendly name:	SMC2586W-G

Fig. 57 UPnP settings.

UPnP (Universal Plug and Play) enables a Windows XP user to automatically discover peripheral devices. When the UPnP functionality is enabled, you can see the SMC2586W-G in My Network Places of Windows XP. The SMC2586W-G can be given a user-friendly name that will be shown in My Network Places. Double-clicking the icon in My Network Places that refers to the SMC2586W-G will launch the Web browser for you to configure the SMC2586W-G.

NOTE: Make sure you have installed the necessary Windows UPnP components on your Windows XP computer.

System Log



☒ Local log
☐ Remote log by SNMP trap
☐ Remote log by BSD Syslog
Syslog server IP address:

Event Types
☒ General
☒ Build-in AP
☒ MIB II traps

Fig. 58 System log settings.

System events can be logged to the on-board RAM of the SMC2586W-G (Local log) or sent in the form of SNMP trap (**Remote log by SNMP trap**) or BSD Syslog (**Remote log by BSD Syslog**) to a remote SNMP trap monitoring server or remote Syslog server, respectively. See the next subsection for more information about SNMP trap settings. Set the IP address of the Syslog server in the **Syslog server IP address** text box.

The system events are divided into the following categories:

- **General:** system and network connectivity status changes.
- **Built-in AP:** wireless client association and WEP authentication status changes.
- **MIB II traps:** Cold Start, Warm Start, Link Up, Link Down and SNMP Authentication Failure.

NOTE: The SNMP Authentication Failure trap is issued when using an incorrect community string to manage the SMC2586W-G via SNMP and the SNMP MIB II OID, **snmpEnableAuthenTraps**, is enabled (disabled by default).

SNMP

Functionality:	Enabled ▾
Read-only community:	*****
Read-write community:	*****
SNMP Trap Table	
IP Address	Community
☒ 192.168.0.2	*****
☐ 0.0.0.0	
☐ 0.0.0.0	
☐ 0.0.0.0	
☐ 0.0.0.0	

Fig. 59 SNMP settings.

The SNMP (Simple Network Management Protocol) functionality can be disabled, and you can specify the name (used as a password) of the read-only and read-write community. In addition, up to 5 SNMP trap targets can be set in the **SNMP Trap Table**.

To specify a trap target:

1. Type the IP address of the target host.
2. Type the **Community** for the host.
3. Select the corresponding check box next to the IP address text box.
4. EliteConnect Management Utility

4. EliteConnect Management Utility

4.1 Introduction

This chapter gives introductory information, such as the design goal and features, on SMC EliteConnect™ Management Utility.

In Chapter 4.2, it outlines EliteConnect Management Utility's basic functionality by using a sample device list file, which is installed by the setup package of EliteConnect Management Utility. EliteConnect Management Utility is designed to manage SMC2582W-B EliteConnect 802.11b Wireless Bridge and SMC2586W-G EliteConnect 802.11g Wireless Bridges.

Chapter 4.3 details all the EliteConnect Management Utility capabilities.

What is the EliteConnect Management Utility?

Managing a large number of WLAN devices is not an easy task. Several critical issues have to be taken into consideration when planning a large wireless network:

- Remote diagnosis
- Remote configuration
- Remote firmware upgrade
- Remote device configuration backup and restore

Only when these issues are correctly addressed can the deployed WLAN become an easily maintained network. That is the major reason why SMC EliteConnect™ Management Utility is developed making management of a large WLAN easy. By EliteConnect Management Utility's "batch processing" capabilities, managing wireless devices becomes a simple click-and-go matter.

Features

Device List Manipulation. EliteConnect Management Utility enables the network administrator to build a device list, which contains information about the deployed WLAN devices.

- **Annotations of devices.** The following items of information can be annotated to each device in the list:
 - **Device ID.** Identifier of the device.
 - **Device name.** Name of the device.
 - **Project name.** Name of the deployment project with which the device is associated.
 - **Geographical Zone 1, Zone 2, and location.** Geographical zone and location in which the device is deployed.
 - **Comments.** Remarks about the device.

- **DNS domain name.** DNS (Domain Name System) domain name of the device.

These information items serve as memos for the network administrator and they are optional. And the following information items must be specified so that EliteConnect Management Utility can communicate with the device by HTTP (HyperText Transfer Protocol):

- **IP address.** IP address of the device.
- **HTTP port.** HTTP port through which the device accepts HTTP traffic.

Either the IP address or DNS domain name, or both, must be specified, otherwise EliteConnect Management Utility has no way to recognize the device.

- **Device system information retrieval.** EliteConnect Management Utility can retrieve some useful system information about the device, including:
 - **MAC address.** MAC (Media Access Control) address of the device.
 - **Firmware version.** Version information about the firmware of the device. This information is useful when doing firmware upgrade.
 - **System up time.** How long the device has operated from its most recent startup.
 - **Model description.** Description of the device model designated by the manufacturer.
- **Cut, Copy, Paste, Delete, Undo, and Redo operations.** These operations are supported to edit device lists.
- **Filtering.** This functionality enables the network administrator to see the selected devices based on the following criteria:
 - **Project name**
 - **Geographical Zone 1**
 - **Geographical Zone 2**
 - **Firmware version**
- **Sorting.** This functionality enables the network administrator to arrange a device list in specific order.
- **Printing.** Printing of a device list.
- **Sending device lists by e-mail.** Sending a device list to others by e-mail within EliteConnect Management Utility.

- **Device Management.** The network administrator can manage devices one by one or in a batch fashion.
- **Configuring by Web browser.** Launching the default Web browser to manage the selected device.
- **Batch processing.** Applying a network management command to multiple devices at a time. The following commands are supported:
 - **Check Alive.** Checking whether the selected devices are operating.
 - **Change SSID.** Changing the SSID setting of every selected device.
 - **Upgrade Firmware by TFTP and HTTP.** Upgrading device firmware.
 - **Back up Configuration by TFTP and HTTP.** Retrieving device configuration files from devices and save them to the local hard disk.
 - **Restore Configuration by TFTP and HTTP.** Restoring saved device configuration files to devices.
- **Event Logging.** The result of each network management command is shown in a log window, and it can be optionally saved to the hard disk for later reference.

NOTE: EliteConnect Management Utility fully supports SMC2582W-B and SMC2586W-G Wireless Bridges while “Check Alive” function is only supported in SMC2682W.

4.2 Tutorial

Before getting started with this tutorial, you have to install EliteConnect Management Utility by running the setup program on a PC and prepare an SMC2582W-B EliteConnect 802.11b Wireless Bridge or SMC2586W-G EliteConnect 802.11g Wireless Bridge.

Overview

User Interface




Fig. 60 Main user interface.

The main user interface of EliteConnect Management Utility is three-paneled. The upper right pane is the Device List View, which shows the devices to manage. The upper left pane is the Workspace Window, which enables you to filter the active device list or switch to another device list. The bottom pane is the History Log View.

EliteConnect Management Utility is equipped with a menu bar and two toolbars for functions such as device list editing, device management. In addition, when you right click anywhere in the active device list, a shortcut menu will appear for you to quickly carry out commands.

How Does It Work?

EliteConnect Management Utility communicates with the SMC Wireless Bridges by HTTP. A network management command calls CGI (Common Gateway Interface) functions on a selected device to configure the device and get status information from it. Network batch commands are implemented by using multithreading techniques, thus, a click-and-go- style of device management can be achieved.

Connecting the Managing PC and a Managed Device

You need at least one SMC2582W-B EliteConnect 802.11b Wireless Bridge or SMC2586W-G EliteConnect 802.11g Wireless Bridge to follow the remainder of the tutorial. Connect the PC on which EliteConnect Management Utility will run and the device with Ethernet. And then, configure the IP address of the PC and of the device so that they are in the same IP subnet.

Running SMC EliteConnect™ Management Utility



Fig. 61 SMC EliteConnect™ Management Utility in the Program Files folder.

Click the **Start** button, point to **Program Files**, point to the **SMC EliteConnect Management Utility** folder, and click the **SMC EliteConnect Management Utility** icon to run EliteConnect Management Utility. A new device list file will be created when the main user interface of EliteConnect Management Utility appears.

The **New** command on the **File** menu enables you to create device list files. The **Open** command on the **File** menu enables you to open existing device list files.

Building a Device List

Adding a New Device

On the Insert menu, click New Device, and then a new device item is added to the device list and the Device Properties dialog box appears for you to enter device properties.

The **Deployment** and **Identification** groups of properties and the **Comments** property are optional for annotation purposes. You have to specify either **IP address or Domain** name and Port so that EliteConnect Management Utility knows how to communicate with the device. Enter the **IP address** of the SMC2582W-B or SMC2586W-G you use for this tutorial. Use 0 or 80 as the port number. The 0 port will be converted to 80 internally by EliteConnect Management Utility. Then click **Apply**. After that, you will notice the changes you have made in the device list.

Properties of Device 5

Deployment
 Project: Chain Restaurant 2
 Zone 1: New York
 Location: Avenue 38
 Zone 2: Area 2

Identification
 Device ID: AG021
 Device name: AG_NV_AV38

Addressing
 IP address: 210.62.11.208
 Port: 0
 Domain name:
 MAC address:

Comments
 On the wall.

Device/network command status
 Firmware version:
 Model:
 Status:
 Up time:

New Device Previous Next Apply Cancel

Fig. 62 **Device Properties** dialog box.

On the left side of the title bar of the **Device Properties** dialog box is a “Pin” button . Click this button to pin the dialog box (the icon will be changed to ) so that it will always stay on top of other windows. Otherwise, the **Device Properties** dialog box disappears if you click anywhere outside of the dialog box.

Clicking **New Device** adds a new item to the device list. You can repeat this procedure several times to add more items to the device list.

Viewing and Editing Device Properties

If there are a number of device items in the device list. You can click the **Previous** or **Next** button of the **Device Properties** dialog box to navigate the device list and see the properties of each device. As an alternative, you can click any device item in the device list to see its properties when the **Device Properties** dialog box is “pinned.”

If the **Device Properties** dialog box is not shown, you can see the properties of a selected device by carrying out the **Properties** command on the View menu.

The properties of a device can be edited in the **Device Properties** dialog box. Be sure to click **Apply** for your changes to take effect.

Editing the Device List



Fig. 63 Edit menu.

Select the desired device item from the device list. You can select consecutive device items by clicking while holding the Shift key. And you can select inconsecutive device items by clicking while holding the Ctrl key. The Select All command on the Edit menu enables you to select all devices in the device list.

Selected device items can be deleted, cut or copied to the Clipboard. Device items cut or copied to the Clipboard can be pasted back to the device list. These operations can be performed by carrying out the corresponding commands on the Edit menu.

Viewing the Device List

Viewing All Opened Device List Files



Fig. 64 All opened device list files.

If several device list files are opened, you can switch between them by clicking the corresponding tree items on the **File** tab of the **Workspace** window. For example, in Fig. 64, the sample device list file installed by the setup program

of EliteConnect Management Utility and an empty new device list file have been opened.

Filtering the Device List

Workspace	Status	Project	Zone 1	IP Address	Port
[-] All	1	Chain Restaurant 1	New York	210.62.11.110	80
[-] Chain Restaurant 1	3	Chain Restaurant 1	New York	210.62.11.120	80
[-] Los Angeles	4	Chain Restaurant 1	New York	210.62.11.121	80
[-] New York					
[-] Chain Restaurant 2					
[-] New York					
[-] San Jose					
[-] Chain Restaurant 3					
[-] Salt Lake City					
[-] San Jose					

Fig. 65 Filter View of the Workspace window.

You can filter a device list by clicking a tree item on the Filter tab of the Workspace window. The tree hierarchy represents filtering criteria. Clicking the “All” tree item (level 0–no filtering) shows all devices in the device list. A level-1 tree item represents filtering by Project. A level-2 tree item represents filtering by Geographical Zone 1. A level-3 tree item represents filtering by Geographical Zone 2. A level-4 tree item represents filtering by Firmware version.

For example, Fig. 65 illustrates that the sample device list is filtered so that only the devices that belong to the “Chain Restaurant 1” project and deployed in “New York” are shown in the Device List View.

NOTE: You cannot edit properties of any device when the device list is filtered.

Sorting the Device List

The device list can be sorted by clicking a column header of the Device List View. For example, if you click the IP Address header, the device list will be sorted in an ascending order by IP address, as shown by Fig. 66.

IP Address	
210.62.11.110	
210.62.11.120	
210.62.11.121	
210.62.11.208	
210.62.11.208	
210.62.12.35	
210.62.18.35	
210.62.21.11	
210.63.12.208	
210.65.11.110	

Fig. 66 Sorting by IP address, in ascending order.

Clicking the **IP Address** header one more time sorts the device list in a descending order, as shown by Fig. 67.

IP Address	
210.62.11.110	
210.62.11.120	
210.62.11.121	
210.62.11.208	
210.62.11.208	
210.62.12.35	
210.62.18.35	
210.62.21.11	
210.63.12.208	
210.65.11.110	

Fig. 6. Sorting by IP address, in descending order.

NOTE: If a newly opened device list file is sorted, an asterisk mark "*" will be added to the file name shown in the title bar of EliteConnect Management Utility, which means the contents of the device list file have been modified.

Rearranging the Column Order

	Status	Zone	Project	Zone 1	IP Address	Port
1			Chain Restaurant 1	New York	210.62.11.110	80
2			Chain Restaurant 2	New York	210.65.11.110	80
3			Chain Restaurant 1	New York	210.62.11.120	80
4			Chain Restaurant 1	New York	210.62.11.121	80
5			Chain Restaurant 2	New York	210.62.11.208	80
6			Chain Restaurant 2	San Jose	210.62.21.11	80
7			Chain Restaurant 1	Los Angeles	210.62.11.208	80
8			Chain Restaurant 3	Salt Lake City	210.63.12.208	80
9			Chain Restaurant 1	Los Angeles	210.62.12.35	80
10			Chain Restaurant 3	San Jose	210.62.18.35	80

Fig. 68 Rearranging the column order by a drag-and-drop operation.

The column order can be rearranged by drag-and-drop operations. Just drag a column header and drop it to another position. For example, as shown in Fig. 68, the Zone 1 column will be inserted between the Status and the Project columns after the drag-and-drop operation is completed.

Showing or Hiding Some Columns




Fig. 69 Showing or hiding some device list columns.

Any device list columns can be hidden by clearing corresponding check boxes next to the menu items of the Columns sub-menu of the View menu. Clicking an unchecked menu item shows its corresponding device list column, and the menu item becomes checked next time you open the Columns sub-menu.

Managing Devices

After selecting one or more devices in the device list, you can carry out the device management commands on the Device menu to manage the selected device(s). The following sub-sections give two examples. Need a new picture, the new utility does not have the change radius server option.




Fig. 70 Device menu.

Checking Whether Devices Are Alive

Select the device item in the device list, which you have created in the **Adding a New Device** Section for your SMC2582W-B or SMC2586W-G, and then carry out the **Check Alive** command on the De-vice menu. The **User Name and Password** dialog box will appear.



Fig. 71 User Name and Password dialog box.

After EliteConnect Management Utility gets the administration credential, it tries to communicate with the device to check whether it is working. The progress will be shown in the History Log View. The results of the management command will be shown in the Status column of the device list as well as the History Log View.

If the Status column shows “Alive,” the **MAC Address**, **Firmware**, **Up Time**, and **Model** columns also show system information about the device.




Fig. 72 History Log View.

Configuring a Device by Web Browser

Select the device item in the device list, which represents the SMC2582W-B or SMC2586W-G you use for this tutorial, and then carry out the **Configure by Web Browser** command on the **Device** menu. The default Web browser will be launched for you to manage the device.

4.3 Using SMC EliteConnect™ Management Utility

This chapter provides more detailed explanations of the EliteConnect Management Utility functionalities.

User Interface Overview

Main User Interface




Fig. 73 Main user interface.

The main user interface of EliteConnect Management Utility consists of three-paned. The upper right pane is the Device List View, which shows the devices to manage. The upper left pane is the Workspace Window, which enables you to filter the active device list or switch to another device list. The bottom pane is the History Log View. In addition, EliteConnect Management Utility is equipped with a menu bar and two toolbars for functions such as device list editing and device management.

[illegible]

The Device List View provides a view for the active device list file. There are 12 columns, including Device ID, Project, Zone 1, Zone 2, Location, Device Name, IP Address, Do-main Name, HTTP Port, Comments, MAC Address, Firmware, Status, Up Time, and Model. Each column shows a property of a device (see “Viewing and Editing Properties of a Device” Section on page 79 for more information).

Workspace Window

Filter View



Fig. 75 Filter View.

EliteConnect Management Utility analyses the structure of the devices items in the active device list and shows the results in a tree fashion on the **Filter** tab of the **Workspace** window. The active device list can be filtered by clicking a tree item (see Section 4.3.3.6 for more information).

File View




Fig. 76 File View.

The File tab of the **Workspace** window lists all opened device list files so that you to quickly switch between them (see “Viewing All Opened Device List Files” Section on page 81 for more information).

History Log View




Fig. 77 History Log View.

The History Log View shows progress and results of network management commands. The contents of the History Log View can also be saved to a log file for later reference (see “Logging Options” Section on page 75 for more information).

Menu

Carrying out the menu commands can access the majority of EliteConnect Management Utility functionalities. The following menu commands are provided if at least one device list file is opened:

- **File**
 - **New.** Create a new document.
 - **Open.** Open a new document.

- **Close.** Close the active document.
- **Save.** Save the active document.
- **Save As.** Save the active document with a new name.
- **Print.** Print the active document.
- **Print Preview.** Display full pages.
- **Print Setup.** Change the printer and printing options.
- **Send.** Send the active document through electronic mail.
- **Shortcuts** to up to 4 MRU (Most Recently Used) files.
- **Exit.** Quit the application; prompts to save documents.
- **Edit**
 - **Undo.** Undo the last action.
 - **Redo.** Redo the previously undone action.
 - **Cut.** Cut the selection and put it on the Clipboard.
 - **Copy.** Copy the selection and put it on the Clipboard.
 - **Paste.** Insert Clipboard contents.
 - **Delete.** Delete the selection.
 - **Select All.** Select the entire document.
- **View**
 - **Columns.** Show or hide the device list columns.
 - **Clear History.** Clear contents of the History Log View.
 - **Toolbars.** Show or hide the toolbars.
 - **Status Bar.** Show or hide the status bar.
 - **Workspace.** Show or hide the Workspace window.
 - **History.** Show or hide the History window.
 - **Properties.** Show the first selected item's properties.
- **Insert**
 - **New Device.** Add a new device to the active device list.
- **Device**
 - **Check Alive.** Check whether the selected devices are alive.

- **Configure by Web Browser.** Launch the default Web browser to configure the first selected device.
- **Change SSID.** Change the SSID setting of selected device.
- **Change Password.** Change the password setting of selected device.
- **Upgrade Firmware by TFTP.** Upgrade the firmware of selected device by TFTP.
- **Back up Configuration by TFTP.** Back up the configuration of selected device to a file by TFTP.
- **Restore Configuration by TFTP.** Restore the configuration of selected device from a file by TFTP.
- **Upgrade Firmware by HTTP.** Upgrade the firmware of selected device by HTTP.
- **Back up Configuration by HTTP.** Back up the configuration of selected device to a file by HTTP.
- **Restore Configuration by HTTP.** Restore the configuration of selected device from a file by HTTP.
- **Cancel Waiting Commands.** Cancel all waiting device management commands (see Section 4.3.4.1.2 for more information).
- **Tools**
 - **Options.** Change application options.
- **Window**
 - **Cascade.** Arrange windows so they overlap.
 - **Title.** Arrange windows as non-overlapping tiles.
 - **Arrange Icons.** Arrange icons at the bottom of the window.
- **Help**
 - **About.** Display EliteConnect Management Utility version number and copy right information.

Shortcut Menu




Fig. 78 Shortcut menu

Right clicking anywhere within the Device List View brings up a shortcut menu as shown in Fig. 78 The commands on the shortcut menu are short-cuts to some of the main menu commands.

- **Cut**–Cut command on the **Edit** menu
- **Copy**–Copy command on the **Edit** menu.
- **Paste**–Paste command on the **Edit** menu.
- **Delete**–Delete command on the **Edit** menu.
- **Select All**–Select All command on the **Edit** menu.
- **Add New Device**–New Device command on the **Insert** menu.
- **Check Alive**–Check Alive command on the **Device** menu.
- **Configure by Web Browser**–Configure by Web Browser command on the **Device** menu.
- **Change SSID**–Change SSID command on the **Device** menu.
- **Change Password**–Change Password command on the **Device** menu.
- **Back up Configuration by TFTP**–Back up Configuration by TFTP command on the **Device** menu.
- **Restore Configuration by TFTP**–Restore Configuration by TFTP command on the **Device** menu.
- **Back up Configuration by HTTP**–Back up Configuration by HTTP

command on the **Device** menu.

- **Restore Configuration by HTTP–Restore Configuration by HTTP** command on the **Device** menu.
- **Properties–Properties** command on the **View** menu.

Toolbars

Toolbar commands are shortcuts to some of the main menu commands. There are two tool-bars–Basic and Device.



Fig. 79 Basic toolbar.

The commands in the Basic toolbar (from left to right) are listed as follows:

- New on the **File** menu.
- Open on the **File** menu.
- Save on the **File** menu.
- Cut on the **Edit** menu.
- Copy on the **Edit** menu.
- Paste on the **Edit** menu.
- Delete on the **Edit** menu.
- Undo on the **Edit** menu.
- Redo on the **Edit** menu.
- Print on the **File** menu.
- About on the **Help** menu.

Device



Fig. 80 Device toolbar.

The commands in the Device toolbar (from left to right) are listed as follows:

- Properties on the **View** menu.
- New Device on the **Insert** menu.

- Check Alive on the **Device** menu.
- Configure by Web Browser on the **Device** menu.
- Change Password on the **Device** menu.
- Change SSID on the **Device** menu.
- Change RADIUS Servers on the **Device** menu.
- Upgrade Firmware by TFTP on the **Device** menu.
- Back up Configuration by TFTP on the **Device** menu.
- Restore Configuration by TFTP on the **Device** menu.
- Upgrade Firmware by HTTP on the **Device** menu.
- Back up Configuration by HTTP on the **Device** menu.
- Restore Configuration by HTTP on the **Device** menu.

Customizing Your Working Environment

EliteConnect Management Utility window layout and application behavior can be customized to your preference.

Showing, Hiding, Docking, Floating, and Repositioning View Windows

The toolbars, status bar, Workspace window, and the History Log View window can be docked to the top, bottom, left, or right side of the main window. And they can be shown or hidden by carrying out corresponding commands on the **View** menu.

You can double-click the title bar of the Workspace window or the History Log View window in docked state to make it “float”. Double-clicking a floating window restores the window to its previous dock state. You can click and hold the title bar of a window, and then drag the window to dock it to another place. In this way, the layout of EliteConnect Management Utility windows can be freely customized. For example, EliteConnect Management Utility can be re-laid out like Fig. 82

	Status	Project	Zone 1	IP Address	Port	Device ID
1		Chain Restaurant 1	New York	210.62.11.110	80	AG001
2		Chain Restaurant 2	New York	210.65.11.110	80	AG013
3		Chain Restaurant 1	New York	210.62.11.120	80	AG002
4		Chain Restaurant 1			80	AG003
5		Chain Restaurant 2			80	AG021
6		Chain Restaurant 2			80	AG102
7		Chain Restaurant 1			80	AG004
8		Chain Restaurant 3			80	AG014
9		Chain Restaurant 1			80	AG005
10		Chain Restaurant 3			80	AG080

Workspace

All

Chain Restaurant 1

Los Angeles

New York

Chain Restaurant 2

New York

San Jose

Chain Restaurant 3

Salt Lake City

San Jose

Filter File

Fig. 81 Floating Workspace window.

SMC EliteConnect Management Utility - [ChainRestaurantProjects.dll]

File Edit View Insert Device Tools Window Help

Workspace

All

Chain Restaurant 1

Los Angeles

New York

Chain Restaurant 2

New York

San Jose

Chain Restaurant 3

Salt Lake City

San Jose

Filter File

	Status	Project	Zone 1
1		Chain Restaurant 1	New York
2		Chain Restaurant 2	New York
3		Chain Restaurant 1	New York
4		Chain Restaurant 1	New York
5		Chain Restaurant 2	New York
6		Chain Restaurant 2	San Jose
7		Chain Restaurant 1	Los Angeles
8		Chain Restaurant 3	Salt Lake City
9		Chain Restaurant 1	Los Angeles
10		Chain Restaurant 3	San Jose

History

Fig. 82 History Log View docked to the right side.

Rearranging the Column Order of the Device List View

	Status	Zone	Project	Zone 1	IP Address	Port
1			Chain Restaurant 1	New York	210.62.11.110	80
2			Chain Restaurant 2	New York	210.65.11.110	80
3			Chain Restaurant 1	New York	210.62.11.120	80
4			Chain Restaurant 1	New York	210.62.11.121	80
5			Chain Restaurant 2	New York	210.62.11.208	80
6			Chain Restaurant 2	San Jose	210.62.21.11	80
7			Chain Restaurant 1	Los Angeles	210.62.11.208	80
8			Chain Restaurant 3	Salt Lake City	210.63.12.208	80
9			Chain Restaurant 1	Los Angeles	210.62.12.35	80
10			Chain Restaurant 3	San Jose	210.62.18.35	80

Fig. 83 Rearranging the column order by a drag-and-drop operation.

The column order can be rearranged by drag-and-drop operations. Just drag a column header and drop it to another position. For example, as shown in Fig. 83, the Zone 1 column will be inserted between the Status and the Project columns after the drag-and-drop operation is completed.

Showing or Hiding the Columns of the Device List View




Fig. 84 Showing or hiding some device list columns.

Any device list columns can be hidden by clearing corresponding check boxes next to the menu items of the **Columns** sub-menu of the **View** menu. Clicking an unchecked menu item shows its corresponding device list column and the menu item becomes checked next time you open the **Columns** sub-menu.

Configuring the Application Behavior

On the **Tools** menu, click **Options**, and then the **Options** dialog box appears. In this dialog box, you can configure EliteConnect Management Utility's behavior.

General Options



Fig. 85 General tab.

On this tab, you can specify the action taken when a device item in the active device list is double-clicked, the number of simultaneous device management commands, and whether the Device Password List function will be enabled.

There are two options for the action taken when a device item is double-clicked—**Launches the default Web browser to configure the device** or **Shows the device's properties (default)**. Except the **Configure by Web Browser** command, all other device management commands on the **Device** menu are “batch” commands that can be applied to several devices at a time. When a batch menu command is carried out, one internal command data structure is generated for each selected device and inserted into a “work queue.” For example, if 50 devices have been selected and a batch command is carried out, there will be 50 device management commands inserted into the queue. And then, first *n* commands are extracted from the queue for execution, where *n* is specified by the **Number of simultaneous device management commands** box, and other commands in the queue are put to waiting state. After one in-action command is completed, another command in the queue is extracted and put to execution. This process continues until all commands in the queue are completed.

Since a username and password pair is needed for EliteConnect Management Utility to communicate with each device, you are, by default, prompted to enter the credential information at the start of a batch device management command. As an alternative, you can build a Device Password List and let EliteConnect Management Utility use the list instead of prompting you every time.

A device password list is a text file with the “.plt” file name extension. And its format is as Fig. 86 shows. The username and password in each text line must be separated by a comma.

```
admin,smcadmin  
xyzadmin,smcpwd  
wireless,wirelesscool
```

Fig. 86 A sample Device Password List.

Select the **Use the following Device Password List instead of asking for device user name and password** check box, and specify the location of the device password list file by clicking the “...” button.

Logging Options




Fig. 87 Logging tab.

On this tab, you can specify whether the contents of the History Log View are also saved to a log file.

To enable logging to a file, select the Enable logging events to a text file check box and then the location of the log file will be shown in the Log file box.

NOTE: The View button is disabled if the log file has not been created by EliteConnect Management Utility. Otherwise, you can click the button to view the contents of the log file.

TFTP Server Options




Fig. 88 TFTP Server tab.

On this tab, you can configure behavior parameters of EliteConnect Management Utility's built-in TFTP server for device firmware upgrade. EliteConnect Management Utility supports a "pull" style and a "push" style of device firmware upgrade. The pull style is achieved by HTTP and TFTP, while the push style is solely achieved by HTTP. The pull style works like the following:

1. EliteConnect Management Utility issues an HTTP command to the device to trigger the firmware upgrade process.
2. The device's TFTP client downloads (pulls) firmware files from the built-in TFTP server of EliteConnect Management Utility.
3. EliteConnect Management Utility polls the device to check the results of the firmware upgrade by HTTP.

In the push style of firmware upgrade, EliteConnect Management Utility use HTTP to upload (push) firmware files to the device's built-in Web server. Device configuration backup and restore are similar to firmware upgrade. The TFTP-related configuration backup/restore procedure is like the following:


1. EliteConnect Management Utility issues an HTTP command to the device to trigger the configuration backup process.
2. If for backup, the device's TFTP client uploads configuration files to the built-in TFTP server of EliteConnect Management Utility. If for restore, the device's TFTP client downloads configuration files from EliteConnect Management Utility's TFTP server.
3. EliteConnect Management Utility polls the device to check the results of the configuration backup/restore by HTTP.

For solely HTTP-based configuration backup/restore, EliteConnect Management Utility communicates with the device's built-in Web server to download or upload configuration files.

For configuration backup by TFTP to succeed, the **Accept write requests** check box must be selected. For configuration restore and firmware upgrade by TFTP to succeed, the **Accept read requests** must be selected. Configure the **Timeout** and **Max no of retries** based on the communication characteristics between EliteConnect Management Utility and the managed devices. Experiments may be needed to find out appropriate values for these parameters.

Clicking **Reset to Defaults** resets the settings on this tab to default values.

HTTP Options



General	Logging	TFTP Server	HTTP
Connect retries: 1			
Connect timeout: 2 sec			
Receive timeout: 2 sec			
Send timeout: 2 sec			
<button>Reset to Defaults</button>			

Fig. 89 HTTP tab.

On this tab, you can configure behavior parameters of EliteConnect Management Utility's Web client engine—Microsoft Internet Explorer control. You may refer to Microsoft documentation about how to pick good values for **Connect retries**, **Connect timeout**, **Receive timeout**, and **Send timeout**. Experiments are helpful in determining values for these parameters.

Clicking **Reset to Defaults** resets the settings on this tab to default values.


Working with Device Lists

A device list file is designated with the “.dlt” file name extension. Each device item in a device list contains information about the device's properties.

Manipulating Device List Files

The **New**, **Close**, **Open**, **Save**, and **Save As** commands and MRU (Most Recently User) file shortcuts on the **File** menu enable you to perform corresponding file operations to device list files.

Adding a New Device to the Active Device List



Properties of Device 5	
Deployment	
Project:	Chain Restaurant 2
Zone 1:	New York
Location:	Avenue 38
Zone 2:	Area 2
Identification	
Device ID:	AG021
Device name:	AG_NY_AV38
Addressing	
IP address:	210.62.11.208
Port:	0
Domain name:	
MAC address:	
Comments	
On the wall.	
Device/network command status	
Firmware version:	Model:
Status:	Up time:
<button>New Device</button> <button>Previous</button> <button>Next</button> <button>Apply</button> <button>Cancel</button>	

Fig. 90 Device Properties dialog box.

To add a new device item to the active device list, click **New Device** on the Insert menu. And then a new device item is added to the device list and the **Device Properties** dialog box appears for you to enter device properties.

The **Deployment** and **Identification** groups of properties and the **Comments** property are optional for annotation purposes. You have to specify either **IP address** or **Domain name** and **Port** so that EliteConnect Management Utility knows how to communicate with the de-vice. Click **Apply** for your changes to take effect. The changes will be immediately reflected in the device list.

EliteConnect Management Utility automatically fills the properties in the Device/network command status group after successful **Check Alive** command execution.

On the left side of the title bar of the **Device Properties** dialog box is a “Pin”  button. Click this button to pin the dialog box (the icon will be changed to ) so that it will always stay on top of other windows. Otherwise, the **Device Properties** dialog box disappears if you click anywhere outside of the dialog box.

Clicking **New Device** adds a new device item to the device list. You can repeat this procedure several times to add more device items to the device list.

Selecting Devices

Click on the selected device. Three types of selection are supported—single selection, multiple consecutive selections, and multiple inconsecutive selections.

Single Selection

	Status	Project	Zone 1	IP Address	Port
1		Chain Restaurant 1	New York	210.62.11.110	80
2		Chain Restaurant 2	New York	210.65.11.110	80
3		Chain Restaurant 1	New York	210.62.11.120	80
4		Chain Restaurant 1	New York	210.62.11.121	80
5		Chain Restaurant 2	New York	210.62.11.208	80
6		Chain Restaurant 2	San Jose	210.62.21.11	80
7		Chain Restaurant 1	Los Angeles	210.62.11.208	80
8		Chain Restaurant 3	Salt Lake City	210.63.12.208	80
9		Chain Restaurant 1	Los Angeles	210.62.12.35	80
10		Chain Restaurant 3	San Jose	210.62.18.35	80

Fig. 91 Single selection.

Click a device item to select it. A selected device item is highlighted.

Multiple Consecutive Selections

	Status	Project	Zone 1	IP Address	Port
1		Chain Restaurant 1	New York	210.62.11.110	80
2		Chain Restaurant 2	New York	210.65.11.110	80
3		Chain Restaurant 1	New York	210.62.11.120	80
4		Chain Restaurant 1	New York	210.62.11.121	80
5		Chain Restaurant 2	New York	210.62.11.208	80
6		Chain Restaurant 2	San Jose	210.62.21.11	80
7		Chain Restaurant 1	Los Angeles	210.62.11.208	80
8		Chain Restaurant 3	Salt Lake City	210.63.12.208	80
9		Chain Restaurant 1	Los Angeles	210.62.12.35	80
10		Chain Restaurant 3	San Jose	210.62.18.35	80

Fig. 92 Multiple consecutive selections.

To select a block of consecutive device items:

1. Click the first item of the block.
2. Click the last item of the block while holding the Shift key.

Multiple Inconsecutive Selections

	Status	Project	Zone 1	IP Address	Port
1		Chain Restaurant 1	New York	210.62.11.110	80
2		Chain Restaurant 2	New York	210.65.11.110	80
3		Chain Restaurant 1	New York	210.62.11.120	80
4		Chain Restaurant 1	New York	210.62.11.121	80
5		Chain Restaurant 2	New York	210.62.11.208	80
6		Chain Restaurant 2	San Jose	210.62.21.11	80
7		Chain Restaurant 1	Los Angeles	210.62.11.208	80
8		Chain Restaurant 3	Salt Lake City	210.63.12.208	80
9		Chain Restaurant 1	Los Angeles	210.62.12.35	80
10		Chain Restaurant 3	San Jose	210.62.18.35	80

Fig. 93 Multiple inconsecutive selections.

To select several inconsecutive device items:

1. Click the first item.
2. Click other items while holding the Ctrl key.

Viewing and Editing Properties of a Device

Single-select a device item and click Properties on the View menu, and then the Device Properties dialog box will appear for you to view or edit the properties of the device.

You can click the Previous or Next button of the Device Properties dialog box to navigate the device list and see the properties of each device. As an alternative, you can click any device item in the device list to see its properties when the Device Properties dialog box is “pinned.”

NOTE: Be sure to click Apply for your changes to take effect.

NOTE: You cannot edit properties of any device when the device list is filtered (see Section 4.3.3.6 for more information).

Editing the Device List



Fig. 94 Edit menu.

You can use the commands on the **Edit** menu to edit the active device list. Refer to Section 4.3.1.5 for explanations of the commands.

Filter the Device List

A screenshot of a software application's 'Workspace' window. On the left is a tree view showing a hierarchy of folders: 'All', 'Chain Restaurant 1' (expanded), 'Los Angeles', 'New York' (selected), 'Chain Restaurant 2', 'New York', 'San Jose', 'Chain Restaurant 3', 'Salt Lake City', and 'San Jose'. On the right is a table with columns: 'Status', 'Project', 'Zone 1', 'IP Address', and 'Port'. The table contains three rows of data, all filtered to show devices from 'Chain Restaurant 1' in 'New York'.

	Status	Project	Zone 1	IP Address	Port
1		Chain Restaurant 1	New York	210.62.11.110	80
3		Chain Restaurant 1	New York	210.62.11.120	80
4		Chain Restaurant 1	New York	210.62.11.121	80

Fig. 95 Device list filtering.

You can filter a device list by clicking a tree item on the Filter tab of the Workspace window. The tree hierarchy represents filtering criteria. Clicking the "All" tree item (level 0—no filtering) shows all devices in the device list. A level-1 tree item represents filtering by Project. A level-2 tree item represents filtering by Geographical Zone 1. A level-3 tree item represents filtering by Geographical Zone 2. A level-4 tree item represents filtering by Firmware version.

For example, Fig. 95 illustrates that the sample device list is filtered so that only the devices that belong to the "Chain Restaurant 1" project and deployed in "New York" are shown in the Device List View.

Sorting the Device List

The active device list can be sorted by clicking a column header of the Device List View. For example, if you click the IP Address header, the device list will be sorted in ascending order by IP address, as shown by Fig. 96

IP Address
210.62.11.110
210.62.11.120
210.62.11.121
210.62.11.208
210.62.11.208
210.62.12.35
210.62.18.35
210.62.21.11
210.63.12.208
210.65.11.110

Fig. 96 Sorting by IP address, in ascending order.

Clicking the **IP Address** header one more time sorts the device list in descending order, as shown by Fig. 97.

IP Address
210.65.11.110
210.63.12.208
210.62.21.11
210.62.18.35
210.62.12.35
210.62.11.208
210.62.11.208
210.62.11.121
210.62.11.120
210.62.11.110

Fig. 97 Sorting by IP address, in descending order.

NOTE: If a newly opened device list file is sorted, an asterisk mark "*" will be added to the file name shown in the title bar of EliteConnect Management Utility, which means the contents of the device list file have been modified.

Viewing All Opened Device List Files




Fig. 98 Viewing all opened device list files.

You can switch between all opened device list files by clicking the corresponding tree items on the File tab of the Workspace window.

Arranging Device List Windows

The commands on the **Window** menu enable you to arrange your Device List View window and switch between them.




Fig. 99 Window menu.

Cascading Windows




Fig. 100 Cascaded device list windows.

The **Cascade** command on the **Window** menu arranges the Device List View windows so that they overlap.

Tiling Windows




Fig. 101 Tiled windows.

The **Tile** command on the **Window** menu arranges the Device List View windows as non-overlapping tiles.

Arranging Minimized Windows



Fig. 102 Minimized windows put in order.

The **Arrange Icons** command on the **Window** menu arranges minimized Device List View windows so that they stay at the bottom.

Managing Devices

Except the **Configure by Web Browser** command, all other device management commands on the **Device** menu are “batch” commands that can be applied to several devices at a time. (Refer to Section 4.3.2.4.1 for more information about what “batch” means.)

Carrying out a Batch Management Command

The procedure for carrying out each batch device management command is described below:

1. Select one or more devices in the active device list.
2. Click a batch command on the **Device** menu.
3. If the Device Password List functionality is not enabled, you will be prompted to enter a user name and password for accessing the device (see Section 4.3.2.4.1 for more in-formation).



Fig. 103 User Name and Password dialog box.

4. Enter username and password when prompted.
5. Monitor the progress of the command in the History Log View.
6. See the results of the command in the History Log View and in the Status column of the Device List View.

NOTE: You have to make sure a device is reachable by EliteConnect Management Utility through the IP address/domain name and port specified in the device list.

Canceling Batch Command Execution




Fig. 104 Cancel Waiting Commands menu command.

When a network batch command is in execution, you can click **Cancel Waiting Commands** on the **Device** menu to cancel all commands waiting in EliteConnect Management Utility's work queue.

After the currently in-action commands complete or fail, all waiting commands are canceled.

NOTE: Depending on the HTTP behavior parameters specified on the HTTP tab of the Options dialog box, you may wait a long period before the waiting commands are canceled (see "HTTP Options" Section on page 77 for more information).

Checking Whether Devices Are Alive

To check whether the selected devices are alive, carry out the **Check Alive** command.

If the Status column shows "Alive" after the device management command is completed, the **MAC Address**, **Firmware**, **Up Time**, and **Model** columns also show system information about the device.

Configuring a Device by Web Browser

To configure the selected device by Web browser, carry out the **Configure by Web Browser** command.

Changing the SSID Setting of Devices

To change the SSID setting of selected device, carry out the **Change SSID** command. You'll be prompted to specify the new SSID.



Fig. 105 Changing SSID dialog box.

Changing the Administration User Name and Password of Devices

To change the administration user name and password settings of every selected device, carry out the Change Password command.

If the Device Password List functionality is disabled, the **Changing User Name and Password** dialog box will appear asking you to enter the **Current admin. user name**, **Current admin. password**, **New user name**, and **New password**.



Fig. 106 Changing User Name and Password dialog box if not using a Device Password List.

The **User type** option is for future models that have different users with different access rights. (SMC2582W-B and SMC2586W-G don't support multiple administration user name/password pairs.)

If the Device Password List functionality is disabled, **Current admin. user name** and **Current admin. password**, **New user name** will not be shown in the Changing User Name and Password dialog box.



Fig. 107 Changing User Name and Password dialog box if using a Device Password List.

Changing the RADIUS Server Setting of Devices

To change the RADIUS server settings of every selected device, carry out the **Change RADIUS Servers** command. You'll be prompted to enter the **Primary RADIUS server** and **Secondary RADIUS server**.




Fig. 108 Changing RADIUS Servers dialog box.

The WPA (Wi-Fi Protected Access) standard uses IEEE 802.1x Port-Based Network Access Control and RADIUS (Remote Authentication Dial-In User Service) for advanced WLAN security.

Managing Device Firmware by TFTP

To manipulate firmware and configuration files of every selected device by TFTP, carry out the various By-TFTP commands. You'll be prompted to enter the IP address of the TFTP server (most of the time, specify the IP address of the computer on which EliteConnect Management Utility runs) and specify the folder containing or to contain the files. Refer to Section 4.3.2.4.3 for more information.



Fig. 109 TFTP Server dialog box.

Upgrading Device Firmware

Carry out the Upgrade Firmware by TFTP command.

Backing up Device Configuration

Carry out the Back up Configuration by TFTP command.

Restoring Device Configuration

Carry out the Restore Configuration by TFTP command.

Managing Device Firmware by HTTP

To manipulate firmware and configuration files of every selected device by HTTP, carry out the various By-HTTP commands. You'll be prompted to specify the folder containing or to contain the files. Refer to Section 4.3.2.4.3 for more information.

Upgrading Device Firmware

Carry out the Upgrade Firmware by HTTP command.

Backing up Device Configuration

Carry out the Back up Configuration by HTTP command.

Restoring Device Configuration

Carry out the Restore Configuration by HTTP command.

Printing the Active Device List

To print the active device list, carry out the Print command on the File menu. And you can preview the pages that will be printed by carrying out the Print Preview command.

Sending the Active Device List to Others by E-mail

The active device list can be sent to others by e-mail. Click Send on the File menu to do this.

Appendix A: Default Settings

TIP: Press the **Default** button on the powered-on SMC2586W-G to reset the configuration settings to factory-default values.

Setting Name	Default Value
Global	
User Name	admin
Password	smcadmin
Host Name	SMC2586W-G
IEEE 802.11g	
Operational Mode	Access Point
Policy	Mixed (Both IEEE 802.11b- and IEEE 802.11g-based wireless clients are supported.)
Regulatory Domain	FCC (U.S.) or ETSI (Europe)
Channel Number	6
SSID	SMC
SSID Broadcasts	Enabled
Transmission Rate	Auto
Transmit Power	High
MAC Address	See the label on the housing of the SMC2586W-G.
Security Mode	Open System
WEP Key Length	64 Bits
Selected WEP Key	Key #1
WEP Key #1	00-00-00-00-00
WEP Key #2	00-00-00-00-00
WEP Key #3	00-00-00-00-00
WEP Key #4	00-00-00-00-00
MAC-Address-Based Access Control	Disabled
Access Control Table Type	Inclusive
Wireless Client Isolation	Disabled
Link Integrity	Disabled
LAN Interface	
Method of obtaining an IP Address	DHCP Client enabled
IP Address	192.168.2.50 (If a DHCP server cannot be found.)
Subnet Mask	255.255.255.0 (If a DHCP server cannot be found.)
Default Gateway	0.0.0.0
DHCP Server	Disabled
Management	
Web Admin Idle Timeout	5 min
UPnP	Enabled
Device Friendly Name	SMC2586W-G
System Log	Local Log
SNMP	Enabled
SNMP Read Community	public
SNMP Write Community	private
Telnet	Disabled

Appendix B: Troubleshooting

Check the following first:

- Make sure that the power of the SMC2586W-G is on and the Ethernet cables are connected firmly to the RJ-45 jacks of the SMC2586W-G.
- Make sure that the LED ALV of the SMC2586W-G is blinking to indicate the SMC2586W-G is working.
- Make sure the types of the Ethernet cables are correct. Recall that there are two types—straight-through and crossover.

Wireless Settings Problems

- The wireless client computer cannot associate with an SMC2586W-G.
 - Is the wireless client set in infrastructure mode?
 - Check the operating mode of the WLAN NIC.
 - Is the SSID of the WLAN NIC identical to that of the prospective SMC2586W-G?
 - Check the SSID setting of the WLAN NIC and of the SMC2586W-G.
 - Is the WEP functionality of the prospective SMC2586W-G enabled?
 - Make appropriate WEP settings of the client computer to match those of the SMC2586W-G.
 - Is the prospective SMC2586W-G within range of wireless communication?
 - Check the signal strength and link quality sensed by the WLAN NIC.

TCP/IP Settings Problems




Fig. 110. Communication stages for a client to reach its correspondent host.

For a wireless client computer to communicate with a correspondent host on the Internet by the host's domain name (e.g. <http://www.wi-fi.com>), it first sends a DNS request to a DNS server on the Internet. The DNS request travels first to the AP, then the AP relays this request to the default gateway of the client computer. Finally, this request is forwarded by the gateway to the DNS server on the Internet. The DNS reply issued by the DNS server is transmitted back to the client computer following a reverse path. When the client computer receives the DNS reply, it knows the IP address of the correspondent host and sends further packets to this IP address.

As illustrated in Fig. 110, the communication path could be broken at some of the stages. The OS-provided network diagnostic tool, **ping.exe**, can be employed to find out TCP/IP-related communication problems.

NOTE: If two or more NICs are installed and operating on a client computer, TCP/IP may not work properly due to incorrect entries in the routing table. Use the OS-provided command-line network tool, **route.exe**, to add or delete entries from the routing table. Or, use Windows-provided Device Manager to disable unnecessary NICs.

Solve the following problems in order:

- My SMC2586W-G does not respond to ping from the client computer.
 - Are two or more NICs installed on the client computer?
 - Use Windows-provided Device Manager to disable unnecessary NICs.
 - Is the underlying link (Ethernet or IEEE 802.11g) established?
 - Make sure the Ethernet link is OK.
 - Make sure the wireless settings of the wireless client computer and of the SMC2586W-G match.
- Are the IP address of the client computer and the IP address of the SMC2586W-G in the same IP subnet?
 - Use WinIPCfg.exe or IPConfig.exe to see the current IP address of the client computer. Make sure the IP address of the client computer and the IP address of the SMC2586W-G are in the same IP subnet.

TIP: If you forget the current IP address of the SMC2586W-G, use Wireless Router/AP Browser to get the information (see Appendix B-3).use the SMC Scan utility that is on the CD.

- The DNS server(s) of the client computer do not respond to ping from the client computer.
 - Solve the preceding problems first.

- If you cannot find any incorrect settings of the SMC2586W-G, the default gateway of the SMC2586W-G may be really down or there are other communication problems on the network backbone.

Other Problems

- My SMC2586W-G has been set to obtain an IP address automatically by DHCP. How can I know its acquired IP address so that I can manage it using a Web browser?
- Use the SMC2586W-G Scan Utility (WLBwrs.exe), which is included in the SMC2586W-G Installation CD. This utility can discover nearby SMC2586W-Gs and show their MAC addresses and IP addresses. In addition, it can launch the Web browser on your computer.

NOTE: On Windows 2000/XP, SMC2586W-G Scan Utility can only be run by a user with administrator privilege.

NOTE: SMC2586W-G Scan Utility does not scan the SMC2682W.




Fig. 111 SMC2586W-G Configuration Utility.

- My SMC2586W-G stops working and does not respond to Web management requests.
- The firmware of the SMC2586W-G may be stuck in an incorrect state.
 - Unplug the power connector from the power jack, and then re-plug the connector to restart the SMC2586W-G.
 - Contact our technical support representatives to report this problem, If this happens after a failed firmware upgrade process, the firmware of the SMC2586W-G may have been corrupted.
- If the SMC2586W-G still does not work after restarting, there may be hardware component failures in the SMC2586W-G.
 - Contact our technical support representatives for repair.

Appendix C : Distances and Data Rates

Important Notice: Maximum distances posted below are actual tested distance thresholds. However, there are many variables such as barrier composition and construction and local environmental interference that may impact your actual distances and cause you to experience distance thresholds far lower than those we post below. If you have any questions or comments regarding the features or performance of this product, or if you'd like information regarding our full line of wireless products, you can visit us on the web at www.smc.com or you can call us toll-free at 800.SMC.4YOU. SMC Networks stands behind this and every product we sell with a 30 day satisfaction guarantee and with a limited-lifetime warranty.

802.11g Wireless Distance Table							
Environmental Condition	Speed and Distance Ranges						
	54 Mbps	48 Mbps	36 Mbps	24 Mbps	18 Mbps	12 Mbps	6-9 Mbps
Outdoors: A line-of-sight environment with no interference or obstruction between the Access Point and users.	60 m (197 ft)	90 m (295 ft)	150 m (492 ft)	190 m (623 ft)	220 m (722 ft)	270 m (886 ft)	350m (1155 ft)
Indoors: A typical office or home environment with floor to ceiling obstructions between the Access Point and users.	40 m (131 ft)	50 m (164 ft)	60 m (197 ft)	65 m (213 ft)	70 m (230 ft)	110 m (361 ft)	180 m (591 ft)

Appendix D: Technical Specification

SMC2586W-G Wireless Bridge

Standards:

- 802.11b
- 802.11g
- 802.3
- 802.3u
- 802.3af

Data rate & modulation:

- OFDM@54Mbps, CCK@11/5.5Mbps, DQPSK@2Mbps and DBSK@1Mbps

Radio Technology:

- OFDM
- DSSS

Operating Range:

- Up to 1,155 feet

Channels:

- USA: 1-11 (FCC),
- Canada: 1-11 (IC),
- Europe: 1-13 (ETSI),
- France: 10-13
- Japan: 1-13 (Japan)

Frequency range:

- 2.402 ~ 2.472 GHz (North America)
- 2.402 ~ 2.4970 GHz (Japan)
- 2.402 ~ 2.4835 GHz (Europe ETSI)
- 2.4465 ~ 2.4835 GHz (France)

Transmission output Power:

- 18 dBm max

Receiving Sensitivity:

- < -80 dBm, Typical

Antenna:

- Removable Antenna with R-SMA connector

Operational Modes:

- Access Point/Bridge (used in pure SMC2586W-G bridging environment)
- Bridge Master (used when SMC2586W-G, SMC2582W-B, and

SMC2682W are in the Bridging environment)

- Bridge Slave (used when SMC2586W-G, SMC2582W-B, and SMC2682W are in the Bridging environment)

Interface:

- 10/100 Mbps RJ-45 Connector
- RS-232c Serial Connector
- 802.11b/g WLAN

Security:

- 64/128-bit WEP
- 802.1x
- WPA
- MAC address filtering
- Disabled SSID broadcast
- Wireless client isolation

Configuration and Management:

- Web-browser
- Telnet
- TFTP
- SNMP
- Syslog
- Event Logging

LEDs

- Power
- LAN
- WLAN
- Alive

Environmental

- Temperature: Operating (0~55C), storage (-20~70C)
- Humidity: 5% to 95% non-condensing in storage

Electromagnetic Compatibility:

- FCC Class B
- Industry Canada
- CE
- ETS 300.328; ETS 300 826

Power Supply:

- Input: 100VAC 60Hz
- Output: 12VDC, 1A

Dimensions (without antenna):

- 8.5" x 5.5 " x 1.25"

Weight:

- 0.96 lbs

SMCPWR-INJ3 Power Injector**Input Power Requirements**

- AC Input Voltage : 90 - 264Vac
- AC Frequency : 47 - 63 Hz
- AC Input Current : 2A at 100Vac, 1A at 240Vac, (-48Vdc)

Power over LAN output Specification

- Pin Assignments and Polarity: () 4/5 () 7/8
- Output Voltage:
 - Aggregate Power: 50W (48Vdc)

Mechanical Requirement

- Dimensions: 4" x 5.5" x 1.5"
- Weight: 1.38 Lbs

Indicators

- System Indicator:
 - AC Power (Green)
 - Power Active (Red) 0.05 A^oIo^o0.8 A
 - Over Current Protection (Red, Flash) Io^o±1.0 A
- Connectors Shielded Rj-45

Environmental Conditions

- Operating Temperature: 32° to 104° F (0° to 40° C)
- Operating Humidity: Maximum 90% Non-condensing
- Storage Temperature: -13° to 185° F (-25° to 85° C)
- Storage Humidity: Maximum 95%, Non-condensing
- Operating Altitude: -1000 to 10,000 ft. (-304.8 to 3048 m)

Safety Approval

- UL 1950
- CSA A22.2 No. 950
- EN 60950
- CB

Regulatory Compliance

- CE Compliance

Electromagnetic Emission and Immunity

- A. FCC Part 15 Class B

FOR TECHNICAL SUPPORT, CALL:

From U.S.A. and Canada (24 hours a day, 7 days a week)

(800) SMC-4-YOU; Phn: (949) 679-8000; Fax: (949) 679-1481

From Europe : Contact details can be found on

www.smc-europe.com or www.smc.com

INTERNET

E-mail addresses:

techsupport@smc.com

european.techsupport@smc-europe.com

Driver updates:

http://www.smc.com/index.cfm?action=tech_support_drivers_downloads

World Wide Web:

<http://www.smc.com/>

<http://www.smc-europe.com/>

For Literature or Advertising Response, Call:

U.S.A. and Canada:	(800) SMC-4-YOU	Fax (949) 679-1481
Spain:	34-91-352-00-40	Fax 34-93-477-3774
UK:	44 (0) 1932 866553	Fax 44 (0) 118 974 8701
France:	33 (0) 41 38 32 32	Fax 33 (0) 41 38 01 58
Italy:	39 (0) 3355708602	Fax 39 02 739 14 17
Benelux:	31 33 455 72 88	Fax 31 33 455 73 30
Central Europe:	49 (0) 89 92861-0	Fax 49 (0) 89 92861-230
Nordic:	46 (0) 868 70700	Fax 46 (0) 887 62 62
Eastern Europe:	34 -93-477-4920	Fax 34 93 477 3774
Sub Saharan Africa:	216-712-36616	Fax 216-71751415
North West Africa:	34 93 477 4920	Fax 34 93 477 3774
CIS:	7 (095) 7893573	Fax 7 (095) 789 357
PRC:	86-10-6235-4958	Fax 86-10-6235-4962
Taiwan:	886-2-87978006	Fax 886-2-87976288
Asia Pacific:	(65) 238 6556	Fax (65) 238 6466
Korea:	82-2-553-0860	Fax 82-2-553-7202
Japan:	81-45-224-2332	Fax 81-45-224-2331
Australia:	61-2-8875-7887	Fax 61-2-8875-7777
India:	91-22-8204437	Fax 91-22-8204443

If you are looking for further contact information, please visit www.smc.com or www.smc-europe.com.

SMC[®]
Networks

38 Tesla

Irvine, CA 92618

Phone: (949) 679-8000

Model Number: SMC2586W-G