

Wall Mounted Single-Handle Lav Set with Base Plate35115801Wall Mounted Single-Handle Lav Set35116801



35115801

35116801

Technical Data

Max. flow rate:2.2 gpmMax. water pressure:147 psiRecommended pressure:14.7 - 72 psiTest pressure:232 psiMax. hot water temperature:176° F*Recommended hot water temp.:120° F - 140° F*Requires rough 38111181 (not included)For best results, Hansgrohe recommends installation by a licensed, professional plumber.

These units may be used with an instantaneous water heater, as long as the output pressure of the heater is at least 22 psi.

*Know and follow all applicable local codes when setting the temperature on the water heater. In Massachusetts, the water heater may be set no higher than 112°F.

Installation with 38111181 rough manufactured before 03/2004

Turn the water off at the supply before beginning this installation.

Remove the covers from the plaster shields (1).

Trim the plaster shields so that they extend 1/16" outside the surface of the finished wall (2). Seal the wall around the plaster shield with waterproof sealant.

Use a 17 mm socket wrench to remove the spout plug.

Use a 27 mm socket wrench to remove the cartridge assembly. Remove and discard the cup washers and springs.

Remove and discard the cartridge and anti-twist device from the housing. Install the new cartridge and anti-twist device in the housing.







Install the new cup washers and springs in the rough. Install the cartridge assembly.





Installation with 38111181 rough manufactured after 04/2004

Turn the water off at the supply before beginning this installation.

Remove the covers from the plaster shields.

Trim the plaster shields so that they extend 1/16" outside the surface of the finished wall. Seal the wall around the plaster shield with waterproof sealant.



Use a 17 mm socket wrench to remove the spout plug.

Use a 27 mm socket wrench to remove the cartridge housing. Remove and discard the flush insert.



Install the cartridge and anti-twist device in the housing.



Install the cup washers and springs in the rough. Install the cartridge assembly.



Installation with all models:

Push the handle over the cartridge stem. Tighten the handle screw with a 2 mm Allen wrench.

If you are installing 35115801, turn to page 6.

If you are installing 35116801, turn to page 10.



6

If \mathbf{x} is greater than 4 3/8", select the two "C" sleeves (1/2").

If **x** is between 37/8'' - 43/8'', select the two "B" sleeves (7/8").

"A" sleeves (1 1/4").

If \mathbf{x} is between 3 1/4" and 3 7/8", select the two

Measure the distance between the wall surface and

Model 35115801 only:





B

7/8″







the end of the handle (x).

Connect the fixation nuts to the sleeves.



Measure the distance from the rough to the outside surface of the finished wall (X) (1).

Add 1 3/16'' to X. Cut the spout connecting thread so that it is X + 1 3/16'' long (2).





Wrap the connecting thread with Teflon tape. Install the mounting thread. Tighten with an 8 mm Allen wrench.



Push the baseplate against the wall (1).

Thread the sleeves into the rough (2).



Tighten the retaining nuts with the service key.



1.

Lightly lubricate the o-rings on the spout and handle escutcheons with the enclosed lubricant (1). Push the escutcheons onto the baseplate (2). Push the spout over the connecting thread (1). Tighten the set screw with a 3 mm Allen wrench (2). Install the handle flange (3).







Measure the distance between the wall surface and the end of the handle (x).

If **x** is between 3 1/4'' and 3 7/8'', select the "A" sleeve (1 1/4'').

If **x** is between 37/8'' - 43/8'', select the "B" sleeve (7/8'').

If **x** is greater than 4 3/8'', select the "C" sleeve (1/2'').



Push the sealing ring into the handle escutcheon (1).

Install the handle escutcheon onto the sleeve (2).



Push the sleeve / handle escutcheon assembly into place over the handle (1). Tighten it by rotating it clockwise (2).



Push the flange over the handle.



Measure the distance from the rough to the outside surface of the finished wall (X) (1).

Add 1 3/16'' to X. Cut the spout connecting thread so that it is X + 1 3/16'' long (2).





Wrap the spout connecting thread with Teflon tape. Install the spout connecting thread. Tighten it with an 8 mm Allen wrench.



Install the spout escutcheon and spout (1). Tighten the spout set screw with a 3 mm Allen wrench (2).



User Instructions



Pivot the handle up to turn the water on, down to turn it off.

Pivot the handle to the left for warmer water, to the right for cooler water.

35115801



35116801



Replacement Parts

 2 handle 3 handle escutcheon 4 spout escutcheon 5 baseplate 6 cartridge 7 aerator 8 spout 9 anti-twist device 10 connecting thread 11 extension kit 12 set screw 12 sut 	96912800 96913800 96927800 96339000 96683800 97282800 97280000 97230000 38982000* 97660000
12 set screw	97601000
	// 001000

14	handle escutcheon	96909800
15	spout escutcheon	96910800
16	washer	97600000
17	ft t	07071000

17 fixing set

97971000

*not included

Cleaning Recommendation for Hansgrohe Products

Modern lavatory faucets, kitchen faucets, and showers consist of very different materials to comply with the needs of the market with regard to design and functionality. To avoid damage and returns, it is necessary to consider certain criteria when cleaning.

Cleaning Materials for Faucets and Showers

Acids are a necessary ingredient of cleaning materials for removing lime, however please pay attention to the following points when cleaning faucets and showers:

- Only use cleaning materials which are explicitly intended for this type of application.
- Never use cleaning materials which contain hydrochloric, formic, phosphoric, or acetic acid, as they cause considerable damage.
- Never mix one cleaning material with another.
- Never use cleaning materials or appliances with an abrasive effect, such as unsuitable cleaning powders, sponge pads, or micro fiber cloths.

Cleaning Instructions for Faucets and Showers

Please follow the cleaning material manufacturer's instructions. In addition, pay attention to the following points:

- Clean the faucets and showers as and when required
- Use the amount of cleaning product and the amount of time recommended by the manufacturer. Do not leave the cleaner
 on the fixture longer than necessary.
- Regular cleaning can prevent calcification.
- When using spray cleaners, spray first onto a soft cloth or sponge. Never spray directly onto the faucet as droplets can enter openings and gaps and cause damage.
- After cleaning, rinse thoroughly with clean water to remove any cleaner residue.

Important

Residues of liquid soaps, shampoos, and shower foams can also cause damage, so rinse with clean water after using.

Please note: if the surface is already damaged, the effect of cleaning materials will cause further damage.

Components with damaged surfaces must be replaced or injury could result. Damage caused by improper treatment is not covered under the warranty.

Limited Lifetime Consumer Warranty

This product has been manufactured and tested to the highest quality standards by Hansgrohe, Inc. ("Hansgrohe"). This warranty is limited to Hansgrohe products which are purchased by a consumer in the United States after March 1, 1996, and installed in either the United States or Canada.

WHO IS COVERED BY THE WARRANTY

This warranty extends to the original consumer purchaser only. This warranty is non-transferable.

WHAT IS COVERED BY THE WARRANTY

This warranty covers only your Hansgrohe manufactured product. Hansgrohe warrants this product against defects in material or workmanship as follows: Hansgrohe will repair at no charge for parts only or, at its option, replace any product or part of the product that proves defective because of improper workmanship and/or material, under normal installation, use, service and maintenance. If Hansgrohe is unable to provide a replacement and repair is not practical or cannot be timely made, Hansgrohe may elect to refund the purchase price in exchange for the return of the product.

LENGTH OF WARRANTY

Replacement or repaired parts of products will be covered for the term of this warranty as stated in the following two sentences. If you are a consumer who purchased the product for use primarily for personal, family, or household purposes, this warranty extends for as long as you own the product and the home in which the product is originally installed. If you purchased the product for use primarily for any other purpose,

including, without limitation, a commercial purpose, this warranty extends only (i) for 1 year, with respect to Hansgrohe and Commercial products, and (ii) for 5 years, with respect to AXOR products.

THIS WARRANTY DOES NOT COVER, AND HANSGROHE WILL NOT PAY FOR:

- A. Conditions, malfunctions or damage not resulting from defects in material or workmanship.
- B. Conditions, malfunctions or damage resulting from (1) normal wear and tear, improper installation, improper maintenance, misuse, abuse, negligence, accident or alteration, or (2) the use of abrasive or caustic cleaning agents or "no-rinse" cleaning products, or the use of the product in any manner contrary to the product instructions. (3) Conditions in the home such as excessive water pressure or corrosion.
- C. Labor or other expenses for the disconnection, deinstallation, or return of the product for warranty service, or for installation or reinstallation of the product (including but not limited to proper packaging and shipping costs), or for installation or reinstallation of the product.
- D. Accessories, connected materials and products, or related products not manufactured by Hansgrohe.

TO OBTAIN WARRANTY PARTS OR INFORMATION

Contact your Hansgrohe retailer, or contact Technical Service at:

Hansgrohe Inc. 1492 Bluegrass Lakes Parkway Alpharetta GA 30004 Toll-free (800) 334-0455.

In requesting warranty service, you will need to provide

- 1. The sales receipt or other evidence of the date and place of purchase.
- 2. A description of the problem.
- Delivery of the product or the defective part, postage prepaid and carefully packed and insured, to Hansgrohe Inc. 1492 Bluegrass Lakes Parkway, Alpharetta, Georgia 30004, Attention: Technical Service, if required by Hansgrohe.

When warranty service is completed, any repaired or replacement product or part will be returned to you postage prepaid.

EXCLUSIONS AND LIMITATIONS

REPAIR OR REPLACEMENT (OR, IN LIMITED CIRCUMSTANCES, REFUND OF THE PURCHASE PRICE) AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE PURCHASER. HANSGROHE NEITHER ASSUMES NOR AUTHORIZES ANY PERSON TO CREATE FOR IT ANY OBLIGATION OR LIABILITY IN CONNECTION WITH THIS PRODUCT.

HANSGROHE SHALL NOT BE LIABLE TO PURCHASER OR ANY PERSON FOR ANY INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES, ARISING OUT OF BREACH OF THIS WARRANTY OR ANY IMPLIED WARRANTY (INCLUDING MERCHANTABILITY).

Some States do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other rights which vary from State to State. You may be required by law to give us a reasonable opportunity to correct or cure any failure to comply before you can bring any action in court against us under the Magnuson-Moss Warranty Act.

PRODUCT INSTRUCTIONS AND QUESTIONS

Upon purchase or prior to installation, please carefully inspect your Hansgrohe product for any damage or visible defect. Prior to installing, always carefully study the enclosed instructions on the proper installation and the care and maintenance of the product. If you have questions at any time about the use, installation, or performance of your Hansgrohe product, or this warranty, please call or write to us or call us toll-free at 800 334 0455.

hansgrohe

Hansgrohe, Inc. • 1490 Bluegrass Lakes Parkway • Alpharetta, GA 30004 Tel. 770 360-9880 • Fax 770 360 9887

www.hansgrohe-USA.com