



Copies of the I/B. Please reproduce them without any changes except under special instruction from Team International BELGIUM. The pages must be reproduced and folded in order to obtain a booklet A5 (+/- 148.5 mm width x 210 mm height). When folding, make sure you keep the good numbering when you turn the pages of the I/B. Don't change the page numbering. Keep the language integrity. **Print only what is inside the frame.**



**KALORIK**



[www.KALORIK.com](http://www.KALORIK.com)



# Programmable Coffee maker

**USK CM 23826**  
**USK CM 34128**  
**120V~ 60Hz 900W**



Front cover page (first page)

Assembly page 1/12



Fax +32 2 359 95 50

Copies of the I/B. Please reproduce them without any changes except under special instruction from Team International BELGIUM. The pages must be reproduced and folded in order to obtain a booklet A5 (+/- 148.5 mm width x 210 mm height). When folding, make sure you keep the good numbering when you turn the pages of the I/B. Don't change the page numbering. Keep the language integrity. **Print only what is inside the frame.**



# **(EN) OPERATING INSTRUCTIONS**

## **IMPORTANT SAFEGUARDS**

**When using electrical appliances, basic safety precautions should always be followed, including the following:**

- 1. READ ALL INSTRUCTIONS**
2. Check that your mains voltage corresponds to that stated on the appliance.
3. Do not touch hot surfaces. Use handles or knobs.
4. To protect against electrical shock do not immerse cord, plugs, or the coffee maker in water or other liquid.
5. Close supervision is necessary when any appliance is used by or near children. The appliance is not to be used by children
6. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
7. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the authorized service facility for examination, repair, or adjustment.
8. The use of accessory attachments not recommended by the appliance manufacturer may cause fire, electric shock or injuries.
9. Do not use outdoors.
10. Do not let cord hang over edge of table or counter, or touch hot surfaces.
11. Do not place on or near a hot gas or electric burner, or in a heated oven.
12. Make sure the appliance never comes into contact with inflammable materials such as curtains, textiles ... when it is in use as they might catch fire.
13. Never fill the water reservoir with warm or hot water. Always use cold water.
14. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
15. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, put the switch in off position, then remove plug from wall outlet.
16. Do not use appliance for other than intended use.



Fax +32 2 359 95 50

Copies of the I/B. Please reproduce them without any changes except under special instruction from Team International BELGIUM. The pages must be reproduced and folded in order to obtain a booklet A5 (+/- 148.5 mm width x 210 mm height). When folding, make sure you keep the good numbering when you turn the pages of the I/B. Don't change the page numbering. Keep the language integrity. **Print only what is inside the frame.**



17. Scalding may occur if the lid of the coffee maker is removed during the brewing cycles.
18. Ensure that the carafe lid is secured before serving.
19. Never use carafe on a range top, conventional oven, or microwave oven.
20. Do not place empty carafe onto hot warming plate. Allow Coffee Maker to cool thoroughly before replacing the carafe.
21. Do not set hot carafe on cold or wet surface. Abrupt changes in temperature may cause carafe to crack.
22. Do not use a cracked carafe, or a carafe with a loose or weakened handle.
23. Do not clean your Coffee Maker with steel wool pads, harsh powder cleaners, or other abrasive materials.
24. When removing lime scale, only use special products for the removal of lime scale. Never use ammonia or any other substance that might damage your health.
25. Only put ground coffee in the filter.
26. Never use your coffee maker without water in it. If you have a programmable coffee maker, make sure to fill it with water before programming it.

## **SAVE THESE INSTRUCTIONS HOUSEHOLD USE ONLY**

### **POLARIZED PLUG INSTRUCTIONS**

This appliance is equipped with a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug will fit into the polarized outlet only one way. If the plug does not properly fit into the outlet at first, reverse it. If it still does not fit, contact a competent qualified electrician. **Do not attempt to modify the plug in any way.**



Fax +32 2 359 95 50

Copies of the I/B. Please reproduce them without any changes except under special instruction from Team International BELGIUM. The pages must be reproduced and folded in order to obtain a booklet A5 (+/- 148.5 mm width x 210 mm height). When folding, make sure you keep the good numbering when you turn the pages of the I/B. Don't change the page numbering. Keep the language integrity. **Print only what is inside the frame.**




## SHORT CORD INSTRUCTIONS

A short power supply cord is provided to reduce the hazards resulting from becoming entangled in, or tripping over a longer cord. Extension cords may be used if care is exercised in their use.

- The electrical rating of the extension cord should be at least that of the appliance. If the electrical rating of the extension cord is too low, it could overheat and burn.
- The resulting extended cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled on by children or tripped over.

## PART DESCRIPTION





Fax +32 2 359 95 50

Copies of the I/B. Please reproduce them without any changes except under special instruction from Team International BELGIUM. The pages must be reproduced and folded in order to obtain a booklet A5 (+/- 148.5 mm width x 210 mm height). When folding, make sure you keep the good numbering when you turn the pages of the I/B. Don't change the page numbering. Keep the language integrity. **Print only what is inside the frame.**



## TYPE OF FILTER

Please use paper filter "Basket Style, 8 to 12 cups", with a flat base.

## BEFORE FIRST USE

- Wash the carafe, lid and removable filter basket in warm, soapy water. Rinse and wipe or air dry thoroughly. Do not use harsh or abrasive cleaners.
- When you use your appliance for the first time, pour fresh water into the water tank (without coffee) and switch on the appliance. Allowing the Coffee Maker to run through a brew cycle with no ground coffee or paper filter will clean out any dust that may have settled inside.
- Once all the water has passed through, switch off the appliance and let it cool down for 15 minutes. When it is cold enough discard the water in the carafe and rinse it out. Your coffee maker is now clean and ready to brew great tasting coffee!

## SETTING THE CLOCK

To set the digital clock, press the HOUR button until the clock displays the desired hour. Press the MIN button until the clock displays the desired number of minutes. There are AM and PM indicators on the top of the digital readout.

Your clock is now set and will continue to keep the correct time until you change it, even when you shut off the Coffee Maker.

NOTE: Power failures and unplugging the Coffee Maker will cause it to reset to 12:00.



Fax +32 2 359 95 50

Copies of the I/B. Please reproduce them without any changes except under special instruction from Team International BELGIUM. The pages must be reproduced and folded in order to obtain a booklet A5 (+/- 148.5 mm width x 210 mm height). When folding, make sure you keep the good numbering when you turn the pages of the I/B. Don't change the page numbering. Keep the language integrity. **Print only what is inside the frame.**



## PREPARATION OF COFFEE

1. Open the lid of the water tank and pour the desired volume of water in it. The water level can be read off the water level indicator. Never exceed the maximum level indicated.
2. Insert filter paper (Type #4) in the filter holder and add the desired quantity of ground coffee using the provided scoop.
3. Never forget to close the water tank lid before switching on the coffee maker.
4. Put the jug with closed lid on the warming plate.
5. Plug in the coffee maker. Press the START/STOP button twice. The red ON light will be illuminated, indicating that your appliance is in use. Wait until the brewing process is finished and the filter is empty before removing the jug.
6. When your Coffee Maker has finished brewing it will automatically switch into its keep warm mode. Your Coffee Maker will keep your coffee warm for two hours, after which time it will automatically turn itself off.

NOTE: Only use cold water in your Coffee Maker. The automatic brew cycle is designed for use with cold water only.

### Practical hints:

- Your coffee maker is equipped with a "Pause-and-Serve" function, which means that when you remove the jug from the appliance at any time, a non-drip valve will automatically operate to stop any drops of coffee falling onto the hotplate. When you put the jug back into place, the non-drip valve opens automatically and allows remaining coffee to filter through into the jug.
- When the water tank is empty, wait a few more minutes, as some water might still drip out of the filter before removing the jug.



Fax +32 2 359 95 50

Copies of the I/B. Please reproduce them without any changes except under special instruction from Team International BELGIUM. The pages must be reproduced and folded in order to obtain a booklet A5 (+/- 148.5 mm width x 210 mm height). When folding, make sure you keep the good numbering when you turn the pages of the I/B. Don't change the page numbering. Keep the language integrity. **Print only what is inside the frame.**



## PROGRAMMING THE COFFEE MAKER

1. To program your coffee maker to brew fresh coffee at a preset time, first follow steps 1 to 4 in the "PREPARATION OF COFFEE" section.
2. Make sure the coffee maker's clock is set to the right time. If not, follow the directions in the "Setting the Clock" section to change it.
3. Press and hold the "TIME" button. The clock will now display 12:00 with the word "TIMER" at the bottom of the display. Use the HOUR and MINUTE buttons to set the desired brewing start time.
4. Press the START/STOP button once to activate the preset brew cycle. The green AUTO light will illuminate when the brew time is properly set.
5. When your preset brew time is reached and the coffee maker starts its brew cycle, the green AUTO light will go out and the red ON light will illuminate.
6. As with the regular brew cycle, an automatic two hour keep warm cycle will start after your coffee maker has finished brewing. At the end of the two hours, the coffee maker will automatically shut itself off.

## AUTO SHUT-OFF

Your Coffee Maker is designed with your convenience and safety in mind. Two hours after the completion of the brew cycle, it will shut itself off automatically.



Fax +32 2 359 95 50

Copies of the I/B. Please reproduce them without any changes except under special instruction from Team International BELGIUM. The pages must be reproduced and folded in order to obtain a booklet A5 (+/- 148.5 mm width x 210 mm height). When folding, make sure you keep the good numbering when you turn the pages of the I/B. Don't change the page numbering. Keep the language integrity. **Print only what is inside the frame.**



## DESCALING AND CLEANING

Before cleaning your Coffee Maker, always be sure it is unplugged and cool. Never immerse cord, plug or Coffee Maker body in water or any other liquid.

- Open the hinged lid and dispose of paper filter and used coffee grounds. Remove the carafe from the Coffee Maker.
- Always grasp the carafe by its handle.
- Remove the cover of the carafe by pulling upwards on the lid until the pins click out of their hinge on the carafe handle.
- The carafe, carafe lid and filter basket may be washed in warm, soapy water or placed in the top rack of the dishwasher.
- Never place any other part of the Coffee Maker in the dishwasher. Do not use harsh or abrasive cleaning products on any part of your Coffee Maker.
- To clean the exterior of your Coffee Maker, wipe the surface with a soft, damp cloth. To avoid water marks, dry and polish with a soft, dry cloth.
- Never try to clean the inside of the water reservoir with a cloth. Doing so will leave lint residue and may result in clogging your Coffee Maker. When you wish to clean the water reservoir, just rinse it out with cold water.
- Removing mineral deposits from your coffee maker prolongs its life span. For decalcification only use products especially made for descaling of coffee makers and follow their instruction manual carefully. Rinse abundantly afterwards. Please decalcify your coffee maker every 3 months or so.





Fax +32 2 359 95 50

Copies of the I/B. Please reproduce them without any changes except under special instruction from Team International BELGIUM. The pages must be reproduced and folded in order to obtain a booklet A5 (+/- 148.5 mm width x 210 mm height). When folding, make sure you keep the good numbering when you turn the pages of the I/B. Don't change the page numbering. Keep the language integrity. **Print only what is inside the frame.**



## PRACTICAL HINTS

### **Problem:**

You notice that the coffee making process is longer than it should be

### **Solution:**

It is probably time to decalcify the appliance. Do not wait for the situation to get worse and coffee maker to stop working completely. The decalcifying frequency depends on the amount of lime in water and therefore can be different from a household to another. Therefore it is important to pay attention to this. A good maintenance of your appliance will prolong its lifespan. Guarantee claims will not be accepted for the replacement of a heating element full of scale.



Fax +32 2 359 95 50

Copies of the I/B. Please reproduce them without any changes except under special instruction from Team International BELGIUM. The pages must be reproduced and folded in order to obtain a booklet A5 (+/- 148.5 mm width x 210 mm height). When folding, make sure you keep the good numbering when you turn the pages of the I/B. Don't change the page numbering. Keep the language integrity. **Print only what is inside the frame.**



## WARRANTY

We suggest that you complete and return the enclosed Product Registration Card promptly to facilitate verification of the date of original purchase. However, return of the Product Registration Card is not a condition of these warranties. You can also fill this warranty card online, at the following address: [www.KALORIK.com](http://www.KALORIK.com)

This KALORIK product is warranted in the U.S.A. for 1 year from the date of purchase against defects in material and workmanship. This warranty is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance.

During this period, the KALORIK product that, upon inspection by KALORIK, is proved defective, will be repaired or replaced, at Kalorik's option, without charge to the customer. If a replacement product is sent, it will carry the remaining warranty of the original product.

This warranty does not apply to any defect arising from a buyer's or user's misuse of the product, negligence, failure to follow KALORIK instructions noted in the user's manual, use on current or voltage other than that stamped on the product, wear and tear, alteration or repair not authorized by KALORIK, or use for commercial purposes. There is no warranty for glass parts, glass containers, filter basket, blades and agitators, and accessories in general. There is also no warranty for parts lost by the user.

ANY WARRANTY OF MERCHANTABILITY OR FITNESS WITH RESPECT TO THIS PRODUCT IS ALSO LIMITED TO THE ONE YEAR LIMITED WARRANTY PERIOD.

Some states do not allow limitation on how long an implied warranty lasts or do not allow the exclusion of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.



Fax +32 2 359 95 50

Copies of the I/B. Please reproduce them without any changes except under special instruction from Team International BELGIUM. The pages must be reproduced and folded in order to obtain a booklet A5 (+/- 148.5 mm width x 210 mm height). When folding, make sure you keep the good numbering when you turn the pages of the I/B. Don't change the page numbering. Keep the language integrity. **Print only what is inside the frame.**



If the appliance should become defective within the warranty period and more than 30 days after date of purchase, do not return the appliance to the store: often, our Consumer Service Representatives can help solve the problem without having the product serviced. If servicing is needed, a Representative can confirm whether the product is under warranty and direct you to the nearest service location.

If this is the case, bring the product, or send it, postage prepaid by the user (all Kalorik customers are responsible for the initial shipment back to the warranty center), along **with proof of purchase** and indicating a **return authorization number** given by our Consumer Service Representatives, to the authorized KALORIK Service Center (please visit our website at [www.KALORIK.com](http://www.KALORIK.com) or call our Customer Service Department for the address of our authorized KALORIK Service Center).

If you send the product, please include a letter explaining the nature of the claimed defect.

If you have additional questions, please call our Consumer Service Department (please see below for complete contact information), Monday through Friday from 9:00am - 6:00pm (EST). Please note hours are subject to change.

If you would like to write, please send your letter to:

**KALORIK Consumer Service Department**

Team International Group of America Inc.  
1400 N.W 159th Street, Suite 102  
Miami Gardens, FL 33169 USA

Or call:

Toll Free: +1 888-521-TEAM / +1 888-KALORIK

**Only letters can be accepted at this address above. Shipments and packages that do not have a return authorization number will be refused.**



Fax +32 2 359 95 50

Copies of the I/B. Please reproduce them without any changes except under special instruction from Team International BELGIUM. The pages must be reproduced and folded in order to obtain a booklet A5 (+/- 148.5 mm width x 210 mm height). When folding, make sure you keep the good numbering when you turn the pages of the I/B. Don't change the page numbering. Keep the language integrity. **Print only what is inside the frame.**

