



# USER'S MANUAL

---

40 WATT ACOUSTIC INSTRUMENT AMP



**acoustic®**

[www.AcousticAmplification.com](http://www.AcousticAmplification.com)



# acoustic®



#### FCC Statements

1. Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

2. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

All trademarks and registered trademarks mentioned herein are recognized as the property of their respective holders.  
1405-10152

## IMPORTANT SAFETY INSTRUCTIONS IMPORTANTES INSTRUCTIONS DE SECURITE

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use the attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. Refer all servicing to a qualified service professional. Servicing is required when the apparatus does not operate normally or has been damaged in any way, including damage to the power cord or plug, damage due to liquids spilled or objects dropped inside the unit, dropping the unit, or anything else that interrupts normal use of the unit.
16. **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
17. When the MAINS plug, or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
18. Protective Ground Terminal: The apparatus shall be connected to an AC main socket with a protective earth ground connection



1. Lisez ces instructions.
2. Conservez ces instructions.
3. Respectez tous les avertissements.
4. Suivez toutes les instructions.
5. N'utilisez pas cet appareil près de l'eau.
6. Nettoyez avec un chiffon sec.
7. Ne bloquez pas les ouvertures de ventilation. Installez-les conformément aux instructions du fabricant.
8. Ne l'installez pas près de sources de chaleur telles que des radiateurs, des ouvertures, des poêles ou d'autres appareils (inclus les amplificateurs) produisant de la chaleur.
9. Ne contournez pas le dispositif de sécurité de la fiche polarisée ou masse. Une fiche polarisée possède deux lames dont une plus large que l'autre. Une fiche de terre a deux lames et une troisième broche de masse. La lame large ou la troisième broche sont fournies pour votre sécurité. Si la fiche fournie ne rentre pas dans votre prise, consultez un électricien pour le remplacement de la prise obsolète.
10. Protégez le cordon d'alimentation pour qu'il ne soit pas piétiné ou pincé, en particulier au niveau des fiches, des prises de courant et du point de sortie de l'appareil.
11. Utilisez uniquement les fixations / accessoires spécifiés par le fabricant.
12. Utilisez uniquement avec le chariot, le stand, le trépied, le support de table spécifiés par le fabricant, ou vendus avec l'appareil. Lorsque vous utilisez un chariot, soyez prudent(e) lorsque vous déplacez le chariot / l'appareil pour éviter des blessures dues au renversement.
13. Débranchez cet appareil pendant les orages ou lorsqu'il n'est pas utilisé pendant de longues périodes de temps.
14. Confiez toute réparation à un personnel qualifié. Une réparation est nécessaire lorsque l'appareil a été endommagé de quelque façon que ce soit, comme par exemple si le cordon d'alimentation ou la fiche sont endommagés, du liquide a été renversé ou des objets sont tombés dans l'appareil, si l'appareil a été exposé à la pluie ou à l'humidité, s'il ne fonctionne pas normalement ou s'il est tombé.
15. Pour toutes interventions techniques s'adresser à un technicien qualifié. L'intervention technique est nécessaire lorsque l'appareil a été endommagé de n'importe quelle façon, comme par exemple si le cordon secteur ou sa fiche sont détériorés, si du liquide acoulé ou si des objets sont tombés à l'intérieur de l'appareil ,si l'appareil a été exposé à la pluie ou à l'humidité, s'il ne fonctionne pas normalement ou s'il est tombé.
16. **ATTENTION:** Pour réduire le risque d'incendie ou de choc électrique ne pas exposer l'appareil à la pluie ou à l'humidité.
17. Quand La prise MAINS, au coupler, est utilisée pour la source d'alimentation électrique. Il est conseillé de garder cette prise facilement accessible.
18. Borne de terre de protection: L'appareil doit être connecté à un connecteur AC principale avec un raccordement à la terre de protection.



### DANGER

Exposure to extremely high noise levels may cause permanent hearing loss. Individuals vary considerably to noise-induced hearing loss but most will lose some hearing if exposed to intense noise for a sufficient period of time.

The U.S. Government's Occupational Safety and Health Administration (OSHA) has specified the following permissible noise level exposures:

DURATION PER DAY (HOURS)	8	6	4	3	2	1
SOUND LEVEL (dB)	90	93	95	97	100	103

According to OSHA, any exposure in the above permissible limits could result in some hearing loss. Ear plugs or protectors in the ear canal or over the ears must be worn when operating this amplification system in order to prevent a permanent hearing loss. If exposure in excess of the limits as put forth above, to insure against potentially harmful exposure to high sound pressure levels, it is recommended that all persons exposed to equipment capable of inducing high sound pressure levels, such as this amplification system, be protected by hearing protectors while this unit is in operation.

### DANGER

L'exposition a des niveaux élevés de bruit peut provoquer une perte permanente de l'audition. Chaque organisme humain réagit différemment quant à la perte de l'audition, mais quasiment tout le monde subit une diminution de l'acuité auditive lors d'une exposition suffisamment longue au bruit intense. Les autorités compétentes en réglementation de bruit ont défini les expositions tolérées aux niveaux de bruits:

DURE EN HEURES PAR JOUR	8	6	4	3	2	1
INNIVEAU SONORE CONTINU EN dB	90	93	95	97	100	103

Selon les autorités, toute exposition dans les limites citées ci-dessus, peuvent provoquer certaines pertes d'audition. Des bouchons ou protections dans l'appareil auditif ou sur l'oreille doivent être portés lors de l'utilisation de ce système d'amplification afin de prévenir le risque de perte permanente de l'audition. Dans le cas d'expositions supérieures aux limites précitées il est recommandé, afin de se prémunir contre les expositions aux pressions acoustiques élevées potentiellement dangereuses, aux personnes exposées aux équipements capables de délivrer de telles puissances, tels ce système d'amplification en fonctionnement, de protéger l'appareil auditif.



THIS SYMBOL IS INTENDED TO ALERT THE USER TO THE PRESENCE OF NON-INSULATED "DANGEROUS VOLTAGE" WITHIN THE PRODUCT'S ENCLOSURE THAT MAY BE OF SUFFICIENT MAGNITUDE TO CONSTITUTE A RISK OF ELECTRIC SHOCK TO PERSONS CE SYMBOLE APPELÉ BUT D'AVERTIR L'UTILISATEUR DE LA PRÉSENCE DE VOLTAGE DANGEREUX NON-ISOLE À L'INTÉRIEUR DE CE PRODUIT QUI PEUT ÊTRE DE PUISSANCE SUFFISAMMENT IMPORTANTE POUR PROVOQUER UN CHOC ÉLECTRIQUE AUX PERSONNES

THIS SYMBOL IS INTENDED TO ALERT THE USER TO THE PRESENCE OF IMPORTANT OPERATING AND MAINTENANCE (SERVICING) INSTRUCTIONS IN THE LITERATURE ACCOMPANYING THE UNIT.

CE SYMBOLE APPELÉ BUT D'AVERTIR L'UTILISATEUR DE LA PRÉSENCE D'INSTRUCTIONS D'UTILISATION ET DE MAINTENANCE DANS LES DOCUMENTS FOURNIS AVEC CE PRODUIT

APPARATUS SHALL NOT BE EXPOSED TO DRIPPING OR SPLASHING AND THAT NO OBJECTS FILLED WITH LIQUIDS, SUCH AS VASES, SHALL BE PLACED ON THE APPARATUS. AFIN DE REDUIRE LES RISQUES D'INCENDIE ET DE DÉCHARGE ÉLECTRIQUE, NE PAS EXPOSER CET APPAREIL À LA PLUIE OU À L'HUMIDITÉ

# acoustic®



## WHAT SETS THE A40 APART

Your new Acoustic® A40 amplifier is designed to sound great with any acoustic instrument or vocal.

We put a lot of thought and effort into selecting exactly the right components and designing a product that will be easy to adjust so you can quickly find the voice of your instrument and project it beyond your personal performance space.

Here are a few of the features that we put into the A40 to make you sound your best -

- 40-watt output: enough power for stage or studio
- Dual combo XLR-1/4" inputs for use with instruments or vocals, each with separate volume
- 8" coaxial design studio monitor-style speaker for extended frequency response
- Ported cabinet design for extended bass response
- 3-Band EQ with sweepable mid-range for more tonal flexibility
- Full-function digital effects with editable parameters and LCD readout
- Auxiliary Bluetooth® connectivity: play backing tracks directly from your mobile device
- DSP-based AUTOMATIC feedback elimination
- Effects Loop
- Full-feature direct output with ground lift, pre/post EQ and level
  - Connect DI output to powered speakers to send your signal to your PA

No matter what your style of playing or choice of acoustic instrument, you will find that your new amp will capture and project the very best of your musical voice.

## SPECIFICATIONS

Power: 40W RMS

Equalizer:

- Low +/- 15dB @ 80 Hz
- Mid +/- 15dB; 500Hz to 1.2kHz [sweepable]
- High +/- 15dB @ 10kHz

Channels: 1

Inputs: 2

Digital Signal Processor [DSP]:

- 20 Preset programs
- 20 User programs
- Reverb, Delay, Chorus, & Flange
- Auto-Feedback Elimination Filter [12 filters, DSP based]

Speaker: 8" Coaxial Studio Monitor style

Dimensions: 18.3" L X 17.3" W x 16.5" D

Weight: 28.7 lbs.

## TAKING CARE OF YOUR NEW AMPLIFIER

### LOCATION

- To avoid deformation, discoloration, or more serious damage, do not expose the unit to direct sunlight, high temperature sources, or excessive humidity.

### POWER SUPPLY

- Turn the power switch off when the A40 is not in use.
- The AC cable should be unplugged from the AC outlet if the A40 will not be used for an extended period of time.
- Avoid plugging the AC cable into an AC outlet that is also powering high consumption appliances such as electric heaters or televisions.  
**NOTE:** Also avoid using multi-plug adapters since these can reduce sound quality, cause operation errors, and result in possible damage.
- To avoid damage, turn off the A40 power switch and all related devices prior to connecting or disconnecting cables.

### HANDLING AND TRANSPORT

- Never apply excessive force to any parts.
- Unplug cables by gripping plugs firmly. Do not pull on cables.
- Physical shocks caused by dropping or bumping can result in serious damage.

### CLEANING


- Clean with a dry, soft cloth.
- A slightly damp cloth may be used to remove stubborn grime and dirt.
- Never use cleaners such as alcohol or thinner.

### ELECTRICAL INTERFERENCE

- The A40 contains electronic circuitry that may cause interference if placed too close to radio or television receivers. If this occurs, move the A40 further away from the affected equipment.

### SERVICE AND MODIFICATION

- There are no user serviceable parts in the A40.
- Do not attempt to open the A40 or make any change to circuits or parts. This will void the warranty.



## FRONT PANEL

- 1. INPUTS** - combination 1/4" [2-conductor instrument cable] or XLR [3 or 4-conductor microphone]
- 2. VOLUME CONTROLS** - these adjust the overall loudness of the corresponding input. If your acoustic instrument has a preamp, you should set the Volume control on your instrument to about half volume. You can then adjust the volume to your normal playing level and still have room to increase or decrease your volume as needed from the instrument.
- 3. PHANTOM POWER (+48V)** - this switch enables a +48 volt DC send on PIN 1 of an XLR cable to power condenser microphones.
- 4. EQUALIZATION**
  - LOW** - set to boost [15 dB] or cut [-15 dB] frequencies at 80 Hz. Controls the lowest fundamental frequencies to enhance the warmth and deep, full tones of your acoustic instrument.
  - MIDRANGE** - set to boost [15 dB] or cut [-15 dB] adjustable from 500 Hz to 1.2 kHz. Allows you to control the definition and voice of your acoustic instrument.
  - FREQUENCY** - this adjusts the center frequency for the MIDRANGE EQ control above: you can sweep between 500Hz and 1.2kHz. Moving the midrange frequency and either cutting or boosting this frequency will give you maximum control over the body of your tone. It also allows you to control the definition and voice of your acoustic instrument or vocals.
  - HIGH** - set to boost [15 dB] or cut [-15 dB] frequencies at 10 kHz. Increasing this will enhance the clarity and brightness of your acoustic instrument.
- 5. DIGITAL EFFECTS** -
  - UP/DOWN soft buttons scroll between programs, select effect types or parameter values
  - Press UP/DOWN buttons together to activate the tuner. Press any button to exit.
  - SELECT button scrolls through individual effects within a program
  - ON/OFF button turns an individual effect on or off within a program
  - PARAM [parameter] button pages through the parameters of an effect
    - UP/DOWN buttons change the parameter value



# USER'S MANUAL

40 WATT ACOUSTIC INSTRUMENT AMP

- SAVE button saves a program to one of 20 user-definable locations
  - UP/DOWN buttons select memory slots [U01 through U20]
  - Press SAVE a 2nd time to move to title [edit as you like]
  - Press SAVE to save your user program
  - Press SELECT or ON/OFF to exit out to the preset screen

In addition to the amazing digital effects, the A40 utilizes a DSP-based AUTOMATIC feedback elimination [AFB] filter. This digital processor scans your input for any unwanted feedback, and will eliminate it. The A40's 12 digital filters remove virtually any feedback from your signal path! The AFB filter settings can be adjusted in any DSP program and will be applied to all program settings.

**6. AUX IN** - this 3-conductor 1/8" Aux input jack will allow you to plug in a CD, MP3 player or any other source so you can play along. To control the volume of this input, adjust the output volume of the device.

**7. BLUETOOTH® INDICATOR** - this indicates the BLUETOOTH® switch [rear panel] has been engaged and is active: press and hold this switch for 3 seconds, then simply tether your mobile or aux device using the passcode [1967] to allow audio playback.

**8. HEADPHONE** - this 1/8" 3-conductor jack is for plugging in headphones. When used, it will disconnect the internal speaker.

**9. POWER** - this indicator light will illuminate when the rear panel power switch is depressed.

DSP PROGRAM PRESETS		
#	TITLE	EFFECTS INCLUDED
1	Dry No EFX	None
2	Short Room	Short reverb
3	Small Room	Small room reverb
4	Medium Room	Mid-size room reverb with early reflections
5	Large Room	Large room reverb with early reflections
6	Small Hall	Small concert hall reverb
7	Medium Hall	Mid-size concert hall reverb
8	Large Hall	Large concert hall reverb
9	Church	Giant reverb with reflection
10	Slow Chorus	Slow, rich, sweeping chorus effect
11	Lush Chorus	Thick chorus effect with more regeneration
12	Flange	Mid-depth flange effect
13	Phaser	Shallow, medium rate phaser effect
14	Slap Back	Short single-repeat delay
15	Med Delay	1/2 sec. delay
16	Long Delay	1 sec. delay
17	Chorus Verb	Slow Chorus combined with Large Hall Reverb
18	Lush Verb	Lush Chorus combined with Large Hall Reverb
19	Crazy Multi	Wide Chorus, Church Reverb, and 1.2 sec. delay
20	Vocal Multi	Vocal Plate Reverb plus 1/2 sec. delay

EDITABLE PARAMETERS	
Chorus, Flanger, Phaser:	Depth, Rate, Level, Pre-Delay Time, Feedback [Effect Level]
Reverb:	Type, Pre-Delay, Time, Level
Reverb Types:	Spring Rev, Short Room, Room, Small Hall, Large Hall, Church, Vocal Plate
Delay:	Type, Delay Time, Level
AFB Detect Mode [Global]:	Slow, Med1, Med2, Fast



## REAR PANEL

- 1. POWER** - this rocker switch will illuminate with a soft amber color when the amp is turned on and ready to play.
  - A. AC LINE IN - this plug accepts a standard CLASS 1 IEC grounded cable [included] to provide AC power to the amplifier.
  - B. VOLTAGE SELECTOR - used to select the input voltage level to 110/115V or 220/230V. Voltage standards vary by country. This switch is preset at the factory. Setting the power supply voltage switch to the incorrect input voltage could damage the power supply and possibly other parts of your equipment.
- 2. DIRECT OUTPUT**
  - A. PRE/POST EQ SWITCH - this switch determines if your direct output signal will be effected by the front panel equalization settings. In the PRE setting, the direct signal is not effected by the front panel settings; in POST setting, the direct signal is effected by the EQ settings.
  - B. DIRECT OUTPUT LEVEL - this adjusts the overall level of the direct output.
  - C. DIRECT OUTPUT - connect a standard XLR balanced cable from this jack to provide a line-level signal to your PA system, powered speaker, or other powered output device.
  - D. GROUND LIFT - this switch disconnects pin 1 on the XLR jack, which is connected to the shield in the cable and acts as the ground point of the circuit, reducing ground-related noise.
- 3. EFFECTS LOOP** - these ¼" unbalanced send and returns allow you to run external effects before the preamp, resulting in clearer effects signal, and cleaner levels [line level vs. instrument level]. Connect the Send to your effect devices input, and the output from your device to the return.
- 4. BLUETOOTH®** - this switch engages the bluetooth® connectivity for use with your mobile devices: simply tether your mobile or aux device using the passcode [1967] to allow audio playback.

