

RFID READER

13.56MHz Reader / Writer

GZ500

User Manual

Version 1.8

Nov 2010

GeZhiTech

CONTENT

| | |
|--|-----------|
| 1. GENERAL INFORMATION | 5 |
| 2. TYPES AND EXPLANATION | 6 |
| 3. CONNECTING TO PC..... | 6 |
| 3.1 GZ500-RS232..... | 6 |
| 3.2 GZ500-USB..... | 7 |
| 4. SDK | 8 |
| 5. DEMO | 8 |
| 5.1 ONLINE..... | 8 |
| 5.2 SHC1102..... | 9 |
| 5.3 ULTRALIGHT | 9 |
| 5.4 MIFARE_1K | 10 |
| 5.5 MIFARE_4K | 10 |
| 5.6 MIFARE_PROX | 11 |
| 5.7 TRH1064 | 11 |
| 5.9 SRIX4K | 12 |
| 5.10 AT88RF020 | 13 |
| 5.11 ISO14443B-4 PROTOCOL SMART CARD | 13 |
| 5.12 I.CODE GZI | 14 |
| 5.13 TAG_IT | 14 |
| 5.14 SRF55V02P | 15 |
| 5.15 SRF55V10P | 15 |
| 5.16 PASS_THROUGH | 16 |
| 6. DLL INFORMATION | 17 |
| 6.1 SYSTEM FUNCTION | 17 |
| 6.1.1 INT WINAPI LIB_VER | 17 |
| 6.1.2 INT WINAPI RF_INIT_COM | 17 |
| 6.1.3 INT WINAPI RF_CLOSEPORT | 17 |
| 6.1.4 INT WINAPI RF_GET_MODEL | 17 |
| 6.1.5 INT WINAPI RF_INIT_DEVICE_NUMBER | 17 |
| 6.1.6 INT WINAPI RF_GET_DEVICE_NUMBER | 18 |
| 6.1.7 INT WINAPI RF_INIT_TYPE | 18 |
| 6.1.8 INT WINAPI RF_ANTENNA_STA | 18 |
| 6.1.9 INT WINAPI RF_LIGHT | 18 |
| 6.1.10 INT WINAPI RF_BEEP | 18 |
| 6.2 DES FUNCTION | 19 |
| 6.2.1 INT WINAPI DES_ENCRYPT | 19 |

| | | |
|--------------|--|-----------|
| 6.2.2 | INT WINAPI DES_DECRYPT | 19 |
| 6.3 | ISO14443A FUNCTION | 19 |
| 6.3.1 | UltraLight | 19 |
| 6.3.1.1 | INT WINAPI RF_REQUEST | 19 |
| 6.3.1.2 | INT WINAPI INT_RF_UL_SELECT | 20 |
| 6.3.1.3 | INT WINAPI RF_M1_READ | 20 |
| 6.3.1.4 | INT WINAPI INT_RF_UL_WRITE | 20 |
| 6.3.1.5 | INT WINAPI RF_HALT | 20 |
| 6.3.2 | Mifare_Class | 21 |
| 6.3.2.1 | INT WINAPI RF_REQUEST | 21 |
| 6.3.2.2 | INT WINAPI RF_ANTICOLL | 21 |
| 6.3.2.3 | INT WINAPI RF_SELECT | 21 |
| 6.3.2.4 | INT WINAPI RF_M1_AUTHENTICATION2 | 22 |
| 6.3.2.5 | INT WINAPI RF_M1_READ | 22 |
| 6.3.2.6 | INT WINAPI RF_M1_WRITE | 22 |
| 6.3.2.7 | INT WINAPI RF_M1_INITVAL | 22 |
| 6.3.2.8 | INT WINAPI RF_M1_READVAL | 23 |
| 6.3.2.9 | INT WINAPI RF_M1_INCREMENT | 23 |
| 6.3.2.10 | INT WINAPI RF_M1_DECREMENT | 23 |
| 6.3.2.11 | INT WINAPI RF_M1_RESTORE | 23 |
| 6.3.2.12 | INT WINAPI RF_M1_TRANSFER | 23 |
| 6.3.2.13 | INT WINAPI RF_HALT | 24 |
| 6.3.3 | Mifare_DESFire | 24 |
| 6.3.3.1 | INT WINAPI RF_DESFIRE_RST | 24 |
| 6.3.3.2 | INT WINAPI RF_COS_COMMAND | 24 |
| 6.3.4 | Mifare_ProX | 25 |
| 6.3.4.1 | INT WINAPI RF_TYPE_RST | 25 |
| 6.3.4.2 | INT WINAPI RF_COS_COMMAND | 25 |
| 6.3.4.3 | INT WINAPI RF_CL_DESELECT | 25 |
| 6.3.5 | SHC1102 | 25 |
| 6.3.5.1 | INT WINAPI RF_REQUEST | 25 |
| 6.3.5.2 | INT WINAPI RF_SHC1102_AUTH | 26 |
| 6.3.5.3 | INT WINAPI RF_SHC1102_READ | 26 |
| 6.3.5.4 | INT WINAPI RF_SHC1102_WRITE | 26 |
| 6.4 | ISO14443B FUNCTION | 27 |
| 6.4.1 | THR1064 | 27 |
| 6.4.1.1 | INT WINAPI RF_TYPEB_RST | 27 |
| 6.4.1.2 | INT WINAPI RF_THR1064_READ | 27 |
| 6.4.1.3 | INT WINAPI RF_THR1064_WRITE | 27 |
| 6.4.1.4 | INT WINAPI RF_THR1064_CHECK | 27 |
| 6.4.2 | AT88RF020 | 28 |
| 6.4.2.1 | INT WINAPI RF_TYPEB_RST | 28 |
| 6.4.2.2 | INT WINAPI RF_AT020_CHECK | 28 |
| 6.4.2.3 | INT WINAPI RF_AT020_COUNT | 28 |

| | | |
|--------------|--|-----------|
| 6.4.2.4 | INT WINAPI RF_AT020_READ | 28 |
| 6.4.2.5 | INT WINAPI RF_AT020_WRITE | 29 |
| 6.4.2.6 | INT WINAPI RF_AT020_LOCK | 29 |
| 6.4.2.7 | INT WINAPI RF_AT020_DESELECT | 29 |
| 6.4.3 | SR176SRIX4K | 29 |
| 6.4.3.1 | INT WINAPI RF_ST_SELECT | 29 |
| 6.4.3.2 | INT WINAPI INT_RF_SR176_READBLOCK | 29 |
| 6.4.3.3 | INT WINAPI INT_RF_SR176_WRITEBLOCK | 30 |
| 6.4.3.4 | INT WINAPI INT_RF_SR176_PROTECTBLOCK | 30 |
| 6.4.3.5 | INT WINAPI INT_RF_SRIX4K_GETUID | 30 |
| 6.4.3.6 | INT WINAPI INT_RF_SRIX4K_READBLOCK | 30 |
| 6.4.3.7 | INT WINAPI INT_RF_SRIX4K_WRITEBLOCK | 31 |
| 6.4.3.8 | INT WINAPI INT_RF_SRIX4K_PROTECTBLOCK | 31 |
| 6.4.3.9 | INT WINAPI RF_ST_COMPLETION | 31 |
| 6.4.4 | TYPE_B SmartCard | 32 |
| 6.4.4.1 | INT WINAPI RF_TYPEB_RST | 32 |
| 6.4.4.2 | INT WINAPI RF_COS_COMMAND | 32 |
| 6.4.4.3 | INT WINAPI RF_CL_DESELECT | 32 |
| 6.5 | ISO15693 FUNCTION | 33 |
| 6.5.1 | INT WINAPI ISO15693_INVENTORY | 33 |
| 6.5.2 | INT WINAPI ISO15693_INVENTORYS | 33 |
| 6.5.3 | INT WINAPI ISO15693_GET_SYSTEM_INFORMATION | 33 |
| 6.5.4 | INT WINAPI ISO15693_SELECT | 34 |
| 6.5.5 | INT WINAPI ISO15693_RESET_TO_READY | 34 |
| 6.5.6 | INT WINAPI ISO15693_STAY_QUIET | 34 |
| 6.5.7 | INT WINAPI ISO15693_GET_BLOCK_SECURITY | 34 |
| 6.5.8 | INT WINAPI ISO15693_READ | 35 |
| 6.5.9 | INT WINAPI ISO15693_WRITE | 35 |
| 6.5.10 | INT WINAPI ISO15693_LOCK_BLOCK | 36 |
| 6.5.11 | INT WINAPI ISO15693_WRITE_AFI | 36 |
| 6.5.12 | INT WINAPI ISO15693_LOCK_AFI | 36 |
| 6.5.13 | INT WINAPI ISO15693_WRITE_DSFD | 37 |
| 6.5.14 | INT WINAPI ISO15693_LOCK_DSFD | 37 |
| 6.6 | FUNCTION OF INFINEON ELECTRIC TAG | 38 |
| 6.6.1 | INT WINAPI SRF55VP_READ | 38 |
| 6.6.2 | INT WINAPI SRF55VP_WRITEBYTE | 38 |
| 6.6.3 | INT WINAPI SRF55VP_WRITE | 38 |
| 6.6.4 | INT WINAPI SRF55VP_WRITE_REREAD | 39 |
| 6.7 | PASS THROUGH FUNCTION | 39 |
| 6.7.1 | INT WIN API RF_TRANSCEIVE1 | 39 |

1. GENERAL INFORMATION



- RS232 or USB Interface
- 4.5 ~ 5.5VDC Operating
- Windows 32 Operating Systems Compatibility
- 13.56MHz RF Operating Frequency
- ISO14443A ISO1443B ISO15693 Protocols
- 150MA Working Current
- Operating Temperature Range: -20°C ~ +50°C
- Storage Temperature Range: -25°C ~ +60°C
- Dimension: 110 × 81 × 26 mm
- Weight: 100g

1. TYPES AND EXPLANATION

GZ500 series readers are in accord with ISO14443A, ISO14443B and ISO15693 protocols, and are classified as following sheet

| | GZ500L | GZ500A | GZ500D | GZ500F |
|-----------|--------|--------|--------|--------|
| ISO14443A | √ | √ | | √ |
| ISO14443B | | | | √ |
| ISO15693 | | | √ | √ |

NOTICE: The difference between GZ500L and GZ500A


GZ500L supported cards: Mifare_1k, Mifare_4k, UltraLight

GZ500A supported cards: Mifare_1k, Mifare_4k, UltraLight, Mifare_ProX


2. CONNECTING TO PC

3.1 GZ500-RS232

The PS/2 port power to Reader




3.2 GZ500USB



GZ500-USB Reader is USB bridge to COM. Connect GZ500 to the USB port of PC, after installing the driver will come out a virtual COM, the operations hereafter are as same as GZ500-RS232.

You can find the virtual COM number on the “Device Manager” as follows:



4. SDK

Responding InstDemo.exe to install the DEMO software and the DLL of the reader to PC, and create corresponding logo on the desk.

The default installation directory is C:\RFREADER, including the following content:


| | |
|----------------------------|--|
| C:\RFREADER\Examples | Sample source code |
| C:\RFREADER\UsbDriver | USB interface driver |
| C:\RFREADER\ICTransfer.exe | DEMO software |
| C:\RFREADER\MasterRD.dll | Reader interface library with application |
| C:\RFREADER\MasterCOM.dll | Connect and transfer data with COM device. |
| C:\RFREADER\GZ_Paper.dll | DEMO software background library |
| C:\RFREADER\RFHELP.chm | DLL explanations at chm format |
| C:\RFREADER\AppConfig.ini | DEMO software configuration files |

5. DEMO

This software run on Win32 system, and need 1024 x 768 dpi at least


5.1 nline

Choose the correct COM number, click [Connect] button to connect the Reader to PC. Click [Read] the product information button, you can check the specific type of the Reader and the supported cards.




5.2 HC1102

Click [Request] button to obtain the card serial number.
 Input the correct key to read/write the card



5.3 UltraLight

Click the [Request] button to obtain the card Serial Number.
 Choose the corresponding address to read/write the card.



5.4 Mifare_1k (STD S50)

Click the [Request] button to obtain the card serial number.


Input the correct password to read, write, increase or decrease the card.



5.5 Mifare_4k (STD S70)

Click the [Request] button to obtain the card serial number.


Input the correct password to read, write, increase or decrease the card.



5.6 Mifare_ProX


Click [Reset] button to obtain the serial number and the reset information of the card according to ISO14443-4 protocol.

Input the COS command, click [Send] button to commute data to card.




5.7 RH1064

Click [Request] button to obtain the card serial number. Hereafter can read, write and validate.



5.8 R176


Click [Req] button to obtain the ID number of the card.
Then you can read, write and lock blocks of the card.



5.9 RIX4K

Click [Req] button to obtain the ID number of the card and click [Read UID] to obtain the UID of the card.

Then you can read, write and lock blocks of the card.



5.10 AT88RF020


Click [ReqB] button to obtain the serial number of the card.
 After check password, you can read, write, signature and lock blocks of the card.



5.11 ISO14443B-4 Protocol Smart Card

Click [Reset] button to obtain the serial number and the reset information of the card according to ISO14443-4 protocol.


Input the COS command, click [Send] button to commute data to card.



5.12 I.CODE GZI

Click [INVENTORY] button to obtain the serial number of the card. You can operate 4 cards at most.


Choose certain card according to the UID to read or write.



5.13 ag_IT

Click [INVENTORY] button to obtain the serial number of the card. You can operate 4 cards at most.


Choose certain card according to the UID to read/write.



5.14 RF55V02P

Click [INVENTORY] button to obtain the serial number of the card. You can operate 4 cards at most.


Choose certain card according to the UID to read/write.



5.15 RF55V10P


Click [INVENTORY] button to obtain the serial number of the card. You can operate 4 cards at most.

Choose certain card according to the UID to read/write.



5.16 Pass_Through

In this windows, input parameters according to ISO14443B and ISO15693 protocol, click [Transceive] button to get response data from tag
CRC bytes is auto managed by reader, it will not be contained in the stream



6. DLL INFORMATION

All types of readers have system function and encrypt function.
Whether readers support other functions depends on their specific types.

6.1 YSTEM FUNCTION

6.1.1 INT WINAPI LIB_VER

Function: Get DLL Version

Prototype: int WINAPI lib_ver (unsigned int *pVer)

Parameter: pVer: [OUT] DLL version

Return: return 0 if successful

6.1.2 INT WINAPI RF_INIT_COM

Function: Connect

Prototype: int WINAPI rf_init_com (int port, long baud)

Parameter: port: [IN] serial port number

baud: [IN] communication baud rate, 4800 ~ 115200 bps

Return 0 on success

6.1.3 INT WINAPI RF_CLOSEPORT

Function: Disconnect

Prototyp: int WINAPI rf_ClosePort(void)

Return 0 on success

6.1.4 INT WINAPI RF_GET_MODEL

Function: Get Device Type

Prototype: int WINAPI rf_get_model (unsigned short icdev,
unsigned char *pVersion,
unsigned char *pLen)

Parameter: icdev: [IN] Device ID

pVersion: [OUT] response information

pLen: [OUT] length of response information

Return 0 on success

6.1.5 INT WINAPI RF_INIT_DEVICE_NUMBER

Function: Designate Device ID

Prototype: int WINAPI rf_init_device_number (unsigned short icdev)

Parameter: icdev: [IN] Device ID

Return 0 on success

6.1.6 INT WINAPI RF_GET_DEVICE_NUMBER

Function: Read Device ID

Prototype: int WINAPI rf_get_device_number (unsigned short *pIcdev)

Parameter: pIcdev: [OUT] response Device ID

Return 0 on success

6.1.7 INT WINAPI RF_INIT_TYPE

Function: Set Reader contactless working mode

Prototype: int WINAPI rf_init_type(unsigned short icdev, unsigned char type)

Parameter: icdev: [IN] Device ID

type: [IN] reader working mode

Return 0 on success

Explanation: this function is not effective to the readers only support single protocol.

type = 'A': set GZ500 into ISO14443A mode

type = 'B': set ISO14443B mode

type = 'r': set AT88RF020 card mode

type = 'l': set ISO15693 mode

6.1.8 INT WINAPI RF_ANTENNA_STA

Function: Manage RF Transmittal

Prototype: int WINAPI rf_antenna_sta (unsigned short icdev, unsigned char model)

Parameter: icdev: [IN] Device ID

model: [IN] transmittal state

Return 0 on success

Explanation: model = 0: turn off RF transmittal

model = 1: turn on RF transmittal

6.1.9 INT WINAPI RF_LIGHT

Function: Manage LED

Prototype: int WINAPI rf_light (unsigned short icdev, unsigned char color)

Parameter: icdev: [IN] Device ID

color: [IN] 0 = off

1 = red

2 = green

3 = yellow

Return 0 on success

6.1.10 INT WINAPI RF_BEEP

Function: beep

Prototype: int WINAPI rf_beep (unsigned short icdev, unsigned char msec)

Parameter: icdev: [IN] Device ID

msec: [IN] beep time, unit 10 MSEL

Return 0 on success

6.2 DES FUNCTION

6.2.1 INT WINAPI DES_ENCRYPT

Function: DES_Encrypt

Prototype: int WINAPI des_encrypt (unsigned char *pSzOut,
 unsigned char *pSzIn,
 unsigned int inlen,
 unsigned char *pKey,
 unsigned int keylen)

Parameter: pSzOut: [OUT] ciphertext, bytes length equal to plaintext
 pSzIn: [IN] plaintext
 inlen: [IN] length of plaintext, integer times of 8 bytes
 pKey: [IN] encrypt key
 keylen: [IN] length of key, 8 bytes for single DES, 16 bytes for triple DES

Return 0 on success

6.2.2 INT WINAPI DES_DECRYPT

Function: DES_Decrypt

Prototype: int WINAPI des_decrypt (unsigned char *pSzOut,
 unsigned char *pSzIn,
 unsigned int inlen,
 unsigned char *pKey,
 unsigned int keylen)

Parameter: pSzOut: [OUT] plaintext, bytes length equal to ciphertext
 pSzIn: [IN] ciphertext
 inlen: [IN] length of ciphertext, integer times of 8 bytes
 pKey: [IN] encrypt key
 keylen: [IN] length of key, 8 bytes for single DES, 16 bytes for triple DES

Return 0 on success

6.3 ISO14443A FUNCTION

6.3.1 UltraLight

6.3.1.1 INT WINAPI RF_REQUEST

Function: ReqA

Prototype: int WINAPI rf_request (unsigned short icdev,
 unsigned char model,
 unsigned short *pTagType)

Parameter: icdev: [IN] Device ID
 model: [IN] REQ MODE
 pTagType: [OUT] response data, chip type code

Return 0 on success

Annotation: mode = 0x26: REQ_STD
 mode = 0x52: REQ_ALL

6.3.1.2 INT WINAPI INT_RF_UL_SELECT

Function: Select UltraLight

Prototype: int WINAPI int_rf_ul_select (unsigned short icdev,
 unsigned char *pSnr,
 unsigned char *pLen)

Parameter: icdev: [IN] Device ID
 pSnr: [OUT] response data, card unique serial number
 pLen: [OUT] length of response data

Return 0 on success

6.3.1.3 INT WINAPI RF_M1_READ

Function: MifareOne read

Prototype: int WINAPI rf_M1_read (unsigned short icdev,
 unsigned char block,
 unsigned char *pData,
 unsigned char *pLen)

Parameter: icdev: [IN] Device ID
 block: [IN] block absolute address
 pData: [OUT] response data from card
 pLen: [OUT] length of response data

Return 0 on success

Annotation: this function is also applicable for UltraLight card. Every page of UltraLight card has 4 bytes. After calling this function, return data of 4 consecutive pages.

6.3.1.4 INT WINAPI INT_RF_UL_WRITE

Function: UltraLight Write

Prototype: int WINAPI int_rf_ul_write (unsigned short icdev,
 unsigned char page,
 unsigned char *pData)

Parameter: icdev: [IN] Device ID
 page: [IN] UltraLight card page address , 0 ~ 0x0F
 pData: [IN] written data, 4 bytes

Return 0 on success

6.3.1.5 INT WINAPI RF_HALT

Function: TYPE_A card HALT

Prototype: int WINAPI rf_halt (unsigned short icdev)

Parameter: icdev: [IN] Device ID

Return 0 on success

6.3.2 Mifare Class

6.3.2.1 INT WINAPI RF_REQUEST

Function: ReqA

Prototype: int WINAPI rf_request (unsigned short icdev,
unsigned char model,
unsigned short *pTagType)

Parameter: icdev: [IN] Device ID
model: [IN] REQ MODE
pTagType: [OUT] response data, chip type code

Return 0 on success

Annotation: mode = 0x26: REQ_STD
mode = 0x52: REQ_ALL

6.3.2.2 INT WINAPI RF_ANTICOLL

Function: Mifare card Anticollision

Prototype: int WINAPI rf_anticoll (unsigned short icdev,
unsigned char bcnt,
unsigned char *pSnr,
unsigned char *pLen)

Parameter: icdev: [IN] Device ID
bcnt: [IN] must be 4
pSnr: [OUT] response data from card, unique serial number
pLen: [OUT] length of response data

Return: return 0 if successful

6.3.2.3 INT WINAPI RF_SELECT

Function: Mifare card Selectting

Prototype: int WINAPI rf_select (unsigned short icdev,
unsigned char *pSnr,
unsigned char snrLen,
unsigned char *pSize)

Parameter: icdev: [IN] Device ID
pSnr: [IN] card unique serial number
snrLen: [IN] length of pSnr
pSize: [OUT] response data from card, capacity code

Return 0 on success

Annotation: card will be on active estate after received this command, only one TYPE_A card on active estate at the same influence range at same time.

6.3.2.4 INT WINAPI RF_M1_AUTHENTICATION2

Function: Mifare_Std Authenticate

```

Prototype: int WINAPI rf_M1_authentication2 ( unsigned short  icdev,
                                             unsigned char  model,
                                             unsigned char  block,
                                             unsigned char  *pKey)

```

Parameter: icdev: [IN] Device ID
 model: [IN] key validate mode
 block: [IN] block absolute address
 pKey: [IN] 6 bytes password

Return 0 on success

Annotation: model = 0x60: use KeyA

model = 0x61: use KeyB

6.3.2.5 INT WINAPI RF_M1_READ

Function: MifareOne Read

```

Prototype: int WINAPI rf_M1_read ( unsigned short  icdev,
                                   unsigned char  block,
                                   unsigned char  *pData,
                                   unsigned char  *pLen)

```

Parameter: icdev: [IN] Device ID
 block: [IN] block absolute address
 pData: [OUT] response data from card
 pLen: [OUT] length of response data

Return 0 on success

6.3.2.6 INT WINAPI RF_M1_WRITE

Function: Mifare_Std Write

```

Prototype: int WINAPI rf_M1_write (unsigned short icdev,
                                   unsigned char  block,
                                   unsigned char *pData)

```

Parameter: icdev: [IN] Device ID
 block: [IN] block absolute address
 pData: [IN] written data, 16 bytes

Return 0 on success

6.3.2.7 INT WINAPI RF_M1_INITVAL

Function: Mifare_Std card Initialize Value

```

Prototype: int WINAPI rf_M1_initval ( unsigned short  icdev,
                                       unsigned char  block,
                                       long  value)

```

Parameter: icdev: [IN] Device ID
 block: [IN] block absolute address
 pValue: [IN] initialize purse value at HEX format, low byte in former

Return 0 on success

6.3.2.8 INT WINAPI RF_M1_READVAL

Function: Mifare_Std Read Value

Prototype: int WINAPI rf_M1_readval (unsigned short icdev,
unsigned char block,
long *pValue)

Parameter: icdev: [IN] Device ID
block: [IN] block absolute address
pValue: [OUT] response value at HEX format, low byte in former

Return 0 on success

6.3.2.9 INT WINAPI RF_M1_INCREMENT

Function: Mifare purse increment

Prototype: int WINAPI rf_M1_increment (unsigned short icdev,
unsigned char block,
long value)

Parameter: icdev: [IN] Device ID
block: [IN] block absolute address
value: [IN] increase value at HEX format, low byte in former

Return 0 on success

6.3.2.10 INT WINAPI RF_M1_DECREMENT

Function: Mifare purse decrement

Prototype: int WINAPI rf_M1_decrement (unsigned short icdev,
unsigned char block,
long value)

Parameter: icdev: [IN] Device ID
block: [IN] block absolute address
value: [IN] decrease value at HEX format, low byte in former

Return 0 on success

6.3.2.11 INT WINAPI RF_M1_RESTORE

Function: Mifare_Std Restore

Prototype: int WINAPI rf_M1_restore (unsigned short icdev, unsigned char block)

Parameter: icdev: [IN] Device ID
block: [IN] block absolute address

Return 0 on success

6.3.2.12 INT WINAPI RF_M1_TRANSFER

Function: Mifare_Std Transfer

Prototype: int WINAPI rf_M1_transfer (unsigned short icdev, unsigned char block)

Parameter: icdev: [IN] Device ID
block: [IN] block absolute address

Return 0 on success

Annotation: this function only be transferred after increment, decrement and restore command

6.3.2.13 INT WINAPI RF_HALT

Function: Mifare Halt

Prototype: int WINAPI rf_halt (unsigned short icdev)

Parameter: icdev: [IN] Device ID

Return 0 on success

Annotation: card will exit active estate after received this command

6.3.3 Mifare_DESFire

6.3.3.1 INT WINAPI RF_DESFIRE_RST

Function: DESFire Reset

Prototype: int WINAPI rf_DESFire_rst (unsigned short icdev,
 unsigned char model,
 unsigned char *pData,
 unsigned char *pMsgLg)

Parameter: icdev: [IN] Device ID
 model: [IN] ReqA mode
 pData: [OUT] response data from card
 pMsgLg: [OUT] length of response data

Return 0 on success

Annotation: mode = 0x26: REQ_STD

mode = 0x52: REQ_ALL

pData = 7 bytes CSN + n bytes RATS according to ISO14443-4 protocol

6.3.3.2 INT WINAPI RF_COS_COMMAND

Function: DESFire data commutting

Prototype: int WINAPI rf_cos_command (unsigned short icdev,
 unsigned char *pCommand,
 unsigned char cmdLen,
 unsigned char *pData,
 unsigned char *pMsgLg)

Parameter: icdev: [IN] Device ID
 pCommand: [IN] COS command
 cmdLen: [IN] length of COS command
 pData: [OUT] response data from card
 pMsgLg: [OUT] length of response data

Return 0 on success

6.3.4 Mifare_ProX**6.3.4.1 INT WINAPI RF_TYPE_RST**

Function: Request ISO14443A-4 card and reset

Prototype: int WINAPI rf_typea_rst (unsigned short icdev,
 unsigned char model,
 unsigned char *pData,
 unsigned char *pMsgLg)

Parameter: icdev: [IN] Device ID
 model: [IN] request mode
 pData: [OUT] response data from card
 pMsgLg: [OUT] length of response data

Return 0 on success

Annotation: mode = 0x26: REQ_STD

mode = 0x52: REQ_ALL

pData: 4bytes CSN + RATS according to ISO14443A

6.3.4.2 INT WINAPI RF_COS_COMMAND

Prototype: int WINAPI rf_cos_command (unsigned short icdev,
 unsigned char *pCommand,
 unsigned char cmdLen,
 unsigned char *pData,
 unsigned char *pMsgLg)

Parameter: icdev: [IN] Device ID
 pCommand: [IN] COS command
 cmdLen: [IN] length of COS command
 pData: [OUT] response data from card, including SW1& SW2
 pMsgLg: [OUT] length of response data

Return 0 on success

6.3.4.3 INT WINAPI RF_CL_DESELECT

Prototype: int WINAPI rf_cl_deselect (unsigned short icdev)

Parameter: icdev: [IN] Device ID

Return 0 on success

6.3.5 SHC1102**6.3.5.1 INT WINAPI RF_REQUEST**

Function: ReqA

Prototype: int WINAPI rf_request (unsigned short icdev,
 unsigned char model,
 unsigned short *pTagType)

Parameter: icdev: [IN] Device ID
 model: [IN] REQ MODE
 pTagType: [OUT] response data from card, chip type code

Return 0 on success

Annotation: mode = 0x26: REQ_STD
mode = 0x52: REQ_ALL

6.3.5.2 INT WINAPI RF_SHC1102_AUTH

Function: SHC1102 card Authenticate

Prototype: int WINAPI rf_Shc1102_Auth (unsigned short icdev, unsigned char *pPassword)

Parameter: icdev: [IN] Device ID
pPassword: [IN] 4 bytes password

Return 0 on success

6.3.5.3 INT WINAPI RF_SHC1102_READ

Function: SHC1102 card read

Prototype: int WINAPI rf_Shc1102_Read (unsigned short icdev,
unsigned char block,
unsigned char *pData,
unsigned char *pLen)

Parameter: icdev: [IN] Device ID
block: [IN] SHC1102 card block address, 0x00 ~ 0x0F
pData: [OUT] response data from card
pLen: [OUT] length of response data

Return 0 on success

6.3.5.4 INT WINAPI RF_SHC1102_WRITE

Function: SHC1102 card write

Prototype: int WINAPI rf_Shc1102_Write (unsigned short icdev,
unsigned char block,
unsigned char *pData)

Parameter: icdev: [IN] Device ID
block: [IN] SHC1102 card block address, 0x00 ~ 0x0F
pData: [IN] written data, 16 bytes

Return 0 on success

6.4 ISO14443B FUNCTION

6.4.1 THR1064

6.4.1.1 INT WINAPI RF_TYPEB_RST

Function: REQ THR1064 card

Prototype: int WINAPI rf_atqb (unsigned short icdev,
 unsigned char model,
 unsigned char *pData,
 unsigned char *pMsgLg)

Parameter: icdev: [IN] Device ID
 model: [IN] REQ MODE 0=REQB, 1=WUPB
 pData: [OUT] response data from card, 8 bytes SN + 4 bytes corresponding data
 pMsgLg: [OUT] length of response data

Return 0 on success

6.4.1.2 INT WINAPI RF_THR1064_READ

Function: THR1064 card read

Prototype: int WINAPI rf_thr1064_read(unsigned short icdev,
 unsigned char page,
 unsigned char *pData,
 unsigned char *pMsgLen)

Parameter: icdev: [IN] Device ID
 page: [IN] page address, 0 ~3
 pData: [OUT] response data from card
 pMsgLen: [OUT] length of response data

Return 0 on success

6.4.1.3 INT WINAPI RF_THR1064_WRITE

Function: THR1064 card write

Prototype: int WINAPI rf_thr1064_write (unsigned short icdev,
 unsigned char page,
 unsigned char *pData,
 unsigned char *pMsgLen);

Parameter: icdev: [IN] Device ID
 page: [IN] page address, 0 ~3
 pData: [IN] written data
 pMsgLen: [OUT] length of written data

Return 0 on success

6.4.1.4 INT WINAPI RF_THR1064_CHECK

Function: THR1064 card Authenticate

Prototype: int WINAPI rf_thr1064_check (unsigned short icdev, unsigned char *pKey)

Parameter: icdev: [IN] Device ID

pKey: [IN] 8 bytes pass word

Return 0 on success

6.4.2 AT88RF020

6.4.2.1 INT WINAPI RF_ TYPEB_RST

Function: REQ ISO14443B protocol card and set GZOT

Prototype: int WINAPI rf_atqb(unsigned short icdev,
 unsigned char model,
 unsigned char *pData,
 unsigned char *pMsgLg)

Parameter: icdev: [IN] Device ID
 model: [IN] REQ MODE 0 = REQB, 1 = WUPB
 pData: [OUT] response data from card
 pMsgLg: [OUT] length of response data

Return 0 on success

6.4.2.2 INT WINAPI RF_ AT020_CHECK

Function: AT88RF020 card Authenticate

Prototype: int WINAPI rf_at020_check (unsigned short icdev, unsigned char *pKey)

Parameter: icdev: [IN] Device ID
 pKey: [IN] 8 bytes pass word

Return 0 on success

6.4.2.3 INT WINAPI RF_ AT020_COUNT

Function: AT88RF020 card count

Prototype: int WINAPI rf_at020_count(unsigned short icdev, unsigned char *pData)

Parameter: icdev: [IN] Device ID
 pData: [IN] signature, 6 bytes

Return 0 on success

6.4.2.4 INT WINAPI RF_ AT020_READ

Function: AT88RF020 read

Prototype: int WINAPI rf_at020_read (unsigned short icdev,
 unsigned char page,
 unsigned char *pData,
 unsigned char *pMsgLen)

Parameter: icdev: [IN] Device ID
 page: [IN] page address, 0 ~ 31
 pData: [OUT] response data from card
 pMsgLen: [OUT] length of response data

Return 0 on success

6.4.2.5 INT WINAPI RF_AT020_WRITE

Function: AT88RF020 write

```

Prototype: int WINAPI rf_at020_write ( unsigned short icdev,
                                     unsigned char  page,
                                     unsigned char  *pData)

```

```

Parameter: icdev:    [IN]    Device ID
           page:     [IN]    page address, 0 ~ 31
           pData:    [IN]    written data, 8 bytes

```

Return 0 on success

6.4.2.6 INT WINAPI RF_AT020_LOCK

Function: AT88RF020 LOCK

```

Prototype: int WINAPI rf_at020_lock (unsigned short icdev, unsigned char *pData)

```

```

Parameter: icdev:    [IN]    Device ID
           pData:    [IN]    4 bytes data

```

Return 0 on success

6.4.2.7 INT WINAPI RF_AT020_DESELECT

Function: AT88RF020 card Deselect

```

Prototype: int WINAPI rf_at020_deselect (unsigned short icdev)

```

```

Parameter: icdev:    [IN]    Device ID

```

Return 0 on success

6.4.3 SR176SRIX4K**6.4.3.1 INT WINAPI RF_ST_SELECT**

Function: ST card (SR176/SRIX4K) Lock

```

Prototype: int WINAPI rf_st_select (unsigned short icdev, unsigned char *pChip_ID)

```

```

Parameter: icdev:    [IN]    Device ID
           pChip_ID: [IN]    response data from card, 1 byte ID code

```

Return 0 on success

6.4.3.2 INT WINAPI INT_RF_SR176_READBLOCK

Function: SR176 Read

```

Prototype: int WINAPI int_rf_sr176_readblock ( unsigned short icdev,
                                               unsigned char  block,
                                               unsigned char  *pData,
                                               unsigned char  *pLen)

```

```

Parameter: icdev:    [IN]    Device ID
           block:    [IN]    block address
           pData:    [OUT]   response data from card
           pLen:     [OUT]   length of response data

```

Return 0 on success

6.4.3.3 INT WINAPI INT_RF_SR176_WRITEBLOCK

Function: SR176 Write

Prototype: int WINAPI int rf_sr176_writeblock (unsigned short icdev,
 unsigned char block,
 unsigned char *pData)

Parameter: icdev: [IN] Device ID
 block: [IN] block address
 pData: [IN] written data, 2 bytes

Return 0 on success

6.4.3.4 INT WINAPI INT_RF_SR176_PROTECTBLOCK

Function: SR176 Lock

Prototype: int WINAPI int rf_sr176_protectblock (unsigned short icdev, unsigned char lockreg)

Parameter: icdev: [IN] Device ID
 lockreg: [IN] LOCKREG

Return 0 on success

Annotation: SR176 has 16 blocks, every lockreg controls 2 blocks

| lockreg | BLOCK | bit_setting | |
|---------|---------|----------------|--------------------|
| b7 | 14 & 15 | 0:Write Enable | 1:Block set as ROM |
| b6 | 12 & 13 | 0:Write Enable | 1:Block set as ROM |
| b5 | 10 & 11 | 0:Write Enable | 1:Block set as ROM |
| b4 | 8 & 9 | 0:Write Enable | 1:Block set as ROM |
| b3 | 6 & 7 | 0:Write Enable | 1:Block set as ROM |
| b2 | 4 & 5 | 0:Write Enable | 1:Block set as ROM |
| b1 | 2 & 3 | 0:Write Enable | 1:Block set as ROM |
| b0 | 0 & 1 | 0:Write Enable | 1:Block set as ROM |

6.4.3.5 INT WINAPI INT_RF_SRIX4K_GETUID

Function: SRIX4K Get UID

Prototype: int WINAPI int rf_srix4k_getuid (unsigned short icdev,
 unsigned char *pUid,
 unsigned char *pLen)

Parameter: icdev: [IN] Device ID
 pUid: [OUT] response data from card, UID
 pLen: [OUT] length of response data

Return 0 on success

6.4.3.6 INT WINAPI INT_RF_SRIX4K_READBLOCK

Function: SRIX4K Read

Prototype: int WINAPI int rf_srix4k_readblock (unsigned short icdev,
 unsigned char block,
 unsigned char *pData,
 unsigned char *pLen)

Parameter: icdev: [IN] Device ID
 block: [IN] block address
 pData: [OUT] response data from card
 pLen: [OUT] length of response data

Return 0 on success

6.4.3.7 INT WINAPI INT_RF_SRIX4K_WRITEBLOCK

Function: SRIX4K Write

Prototype: int WINAPI int rf_srix4k_writeblock(unsigned short icdev,
 unsigned char block,
 unsigned char *pData)

Parameter: icdev: [IN] Device ID
 block: [IN] block address
 pData: [IN] written data, 4bytes

Return 0 on success

6.4.3.8 INT WINAPI INT_RF_SRIX4K_PROTECTBLOCK

Function: SRIX4K Lock

Prototype: int WINAPI int rf_srix4k_protectblock(unsigned short icdev, unsigned char lockreg)

Parameter: icdev: [IN] Device ID
 Lockreg: [IN] LOCKREG

Return 0 on success

Annotation: 7~15 blocks of SRIX4K card can be written protect

| lockreg | BLOCK | bit_setting | |
|---------|-------|----------------|--------------------|
| b7 | 15 | 1:Write Enable | 0:Block set as ROM |
| b6 | 14 | 1:Write Enable | 0:Block set as ROM |
| b5 | 13 | 1:Write Enable | 0:Block set as ROM |
| b4 | 12 | 1:Write Enable | 0:Block set as ROM |
| b3 | 11 | 1:Write Enable | 0:Block set as ROM |
| b2 | 10 | 1:Write Enable | 0:Block set as ROM |
| b1 | 9 | 1:Write Enable | 0:Block set as ROM |
| b0 | 7 & 8 | 1:Write Enable | 0:Block set as ROM |

6.4.3.9 INT WINAPI RF_ST_COMPLETION

Function: ST Desactivated

Prototype: int WINAPI rf_st_completion (unsigned short icdev)

Parameter: icdev: [IN] Device ID

Return 0 on success

6.4.4 TYPE_B SmartCard

6.4.4.1 INT WINAPI RF_TYPEB_RST

Function: Req ISO14443B-4 protocol Smart card and Reset

Prototype: int WINAPI rf_atqb (unsigned short icdev,
unsigned char model,
unsigned char *pData,
unsigned char *pMsgLg)

Parameter: icdev: [IN] Device ID
model: [IN] REQ MODE 0 = REQB, 1 = WUPB
pData: [OUT] response data from card
pMsgLg: [OUT] length of response data

Return 0 on success

6.4.4.2 INT WINAPI RF_COS_COMMAND

Prototype: int WINAPI rf_cos_command (unsigned short icdev,
unsigned char *pCommand,
unsigned char cmdLen,
unsigned char *pData,
unsigned char *pMsgLg)

Parameter: icdev: [IN] Device ID
pCommand: [IN] cos command
cmdLen: [IN] length of cos comman
pData: [OUT] response data from card, including SW1, SW2
pMsgLg: [OUT] length of response data

Return 0 on success

6.4.4.3 INT WINAPI RF_CL_DESELECT

Function: ISO14443B card Deselect

Prototype: int WINAPI rf_cl_deselect (unsigned short icdev)

Parameter: icdev: [IN] Device ID

Return 0 on success

6.5 ISO15693 FUNCTION

6.5.1 INT WINAPI ISO15693_INVENTORY

Function: ISO15693_Inventory (single card)

Prototype: int WINAPI ISO15693_Inventory (unsigned short icdev,
unsigned char *pData,
unsigned char *pLen)

Parameter: icdev: [IN] Device ID
pData: [OUT] response data from tag, 1 byte DSFID + 8 bytes UID
pLen: [OUT] length of response data

Return 0 on success

6.5.2 INT WINAPI ISO15693_INVENTORYS

Function: ISO15693_Inventory (several cards)

Prototype: int WINAPI ISO15693_Inventorys (unsigned short icdev,
unsigned char *pData,
unsigned char *pLen)

Parameter: icdev: [IN] Device ID
pData: [OUT] response data from tag, every 9 bytes is a team, the structure of
every team is:
1byte DSFID + 8 bytes UID
pLen: [OUT] length of response data

Return 0 on success

6.5.3 INT WINAPI ISO15693_GET_SYSTEM_INFORMATION

Function: ISO15693_Get_System_Information

Prototype: int WINAPI ISO15693_Get_System_Information(unsigned short icdev,
unsigned char model,
unsigned char *pUID,
unsigned char *pData,
unsigned char *pLen)

Parameter: icdev: [IN] Device ID
model: [IN] bit0=Select_flag, bit1=Address_flag, bit2=Option_flag
pUID: [IN] 8 bytes UID
pData: [OUT] response data from tag
pLen: [OUT] length of response data

Return 0 on success

Annotation: If set Select_flag, only the cards on Selected state respond this command
If set Address_flag, only the cards that the UID are congruous will respond
this command
Clear Option_flag = 0

6.5.4 INT WINAPI ISO15693_SELECT

Function: ISO15693_Select

Prototype: int WINAPI ISO15693_Select (unsigned short icdev, unsigned char *pUID)

Parameter: icdev: [IN] Device ID
 pUID: [IN] 8 bytes UID

Return 0 on success

6.5.5 INT WINAPI ISO15693_RESET_TO_READY

Function: ISO15693_Reset_To_Ready

Prototype: int WINAPI ISO15693_Reset_To_Ready (unsigned short icdev,
 unsigned char model,
 unsigned char *pUID)

Parameter: icdev: [IN] Device ID
 model: [IN] bit0=Select_flag, bit1=Address_flag, bit2=Option_flag
 pUID: [IN] 8 bytes UID

Return 0 on success

Annotation: If set Select_flag, only the cards on Selected state respond this command
 If set Address_flag, only the cards that the UID are congruous will respond
 this command
 Clear Option_flag = 0

6.5.6 INT WINAPI ISO15693_STAY_QUIET

Function: ISO15693_Stay_Quiet

Prototype: int WINAPI ISO15693_Stay_Quiet (unsigned short icdev, unsigned char *pUID)

Parameter: icdev: [IN] Device ID
 pUID: [IN] 8 bytes UID

Return 0 on success

6.5.7 INT WINAPI ISO15693_GET_BLOCK_SECURITY

Function: ISO15693_Get_Block_Security

Prototype: int WINAPI ISO15693_Get_Block_Security (unsigned short icdev,
 unsigned char model,
 unsigned char *pUID,
 unsigned char block,
 unsigned char number,
 unsigned char *pData,
 unsigned char *pLen)

Parameter: icdev: [IN] Device ID
 model: [IN] bit0=Select_flag, bit1=Address_flag, bit2=Option_flag
 pUID: [IN] 8 bytes UID
 block: [IN] block address
 number: [IN] the number of block to be read, < 0x40
 pData: [OUT] response data from tag
 pLen: [OUT] length of response data

Return 0 on success

Annotation: If set Select_flag, only the cards on Selected state respond this command
 If set Address_flag, only the cards that the UID are congruous will respond this command
 Clear Option_flag = 0

6.5.8 INT WINAPI ISO15693_READ

Function: ISO15693_Read

```

Prototype: int WINAPI ISO15693_Read ( unsigned short  icdev,
                                     unsigned char   model,
                                     unsigned char   *pUID,
                                     unsigned char   block,
                                     unsigned char   number,
                                     unsigned char   *pData,
                                     unsigned char   *pLen);
  
```

Parameter: icdev: [IN] Device ID
 model: [IN] bit0=Select_flag, bit1=Address_flag, bit2=Option_flag
 pUID: [IN] 8 bytes UID
 block: [IN] block address
 number: [IN] the number of block to be read, < 0x40
 pData: [OUT] response data from tag
 pLen: [OUT] length of response data

Return 0 on success

Annotation: If set Select_flag, only the cards on Selected state respond this command
 If set Address_flag, only the cards that the UID are congruous will respond this command
 Clear Option_flag = 0

6.5.9 INT WINAPI ISO15693_WRITE

Function: ISO15693_Write

```

Prototype: int WINAPI ISO15693_Write ( unsigned short  icdev,
                                       unsigned char   model,
                                       unsigned char   *pUID,
                                       unsigned char   block,
                                       unsigned char   *pData)
  
```

Parameter: icdev: [IN] Device ID
 model: [IN] bit0=Select_flag, bit1=Address_flag, bit2=Option_flag
 pUID: [IN] 8 bytes UID
 block: [IN] block address
 pData: [IN] written data, 4 bytes

Return 0 on success

Explanation: If set Select_flag, only the cards on Selected state respond this command
 If set Address_flag, only the cards that the UID are congruous will respond this command

If write TI card, set Option_flag,
 If write I.CODE GZI card, clear Option_flag

6.5.10 INT WINAPI ISO15693_LOCK_BLOCK

Function: ISO15693_Lock_Block

Prototype: int WINAPI ISO15693_Lock_Block (unsigned short icdev,
 unsigned char model,
 unsigned char *pUID,
 unsigned char block)

Parameter: icdev: [IN] Device ID
 model: [IN] bit0=Select_flag, bit1=Address_flag, bit2=Option_flag
 pUID: [IN] 8 bytes UID
 block: [IN] block address

Return 0 on success

Annotation: If set Select_flag, only the cards on Selected state respond this command
 If set Address_flag, only the cards that the UID are congruous will respond this command
 If write TI card, set Option_flag,
 If write I.CODE GZI card, clear Option_flag

6.5.11 NT WINAPI ISO15693_WRITE_AFI

Function: ISO15693_Write_AFI

Prototype: int WINAPI ISO15693_Write_AFI (unsigned short icdev,
 unsigned char model,
 unsigned char *pUID,
 unsigned char AFI)

Parameter: icdev: [IN] Device ID
 model: [IN] bit0=Select_flag, bit1=Address_flag, bit2=Option_flag
 pUID: [IN] 8 bytes UID
 AFI: [IN] AFI to be written

Return 0 on success

Annotation: If set Select_flag, only the cards on Selected state respond this command
 If set Address_flag, only the cards that the UID are congruous will respond this command
 If write TI card, set Option_flag,
 If write I.CODE GZI card, clear Option_flag

6.5.12 INT WINAPI ISO15693_LOCK_AFI

Function: ISO15693_Lock_AFI

Prototype: int WINAPI ISO15693_Lock_AFI (unsigned short icdev,
 unsigned char model,
 unsigned char *pUID)

Parameter: icdev: [IN] Device ID
 model: [IN] bit0=Select_flag, bit1=Address_flag, bit2=Option_flag

pUID: [IN] 8 bytes UID

Return 0 on success

Annotation: If set Select_flag, only the cards on Selected state respond this command
 If set Address_flag, only the cards that the UID are congruous will respond this command
 If write TI card, set Option_flag,
 If write I.CODE GZI card, clear Option_flag

6.5.13 INT WINAPI ISO15693_WRITE_DSFD

Function: ISO15693_Write_DSFD

Prototype: int WINAPI ISO15693_Write_DSFD (unsigned short icdev,
 unsigned char model,
 unsigned char *UID,
 unsigned char DSFD)

Parameter: icdev: [IN] Device ID
 model: [IN] bit0=Select_flag, bit1=Address_flag, bit2=Option_flag
 pUID: [IN] 8 bytes UID
 DSFD: [IN] DSFD to be written

Return 0 on success

Annotation: If set Select_flag, only the cards on Selected state respond this command
 If set Address_flag, only the cards that the UID are congruous will respond this command
 If write TI card, set Option_flag,
 If write I.CODE GZI card, clear Option_flag

6.5.14 INT WINAPI ISO15693_LOCK_DSFD

Function: ISO15693_Lock_DSFD

Prototype: int WINAPI ISO15693_Lock_DSFD (unsigned short icdev,
 unsigned char model,
 unsigned char *pUID)

Parameter: icdev: [IN] Device ID
 model: [IN] bit0=Select_flag, bit1=Address_flag, bit2=Option_flag
 pUID: [IN] 8 bytes UID

Return 0 on success

Annotation: If set Select_flag, only the cards on Selected state respond this command
 If set Address_flag, only the cards that the UID are congruous will respond this command
 If write TI card, set Option_flag,
 If write I.CODE GZI card, clear Option_flag

6.6 Function of Infineon Electric Tag

6.6.1 INT WINAPI SRF55VP_READ

Function: SRF55XXP Read a PAGE

```

Prototype: int WINAPI Srf55vp_Read ( unsigned short   icdev,
                                     unsigned char    *pUID,
                                     unsigned char    page,
                                     unsigned char    *pData,
                                     unsigned char    *pLen)
  
```

Parameter: icdev: [IN] Device ID
 pUID: [IN] 8 bytes UID
 page: [IN] address
 pData: [OUT] response data from tag
 pLen: [OUT] length of response data

Return 0 on success

6.6.2 INT WINAPI SRF55VP_WRITEBYTE

Function: SRF55XXP Write 1BYTE

```

Prototype: int WINAPI Srf55vp_WriteByte ( unsigned short   icdev,
                                           unsigned char    *pUID,
                                           unsigned char    page,
                                           unsigned char    byteaddr,
                                           unsigned char    data)
  
```

Parameter: icdev: [IN] Device ID
 pUID: [IN] 8 bytes UID
 page: [IN] address
 byteaddr: [IN] write the bytes to excursion address of the PAGE, 0 ~ 8
 data: [IN] written data

Return 0 on success

6.6.3 INT WINAPI SRF55VP_WRITE

Function: SRF55XXP Write a page

```

Prototype: int WINAPI Srf55vp_Write ( unsigned short   icdev,
                                       unsigned char    *pUID,
                                       unsigned char    page,
                                       unsigned char    *pData)
  
```

Parameter: icdev: [IN] Device ID
 pUID: [IN] 8 bytes UID
 page: [IN] address
 pData: [IN] written data, 8 bytes

Return 0 on success

6.6.4 INT WINAPI SRF55VP_WRITE_REREAD

Function: SRF55XXP write PAGE and Return to the real data of this PAGE

Prototype: int WINAPI Srf55vp_Write_Reread(unsigned short icdev,
 unsigned char *pUID,
 unsigned char page,
 unsigned char *pWdata,
 unsigned char *pRdata,
 unsigned char *pLen)

Parameter: icdev: [IN] Device ID
 pUID: [IN] 8 bytes UID
 page: [IN] address
 pWdata: [IN] written data, 8bytes
 pRdata: [OUT] response data from tag
 pLen: [OUT] length of response data

Return 0 on success

6.7 PASS THROUGH FUNCTION

6.7.1 INT WIN API RF_TRANSCEIVE1

Function: Send parameteres to Tag and receive response data

Prototype: int WINAPI rf_transceive1(unsigned short icdev,
 unsigned char *pTxData,
 unsigned char sendLen,
 unsigned char *pRxData,
 unsigned char *pMsgLg)

Parameter: icdev: [IN] Communication device identifier
 pTxData: [IN] parameter sent to tag, without CRC bytes
 CRC bytes is auto managed by reader
 sendLen: [IN] length of parameter
 pRxData: [OUT] response data from tag
 pMsgLg: [OUT] length of response data

Return 0 on success