




USER'S MANUAL
for
3000 Pro Runner



BUILT FOR HEALTH

CONTENT

Important safety precautions	3
Assembly instructions	4
Folding & unfolding instructions	7
Grounding methods	8
Operation guide	9
Getting started guide	14
Safety exercises	15
Warm-up exercises	16
Maintenance instructions	17
Belt adjustment	18
Exploded drawing	19
Parts list	20
Error code and significance	23
Service	25

IMPORTANT SAFETY PRECAUTIONS













WARNING: Before starting any exercise program, consult with your physician or health professional, especially the person who is above 35 years old people or has some health problems before. We take no responsibility for any troubles or hurts due to above reasons. Don't power on until you finish assembly the treadmill and covering the protected top of motor.

ATTENTIONS:


1. When using this treadmill, keep attaching the safety pull pin rope to your clothes or belt.
2. Do not plug anything into any parts of this equipment, or it may damage.
3. Position the treadmill on a clear, level surface. Do not place the treadmill on thick carpet as it may interfere with proper ventilation. Also, do not place the treadmill near water or outdoors.
4. Never start the treadmill while you are standing on the walking belt. After turning the power on and adjusting the speed control, there may be a pause before the walking belt begins to move, always stand on the foot rails on the sides of the frame until the belt is moving.
5. Wear appropriate clothing when exercising on the treadmill. Do not wear long, loose fitting clothing that could become caught in the treadmill. Always wear running or aerobic shoes with rubber soles.
6. Keep small children or pet away from the treadmill during operation.
7. Do not do exercise in 40 minutes after meal.
8. The treadmill is only used for adults, child use the treadmill must have adult on side.
9. Always hold the handrails when initially walking or running on the treadmill, until you are familiar with the use of the treadmill.
10. The treadmill is for indoor equipment, do not use outdoor. Position the treadmill on a clean, level surface. Note the treadmill made by special equipment, please do not remodel or do others.
11. The power cord of motorized treadmill is specialized. If the power cord is damaged, please purchase it from distributor or contact our company directly.
12. If the treadmill should suddenly increase in speed due to an electronics failure or the speed inadvertently increased, the treadmill will come to a sudden stop when the pull pin is disengaged from the console.
13. Do not connection in the middle of power cord, extending the power cord or replace the power cord plug. Stacked weight object on the power cord or make the power cord near the high temperature heat, prohibit use the porous socket, otherwise it will cause fire or electric shock injury accident because of poor contact.
14. When the treadmill is not being used, the power cord should be unplugged and the safety pull pin removed. Note the power cord of motorized treadmill made by special equipment, and if it is broken, please contact distributor quickly.
15. The treadmill is for home use only.
16. The treadmill maximum user weight is 130kgs
17. Please do not overuse the treadmill so can avoid any injury and do not use incorrect way for your safety.
18. When the treadmill is not being used, please keep the safety pull pin in the safety place to avoid the other use.

ASSEMBLY


When you open the carton, you will find the below spare parts:

<p>1 Main frame 1set</p> 	<p>D7 Washer 8PCS</p> 	<p>D23Half round hex bolt M10*15 4PCS</p> 	<p>C15 Safety key 1set</p> 
<p>D36 Allen wrench 80*80*6 1 PC</p> 	<p>B6 Silicon oil 1 PC</p> 	<p>D24Half round hex bolt M10*55 4 PCS</p> 	<p>D 41Screw driver 1PC</p> 
<p>D40 Screw ϕ 4.2*25 6PCS</p> 	<p>B26 Left side cover 1PC</p> 	<p>B27 Right side cover 1PC</p> 	<p>C29 MP3 Line</p> 


STEP 1: According to the following steps to lift up the computer bracket. Be careful not press the line when folding



STEP 2: According to the picture to tight the bolt M10*15 (D23) ,M10*55(D24)and inner washer (D7)




Step 3: Fix the Left side cover(B26) and Right side cover(B27) on the upright with self-tapping screw(D40), then put on the safety key(C15) and insert MP3 line(C29) on the computer




ATTENTION: Must confirm complete assembly as the required above and lock all bolts. Do the following operations after checking everything is OK. Before you use the treadmill, please read the instructions carefully.

FOLDING INSTRUCTION



Lift up the machine and force to pull up until you heard "click" that made by safety casing stuck the pneumatic cylinder.

UNFOLDING INSTRUCTION



Kick the safety sleeve lightly and pull down the machine at the same time as the arrow direction. Then the machine will fall down smoothly.

GROUNDING METHODS

This product must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This product is equipped with a cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

DANGER – Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product – if it will not fit the outlet, Please find a proper outlet installed by a qualified electrician.

This product is for use on a nominal 220V circuit and has a grounding plug . Make that the product is connected to an outlet having the same configuration as the plug. No adapter should be used with this product.

OPERATION GUIDE

1.1. WINDOW DISPLAY



1.2. START

Normal start after 5 seconds countdown

1.3 PROGRAM

1 manual mode, 16 pre-set programs, 1 body fat program ,3 countdown function , 3 users

1.4. SAFETY LOCK FUNCTION

The window shows "---" when take away the safety lock and the treadmill will stop quickly with "didi" alarm noise. And put the safety lock on, the computer will display for 2 seconds and the date count down to "0"

1.5. BUTTON FUNCTION

1.5.1. START/STOP

“START”--When the treadmill is not running, press this button to start, speed is “0.8”

“STOP”--When the treadmill is running, press this button to stop, then set program default and then return to manual mode after stopped.

1.5.2 “PROGRAM” BUTTON

When the treadmill is not running, press this button can circle choose from manual mode to pre-set mode P1-P15,U1-U3 and body fat;

1.5.3 “MODE” BUTTON

When the treadmill is not running, press this button to choose countdown modes:“H-1”,“H-2”,“H-3”;“H-1” is the time countdown mode, and “H-2” is the distance countdown mode, “H-3” is the calorie countdown mode; press the “SPEED+/-” or “INCLINE+/-”button to adjust the data. After that, press the “START” button to start this treadmill

1.5.4 “SPEED +/-” BUTTON

SPEED +/- --Adjust speed when treadmill start, the increment is 0.1km/time in kilometer. Press the button more than 2 seconds, and it will be up or down automatically.

1.5.5 SPEED QUICK BUTTON

Press the speed quick button 5km/h, 10km/h, 15km/h to adjust the speed directly when the treadmill is running

1.5.6 “INCLINE+/-” BUTTON

INCLINE +/- --Adjust incline when treadmill start; the increment is 1 level/time. Press the button more than 2 seconds, and it will be up or down automatically

1.5.7 INCLINE QUICK BUTTON

Press the incline quick button 3, 6, 9 to adjust the incline directly when the treadmill is running

1.6. DISPLAY FUNCTION

1.6.1 SPEED

Display running speed

1.6.2 TIME

Display the running time or countdown time

1.6.3 DISTANCE

Display the running total distance or distance countdown.

1.6.4 CALORIE

Display the calorie or calorie countdown

1.6.5 INCLINE

Display the incline

1.6.6 PULSE

Display pulse data

1.6.7 ALL WINDOW DISPLAY DATA RANGE

TIME: 0:00 – 99.59(MIN)

DISTANCE: 0.00 – 99.9(KM)

CALORIES: 0.0 – 999 (C)

SPEED:0.8-20.0(km/h)

PULSE: 50 – 200 (BPM)

INCLINE: 0 – 15

1.7. PULSE FUNCTION

When the treadmill is running, hold the hand pulse about 5 seconds, it will display pulse data. The pulse data range is 50-200 times/ minute. It has heart-shaped graphics when testing pulse. This data is only for reference, can not be as medical data.

1.8. PROGRAM EXERCISE CHART

		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
P01	SPD	2	5	5	5	10	10	5	5	5	3	3	2	5	5	3	2
	INC	0	0	1	1	1	1	2	2	2	2	3	3	3	2	2	0
P02	SPD	2	2	7	2	2	7	7	12	4	4	12	4	4	12	4	2
	INC	0	1	2	2	3	3	2	2	3	3	2	2	3	2	2	0
P03	SPD	2	4	9	9	4	4	8	8	10	10	12	4	4	8	4	2
	INC	0	1	2	3	4	5	4	5	4	2	1	2	3	2	1	0
P04	SPD	2	6	6	6	12	12	12	12	6	6	3	3	3	5	5	2
	INC	0	1	2	3	4	5	6	7	6	6	5	4	3	2	1	0
P05	SPD	2	4	6	12	12	12	3	3	3	3	12	12	12	6	4	2
	INC	0	2	4	6	4	2	1	0	1	1	2	2	2	2	3	0
P06	SPD	2	4	5	5	6	6	8	8	6	6	8	8	6	9	6	2
	INC	0	1	3	4	4	3	3	1	2	1	2	1	2	1	2	0
P07	SPD	2	7	7	9	9	4	4	12	12	4	4	8	8	4	4	2
	INC	0	1	1	2	2	3	3	4	4	3	3	2	2	1	1	0
P08	SPD	2	2	6	6	6	8	9	10	11	12	9	5	5	5	3	2
	INC	0	1	2	4	2	1	2	4	2	1	2	4	2	1	2	0
P09	SPD	2	4	8	10	2	4	8	10	2	4	10	2	4	10	4	2
	INC	0	1	2	3	4	5	6	7	8	9	8	6	4	2	1	0
P10	SPD	2	5	6	7	8	9	10	11	10	9	8	6	7	5	4	2
	INC	0	1	2	4	6	6	6	4	4	4	2	2	2	1	1	0
P11	SPD	2	5	6	7	9	9	6	9	6	9	6	10	6	10	7	2
	INC	0	2	2	2	3	3	3	4	4	4	5	5	5	4	4	0
P12	SPD	2	6	8	10	8	6	4	6	8	12	8	6	8	12	12	2
	INC	0	1	1	3	3	5	5	7	7	5	5	3	3	1	1	0
P13	SPD	2	12	4	12	4	12	4	12	4	12	4	12	4	12	4	2
	INC	0	8	10	13	4	8	10	13	4	8	10	13	4	8	10	0
P14	SPD	2	8	10	12	4	8	10	12	4	8	10	12	4	8	10	2
	INC	0	8	12	13	4	8	12	13	4	8	12	13	4	8	12	0
P15	SPD	2	12	10	8	12	12	10	8	12	12	10	8	12	12	10	2
	INC	0	3	4	5	6	8	7	8	8	7	7	6	5	4	3	0
P16	SPD	2	12	4	12	4	12	4	12	4	12	4	12	4	12	4	2
	INC	0	4	5	6	2	4	5	6	2	4	5	6	2	4	5	0

1.9 MANUAL MODEL OPERATION

1.9.1 Press start key, time count down 5 seconds, then treadmill will start to work with initial speed 0.8km/h

1.9.2 Press speed +/-, you can adjust the speed

1.9.3 Press incline+/-, you can adjust the incline

1.9.4 Press stop, you can stop treadmill at working state

1.9.5 Press quick speed key, you can quickly adjust the speed you want

1.9.6 Press quick incline key, you can quickly adjust the incline you want

1.10 3 COUNTDOWN FUNCTION PARAMETER DATA

Countdown time initial setting 30: 00 minutes, setting range 5: 00---99: 00 minutes , each step 1: 00.

Countdown calorie initial setting 50therm, setting range 10---990 term, each step 10.

Countdown distance initial setting 1.0km, setting range 0.5---99.9 km, each step 0.1

Cycle switch order is: manual, time, distance, calories.

1.11 BODY TESTER (FAT)

At the beginning state, press "PROGRAM" continually to enter "FAT" body fat test, window display "FAT". Press "MODE" to enter (F1 SEX, F2 AGE, F3 HEIGHT, F4 WEIGHT). Press "SPEED+", "SPEED-" to set. After setting, the computer will display F5 and grasp the hand pulse, the window will display your body quality index.

The body quality index is to test the relation between height and weight not the body scale.

The body FAT suits for any male and female to adjust the weight according together with other body quality index. The ideal FAT should be between 20-25, if under 19, it means too thin. If between 25 and 29, it means overweight, if over 30, it means obesity. (The data is just for reference and can not be as medicinal data)

-
- 01 Sex 01 Male 02 Female
 - 02 Age 10-----99
 - 03 Height 100----200
 - 04 Weight 20-----150
 - 05 FAT \leq 19 Under weight
FAT= (20---25) Normal weight
FAT= (25---29) Over weight
FAT \geq 30 Obesity

1.12 OTHERS

1.12.1. The system will enter into power saving mode automatically if there is no any action within 10 minutes under IDLE MODE and there is no display and backlit on the computer. Press any key to resume the system.

1.12.2. Countdown time, countdown calorie and countdown distance, you just can set one of them at one time, press last item to set running, the setting parameter is countdown, others display normal data

1.12.3. MP3 audio function: Insert the MP3 line in the input hole of the right side in the computer

GETTING STARTED GUIDE

PREPARE

If you are around 35 years old, or have health problem, even this is your first time to do fitness exercise, please consult doctor or professional before use it.

Before do exercise, please stand on the side to learn how to operate, such as start, stop and speed adjustment. After that stand on the plastic deck of the treadmill board, catch hold of the handrail, start by 1.6--3.2 km/h low speed, stand straight, look forward, one foot try to do few times, then stand on the belt to do exercise. After adapting, you can adjust the speed to 3--5 km/h and keep doing about 10 minutes, then stop.

EXERCISE

Please stand on the side to learn how to operate, such as speed and incline, until you know it then can start do exercise. Walk 1 km by constant step need about 15-25 minutes, please record it in fact. And walk 1km by 4.8 km/h need about 12 minutes. If you can do it easily by few times, then can adjust the high speed and incline, and go on to do 30 minutes, you can take a good exercise. Before do slow walk exercise, please remember it is for your health and can not irritable.

AMOUNT OF EXERCISE

SHORTCUT—The best way to save time is do 15-20 minutes exercise.

Warm up 2 minutes by 4.8 km/h, and adjust the speed to 5.3 km/h and 5.8 km/h, continue do exercise by this two speeds. Then add 0.3 km/h per 2mins speed increase, until you feel breathing quickened but not breathe hard. Keep this speed to do exercise, if feels uncomfortable, please reduce 0.3 km/h. Leave 4 minutes to reduce speed at last. If you fell it is hard to strengthen exercises by increase speed, then you can choose the way of increase incline slowly, it also can strengthen exercise.

CONSUMPTION OF HEAT—This way can really consumption the heat.

Warm up 5 minutes by 4--4.8 km/h speed, then add 0.3 km/h per 2 minutes increasing speed, you can do 45mins on the speed that you feel it is comfortable and challenge. In order to strengthen do exercise. You can do 1 hour by this speed and add 0.3 km/h speed when you heard some business advertisements, and return the speed back when go to next program, so at this period, the heat will be consumed enough. At last keep 4 minutes to reduce the speed.

EXERCISE FREQUENCY

Target is 3--5 times per week, do 15-60mins each time. It is better to make a time schedule, do not accord to your favor. You can get the strenuous exercise degree through adjusting speed and incline. We'd suggest that do not set incline when start do exercise.

SAFETY EXERCISE


Please consult professional staff before do exercise. He can help recommendation exercise rate/intension and time according to your age and health condition. When running, if you feel chest tightness or chest pain, irregular Heartbeats, short of breath, dizziness or other unwell, please stop immediately! And consult professional before you want continually to do exercise. If you often use treadmill, you can choose normal walk speed or jog speed.

If you have no experience or can't make sure the best testing speed, you can reference below standard:

Speed 1-3.0 km	weak constitution people.
Speed 3.0-4.5 km	sedentary or not often exercise people.
Speed 4.5-6.0 km	walking quickly people.
Speed 6.0-7.5 km	fast walk people.
Speed 7.5-9.0 km	jogger.
Speed 9.0-12.0 km	intermediate speed runner.
More than 12.0 km	excellent runner.

ATTENTION: It is suitable for walker to choose less than or equal to 6 km speed.

WARM-UP EXERCISE



It is better to do some warm-up exercise. Warm the muscle easy stretch, so use 5-10 mins to warm-up. Then stop and according below method to do stretch exercise for five times, and each foot do 10 seconds or more every time. After running, do those stretch exercises again

- 1. Reach Down:** Knees slightly bent and body slowly bent forward, back and shoulders relax, trying to touch toes. Keep 10-15 seconds and relax. Repeat 3 times(See picture 1).
- 2. Hamstrings Stretches:** Sitting on a clean cushion, put one leg straight, the other inward and close to the inside of the straight leg. Try to touch your toes with your hands. Keeping for 10 to 15 seconds, and relax. Repeat 3 times for each leg (See picture 2).
- 3. Crus and Feet Tendon Stretches:** Standing with two hands on the wall or tree, one leg behind. Keeping your legs straight and the heel on the ground, tilt to the wall or tree. Keep 10 to 15 seconds, and relax. Repeat 3 times for each leg (See picture 3).
- 4. Quadriceps Stretches:** Keeping your balance with your left hand holding on the wall or table, then stretch your right heel toward your buttocks slowly, until you feel very tense in the front of your thigh. Keep 10 to 15 seconds, and relax. Repeat 3 times for each leg (See picture 4).
- 5. Sartorius (Inner Muscles of the Thigh Muscle Stretches:** Sitting down with your soles opposite and knees outward Pull your feet toward your groin Keep 10 to 15 seconds, and relax. Repeat 3 times (See picture 5).

MAINTENANCE INSTRUCTION

WARNING: Please make sure pull out the treadmill's power plug before cleaning or maintaining the product.

CLEANSING: General cleaning of the unit will greatly prolong the treadmill's life.

Keep treadmill clean by dusting regularly. Be sure to clean the exposed part of the deck on either side of the walking belt and also the side rails. This reduces the build up of foreign material underneath the walking belt. Make sure the shoes are clean. The top of the belt may be cleaned with a wet soapy cloth. Be careful to keep liquid away from inside the motorized treadmill frame or from underneath the belt.

WARNING: Always unplug the treadmill from the electrical outlet before removing the motor cover. At least once a year remove the motor cover and vacuum under the motor cover.


This treadmill's walking belt and deck are equipped with a pre-lubricated, low maintenance deck system. The belt/ deck friction may play a major role in the function and life of your treadmill, thus requiring periodic lubrication. We recommend a periodic inspection of the deck.

We recommend lubrication of the deck according to the following timetable:

Light user (less than 3 hours/ week)	Every 60 days
Medium user (3-5 hours/ week)	Every 45 days
Heavy user (more than 5 hours/ week)	Every 30 days


We suggest you buy lubricating oil from local distributors or contact our company directly.

Pay attention, any other maintains please ask professionals for help.



BELT ADJUSTMENT

Place treadmill on a level surface. Make treadmill run at approximately 6-8 km/h, observe the running belt deviate condition.



If the belt has drifted to the right, unplug the safety lock and power switch, and turn the right adjusting bolt 1/4 turn clockwise, then insert the power switch and safety lock, make the treadmill running, observe the running belt deviate condition. Repeat above steps until the running belt be placed in the middle.

See picture A


Once the treadmill belt swerving to the left, unplug the safety lock, turn off the power, then with the left adjusting bolt clockwise rotation 1 / 4 laps, and turn on the safety lock and power to make treadmill running, checking the deviation of the treadmill belt. Repeat the above steps until the belt centered.

See picture B

The treadmill belt will gradually relax after above steps or after a period of time using, unplug the safety lock, and turn off the power, with the two adjusting bolt clockwise rotation 1 / 4 laps, and turn on the safety lock and power to make treadmill running, then standing on the belt to confirm the tightness. Repeat the above steps until the belt moderate tightness.

See picture C

EXPLODED DRAWING



PARTS LIST

A Welding Parts

No.	Description	Spec.	QTY
A1	Main frame		1
A2	Base frame		1
A3	Left upright bracket		1
A4	Right upright bracket		1
A5	Computer bracket		1
A6	Incline bracket		1
A7	Inductor bracket		1
A8	Running board support tube		1

B Plastic Parts

No.	Description	Spec.	QTY
B1L	Left computer bracket		1
B1R	Right computer bracket		1
B2	Computer bottom panel		1
B3	Computer board		1
B4	Air cushion		2
B5	Bookcase		1
B6	Silicon oil		1
B7	Handrail foam		2
B8	Inner plug		2
B9	Overlay		1
B10	End cap		2
B11	Cushion		2
B12	Cushion		4
B13	Transport wheel		2
B14	Motor side cover		2
B15	Left rear cover		1
B16	Right rear cover		1
B17	Motor cover		1
B18	Limited cushion		2
B19	Transport wheel		2
B20	End cap		2

B21	Transport wheel plug		2
B22	Square inner plug		4
B23	Ring protect plug		2
B24	Power buckle		1
B25	Side rail		1
B26	Left side cover		1
B27	Right side cover		1
B28	Bottle bracket		2
C Electrical parts			
C1	AC Motor		1
C3	Invertor		1
C4	Front roller		1
C5	Rear roller		1
C6	Motor belt	210-J7	1
C7	Running belt		1
C8	Running board		1
C9	Incline motor		1
C10	Inductor		
C11	Filter		
C12	Handrail incline button		2
C13	Handrail speed button		2
C14	Upper controller		1
C15	Safety key		1
C17	Safety key sensor		1
C18	Cylinder		1
C19	Power line		1
C20	Overload protector		1
C21	Power switch		1
C22	Single line		3
C23	Single line		1
C24	Computer lower wire	Length 1800mm	1
C25	Computer upper wire	Length 800mm	1
C26	Outlet		1
C27	Ground line		1
C28	Magnetic ring		3
C29	MP3 Line		1

D Hardware

D1	Cross round head screw	M5*20	4
D2	Sleeve		2
D3	Flat washer	M8	15
D4	Lock nut	M8	8
D5	Cross round head screw	M6*10	2
D6	Half round hex bolt	M10*45	3
D7	Flat washer	M10	17
D8	Lock nut	M10	5
D9	Bolt	M6*40	2
D10	Bolt	M6*65	2
D11	Bolt	M6*25	2
D12	Self-tapping head bolt	ST4.2*16	21
D13	Hex round screw	M8*55	1
D14	Hex round screw	M8*60	2
D15	Hex round screw	M8*20	4
D16	Spring washer	M8	6
D17	Self-tapping head bolt	ST2.9*16	4
D19	Hex round screw	M8*80	1
D21	Bolt	M5*10	5
D23	Half round hex bolt	M10*15	4
D24	Half round hex bolt	M10*55	4
D25	Half round hex bolt	M10*60	4
D27	Half round hex bolt	M10*20	2
D28	Half round hex bolt	M8*50	2
D29	Self-tapping head bolt	ST4.2*40	4
D30	Self-tapping head bolt	ST4.2*50	4
D31	Self-tapping head bolt	ST4.2*19	2
D32	bolt	M5*15	3
D33	Half round hex bolt	M8*40	2
D34	Half round hex bolt	M8*30	1
D35	Bolt	ST4.2*19	6
D36	Allen wrench	80*80*6	1
D37	Screw	ST4.2*30	2
D38	Screw	M6*55	2
D39	Bolt	ST3*10	8
D40	Screw	ST4.2*25	6
D41	Screw driver	13、15、17	1

ERROR CODE AND SIGNIFICANCE

Error Code	Error Code Description	Measures
E01	Communication abnormal: The inverter and computer has abnormal communication after start	<p>1,Check if the computer is connected with the inverter well, or any damages of the lines</p> <p>2,Check the inverter and Change it if it is damaged</p> <p>3,Check the computer and change it if it is damaged</p>
E02	Overheat protection	<p>1,Power on after power off for 20 seconds, if it still displays E02 then go on the second step.</p> <p>2,Check if there have dirties inside the fan and fin or the fan is broken. If it still displays E02 then go to next step</p> <p>3,Change the inverter</p>
E03	Low input volatge of Inverter	<p>1,Power on after power off for 20 seconds, if it still displays E03 then go on the second step.</p> <p>2,Check if the voltage is under standard then go to next step if it still displays E03</p> <p>3,Change the inverter.</p>
E05	Inverter over current faulty	<p>1,Power on after power off for 20 seconds, if it still displays E05 then go on the second step.</p> <p>2,Check if the roller bearing is broken, or the running board and running belt are lack of lubrication then go to next step if it still displays E05</p> <p>3,Change the inverter.</p>
E07	Overload protection	<p>1,Power on after power off for 20 seconds, if it still displays E07 then go on the second step.</p> <p>2,Check if the roller bearing is broken, or the running board and running belt are lack of lubrication then go to next step if it still displays E07</p> <p>3,Change the inverter.</p>
E08	Inverter system fault	<p>1,Power on after power off for 20 seconds, if it still displays E08 then go on the second step.</p> <p>2,Check if the upper connecting wire is connected well then go to next step If it still displays E08.</p> <p>3,Change the inverter.</p>
—	The computer can not induct the safety	<p>1,Check If the safety key switch is damaged, the connect way is correct, or the magnet is in good condition.</p>

	key sensor	<p>2,Check if the safety key is in good condition and re-set well</p> <p>3,Change the safety key</p>
E09	Incline fault	<p>1,Check if the incline sensor plug is connected well and then go to next step If it still displays E09.</p> <p>2,Change the inverter If it still displays E09.</p> <p>3,Change the incline motor.</p>
No display in computer	/	<p>1,Check if the power line is connected well,or the switch is on or the fuse is burnt or not</p> <p>2,Check if the lines are connected well between the computer and controller.</p> <p>3,Inverter or computer is broken.</p>

IMPORTANT INFORMATION REGARDING SERVICE

In you have any problems, please contact Mylna Service. Our consultants have extensive experience and will help you with questions about products, installation, ordering spare parts or any errors and omissions. We would like you to contact us before contacting the store so we can offer you the best help.

Please visit our website www.xerfit.fi - here you will find information about the products and user manuals in Finnish and English. On our website you can find a contact form and this gives us the information we need to assist you as efficiently as possible.

