



Modeler® Importing DXF Files

Introduction

Starting with version 6.6, Bose® Modeler® sound system software contains new features designed to facilitate the import of two and three-dimensional drawing files. These features allow you to leverage work performed outside the Modeler environment within popular 2D and 3D drawing environments. Two new import file types are now supported:

- Modeler Text Format files (.MTF)
created by the Bose Modeler Software Plugin for Google® SketchUp®.
- Drawing exchange format files (.DXF)
created by Autodesk® AutoCAD® and other compatible drafting applications.

This application note describes the import of .DXF files and how to start work in Modeler based on the imported drawings. Modeler offers the following .DXF import features:

- Import of 2D and 3D .DXF files. A 2D drawing is imported into a special *Guide Layer* that facilitates the creation of a three-dimensional room model. A 3D drawing is imported as a three-dimensional geometric model that can be used right away as a starting point for design work within Modeler software.
- Preservation of layer structure. The import tool preserves name and color of the layers as defined in the .DXF file. Layers for 2D import are selectable from a list of all available layers in the .DXF file and are adjustable in color and elevation. When a 3D file is imported, apart from the choice of layers and the adjustment of colors, materials as well as surface types can be assigned to each layer.
- Both types of .DXF files allow the adjustment of their scale and with 2D files, offset and orientation of the drawing may also be defined by the user.
- The snapping functionality of Modeler software's various drawing tools is extended to the 2D drawing in the *Guide Layer* which, together with the various extrusion tools, allows for a very effective creation of a three-dimensional room model.

The information in this application note is organized into three primary sections:

Section 1: Importing a .DXF drawing into Modeler software

Section 2: Start working with a 2D drawing

Section 3: Start working with a 3D model

Associated Reading:

Modeler 6.6 Software User Manual

Modeler Application Notes

Preparing AutoCAD Files For Bose Modeler Software Import

Section 1 – Importing a .DXF File

Import of AutoCAD® 2D .DXF files

You can either chose to open a single 2D .DXF drawing or to add it to the currently opened project. You *cannot* import a 2D .DXF drawing into an already existing model. In order to import a 2D .DXF file,

1. Select **File - Import Model - AutoCAD DXF File**.
Alternatively, you may use the keyboard shortcut **Ctrl-I**.
2. Browse the file system to locate the 2D AutoCAD file of interest, select it, then click **OPEN**.
3. The following DXF conversion dialog will determine how the DXF file will be imported into Modeler® software as a *Guide Layer* within the room model.

NOTE: With very complex .DXF files, it may take a while until the DXF conversion window is displayed. Note the status bar.




Figure 1 – 2D .DXF file conversion

The DXF conversion dialog shows all available layers in a spreadsheet that can be sorted by clicking on the header of each column. All layers are selected for import by default but can also be checked individually. Selecting the checkbox in the *Layer* header toggles *all* layers on/off. For each layer, its elevation in the *Guide Layer* and its color can be adjusted. Select **OK** to accept the parameters and to begin the import process.

Modeler®

Importing DXF Files



Once Modeler® software constructs the geometry elements from the information in the .DXF file, a window for the attributes of the *Guide Layer* appears as shown in Figure 2.

NOTE: Often, not all layers that are listed in the DXF conversion dialog will show up in the subsequent window for the *Guide Layer* attributes. There are two types of layers that won't be transferred into the *Guide Layer*: Empty layers and layers that only contain objects combined into blocks. If a layer contains both blocked and exploded elements, only the latter will be made available in the *Guide Layer*.





Figure 2 - Guide Layer Attributes

The *Guide Layer* window can be accessed at any time, also after the completion of the import process. This way, a variety of adjustments can be made to the *Guide Layer* during subsequent modelling. The *Guide Layer* can be accessed by selecting the *Guide Layer* icon in the *Arrange* toolbar: 

The *Guide Layer* icon also features a wing-menu that allows toggling the display state of the *Guide Layer*. The same functionality is available via the *Display* tab in the *Model Settings* but the fastest way is certainly to utilize the direct keyboard shortcut "g".

The *Guide Layer* window is organized in five main sections. The bottom of the window shows a spreadsheet with all imported layers that contained valid geometry data. Make sure that the colors set for these layers are distinguishable from the background color you chose for the Model window. As in the conversion dialog, the list can be sorted, layers can be selected for display and the elevation of the displayed layer can also be adjusted. The upper section of the *Guide Layer* window contains four important options to adjust the appearance of the *Guide Layer* content within the Model window:

- 1. Scale.** This section defines the *Units* that will be used for the imported DXF data. This selection is important since a .DXF file does not contain any information about the scale that was used during the creation of the drawing. You can select between standard Metric units (meter, centimeter, millimeter), English units (feet, inches) or you can chose a custom scaling ("Other"). If the latter is used, a scale factor can be defined in the *Scale* text box.
- 2. Offset.** This section determines where Modeler® software locates the *Guide Layer* content within the *Model Window*. If the pull-down menu for "*Centering*" is set to "Automatic", the DXF data will be centered in the model based on the extent of the data in the two dimensions available. If the menu is set to "Manual", offset coordinates can be entered in the two respective fields. If the values are set to Zero, the origin of the "*Global Coordinate System*" within the original .DXF drawing will be placed at the Modeler® software coordinate system origin. Any other number for offset will re-locate the *Guide Layer* content with regards to this reference. Further information on how to best center an imported .DXF drawing is provided at the end of this chapter.
- 3. Rotate.** This section allows the adjustment of the basic orientation of the imported layer(s) as well as any additional rotation around the Modeler software coordinate system origin. While the latter may be less frequently applied, note that you can utilize the "*Orientation*" setting to import a cross-sectional drawing of the room and start modeling from there, e.g., by applying the *Extrude Surface* tool. Note that once you change the orientation, the axis available for "*Offset*" will change accordingly. The "*Rotate*" section also allows you to invert (i.e., mirror) the *Guide Layer* content at one of the two available main axis.
- 4. Drawing.** This section allows you to enter the width of the lines as drawn in the *Guide Layer*. We recommend keeping this value small in order to avoid cluttering of the display. Also available is an option that allows you to display any vertices within the *Guide Layer* content. This function is important with regards to Modeler software's ability to have its drawing tools snap to vertices within the *Guide Layer*. With vertices shown, the user is able to distinguish a valid snap location from a simple crossing of two lines.

Import of AutoCAD® 3D .DXF files

You can either chose to open a single 3D .DXF model or to add it to the currently opened project. In order to import a 3D .DXF file.

1. Select **File - Import Model - AutoCAD DXF File**. (Keyboard shortcut **Ctrl-I**.)
2. Browse the file system to locate the 3D AutoCAD file of interest, select it, then click **OPEN**.
3. The following DXF conversion dialog will determine how the DXF file will be imported into Modeler software as a room model.




Figure 3 – DXF conversion dialog

As with 2D import, the 3D DXF conversion dialog shows all available layers in a spreadsheet that can be sorted by clicking on the header of each column. Again, layers can be checked individually for import. Selecting the checkbox in the *Layer* header toggles *all* layers on/off. For each layer, its material, surface type and its color can be adjusted. Assign materials to each layer by dragging the desired material from the set of material databases on the left side of the window onto the respective cell-entry within the spreadsheet. You can now also assign Modeler® software specific surface types and color to each layer. Select **OK** to accept the parameters and to begin the import process. Once Modeler software constructs the geometry elements from the information in the .DXF file, a window for the scale of the DXF drawing will appear as shown in Figure 4.




Figure 4 – 3D DXF Scale

As with the *Guide Layer* window, the section **Scale** defines the units and scale that will be used for the imported DXF data. Again, select between “Metric” or “English” units or custom scaling by choosing the “Other” option and entering the scale factor in the associated text box. **Model Dimensions** displays the overall extents of the imported .DXF data in the selected units and should give you a good indication about whether the chosen scale factor is roughly correct.

How to center a 2D Guide Layer or a 3D model

As described for the *Guide Layer* window, it is in general advisable to adjust the offset of the imported drawing. This section describes an easy-to-use method to exactly center the room model and, if applicable, the two-dimensional *Guide Layer* around a user-defined location within the room model.

Starting with version 6.6, Bose® Modeler® software offers an option to center model and *Guide Layer* around the location of any of the following room model items:

- a vertex of any surface in the model,
- a loudspeaker or
- a listener.

For the purpose described in this section we recommend to utilize the first option of centering the model and *Guide Layer* around the vertex of a surface within the model. The following example attempts to explain the recommended method for application with a **2D Guide Layer**. For simplicity, the .DXF drawing consists of just the playing field of a soccer arena but of course, the method also applies to much more complex models.

For this example, we will adjust the offset of the model and the *Guide Layer* such that the midpoint of the soccer field will coincide with the Modeler software (0,0,0) coordinate system origin. But first, let's take a look at how the drawing will be imported using "Automatic" offset:




Figure 5 – Soccer field with "Automatic" Guide Layer offset

Modeler®

Importing DXF Files

With “Automatic” centering, Modeler® software places the *Guide Layer* such that the maximum extent of the drawing in both dimensions (here: x and y) is centered around the Modeler software origin. In this case, the model does not only contain the soccer field (the geometry of interest) but also two other elements that skew the offset of the *Guide Layer*. This way, the playing field is offset to negative x and also towards positive y.

The next figure shows how the model is centered when “Manual” offset is chosen and both the x and y offsets are set to zero. This way, the Modeler software origin coincides with the origin of the Global Coordinate System within the original .DXF drawing. Using this option, the midpoint of the field is offset even further from the Modeler software origin.




Figure 6 – Soccer field with “manual” centering and zero offset for x and y

Modeler®

Importing DXF Files

As you may note, the .DXF drawing contains a little triangle depicted in blue. This triangle was added to the .DXF drawing in order to facilitate the method of centering described below. Let's zoom into the middle to the soccer field:




Figure 7 – Midpoint of soccer field with guide object for the helper surface

Note that the triangle was drawn such that the tip coincides with the midpoint of the field. We now want to draw a helper surface in Modeler® software, which utilizes the ability to snap to vertices of the *Guide Layer*, and coincides exactly with the blue triangle. Let's zoom in again on the tip of the triangle, this time with the *Guide Layer* vertices displayed:




Figure 8 – Midpoint of soccer field with tip of guide object (vertices turned on)

Note the many vertices that make up the small circle at the midpoint. It would be very hard to exactly place a vertex of a helper surface in this region since so many *Guide Layer* vertices are valid candidates for snapping.

Thus, we will temporarily turn off all layers except the one that contains the blue triangle:




Figure 9 – Midpoint of soccer field with field layer turned off

We can now use the *Draw Polygonal Surface* tool to create a helper surface on top of the triangle. The following figure shows the model including the new helper plane. For better clarity, we have floated the *Detail Window* and chose the *Properties Tab* showing the properties of the newly created helper surface.




Figure 10 – Soccer field with helper plane and vertex properties

Note that we have selected the vertex at the midpoint of the field (#0) and also its arbitrary offset from zero. Now, right-click into the row describing the coordinates of the desired vertex and chose **"Center Vertex"** as depicted in the figure below:




Figure 11 – Center Vertex function

Both the model surface(s) and the *Guide Layer* content will now be moved such that the chosen vertex coincides *precisely* with the Modeler® software coordinate system origin as seen in the figure below:




Figure 12 – Centered Guide Layer and model. Note precise midpoint placement.

NOTE: The “Center Vertex” functionality is only available in the *Properties Tab* within the *Detail Window*, i.e., not via the Properties in the right-click-menu.

With **3D .DXF models**, the concept of centering around a surface’s vertex is identical to the method above. Nonetheless, all issues related to snapping to the *Guide Layer* are not applicable, simply because there is no *Guide Layer* in use. Thus, all subsequent centering is applied to the model only. You may either center around any vertex of any surface that was imported with the 3D model or you may chose to insert a helper surface in case you don’t have a vertex available in the desired location. You may also place a listener or loudspeaker at the desired location and apply the “**Center Listener**” or “**Center Loudspeaker**” algorithm, analogous to “**Center Vertex**”. Note that the centering function works in all three major room dimensions, so in case you want to avoid that the z-coordinates of the model are changed, make sure that your reference vertex/listener/loudspeaker for centering has an elevation of zero.

Section 2 – Start working with a 2D drawing

General modeling strategies

Before you import a .DXF drawing into Modeler® software and start working with the creation of a 3D simulation model, you should think about the best way to build your geometry. The “best” way in this sense means: Minimize modeling time by utilizing as many “semi-automatic” drawing tools as possible. The tools for the extrusion of surfaces are very powerful when used in conjunction with a *Guide Layer*. The two following examples illustrate this:

In a first example, imagine you have to create a model for a room that features a **complex floor shape**, with lots of corners, recessed wall elements, dedicated seating areas, columns that need to be cut out of the floor, etc. but at the same time, with a relatively **simple**, i.e., uniform, **ceiling** structure. In such a case, the recommended approach is to import a floor plan into the *Guide Layer* and using the *Draw Polygonal Surface* tool to create a polygon that follows the outline of the room. Then, use the *Extrude Walls* tool to create side walls and a flat ceiling of continuous height. Or use the *Extrude Surface* tool to clip the side wall extrusion at more complicated ceiling shapes, such as a barrel vault.

In a second example, should you have to model a room with a **simple-shaped floor** plan but a **complicated**, auditorium-like **ceiling**, it may be more efficient to import a cross-sectional drawing of the room, rotate the *Guide Layer* to the correct orientation and center it appropriately, e.g., such that the floor level is at zero height. Now, use the *Draw Polygonal Surface* tool and create a polygon that follows the outline of the room in this sectional view and which will define the footprint for an extrusion. Create two bounding surfaces at the desired location of the two side walls. Now, use the *Extrude Surface* tool and extrude the footprint surface towards the two boundaries with the termination setting “Closed”.

How much detail ?

For this section, we assume that you are familiar with the content of section 1 and have a suitable .DXF drawing imported and oriented in the model.

With a detailed architectural drawing available in the *Guide Layer*, it is very tempting to follow every small edge available, especially since Modeler® software allows the various drawing tools to snap onto available vertices in the *Guide Layer*.

In general, it is **not** recommend to follow this approach for two different reasons. One is that too much detail in the geometry of a model for acoustic predictions slows down calculations. (More information about this aspect can be found in section 3). The other, equally important, aspect is that - in general - building and especially *modifying* room models becomes much trickier when the vertices of surfaces leave the smallest available *Room Snap Grid* in Modeler software (0.1 meter). While various snapping algorithms within Modeler software help overcoming the associated problems, it is typically more time-consuming to build models whose major surfaces do not coincide with the room snap grid. Below, we try to outline *one* possible strategy to work with an imported 2D *Guide Layer* that has proven to work quite conveniently.

The main decision you need to make while using a *Guide Layer* is: When should I snap to a *Guide Layer* vertex and when should I "draw on top of" the *Guide Layer* by utilizing the *Room Snap Grid* only. The following picture shows a screenshot of part of the ground floor of an indoor swimming pool.




Figure 13 –Imported Guide Layer of a swimming pool.

In this example we can depict some good candidates for snapping to vertices. Especially the angled boundaries of the pools would be hard to do without utilizing the snapping functions. The next screenshot shows an enlarged detail of the situation:




Figure 14 –Model surface created on top of one pool.

Note the blue indicators of available vertices in the *Guide Layer*. Many vertices describe the various curvatures with a detail that is not required for our purpose. Thus, the contour of the pool has been followed with a reduced set of vertices.

In a second example (from the same project), we look at a part of the *Guide Layer* drawing where snapping to its vertices would be less convenient when further proceeding with the model. There are two elements in this part of the model we'd like to use for guidance: the location of the upper side wall and the footprints of rectangular columns that support this side wall. Of course it is possible to again use the snapping functionality and place model elements precisely over the *Guide Layer* elements but a detailed inspection of the side wall of this example would reveal that it is not precisely parallel to the x-axis, but offset by some millimeters at one edge.

Such a slightly angled surface is hard to work with, it gets difficult to join adjacent surfaces or to add vertices at exact locations. We will thus create a wall surface that only comes close to the actual drawing reference but that will rest on the closest available room snap grid. Typically, the resulting error is in the range of a couple of centimeters and thus negligible. The following screenshot shows the respective part of this model.




Figure 15 -Imported Guide Layer with side walls and column locations.

The next issue with this particular *Guide Layer* is the fact that one edge of the square column footprints does not coincide with edge of the wall. This can be seen if one zooms into the boundary:




Figure 16 -Misalignment of side wall and edge of column.

There's just no sense in trying to be accurate and to model the column where it's precisely located in the *Guide Layer* - it makes much more sense to have it align with the side wall. The following figure shows the same part of the model with a column footprint and a side wall element added by utilizing a 0.1 m *Room Snap Grid*. Note that the column edge is now precisely aligned to the side wall. Note also the very small misalignment of a few centimeters at the other side of the column.




Figure 17 –Column footprint and wall drawn using the Room Snap Grid.

Snap to vertex functionality

As mentioned before, Modeler® software allows its various drawing tools to utilize the snapping functionality with regards to available vertices in the *Guide Layer*. In order to allow Modeler software to snap to the *Guide Layer*, you need to check the appropriate box in the *Drawing/Saving* tab of the *Model Settings*.




Figure 18 –Model settings to enable snap to vertex .

Since vertices in the *Guide Layer* may be located in very close proximity to each other, it is recommended to set the sensitivity for snapping to a small value and zoom into the drawing during surface creation in order to ensure sufficient visibility of details. The *Snap To Vertex* setting does not distinguish between vertices in the *Guide Layer* or in the actual model - once activated, it applies to both. This may be disadvantageous in two situations:

1. If you want to **snap to model surfaces alone**, you either need to temporarily turn off the complete *Guide Layer* (Keyboard-shortcut "g") or you turn off only the layers that contain the elements that get into the way (see the centering example in section 1).
2. If you want to **snap to the Guide Layer alone**, you need to disable the display of any model surfaces that get into the way of *Guide Layer* vertices by turning off the respective *Surface Types* in the *Display Tab* of the *Model Settings*. This may also require to temporarily change the assignment of *Surface Type* to some surfaces.

The display of vertices can be toggled with a checkbox in the *Drawing* section of the *Guide Layer* window as displayed in the figure below.




Figure 19 – Toggle vertex display in Guide Layer Attributes.

Note: Modeler® software snaps to the available vertices of an element in the *Guide Layer* but not to intersections of elements. Thus, displaying the vertices of the *Guide Layer* is recommended.

Surface visibility

Another interesting feature of the *Guide Layer* is the ability to choose the elevation of the various layers. This way, layers that describe floors and walls can be placed at zero height and layers that describe lighting elements, cable trusses, or ceiling support structures, can be placed at the actual mounting height in order to simplify collision detection when placing loudspeakers.

Layers are displayed in the Model view at an elevation as specified in the *Guide Layer* window. Depending on their z-coordinates, surfaces created in Modeler software may appear differently if their vertices result in being either above, below or at the same height as the respective layer elevation. The following pictures try to illustrate this situation:




Figure 20 – Guide Layer only (left) and with surface above (right). Note regular (black) surface edges.




Figure 21 – Guide Layer at same height as surface (left) and above surface (right). Note color change of surface edges and details to vertex indicators.

This artifact also appears during the creation phase of a new surface whose edges lie exactly above lines from the *Guide Layer*, which is normal when you utilize snapping to vertices of the *Guide Layer*: These collinear edges disappear during surface creation as can be seen in the example below.




Figure 22 – “Disappearing” edges of newly created surface with Guide Layer at elevation \geq Zero.

Section 3 – Start working with a 3D model

Depending on the original purpose of the 3D .DXF model you received, it may not be suitable for acoustical modeling right away. In general, a good acoustical model requires much less detail than an architectural model. Too *much* detail does not only slow down calculations, it may also cause inaccurate results. It is therefore good practice to simplify a 3D model should it contain too much detail. As a *general* rule, don't model surfaces with an extent of less than 0.5 to 1.0m in any dimension. Among others, some common recommendations are:

- Don't build stairs by modeling all their individual steps. Instead, model a continuous surface with scattering reflection characteristics.
- Don't model window or door frames that are just some centimeters deep. Remove those elements and replace them by doors and windows from the respective Modeler® software toolbar. These elements are much more efficient with regards to acoustical modeling.
- Remove any decorative elements like chairs or other furniture. Instead, try to understand their acoustical behavior and assign corresponding characteristics to the underlying surfaces. Do not remove elements that *do* have an important acoustic property, e.g., a shelf that obstructs parts of the room from direct sound arrivals.
- Remove support structures (e.g., steel elements in the ceiling) as long as they are small (sound will typically diffract around them), unless they are required, for collision detection.

Coupled spaces

It is often likely that the original purpose of the 3D model that you have imported was not necessarily related to acoustic predictions. Depending on the complexity of the modeled building, the drawing may contain several building blocks which may or may not be acoustically coupled. A typical example would be a transportation venue that spans over several floors that are only coupled by relatively small openings. In general, coupled spaces are not recommended in Modeler software since a "global" reverberation time is assumed for the acoustical predictions. Should your 3D drawing contain such complex structures, it is recommended that you remove all building blocks except the one of interest, close any openings and restrict the predictions to the section of interest.

Bent surfaces

Depending on how much care was taken when the AutoCad® model was created, your model may also contain bent surfaces, i.e., surfaces where not all corner vertices are located in the same plane. Should Modeler software detect such surfaces during the import, it will correct the bentness by relocating one or more vertices of the surface in question and mark it with a red shading. The display of "*Bent Planes (shading)*" must be activated in the *Application Preferences* in order to see these planes. Should you see bent planes in your model, we recommend that you fix these surfaces by deletion and rebuilding them with triangles using the *Insert Face* tool.

Modeler®

Importing DXF Files



Close Openings

For any reason, your imported room model may contain openings. Check your model carefully to detect critical, unintended openings. Modeler® software doesn't require the simulation model to be "watertight", e.g., it is allowed to model a stadium with a large opening in the ceiling, but certainly, it is undesirable that the model contains larger openings where they don't belong. It is often usually practical to search for any openings by utilizing *Camera View* and setting the "*Back Color*" to a very distinctive color, e.g., pink. You can then maneuver through your model and look around for any inconsistencies in the geometry. As with bent surfaces, the most effective way to close openings is inserting triangular surfaces with the help of the *Insert Face* tool.

Assign surface types & descriptions

After importing to Modeler software, you should consider assigning surface specific descriptions since these are not available in .DXF files. Also, since the DXF conversion dialog only allows assigning Modeler software specific surface types *per layer*, you may now want to assign surface types to individual *surfaces* by utilizing the *Surface Tab*.

Assign acoustical properties to surfaces

As described in section 2, you have the option of assigning acoustical materials to individual *layers* during the import phase of a 3D .DXF file. Nonetheless, materials are typically assigned to each *surface*, so please make sure you verify the material assignment for each individual surface. In order to properly define all acoustical properties of a given surface, you also need to assign the correct reflection characteristics (scattering, specular) and, if utilized, occupancy settings to each surface. The *Surface Tab* in the *Detail View* and its capabilities for sorting allow for effective assignment of these properties.

Set Acoustical Parameters

A .DXF file does not contain any information about the acoustical environment of the room model. Therefore, use the *Acoustics Tab* in the *Detail View* to set the relevant acoustical parameters like temperature, humidity, occupancy and background noise. Also, before you start performing acoustical predictions in your room model, make sure that the source used for Ray tracing predictions of reverberation time is placed in a reasonable location.

Conclusion

We certainly hope the concepts and recommendations discussed in this application note are helpful to you. We hope you will enjoy working with Bose® Modeler® Sound System Software. We encourage you to send us your suggestions about how to improve the tools or the workflow for importing 2D and 3D .DXF files.

