



Catalog Number DOC026.53.00742

Sigma SD900 Portable Sampler

USER MANUAL

December 2007, Edition 2

Section 1 Specifications	7
1.1 Dimensions	10
1.2 Bottle and retainer configurations	11
Section 2 General Information	13
2.1 Safety information	13
2.1.1 Use of hazard information	13
2.1.2 Precautionary labels	13
2.1.3 Confined space precautions	14
2.2 Sampler overview	15
2.2.1 Sampler components	15
Section 3 Installation	17
3.1 Unpack the sampler	17
3.2 Installation guidelines.....	19
3.2.1 Manhole installation	21
3.3 Sampler base preparation.....	21
3.3.1 Clean the sample bottles	21
3.3.2 Single bottle installation	22
3.3.2.1 Full bottle shut-off installation.....	22
3.3.3 Multiple bottle installation	23
3.3.3.1 Bottle number 1 position	23
3.3.3.2 Two or four bottle installation	24
3.3.3.3 Eight bottle installation	25
3.3.3.4 24 bottle installation	26
3.3.3.5 Distributor installation.....	28
3.4 Intake tubing and strainer installation	29
3.5 Electrical installation	30
3.5.1 Power installation.....	31
3.5.1.1 Battery installation.....	31
3.5.1.2 AC power installation	32
3.5.2 Flow meter installation	33
3.5.3 Communications installation	33
3.5.4 Sonde installation.....	34
3.5.4.1 Status of SDI-12 Measurements	35
Section 4 Sampler operation	37
4.1 Power on and power off	37
4.2 Controller overview	37
4.2.1 Keypad description	37
4.2.2 Navigation	38
4.2.3 Parameter selection	38
4.3 Main menu overview	39
4.4 Sampler programs	39
4.4.1 Sampler program overview	40
4.4.2 Create a sampler program	41
4.4.2.1 Tips and techniques	41
4.4.3 Modify a program	42
4.4.4 Review a program.....	42
4.4.5 Restore default settings	43
4.4.6 Store programs as presets.....	43
4.4.6.1 Load a stored program.....	43
4.5 Start or stop a program	44
4.6 Manual operation	44

Table of Contents

4.6.1 Collect grab samples	44
4.6.2 Move the distributor arm	45
4.6.3 Start or stop the pump	45
4.7 View data	45
4.7.1 Status screen	45
4.7.2 Status for main program	46
4.7.2.1 Ready to start	46
4.7.2.2 Running/halted	46
4.7.2.3 Complete	47
4.7.3 Status for stormwater program	47
4.7.4 Sample history	47
4.7.5 Event log	48
4.7.5.1 View the event log	49
4.7.5.2 Erase the event log	49
4.8 Volume calibration	49
4.8.1 Volume calibration using the liquid sensor	50
4.8.1.1 Reset the calibration	50
4.8.2 Volume calibration based on time	51
4.8.3 Verify sample volume	52
4.9 Controller settings	52
4.9.1 Liquid sensor calibration	53
4.9.2 Set password	53
4.9.3 Tubing life indicator	54
4.9.3.1 Enable the tubing life indicator	54
4.9.3.2 Tubing life status	54
4.9.3.3 Tubing life cycle limit	54
4.9.3.4 Reset tubing cycles	55
4.9.3.5 SDI-12 configuration	55
Section 5 Advanced sampling	59
5.1 Advanced sampling overview	59
5.2 Advanced sampling menu	59
5.3 Advanced sampling instructions	59
5.3.1 Send output signal at program completion	60
5.3.2 Send output signal with sample cycle (special output)	60
5.3.3 Operate from external signal (setpoint sample)	61
5.3.3.1 Setpoint sampling triggers (SDI-12)	61
5.3.4 Set multiple start and stop times	64
5.3.5 Collect first flush stormwater samples	64
5.3.6 Set variable intervals	66
5.3.7 Timed Bottle	66
Section 6 Maintenance	69
6.1 Upgrades, Repairs, General Maintenance	69
6.2 Sampler cleaning	69
6.3 Pump maintenance	69
6.3.1 Pump tube life	69
6.3.2 Pump tube replacement	70
6.3.3 Rotor removal and cleaning	72
6.4 Distributor arm tubing replacement	74
6.5 Desiccant replacement	74
Section 7 Troubleshooting	77
7.1 General troubleshooting	77
7.2 Error messages and notifications	78

7.3 Diagnostic tests.....	80
7.3.1 Distributor diagnostic	80
7.3.2 Keypad diagnostic.....	80
7.3.3 LCD diagnostic.....	80
7.3.4 Liquid sensor diagnostic	81
Section 8 Replacement Parts and Accessories.....	83
8.1 Bottle kits	83
8.2 Containers and bottle sets	83
8.3 Replacement parts.....	83
8.4 Accessories.....	84
Section 9 Contact information	87
Appendix A Wiring for non-Sigma flow meters	89
Appendix B SDI-12 Configuration for a Hydrolab Sonde	93
9.0.1 SDI-12 Configuration	94
Index.....	101

Section 1 Specifications

Specifications are subject to change without notice.

Sampler body dimensions (see Figure 1 on page 10)	
Standard base	Diameter: 50.5 cm (19.9 in.) Height: 69.4 cm (27.3 in.) Weight: with (24) 1-L polyethylene bottles—15 kg (35.6 lb); weight with (1) 2.5-gal polyethylene container—14.8 kg (32.6 lb)
Compact base	Diameter: 44.1 cm (17.4 in.) Height: 61 cm (24 in.) Weight: with (24) 575-mL polyethylene bottles— 12.2 kg (27 lb); weight with (1) 2.5-gal polyethylene container—12.9 kg (28.3 lb)
Composite base	Diameter: 50.28 cm (19.8 in.) Height: 79.75 cm (31.4 in.) Weight: with (12) 950-mL glass bottles—15 kg (36 lb)
Sample bottle capacity (see Figure 2 on page 11)	
Standard base	(24) 1 L polyethylene and/or 350-mL glass bottles (8) 2.3 L (0.6 gal) polyethylene and/or 1.9 L (0.5 gal) glass bottles (4) 3.8 L (1 gal) polyethylene and/or (4) 3.8 L (1 gal) glass bottles (2) 3.8 L (1 gal) polyethylene and/or (2) 3.8 L (1 gal) glass bottles (1) 21 L (5.5 gal) polyethylene composite container or (1) 15 L (4 gal) polyethylene composite container or (1) 20 L (5.25 gal) polyethylene or (1) 10 L (2.5 gal) polyethylene or (1) 10 L (2.5 gal) glass
Compact base	(24) 575 mL polyethylene bottles (8) 950 mL glass bottles (1) 10 L (2.5 gal) polyethylene bottle (1) 10 L (2.5 gal) glass bottle
Composite base	(1) 21 L (5.5 gal) polyethylene bottle
Sampler	
Sampler housing	Impact-resistant ABS, 3-section construction. Double-walled base with 2.54 cm (1 in.) insulation—direct bottle contact with ice.
Sample temperature range	0–60°C (32–140 °F)
Strainers	316 stainless steel in standard size, high velocity or low profile for shallow depth applications and Teflon®/316 stainless steel in standard size
Sample intake tubing	9.5 mm (3/8 in.) I.D. vinyl or Teflon®-lined polyethylene
SD900 controller	
Enclosure	High-Impact, injection-molded PC/ABS blend; submersible, watertight, dust-tight, corrosion, and ice resistant; NEMA 4X, 6, IP 67
Power requirements	12 VDC supplied by optional AC power converter or battery
Overload protection	6 amp DC line fuse for pump
Pump	Peristaltic high speed, with spring-mounted rollers
Pump rollers	Nylatron, impact/corrosion resistant
Pump enclosure	Track is injection-molded polyphenylene sulfide. Cover is polycarbonate, high impact resistant. Pump enclosure rated IP37.
Pump tubing	9.5 mm I.D. x 15.9 O.D. mm (3/8 in. x 5/8 in.) silicone

Specifications

Pump tubing life	20,000 sample cycles under the following conditions: <ul style="list-style-type: none"> • 1 L sample volume • 1 rinse • 6 minute pacing interval • 16 ft of ³/₈ in. intake tube • 15 ft of vertical lift • 70 °F sample temperature
Tubing replacement time	< 1 minute using pre-cut pump tube
Maximum vertical lift to draw sample	Minimum of 28 ft, using 29 ft of ³ / ₈ -in. vinyl intake tube at sea level at 20–25 °C (68–77 °F)
Pump flow rate	1.25 gpm (4.8 L/min) at 3 ft (1 m) vertical lift using ³ / ₈ -in. intake tube
Typical sample volume repeatability	± 5% of 200 mL sample volume using uncalibrated liquid detect with 15 feet vertical lift, 16 feet of ³ / ₈ -in. vinyl intake tube configured for a single bottle using full bottle shut-off at room temperature and 5000 ft elevation
Typical sample volume accuracy	± 10% of 200 mL sample volume using uncalibrated liquid detect with 15 feet vertical lift, 16 feet of ³ / ₈ -in. vinyl intake tube configured for a single bottle using full bottle shut-off at room temperature and 5000 ft elevation
Typical transfer velocity	2.9 ft/s (0.9 m/s) with 15 ft (4.6 m) vertical lift, 16 ft of ³ / ₈ -in. vinyl intake tubing, 70 °F (21 °C) and 5000 ft elevation
Liquid sensor	Ultrasonic
Liquid sensor body	Ultem® NSF ANSI standard 51 approved, USP Class VI compliant
Internal battery	Lithium
Internal clock	Indicates real time and date
Storage temperature	–30 to 60 °C (–22 to 140 °F)
Operating temperature	0 to 50 °C (32 to 122 °F)
Storage/operating humidity	100% condensing
Graphics display	Graphic dot matrix, 128 x 64 pixel with LED backlight. Self prompting, menu-driven program.
Status display	Indicates the number of samples collected, the number of missed samples, inhibit mode, bottle position, time or counts to next sample and battery voltage. In addition, when an SDI-12 sonde is detected, the user has the option to display the current measurement values.
Automatic shutdown	Multiple bottle mode: after complete revolution of distributor arm (unless Continuous Mode is selected). Composite mode: after preset number of samples have been delivered to composite container, from 1 to 999 samples, or upon full container.
User interface	Embossed keypad with one power key, four function keys, and eight navigation keys; LED indicator
Sample history	Stores up to 510 entries for sample time stamp, bottle number and sample status (success, bottle full, rinse error, user abort, distributor error, pump fault, purge fail, sample timeout, power fail and low main battery)
Event log	Records Power On, Power Fail, Firmware Updated, Pump Fault, Distributor Arm Error, Low Memory Battery, Low Main Battery, User On, User Off, Program Started, Program Resumed, Program Halted, Program Completed, Grab Sample, Tube Change Required, SDI-12 communication errors, setpoint high on/off, and setpoint low on/off.
Connections	Power, auxiliary, serial communications and distributor, SDI-12 (optional).
Fittings	Barbed fittings for ³ / ₈ -in. I.D. flexible tubing

Wetted materials	Typical materials in contact with sample: stainless steel, PE, Teflon, Ultem, Silicon or approved materials that can be tested for leaching properties
Weight	4.2 kg (9 lb, 5 oz)
Dimensions	10- ³ / ₈ in. (26.4 cm) L x 11- ¹ / ₂ in. (29.2 cm) W x 6- ³ / ₄ in. (17.1 cm) H
Programming features	
Password protection	6-character; protect changes to program and system settings
Multiple programs	Stores up to three sampling programs
Cascade programs	Two samplers used in combination. The second sampler is initiated after the first sampler completes the program.
Synchronized sampling	Ability to simultaneously take two samples with input from a single flow meter
Sample volume	Programmed in 10-mL increments from 100 to 10,000 mL
Air purge	Air purged automatically before and after each sample; duration automatically compensates for varying intake line lengths.
Intake rinse option	Option to rinse intake line with source liquid prior to each sample, 1 to 3 rinses.
Sample distribution	Composite, samples per bottle or bottles per sample.
Set point sampling	Ability to start and/or stop a sample program based on an external trigger or user-defined high/low setpoints based on SDI-12 measurements.
User start/stop times	Up to 12 user-defined start/stop times/dates, with option to restart at position 1.
Storm water program	Ability to run time-based, first flush program in parallel with main sample program.
Current status	Display parameters relevant to main and/or storm water programs, and SDI-12 measurements.
Units of measure	Volume: gallons or mL; length: feet (ft) or cm
Sample retries	Option to repeat sample collection cycle from 1 to 3 times if sample not obtained on initial attempt.
Manual grab sample	Ability to manually deliver a grab sample to a specific bottle location
Run modes	Continuous or non-continuous with user-entered number of samples.
Time pacing	Uniform or variable time intervals.
Flow pacing	Uniform or variable flow intervals.
Auxiliary connector	Power to Sigma 9XX, SD900, flow pulse input, external inhibit, special output, bottle number output and program complete output.
Program delay	Two formats: 1) 1–9,999 flow pulses (in one unit increments); 2) Programmable start time/date
Timed Bottle Sets	Enables a single sampler to function like multiple samplers.
Communication	
Firmware updates	Ability to perform field upgrades using Sample View software
Serial interface	RS232 compatible; allows on-site collection of stored data including event log and sample history. Ability to configure remotely. Supports Modbus for SCADA connectivity.
SDI-12	Plug & Play interface to Hydrolab DS5 and MS5 sondes to provide measurement data in setpoint sampling applications. Note: Plug & play capability requires firmware v5.43 or greater to be installed in the sonde.

Specifications

1.1 Dimensions




Figure 1 Portable sampler dimensions

1	Portable sampler with compact base	3	Portable sampler with composite base
2	Portable sampler with standard base		

1.2 Bottle and retainer configurations




Figure 2 Bottle and retainer configurations

Section 2 General Information

2.1 Safety information

Please read this entire manual before unpacking, setting up, or operating this equipment. Pay attention to all danger and caution statements. Failure to do so could result in serious injury to the operator or damage to the equipment.

To make sure that the protection provided by this equipment is not impaired, do not use or install this equipment in any manner other than that specified in this manual.

2.1.1 Use of hazard information

DANGER

Indicates a potentially or imminently hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

Indicates a potentially or imminently hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

Indicates a potentially hazardous situation that may result in minor or moderate injury.

Important Note: Information that requires special emphasis.

2.1.2 Precautionary labels

Read all labels and tags attached to the instrument. Personal injury or damage to the instrument could occur if not observed. A symbol, if noted on the instrument, will be included with a danger or caution statement in the manual.

	This symbol, if noted on the instrument, references the instruction manual for operation and/or safety information.
	Electrical equipment marked with this symbol may not be disposed of in European public disposal systems after 12 August of 2005. In conformity with European local and national regulations (EU Directive 2002/96/EC), European electrical equipment users must now return old or end-of life equipment to the Producer for disposal at no charge to the user. Note: For return for recycling, please contact the equipment producer or supplier for instructions on how to return end-of-life equipment, producer-supplied electrical accessories, and all auxiliary items for proper disposal.
	This symbol, when noted on a product enclosure or barrier, indicates that a risk of electrical shock and/or electrocution exists.
	This symbol, if noted on the product, indicates the need for protective eye wear.
	This symbol, when noted on the product, identifies the location of the connection for Protective Earth (ground).
	This symbol, when noted on the product, identifies the location of a fuse or current limiting device.
	This symbol, when noted on the product, indicated the presence of devices sensitive to Electro-static Discharge (ESD) and indicated that care must be taken to prevent damage with the equipment.
	This symbol, if noted on the product, indicates a pinch hazard. Keep hands and fingers clear.

2.1.3 Confined space precautions

Important Note: *The following information is provided to guide users of Sigma SD900 Portable Samplers on the dangers and risks associated with entry into confined spaces.*

On April 15, 1993, OSHA's final ruling on CFR 1910.146, Permit Required Confined Spaces, became law. This new standard directly affects more than 250,000 industrial sites in the U.S.A. and was created to protect the health and safety of workers in confined spaces.

Definition of a confined space

A confined space is any location or enclosure that presents or has the immediate potential to present one or more of the following conditions:

- An atmosphere with less than 19.5% or greater than 23.5% oxygen and/or more than 10 ppm Hydrogen Sulfide (H₂S).
- An atmosphere that may be flammable or explosive due to gases, vapors, mists, dusts or fibers.
- Toxic materials which upon contact or inhalation, could result in injury, impairment of health or death.

Confined spaces are not designed for human occupancy. They have restricted entry and contain known or potential hazards. Examples of confined spaces include manholes, stacks, pipes, vats, switch vaults, and other similar locations.

Standard safety procedures must always be followed prior to entry into confined spaces and/or locations where hazardous gases, vapors, mists, dusts or fibers may be present. Before entering any confined space check with your employer for procedures related to confined space entry.

2.2 Sampler overview

DANGER

This sampler is designed for collection of aqueous samples only. Non-aqueous samples may damage the equipment and could result in fire and chemical hazards.

The SD900 sampler automatically collects and preserves liquid samples. The sampler is suitable for collection of conventional and toxic pollutants and suspended solids.

2.2.1 Sampler components

The sampler consists of three main sections (Figure 3). The center section contains the controller. Use the controller to program the sampler and for manual operation. The controller contains the following components:

- Pump—operates in the forward or reverse direction to collect a sample, rinse and purge the intake tube.
- Liquid sensor—allows the sampler to dispense accurate sample volumes into the sample bottle(s). Can be calibrated to specific sample conditions in the field.
- Cable connectors—for power, flow meter or communication.
- Desiccant—absorbs internal moisture in the controller and prevents corrosion.




Figure 3 Sampler components

1	Bottle/base section	3	Power source	5	Controller
2	Center section	4	Top cover		

Section 3 Installation

CAUTION

Only qualified personnel should conduct the tasks described in this section of the manual.

WARNING

Explosion hazard. This product is not designed for hazardous locations where combustible environments may exist.

3.1 Unpack the sampler

The sampler can be set up for single-bottle or multiple-bottle collection. The components for each configuration will vary (see [Figure 4](#) for single-bottle or [Figure 5 on page 19](#) for multiple-bottle collection).

Check the sampler packages for the following components:

- Sampler—includes cover, base and midsection with controller and distributor or full bottle shut-off
- Bottle(s)—1, 2, 4, 8 or 24
- Power source—battery or AC power supply
- Pump tubing—replacement
- Sample intake tubing—vinyl or Teflon-lined
- Silicone grease packet—for desiccant maintenance
- Strainer—stainless steel or Teflon/stainless steel
- User documentation




Figure 4 Sampler with single bottle

1	Sampler base	7	Top cover (Cat. No. 8890)
2	Container support (Cat. No. 1502) ¹	8	Strainer
3	Bottle	9	Intake tubing, vinyl or teflon-lined
4	Full bottle shut-off (Cat. No. 8996)	10	AC power supply (optional)
5	Sampler center section (Cat. No. 8922)	11	Battery recharger (optional)
6	Battery (Cat. No. 8754400, optional)		

¹ The container support for a 2.5-gal bottle with the standard base is shown. Other bottle sizes may not use a container support.




Figure 5 Sampler with multiple bottles

1	Sampler base	7	Intake tubing, vinyl or teflon-lined
2	Sample bottles	8	Strainer
3	Retainer	9	Distributor assembly
4	Sampler center section	10	AC power supply (optional)
5	Battery (Cat. No. 8754400, optional)	11	Battery recharger (optional)
6	Top cover (Cat. No. 8890)		

3.2 Installation guidelines

WARNING

Explosion hazard. This product is not designed for hazardous locations where combustible environments may exist.

Refer to the following guidelines and [Figure 6](#) when evaluating site location.

- If the site is located in a confined space such as a manhole, refer to [section 2.1.3 on page 14](#) for safety information.
- Make sure that the site has a level surface or a place to hang the suspension harness, support bracket or spanner bar ([Figure 6](#)).

Installation

- Make sure that the temperature at the site is within the operating temperature range that is specified for the sampler.
- Make sure that the intake tube is as short as possible.
- Maximize the vertical slope of the intake tube from the sampler to the sample source so that the tube drains completely. This prevents cross-contamination of samples and freezing the tube.

Note: See [Specifications on page 7](#) for limitations on transport velocity and maximum vertical lift.

Note: If site conditions do not permit the intake tube to have a downward slope, or if the line is pressurized, disable the liquid sensor and calibrate the sample volume ([section 4.8.2 on page 51](#)).

- Install the strainer in the middle of the sample stream (not near the surface or bottom) to make sure that a representative sample is collected.




Figure 6 Mounting configuration

1 Strainer	4 Vertical lift
2 Intake tubing	5 Mounting surface
3 Suspension harness	

3.2.1 Manhole installation

WARNING

Explosion hazard. This product is not designed for hazardous locations where combustible environments may exist.

Installation in a manhole requires suspending the sampler above the sample water. Refer to [section 2.1.3 on page 14](#) for safety information in confined spaces.

Prerequisites:

Use the following hardware to mount the sampler in a manhole.

- Spanner bar or support bracket. A spanner bar is placed inside the manhole and is supported by pressure against the walls. A support bracket has the same width as the manhole cover and is placed directly under the cover for support.
- Suspension harness

Note: See [Accessories on page 84](#) for ordering information.

Installation procedure

Complete the following steps to mount the sampler in a manhole.

1. Connect the suspension harness to the latches on the sampler cover.
2. Hang the suspension harness on the spanner bar or support bracket.
3. Mount the spanner bar or support bracket in the manhole.

3.3 Sampler base preparation

CAUTION

Biological sample hazard. Follow safe handling protocols during contact with sample bottles and sampler components. Disconnect the sampler from power to disable the pump before handling.

The sampler is set up at the factory with a single bottle or multiple bottle configuration. To change the bottle configuration:

- Use [Figure 2 on page 11](#) to determine the components that are required for the selected configuration.
- Install the full bottle shut-off device ([section 3.3.2.1 on page 22](#)) or distributor assembly ([section 3.3.3.5 on page 28](#)).

3.3.1 Clean the sample bottles

Clean the sample bottles and caps using a brush and water with a mild detergent before setting up the sampler. Rinse the containers with fresh water followed by a distilled water rinse. Glass bottles may also be autoclaved.

3.3.2 Single bottle installation

Use a single bottle when one composite sample is needed. A full bottle shut-off signals the controller when to stop sample collection. Refer to [Figure 4 on page 18](#) for a diagram of required components.

Prerequisites:

- One plastic or glass bottle
- Retainer (Cat. No. 2190)

Note: Refer to [Figure 2 on page 11](#) to make sure that the correct sample bottle is used with the correct sampler base and retainer.

Installation procedure:

1. Clean the sample bottle as described in [section 3.3.1](#).
2. If using a 2.5-gallon bottle with the standard base, place a container support (Cat. No. 1502) in the sampler base.
3. Place the sample bottle in the center of the base.
4. Fill the sampler base with ice after the bottle is in place to preserve samples.

Note: The time that it takes the ice to melt varies with the amount of ice used, the external temperature and sample temperature.

5. Place the midsection over the base, making sure that the full bottle shut-off is inside the neck of the bottle.
6. Program the sampler and install in the field.

3.3.2.1 Full bottle shut-off installation

The full bottle shut-off is typically installed at the factory and signals the controller when the bottle is full. Complete the following steps to replace or install a new full bottle shut-off.

Prerequisites:

- Full bottle shut-off device

Installation procedure:

1. Slide the slot in the full bottle shut-off base plate under the retainer pin inside the center section ([Figure 7](#)). Make sure that the tube and cable exit through the openings in the full bottle shut-off assembly.
2. Position the thumbscrew over the threaded hole and hand tighten to hold the device in place.
3. Connect the cable on the full bottle shut-off to the bottom of the controller ([Figure 7](#)). Turn to tighten.
4. Connect the free end of the full bottle shut-off tubing to the inside tube fitting ([Figure 7](#)).




Figure 7 Full bottle shut-off installation

1	Inside tube fitting	4	Slot in full bottle shut-off base plate
2	Threaded hole	5	Thumb screw on full bottle shut-off assembly
3	Retainer pin		

3.3.3 Multiple bottle installation

Use multiple bottles to collect samples into separate bottles or into more than one bottle. A distributor positions the sample tube over each bottle. Position the bottles in the sampler base as shown in [section 3.3.3.1](#). Refer to [Figure 5 on page 19](#) for a diagram of required components.

3.3.3.1 Bottle number 1 position

Position the first sample bottle (number 1) under the label in the sampler base (see [Figure 8](#)). Place the remaining bottles in increasing number in the direction indicated by the label.




Figure 8 Bottle number 1 location

1	Bottle #1 location for 24 bottles	6	Standard base
2	Bottle #1 location for 8 bottles	7	Bottle #1
3	Bottle #1 location for 2 or 4 bottles	8	Elastic straps
4	Bottle #1 location in compact base	9	Retainer
5	Compact base	10	Sample bottle

3.3.3.2 Two or four bottle installation

Use 2 or 4 bottles to collect samples into one-gallon bottles.

Prerequisites:

- Two or four 1-gallon plastic or glass bottles
- Retainer (Cat. No. 2190)

Note: Refer to [Figure 2 on page 11](#) to make sure that the correct sample bottles are used with the correct sampler base and retainer.

Installation procedure:

1. Clean the sample bottles as described in [section 3.3.1](#).
2. Place the bottles in the base as shown in [Figure 9](#). Arrange the bottles so that the first bottle is located under the label at the point marked 2 or 4 BOT ([Figure 8 on page 24](#)).
3. Place the retainer over the bottles with the knobs pointing up. Secure with the straps ([Figure 9](#)).

- To keep samples cool, fill the sampler base with ice after the bottles are in place.

Note: The time that it takes the ice to melt varies with the amount of ice used, the external temperature and sample temperature.

- Place the midsection over the base, program the sampler and install in the field.




Figure 9 Two and four bottle installation

1	Standard sampler base (Cat. No. 8976)	3	Retainer (Cat. No. 2190)
2	1-gallon plastic or glass bottles (2x)	4	1-gallon plastic or glass bottles (4x)

3.3.3.3 Eight bottle installation

Use 8 bottles to collect samples into one-liter or two-liter bottles.

Prerequisites:

- 8 plastic or glass bottles
- Retainer (see [Figure 2 on page 11](#) for catalog number)

Note: Refer to [Figure 2 on page 11](#) to make sure that the correct sample bottles are used with the correct sampler base and retainer.

Installation procedure:

- Clean the sample bottles as described in [section 3.3.1](#).
- Place the bottles in the base (see [Figure 8 on page 24](#)):
 - Compact base first bottle position: under the arrow label.
 - Standard base first bottle position: under the 8 BOT label.
- Place the retainer over the bottles with the knobs pointing up. Secure with the straps.

Note: The retainer for the compact base has two pieces. Place the larger piece in the bottom of the base.

- To keep samples cool, fill the sampler base with ice after the bottles are in place.

Note: The time that it takes the ice to melt varies with the amount of ice used, the external temperature and sample temperature.

- Place the midsection over the base, program the sampler and install in the field.




Figure 10 Eight bottle installation

1	Standard sampler base (Cat. No. 8976)	5	950-mL glass bottles (8x)
2	1.9-L glass bottles or 2.3-L plastic bottles (8x)	6	Retainer bottom (Cat. No. 2347)
3	Retainer (Cat. No.1422)	7	Compact sampler base (Cat. No. 8975)
4	Retainer top (Cat. No.2347)		

3.3.3.4 24 bottle installation

Use 24 bottles to collect samples into 350-mL, 575-mL or 1-liter bottles.

Prerequisites:

- 24 plastic or glass bottles
- Retainer

Note: Refer to [Figure 2 on page 11](#) to make sure that the correct sample bottles are used with the correct sampler base and retainer.

Installation procedure:

1. Clean the sample bottles as described in [section 3.3.1](#).
2. Place the bottles in the base:
 - Compact base: arrange the bottles so that the first bottle is located under the arrow label ([Figure 8 on page 24](#)).
 - Standard base: arrange the bottles so that the first bottle is located under the label marked 24 BOT ([Figure 8 on page 24](#)).
3. Place the retainer over the bottles with the knobs pointing up. Secure with the straps ([Figure 11](#)).

Note: If using 350-mL glass bottles with the standard base, place the bottles around the outside of the retainer.

4. To keep samples cool, fill the sampler base with ice after the bottles are in place.

Note: The time that it takes the ice to melt varies with the amount of ice used, the external temperature and sample temperature.

5. Place the midsection over the base, program the sampler and install in the field.




Figure 11 24 bottle installation

1 Standard sampler base (Cat. No. 8976)	5 Retainer (Cat. No. 1422)
2 350-mL glass bottles (24x)	6 Compact sampler base (Cat. No. 8975)
3 Retainer (Cat. No. 2189)	7 575-mL plastic bottles (24x)
4 1-L plastic bottles (24x)	

3.3.3.5 Distributor installation

CAUTION

Pinch hazard. Make sure the sampler is powered off before removing or installing the distributor assembly.

The distributor automatically moves the sample tube over each bottle during multiple bottle sampling. The distributor assembly is typically installed at the factory. Complete the following steps to install a new or different assembly.

Prerequisites:

- Distributor assembly—three assemblies are available. Refer to [Figure 2 on page 11](#) to make sure that the correct distributor assembly is used.

Installation procedure:

1. Slide the two slots in the distributor assembly housing under the retainer pins located on the top inside surface of the center section ([Figure 12](#)).
2. When fully seated, hand tighten the thumbscrew on the distributor assembly to hold the distributor in place.
3. Push the distributor tubing on the sampler fitting on the top inside surface of the center section ([Figure 12](#)).
4. To make sure that the arm has sufficient freedom of movement, hand-rotate the arm in a circle (both clockwise and counterclockwise) until it hits the arm stop. If the arm does not rotate freely, reposition the tubing to the other side of the arm so that the arm can rotate.

Note: Do not force the arm past the arm stop. The arm stop prevents the arm from rotating more than 360 degrees and pinching the tubing.

5. Install the mid section on the base.
6. To make sure that the distributor is aligned properly, run the manual distributor diagnostic (see [section 7.3 on page 80](#)).




Figure 12 Distributor assembly installation

1	Thumbscrew	3	Retainer pins
2	Arm stop	4	Slots

3.4 Intake tubing and strainer installation

Place the intake tubing and strainer directly in the sample source to collect samples. Refer to [section 3.2 on page 19](#) to make sure that samples are free from contamination and are representative of the sample source.

Prerequisites:

- Vinyl or Teflon-lined tubing
- Connection kit (Cat. No. 2186) (for Teflon-lined tubing only)
- Strainer

Note: See [Accessories on page 84](#) for ordering information.

Installation procedure:

1. Connect one end of the tubing to the liquid sensor fitting.
Note: Use Cat. No. 2186 (connection kit) if using Teflon-lined tubing.
2. Press the tubing into the strain relief ([Figure 13](#)).
3. Route the tubing through the sampler housing so that the tubing is not pinched when the cover is on.
4. Connect the other end of the tubing to the strainer.
Note: Use Cat. No. 2186 (connection kit) if using Teflon-lined tubing.

5. Place the intake tube and strainer in the main stream of the sample source where the water is turbulent and well-mixed. Make sure that the intake tube does not have kinks or loops.




Figure 13 Intake tubing installation

1 Strainer	3 Strain relief
2 Intake tubing	4 Liquid sensor

3.5 Electrical installation

Connect cables to the controller as shown in [Figure 14](#) for the following components:

- Power ([section 3.5.1](#))
- Flow meter or other device ([section 3.5.2 on page 33](#))
- Communications ([section 3.5.3 on page 33](#))




Figure 14 Side view of controller—connectors

1	Power connector	4	SDI-12 connector (optional)
2	Auxiliary connector	5	Distributor/full bottle shut-off connector
3	Serial connector		

3.5.1 Power installation

The sampler can be powered by a battery ([section 3.5.1.1](#)) or by AC power ([section 3.5.1.2](#)).

3.5.1.1 Battery installation

Prerequisites:

- 12 VDC gel electrolyte (lead acid) battery plus recharger.

Note: A 2-pin to 3-pin adaptor cable (Cat. No. 8739400) may be used with older batteries containing a 2-pin connector to power the sampler.

Installation procedure:

1. Place the battery directly behind the controller ([Figure 3 on page 15](#)).
2. Pull the rubber straps up and over the clips at each end of the battery to secure it to the sampler body.
3. Connect the cable from the battery to the power connector on the controller.

Optional battery cable

If the external battery cable with bare leads (Cat. No. 2198) is used, the following requirements must be met:

- The cable must not be altered to more than 3 meters long.
- The cable can only be connected to a 12 VDC battery.
- The maximum voltage cannot exceed 18 VDC.
- Failure to observe proper polarity when connecting the clips to the battery will result in a blown fuse in the cable.

3.5.1.2 AC power installation

WARNING

Electric shock hazard. The temperature of the power supply will increase when the sampler pump is operating. If the time interval between sample cycles is too short, the power supply can become overheated and result in a electric shock hazard or power supply failure. Refer to the power supply instruction sheet (DOC306.53.00801) to determine the time that the pump must stay off between sample cycles to prevent overheating.

Prerequisites:

Important Note: Use only the AC power supply that is specified for this sampler. The power supply connector must have three pins. An adapter cannot be used to convert a older two-pin power supply for use with this sampler.

- AC power supply (Cat. No. 8754500US)

An optional AC power backup can be used to accommodate power failures, and is available with two different cable lengths: 16 in. (Cat. No. 8757400), or 28 in. (Cat. No. 5698200).

Installation procedure:

1. Place the power supply directly behind the controller ([Figure 3 on page 15](#)).
2. Pull the rubber straps up and over the clips at each end of the power supply to secure it to the sampler body.
3. Connect the cable from the power supply to the power connector on the controller.

Electrical transients

When connected to an AC power source, the SD900 controller may be temporarily upset by strong electrical transients caused by sources such as lightning or large electrical motors. These upsets can result in a missed sample, but the SD900 controller will recover and continue with the sample program.

A missed sample will be recorded and can be viewed in the status, event log or sample history screens. Remedial actions may involve the use of a power line filter or connecting the controller to a different branch circuit.

3.5.2 Flow meter installation

The sampler can be connected to a flow meter to start or stop sampling based on the flow volume.

Prerequisites:

- Multi-purpose full cable for Sigma flow meters (or 980 half cable for the model 980 flow meter). To connect to another brand of flow meter, use a multi-purpose half cable and follow the wiring instructions in [Appendix A on page 89](#).
- Optional splitter ([Figure 15](#)) to provide additional connections. Two or more splitters may be connected in series.

Note: See [Accessories on page 84](#) for ordering information.

Installation procedure:

1. Connect one end of the cable to the flow meter. For connection to the model 980 flow meter, follow the instructions in the model 980 user manual.
2. Connect the other end of the cable to the controller.

Note: For connection to a flow meter with an existing 6-pin cable, use the auxiliary adapter cable (6-pin to 7-pin adapter)




Figure 15 Splitter

3.5.3 Communications installation

The sampler can be connected to a PC or Modbus device for data transfer or programming.

Prerequisites:

- Serial cable ([Figure 16](#))

Note: See [Accessories on page 84](#) for ordering information.

Installation procedure:

1. Connect one end of the cable to the PC or Modbus device.
2. Connect the other end of the cable to the controller. The pin assignments for the serial cable are detailed in [Table 1](#).




Figure 16 Serial connector cable

Table 1 Serial cable reference

7-pin connector assignment letter	Signal description	DB-9 pin assignment number
B	Signal ground	5
D	RCD	3
F	TXD	2
G	Earth ground	—

3.5.4 Sonde installation

The sampler can be connected to a sonde for use in collecting measurement data.

Prerequisites:

- Compatible sonde

Important Note: When connecting a Hydrolab DS5 or MS5 to a mains powered SD900, minor measurement errors may occur in the MS/DS 5 due to electromagnetic effects.

Installation procedure:

1. Connect the 6-pin end of the Hydrolab DS5/MS5 SDI-12 50 ft cable (Cat. No. 8762400) or the Hydrolab DS5/MS5 SDI-12 100 ft cable (Cat. No. 8762500) to the sonde bulkhead connector
2. Connect the other end of the cable to the SDI-12 connector on the controller. See [Figure 17 on page 35](#).




Figure 17 Sonde Connection

1	Sonde	4	SDI-12 connector
2	Sonde bulkhead connector	5	50 ft or 100 ft cable
3	6-pin cable connector		

3.5.4.1 Status of SDI-12 Measurements



If a sonde is detected on the SDI-12 interface and the sonde provides measurement data, the user can view the current status of these measurements by using the STATUS hard key or by selecting STATUS from the main menu.



The measurement status screen displays current measurement of each channel on the sonde, including the measurement name and unit assigned to each channel. Measurements are updated based on the user-defined scan interval. Navigation arrows on the screen indicate if information for additional channels is available.

Section 4 Sampler operation

4.1 Power on and power off



Important Note: The AC power supply will become overheated if the sampler pump is operated continuously. Refer to the power supply instruction sheet (DOC306.53.00801) to determine the time interval that must be allowed between sample cycles to prevent damage to the AC power supply and/or to prevent a burn hazard.

Power on: press **POWER** (Figure 18). The LED will blink.

Power off: press **POWER** and select **YES**. The LED will stay off.

Sleep mode: automatic after two minutes of inactivity. The LED will blink but the display will be blank. Press any key to restore the display.

4.2 Controller overview

4.2.1 Keypad description

The keypad and description is detailed in Figure 18.




Figure 18 SD900 keypad

1	POWER: press to turn controller on or off	7	BACK: cancel or return to previous screen
2	VOLUME CALIBRATION: enter volume calibration menu	8	ARROW KEYS: moves cursor or scrolls through values
3	STOP: stops the pump or distributor if running	9	STATUS: displays current status of the sample program
4	LED: blinks when controller is powered on	10	RUN/HAULT PROGRAM: starts or stops a sample program
5	MENU: displays the main menu	11	MANUAL OPERATION: manual operation of pump or distributor
6	ENTER: selects the highlighted or entered value		

4.2.2 Navigation



Use the controller to access all sampler operations. Use the **ARROW** keys, **ENTER** key and **BACK** key to move from one screen to another. An arrow on the display indicates that more screens are available (Figure 19).

Example:

1. Press the **MAIN MENU** key.
2. Press the **DOWN ARROW** key to highlight diagnostics. Press **ENTER**. The diagnostics menu will be shown.
3. Note the down arrow on the bottom of the display (Figure 19). Press the down arrow until additional options are shown.
4. Press the **BACK** key or **MAIN MENU** key to return to the main menu.



Figure 19 Screen navigation

1 Left arrow	3 Up arrow
2 Right arrow	4 Down arrow

4.2.3 Parameter selection

Parameter selection is made in one of two ways (Figure 20):

- Selection from a list
- Enter a value using the arrow keys




Figure 20 Parameter selection

1 Select item from list	2 Enter value with arrows	3 Acceptable range
-------------------------	---------------------------	--------------------

4.3 Main menu overview

The SD900 sampler main menu contains four options for sampler operation, monitoring or data management. Each option is detailed in [Table 2](#).

Table 2 SD900 sampler menu overview

Menu option	Description
Program setup	Create, review, or set up a sampling program
Modify all	Create or edit a sampling program
Modify selected	Edit a portion of a sampling program
Review	Review a sampling program
Presets	Enter or select up to three program templates
Restore defaults	Restore the program default selections
Status	Display the status of the current program
Diagnostics	Review and manage data or test the operation of components
Event log	Display or delete the event log
Sample history	Review the sampling history
Distrib diag	Test the ability of the distributor to detect each of the 24 bottle positions <i>Note: Only active when the sample program is configured for more than 1 bottle.</i>
Keypad diag	Test the operation of each key
LCD diag	Test the operation of the LCD display screen
Liquid sensor diag	Display calibration data for the liquid sensor
System setup	Change controller settings or calibrate the liquid sensor
Time/date setup	Set the time (24 hour) and date
SDI-12	Configure operation of SDI-12 sonde. (Appears only if sonde is detected.)
Communication	Set the baud rate (19200, 38400, 57600 or 115200) and protocol (Modbus RTU or ASCII) for the serial port
Setup base	Specify whether the standard or compact base is used
Language	Select one of the available languages
Liq sensor cal	Calibrate the liquid sensor
Set contrast	Adjust the contrast of the LCD display screen
Password setup	Create or disable a password
Tubing life	Enable optional alarm to indicate when pump tubing needs to be changed

4.4 Sampler programs

Create sampler programs to operate the sampler automatically. Once programmed, install the sampler at the sampling site. Return to collect the samples at regular intervals or when the sampling program is complete. Sampler programs can be stored for later recall ([4.4.6 on page 43](#)).

Sampler operation

4.4.1 Sampler program overview

Table 3 outlines the menu for creating a basic sampling program.

Table 3 Basic program setup

Menu option	Description
Bottles	Enter bottle information.
Bottle quantity	Select the number of bottles in the sampler (1, 2, 4, 8, 12 or 24).
Bottle volume	Enter the capacity of each bottle in milliliters or gallons (0.5–99.8 gal or 50–65000 mL).
Intake tubing	Enter intake tubing information.
Tubing length	Enter the length of the intake tube from the strainer to the liquid sensor (3–99 ft or 100–3000 cm). An accurate length is necessary to obtain accurate sample volumes.
Intake tube type	Select the size and type of tubing (¼ in. vinyl, ⅜ in. vinyl or ¾ in. teflon)
Program delay	Delay starting the sampling program until specified time and day or until specified number of counts is reached.
Enable/disable	Select enable to use a program delay or disable to omit it.
Date and time	If enabled, enter the date and time when the program will start (24 hour format).
Counts	If enabled, enter the counts from the flow meter when the program will start (1–9999 counts). If counts is selected and the sample pacing is later set to time, the program delay will be disabled.
Sample pacing/collection	Specify whether to collect samples at regular time intervals or regular flow volume.
Time based	Collect samples at regular time intervals.
Pacing interval	Enter the time interval, in hours and minutes (0:01–999:00).
Take first sample	Select whether the program will start immediately or after the first time interval has passed.
Flow based	Collect samples at a specified flow volume (requires external flow meter).
Take sample every	Enter the flow interval that must expire between sample cycles, in counts (1–9999 counts).
Override time	Select enable to force a sample to be collected if the flow volume is unusually low.
Time	If enabled, enter the maximum time between samples (0:01–999:00). Timer is reset each time a sample is collected based on flow counts.
Take first sample	Select whether the program will start immediately or after the first flow interval has passed.
Sample distribution	For multiple bottle sampling, specify how the samples are delivered to the bottles.
Deliver samples to all	Select whether each sample will be delivered to all bottles or not.
Yes	Each sample will be delivered to all bottles.
End after last	Program will stop after the last sample has been collected. Enter number of samples (1–999).
Continuous	Sampler will continue collecting samples until stopped manually.
No	Samples will be delivered to a subset of bottles (see Figure 21 on page 42).
Samples/bottle	Enter the number of samples to be collected in each bottle (1–999).
Bottles/sample	Enter the number of bottles that will contain the same sample.
Liquid sensor	Enable/disable. If disabled, the sample volume must be calibrated by time.
Sample volume	Enter the volume to be collected per sample. If bottles/sample mode is selected, each bottle receives a full sample volume (100–10,000 mL).
Intake rinses	Enter the number of times the intake tube will be rinsed before each sample is collected (0–3).
Sample retries	Enter the number of sample retries to perform when a failure occurs (0–3).
Site ID	Enter a name for the sampling location (enter up to 12 characters). The site ID is used as the preset name if the program is saved.
Advanced sampling	Access the advanced sampling menu.
Done	Finished creating basic sampling program. Prompts user to start or cancel the program.

4.4.2 Create a sampler program



Create a sampler program to set up the sampler for automatic sampling routines.

Procedure:

1. Select **PROGRAM SETUP** from the main menu.
2. Select **MODIFY ALL**. The first parameter, bottle quantity, will be shown.
3. Select the number of bottles in the sampler. The next parameter, bottle volume, will be shown.
4. Enter the volume of the individual bottle(s). Use the **LEFT AND RIGHT ARROW** keys to move the cursor left or right. Use the **UP AND DOWN ARROW** keys to change the value. Change the units if necessary (gal or mL) with the arrow keys.
5. Continue to select or enter values for each parameter until complete. Refer to [Table 3 on page 40](#) for a complete list of all available options for a basic sample program.

4.4.2.1 Tips and techniques

Refer to [Table 4](#) and [Figure 21](#) for help with sample programming.

Table 4 Tips and techniques for the basic sampling program

Parameter	Tips and techniques
Bottle quantity	When 1 bottle is selected, the full bottle shut-off device is enabled and the distributor is disabled. When more than 1 bottle is selected, the distributor diagnostic is enabled.
Intake tubing	The sampler uses the intake tubing information to determine sample volume. If the intake tubing information is not accurate, the sample volume will not be accurate.
Program delay	If the program delay is set to counts and sample pacing is set to time, the program delay will be disabled.
Sample pacing—flow	Each time a sample is collected based on flow counts, the override timer is reset.
Sample distribution	If the bottle quantity is 1, the sample distribution option will not be available.
	See Figure 21 for a description of samples per bottle vs. bottles per sample.
	Bottles per sample—use bottles per sample when the sample volume is larger than one bottle can hold.
	Samples per bottle—the distributor arm will not advance to the next bottle until the specified number of samples has been delivered to the current bottle.
Liquid sensor	If the liquid sensor is disabled, the sample volume must be calibrated manually.
Sample volume	The sample volume must be entered as mL (1 gal.= 3785.4 mL). Make sure that the sample volume does not exceed the bottle volume. Sample volumes are rounded to the nearest 10 mL.




Figure 21 Two samples per bottle (left) vs. two bottles per sample (right)

4.4.3 Modify a program



Use the modify selected option to change an individual parameter for the currently loaded program.

Procedure:

1. Select **PROGRAM SETUP>MODIFY SELECTED**.
2. The selected parameters are grouped within the following subheadings. Select one of the available subheadings using the up and down arrow keys.
 - Bottles—quantity and volume
 - Intake tubing—length and type
 - Program delay
 - Sample pacing/collection—time or flow based
 - Sample distribution—for multiple bottle sampling
 - Liquid sensor—enable/disable
 - Sample volume—enter volume
 - Intake rinses—enter number
 - Sample retries—enter number
 - Site ID—enter ID
 - Advanced sampling
3. Change the parameter as shown in [section 4.2.3 on page 38](#).

4.4.4 Review a program



Use the review option to view the selected parameters without making any changes to the program.

Procedure:

1. Select **PROGRAM SETUP>REVIEW** from the main menu.
2. Press **ENTER** to view each entry.

4.4.5 Restore default settings



Use the restore option to set all program parameters to the default settings.

Procedure:

1. Select **PROGRAM SETUP>RESTORE** from the main menu.
2. Select **YES** to restore the factory default settings.

4.4.6 Store programs as presets



Use the presets option to store up to three sampler programs for later use. If any changes are made to a preset program after it is loaded, the program must be stored again to save the changes.

Procedure:

1. Select **PROGRAM SETUP>PRESETS** from the main menu.
2. The three available presets are displayed as **P1**, **P2** and **P3**. Select one of the presets.

Note: If a program is already stored, the site ID for that program will appear to the right of the preset number. If no preset program has been stored, the preset field will be empty.

3. Select **STORE CURRENT** to store the current program as a preset.

4.4.6.1 Load a stored program

Use the load program option to use a preset program as the current program.

Procedure:

1. Select **PROGRAM SETUP>PRESETS** from the main menu.
2. Select one of the presets (**P1**, **P2** or **P3**).
3. Select **LOAD PROGRAM** to load the selected preset as the current program. The selected preset program will be loaded and the display will return to the main menu. The program can be modified or used as is.

If a preset program is loaded and then modified, the program must be stored again (store current) to save the changes.

4.5 Start or stop a program

Use the **RUN/HALT PROGRAM** key to start or stop a program.

Procedure:

1. Press **RUN/HALT PROGRAM** to run, halt, resume or end a sampler program.
2. Select one of the available options:
 - **Start:** starts the currently loaded program. The status changes to running.
 - **Halt:** stops the program temporarily. The status changes to halted.
 - **Resume:** if halted, the program resumes from the point at which it was halted. The status changes to running.
 - **Start over:** if halted, the program starts from the beginning. The status changes to running.
 - **End program:** ends the currently running program. The program status changes to complete.

Note: A program must be stopped before the program setup or system setup menus can be modified.

4.6 Manual operation

Use manual operation to collect a grab sample, move the distributor arm or operate the pump.

4.6.1 Collect grab samples



Grab samples can be collected to verify sample volume or to collect samples without running a sampling program.

Procedure:

1. Press the **MANUAL OPERATION** key.
2. Select **GRAB SAMPLE**.
3. Place the intake tube into the sample water. Remove the outlet pump tube from the fitting on the sampler and place the tube into a sample container.
4. Enter the volume to be collected and press **ENTER**.

Note: The grab sample volume can only be modified if the liquid sensor is enabled. If the liquid sensor is disabled, the grab sample volume will reflect the volume defined using timed calibration.

5. The pump will purge the intake tube and then collect the specified volume of sample. The pump will then purge the intake tube.

To stop the pump at any time during the sample cycle, press the **STOP** key.

4.6.2 Move the distributor arm




When configured for multiple bottles, the distributor arm can be moved manually to distribute a grab sample to a specific bottle.

Procedure:

1. Press the **MANUAL OPERATION** key.
2. Select **MOVE DISTRIB**.
3. The current bottle number will be displayed. Enter the bottle number over which to position the distributor arm. Press **ENTER**.
4. The distributor arm will move to the selected bottle. To stop the distributor arm at any time, press the **STOP** key.

4.6.3 Start or stop the pump



The pump can be operated outside of a sampling program to collect a sample or purge the intake tubing.


Procedure:

1. Press the **MANUAL OPERATION** key.
2. Select **OPERATE PUMP**.
3. Select the direction to run the pump:
 - **Run forward:** pump operates in the forward direction to collect a sample and deposit into a sample container.
 - **Run backward:** pump operates in the reverse direction to purge the intake line.
4. The screen will display pumping if the forward direction was selected or purging if the reverse direction was selected.
5. The pump will operate until the **STOP** key is pressed.

4.7 View data

Data can be viewed from one of the status screens or from the diagnostics menu.

4.7.1 Status screen



The Status screen can be accessed by pressing the **STATUS** key or by selecting **STATUS** from the main menu.



If the storm program is enabled but no sonde is connected, the status of either the main program or the storm program can be viewed by selecting **MAIN** or **STORM** from the status menu.

Sampler operation



If the storm program is enabled and a sonde is detected, selecting **SAMPLE PROGRAM** from the status submenu allows the user to select the status of the main or storm programs. In addition, current sonde measurements can be viewed by selecting **MEASUREMENTS**.



If the storm program is disabled and a sonde is connected, the status of the main sample program or the current sonde measurements can be viewed by selecting **SAMPLE PROGRAM** or **MEASUREMENTS** from the status submenu

4.7.2 Status for main program


The status screen for the main program gives information about the program depending on the status of the main program. The status information depends on whether the program is in the ready to start, running/halted or complete mode.

4.7.2.1 Ready to start




The status reads **READY** when a program is ready to start and also displays the power supply voltage and the current time.

4.7.2.2 Running/halted



The status reads **RUNNING** or **HALTED** when a program is currently running or has been halted by the user. Use the **RIGHT ARROW** key to access information about the program currently running.



The information displayed includes:

- Power supply voltage
- Inhibit mode (none, setpoint trigger, program delay, user start, storm trigger, full bottle, setpoint delay)
- Sample summary (number of samples tried, missed and remaining)
- Next sample information (sample number, bottle number of next sample)
- Time before next sample
- Program start time

4.7.2.3 Complete



The status reads **COMPLETE** when a program ends after all sample cycles have been completed or when ended by the user. Use the **RIGHT ARROW** key to access information about the program that just ended. The display includes:

- Power supply voltage
- Program end time
- Sample summary (number of samples tried and missed)

4.7.3 Status for stormwater program



The status screen shows information about the stormwater program similar to that shown for the main program (Ready, Running, Halted or Complete).

Use the **RIGHT ARROW** key to access additional information about the program.

4.7.4 Sample history



Sample history displays the sample number, bottle number, result and time/date for each sample. The following results can be shown:

- **Success**—the sample was drawn successfully
- **Bottle full**—the full bottle shut-off was activated
- **Rinse error**—an error occurred during the rinse cycle
- **User abort**—a user pressed the **STOP** key to end the program
- **Arm faulty**—the distributor arm did not move correctly
- **Pump fault**—a fault occurred when the pump was operating
- **Purge fail**—an error occurred during the purge cycle
- **Sample time out**—liquid not detected within the timeout period
- **Power fail**—a power failure occurred during sampling

If a program is running or has been halted, the sample history is displayed for the currently running sample program. If the program has been completed, the sample history is displayed for the most recently completed sampling program. The sample history is automatically erased when a new program is started.

Procedure:

1. Select **DIAGNOSTICS>SAMPLE HISTORY** from the main menu to view the sample history.
2. The sample history will list the sample numbers, bottle numbers and brief result for each sample. Select a sample from the list and press **ENTER** to view complete details.
3. The complete details for the selected sample will be shown.

4.7.5 Event log



The event log records information on the following events:

- **Power on**—power was connected to the controller
- **Power fail**—power was intentionally or unintentionally disconnected from the controller without first turning power off
- **Firmware update**—a new version of firmware was installed
- **Pump fault**—a fault occurred when the pump was operating
- **Arm fault**—the distributor arm did not move correctly
- **Low memory battery**—the internal battery should be replaced
- **User on**—a user turned the power on using the power key
- **User off**—a user turned the power off using the power key
- **Program start**—the sample program was started
- **Program resume**—a program was resumed from the halt state
- **Program halt**—a program was halted
- **Program complete**—a program was completed
- **Grab sample**—a grab sample was taken
- **Change tube**—the maximum pump cycle counts have expired
- **SDI-12 timeout**—a communication error occurred on the SDI-12 interface.
- **High setpoint on**—user defined high setpoint was activated. Indicates measurement channel of interest and current measurement value.
- **High setpoint off**—user defined high setpoint was cleared. Indicates measurement channel of interest and current measurement value.
- **Low setpoint on**—user defined low setpoint was activated. Indicates measurement channel of interest and current measurement value.
- **Low setpoint off**—user defined low setpoint was cleared. Indicates measurement channel of interest and current measurement value.

4.7.5.1 View the event log

View the event log to see details about the events that have been recorded.

Procedure:

1. Select **DIAGNOSTICS>EVENT LOG** from the main menu to view the event log.
2. Select **DISPLAY**.
3. The event log will list the date and event. Select an event from the list and press **ENTER** to see complete details.

The top bar will show the event number and total number of events in the event log. For example, 01/80 will be displayed for event number 1 and a total number of 80 events.

4. The time/date, event description and any additional data for the selected event will be displayed.

4.7.5.2 Erase the event log

Erase the event log after event details have been reviewed to reduce the number of entries that are shown.

Procedure:

1. Select **DIAGNOSTICS>EVENT LOG** from the main menu to erase the event log.
2. Select **ERASE**.
3. Select **YES** to confirm the deletion.

4.8 Volume calibration



Samples can be collected with the liquid sensor enabled (recommended) or disabled. When the liquid sensor is enabled, the volume calibration is optional. When the liquid sensor is disabled, the volume for samples, rinses and stormwater must be calibrated manually.

When the liquid sensor is used for volume calibration, the sensor is adjusted to accurately measure all programmed volumes. When the sensor is disabled and the volume is calibrated by time, all programmed sample volumes must be calibrated individually.

Verify calibrations by measuring the volume from a grab sample ([section 4.8.3 on page 52](#)). If calibration using the liquid sensor does not give accurate volumes, the sensor can be calibrated ([section 4.9.1 on page 53](#)).

For typical applications, tap water can be used for volume calibration. If the sample composition is significantly different from typical water samples, calibrate the sampler using the liquid to be collected.

Calibration cannot occur while a sample program is running. All programs must be ended before calibration.

4.8.1 Volume calibration using the liquid sensor

Use the volume calibration with the liquid sensor enabled to adjust sample volumes slightly.

Procedure:

1. Make sure the liquid sensor is enabled by selecting **PROGRAM SETUP>MODIFY SELECTED>LIQUID SENSOR>ENABLE**.
2. Press **VOLUME CALIBRATION** and select **CALIBRATION**.
3. Remove the outlet pump tube from the fitting on the sampler and place the tube into a graduated cylinder. Place the intake tube into the sample source or tap water.

Note: Use the sample source for best accuracy.

4. Select **START**.
5. The pump will purge the intake tube and then collect the sample volume that is specified in the sampling program. The pump will then purge the intake tube.

To halt the calibration at any time, press the **STOP** key.

6. When the sample has been collected, select **DONE**. Compare the volume collected in the graduated cylinder with the sample volume that is entered in the program setup menu.

Select **REPEAT** to repeat the volume collection if necessary.

7. If the volume that was collected is different from the sample volume in the current program, enter the volume that was actually collected. Press **ENTER**. The sensor is then adjusted to accurately measure all programmed volumes.

To verify sample volume, collect a grab sample ([section 4.8.3 on page 52](#)).

8. Select **START** to start the sampling program or **CANCEL** to exit the volume calibration menu.

4.8.1.1 Reset the calibration



Use the reset cal option to restore the volume calibration to the default factory settings.

Procedure:

1. Make sure the liquid sensor is enabled by selecting **PROGRAM SETUP>MODIFY SELECTED>LIQUID SENSOR>ENABLE**.
2. To undo the calibration, press **VOLUME CALIBRATION** and select **RESET CAL**.
3. The calibration will be reset to the default calibration and the message “value has been reset to 0” will be shown.

4.8.2 Volume calibration based on time



When the liquid sensor is disabled, the main sample volume, the first flush storm volume (if storm water is enabled), and the rinse (if rinses are > 1) must be calibrated manually.

The sample volume is calibrated for the volume specified in the current program. If the sample volume is changed in the program, the sample volume must be recalibrated for the new volume.

Procedure:

1. Make sure the liquid sensor is disabled by selecting **PROGRAM SETUP>MODIFY SELECTED>LIQUID SENSOR>DISABLE**.
2. Press **VOLUME CALIBRATION**. Select one of the displayed volumes to calibrate if more than one is listed.
3. If calibrating a sample volume, remove the outlet pump tube from the fitting on the sampler and place the tube into a graduated cylinder. Place the intake tube into the sample source or tap water.
4. Select **START**. The pump will purge the intake tube and then begin to collect a sample.
5. Stop the pump at the selected volume or rinse location:
 - Sample volume: observe the volume in the graduated cylinder and press the **STOP** key when the volume specified in the main program is collected.
 - Rinse: observe the liquid as it travels up the intake tube and press the **STOP** key when the liquid reaches the liquid detector.
 - Storm volume: observe the volume in the graduated cylinder and press the **STOP** key when the volume specified in the stormwater program is collected.
6. If the pump was stopped at the correct volume, select **DONE**. To repeat the calibration select **REPEAT**.
7. Select another volume to calibrate or select **DONE**.

Note: All volumes must be calibrated before exiting the volume calibration menu.

8. When finished, connect the outlet pump tube to the tube fitting on the sampler.
9. Select **START** to start the sampling program or **CANCEL** to exit.

4.8.3 Verify sample volume



To check the sample size after calibration use the Manual Operation key to take a grab sample. Do not go back into calibration to check the volume since the volume compensation is reset to zero at the start of a calibration.

Procedure:

1. Press the **MANUAL OPERATION** key. Select **GRAB SAMPLE**.
2. Remove the outlet pump tube from the fitting on the sampler and place the tube into a graduated cylinder. Place the intake tube into the sample source or tap water.
3. If the liquid sensor is enabled, enter the volume that needs to be verified. If the liquid sensor is disabled, enter the volume specified in the program.
4. Press **ENTER**. The pump cycle will start (purge-sample-purge).
5. Compare the volume that was collected in the graduated cylinder to the volume specified in step 3. If the volume is acceptable, the sampler is calibrated correctly. If the volume is incorrect, repeat the volume calibration.

4.9 Controller settings

Use the system setup menu to change the following parameters:

- Date and time
- Communication
- Sampler base
- Liquid sensor calibration
- Display contrast
- Password
- Pump tube replacement reminder
- SDI-12 (optional)

Procedure:

1. Select **SYSTEM SETUP** from the main menu.
2. Select one of the available parameters, for example time/date setup. Refer to [Table 2 on page 39](#) for an overview of the system setup menu.
3. Make selections or change values with the arrow keys. Use the **LEFT AND RIGHT ARROW** keys to move the cursor left or right. Use the **UP AND DOWN ARROW** keys to change the value.
4. Select another parameter from the system setup menu, or press **BACK** to return to the main menu.

4.9.1 Liquid sensor calibration



The accuracy of the liquid sensor can vary with the type of liquid that is being sampled. For example, the volume of a highly turbid sample may not be as accurate as that of clear water. In some applications, the liquid sensor may be calibrated using the source liquid to improve detector performance.

Procedure:

1. Make sure the liquid sensor is enabled by selecting **PROGRAM SETUP>MODIFY SELECTED>LIQUID SENSOR>ENABLE**.
2. Select **SYSTEM SETUP>LIQ SENSOR CAL** from the main menu.
3. Select **PERFORM CAL**.
4. Place the intake tube into the sample source or tap water (if tap water is representative of the type of samples to be collected).

Note: Use the sample source for best accuracy.

5. Select **START**. The pump will operate in reverse to purge the intake tube.
6. The pump will then operate in the forward direction. Observe the sample flow in the intake tube to verify that it passes the liquid sensor. When the sample passes through the liquid sensor and no bubbles are present, press the **STOP** key.
7. The liquid sensor calibration is complete after the intake tube is automatically purged. Select **DONE** to exit the liquid sensor menu or **REPEAT** to repeat the calibration.

*Note: To restore the default calibration for the liquid sensor, select **SYSTEM SETUP>LIQ SENSOR CAL>RESTORE DEFAULT** from the main menu.*

4.9.2 Set password



A password can be enabled to restrict access to the program setup and system setup menus.

Procedure:

1. Select **SYSTEM SETUP>PASSWORD SETUP** from the main menu.
2. Select **ENABLE** to activate a password.
3. Select **YES** to set a new password or **NO** to activate the existing password.
4. If yes was selected, enter the old password and press **ENTER**. If changing the password for the first time, enter 900900 as the old password.
5. Enter a new password and press **ENTER**. The new password will be required to access the menus for program setup and system setup.



4.9.3 Tubing life indicator



The tubing life option can be used to set a reminder to replace the pump tubing. The user defines a maximum number of pump cycles after which a message will be shown to replace the pump tubing. After replacing the tubing, the current number of cycles must be reset for the new tubing.

4.9.3.1 Enable the tubing life indicator




Enable the tubing life indicator to set a reminder for when the pump tubing should be replaced.

Procedure:

1. Select **SYSTEM SETUP>TUBING LIFE** from the main menu to access the tubing life option.
2. Select **ENABLE** to activate the tubing life indicator.

4.9.3.2 Tubing life status




Use the status option to see how many pump cycles have been completed.

Procedure:

1. If the tubing life option is not enabled, select **SYSTEM SETUP>TUBING LIFE>ENABLE>STATUS**. If the tubing life option is enabled, select **SYSTEM SETUP>TUBING LIFE>STATUS**.
2. The current number of cycle counts on the pump since the tubing life indicator was reset and the cycle limit set by the user are both shown. Press **ENTER** or **BACK** to return to the system setup menu.

4.9.3.3 Tubing life cycle limit




Use the cycle limit option to set the number of pump cycles when the change tube reminder will be shown.

Procedure:

1. If the tubing life option is not enabled, select **SYSTEM SETUP>TUBING LIFE>ENABLE>CYCLE LIMIT**. If the tubing life option is enabled, select **SYSTEM SETUP>TUBING LIFE>CYCLE LIMIT**.
2. Change the cycle limit to the number of pump cycles after which the pump tubing should be replaced. After setting the limit, press **ENTER** to view the current status and verify the cycle limit.
3. When the number of actual cycle counts equals the cycle limit set by the user, the “change tube” message will be shown when a key is pressed and an entry will be placed in the event log.

4.9.3.4 Reset tubing cycles



When the “change tube” message is shown, replace the pump tubing and then reset the pump cycles.

Procedure:

1. If the tubing life option is not enabled, select **SYSTEM SETUP>TUBING LIFE>ENABLE>RESET CYCLES**. If the tubing life option is enabled, select **SYSTEM SETUP>TUBING LIFE>RESET CYCLES**.
2. Select **YES** to reset the pump cycle count to 0. Press **ENTER** to view the status screen to verify that the cycle count is set to 0.

Note: It is important to reset the pump cycles so that the change tube message will be shown at the correct time for the new tube.

4.9.3.5 SDI-12 configuration



The optional SDI-12 interface can connect to devices such as the Hydrolab MS5 and DS5 to collect water quality measurement data for use as triggers in setpoint sampling applications. Use 50 ft cable (Cat. No. 8762400) or 100 ft cable (Cat. No. 8762500) to connect one of these devices to the SD900 (see [Figure 17 on page 35](#)).

The SD900 supplies power to the SDI-12 device. A separate power source for the sonde is necessary only when data logging is required. The address assigned to the SDI-12 sensor is automatically determined by the SD900. The SD900 can retrieve up to nine measurements from one SDI-12 sensor.

The SDI-12 interface is enabled only if a device is connected on the external SDI-12 connector and is detected. Scanning for a sonde occurs automatically. If a sonde is detected, an additional selection appears in the SYSTEM SETUP menu for configuring the SDI-12 interface.



The SDI-12 setup menu is used to obtain details about the connected sonde, configure the parameter type and unit, and set scan intervals for the SDI-12 device. From the main menu, select SYSTEM SETUP>SDI-12.

The DISPLAY SONDE option displays specific information regarding the attached SDI-12 device, including:

- Device vendor name
- Device model name
- Current SDI-12 address assigned to the device
- SDI-12 protocol version implemented on the device
- Number of available measurements
- Warmup time

The CFG PARAMETERS option allows the user to define measurement types and units for the measurement channels returned by the SDI-12 device. Each channel is displayed with a generic reference indicator according to the order defined in the SDI-12 device. The user can assign a label (such as Temperature) and a unit (such as Celsius) to each measurement channel. Assigning specific labels and units to a channel makes the channel easier to identify when defining a setpoint sampling algorithm or viewing measurement status.

[Table 5](#) lists the types of measurements, units, and resolutions supported by the SD900:

Table 5 Measurements supported by SD900

Measurement	Unit	Resolution
Ammonia (NH ₃)	mg/L-N	2
Ammonium (NH ₄ ⁺)	mg/L-N	4
	mV	2
Chloride (CL ⁻)	mg/L	4
	mV	4
Chlorophyll	ug/l	2
	Volts	4
Conductivity	mS/cm	4
	uS/cm	3
DO	mg/L	2
	%sat	2
Ext. Sonde Pwr	Volts	4
	%	4
HOCl	ppm	4
	Volts	4
Int. Sonde Pwr	Volts	4
	%	4
Level	meter	3
	ft	3

Table 5 Measurements supported by SD900

Measurement	Unit	Resolution
	psi	3
NH3+NH4	mg/L-N	4
Nitrate (NO3-)	mg/L-N	2
	mV	2
ORP	mV	0
PAR	uE/S/n2	4
pH	pH unit	2
Phycocyanin	cells/mL	2
	mV	2
Phycoerythrin	cells/mL	2
	mV	2
raw TDG	mV	4
ref PAR	uE/S/n2	4
Resistivity	kOhm/cm	3
Rhodamine	ppb	2
	Volts	2
Salinity	ppt	4
Total Dissolved Solids	g/L	2
Temperature	C	2
	F	2
	K	2
Total Dissolved Gas	mmHG	4
	psi	4
Transmission	%	4
	volts	4
	%660nm	4
	v660nm	4
Turbidity	NTU	1
	volts	1

The SD900 directly supports the Hydrolab MS5 and DS5 by automatically detecting the measurement type and unit for each of the SDI-12 parameters. By default in Hydrolab sondes, the SDI-12 interface is not enabled. Refer to [Appendix B on page 93](#) for configuration of the Hydrolab sondes for SDI-12 interface.

Note: Hydrolab firmware v5.43 or later must be installed in the Hydrolab sonde for auto configuration.

The SCAN INTERVAL is a user supplied parameter that defines the periodic interval rate at which the SD900 refreshes measurement data supplied from the sonde. Shorter intervals allow the SD900 to be more responsive in setpoint sampling applications, but decrease battery life.

Section 5 Advanced sampling

5.1 Advanced sampling overview

Use the advanced sampling menu for the following operations:

- Send a 12 VDC output signal to start a second sampler, activate a relay or for communications
- Set the sampler to start and stop from an external signal
- Set multiple start and stop times
- Set variable time intervals
- Collect first flush samples from stormwater
- Define a setpoint sampling algorithm.
- Configure the sampler with timed bottle sets.

5.2 Advanced sampling menu

Table 6 outlines the menu for the advanced sampling operations.

Table 6 SD900 advanced sampling menu

Menu option	Description
Program complete O/P	Send a signal at the completion of a sampling program. The signal can be used to start a second sampler or activate a relay.
Setpoint sample	Start and stop the sampler from either an external trigger on the auxiliary interface or a measurement supplied on the SDI-12 interface.
Special output	Send a signal to a connected device.
Each sample	Send signal at the completion of each sample cycle.
Sample pumping	Send signal during the sample intake.
Rinse to purge	Send signal during the entire sample cycle, including all purge and rinse cycles.
Start/stop times	Start and stop a program at user specified dates and times.
Program start	Set up to 12 start and stop times for any one program.
Stormwater	Collect first flush samples at timed intervals. Can be initiated by external device.
Immediate	Start program immediately.
External	Start program from an external device.
Variable intervals	Sample at variable time or flow intervals.
Timed bottle	Allow a single sampler to function like multiple samplers.
Done	Exit the advanced sampling menu.

5.3 Advanced sampling instructions



To access the advanced sampling menu, select **PROGRAM SETUP>MODIFY SELECTED>ADV SAMPLING** from the main menu.

5.3.1 Send output signal at program completion



A 12 VDC signal can be sent through pin F of the auxiliary connector at the completion of a sampling program or when the full bottle shut-off is activated. The signal remains on for 61 seconds.

To enable the ability to transfer sample history to an external Sigma 950 flow meter, program complete must be disabled to enable the bottle number output. In addition, the special output must be enabled and configured to assert after the sample cycle is complete.

The output signal can be used for the following purposes:

- Start another sampler. Cascading samplers require a cascading cable (Cat. No. 8757300). The slave sampler must enable setpoint sampling and start on external trigger.
- Activate a relay or other device when the program is complete.

Procedure:

1. Select **PROGRAM SETUP>MODIFY SELECTED>ADV SAMPLING** from the main menu.
2. Select **PGM COMPLT O/P>ENABLE**.
3. The message “Bottle number output disabled on pin F” will be shown. The bottle number output to send sample history to a Sigma 950 flow meter will be disabled.
4. Select **BACK** or **ENTER** to activate the output signal.

5.3.2 Send output signal with sample cycle (special output)



The special output option sends a 12 VDC signal through pin E of the auxiliary connector during or after a sample cycle.

In order to transfer sample history to an external flowmeter, two configurations are necessary. First, the program complete output needs to be disabled to enable the bottle number output. The bottle number output transmits whether or not the sample was taken successfully and which bottle the sample was deposited in.

Second, the special output needs to be enabled and configured to assert “After Each Sample.”

The sample history will be transferred to the external Sigma 950.

There are three possible output signal configurations:

- After each sample—four second pulse at the end of each sample cycle. This option is used to signal an external device that a sample cycle is complete.
- During sample intake—during the sample intake portion of the cycle only, ignoring all purges and rinse cycles.
- During entire cycle—during the entire sample cycle including all purge and rinse cycles.

Procedure:

1. Select **PROGRAM SETUP>MODIFY SELECTED>ADV SAMPLING** from the main menu.
2. Select **SPECIAL OUTPUT>ENABLE**.

3. Select one of the output options:
 - **AFTER CYCLE**—at the completion of each sample cycle.
 - **SAMPLE PUMPING**—during sample intake only.
 - **ENTIRE CYCLE**—during entire sample cycle.

5.3.3 Operate from external signal (setpoint sample)



The setpoint sample option starts and stops the sampler after receiving a signal from an external device such as a flow meter. The current status indicates when the sample program is being inhibited by an external device.

Note: Setpoint and stormwater sampling cannot be enabled at the same time.

Procedure:

1. Select **PROGRAM SETUP>MODIFY SELECTED>ADV SAMPLING** from the main menu.
2. Select **SETPT SAMPLE>ENABLE**.
3. Select one of the setpoint options:
 - **START ON SETPT**—starts a sample program when the signal is received, ignoring all future transitions, and continues until the program is complete.
 - **START/STOP**—starts a sample program when the signal is received and stops the program when the signal is no longer received.
4. Enter a delay time in hours and/or minutes that must expire before the sample program starts. The delay time will begin when the external signal is received. The program will begin after the delay time has passed.

Note: Setpoint control and delay apply globally to all triggers.

5.3.3.1 Setpoint sampling triggers (SDI-12)




When an SDI-12 device is connected to the SD900, its measurements are available as setpoint sampling triggers (in addition to the external inhibit.). A maximum of 4 measurement triggers can be enabled independent of the external trigger. If multiple triggers are enabled, the program will be activated when at least one trigger is satisfied, and deactivated when all triggers are cleared.

To enable measurement setpoint triggers, from the main menu select **PROGRAM SETUP>MODIFY SELECTED>ADV SAMPLING>SETPT SAMPLE>SETPT TRIGGER**.

If an SDI-12 device is detected, a list of measurements is displayed along with the external trigger. Select a trigger source from the list to define a setpoint.

Note: A checkmark in the left most column indicates a specific channel is already enabled as a trigger. In order to disable Setpoint Sampling, each individual channel must be disabled.



Each measurement trigger can be defined as a high or low setpoint. Additionally, an optional deadband value can be set. The purpose of a deadband is to keep the trigger from rapidly fluctuating between active and inactive states when the trigger measurement value hovers near the defined setpoint.

In figures 21 and 22, pH is the measurement parameter selected as the trigger. The setpoint is set at 7.00 and the deadband value is set to 0.10 pH.

In a HIGH SETPOINT condition (Figure 22), the trigger becomes active when the rising pH value reaches the setpoint value of 7.00. The trigger condition does not clear until the pH measurement value falls below 6.9 (the setpoint value minus the deadband value.)

In a LOW SETPOINT condition (Figure 23), the trigger becomes active when the decreasing pH measurement value reaches 7.00. The trigger condition does not clear until the pH measurement value rises to 7.10 (the setpoint value plus the deadband value).




Figure 22 High Setpoint

1	pH values scale	4	Deadband
2	Setpoint trigger ON (Time-stamp recorded in event log)	5	Setpoint (7.00)
3	Setpoint trigger OFF (Time-stamp recorded in event log)	6	Scan intervals




Figure 23 Low Setpoint

1	pH values scale	4	Deadband
2	Setpoint trigger On (Time-stamp recorded in event log)	5	Setpoint (7.00)
3	Setpoint trigger Off (Time-stamp recorded in event log)	6	Scan Intervals



Enter a setpoint trigger within the allowable range.




Enter an optional deadband to prevent questionable triggers when the measurement value hovers around the user defined setpoint.



Select ENABLE to store the trigger definition.
Select DISABLE to remove the existing trigger definition.



Once a trigger definition has been enabled, choose SETPT CONTROL to define how the sample program is controlled.



Choose either the START ON SETPT or the START/STOP option. If the START ON SETPT option is chosen, once a setpoint trigger is active, the sampling program will begin running continuously and stop when the program expires. If the START/STOP option is chosen, once a setpoint trigger is active, the program will begin running and stop when the trigger is cleared.

Enter a setpoint delay if desired. The delay time begins when the setpoint trigger becomes active. The program will begin running when the delay time expires.

Note: Setpoint control and delay options are global settings applied to all triggers.

5.3.4 Set multiple start and stop times



The start/stop time option creates an intermittent sampling schedule. The program begins sampling at the first start time and continues until the first stop time. Up to 12 start and 12 stop times can be specified.

Procedure:

1. Select **PROGRAM SETUP>MODIFY SELECTED>ADV SAMPLING** from the main menu.
2. Select **STRT/STOP TIME>ENABLE**.
3. If the sample program is configured for multiple bottles, select **ENABLE** to start sampling at bottle 1 when each start time is reached. Select **DISABLE** to continue the distribution sequence from the last stop time.
4. Enter the time (24 hour) and date for the first start time.
5. Enter the time (24 hour) and date for the first stop time.
6. Repeat steps 4 and 5 until all start and stop times have been entered.

5.3.5 Collect first flush stormwater samples



The stormwater option collects first flush (FF) samples or initial runoff during storm conditions when pollutants are typically at a high concentration. The first flush samples are collected at timed intervals and can be initiated by an external device. A stormwater program can run at the same time as the main program. The stormwater option has the following capabilities:

- Collection of grab samples at up to 24 different time intervals. First flush and main program flow-weighted composite samples are automatically segregated. The first flush sample volume may be set independently of the sample volume for the flow-weighted composite.
- Initiation by an external device. A dry contact closure across pins B and D on the auxiliary connector, held closed for at least 61 seconds, is required.
- When sampling with multiple bottles, the sampler can be programmed to collect one large “first flush” sample (or small multiple samples) at timed interval(s). The number of bottles

segregated for the first flush sample is selectable. Concurrently, flow-weighted samples are collected from the beginning of the storm until all remaining bottle(s) are filled, or after a user selected time has elapsed.

Procedure:

1. Select **PROGRAM SETUP>MODIFY SELECTED>ADV SAMPLING** from the main menu.
2. Select **STORMWATER>ENABLE**.
3. Select whether the program will be started immediately or from an external device:
 - **Immediate**—program starts when **RUN** is pressed and **START** is selected.
 - **External**—program starts when signaled by an external device.
4. If configured for a single bottle, enter the number of first flush (FF) samples to collect.
5. If configured for multiple bottles, enter the number of bottles to be used for first flush collection.
6. Enter the multi-bottle distribution mode ([Figure 21 on page 42](#)):
 - **Samples per bottle**: more than one sample is collected in each bottle
 - **Bottles per sample**: more than one bottle is used to collect each sample.
7. Enter the number of samples per bottle or bottles per sample.
8. Enter the time interval between each first flush sample cycle.

Variable intervals may be entered, or the same time may be entered for each interval. The sum of the intervals is equal to the total length of the stormwater collection period. First flush samples are usually collected within 30 minutes of a storm.

Note: The number of intervals is determined by the number of bottles and the distribution mode.
9. Enter the volume of each first flush sample.
10. Select **ENABLE** to set a time limit for stormwater collection. Enter the program time limit. The program will stop when this time limit is reached.

Select **DISABLE** to allow the program to run until complete without a time limit.

NPDES requirements typically request monitoring for the first three hours of a storm. If the flow volume is lower than expected, flow-weighted sampling could continue for some time as flow rates drop and sample intervals become longer.

5.3.6 Set variable intervals



Variable time or flow intervals can be set for sample cycles. Intervals will be in hours and minutes if the sample pacing mode is time based. Intervals will be in counts if the sample pacing mode is flow based.

Procedure:

1. Select **PROGRAM SETUP>MODIFY SELECTED>ADV SAMPLING** from the main menu.
2. Select **VARIABLE INTVL>ENABLE**.
3. Enter the time (or count) interval between each sample cycle. Up to 99 intervals can be entered.

Note: When entering individual intervals, the current interval is recorded only when the **ENTER** key is pressed and does not record when the back key is pressed.

5.3.7 Timed Bottle



The timed bottle option allows a single sampler unit to function like multiple samplers. This can be useful in situations of high versus low flow days, for example.

In this mode, the user configures the sampler to execute a sampling program in multiple parts. The first part of the program executes for a time interval defined by the operator, where after the second part operates for a user defined time interval, followed by the third part, and so on.

The sample bottles are also divided into multiple sets. The first set of bottles is assigned to part one of the sampling program, the second set of bottles is assigned to part two of the sampling program, and so on.

A timed bottle program can run at the same time as the storm program, setpoint sampling, and variable intervals.



The timed bottle function, when enabled with variable intervals, will collect samples in each timed bottle set according to the variable intervals defined. When a timed bottle set switch occurs upon expiration of the trigger time, the variable interval index is reset.

Note: Timed bottle can be enabled only if the sampler is configured with multiple bottles, non-composite mode, and the distribution mode set to *Bottles/Sample*.

Procedure:

1. Select **PROGRAM SETUP>MODIFY SELECTED>ADVANCED SAMPLING** from the main menu.





2. Select TIME BOTTLE>ENABLE

3. Enter the number of samples to be collected in each timed bottle set.

4. Select one of the timed bottle trigger time methods:

- 24 HR Format—Enter a time in hours and / or minutes that must expire every 24 hr (day) before one bottle set switches to the next bottle set.
- Duration—Enter a time in hours and / or minutes that must expire before one bottle set switches to the next bottle set. As long as the controller is not inhibited, the trigger timer starts when RUN is pressed and START is selected.

5. **Info Message:** The bottle set size equals the number of bottles per sample selected. Two bottles per sample means two bottles equal one timed bottle set. The sampler displays this information.

6. Select one of the RUN MODE options.

- Selecting CONTINUOUS causes the program to continuously run and switch bottle sets after each specified trigger time expires until manually stopped.
- Selecting END AFTER LAST causes the controller to stop sampling when the last sample is collected in the last bottle of the last timed bottle set.

Note: If Take 1st Sample is set to IMMEDIATE on the controller, the first sample of every timed bottle set is taken immediately. If Take 1st Sample is set to AFTER THE INTERVAL, the first sample of every timed bottle set is taken after the first interval.

CAUTION

Only qualified personnel should conduct the tasks described in this section of the manual.

WARNING

Potential shock hazard. Always disconnect power to the sampler before performing any maintenance or service.

CAUTION

Biological sample hazard. Follow safe handling protocols during contact with sample bottles and sampler components. Disconnect the sampler from power to disable the pump before handling.

6.1 Upgrades, Repairs, General Maintenance

Only a qualified technician should service the sampler. For example, steps that require knowledge of CMOS electrostatic discharge precautions and advanced electronics training should only be performed by a qualified technician.

6.2 Sampler cleaning

Sampler housing

Clean the interior and exterior of the sampler housing with a damp sponge and mild detergent. Do not use abrasive cleaners.

Sample bottles

Clean the bottles using a brush and water with a mild detergent, followed by a fresh water rinse and a distilled water rinse. Glass bottles may also be autoclaved.

6.3 Pump maintenance

CAUTION

Pinch hazard. Always disconnect power to the sampler before opening the pump cover.

The tubing in the peristaltic pump will deteriorate over time from the action of the rollers against the tubing. Be sure to replace the pump tubing before it splits to prolong the life of the sampler and prevent contamination of the work area.

6.3.1 Pump tube life

Pump tube life depends on several factors:

- Distance from sample source. Locate the sampler as close to the sample source as possible.
- Vertical lift. Minimize the vertical lift as much as possible.
- Intake rinses. Minimize the number of intake rinses prior to sample collection.
- Sample retries. Minimize the number of sample retries to successfully collect a sample.
- Sample volumes/duration. Minimize the volume of sample and maximize the time between samples.

- Constituents in the sample liquid. Grit and other abrasive solids cause greater wear on the tube when they are squeezed through the pump rollers.

6.3.2 Pump tube replacement

Important Note: Use of tubing other than that supplied by the manufacturer may cause excessive wear on mechanical parts and/or poor pump performance.

Inspect the pump tubing and rollers on a regular basis. Replace the tubing when deteriorated, at regular intervals or when the “change tube” message is displayed (section 4.9.3 on page 54).

Prerequisites:

- Pump tubing—pre-cut or bulk (15 ft or 50 ft)

Note: See [Replacement parts on page 83](#) for ordering information.

Removal procedure:

1. Turn off the controller power.
2. If using bulk pump tubing, cut a 23.25 inch piece and mark the tube with alignment dots at the locations shown in [Figure 24](#).
3. Disconnect the old pump tubing from the liquid sensor and from the tube fitting on the sampler housing.
4. Loosen the thumbscrew on the pump cover and open the cover.
5. Pull the tube from the pump tube track while turning the rotor to remove the old tubing from the pump.
6. Clean the silicone residue from the interior of the pump housing and from the rollers (see [section 6.3.3 on page 72](#)).




Figure 24 Pump tubing measurement

1	To liquid sensor	3	Inside pump body
2	Alignment dot	4	To tube fitting on center section

Installation procedure:

1. Connect one end of the tubing to the liquid sensor fitting. Press the tubing into the pump tube guide (Figure 25).
2. Press the tubing into the upper pump tube track. Make sure that the alignment dot is in line with the upper pump tube track as shown in Figure 25.
3. Hold the tubing with one hand while rotating the pump rotor to guide the tubing around the rotor (Figure 25). The guide pins will push the tubing into place.
4. Press the tubing into the lower pump tube track. Make sure that the alignment dot is in line with the lower pump tube track as shown in Figure 25.
5. Close and secure the pump cover with the thumbscrew.
6. Connect the open tube end to the tube fitting on the sampler (Figure 26).




Figure 25 Pump tubing installation

1 Pump tube guide	5 Rotor
2 Pump tube track (upper)	6 Pump tube track (lower)
3 Guide pin	7 Connection to liquid sensor
4 Alignment dot	




Figure 26 Pump tube installed

1	Pump tube to sampler tube fitting
2	Pump tube to liquid sensor

6.3.3 Rotor removal and cleaning

Remove the pump rotor to thoroughly clean the silicone residue from the pump tube.

Procedure:

1. Remove the pump tube (see [section 6.3.2 on page 70](#)).
2. Open the rubber flap on the end of the rotor and remove the screw with a flat-blade screwdriver ([Figure 27](#)).
3. Remove the rotor. A collet connects the rotor to the pump shaft and can come off when the rotor is removed ([Figure 27](#)).
4. Clean the rotor, pump tube tracks and pump housing with a mild detergent.
5. If the collect was removed in step 3, align the recess in the collet with the tang on the shaft and push the collet on the shaft ([Figure 27](#)).
6. Push the rotor on the shaft and secure with the screw. Do not overtighten the screw. Close the rubber flap on the rotor.
7. Install the pump tube ([section 6.3.2 on page 70](#)).




Figure 27 Pump rotor removal

1	Shaft	5	Rotor
2	Collet recess	6	Collet
3	Rubber flap	7	Tang
4	Screw		

Note: A complete pump assembly replacement (Cat. No. 6262000) may be ordered.

6.4 Distributor arm tubing replacement

The distributor arm moves over each bottle during multiple bottle sampling. Inspect the tubing in the distributor arm on a regular basis. Replace the tubing when deteriorated or at regular intervals.

Prerequisites:

- Tubing, distributor arm, pre-cut. Make sure that the correct tube is used for the correct distributor and distributor arm. Refer to [Figure 2 on page 11](#) and to [Replacement parts on page 83](#).

Procedure:

1. Remove the old tubing from the distributor arm.
2. Insert the new tubing into the distributor arm so that the end of the tubing extends out of the nozzle no more than 1/8 inch ([Figure 28](#)).

Note: Do not let the tubing extend more than 1/8 inch past the nozzle end of the arm. If the tubing extends too far, the tubing will get caught on the bottles and interfere with sampling.

3. To make sure that the distributor is aligned properly, run the manual distributor diagnostic (see [section 7.3 on page 80](#)).




Figure 28 Distributor assembly

1	Nozzle	4	Shaft
2	Distributor arm	5	Tube
3	Distributor motor		

6.5 Desiccant replacement

A desiccant cartridge is located inside the controller to absorb moisture and prevent corrosion. Over time the desiccant will become saturated with moisture and should be replaced.

Monitor the desiccant color through the clear plastic window ([Figure 29](#)). The color will change from yellow to green when the desiccant is saturated.

Prerequisites:

- Desiccant
- Silicone grease

Note: See [Replacement parts on page 83](#) for ordering information.

Procedure:

1. Unscrew and remove the desiccant holder from the controller (Figure 29).
2. Remove the plug from the end of the desiccant tube (Figure 30) and discard the spent desiccant.
3. Fill the desiccant tube with fresh desiccant.
Note: Fresh desiccant should be yellow.
4. Replace the plug.
5. Apply grease to the O-ring (Figure 30).
6. Replace the desiccant tube in the controller.




Figure 29 Side view of controller—pump and desiccant

1 Desiccant window	2 Peristaltic pump
--------------------	--------------------




Figure 30 Desiccant holder

1 Plug	3 O-ring
2 Desiccant tube	

Section 7 Troubleshooting

7.1 General troubleshooting

Refer to the information in [Table 7](#) when a problem with the sampler occurs.

Table 7 SD 900 general troubleshooting information

Problem	Cause	Solution
Instrument will not power on with AC power.	Problem may be with the controller, power supply or main power source.	Isolate components to determine which component has the problem.
	Problem with circuit breaker.	Check the circuit breaker for the main power.
	Problem with electrical outlet.	Check to see if the outlet is receiving power.
	Defective power supply.	Replace power supply or use a battery.
	Defective controller.	Contact the service center.
Instrument will not power on with DC power.	Battery is not charged.	Replace with a fully charged battery.
	Battery does not hold charge.	Replace battery or use an AC power supply.
	Defective controller.	Contact the service center.
Battery life is short.	Insufficient voltage.	The lead-acid battery should hold 12.6 V to 13.4 V when fully charged.
	Battery power drains quickly.	Fully charge the battery and allow to stand for one hour. If the voltage drops below 12.5 V, replace the battery.
	Incorrect sampler base configuration.	Set sampler base to portable option (Table 2 on page 39).
Sampler will not create sufficient lift.	Strainer is not completely submerged.	Make sure the strainer is completely submerged.
	Intake tube has a leak.	Replace intake tube.
	Pump tube is worn.	Replace pump tube.
	Pump roller assembly is worn.	Contact the service center.
Inaccurate sample volumes.	Incorrect volume calibration.	Repeat the volume calibration and take a grab sample to verify accuracy.
	Incorrect intake tube length is programmed in the sampler.	Measure the intake tube length and enter in the program setup menu.
	Intake tube is not completely purging.	Make sure the intake tube is on a downward slope as vertical as possible, with no low points where liquid can accumulate.
	Strainer is intermittently submerged.	Install the shallow depth strainer (Cat. No. 2071 or 4652).
	Worn pump tubing and/or roller assembly.	Replace pump tubing; contact service center for roller assembly.
	When the liquid sensor is disabled, variable suction heads will cause variable sample volumes.	Enable the liquid sensor and complete a volume calibration.
	Liquid sensor is not operating properly.	Calibrate the liquid sensor using the same liquid that is being sampled.

7.2 Error messages and notifications

Messages will be shown in the controller display when errors occur or to confirm that an operation is complete. Refer to [Table 8](#) for a description of the possible messages.

Table 8 SD 900 error and information messages

Message	Reason	Action
ERROR WRONG RANGE	The value that was entered is outside of the acceptable range.	Press BACK or ENTER . Enter a valid number that is within the range specified on the bottom of the screen.
BOTTLE NUMBER OUTPUT DISABLED ON PIN F	Message is displayed when program complete output is enabled. The bottle number output on the auxiliary port (pin F) is automatically disabled.	Press BACK or ENTER to keep program complete output enabled. If bottle number output is preferred, disable the program complete output.
NOT ALLOWED CANNOT ENABLE SETPOINT SAMPLING AND STORM WATER	An attempt was made to enable setpoint sampling and stormwater sampling at the same time.	Disable setpoint sampling or stormwater sampling, then enable the preferred option.
NOT PERMITTED. END THE PROGRAM FIRST TO ACCESS THIS FEATURE	An attempt was made to access a menu such as program setup, system setup, volume calibration or manual operation while a program was running.	Press BACK or ENTER and select END PROGRAM or CANCEL to continue the program.
NEED TO CAL. LIQUID SENSOR IS DISABLED. CAL IS REQUIRED!	The liquid sensor was disabled and a manual volume calibration is required.	Calibrate all volumes as specified in section 4.8 on page 49 .
NEED TO CAL. LIQUID SENSOR IS ENABLED. SENSOR REQUIRES CAL	The liquid sensor must be calibrated.	Calibrate the liquid sensor as specified in section 4.9.1 on page 53 .
DISTRIBUTOR MOVE IS COMPLETE	Confirmation that the distributor arm was moved to a specific bottle position and the move is complete.	Press BACK or ENTER to acknowledge the information.
NOT ALLOWED. 1 BTL CONFIGURED DISTRIBUTOR NOT RELEVANT.	An attempt was made to move the distributor when the program setup was set to a single bottle.	Change the bottle number configuration in the program setup menu before moving the distributor.
RESET CAL. VALUE HAS BEEN RESET TO 0.	Confirmation that volume calibration with the liquid sensor enabled was reset to 0 in the volume calibration menu.	Press BACK or ENTER to acknowledge the information. The liquid sensor is no longer calibrated.
NOT ALLOWED. ENABLE LIQUID SENSOR TO PERFORM CAL	An attempt was made to calibrate the liquid sensor when the liquid sensor was disabled.	Enable the liquid sensor in the program setup menu.
BOTTLE NUMBER OUTPUT ENABLED ON PIN F	Confirmation that the bottle number output on pin F of auxiliary port is enabled when the program complete output is disabled.	Press BACK or ENTER to acknowledge the information.
CANNOT ENABLE. PGM START/STOP AND STORM WATER AT SAME TIME	An attempt was made to enable start/stop time and stormwater at the same time.	Disable start/stop time or stormwater in the advanced sampling menu, then enable the preferred option.
FAULT. PUMP FAULT	The pump failed to operate properly.	Examine the pump for obstructions.
ALARM. CHANGE TUBE	The specified maximum number of pump cycles have expired. The pump tube should be changed.	Change the pump tube and reset the maximum number of pump cycles (section 4.9.3 on page 54).
FAULT. ARM FAULTY	The distributor arm failed to operate properly.	Make sure the distributor arm is connected properly and can move freely in both directions.

Table 8 SD 900 error and information messages (continued)

Message	Reason	Action
ERASING LOG. PLEASE WAIT	Confirmation that the event log is being cleared.	Wait for the log to be erased.
ERROR WRONG PWD	An incorrect password was entered.	Press BACK or ENTER and enter the correct password.
PGM DELAY DISABLED	A program delay was set based on counts but sample pacing/collection was set based on time. The program delay is automatically disabled.	To use a program delay in counts, set the sample pacing/collection to flow based.
STARTING PLEASE WAIT	Confirmation that a program is starting.	Wait for the program to start.
ALARM LOW BATTERY	The main battery power is low.	Replace the battery with a fully-charged battery.
ALARM LOW MEMORY BATTERY	The internal memory battery is low	Contact the service center.
ERROR INVALID SELECTION	The selection is not compatible with the program setup. For example, the base selected in the system setup menu must be compatible with the number of bottles in the program setup menu.	Select a value that is compatible with the values specified in the program setup menu.
CANNOT ENABLE TB SET IN 1 BOTTLE CONFIGURATION	An attempt was made to enable Timed Bottle with bottle quantity of sampler configured to 1 bottle.	Change the bottle quantity in the program setup menu to more than 1.
CANNOT ENABLE TB SET IN SAMP/BOT CONFIG	An attempt was made to enable Timed Bottle with distribution mode of sampler configured to sample per bottle.	Change the distribution mode in the program setup menu to bottles per sample.
CANNOT ENABLE TB SET IN COMPOSITE MODE	At attempt was made to enable Timed Bottle with Deliver to All Bottles enabled (Composite mode).	Disable Composite Mode in the program setup menu (OPT_NO.)
INVALID SELECTION (BOTTLE QUANTITY)	An attempt was made to change the bottle quantity to 1 with Timed Bottle enabled.	Press ENTER key and choose other options.
ERROR WRONG RANGE (BOTTLES PER SAMPLE)	An attempt was made to set a value with bottle per sample greater than total bottle quantity, or total bottle quantity cannot be divided equally, or total bottle quantity is out of range.	Press ENTER key and choose other options.
ERROR WRONG RANGE (FF NUM OF BTLS)	An attempt was made to set a value to FF number of bottles when the difference between total bottle quantity and ff number of bottle cannot be equally divided by bottles per sample or is out of range.	Press ENTER key and choose other options.

7.3 Diagnostic tests

Use the diagnostics option to test for correct operation of the following components:

- Distributor ([section 7.3.1](#))
- Keypad ([section 7.3.2](#))
- Display ([section 7.3.3](#))
- Liquid sensor ([section 7.3.4](#))

An overview of the available diagnostic tests is shown in [Table 2 on page 39](#).

7.3.1 Distributor diagnostic



Use the distributor diagnostic to check for proper operation of the distributor. The test moves the distributor arm to all 24 bottle positions regardless of the number of bottles that are specified in the program.

Note: The distributor diagnostic is only active when the sample program is configured for multiple bottles.

Procedure:

1. Select **DIAGNOSTICS>DISTRIB DIAG** from the main menu. The distributor arm will begin moving to all positions.
2. The display will show **ARM MOVING** and then return to the diagnostics menu when the test is complete.

If the arm is not connected or is not able to move to all positions, the message “arm faulty” will be shown. Review [section 3.3.3.5 on page 28](#) and [section 6.4 on page 74](#) to make sure the distributor and arm are set up properly.

7.3.2 Keypad diagnostic



Use the keypad diagnostic to make sure each key on the keypad is operating correctly.

Procedure:

1. Select **DIAGNOSTICS>KEYPAD DIAG** from the main menu.
2. Press each key on the keypad (except the **BACK** key). The display should show the name of the key that was pressed.
3. To exit the test, press **BACK** key.

7.3.3 LCD diagnostic



Use the LCD diagnostic to make sure the controller display is operating correctly.

Procedure:

1. Select **DIAGNOSTICS>LCD DIAG** from the main menu to begin the test.
2. Observe the display. Each row will show SD900 and then each pixel will darken. When complete, the display will briefly show “test complete”.

7.3.4 Liquid sensor diagnostic



Use the liquid sensor diagnostic to show the current calibration information for the liquid sensor.

Procedure:

1. Select **DIAGNOSTICS>LIQ SENSE DIAG** from the main menu.
2. The display will show the input frequency (MHz), the output voltage (VDC) and the signal to noise ratio for the current calibration.

Section 8 Replacement Parts and Accessories

8.1 Bottle kits

Description	Catalog number
Single bottle kits (include full bottle shut off):	
10-L (2.5-gal) glass bottle and full bottle shut off (for standard base)	PS010025
10-L (2.5-gal) poly bottle and full bottle shut off (for standard base)	PS010030
10-L (2.5-gal) glass bottle and full bottle shut off (for compact base)	PC010025
10-L (2.5-gal) poly bottle and full bottle shut off (for compact base)	PC010030
15-L (4.0-gal) poly bottle and full bottle shut off (for standard base)	PS010040
21-L (5.5-gal) poly bottle and full bottle shut off (for standard base)	PS010055
Multi-bottle kits (include retainer and distributor arm):	
(24) 350-mL glass bottles, retainer and distributor arm (for standard base)	PS240350
(24) 575-mL poly bottles, retainer and distributor arm (for compact base)	PC240575
(24) 1-L poly bottles, retainer and distributor arm (for standard base)	PS241000

8.2 Containers and bottle sets

Description	Catalog number
Container, 10-L (2.5-gal) glass with cap	6559
Container, 10-L (2.5-gal) poly with cap	1918
Container, 15-L (4-gal) poly with cap	1367
Container, 21-L (5.5-gal) poly with cap	6498
Container, 20-L (5.25 -gal) poly with cap	6494
Bottle set, (24) 1-L poly with caps	737
Bottle set, (24) 350-mL glass with caps	732
Bottle set, (24) 575-mL poly with caps	1369
Bottle set, (8) 2.3-L (0.6-gal) poly with caps	657
Bottle set, (8) 1.9-L (0.5-gal) glass with caps	1118
Bottle set, (8) 950-mL glass with caps	2348
Bottle set, (4) 3.8-L (1-gal) poly with caps	2217
Bottle set, (4) 3.8-L (1-gal) glass with caps	2216
Bottle set, (2) 3.8-L (1-gal) poly with caps	2215
Bottle set, (2) 3.8-L (1-gal) glass with caps	2214

8.3 Replacement parts

Description	Catalog number
Desiccant, refill, 1.5 pounds	8755500
Desiccant cap assembly	8754900
Desiccant tube	8742100
Desiccant tube assembly	8741500
Desiccant tube assembly with grease packet	8755600
Grease, silicone, 7 grams (0.25 oz)	000298HY
Pump assembly replacement	6262000
Pump Cover/Door Assembly	8755400

Replacement Parts and Accessories

8.3 Replacement parts (continued)

Description	Catalog number
Tubing for Distributor Arm, 16¼-inch, for assembly 8584 (arm 8585)	8579
Tubing for Distributor Arm, 17-inch, for assembly 8580 (arm 8581)	8577
Tubing for Distributor Arm, 18¾-inch, for assembly 8582 (arm 8583)	8578
Tubing for Peristaltic Pump, pre-cut for portable sampler	8753800
Tubing for Peristaltic Pump, 15 ft	4600-15
Tubing for Peristaltic Pump, 50 ft	4600-50
Tubing, Teflon-lined intake ¾-in., 10 ft	921
Tubing, Teflon-lined intake ¾-in., 25 ft	922
Tubing, Teflon-lined intake ¾-in., 100 ft	925
Tubing, vinyl intake ¾-in., 25 ft	920
Tubing, vinyl intake ¾-in., 100 ft	923
Tubing, vinyl intake, ¾-in., 500 ft	924
Tubing Connection Kit, for Teflon-lined PE tubing	2186

8.4 Accessories

Description	Catalog number
3-way Splitter Assembly	939
AC Back up, 16 in. cable	8757400
AC Back up, 28 in. cable	5698200
Battery, gel electrolyte (lead acid), with 3 pin connector, 12 VDC	8754400
Battery Charger, gel electrolyte, with 3 pin connector, 90–250 VAC	8753500US
Base, standard assembly	8976
Base, compact assembly	8975
Base, 5.5-gal. poly container	8561
Cable, Hydrolab DS5/MS5 SDI-12, 50 ft	8762400
Cable, Hydrolab DS5/MS5 SDI-12, 100 ft	8762500
Cable, multi-purpose full, 7 pin, 10 ft	8757100
Cable, multi-purpose full, 7 pin, 25 ft	8757000
Cable, multi-purpose half, 7 pin, 10 ft	8756900
Cable, multi-purpose half, 7 pin, 25 ft	8756800
Cable for Cascade Sampling, 7 pin, 25 ft	8757300
Cable for 980 instrument, half, 7 pin, 10 ft	8758100
Cable for 980 instrument, half, 7 pin, 25 ft	8757200
Cable, battery adaptor (2 to 3 pin)	8739400
Cable, auxiliary adaptor (6 to 7 pin)	8758000
Cable, serial (DB9 to 7 pin), 3 meters	8758200
Distributor Assembly with Arm, 24 bottle, compact base	8580
Distributor Assembly with Arm, 24 bottle standard base	8582
Distributor Assembly with Arm, 2, 4, and 8 bottle base and 8 bottle compact base	8584
Distributor Arm for Assembly 8580	8581
Distributor Arm for Assembly 8582	8583
Distributor Arm for Assembly 8584	8585

8.4 Accessories (continued)

Description	Catalog number
Flow-thru Module	2471
Full Bottle Shut-off	8996
Manhole Spanner Bar, 18–28 inches	9542
Manhole Spanner Bar, 28–48 inches	9557
Manhole Support Bracket, 18–27 inches	5713000
Power Supply, 3 pin connector, 100–120 VAC	8754500US
Retainer, (8), (24) poly/glass bottles	1422
Retainer, (24) 350 mL glass bottles	2189
Retainer, (8) 950-mL glass bottles	2347
Retainer, 1-gal. glass/poly bottles	2190
Retrofit Kit, SD900 controller assembly for portable samplers (includes controller, pump tube, manual)	8759400
Sampler Locking Assembly	1354
SampleView CD with RS-232 Cable	8757500
SDI-12 (factory install option)	87390SD
Strainer, all 316 stainless steel, 6.0 in. long x 0.406 in. OD	2071
Strainer, all 316 stainless steel, 7.94 in. long, x 1.0 in. OD	2070
Strainer, stainless steel, 3.9 in. long x 0.406 in. OD	4652
Strainer, Teflon®/stainless steel, 5.5 in. long x 0.875 in. OD	926
Strainer, Teflon/stainless steel, 11.0 in. long x 0.875 in. OD	903
Support, container, for standard base, 2.5 gal. glass and 3 gal. poly	1502
Suspension Harness	1355
Universal Junction Box (4-20mA input)	8760600

Section 9 Contact information

**United States:
Hach Company**
P.O. Box 389
Loveland, Colorado
80539-0389 U.S.A.
Tel 800-635-4567
Fax (970) 461-3919
orders@hach.com
www.hach.com

**Repair Service in the
United States:
Authorization must be
obtained before sending
any items for repair.**
HACH Company
Tel (800) 635-1230
or (970) 669-3050
Fax (970) 461-3924
techhelp@hach.com

**Canada, Latin America,
sub-Saharan Africa, Asia,
Australia and New Zealand:**
Hach Company World
Headquarters,
P.O. Box 389
Loveland, Colorado,
80539-0389 U.S.A.
Tel (970) 669-3050
Fax (970) 461-3939
intl@hach.com

**Europe, Middle East and
Mediterranean Africa:
Hach Lange GMBH**
Willstätterstraße 11
D-40549 Düsseldorf
Tel. +49 (0)2 11 52 88-320
Fax +49 (0)2 11 52 88-210
info@hach-lange.de
www.hach-lange.de

Hach Lange EU subsidiaries:

HACH LANGE LTD
Pacific Way
Salford
GB-Manchester, M50 1DL
Tel. +44 (0)161 872 14 87
Fax +44 (0)161 848 73 24
info@hach-lange.co.uk
www.hach-lange.co.uk

HACH LANGE LTD
Unit 1, Chestnut Road
Western Industrial Estate
IRL-Dublin 12
Tel. +353(0)1 46 02 5 22
Fax +353(0)1 4 50 93 37
info@hach-lange.ie
www.hach-lange.ie

**DR. BRUNO LANGE
GES. MBH**
Industriestraße 12
A-3200 Obergrafendorf
Tel. +43 (0)27 47 74 12
Fax +43 (0)27 47 42 18
info@hach-lange.at
www.hach-lange.at

**DR. LANGE NEDERLAND
B.V.**
Laan van Westroijen 2a
NL-4003 AZ Tiel
Tel. +31(0)344 63 11 30
Fax +31(0)344 63 11 50
info@hach-lange.nl
www.hach-lange.nl

DR. BRUNO LANGE AG
Juchstrasse 1
CH-8604 Hegnau
Tel. +41(0)44 9 45 66 10
Fax +41(0)44 9 45 66 76
info@hach-lange.ch
www.hach-lange.ch

**HACH LANGE FRANCE
S.A.S.**
33, Rue du Ballon
F-93165 Noisy Le Grand
Tél. +33 (0)1 48 15 68 70
Fax +33 (0)1 48 15 80 00
info@hach-lange.fr
www.hach-lange.fr

HACH LANGE SA
Motstraat 54
B-2800 Mechelen
Tél. +32 (0)15 42 35 00
Fax +32 (0)15 41 61 20
info@hach-lange.be
www.hach-lange.be

HACH LANGE E.P.E.
27, Avlidos str
GR-115 27 Athens
Tel. +30 210 7777038
Fax +30 210 7777976
info@hach-lange.gr
www.hach-lange.gr

HACH LANGE APS
Åkandevej 21
DK-2700 Brønshøj
Tel. +45 36 77 29 11
Fax +45 36 77 49 11
info@hach-lange.dk
www.hach-lange.dk

HACH LANGE AB
Vinthundsvägen 159A
SE-128 62 Sköndal
Tel. +46 (0)8 7 98 05 00
Fax +46 (0)8 7 98 05 30
info@hach-lange.se
www.hach-lange.se

HACH LANGE S.R.L.
Via Riccione, 14
I-20156 Milano
Tel. +39 02 39 23 14-1
Fax +39 02 39 23 14-39
info@hach-lange.it
www.hach-lange.it

HACH LANGE S.L.U.
Edif. Arteaga Centrum
C/Larrauri, 1C- 2ª Pl.
E-48160 Derio/Vizcaya
Tel. +34 94 657 33 88
Fax +34 94 657 33 97
info@hach-lange.es
www.hach-lange.es

HACH LANGE LDA
Av. do Forte nº8
Fracção M
P-2790-072 Carnaxide
Tel. +351 214 253 420
Fax +351 214 253 429
info@hach-lange.pt
www.hach-lange.pt

HACH LANGE SP.ZO.O.
ul. Opolska 143 a
PL-52-013 Wrocław
Tel. +48 (0)71 342 10-83
Fax +48 (0)71 342 10-79
info@hach-lange.pl
www.hach-lange.pl

HACH LANGE S.R.O.
Lešanská 2a/1176
CZ-141 00 Praha 4
Tel. +420 272 12 45 45
Fax +420 272 12 45 46
info@hach-lange.cz
www.hach-lange.cz

HACH LANGE S.R.O.
Roľnícka 21
SK-831 07 Bratislava –
Vajnory
Tel. +421 (0)2 4820 9091
Fax +421 (0)2 4820 9093
info@hach-lange.sk
www.hach-lange.sk

HACH LANGE KFT.
Hegyalja u. 7-13.
H-1016 Budapest
Tel. +36 (06)1 225 7783
Fax +36 (06)1 225 7784
info@hach-lange.hu
www.hach-lange.hu

HACH LANGE S.R.L.
Str. Leonida, nr. 13
Sector 2
RO-020555 Bucuresti
Tel. +40 (0) 21 201 92 43
Fax +40 (0) 21 201 92 43
info@hach-lange.ro
www.hach-lange.ro

HACH LANGE
8, Kr. Sarafov str.
BG-1164 Sofia
Tel. +359 (0)2 963 44 54
Fax +359 (0)2 866 04 47
info@hach-lange.bg
www.hach-lange.bg

**HACH LANGE SU
ANALİZ SİSTEMLERİ
LTD.ŞTİ.**
Hilal Mah. 75. Sokak
Arman Plaza No: 9/A
TR-06550 Çankaya/ANKARA
Tel. +90 (0)312 440 98 98
Fax +90 (0)312 442 11 01
bilgi@hach-lange.com.tr
www.hach-lange.com.tr

HACH LANGE D.O.O.
Fajfarjeva 15
SI-1230 Domžale
Tel. +386 (0)59 051 000
Fax +386 (0)59 051 010
info@hach-lange.si
www.hach-lange.si

HACH LANGE E.Π.E.
Αυλιός 27
GR-115 27 Αθήνα
Τηλ. +30 210 7777038
Fax +30 210 7777976
info@hach-lange.gr
www.hach-lange.gr

Appendix A Wiring for non-Sigma flow meters

CAUTION

Only qualified personnel should conduct the tasks described in this section of the manual.

Prerequisites:

- Multi-purpose half cable
- Auxiliary adapter cable (6-pin to 7-pin adapter)
- Optional splitter ([Figure 15 on page 33](#)) to provide additional connections. Two or more splitters may be connected in series.

See [Accessories on page 84](#) for ordering information.

Procedure:

Use the auxiliary connector diagram in [Figure 31](#) and wiring information in [Table 9](#) to wire the flow meter to the controller.




Figure 31 Auxiliary connector (7-pin)

Table 9 Half-cable wiring information for non-Sigma flow meters

Pin	Signal description	Wire color ¹	Purpose	Rating
A	12 VDC power output	White	Power supply positive output. Powers an external device or flow meter. Must be used in conjunction with pin B (common).	This output is protected by a thermal current limiter. 12 VDC nominal output at 1 A maximum when using battery 8754400 to power the sampler. 15 VDC regulated output at 0.5 A maximum when using AC power to power the sampler.
B	Common	Blue	Power supply negative return. When using AC power, this pin is connected to earth ground.	

Wiring for non-Sigma flow meters

Table 9 Half-cable wiring information for non-Sigma flow meters (continued)

Pin	Signal description	Wire color ¹	Purpose	Rating
C	Pulse/Current input	Orange	<p>This input triggers sample collection. The signal may be generated by:</p> <ul style="list-style-type: none"> An external flow meter or other device with an appropriate pulse or 4-20mA control output. Simple floating (dry) contact closure. An external flow meter or other device with a 4-20mA control output. <p>(For information on flow pacing, see instruction sheet supplied with 4-20 mA input.)</p>	<p>In pulse mode, this input responds to a positive pulse with respect to Common (pin B). It is terminated (pulled low) to Common (pin B) through a series 1 kΩ resistor and 7.5 V zener diode. In current mode, the input responds to current entering pin C and returning on pin B (common). The input burden is 100 ohms plus 0.4V. The maximum input current is internally limited at 40 - 50 mA, but long term operation in this state constitutes abuse and is not warranted.</p> <p>Absolute maximum input: 0 to 15 VDC with respect to Common (pin B). Signal required to activate input: 5–15 V positive going pulse with respect to common (pin B) of at least 50 millisecond duration. Source impedance of driving signal should be less than 5 kΩ.</p> <p>Dry contact (switch) closure of at least 50 millisecond duration between pin A (12 VDC) and pin C (Pulse Input). Contact resistance should be less than 5 kΩ. Contact current will be less than 8 mA DC.</p>
D	Liquid level actuator/auxiliary control input	Black	<p>This input sends a signal to the microprocessor inside the sampler causing it to "wake up" and begin or resume its sampling program. Applications for this input include:</p> <p>A simple float level switch (dry contacts) may be used to actuate the sampler when liquid is present.</p> <p>Start this sampler after another sampler has finished its program.</p> <p>Start the sampler in response to some user-defined condition from an external device that provides an appropriate control signal. For example a pH meter could be used to initiate sampling in response to a high or low pH condition.</p>	<p>This input is terminated (pulled high) to an internal +5 V supply through an 11 kΩ resistance and protected by a series 1 kΩ resistor and 7.5 V zener diode terminated to Common (pin B). The input responds to a high to low voltage transition with a logic low pulse width of at least 50 milliseconds.</p> <p>Absolute maximum input: 0 to 15 VDC with respect to Common (pin B). Signal required to activate input: External logic signal having 5-15 VDC power source. The drive signal should be normally high. The external driver should be capable of sinking 0.5 mA @ 1 VDC maximum at the logic low level.</p> <p>A logic high signal from a driver with power source of greater than 7.5 V will source current into this input at the rate of: $I = (V - 7.5)/1000$ where:</p> <p>I is the source current</p> <p>V is the power supply voltage of the driving logic.</p> <p>Dry contact (switch) closure of at least 50 millisecond duration between pin D and pin B (common). Contact resistance should be less than 2 kΩ. Contact current will be less than 0.5 mA DC.</p>
E	Event output	Red	<p>Normally at 0 VDC, this line goes to +12 VDC upon any of the selected events described in section 5.3.2 on page 60.</p>	<p>This output is thermally protected against short circuit currents to common (pin B). Limit external load current to 0.2 A.</p> <p>The output is normally logic low (0 VDC) with respect to common (pin B). Active high output levels are:</p> <p>15 VDC nominal when using AC power to power the sampler</p> <p>12 VDC nominal when using battery 8754400 to power the sampler.</p>

Table 9 Half-cable wiring information for non-Sigma flow meters (continued)

Pin	Signal description	Wire color ¹	Purpose	Rating
F	Program complete output	Green	Normally an open circuit, this line switches to ground for 90 seconds at the conclusion of the sampling program. Used to “wake up” another sampler to take over sampling or to signal an operator or data logger upon the completion of the sampling program. This pin is also used to signal the bottle full condition in a single bottle/continuous mode, and will transmit the bottle number to a flow meter if the program complete signal is disabled.	This is an open collector output with 18 V zener clamp diode for overvoltage protection. The output is active low with respect to common (pin B). Absolute maximum ratings for output transistor: Sink current = 25 mA DC maximum. External pull-up voltage = 18 VDC maximum.
G	Shield	N/A	Provides connection to earth ground when the sampler is powered using AC power. This connection is only intended for use in controlling RF emissions and susceptibility.	Not intended for use as safety ground. Do not use as a current carrying conductor. Cables greater than 3 meters length connected to the sampler auxiliary port should be shielded. Regardless of length, if a shielded cable is connected to the auxiliary port, the shield (drain) wire should only be connected to earth ground at one end of the cable to avoid ground loop currents.

¹ Wire color refers to the colors of multi-purpose cables Cat. No. 8756800 and 8756900.

Appendix B SDI-12 Configuration for a Hydrolab Sonde

Prerequisites:

- SDI-12 compatible sonde
- Power adapter (Mains/Battery. Power adapter not required if sonde is powered by Internal Battery Pack.)
- External power adapter cable (not required if sonde is powered by Internal Battery Pack).
- Detachable cable (Cat. no. 13470HY/015XXX)
- HYDRAS 3LT software tool installed in PC
- PC

Refer to [Figure 32](#) for when configuring the power supply setup.

Setup for sonde powered by IBP

If your sonde is internally powered by an IBP (Internal Battery Pack), connect the 9-pin end of the detachable cable to one of the COM ports available in the PC. Connect the other end of the detachable cable (6-pin connector) to the bulkhead connector. Follow the SDI-12 configuration instructions (see [SDI-12 Configuration on page 94](#)).

Setup for sonde with external power source

Connect the power adapter to the power source (AC main or external battery) and connect the other end to the external power adapter cable. Connect one end of the external power adapter cable to one of the COM ports in the PC and the other end to the detachable cable. Connect the 6-pin connector to the bulk head connector of the sonde. Follow the instructions given for configuring the SDI-12 (see [SDI-12 Configuration on page 94](#)).




Figure 32 Setup for sonde with external power source

1	To power source (if applicable)	4	Sonde bulkhead connector
2	9-pin connector	5	6-pin connector
3 Cable configuration may vary depending on application. Refer to Hydrolab DS5X, DS5, and MS5 Water Quality Multiprobes User Manual (Cat. No. 003078HY).			

SDI-12 Configuration for a Hydrolab Sonde

9.0.1 SDI-12 Configuration

Once the sonde is connected to one of the COM ports in the PC, go to START MENU>ALL PROGRAMS>HYDRAS3 LT in the PC. This will start the Hydras3 LT software as shown in [Figure 33](#).




Figure 33 Hydras3 LT Window

Upon starting, the HYDRAS3 LT software scans the available COM ports in the PC. If a sonde is detected, this information will be displayed in the Connected Sondes tab of the HYDRAS3 LT window.

If your sonde is not listed in the Connected Sondes tab, check the connection to the power supply and the connection to the COM port.

Make sure the connected sonde is highlighted in the Connected Sondes window, and click the Operate Sonde button ([Figure 33](#)). A popup configuration window will appear ([Figure 34](#)).




Figure 34 Hydras3 LT configuration window

Click on the settings tab to configure the sonde SDI-12 interface (Figure 35).




Figure 35 Settings tab

Click on the Enabled checkbox in the communication window of the settings tab. This enables the SDI-12 interface.

Select the address from the valid range for the sonde, as shown in [Figure 36](#). The valid address range is from 0 - 9.




Figure 36 Address configuration

Click on the Define SDI Parameter Order button to configure the order of available parameters for the SDI-12 interface. This will open Define SDI Parameter Order window (Figure 37), showing the total available parameters in the left pane. The right pane displays the selected parameter and its order position.

You can define your own parameter list from the available parameter set and change the order using the up and down button near the right pane. After completing the parameter selection and setting the parameter order, click the OK button.




Figure 37 Define SDI Parameter Order




Figure 38 Save Settings

In the settings tab, click on Save Settings to save the settings and close the Hydras3 LT software (Figure 35). This completes the configuration of the sonde for the SDI-12 interface.

A			
AC power			
installation	32		
accessories	83		
advanced sampling			
menu overview	59		
operate from external signal	61		
output signal	60		
stormwater	64		
variable intervals	66		
auxiliary connector			
output signal	60		
B			
battery installation	31		
bottles			
bottle no. 1 position	23		
cleaning	21		
eight bottle installation	25		
four bottle installation	24		
list of	83		
setting the number of	42		
twenty four-bottle installation	26		
two bottle installation	24		
bottles per sample	42		
C			
calibration			
liquid sensor	53		
manual calibration	51		
sample volume	49		
cascade sampling	60		
cleaning			
bottles	21		
pump rotor	72		
communication			
serial connector	33		
containers. See bottles			
D			
data			
event log	48		
sample history	47		
viewing	45		
default settings	43		
desiccant			
replacement	74		
diagnostic tests	80		
distributor			
arm tube replacement	74		
diagnostic test	80		
installing	28		
manual operation of	45		
E			
error messages	78		
event log	48		
F			
flow meter			
installation	33		
trigger sampler operation with	61		
full bottle shut-off installation	22		
G			
grab samples	44, 52		
I			
ice for sample preservation	22		
intake tubing			
installing	29		
specifying type and length	42		
K			
keypad	37		
L			
LED indicator	37		
liquid sensor			
calibration of	53		
diagnostic test	81		
volume determination with	49		
M			
maintenance			
desiccant replacement	74		
distributor tube replacement	74		
pump rotor cleaning	72		
pump tube replacement	70		
manhole installation	21		
manual operation			
distributor	45		
grab samples	44		
pump	45		
O			
output signal			
at each sample cycle	60		
at program completion	60		
P			
password	53		
preserving samples	22		
presets	43		

Index

- pump
 - cleaning the rotor 72
 - manual operation of 45
 - tube installation 71
 - tube replacement 70
- R**
- rotor 72
- S**
- safety
 - confined space precautions 14
 - general information 13
- sample history 47
- sample program
 - basic menu overview 39
 - bottle number 42
 - cascade sampling 60
 - default settings 43
 - history 47
 - intake tubing 42
 - multiple start/stop times 61, 64
 - reviewing 42
 - starting or stopping 44
 - status 45
- sampler
 - components 15
 - manhole installation 21
 - mounting 19
 - replacement parts 83
- sampler setup
 - eight bottles 25
 - twenty four bottles 26
 - two or four bottles 24
- samples per bottle 42
- SD900 controller
 - advanced software overview 59
 - diagnostic tests 80
 - keypad 37
 - passwords 53
 - software overview 39
 - turning on or off 37
- SDI-12 55
- sdi-12 55
- serial connector
 - pin assignments 33
- setpoint sampling 61
- sonde configuring 93
- spanner bar 21
- stormwater sampling
 - first flush samples 64
 - menu overview 59
- T**
- templates. See presets
- timed bottle 66
- troubleshooting
 - diagnostic tests 80
 - table 77
- tubing replacement reminder 54
- tubing, distributor 74
- tubing, intake
 - installing 29
- tubing, pump
 - installation 71
 - replacement 70
 - tubing life 69
- V**
- variable intervals 66
- volume
 - bottle 41
 - calibration 49
 - manual calibration 51
 - verify sample volume 52