

AGES
14+

nano

drone for beginners



SAFETY GUIDE OF LITHIUM BATTERY



By operating this device you acknowledge and accept all risks and responsibilities of the use, storage and proper disposal of any and all included lithium batteries.

Warning You agree to follow the safety precautions outlined below in addition to any and all state, local or federal laws regarding lithium batteries.

Axis Drones and its affiliates are not responsible for any misuse.

Please read and understand the following regarding the usage of Lithium batteries.

Guarantee of the lithium battery:

The Lithium battery included with your device is guaranteed to be free from any manufacturing defects prior to initial use. Once the device has been used, owner accepts any and all liability for the Lithium battery, maintenance and disposal.

Lithium Battery Warnings:

- Through the use of the included Lithium battery, you have assumed all risk and responsibility regarding a Lithium battery and its use.
- **ALWAYS** unplug your battery from the charger immediately upon full charge.
- Do not attempt to charge your battery if it becomes swollen or hot.
- It's best to store your batteries charged and at room temperature. Storing a fully discharged battery may cause irreversible damage to the battery.
- Never disassemble, puncture or modify the battery pack in any way.
- Never allow the battery temperature to exceed 150° F [65° C].
- If your battery begins to swell or "puff" during charge or discharge, or becomes damaged in any way, stop using it and contact Axis Drones at 800-610-0605 to learn the proper way to dispose of your battery.

Charge Warnings:

- Only use the included charger with the included Lithium battery.
- Do not leave the charger unattended while in use, and always charge your battery in a fire-resistant location.
- Disconnect the battery and remove input power from the charger immediately if either become hot.
- Do not allow water or other foreign objects to enter the charger. Keep the charger away from moisture and do not submerge in water.
- Please keep all electronic components out of the reach of children.

WHAT'S IN THE BOX

Nano Drone




USB Charging Cable



Spare Blades



REMOTE CONTROL



No	Function switch	Function description
1	Trimmer A	Fine tuning of forward and backward movement
2	Left stick	Throttle - Rotation - Speed Selection
3	Power Indicator	Slow Blink: Not Transmitting Fast Blink: Attempting to pair Solid: Paired and Operational
4	Power switch	Right: OFF Left: ON
5	Right stick	Directional Movement - Trick Mode
6	Trimmer B	Fine tuning of left and right movement

ENVIRONMENT FOR FLIGHT

Please be aware of all surroundings when operating the Axis Nano Drone.




Note

- DO NOT FLY NEAR PEOPLE, ANIMALS OR PROPERTY
- Adult supervision is recommended for users under 18
- Indoor flight should have plenty of open space
- Damage to property or injury to people is a risk, fly safely.


ATTENTION

- Always keep the Axis Nano Drone in your line of sight
- If device travels too far away from user it may lose control
- When flying outdoors please do not operate in med-high wind
- Always make sure your Axis Nano is fully charged before flight
- Replace remote control batteries before they become too weak
- Avoid colliding with people, property or animals

Releasing throttle at high altitude may result in injury or damage to device, people or property.



Always keep device at a safe distance from the ground and other objects.





Please DO NOT fly in areas with many obstacles or around objects that can be easily damaged.



INSTALLING BATTERIES IN CONTROLLER


■ Battery install

Please load the batteries with the correct polarity, as shown below:



CHARGING DRONE

- Connect charging cable to the drone FIRST, then plug the USB side in.
- It is recommended to charge with a computer USB port, not a wall adapter.
- The red light will be OFF while charging and ON when fully charged.
- Promptly remove the cable from both the USB and drone upon full charge.
- DO NOT LEAVE drone unattended while charging.



GETTING STARTED



(Figure 1)



(Figure 2)





(Figure 3)

1. Place the Axis Nano Drone on a flat LEVEL surface and turn power on
2. Align joysticks as shown in (Figure 1), Left stick down, right stick center
3. Turn the controller on by sliding the power switch to the left
4. Power Indicator light will begin flashing, indicating it is ready to pair
5. Move left joystick FULLY UP (Figure 2) then FULLY DOWN (Figure 3)
6. Lights on both the Axis Nano Drone and the Controller will remain solid
7. Your Axis Nano Drone and Controller are now paired and ready for flight!


OPERATION AND CONTROL

The throttle on the Axis Nano will take some practice to achieve a good hover. We recommend using your thumb and index finger to make small adjustments to the throttle stick; you can progress to just your thumb with experience. The Axis Nano will start out in LOW Speed, please start here to get acquainted.



Moving Left Stick Up/Down controls the Rise/Fall of the Axis Nano Drone



Moving Left Stick Left/Right controls the Yaw (Rotation) to adjust orientation



Moving Right Stick Up/Down controls Forward and Reverse Flight Direction



Moving Right Stick Left/Right controls Left and Right Flight Direction



TRIMMER

Backward trimmer	Drift Forward 	Trim Backward 	 Backward trimmer
Forward trimmer	Drift Backward 	Trim Forward 	 Forward trimmer
Left Flying trimmer	Drift Right 	Trim Left 	 Left Flying trimmer
Right Flying trimmer	Drift Left 	Trim Right 	 Right Flying trimmer

When you first take off you should attempt to level the Axis Nano into a hover.

Begin with the drone in front of you with the bow of the drone facing forward.

Take off and begin to maintain a steady height around 3 feet off the ground.

If the Axis Nano drifts in any one direction you can use the Trimmer Tabs to make precision adjustments to the motors in order to keep the drone centered.

For Example: If the Axis Nano drifts toward you (reverse) press Trimmer A UP one click at a time until it stays steady, if it drifts away (forward) press DOWN.

Each click is one adjustment, you can click in the opposite direction until you hear a LONG BEEP, that indicates you are back at the center setting.


The same is true if it drifts Left, you would press Trimmer B RIGHT and if it drifts Right, you would adjust the Trim LEFT until it stays centered.

This is important if you want to have precision flight with takeoff and landing.

If you just want to fly around and have fun, it may not matter if it drifts a little.

SPEED SETTINGS

There are 3 unique speed settings programmed into the Axis Nano. To change speeds at any time simply press the Left Stick IN (Figure 1) Pressing multiple times allows you to cycle through all of the speeds. Each speed is indicated by a corresponding number of beeps.



(Figure 1)

Low Speed:

This is the Default speed every time you power up, indicated by a single beep. Low speed is designed for practicing take-off, trimming, rotation and landing. It does not provide much directional movement.

Medium Speed:


Indicated by two beeps. Medium speed is twice as fast as low speed and is designed to practice take-off, trimming, rotation, landing and slow directional movement.

High Speed:

Indicated by three beeps. High speed provides full flight function, designed to be stable, precise and perfect for beginners. While not as fast as other models' high speed it will still provide hours of fun!

FLIPS AND ROLLS


The Axis Nano is pre-programmed with an algorithm to perform flips and rolls with ease, simply press the Right Joystick IN (Figure 2) to enter "Trick Mode" Once in "Trick Mode" - indicated by beeping, simply push the Right Stick fully in the direction you want to flip or roll! (SEE NEXT PAGE)



(Figure 2)

FRONT FLIP

Press Right Stick IN, Controller will beep, Push Right Stick FULL UP



BACK FLIP

Press Right Stick IN, Controller will beep, Push Right Stick FULL DOWN




ROLL LEFT

Press Right Stick IN, Controller will beep, Push Right Stick FULL LEFT



ROLL RIGHT

Press Right Stick IN, Controller will beep, Push Right Stick FULL RIGHT



TROUBLESHOOTING

In the event you have issues with your Axis Nano please check here:

Drone won't lift off of ground:

1. Check the orientation of your blades to match (Figure 1) below
2. Make sure your drone and remote batteries are fully charged
3. Check that blades are not bent or damaged, replace as needed

Drone drifts heavily in one direction:

1. Make sure your Trimmer settings are at CENTER (page 6)
2. Make sure all blades are evenly and fully seated on driveshafts
3. Restart and Pair Drone and Controller (page 4)
4. If 1-3 did not solve please recalibrate your drone (page 10)
5. If 1-4 did not work you are in a hurricane, seek shelter

Controller and Drone won't connect:

1. Replace the batteries in the controller with BRAND NEW ones
2. Fully charge the drone and try again (page 4)

Drone won't hover, keeps going up and down:

1. Use thumb and index finger on throttle to make smaller adjustments
2. Check that blades are not damaged or on incorrectly
2. Drink less coffee, take yoga, breathe and relax :)

One or more lights/motors stopped working:

1. You broke it dude, give us a shout for a discount on your next one!

CHANGING BLADES

- To remove blades, firmly grasp the center of the blade and pull UP.
- To replace blades, firmly press the new blade DOWN onto shaft.
- Orientation of blades should be as shown below when viewing drone from rear to front AND from front to rear:



RECALIBRATION OF ACCELEROMETER

If your Axis Drone begins to be unstable during flight, drifts heavily in one direction or troubleshooting doesn't work please do the following:

1. Turn off Drone and Controller
2. Make sure that all batteries are fully charged
3. Place Drone on flat LEVEL surface
4. Turn Drone on
5. Turn Controller on
7. Push the Throttle (Left Stick) to Lower Left, HOLD
8. Push Control (Right Stick) to Lower Left, HOLD



9. Drone lights will turn solid, indicating success.


POWER FAILURE FROM CRASH

If your Axis Nano crashes, becomes entangled or blades jam, it should automatically shut itself off to prevent further damage or danger.

If battery is fully charged, you should be able to turn the power switch off and then back on and repeat the pair cycle (page 4).

If the drone fails to turn back on, please turn it off and fully charge. Be sure to watch the drone after a bad crash to make sure the battery does not overheat while charging; if it does, please dispose of it.

Exploded View



Number	Part Name	Quantity	Number	Part Name	Quantity
1	Blade B	2	6	Circuit Board - Receiver	1
2	Blade A	2	7	Lithium Battery	1
3	Upper Housing - Blade Guard	1	8	Lower Housing	1
4	Motor (counterclockwise)	2	9	Screw	4
5	Motor (clockwise)	2	10	Landing Skid - Motor Guard	1