



Clearing the Fastest Lap and Preparing the Performance Monitor for a Different Circuit

Turn On ignition with any button held pressed. The display will change to:




Release the button and the display will change to show your fastest lap (Fastest Time of the Day):



The display will then change to:



As soon as this display appears, press any button and the display will change to:



Now you have successfully cleared the fastest lap and told the system to clear the performance monitor memory. **DO NOT trigger false laps with the beacon before going out on your first lap of a new circuit.**

You should do this every time you start a session at a different track.

To Clear the Lap Number


Press both top buttons for 3 seconds.

To Clear the Elapsed Time

Press both bottom buttons for 3 seconds.


Displaying Your Fastest Lap

Use the top or bottom right hand buttons to scroll the Gauge window beyond Oil Pressure so that the display shows:



Recalling Your Lap Times

Enter Recall Mode by pressing both right hand buttons together. The display changes to:



Showing the last lap was lap 14 with a lap time of 1:26.04. Use the right hand buttons to select the maximum temperatures and minimum pressures in this lap. Here the minimum oil pressure was 68 psi.

Use the left hand buttons to scroll backwards and forwards through the lap time memory.

Press both right hand buttons again to exit Recall Mode.

To Enter Set Up Mode

Press both left hand buttons together and the display changes to:



And then to:



The left hand buttons select the item to be set up and the right hand buttons change the setting of the item.

Press both left hand buttons again to exit Set Up Mode.



The SWIS20 Steering Wheel Instrument System Operating Manual



Contents

1. Introduction
2. The Buttons and Display Windows
 - 2.1 The Buttons
 - 2.2 The Display Windows
 - 2.2.1 The Gear Window
 - 2.2.2 The Laps Window
 - 2.2.3 The Lap Time Window
 - 2.2.3.1 The Performance Monitor Option
 - 2.2.4 The Speed Window
 - 2.2.5 The Elapsed Time Window
 - 2.2.6 The Gauge Window
3. Set Up Mode
 - 3.1 General
 - 3.2 Function 0 Tachometer and Other Displays
 - 3.3 Function 1 Set Defaults
 - 3.4 Function 2 Session Number
 - 3.5 Function 3 Hold Time
 - 3.6 Function 4 Blank Time
 - 3.7 Function 5 Infra Red Channel Number
 - 3.8 Function 6 "IN" Channel
 - 3.9 Function 7 Performance Monitor Display
 - 3.10 Function 8 Display Performance in Elapsed Time Window
 - 3.11 Function 9 Elapsed Time Units
 - 3.12 Function 10 Number of Wheel Pulses
 - 3.13 Function 11 Wheel Circumference
 - 3.14 Function 12 Wheel Turns per Sample
 - 3.15 Function 13 Sample Period
 - 3.16 Function 14 Start Logging Trigger
 - 3.17 Function 15 Number of Tach. Pulses per Two Turns
 - 3.18 Function 16 Tacho Filter
 - 3.19 Function 17 Tacho Pulse Polarity
 - 3.20 Fuel and Other Alarm Limits
 - 3.21 Shift Light Set Up
 - 3.22 Gear Indicator Set Up
 - 3.23 Monitoring Inputs in Set Up Mode
 - 3.24 Function 33 Clear Function
4. Using the SWIS20 System
 - 4.1 Odometer
 - 4.2 Gear
 - 4.3 RPM and Shift Lights

The SWIS10-R Steering Wheel

Gear can be calculated—not very satisfactory or can come from gear position sensor.

This window always shows lap number

The Lap Time Window shows lap time, the performance monitor and warnings. You can set this to show RPM or lap time only. Using the right hand buttons, the fastest lap time, battery voltage and the user 1 channel can be displayed here.





The Speed window can display speed oil pressure, water temperature or oil temperature. If speed is not shown here normally, it can be shown by pressing the top left hand button for 3 seconds—useful for the pit lane. The original display can be restored by pressing the bottom left hand button.

The Elapsed Time is useful during qualifying or endurance races. However this window can be changed to show seconds only lap time or the performance monitor.

Use the right hand buttons to change the gauge reading in this window. Scrolling beyond Oil P gives Fastest Lap, then RPM, then Battery voltage, then the User 1 Channel before flipping back to Fuel.

8.3 Aligning The Beacon and IR Detector

The Beacon Beam diverges at 40 degrees and the IR Detector acceptance cone angle is about 15 degrees. Ensure that the IR Detector will fall within the Beacon's beam and, just as important, be sure that the acceptance cone of the IR Detector includes the Beacon when the car passes it.



Farringdon Instruments Limited Unit 9 Oriol Court, Omega Park, ALTON.
Hampshire GU34 2YT. Telephone 01420 541591 Facsimile 01420 587212.
www.farringdininstruments.co.uk

- 4.4 Speed
- 4.5 Elapsed Time
- 4.6 Oil Pressure
- 4.7 Water Temperature
- 4.8 Oil Temperature
- 4.9 Fuel
- 4.10 Battery Voltage
- 4.11 The Lap Timer
- 4.12 Recall Mode
- 4.13 Best Lap (Ftd)
- 4.14 Displaying RPM
- 4.15 The Performance Monitor Option

- 5. Data Logging
- 6. Data Analysis
- 7. Connecting Other Sensors
- 8. Beacon Settings and Siting
 - 8.1 Understanding Infra Red Communications
 - 8.2 Aligning the Beacon and Detector
 - 8.3 Beacon Conflicts

1. Introduction

Thank you for choosing the Farringdon SWIS20 Steering Wheel Instrument System. This manual will describe how to use and set up system in your car. Of course, the system will not work properly until it has been loaded with all the essential information about your car—for example the circumference of the wheel. So please take a little time to ensure that you know how to set up the system before you use it for the first time.

2. The Controls and What is Displayed

The Steering Wheel Instrument System has four buttons and six display windows. This section explains how to use the buttons and what is displayed in the windows.

2.1 The Buttons

Each side of the Instrument Cluster, there is a double membrane push button. These buttons will click when pressed and give an “over-centre” feel. They are deliberately stiff and will not respond to very short pushes. This prevents them being pressed accidentally or operated by vibration.

While driving, the left hand buttons will control the brightness of the display and the right hand buttons select the gauge that is displayed in the gauge window as follows:

Pressing the top left button increases the brightness one step. Pressing the bottom left hand button decreases the brightness one step. There are 10 steps in all.

If the LED next to the Oil P legend is lit, the oil pressure in (psi) is shown in the gauge window. Pressing the bottom right hand button causes the LED next to the Water legend to light and the water temperature (in degrees centigrade) is shown in the gauge window. Pressing the top right hand button switches the display back to Oil Pressure. In this way, the right hand buttons “scroll through” the gauges.

Pressing both top buttons for about 3 seconds clears the lap count. This is often necessary on the starting grid after passing the lap timing beacon during the parade and warm up laps.

Pressing both bottom buttons for about 3 seconds clears the elapsed time. This may be done at the start of a qualifying session or the start of an endurance race or session.

The remaining combinations are pressing both left hand buttons or both right hand buttons. After holding both left hand buttons for about 3 seconds, the set up mode is entered. (See Section 3) After holding both right hand buttons for about 3 seconds Recall Mode is entered. (See section 5.2)

8. Beacon Setting and Siting

8.1 Understanding Infra Red Communications

Infra red light (IR) from light emitting diodes (LEDs) can be turned on and off very quickly and it is this property that makes infra red ideal for short range communications. To increase the sensitivity of the receivers, a “carrier” frequency is used to turn on and off the LED. The receiver can then look for light that is being modulated at this frequency amongst other background light. To impose information on the infra red beam, this carrier frequency is itself turned on and off.

There are two ways in which this form of communication can be interrupted, first, by any light source strong enough to saturate the receiver - for example - the sun or another more powerful IR source - and second, other transmissions using the same carrier frequency.

The reason for the recessed lens and photodiode in the IR detector is to shield it from direct sunlight so providing the IR detector will not “see” the setting sun behind the beacon, it will not be saturated by the sun.

However, some other lap timer and data logging systems do use the same carrier frequency and others use much more powerful IR beams and it is for this reason that you must take care where the beacon is positioned.

8.2 Beacon Conflicts

From the explanation given in the previous section it is clear that reliable operation can only be guaranteed when the beacon is sited away from all others. A distance of 5 metres along the pit wall is probably safe. The Lap Timer will ignore all infra red signals on the same carrier frequency that do not contain the Main Channel or IN codes saved in its memory but if you find that lap times are obviously incorrect, look for another Beacon using your channel on the pit wall. With only four channels to choose from, it may be that more than four teams are using Beacons at the same track. In this case agree to use a single beacon and set all the Lap Timers to respond to this channel.

It is especially important to site the Beacon away from other beacons using large external batteries and having a large array of LEDs pointing over the track. These probably emit very strong IR signals which will saturate your Lap Timer.

7. Connecting Other Sensors

Other sensors can be connected to the system through the “User Channels”. The loom has several, up to a maximum of eight, user channel three pin Mini Sureseal sockets. The pin designations are all the same and are as follows:

Pin 1 Ground
Pin 2 Sensor signal
Pin 3 +5 volts

The Sensor signal must range from ground to a maximum of +5 volts. For potentiometers, simply connect the wiper to the signal pin and +5 volts and ground to either end of the track.

For active pressure sensors—such as those used for brake pressure, connect the +5 volts and ground to the specified wires and the output to pin 2. These sensors give an output ranging from 0.5 volts to 4.5 volts. **DO NOT** use the chassis as a ground connection for any sensor.

Connect any screen to the ground pin.

Lambda sensors usually require 12 volts to supply the heater and the interface box but the output is usually from 0 to 5 volts. Be careful with the ground wires—do not use the ground in the Mini Sureseal connector as the return for the heater supply.

Refer to the Podium Flash manual to see how to set the data analysis software to adjust the scale and offset of the sensors.

2.2 The Display Windows

There are six display windows:



Starting from the top left, the windows are:

Gear	Laps	Lap Time/RPM
Speed/Gauge 2	Elapsed/Lap Time	Gauge 1

2.2.1 The Gear Window

Shows the current gear if it can; otherwise this window is blank. If there is a connection to the Gear Box, then a number 0 or n indicates Neutral. If there is not gear output from the gear box, then the overall gear ratios in MPH (or KPH) per 5000 rpm must be entered in Set Up Mode. (see Section 3.22)

2.2.2 The Laps Window

This window the number of times the car has passed the Beacon. Note that this may not be the lap number in a race. The lap number can be reset to 0 by pressing both top buttons for about 3 seconds.

2.2.3 The Lap Time/RPM Window

Lap Time window is used for Lap Time! A quick set up change can be made to display RPM in this window where cars are being driven on the road. (see section 3.2) The odometer reading and best lap time are displayed here on power on.

If any gauge reading passes the limit set in Set Up Mode, an Alarm flashes in this window. Because 7 segment displays are used there is a limited set of letters that can be shown so the alarm for Oil Pressure is “Oil”, for Water Temperature or Oil Temperature it is “Hot” and for Fuel Level or Pressure the alarm is “Fuel”.

No oil pressure warning is given unless the engine is running. If the Hold Time is set to 0 and the car is not moving, warnings are given by flashing the gauge window.

Scrolling past Oil Pressure gives the following displays:

Lap Time Window	Gauge Window
Best lap Time	Ftd
Engine Speed (RPM)	tac
Battery Voltage	bat
User 1 input	US1

2.2.3.1 The Performance Monitor Option

If the Performance Monitor is switched on, then after the Hold Time has expired (see Section 5) the Lap Time Window shows the difference in time into the lap between the current and best laps as a time prefixed with a + or— sign.

2.2.4 The Speed/Gauge 2 Window

Shows the Speed in MPH or KPH. Speed can be shown only over a minimum value that will depend on the wheel circumference and the number of wheel pulses detected in a full wheel revolution. Alternatively this window can display a gauge reading. If a gauge reading is displayed here, speed can be shown by holding the top left hand button down for 3 seconds. The speed is then shown alternately with the letters SPd to remind you that speed is being displayed. This is designed for pit lane use and window can be returned to the gauge reading by pressing the bottom left hand button.

2.2.5 The Elapsed/Lap Time Window

If lap times are shown in the lap time/rpm window then elapsed time from power on is shown in this window. Pressing both bottom buttons for about 3 seconds will clear this time. It is used to show time into a qualifying session or an endurance race or driver session.

If RPM is shown in the Lap Time/RPM window, then this window shows lap time but only the seconds. . For example a lap time of 1 minute 2.38 seconds will be displayed as 2.38.

If the Hold Time is set to 0, and the Performance Monitor is on, the Performance Monitor is shown in this window.

to charge the battery. If the battery is not charged, the real time clock and calendar will not be able to maintain the data and time.


Tip: A small LED shines from behind the SD card slot under the card door. This light every time a sample is taken and is turned on while a file is being terminated. DO NOT remove the card if the LED is on.

6. Data Analysis

Data analysis is provided by PC software package supplied by PolyLogic called Podium Flash.

To look at the data collected, simply remove the SD card and plug it into your lap top. Instructions for the lap top software are supplied with the CD-ROM.

Plots such as the one shown above can be displayed using the Podium Flash Data Analysis package.



Minimum Battery Voltage
Maximum RPM for the lap
User 1 reading at the beacon
User 2 reading at the beacon
...
User 8 reading at the beacon

To use the data logging you must set up the tacho pulses, the wheel pulses and circumference and you must decide on the rate at which you want to record data and what criterion should be used to start logging. These parameters can be set up on the steering wheel or from Podium Flash, the data analysis software.

You should set the real time clock in the data logger so that you know when the data was recorded. The clock can only be set through Podium Flash. First make sure that the clock on your PC is correct then in the setup dialogue tick the Set Time check box.

About the files recorded on the SD card.

The files are numbered sequentially from 1 to 999. This number will not reset unless the non-volatile memory becomes corrupted in which case everything is set to the default state and the file number is set to 0. The files have a created and last modified date and time, these are the dates and times at which logging starts and ends.

The files are read only and cannot be deleted. When the card is full you must re-format it with Podium Flash. If you are logging at a sample period of 100 milliseconds, a single 512M byte SD card will last you at least a season so you may wish to keep this and buy a new one at the start of the next season.

There are SD cards and SD cards! If you use less than the best you may not be able to sample data fast enough and the data will be corrupted. **Also you will need to format the card with Podium Flash before you use it.** Podium Flash will write a setup file to the card at the end of the formatting procedure and it is sensible to check the setup before using a new card.

Warning, the data logger continues to write data to the SD card until the power to the data logger (and steering wheel) is switched off. The logger then requires some time to write data held in buffer memories to the card and to complete the file. Do not remove the card before at least 4 seconds has elapsed after the power has been switched off.

In order for the system to complete a file, the back-up battery in the data logger enclosure must be charged. If you are having trouble writing files to the card, try leaving power connected to the data logger for an hour or so

2.2.6 The Gauge 1 Window

The gauge 1 window shows the value of the selected Temperature, Pressure or Level as selected by the right hand buttons. Scrolling past Oil Pressure cause other measurements to be shown in the Lap Time Window and an appropriate label in the Gauge Window such as tac, Ftd, bat, or US1. (See Section 2.2.3.4)

3. Set Up

3.1 General

The system may be set up either from your laptop or through the buttons on the steering wheel. The set up state is held in memory in the control box and on the SD card. If the SD card is in the control box, then the setup is taken from this. If you change the setup with the SD card in the control box, the setup on the card is changed as well.

To set up the system using your laptop, start the data analysis program, Podium Flash supplied with the system, and click on the top menu SETUP. Insert the SD card into the laptop (the Sandisk cards supplied fold in half to reveal a connector that plugs into your laptop's USB sockets). Now click on Logger and the set up pages are displayed. Change the setup to suit your requirements and click OK. Wait for a few seconds for the setup file to be written to the card. Remove the card and insert in in the control box. When the system is switched on, the new setup will be copied to the system.

To enter Set Up Mode, press both left hand buttons for about 2 seconds. The display will change and show "SetuP" in the Lap Time Window and for a moment shows what the three bottom windows will contain. The Speed Window will display the Function Number, the Elapsed Time Window will show a hint at what function has been selected (as far as possible with the 7-segment displays) and the Gauge Window will show the value of the function. This value can be changed with the right hand buttons. For Example, Function 2 is the Hold Time (the time the lap time should be frozen in the Lap Time Window after passing the beacon). When setting up this time, the Speed Window will display 2, the Elapsed Time Window will display "Hold" and the Gauge Window will display the time set. Pressing the top right hand button will increase the time and pressing the bottom right hand button will decrease it.

Some Functions are On or Off. These are changed by pressing the top right hand button for On and the bottom right hand button for Off.

Once all the changes have been made, the Set Up Mode can be left by pressing both left hand buttons together for about 3 seconds.

A table listing the various parameters to set up is shown below. Once you have used it a few times you will find that the hints are enough to guide you through the Set Up process.

Function Number	Hint in Elapsed Time Window	Function Description	Default Value
0	Tach SPd OilP Cool OilT Fu P	Display tachometer in Lap Time Window Display Speed in the Speed/Gauge 2 Window Display Oil Pressure in the Speed/Gauge 2 Display Water Temp in the Speed/Gauge 2 Display Oil Temp in Speed/Gauge 2 Window Display Fuel Pressure (or level) in S/Gauge 2	OFF OFF OFF OFF OFF OFF
1	def	Set Everything to Default Values	OFF
2	SESS	Session Number—this automatically increases every time the system is turned on.	0
3	Hold	Hold Time in seconds. Time that the Lap Time is frozen after passing the beacon.	30
4	blnc	Blank Time in seconds. Time that the IR receiver ignores any other input after seeing its beacon.	10
5	IrCh	Channel Number for IR Detector. Choose 0 to receive PI beacon at UK Tracks.	1
6	InCh	IN Channel Number. Set this to IN code of beacon.	100
7	PerF	Performance Monitor Display ON or OFF	OFF
8	Here	Display Performance in Elapsed Time Window	OFF
9	Hour	Elapsed Time in Hours and Minutes (normally in Minutes and Seconds).	OFF
10	PPt	Pulses per Turn from Wheel Sensor	2
11	Circ	Wheel Circumference in centimetres	180
12	tps	Turns per Sample. Number of wheel turns between PM sample. DO NOT CHANGE	2
13	Per	Sample Period in milliseconds	100
14	Strt	Start Data Logging Trigger. 0 = never, 1 = when powered on, 2 = when engine started and 3 = when min. speed reached. Logging stops when power is turned off.	
15	tach	Number of Pulses per Two Engine Revolutions.	4
16	Filt	Tacho Pulse Filter—units are usecs + 50	100
17	POSP	Tacho Pulse Polarity—Positive	ON
AL	Lirn	Alarm Limit for Fuel.	10

stored in memory every few metres along the track. After the hold time has expired, the lap time window then displays the difference between the time at this point on the circuit for this lap and the time for the best lap. This difference is recalculated every few meters and the display updated.

If the lap time is displayed in the upper large window, the time difference is prefixed with a + or - sign. If it is displayed in the centre bottom window a negative sign only is available. To use the Performance Monitor, set function 7 (Perf) to ON. Make sure that you clear the best lap at the start of the session and do not switch off the system before starting your out lap.

5 Data Logging

Data logging in the SWIS20 is completely different from previous Farringdon systems. Data is logged against time, that is every so many milliseconds, all the channels are read and the results stored on the SD card.

The data collected for each sample is as follows:

Time into lap (time from beacon)
Speed
RPM
Oil Pressure
Water Temperature
Oil Temperature
Fuel Level or Pressure
Battery Voltage
Lateral G
Axial G
Data Logger Temperature
User 1
User 2
...
User 8

In addition at the end of each lap the following data is collected and stored on the card.

Lap Time
Lap Number
Session Number
Minimum Oil Pressure
Maximum Water Temperature
Maximum Oil Temperature
Minimum Fuel Level or Pressure

The Lap Time may be displayed in the large Lap Time/RPM window or alternatively, in the centre bottom window in place of elapsed time. (See Set UP for details.)

If the IN channel has been set up correctly, your car can be called into the pits by switching the beacon to the IN position. The word "Pits" is shown flashing in the Lap Time/RPM window.

4.12 Recall Mode

If the right hand buttons are pressed together for 3 seconds Recall Mode is entered. The last lap time is shown in the Lap Time/RPM window together with the lap number in the Lap window. The right hand buttons may be used to select a gauge. The gauge reading is the minimum or maximum for that lap. Minimum pressures and maximum temperatures are recorded. Use the left hand buttons to scroll through the laps retained in memory.

Pressing both right hand buttons together for 3 seconds causes the system to exit Recall Mode.

4.13 Best Lap (Ftd)

The best (smallest) lap time is stored and can be displayed by using the right hand buttons to scroll up to the point where "Ftd" (fastest time of the day) is shown in the gauge window. The best lap is shown also during the power up sequence and can be cleared by pressing any button at the next point in the sequence.

4.14 Displaying RPM

As an option available in Set Up, the Lap Time/RPM window can be made to show RPM rather than lap time. If this option is selected, then the lap time is shown in the elapsed time window as seconds. After reaching 59.99 the display rolls over to 0.00. Although the minutes are not shown this display is adequate for lap timing.

4.15 The Performance Monitor Option

The Performance Monitor provides the "unfair advantage" that every driver is looking for! Further, if you are prepared to entrust your car to someone who you know will drive faster than you, the Performance Monitor becomes a very powerful training aid.

The system works as follows:

The best lap must be cleared at the start of a session at a new circuit. During the first complete lap and on all subsequent laps, the time into the lap is

Function Number	Hint in Elapsed Time Window	Function Description	Default Value
18	Fu n	Fuel Sensor Output Inverted	OFF
19	Fu d	Fuel Sensor Delay. Delays fuel alarm for 10 seconds so that fuel alarm is not triggered by cornering.	OFF
AL	Lim	Alarm Limit for Oil Temperature	110
AL	Lim	Alarm Limit for Water Temperature (degrees C)	95
AL	Lim	Oil Pressure Alarm Limit (psi)	20
tac	LedS	Shift Light Settings—Green LED 1 to Red LED 9 (rpm x 100)	10 to 90
20	G ip	Electrical Gear Input Connected	OFF
21	N ip	Neutral Switch Input Connected	OFF
22	Gr 1	Gear 1 mph/5000 rpm (or pot reading)	-
23	Gr 2	Gear2 mph/5000 rpm (or pot reading)	-
24	Gr 3	Gear 3 mph/5000 rpm (or pot reading)	-
25	Gr 4	Gear 4 mph/5000 rpm (or pot reading)	-
26	Gr 5	Gear 5 mph/5000 rpm (or pot reading)	-
27	Gr 6	Gear 6 mph/5000 rpm (or pot reading)	-
28	Gr n	Potentiometer reading for neutral	-
29	Gr r	Potentiometer reading for reverse	-
Monitor Mode			
30	X g	Displays value read from x G sensor	-
31	Y g	Displays value read from y G sensor	-
32	Usr1..8	Displays value read from User (1 .. 8) Input	-
33	Gear	Displays Gear potentiometer reading	
34	-CL-	Clears Memories. Set to 1 to clear tell-tale Set to 2 to Clear Lap End Memory Set to 128 to Clear Odometer. To clear more than one item enter sum of codes. E.g. to everything enter 131. (1+2+128).	

3.2 Tachometer and Other Display Options

The tachometer option is the first to be accessed so that the Lap Timer may be switched off and replaced by a digital tachometer. Set to On to display RPM. This is followed by options for the Speed/Gauge 2 window. The hint shown in the Elapsed/Lap Time window are as follows:

SPd = Speed
OilP = Oil Pressure
Cool = Water Temperature (or CHT)
OilT = Oil temperature
FuP = Fuel Pressure (or level)

3.3 Set Defaults

Setting this Function to On sets all functions back to the factory settings. Set to yes then leave set up mode by pressing both left hand keys.

3.4 Session Number

The session number is stored with lap times and data. It is incremented every time the beacon is seen on the out lap but can be set manually with this function.

3.5 Hold Time

The Hold Time is the time in seconds that the lap time is frozen in the Lap Time Window after passing the beacon. Set this to be long enough for you to reach a suitable place on the track to glance down and read it.

Setting the Hold Time to 0 changes three aspects of the display. First the lap time remains displayed throughout the lap, second, the Performance Meter is shown in the Elapsed Time window and third, gauge warnings are signified by a flashing gauge window until the car is moving.

3.6 Blank Time

This is the time that the Infra Red Detector ignores all signals after seeing its beacon. 10 seconds is a good time to use but it can be extended to blank out other beacons placed around the track in order to generate segment times on some other systems.

3.7 Infra Red Channel Number

Set this to the channel number you are going to use. If you wish to use the PI Beacons on most UK circuits and you have a dual channel IR Detector, then set the channel number to 0.

pit lane. To confirm that speed is being displayed, the speed is shown alternating with the text SPD. To clear the speed display, press the bottom left hand button.

4.5 Elapsed Time

The elapsed time is displayed in the bottom centre window and can be reset to zero by pressing both bottom buttons for a second or two. The units are normally minutes and seconds but can be changed to hours and minutes in Set Up.

4.6 Oil Pressure

Oil pressure is the measurement of the highest priority and an oil pressure warning will overrule any other. When the engine is not running an oil pressure warning can be turned off (in the normal way by pressing either right hand button) but when the engine is running this alarm cannot be turned off. The alarm given in the Lap time/RPM window is a flashing "Oil".

4.7 Water Temperature

Water temperature is the second highest priority. Its alarm can be turned off at any time. The alarm is displayed in the Lap Time/RPM window as "Hot"

4.8 Oil Temperature

Oil Temperature is the third highest priority. Its alarm is also "Hot" but the gauge LED will be light next to the Oil Temp legend.

4.9 Fuel

Fuel level or pressure is the lowest priority and its alarm is "Fuel".

4.10 Battery Voltage

Battery voltage can be displayed in the Lap Time/RPM window by pressing the top right hand button until "Bat" is shown in the gauge window. There is no warning for battery voltage.

4.11 The Lap Timer

When switched on the steering wheel enters its power up sequence before reaching its normal state. The lap time starts at 00:00.00 and increments continuously until it sees the beacon for the first time. The lap time is then frozen for the "hold" time. The hold time is adjustable in Set Up. The number of laps completed is shown in the two digit lap window. (The number rolls over from 99 to 0.)

4. Using the SWIS20

When power is applied, the steering wheel first displays all segments (all numbers are 8s). They are then cleared and the serial numbers of the steering wheel itself (in the Speed/Gauge 2 window), the serial number of the data logger (in the lap time/RPM window) and the software revision (in the gear window) are displayed. **If no button is pressed while the serial numbers are displayed, the remainder of the power-up sequence is skipped.** If any button is pressed the odometer reading is shown next.

4.1 Odometer

The odometer (total distance travelled) is displayed when the steering wheel powers up. It can be cleared back to zero by using function 34 in the set up procedure. It shows the total number of whole miles (or kilometres) travelled since it was last reset.

4.2 Gear

The gear window shows the gear selected. If the gear is calculated from engine RPM and road speed, remember that it can only show the correct gear *after* you have released the clutch. It cannot show you that you are *about to* select the wrong gear. Further, it will not show the gear until the car is travelling fast enough to obtain a valid speed.

On the other hand, if the gear signal comes from a sensor in the gearbox, then this will show the gear when the car is stationary and at all other times.

4.3 RPM and Shift Lights

Experiment with the shift light settings to find the most easily read arrangement. You may find that the lights should be set to light at small intervals (200 rpm or so) at the top of the RPM range to allow you to gauge the *rate* at which the RPM is approaching the shift point.

4.4 Speed

Speed can be shown all the time or on demand in the in the Speed/Gauge 2 window. (see Set Up) The speed is calculated from the time between the pulses coming from the wheel sensor. Because this timer can measure only small times, speed cannot be shown until some minimum value is reached. This value depends on the number of pulses per wheel turn from the wheel sensor and the diameter of the wheel. Typically the lowest speed that can be displayed is between 10 and 30 mph.

If the Speed/Gauge 2 window is displaying another gauge, then pressing the top left hand button for about 2 seconds causes the Speed/Gauge 2 window to show speed. This function has been added to monitor your speed in the

3.8 "IN" Channel Number

All Farringdon Beacons come with an channel number from 1 to 250. Set this channel number to that of your beacon. This is most easily done by pointing the beacon, switched to "IN" at the IR Detector while at this point in the set up procedure. The Gauge Window will show the channel number detected.

3.9 Performance Monitor Display

The Performance Monitor shows the time difference in the Lap Time Window between the time to the current point on the track and the time taken in the Best Lap to reach the same point. It is shown only after the Hold Time has expired. If you turn this display ON, then the data logging must be ON; so setting this function ON also sets the Data Logging function ON. Remember to clear the best lap when you visit a different track.

3.10 Display Performance Monitor in Elapsed Time Window

Set this to ON to display the Performance Monitor in the Elapsed Time Window. No + sign is shown but a—sign is displayed when you are faster than your best lap.

3.11 Elapsed Time Units

Elapsed Time can be measured in minutes and seconds or hours and minutes. The latter is useful for endurance races.

3.12 Number of Wheel Pulses per Turn

Enter the number of pulses the wheel sensor will generate for each tuen of the wheel—the number of targets.

3.13 Wheel Circumference

Enter the wheel circumference in centimetres. The circumference is best measured by marking the tyre on the wheel to which the sensor is attached and rotating it at least twice, measuring the distance covered and dividing by the number of times the wheel was turned.

To show the speed in KPH, divide the circumference by 1.6 and enter this value.

3.14 Wheel Turns per Sample

The Performance Monitor (if fitted) will calculate the number of wheel turns counted between sampling the time from beacon. This function displays the result. Do not change.

3.15 Sample Period

Enter the sample time you want to use. A good figure for comparing driving style would be 100 msec. If you have suspension potentiometers on the User channels, you may wish to sample much faster. The maximum sampling speed is 500 samples per second—for this enter a sample period of 2 milliseconds. At this rate you should be able to see frequencies of 100 HZ.

3.16 Start Logging Trigger

Enter the code as follows: 0 = never. 1 = when ever power is applied, 2 = when a speed of 40 mph is reached and 3 = when the engine has started. We recommend the latter as it gives important diagnostic data while the engine is being warmed up. [Data logging stops when power is removed.](#)

3.17 Number of Tachometer Pulses for Two Revs. Of the Engine

The number entered depends on your ignition system. If electronic ignition is used, then there will probably be a tacho pulse output. If not it may be necessary to purchase an HT sensor which clips on to a plug lead which will produce just one pulse per two turns for a 4 stroke engine.

3.18 Tacho Filter

Often pulses from the ignition system are noisy and have to be filtered to give reliable tacho readings. This function sets the minimum pulse widths that are counted as tacho pulses. The units are in microseconds plus 50. Set this to 100 as a start.

3.19 Tach Pulse Polarity

This is set to positive by default. (Positive Polarity ON.)

3.20 Fuel and Other Alarm Limits

It is recommended that you not change the default settings for the alarm limits for fuel, oil temperature and pressure and water temperature—these have been specified by the Radical factory.

3.21 Shift Light Set Up

The shift lights are set up following the alarm limits. Set the value to the RPM/100 at which you want the LED to light. You can set more than one light to the same value so that, for example the top three bright LEDs can be set up to come on at the same RPM.

3.22 Gear Indicator Set Up

There are three items to be set up for the gear indicator to work correctly. If there is an analogue output from the gearbox—usually a potentiometer, then set function 20 to ON. Connect the potentiometer across the +5V and Ground outputs. Use Function 33 to monitor the values for each gear and enter these in Functions 22 to 29.

If there is not direct output from the gearbox, then the gear ratios have to be entered in set up mode so that the system can deduce the gear the car is using. The ratios are expressed as miles per hour per 5000 rpm. (If you have chosen to use KPH by dividing the wheel circumference by 1.6, then enter the ratios as KPH per 5000 RPM.) If the gearbox is a sequential type then there may be a neutral switch. In this case the switch must go to ground when in neutral and Function 17 should be set to ON. The display will show a blank if the engine or car is not running fast enough but will show 0 only when the neutral switch is actuated.

Use the following equation (or a gear ratio chart) to calculate these figures.

$(\text{circumference}) \times (\text{Gear Ratio}) \times (\text{Final Drive Ratio}) \times 1.863 = \text{mph}/5000 \text{ rpm.}$

Or $(\text{circumference}) \times (\text{Gear Ratio}) \times (\text{Final Drive Ratio}) \times 3 = \text{kph}/5000 \text{ rpm.}$

Where (circumference) is the wheel sensor wheel circumference in centimetres.

3.23 Monitoring Inputs in Set Up Mode

A very useful Monitoring Mode is available in Set Up. Functions 30 to 33 read out the values of each axis from the Accelerometer, all 8 User Channels and the gear pot. Use the values to check the working of any sensors you have connected to the User Channels and to check the accelerometer. The figures displayed are the outputs of the system ADC and range from 1023 for an input of 5 volts (the maximum) and 0 for ground voltage. (The display wraps round after 999 so 1024 reads as 23.)

3.24 Clearing System Memories

Function 30 allows three memories to be cleared. Setting the function to 1 will clear the tell-tale reading, setting it to 2 will clear the Lap End memory and setting it to 128 will clear the Odometer. To clear more than one at a time, simply add the values together. For example to clear the tell-tale and the Lap End memory, enter 3.