

Addendum to User's Manual No. 9R165

Elster M201E Universal DP Tester

For Differential Pressure "Drop" Tests
of Natural Gas Meters













Table of Contents

Elster M201E Universal DP Tester	3
User Interface Keys	4
Mode Select – Enhanced or Legacy	5
Time Units Select	6
Enhanced Mode – Running a Drop Test	7
Legacy Mode – Running a Drop Test	8
Using the Equalizing Manifold Option	9
M201E Legacy and Enhanced Comparison Table	10

Notes:

1. This Addendum addresses features unique to model M201E. Additional user instructions for those M201E functions common to all M2 Series Smart Manometers can be found in User's Manual No. 9R165, "M2 – SERIES USER MANUAL: SMART MANOMETER / ROTARTY GAS METER TESTER". User's Manual No. 9R165 is included with M201E shipments along with Addendum No. 9R166.
2. Information and specifications in this document are subject to change without notice. Check the Elster Gas Depot web site (www.elstergasdepot.com) for latest manual revision.

M201E Legacy and Enhanced Comparison Table

	Legacy Displays	NEW Enhanced Displays
Select Legacy or Enhanced Mode		
Measure Mode	 No Measure Mode, only Standby...	 Standby with Live DP Display
Test Mode – Acquire Data	 No DP Display, no timer	 Live DP display, internal stop watch
Test Results Display	 Average DP Displayed	 Test Period & Average DP Displayed
Test Results “Min/Max” Display	 Test Min/Max above, Ave. DP below	 Test Min/Max above, Ave. DP below

Elster M201E Universal DP Tester

Periodic differential pressure tests, or “drop” tests, on rotary natural gas meters are necessary to track meter condition. The tests indicate changes in meter performance over time and reveal when a meter should be removed from service for repair or reconditioning. “Slow” meters, those with higher differential pressure, result in under-billing and therefore cost the natural gas supplier money.

Elster’s enhanced M201E Universal DP Tester has new features to improve its general usefulness and make Rotary (Natural) Gas Meter drop tests easier. The new Measure Mode displays differential pressure readings while standing by for a drop test. This allows users to make general DP measurements and provides convenient feedback on zero performance (simultaneously pressing the “Min/Max” and “Hold” keys takes a new zero when needed). Measure Mode also lets users know when the M201E is correctly connected to a meter and ready for a test to be run.


When a drop test is started, the enhanced M201E uses an internal stop watch to time the test period. This means the technician no longer needs to time the drop test externally, he only needs start a test (press the “Hold” key from Measure Mode) and then stop it (press the “Hold” key again) after one meter revolution. The M201E results screen shows the test period and average DP once the test is stopped. To view the minimum and maximum DP measured during the test, simply press the Min/Max key. Toggle the Min/Max key again to return to the test time and average DP results display.

The enhanced M201E includes a Mode Select program menu for Legacy or Enhanced modes of operation – the users chooses which mode is best for them. See the “M201E Legacy and Enhanced Display Comparison Table” on the last page of this Addendum for more information.

New hardware option protects the M201E from one sided overpressure. See the Manifold section of this Addendum for more details.


User Interface Keys

Refer to the graphic below as reference for instructions in this Addendum.



Using the Equalizing Manifold Option

To protect the M201E's differential pressure sensor from damage due to accidental over pressure, it is important to use the M201E's Universal DP Tester's equalizing manifold correctly. The Integral Push-To-Read (IPTR) cartridge valve.



IPTR Cartridge Valve

Integral valve is open and DP sensor equalized until the push button valve is depressed

Instructions

1. Install preferred connectors in the 1/8" NPT (female) connections on the M201E or M201E manifold. Use Teflon tape or other suitable thread sealer.
2. The IPTR are normally open and the M201E sensor is equalized.
3. Make connections to the gas meter's HI and LO ports. Be certain to observe the P1 (HI) and P2 (LO) on the M201E.
4. Turn M201E "On". Display should read zero since HI and LO sides are connected and pressure is equalized. If not, re-zero the M201E by simultaneously pressing the Min/Max and Hold keys.
5. To make differential pressure measurements with IPTR manually depress and hold the push-to-read valve.
6. Upon completion of use / test, release the IPTR valve to equalize pressure on the M201E sensor. Then disconnect pressure lines.

Legacy Mode – Running a Drop Test

The M201E Legacy mode operates the same as the original M201E. Legacy mode provides the user with less information than Enhanced mode does. No live pressure readings are displayed either prior to or during the test. Upon test completion, the display shows only the average differential pressure over the test period.

To run a Legacy Mode drop test on a rotary natural gas meter, follow the steps below.

Keystroke	Display
1. Turn unit on using the On/Off key. Unit powers on ready to start a drop test.	Reads "Press Hold to Acquire Data".
2. Press the Hold key to start the test.	Reads "Acquiring Data..". No values are displayed while pressure values are stored.
3. Press the Hold key again to stop the test.	Reads "R" for result and "XX.XX Units", the average Differential Pressure (DP) during the test period.
4. Press Min/Max key for additional test information if desired.	Top line shows Minimum and Maximum DP value over test period, Bottom line reads "R" for result and "XX.XX Units", the average DP over the test period
5. To start a retest, press the Hold key. Repeat Steps 3 & 4.	Reads "Acquiring Data..".
6. Press the ◀ arrow key.	Returns to Measure Mode

Mode Select – Enhanced or Legacy

The M201E Universal DP Tester Mode Select option in the program menu for Legacy or Enhanced operation. The user chooses which mode to use. See the "M201E Legacy vs. Enhanced Comparison Table" at the end of this manual addendum for a comparison of features and displays.

To configure the M201E for either Legacy or Enhance mode operation, follow the steps shown on below.

Keystroke	Display
1. Turn unit on using the On/Off key.	Top line reads " 'Hold' to Test", Bottom line displays live Differential Pressure value
2. Press the Prgm key.	Top line reads "Program Mode", Bottom line reads "Units Select"
3. Press the ▲ arrow key.	Top line reads "Program Mode", Bottom line reads "Mode Select"
4. Press the ► arrow key.	Top line reads "Mode Select", Bottom line reads current mode, Enhanced or Legacy
5. To retain the displayed mode, press the Prgm key and proceed to Step 7.	Top line reads "Program Mode", Bottom line reads "Mode Select"
6 a. To change the displayed Mode, press the ▲ or ▼ arrow key.	Top line reads "Mode Select", Bottom line displays the new mode option, Legacy or Enhanced
6 b. To retain the displayed mode, press the Prgm key.	Top line reads "Program Mode", Bottom line reads "Mode Select"
7. Press the ◀ arrow key.	Returns to Measure Mode

Time Units Select

The M201E enhanced Universal DP Tester, includes a Time Unit Select option in the program menu for Enhanced Mode operation. The user chooses either seconds or minutes as the desired time unit for the results display.

To the desired time unit, follow the steps shown on below.

Keystroke	Display
1. Turn unit on using the On/Off key.	Top line reads “ ‘Hold’ to Test”, Bottom line displays live Differential Pressure value
2. Press the Prgm key.	Top line reads “Program Mode”, Bottom line reads “Units Select”
3. Press the ▲ arrow key twice.	Top line reads “Program Mode”, Bottom line reads “Time Units”
4. Press the ► arrow key.	Top line reads “Time Units”, Bottom line reads current mode, Seconds or Minutes
5. To retain the displayed time unit, press the Prgm key and proceed to Step 7.	Top line reads “Program Mode”, Bottom line reads “Mode Select”
6 a. To change the displayed Mode, press the ▲ or ▼ arrow key.	Top line reads “Time Units”, Bottom line displays the new unit option, Minutes or Seconds
6 b. To retain the displayed time unit, press the Prgm key.	Top line reads “Program Mode”, Bottom line reads “Time Units”
7. Press the ◀ arrow key.	Returns to Measure Mode

Enhanced Mode – Running a Drop Test

The M201E Enhanced mode provides more user feedback at the display than Legacy mode does. Live pressure readings are displayed prior to and during a drop test. Upon test completion, the display shows the test period that was used along with the average differential pressure over the test period.

To run an Enhanced Mode drop test on a rotary natural gas meter, follow the steps below.

Keystroke	Display
1. Turn unit on using the On/Off key.	Top line shows “ ‘Hold’ to Test”, Bottom line displays live Differential Pressure (DP) value
2. Press the Hold key to start the test.	Top line shows “Acquiring Data..”, Bottom line displays live DP value
3. Allow M201E to acquire test data per user company’s procedures.	Top line shows “Acquiring Data..”, Bottom line displays live DP value
4. Press the Hold key again to stop the test.	Top line shows the length of the test in seconds or minutes, Bottom line reads “R” for result and shows the average DP over the test period
5. Press Min/Max key for additional test information if desired.	Top line shows Minimum and Maximum DP value over test period, Bottom line reads “R” for result and shows the average DP over the test period
6. To start a new test, press the Hold key. Repeat Steps 3 & 4	New test is run.
7. Press the ◀ arrow key.	Returns to Measure Mode