

1. SAFETY PRECAUTIONS.....	5
2. PHONE REGISTRATION.....	11
3. PHONE OVERVIEW.....	12
4. GETTING STARTED.....	17
5. TEXT ENTRY.....	29
6. CALLING.....	32
7. MENUS.....	38
7.1 MESSAGES	38
7.2 PHONEBOOK.....	48
7.3 CALL HISTORY	52
7.4 SETTINGS	54

7.4.1	<i>Dual SIM switch</i>	54
7.4.2	<i>Dual SIM settings</i>	54
7.4.3	<i>Phone settings</i>	55
7.4.4	<i>Network settings</i>	65
7.4.5	<i>Security settings</i>	67
7.4.6	<i>Connectivity</i>	70
7.4.7	<i>Restore factory settings</i> ...	71
7.4.8	<i>Shortcuts</i>	71
7.5	MULTIMEDIA.....	72
6.5.1	<i>Image viewer</i>	72
7.5.2	<i>Video recorder</i>	74
7.5.3	<i>Video player</i>	74
7.5.4	<i>Sound recorder</i>	74
7.5.5	<i>FM radio</i>	75

7.6 FUN & GAMES	76
7.7 CAMERA	77
7.8 AUDIO PLAYER	79
7.9 USER PROFILES	80
6.10 ORGANIZER.....	83
6.10.1 <i>Calculator</i>	83
6.10.2 <i>Calendar</i>	84
6.10.3 <i>Tasks</i>	86
6.10.4 <i>Alarm</i>	86
6.10.5 <i>World clock</i>	86
6.10.6 <i>Currency converter</i>	87
6.10.7 <i>Stopwatch</i>	87
7.11 SERVICES.....	88
7.11.1 <i>STK</i>	88

7.11.2 <i>Internet Services</i>	88
7.12 FILE MANAGER.....	90
8. APPENDIX I	
TROUBLESHOOTING	91
9. APPENDIX II ABBREVIATIONS	
AND EXPLANATION.....	107
10.APPENDIX :LIST OF	
ACCESSORIES IN PACKING	
BOX.....	110
11. SERVICE CENTER LIST	111

1. Safety Precautions

Information for parents

Please read the operating instructions and safety precautions carefully before use.

Explain the content to your children and the hazards associated with using the phone.



Remember to comply with legal requirements and local restrictions when using the phone, for example, in aeroplanes, petrol stations, hospitals or while driving.



Mobile phones can interfere with the functioning of medical

devices such as hearing aids or pacemakers. Keep at least 20 cm (9 inches) between the phone and pacemaker. When using the mobile phone hold it to the ear which is furthest away from the pacemaker. For more information, consult your doctor.



Always keep the phone and accessories out of reach of small children.

Small parts such as the SIM card, dust cap, lens ring and lens cap as well as the microSD card can be dismantled and swallowed by small children.



Do not place the phone near to electromagnetic data carriers such as credit cards and floppy disks. Information stored on them could be lost.



Permanent hearing loss may occur if you use earphones or headphones at high volume. You can adapt over time to a higher volume, which may sound normal but can be damaging to your hearing. Set your volume to a safe level. If you experience discomfort or buzzing in your ears, reduce the volume or discontinue use of your earphones or headphones.



Ring tones, info tones and handsfree talking are reproduced through the loudspeaker. Do not hold the phone to the ear when it rings or when you have switched on the handsfree function. Otherwise you risk serious permanent damage to your hearing.



The mains voltage (V) specified on the power supply unit must not be exceeded. Otherwise the charging device may be damaged.

The power supply must be plugged into an easily accessible AC mains power socket when charging the battery. The only way to turn off the charging device after charging the battery is to unplug it.



You may only open the phone to replace the battery, SIM and microSD card. You must not open the battery under any circumstances. All other changes to this device are strictly prohibited and will invalidate the guarantee.



The phone may cause interference in the vicinity of TV sets, radios and PCs.



Dispose of unwanted batteries and phones as permitted by the laws in your countries.



Only use original batteries and charging devices. Otherwise you risk serious damage to health and property. The battery could explode, for instance.

All batteries can cause property damage, injury or burns if a conductive material such as jewelry, keys or beaded chains

touch exposed terminals. The material may complete an electrical circuit and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside your pocket, purse or other container with metal objects.


Do not dispose of batteries in fire as they may explode.

Improper use will invalidate the guarantee!
These safety instructions also apply to original accessories.

2. Phone Registration

In order to register the details of the customer, the software embedded in the phone has the facility to send an sms automatically to MIRC Electronics Ltd upon insertion of the SIM card. It is in the interest of the user to register its details with the company for any future services , as may be needed. The user agrees to pay the SMS charges in respect of the automated SMS sent to the company upon insertion of the SIM card.

3. Phone Overview



Communication control keys

SIM1/ SIM2 Calling key is used to make a call after a number has been entered or selected from the phone book, or to answer an incoming call. In idle screen, press SIM1/ SIM2 Calling key to show call logs of SIM1/ SIM2 card.

End key is used to end a call during calling or conversation, or to quit the menu and return to idle screen. Press and hold the End key for about three seconds to turn on/off the phone.

LSK/RSK

In idle screen, press the left soft key to open the main menu. In idle screen, press the right soft key to directly access the phone book list. During menu operation,

the current functions of the left and right soft keys are shown in the bottom line of the screen, and they are closely related to the current status of the phone.

Keypad

Press keypad to enter numbers or characters.

You can also use number keys to select menus. If a number is shown before an option in menu list, you can select the option quickly by pressing the corresponding number key.

key

In standby mode, press and hold it in idle screen to activate/deactivate the Meeting mode.

In standby mode, press RSK and then press

key to lock the keypad or unlock the keypad.




In editing screen, press # key to switch input method.

Connection jack










The connection jack is used to connect charger.

Icons displayed on the main screen (Icons may be changed without further notice)

The following icons may be displayed in the first line of the screen.

	Signal strength
	Battery status
	Keypad locked

ONIDA-S555

	Alarm activated
	New SMS received or SMS full
	New MMS received
	Headset mode
	Ring
	Vibration only
	Vibration and ring
	Vibration then ring
	Missed calls

4. Getting Started

What is a SIM card

When registering your mobile phone number, you will have a SIM card (Subscriber Identity Module) provided by the network operator.

The SIM card has information reserved for your use. It includes your phone number, PIN (Personal Identification Number), PIN2, PUK (password to unlock PIN), PUK2 (password to unlock PIN2), IMSI (International Mobile Subscriber Identity) number, network information, phone book data, SMS data and so on. If it is lost, contact your network operator immediately for help.

PIN code

PIN is the password provided by your network operator. It is usually 4 digits. When you input the PIN code, the screen displays “*” to replace the number entered.

PIN is used to access the SIM card. If the PIN protection function is enabled, the screen will display “Enter PIN” each time the phone is switched on. You can deactivate this feature but you risk unauthorized use of the phone. Some network operators do not permit deactivating the control.

PIN2 code

PIN2 is required for some specific functions provided by the network, such as the charge information.

Note: If you enter the PIN incorrectly three

times in a row, the SIM card will be locked. Please contact your network operator immediately for decoding. Attempting to decode by yourself may result in the permanent failure of the SIM card.

PUK code

PUK (Personal Unblocking Key, 8-digit) unlocks a locked PIN. If you enter the PUK incorrectly ten times in a row, the SIM card will become invalid. Please contact your network operator for a new SIM card.

Installing the SIM card

1. Press and hold the End key to turn off the phone.
2. Remove the battery cover and then the battery.
3. Insert the SIM card into the card

holder. Ensure that the cut corner is at the right bottom and the metal contacts face the phone.

4. Re-install the battery. Place the battery cover onto the back of your phone and slide it forward until the latch catches the cover.

Note: A SIM card can be easily damaged if its metal contacts become scratched. Therefore, take special care when holding or inserting it and keep it away from small children.

Charging the battery

The battery is not fully charged when first unpacked. It takes three charging-discharging cycles for the battery to reach its peak performance. The battery can be charged and discharged hundreds of times. However, the capacity of the battery

will be reduced each time it is charged/emptied, and it will eventually wear out. When the talk time and the standby time are noticeably shorter than normal, replace the battery. Use original batteries and charging devices only.

Unplug the charger from the outlet and the phone when not in use. Do not leave a fully-charged battery connected to a charger because overcharging may shorten the lifetime of the battery. If unused, a fully-charged battery will lose its charge over time.

If the battery is completely discharged, the charging may not start immediately when you plug in the connector. Wait 10 to 15 minutes for the phone to begin charging.

Use the battery only for its intended purpose. Never use any charger or battery

that is damaged.

Do not short-circuit the battery. An accidental short circuit may occur when a metallic object such as a coin, clip or pen causes the direct connection of the positive (+) and negative (-) terminals of the battery, for example, when you carry a spare battery in your pocket or purse. Short circuit may damage the battery and the connecting object.

Storage at too high or low temperatures will result in a gradual capacity loss. As a result the operating time of your mobile phone may be considerably reduced, even after the battery is fully charged.

Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Dispose of unwanted batteries and phones as permitted by the laws in your

countries.

Note: The actual operation time of a battery varies based on the operation mode, network settings and call settings.

Charge a battery according to the following steps:

1. Connect the charger to the connection jack of the phone in proper direction, and connect the charger to a main socket.
2. The phone displays "Charger Connected!" and starts charging after properly connected. The battery icon dynamically displays the charging process. In switch-off state, the phone dynamically displays the charging process.
3. When the battery is fully charged, the

charging process stops automatically, and the battery icon indicates full grid on the screen. After the battery is fully charged, remove the charger from the phone and socket as soon as possible.

Note:

- After the phone has run out of battery, we recommend that you recharge the battery in time. If you do not recharge the battery in two days, the phone may enter the slow charging mode. When you recharge the battery, there may be no display temporarily. After about 10 minutes, the charging indicator icon is displayed on the screen of the phone. If you do not recharge the battery more than two days, the battery may enter the over discharge protection state. Thus, in order to get the battery into normal charging mode quickly, we

recommend that you charge the battery on an adapter to activate the battery for charging, and then charge the battery with the phone. Alternatively, you can charge the battery with the adapter.

- Do not change the parts and accessories of the battery by yourself or take off the battery cover for safety.
- Use only original batteries and charging devices. Otherwise you risk serious damage to health and property.
- Do not use the phone while charging.
- It takes approximately four hours to fully charge a battery. Remove the charger quickly after the battery is fully charged.
- After pulling out the battery system date and time will be reset to default

values(factory settings).

Removing the battery

Before removing the battery, ensure that you phone is power off. You can do as follows:



Installing a T-Flash card

You can insert a T-Flash card to expand the memory capacity of your phone. When

installing a T-Flash card, ensure that the golden contact area on the T-Flash card is facing downward, and the beveled edge of the T-Flash card is properly aligned with that of the card slot.

Switching the phone on

Press and hold the End key to turn the phone on/off. The phone will automatically search for the network, if there is no password protection for the SIM card and the phone. After the phone is registered on the network, the name of the service provider will be displayed on the idle screen. Then you can make or answer a call.

The phone remains in searching state if it fails to find the available network system temporarily.

After the phone is switched on, if a

password is required, enter the correct PIN code and press the RSK or the OK key for confirmation. After unlocked, the phone will display the name of the registered network and the signal strength. Contact your network operator if you do not know the PIN code.

After the phone is switched on, if it displays “Insert SIM Card” on the screen, press and hold the End key to turn the phone off, and check whether the SIM card is properly inserted.

Switching the phone off

Press and hold the End key to turn the phone off. After the switch-off animation is displayed on the screen, the phone will be switched off.

Do not attempt to turn the phone off by directly taking out the battery.

5. Text Entry

When an editing screen is displayed, the current text input method is indicated in the upper left corner of the display. To have more options to enter text, do one of the following ways to select the desired input methods:

- Go to **Settings > Phone settings > Pref. input methods.**
- In editing screen, select **Options > Input method.**

Changing the input method

Press the # key to select an input method.

Inserting symbols

Press the * key and select the required symbols.

Numeric

When the input method icon is shown as '123', input numbers directly with number keys.

Traditional input mode

The input method icon is shown as 'abc', 'ABC', 'Abc', 'HI', ' '.

Press each letter of the word you want to write.

While entering text, press the RSK (**Clear**) once to delete the last character on the display; press and hold it to delete all entered text.

Smart input

The input method icon is shown as 'ABC', 'eZi abc', 'HI'

Press each key associated with the letter you want to enter. The letters you have

entered appear at the bottom of screen. The candidate words change with each key you press. When the candidate words are displayed, press the direction keys to choose words.

While entering text, press the RSK (**Clear**) once to delete the last character on the display; press and hold it to delete all entered text.

6. Calling

Making a call

In idle screen, enter a phone number and press the SIM1/SIM2 Calling key to make a call by SIM1/SIM2 card.

Press the End key to end a call.

Making an international call

1. Press the * key twice to enter “+”.
2. Enter the country code, area code and phone number.
3. Press the SIM1/SIM2 Calling key to make a call by SIM1/SIM2 card.

Dialing an extension number

You can press "P" "W" and then enter the extension number. press the * key three

times in a row to enter "P", or press the asterisk key four times in a row to enter "W".

Making a call from phone book

1. In idle screen, press the RSK to go to **Phonebook**, scroll and select a contact person
2. Press SIM1/SIM2 Calling key to make a call by SIM1/SIM2 card.

Dialing a previous number

1. In idle screen, press SIM1/SIM2 Calling key to display Call History of SIM1/SIM2 card. Press navigation key to select a number.
2. Press SIM1/SIM2 Calling key to make a call by SIM1/SIM2 card.

Listening to voice mail

In idle screen, press and hold number key 1 to enter **Voicemail server**.

You need to set the voice mail number and store it on your SIM card. To set the number, go to **Messaging > Message settings > SMS > SIM1 / SIM2 message settings > Voicemail server**, press LSK key and then select **Edit**.

Answering a call

- Press the SIM1/SIM2 Calling key or OK key.
- Press the LSK key and select **Options** and **Answer**.

Ending a call

Press the End key.

Rejecting a call

- Press the End key.

Call options

Press **Options** during a call for more options. Options vary depending on the current situation.

Hold Single call	Hold the current call.
End Single call	End the current call.
New Call	Add a new call and talk with more than one party at a time.

Phonebook	Use Phonebook to search for numbers.
Call history	View the call history.
Messaging	Read/write a message during a call.
Sound Recorder	Record the call.
Mute	The person on the other end of the line cannot hear you (muting).

DTMF	Enter tone sequences (number) for remote inquiries to an answering machine.
-------------	---

Dual-SIM card dual-standby call

When both SIM 1 and SIM 2 cards of a mobile phone are under standby state on the network, meanwhile the SIM 1/SIM 2 card is being used for a call, any call to the other SIM 1/SIM 2 card cannot be connected.

7. Menus

7.1 Messages

The phone supports Short Messaging Service (SMS) and Multimedia Messaging Service(MMS). You can send text/multimedia messages and manage the messages that you sent and received.

If the memory for short messages is not full, short messages will be directly saved in the SIM card. A flashing icon will appear on the top of the main screen if the memory is full.

The phone also supports Multimedia Message Service (MMS), which is a network service. It enables you to send messages with images, sounds and texts. Ask your service provider whether this service is available. You may need to

subscribe to the service from your network operator before sending and receiving multimedia message. All multimedia messages are stored in the memory of the phone. The SIM card cannot store multimedia messages. If the memory for MMS is full the phone can not receive the new ones anyway, please delete the unused MMS and download them manually.

1. Write (Text/Multimedia) message

Create and edit the Text/Multimedia message in the menu “Write message”.

Create a new Text message.

1. Go to **Menu > Message > Write message > SMS** to navigate to message editor screen..
2. Edit the text message content.
3. Press the LSK (**Options**) and then

select **Advanced** to add the required items, including **Insert number**, **Insert name**, **Insert bookmark**.

4. Press the LSK (**Options**) and select **Send to** or press OK key to navigate to **Send SMS** screen.
5. Enter the recipient numbers in Enter recipient option or attach the recipients from the phonebook list.
6. Press OK key and then select **From SIM1/2** to send the SMS.

Create a new Multimedia message

1. Go to **Menu > Messages > Write message > MMS** to navigate to message editor screen..
2. Press LSK (**Options**) and then select **Add subject** to edit the subject for this

MMS.

3. Press the LSK (**Options**) and select the items you want to send, including images (**Add picture**), audios (**Add sound**) and so on.
4. Press the LSK (**Options**) and select **Send to** or press OK key to navigate to **Send MMS** screen.
5. Enter the recipient numbers in Enter recipient option or attach the recipients from the phonebook list.
6. Press LSK (Options) and select **Change to Cc/Bcc**, edit the MMS to be carbon copied or blind carbon copied to.
7. Press OK key and then select **From SIM1/ SIM2** to send the MMS.

2. Inbox

Incoming short messages are saved in inbox.

View	View the current message.
Reply by SMS	Reply the message by short message.
Reply by MMS	Reply the message by Multimedia message
Call sender	Make a call with the sender.
Forward	Forward this short message to others.
Delete	Delete the message.

Delete all	Delete all the messages in inbox.
Save to phonebook	Save the message to the phone.

You cannot receive new messages if the memory for messages is full. Delete unnecessary messages.

3. Drafts

You can save short messages as draft while creating it.

4. Outbox

Messages successfully sent, not sent and to be sent are saved here.

5. Sent Messages

Messages successfully sent are saved here.

6. Delete messages

You can delete the messages store in **Inbox**, **Drafts**, **Outbox**, **Send messages** and **all messages**.

7. Cell Location Display

Cell Location Display are messages that your network operator broadcasts to all users within a particular area, such as weather forecast, transportation conditions, etc.

Receive mode	Enable or disable the function.
Read message	Scroll to read broadcast messages.

Languages	Set languages for cell broadcast information. Only information in the set language can be received.
Channel settings	Select the channel of cell broadcast.

For more information about available channels and the information they provide, contact your network operator.

8. Message Settings

Set the following settings of short messages.

Profile settings	Set profile name, SMS Center No., validity period and message type.
-------------------------	---

Voicemail server	Set a voicemail number and make a voicemail
Common settings	Enable or disable the delivery report, reply path and Save sent message of short messages.
Memory status	View the memory usage ratio of the SIM card and phone for short messages.
Preferred storage	Set to save short messages to the SIM card or to the phone.
Preferred connection	You can select between Prefer GPRS , Prefer GSM and GSM only .

Set the following settings of Multimedia Message Service (MMS).

Compose	Set how a multimedia message is composed, including creation mode, picture resizing , Best slide duration, auto signature and Signature.
Sending	Set validity period, delivery report, read report, priority, slide timing and delivery time for sending multimedia messages.
Retrieval	Set home network, roaming, read report and delivery report for receiving multimedia messages.

Preferred storage	Set to save short messages to the Memory card or to the phone.
Memory status	View the memory usage ratio, used space and free space for multimedia messages.

7.2 Phonebook

The phone provides two kinds of storage media: SIM card and phone. The phone can store 500 entries. The capacity of the phone book on your SIM card depends on the type of SIM card provided by your network operator.

Enter a number in idle screen and press the OK key to save the number. Select the storage location. Then the edit interface appears. If To SIM1 or To SIM2 is selected, you need to edit the name and number. If

To phone is selected, you need to edit the items that you set in the settings of phone book, including the name, number, email address, caller picture and caller ringtone.

The small icon on the left of the phone book list indicates whether the record is stored on the SIM1 card, the SIM2 card or the phone.

There are the following options if you access the phone book from menu.

View	View the information of the phone number you selected.
Send SMS	Send a text message to the phone number you selected.

Send MMS	Send a multimedia message to the phone number you selected.
Call	Make a call with the number you selected.
Edit	Edit the information of the phone number you selected.
Delete	You can delete the phone number you selected.
Copy	Copy the phone number to phone, to SIM1, to phone,

Move	Move the phone number to phone, to SIM1, to phone,
Send business card	Send the contact via SMS, MMS and bluetooth.
Phonebook Settings	View the memory status. Set the default storage of new numbers. Edit and send your own vCard. Select vCard version. Set speed dial numbers. Set extra numbers. Copy, Move, Delete contacts.

7.3 Call History

In idle screen, press the SIM1/SIM2 Calling key dial key to directly access the call logs of the SIM2/ SIM1.

In idle screen, press the Calling key or go to **Call History > Mssed calls/Daled calls/Rceived calls**, to view the call logs.

Select a call from the list. When the call is displayed, press the calling key to make a call from the SIM1/SIM2 card. Press the LSK or OK key to view the details of the call. Select **Options** for more options.

View	View the call history details.
Call	Dial the selected number.

Send SMS	Send a text message to the phone number you selected.
Send MMS	Send a multimedia message to the phone number you selected.
Save to Phonebook	Save the selected number to the Master SIM card, the Slave SIM card or the phone.
Edit before call	Edit the selected number before establish a call to it.
Delete	Delete the select number from the list.

Delete SIM1 call logs: Delete missed calls,

diald calls or received calls, or delete all.

7.4 Settings

7.4.1 Dual SIM switch

You can select between **Manually selected by user** and **Automatically decided by SIM card**.

7.4.2 Dual SIM settings

Set **Dual SIM open**, **Only SIM1 open**, **Only SIM2 open** or **Flight mode**.

When you are on a flight where the use of mobile phones is prohibited, select flight mode so that the phone will not connect to any network. However, alarm and calendar reminder will remain on. You can still use the entertainment features such as audio player and camera in flight mode.

7.4.3 Phone settings

1. Time and date

Set home city	Set your time zone.
Set time/date	Set the time and the date.
Set format	Set the format for the time and the data.
Update with time zone	<p>This function requires network support.</p> <p>If activated, the time zone is switched automatically to local time by the network.</p>

Auto update time	You can select between Off, First confirm and On.
-------------------------	---

2. Schedule power on/off

Set the time to power on/off the phone automatically.

Warning: In specific areas where the use of phone is prohibited (such as in aero planes), please remember to disable the automatic switch-on function before entering the areas to prevent unexpected accidents.

3. Language

Set current display language.

4. Call settings

1. SIM1 call settings

Call waiting

Activate	If activated, an incoming call is signaled by a call waiting tone when you are on another call. The number/name of the incoming call is displayed.
Deactivate	Cancel the call waiting function.
Query status	Inquire the current status from the network.

Call divert

You can specify the conditions under which

calls should be diverted to your voice mail box or another number.

Divert all voice calls	All voice calls are diverted.
Divert voice calls if unreachable	A voice call is diverted if the phone is switched off or is out of range.
Divert voice calls if no answer	A voice call is diverted if not answered.
Divert voice calls if busy	A voice call is diverted if another call is in progress.

Divert all video calls	All video calls are diverted.
Divert all data calls	All data calls are diverted.
Cancel all diverts	Cancel all call divert settings.

Call barring

Restrict the dialing or receiving of certain calls. To activate or cancel call barring, you have to enter the network password provided by your network operator.

Outgoing calls	If All calls is activated, no calls can be made. If International calls is activated, no international calls can be made. If International calls except to home PLMN is activated, only local calls or calls to the home country (that is, the country to which the network operator belongs) can be made.
-----------------------	---

Incoming calls	If All calls is activated, no calls can be received. If When roaming is activated, you may not receive calls when you are outside your home network.
Cancel all	Cancel all restrictions to calls. Password from your network operator is required.
Change barring password	Change barring password. The original barring password is required.

Line switching

Switch to Line 1 or Line 2.

Note: If you select Line2, whether you can make calls is dependent on the network operator.

2. SIM2 call settings

For the detailed information of SIM2 call settings, please refer to the contents in “**SIM1 call settings**”.

3. Advance Settings:

Auto Redial

Once activated, the phone will automatically redial, if there is no answer for a number you have dialed.

Auto record

All the call you connect will auto record.

Call Time Reminder

If activated, the phone beeps at the interval time you set during a call.

Reject by SMS

If you reject a call, you can select to send a SMS to the caller you reject.

Auto Call Disconnect

Choose whether to activate the auto quick end function, and set the duration.

Answer mode

You can select Any key or Auto answer when headset mode.

5. Pref. input methods

Set input method for text entry.

6. Display

Wallpaper	Set the standby image of the phone. You can select standby image from System or User Defined.
Screen saver	Set the waiting time and image for the screen saver.
Show date and time	If activated, date and time are displayed on the idle screen.
Show owner number	Show or hide the operator number in standby mode.

7. Themes

Select **Theme1,Theme2.**

8. Dedicated key

You can select a function for direction keys from a list.

9. UART settings

You can select between SIM1 and SIM2.

10. Misc. settings

You can set the LCD backlight.

7.4.4 Network settings

It requires network support.

The network that your phone uses is configured automatically. When turned on, the phone automatically connects to the

designated network, or automatically connects to a roaming network when you are outside the coverage of your regular network. When outside the coverage of your regular network, you can manually select the local network system.

1. SIM1 network settings

Network selection

Automatic	The phone will scan for the available network when you are outside the home network.
Manual	The phone will list all networks for you to choose from when you are outside the home network.

Preferred networks

Select the preferred network operator. The default is the network of your SIM card.

2. SIM2 network settings

For the detailed information of SIM2 network settings, please refer to the contents in “**SIM1 network settings**”.

7.4.5 Security settings

The phone provides several codes to protect your phone against misuse.

1. SIM1 security

PIN lock	The SIM1 card is protected against misuse by the PIN code. SIM1 card lock may be set after you enter the PIN code correctly.
Change PIN	Set new passwords for SIM1 PIN.
Change PIN2	Set new passwords, including SIM1 PIN and SIM1 PIN2.

2. SIM2 security settings

For the detailed information of SIM2 security settings, please refer to the contents in “**SIM1 security settings**”.

3. Phone security

If the phone lock is activated, the phone lock password is requested after the phone is switched on. The default password is "0000". If the phone is locked, only emergency calls can be made.

And you can also change the phone password.

4. Auto keypad lock

Keypad lock prevents the inadvertent phone usage. However, you can still be called and you can make emergency calls.

5. Mobile Tracker

Status Setting

You can set On to activated the function.

Recipient Number

You can enter 5 number to receive the

message send by unauthorized person.

M Tracker Message

You can edit the message.

Note: Using this function need password. For safety, Suggest you change default password for your own password (Mobile default password is 0000, please revise instantly password)

7.4.6 Connectivity

Bluetooth

You can connect wirelessly to other compatible devices with wireless Bluetooth technology. Compatible devices may include mobile phones, computers and enhancements such as headsets and car kits. You can use Bluetooth connectivity to send images, video clips, music, sound clips and notes. Since devices with Bluetooth wireless technology communicate by radio

waves, your device and the other device do not need to be in direct line-of-sight. The two devices only need to be within 10 meters (33 feet) of each other, but the connection may be subject to the interference from obstructions such as walls or other electronic devices.

Data account function is used to set account information.

7.4.7 Restore factory settings

Reset the phone to default values (factory settings).

The phone password is required, which is "0000" by default.

7.4.8 Shortcuts

You can set and activated shortcuts.

7.5 Multimedia

6.5.1 Image viewer

Pictures taken can be accessed quickly in **Image viewer**. Select **Options** for available options while viewing pictures.

View	Browse the pictures saved here.
Image information	View the information of the picture you select.
Print	You can print the select image by Bluetooth device.
Browse style	Select List style or Matrix style .

Send	Send the picture as MMS or Bluetooth.
Use as	You can used it as wallpaper, screen saver.
Rename	Rename the picture.
Delete	Delete the picture.
Sort by	Sort the pictures by name, type, time, size or none.
Delete all files	Delete all the pictures saved here.
Storage	Set the storage location of the picture.

7.5.2 Video recorder

Video recorder allows you to record video files. Press Ok key to record/pause. Press Left Soft key to set the relation parameter. Press right soft key to stop/exit player. Use navigation left /right key to zoom out or zoom in.

7.5.3 Video player

Video player allows you to browse or process video recording files. Press Ok key to play/pause. Press right soft key to stop/exit player. Use navigation left /right key to control the movie playing progress and use up /down key to control volume. Press “*” key to play in full screen.

7.5.4 Sound recorder

Your phone supports two kinds of recording formats: AMR, WAV. Select a format from

Settings in Options. A call may also be recorded and saved to the phone or the memory card.

7.5.5 FM radio

This option allows you to listen to FM radio.

Channel list	Edit channel list.
Manual input	Input the channel manually.
Auto search	Set automatic searching for channels.
Settings	Set background play, loud speaker and record information.

Record	Record the FM programs.
Append	Record the FM programs and add the old one.
File list	View the recorded file list.

7.6 Fun & Games

Games

The phone provides **Magic Sushi**. Read **Help** to know how to play the game. You can set BGM, sound effect , games vibration and volume by **Games settings**.

7.7 Camera

The phone is provided with a built-in 1.3 mega pixel CMOS camera at the back, which supports the photographing and video shooting functions. Pictures are saved in the file system of the phone. The file is in the *.jpg format. You can send the pictures taken by the MMS/Bluetooth function provided by the phone.

While in camera mode, press the LSK to set the camera. Then save the settings. Aim the camera lens at the place/object, and then press the OK key to take a photo. Keep the camera lens steady for a while for the image quality. After photographing, the still scenery just taken is displayed on the screen.

Photos	View the saved pictures.
---------------	--------------------------

Camera settings	Set Shutter sound, EV, Contrast, Anti-flicker, Delay timer of the camera.
Image settings	Set image size and image quality.
White balance	Set light condition.
Scene mode	Select pre-defined settings for the current environment.
Effect settings	You can select a effect form a list.

Storage	Set the storage location for photos.
Restore default	Restore the default settings of camera.

7.8 Audio player

Audio player allows you to play audio files.

The phone supports T-Flash memory card. You need to save downloaded music files to directory **My Music**, so that they can be played normally.

Play	Play the music files
-------------	----------------------

Details	Check the details of music files
Refresh list	Refresh the list of music files.
Settings	Settings include Pre. playlist, List auto gen., Repeat, Shuffle, Background play, Bluetooth settings

7.9 User profiles

The phone is provided with six pre-defined user profiles that allow the operations of the phone to best suit the environment you are in. The profiles are **General**, **Meeting**, **Outdoor**, **Silent**, **My style** and **Save**

Power.

Note: To activate the Silent profile, go back to the idle screen, press and hold the # key until the phone gives you a prompt.

You can customize the following options for new profiles.

Alert type	Four types of Ring only , Vib. only , Vib. and ring and Vib. then ring are available for your selection.
Ring type	Three types of Single , Ascending and Beep once are available for your selection.

SIM1 incoming call	You can select a tone from a list to set as SIM1 incoming call.
SIM2 incoming call	You can select a tone from a list to set as SIM2 incoming call.
Ringtone volume	You can set the volume of ring.
SIM1 message	You can select a tone from a list to set as SIM1 message .
SIM2 message	You can select a tone from a list to set as SIM2 message.

keypad	You can select tone or click.
Message volume	You can set the volume of message.
Keytone volume	You can set the volume of keytone.
System alert	You can activate it.

6.10 Organizer

6.10.1 Calculator

1. Enter the amount to be calculated.
Press the # key to enter decimal

- points.
2. Use navigation keys to operate and OK key to get the result.

6.10.2 Calendar

You can enter events in the calendar.

In the calendar interface, press the up and down direction keys to scroll to different weeks, and press the left and right direction keys to scroll to different days.

View	View or edit event memos for the day.
View all	View all the event memos.
Add event	Add event memos.

Delete event	Delete the selected event.
Jump to date	Enter a specific date to be located and the cursor will jump to the date quickly.
Go to today	Jump to today.
Go To weekly View	Go to weekly view
Settings	You can switch to Indian or English calendar to view the data.

6.10.3 Tasks

If activated, the phone rings as a reminder when the set time arrives. You can view, add, edit and delete task if required.

6.10.4 Alarm

You can set five types of alarm clock time if required. Then the alarm icon will be displayed on the idle screen.

Scroll to an alarm and select **Edit** for settings. You can set whether to enable the alarm, the ring time, ring mode, audio options, snooze minutes and alert type.

6.10.5 World clock

You can check the current local date and time of major cities in the world.

6.10.6 Currency converter

1. Set the exchange rate and confirm with the OK key.
2. Enter the amount to be converted in **Local**. Confirm with the OK key. The amount in the other currency is displayed in **Foreign**.

6.10.7 Stopwatch

You can measure times, for example, for a sports game. The phone provides the following two types of stopwatches.

Typical Stopwatch	The functions of Split timing , Lap timing and View record are provided.
--------------------------	---

nWay Stopwatch	Press direction keys to start stopwatch. The total time is displayed on the top of the screen. Press and hold the left soft key to reset.
---------------------------	---

7.11 Services

7.11.1 STK

STK is shown only if it is provided by your SIM card. For further details, please contact your network operator.

7.11.2 Internet Services

With the Internet service function, you can use the phone to surf the Internet.

Homepage	Connect browser to a homepage you set.
Bookmarks	The phone displays a list of stored bookmarks. To add a page to bookmarks, go to Bookmarks > Options > Add bookmark.
Input address	Enter the URL for direct connection to an Internet address.
Recent pages	The phone displays the recently-visited pages.

Settings	Set the browser settings, including Homepage, Select Profiles, Data account, Brower options and Preferences .
-----------------	---

7.12 File manager

You can use **File manager** to organize your files in folders.

If a memory card is inserted, the files stored on it are organized separately.

Select **Phone** or **Memory card** and select **Options** for more option.

8. Appendix I Troubleshooting

If you encounter problems while using the phone, or if it performs erratically, you can consult the information in the following table. If a particular problem cannot be resolved by using the following information, contact the dealer where you purchased the phone.

Problem	Possible causes	Possible solution
----------------	------------------------	--------------------------

<p>Poor reception</p>	<p>The network signal is too weak at your current location, for example, in a basement or near a tall building, because wireless transmissions cannot effectively reach it.</p>	<p>Move to a location where the network signal can be properly received.</p>
-----------------------	---	--

	<p>The network is busy at the current time, for example, during peak times, because there may be too much network traffic to handle additional calls.</p>	<p>Avoid using the phone at such time, or try again after waiting a short time.</p>
--	---	---

	<p>You are too far away from a base station for your service provider.</p>	<p>You can request a service area map from your service provider.</p>
<p>Echo or noise</p>	<p>Poor network trunk quality on the part of your service provider.</p>	<p>Press the End key and dial again. You may be switched to a better-quality network trunk or phone line.</p>

	Poor local telephone line quality	Press the End key and dial again. You may be switched to a better-quality network trunk or phone line.
Battery will not charge.	The battery or battery charger is damaged.	Contact the dealer.

	The temperature of the phone is below -10°C or higher than 55°C .	Adjust the battery charging environment to avoid extremes of temperature.
	Poor contact between the battery and charger.	Check all connectors to make sure all connections have been properly made.

<p>Shortened standby time</p>	<p>The standby time is related to your service provider system configuration. The same phone used with different service providers' systems will not provide exactly the same length of standby time.</p>	<p>If you are located in an area where signaling is weak, temporarily switch off the phone.</p>
-------------------------------	---	---

	<p>The battery is depleted. In high temperature environments, battery life will be shortened.</p>	<p>Use a new battery.</p>
--	---	---------------------------

	<p>If you are not able to connect to the network, the phone will continue to send out signals as it attempts to locate a base station. Doing so consumes battery power and will consequently shorten standby time.</p>	<p>Change your location to one where the network is accessible, or temporarily turn off your phone.</p>
--	--	---

You cannot switch your phone on.	Battery power has been depleted.	Recharge the battery.
SIM card error	SIM card malfunction or damage	Take the SIM card to your service provider for testing.
	SIM card is inserted improperly.	Insert the SIM card properly.

	Debris on the SIM card contacts	Use a soft and dry cloth to clean the SIM card contacts.
Unable to connect to the network.	SIM card invalid.	Contact your service provider.
	You are not within the service area of the network.	Check the service area with your service provider.

	Poor signal.	Move to an open space, or if you are inside a building, move closer to a window.
--	--------------	--

<p>You cannot answer incoming calls.</p>	<p>You have activated the call barring feature.</p>	<p>Go to Settings > Phone settings > Call settings > SIM1/SIM2 call settings > Call barring, and then select Cancel all.</p>
--	---	--

<p>You cannot make outgoing calls.</p>	<p>You have activated the call barring feature.</p>	<p>Go to Settings > Phone settings > Call settings > SIM1/SIM2 call settings > Call barring, and then select Cancel all.</p>
--	---	--

<p>PIN Code is blocked.</p>	<p>You have entered an incorrect PIN code three consecutive times.</p>	<p>Contact your service provider. If the service provider provides the PUK code of the SIM card, use the PUK code to unlock the SIM card.</p>
<p>Unable to enter information into the phone book.</p>	<p>The memory of the phone book is already full.</p>	<p>Delete unnecessary data from the phone book.</p>

<p>Unable to select certain features.</p>	<p>Your service provider does not support these features, or you have not applied for services that provide these features.</p>	<p>Contact your service provider.</p>
---	---	---------------------------------------

9. Appendix II Abbreviations and Explanation

GSM	Global System of Mobile Communication
GPRS	General Packet Radio Service
SMS	Short Message Service
WAP	Wireless Application Protocol
FDN	Fixed Dialing Numbers
SIM	Subscriber Identity Module
PIN	Personal Identification Number

PUK	Personal Unblocking Key
IMEI	International Mobile Equipment Identity
MCC	Mobile Country Code
MNC	Mobile Network Code
Call waiting	A service provided by the network, which allows you to answer another incoming call without interrupting the active call, but it is different from conference call. You can only talk to one party while another party is held at the same time.

Call divert	A service provided by the network, which allows you to divert an incoming call to a specified number according to different circumstances.
Roaming	The phone is not used in the area of its local registered network. It includes international and domestic roaming. In this manual it refers to international roaming only.
STK	SIM Toolkit

10. Appendix :List of Accessories in Packing Box

One mobile phone

One battery

One charger

One headset

One data cable

One user manual

11. Service Center List

Maharashtra: Mumbai-Andheri
32945199/26878136 / 8137/ 4879/
26874891/ 9324102119
Mumbai-Chembur
32937984/25241984/ 9323786625
Mumbai-Borivali 9867643695/
28697754 / 28697802 /9867643695 /
9323724415 Mumbai-Goregaon
9324721942 / 28764605 /
28791499/9892530953
Mumbai-Lalbaug 9869230643/
24714300 / 64517177 / 9869230643
Thane 25470806 / 9322192400 /
25421948 / 9323724463 Kalyan
3209470/ 2327060/ 9324451953
Vasai 2334089 / 90/9323698399

Vashi 27827503/27827583 /
 9821716724 Vasai 6451455/
 9967905543 Kalyan 3212075/
 9323294772 Nagpur 3248461/65 /
 9373599205 Nagpur – South
 2222366 / 6460366/ 9372425958
 Amravati 3297767/ 9326280099
 Chandrapur 277166 / 9372277166
 Akola 6418348 / 9326450488 Pune
 32931959/ 2605 4770/
 40078356 / 9372497877
 AhmedNagar 2425877/ 9325606919
 Pune NEW Wanawadi 40052177 /
 40090377 / 9371205077
 Pune-Kothrud 25461876 /
 9371205077 Solapur 3294758
 /2723711 / 9370454570 Pimpri /
 Chinchwad 27485173/ 9890968052
 Panaji - North Goa 222 2736 / 222

1099 / 222 8295 / 9325551233
Madgaon - South Goa
3259391 / 9326797265
Kolhapur 2462325/ 9371225633
Sangli 3298587 / 2322 242 /
9370820104 Ratnagiri 321683 Satara
284351 / 9370820104 Aurangabad
3252656 / 9372369399
Aurangabad 6992444 / 9922681232
Nasik 3200775/ 6524123 / 578524
9372422890 Jalgaon 3206670 /
3204257/ 232368 / 9370730985
Nanded 325025 / 321253
/9325084880

Karnataka: Bangalore- Indiranagar
32928265/ 9341033739 /Bangalore -
Rajaji Nagar 23122672 / 23125245
9916908103 Bangalore -

Jaynagar 26577409 / 26576274 /
9916908046 Bangalore Radial CRC
25438796 / 25438795
9902732891 Mysore CRC
3206473 / 2463437 / 9341255959
Kolar 401445 / 9844405543
Mangalore 3255339 / 2411210 /
9341880107 Mangalore 2414924 /
2415445 Hassan 266606 Udupi
2532810/ 2532830 Shimoga 277391/
226846 Hubli 3298808 / 2214814 /
2288712 / 9341680104 Gulbarga
324327 / 275816 / 9886628723
Raichur 231311 / 9886628723
Davangere 325765 / 233982 /
253585 / 9449629481 Bellary
277826 / 9449629481 Belgaum
3295249 / 2424095 / 2469139 /
9342306934 Bijapur 2255278 /

9342306934

Tamil Nadu : Chennai 32961651 /
 28330220 / 9381144102 Chennai
 – Adyar 24525067 Chennai -
 Tambaram 22413334 Chennai –
 Avadi 26558118 Chennai –
 Tondairpet 25913350 Chennai –
 Valasarawakam 24865500 Chennai –
 Kilkattalai 22475300 Pondicherry
 3296177 / 2342467/ 2348856 /
 2222368 / 9344444112 Cuddalore
 324566 /236677 / 223105
 /9345344108 / Vellore 2235946/
 2235964/ 4203946 / 9894600218
 Chennai – Radials 32973243 /
 32973244 / 9381144118
 Kanchipuram 67270964
 Tiruvannamalai 250761 / 254167

Madurai 3259062 / 2533 033/
6543001/ 6543002 / 9360044103
Tirunelveli 3291831/ 2331731/
2331831/ 2331901/ 9367944111
Nagercoil 234362 / 234372 /
9381251696 Trichy 2775133 /
2770433 / 9345144120 Dindigul
2433747 / 9344678809 Thanjavur
271729 / 271297 9360318839
Madurai 2604340 / 2600529 /
9360044116 Karaikudi 227939/ 40 /
9360009802 Puddukotai 320441
Coimbatore 3258032/ 252 7314 /
3250431/ 243 3340 / 244 3482/
93448 44117 / 93448 44104 Salem
3048090 /244 9525 / 244 3237 93444
44113 Erode CRC 222 7211 / 222
7201 / 93622 27201 Karur 259 295
/ 234 295 / 9367155286 Pollachi

325756/ 231796 Tiruppur 223 4526 /
223 0407 93443 44110

Andhra Pradesh: Hyderabad
32935964 Secunderabad 27840126 /
9885579039 Kukatpally 23161296 /
9885569764 Malakpet 24547649/
9885578329 Kurnool 278510 /
9393840105 Tirupathi 2286867/
6563377 /9391724389 Karimangar
2230947 / 9290077307 Nizamabad
550115 / 9347240104 / Godavri
Khani 932444204 Ameerpet
32495566 / 62615566 /
9246509614 Nellore 9393667793
Godavari Khani 243123 /
9849262806 Warrangal 2454951 /
9885850002 Mahabub Nagar
253475/ 9849412435

Ananthapur 227801/ 9346235756
Proddatur 248844 / 9849655619
Vijaywada 3299410 / 2438681 /
6536040 / 9397840107 Vizag
3296423 / 2598 463/ 6533825 /
9394240111 Rajahmundry 6663873 /
2443873 / 9393940112 Guntur
3252223 /2233006/ 9396402716
Vizianagaram 9246492177 Eluru
9246492177 Bhimavaram
9246492177 Ongole 9246492177
Tenali 9246492177 Khammam
9246492177 Kakinada 9290624383

Kerala: Cochin 3259353/ 3988900 /
2357 536 / 2357 440 / 9388648410
Calicut 3942114 / 2740 858 / 2743
502 / 9349748417 Vadagara 2522502
/ 9947033220 Malapuram 3298228/

2730125 /9947033228 Kannur
 3292681 /2766 581 / 2711733 /
 9349748416 Payannur 325456/
 201/742/209/511/ 9446005231
 Thalassery 3205179/ 2322152 /
 9446005225 Trivandrum 2465 426 /
 2462 924 / 9349348418
 Balarampuram 2409010 / 2409238 /
 9947030083 Attingal 2629368/
 9947030088 Kottayam 3292651 /
 2575 446 / 2575 336 / 9947031631
 / 9349948420 Kattappana 273255 /
 9947031643 Thodupuzha 220355 /
 9947031644 Trichur
 3296725 / 3249666/ 2337667 /
 9349848419 Kollam 3963666 /
 2765 721 / 2743 701/ 9387008421
 Pathanamthitta 2231450 /
 9349996332 Alleppy 3255001 /

2267065 / 9388899449 Perumbavur
2520099 / 2590099/ 9388405846
Aluva 6520208/ 2620208/
9387171000 Palakkad 938883883
Mavelikara 3290222 / 9995154512
Tirur 9847425151 Irinjalakuda
3291515 / 2830796 9387301515
Gujarat: Ahmedabad 32942148
/26422176/ 26422174/ 26440505/
26422175 / 30028232 / 9925236541 /
9998082070 Gandhinagar
32900501/ 23243747 / 9925236511
Bhavnagar 2522523 / 9925236555
Rajkot 3204919/ 2454783
Gandhidham 323070 / 9327314443
Mehsana 254573 / 9825477439
Jamnagar 9924047076 Baroda
3253267 /2786041/42/43/45 Surat
3018652 /2465633 / 34 /9825979998

Surat 9824172114

Madhya Pradesh: Indore 3249000/
3241043 / 2530 146 / 679 / 126 /
9302473112 Gwalior 3240900/
2428513 /9300773115 Ujjain
3240900 / 2525921 /
9301508801 Ratlam 324490 /
230235 / 9329435055 Bhopal
3240900 / 2558192 / 9301373113
Jabalpur 3240900 / 2450621 /
9303373114 Rewa 256491 /
9893974910 Balaghat 247652 /
9425139552 Itarsi 235222
/9981207108 Dewas 220005
/9893064949 Sagar 329951/ 2392086
/ 9329414144

Rajasthan: Jaipur 3206300 / 3245484

/ 5101951/ 5116601 / 5116602 /
5116603 /9314914110 Ajmer
3291084 / 2632548 / 9352214113
Kota 5100137 / 9314412303 Jodhpur
3253809/ 2440413 / 2622366 /
2633449 / 9314714116 Pali 320900 /
256370 / 9352916107 Udaipur
3297675 / 2411548 / 2417182 /
9314414112 Bikaner 3295324 /
2525425 / 2201958 / 9351658717
Ganganagar 2476195 / 9252524717/
9784866246 Bhilwara 307054 /
9214966006/ 9829142360 Sikar
253645 / 9214177130 Alwar
5120630 / 9351372508
Punjab & Himachal Pradesh:
Ludhiana 9316404203 / 9317617216
/ 98888904201 Chandigarh
2714614/ 2703248 Bhatinda

2254265 / 5012075 Patiala 3255432
/ 2205603 Jalandhar 3245432 /
2225891 / 2235488 Amritsar
3245432 / 2530349 Hoshiarpur
245508 Pathankot 2254182
Kangra 9816944028 / 9218922881
Shimla 2655136 / 9816046016 Bhota
9817109838

Jammu & Kashmir: Jammu
2562258 / 9906037727 / 9906026170
/ 9906020854 Srinagar 2481083 /
9419006964 / 9906303093

Haryana: Karnal 3295237 / 3293794
2220525 / 2220725 / 2220825 /
9354717310 / 9355956700 Ambala
3296270 / 4006270 /
93158-59018 Rohtak 250335 /

9315430724 Faridabad 3297290
4050637 Gurgaon 3240134 /4202835
/ 93135-95193 / 9313940390 Panipat
4006498 / 9315430718 Hisar
9896111603 Hisar 9896111603
Bhiwani 9812244146 Fatehabad
220668 / 9812114637 Sonipat
9815900579 Kurukshetra 652172
/ 92541017528 Jind 9812175001

Delhi: South Delhi 32449736/
2694 48 - 26 / 34 / 43 / 24 / 42 / 8822
/ 3843 / 46028228 / 9350852821 /
9350852822 /
9313572659/9350414121 East Delhi
65656240 / 41 / 9350595643/
9350595658 / 9810841314 West
Delhi 65656239 / 9313363012 /
9350852813 North Delhi 2745 5617 /

2663 / 9350593596 / 9350852822

Uttar Pradesh Lucknow 3252284/
 3225340/232 3306/ 232 3044/
 2335764/ 9336848973/ 336848974
 Kanpur 3265005/
 3264550/2540581/9935769322
 Faizabad 320808/ 241314
 9415061089/ 9335029940/ Nirala
 2786530 /4066249 / 9839173503
 Kanpur / 9336337575
 /9919237575 / 9415062345/
 9336866999 Kanpur 9415062345/
 9336866999 Lucknow 9335030333/
 9305461689 Jhansi 9415502608,
 9936674704 Raibareilly
 9335671666/9415082635
 Varanasi 3298538/ 2224560 /
 2227704 09336847755 Gorakhpur

3293222/2346126/9335029936

Allahabad 3296888/ 2260768/

9336847754 Allahabad 2427080/

9450542506 Mahmooorganj

2225135/9935758360 Ghaziabad

3263207/3223868/4104981/9313171

608 Bareilly 3256600/ 2302688/

9837554885 Meerut 3254424/

2640296 /9385312016 / 9319604400/

9319604400/

9319604400/9319604400 Noida

3229094/ 3228483/ 4267157/

9313171607 Saharanpur 9760363770

MuzafferNagar 897363001/

9897363001 BulandShahar

9358713434/ 9358713434 Bijnor

9335348707/ 9335348707 Bareilly

Moradabad 9319963000/

9319963000 Agra 3256033 /

3202045/2523067/ 9336847763 Agra
205995/ 9336847761

Etah 309527/9358085588 Mathura
3298208/9319338400 Kasaganj
9319878333/ 9219986444

Uttaranchal: Dehradun 3250544/
2650916/ 9336618068 Haldawani
326300/ 282462/ 9336847756

Chattisgarh: Raipur 3240900/
4074325/ 9329570731/ 4074326/
3203435/ 4069176 Korba
320090/245857/9301321361 Bhilai
3940900/ 4050700 / 9301321362
Rajnandgaon 9329551000

West Bengal: Kolkata South - New
Alipore 32426424/ 24007951/
24007952 / 24007953/

24009999/8322/09330913133/09830
537820/09433460983/09836038804
Kolkata North – Saltlake
2426425/6431/22896221/22896192/2
2896193/ 9339733104/
9433522575/ 9339310761 Asansol
2280978/9433522574 Siliguri
2525722/ 2525721/ 9434130296/
9338078401/ 9434178876
Barrackpore (24PG North)
9332066199 Garia (24 PG South)/
24367528/ 9339772596 Murshidabad
274691/ 9232473594/ 9333194352/
9434743675 Nadia 9332656601
Burdwan 2542387/ 9332100554/
9332233901 Durgapore 3290954/
3208585/ 9332800271

Assam: Guwahati 2413138 /
2413158/09435044420/9954890168
/9864116390 Jorhat 2309008/
9435091567 Guwahati
09864408750/ Tinsukia 2337512/
09864052167

Orissa: Bhubaneshwar
0674-3299315/2530449/
2573439/09338167410 /
9338167416/ 9338167411
Rourkela 3295442/2507092/
9337467417 Cuttack 3254442/
2331122/ 9337167412 Sambalpur
3295442/ 2404871/ 9338967419
Behrampur / 3295442/ 2221574/
9338967414 Balasore 329442 /
241348/9338367415
Bihar: Patna 3252513 / 3259715 /
16/2261 071/09334461210 /

9234611210/ Muzaffarpur 2247221/
9334061211 Gaya
2432863/9334140303 Bhagalpur
2409473/ 9431383711 Arrah
2409473/ 9304386630
Jharkhand: Ranchi
3299585/2341049/9334465110
Jamshedpur 3205008/2432464/
9334173951/ 9334133359
Hazaribagh 9431366644 Dhanabd
9234411586



ONIDA

Customer's Warranty Card

Details

Customer's Name: _____

Address _____

Dealer's Name _____

Dealer Address & Stamp _____

Model: _____

Date of Purchase: _____

Date of Expiry of Warranty _____

Please paste the IMEI sticker in the space provided below, the Warranty of your handset is based on the same, so keep the form in a safe place

MIRC ELECTRONICS LTD provides this Limited Warranty to person who has purchased the ONIDA mobile phone and original accessory delivered with your mobile phone.

1.The warranty period for the transceiver for 1 year, battery & charger for 6 months is from the date of purchase of the product.

2.The warranty does not cover external housing and cosmetic parts.

3.MIRC ELECTRONICS LTD warrants to you that during the warranty period MIRC ELECTRONICS LTD or a MIRC ELECTRONICS LTD authorized service network will repair or replace, at MIRC ELECTRONICS LTD option, any defective product, or parts thereof, with new or factory rebuilt replacement items, and return the product to the consumer in working condition. No charge will be made to the consumer for either parts or labour in repairing or replacing the product. All

replaced boards or equipment shall become property of MIRC ELECTRONICS LTD.

4. The warranty in respect of a repaired or replaced product/part shall extend for the remaining warranty period of the repaired product or replacement thereof to the consumer

5. Upon request from MIRC ELECTRONICS LTD or its authorized service center, the consumer must provide the purchase receipt or other documentation or information in respect of the date and place of purchase.

6. The consumer shall have no coverage or benefits under this warranty in the event that any of the following conditions are applicable.

- The Product has been subject to abnormal use or conditions, improper storage, exposure to excessive moisture or dampness, exposure to excessive moisture or dampness, exposure to excessive

temperatures, unauthorized modifications, unauthorized repair including but not limited to use of unauthorized spare parts in repairs abuse, accident, Acts of God, spills of food or liquids, maladjustment of customer control and breakage or damage to antenna.

- MIRC ELECTRONICS LTD has not been notified by the consumer of the defect in the product during the applicable warranty period.

- The product serial number or the accessory date code has been removed, defaced or altered.

- The defect or damage caused by defective function of the cellular system or by inadequate signal reception by the external antenna.

- The product has been used with or connected to an accessory not supplied by MIRC ELECTRONIC LTD, not fit for use with ONIDA mobile phones or used in

other than its intended use.

- The seals of the product's battery enclosure have been broken or show evidence of tampering or the product's battery has been used in equipment other than that for which it has been specified.

7. In order to derive the benefits of this warranty, the consumer should follow the following procedure.

- The consumer shall return the product to place of purchase for repair or replacement.

- The consumer may contact local MIRC ELECTRONICS LTD office for the nearest authorized service center.

- The consumer shall arrange for the product to be delivered to the authorized service center.

- The consumer will be billed for any parts or labour charges not covered by this warranty. The consumer shall

be responsible for expenses related to
reinstallation of the product.



ONIDA