

# FlexRay ASSP MB88121B User's Manual



# **FlexRay ASSP MB88121B User's Manual**

**FUJITSU LIMITED**



# PREFACE

## ■ Purpose of this document

Thank you for reading about this Fujitsu semiconductor device.

The MB88121B is a controller that performs FlexRay communications in accordance with the FlexRay Protocol Specification Version 2.1.

This document is for engineers who are developing products that use the MB88121B, and explains the registers, functions, and operation of the MB88121B. Read through the entire manual.

## ■ Trademark

FlexRay is a registered trademark of DaimlerChrysler AG.

The company names and brand names herein are the trademarks or registered trademarks of their respective owners.

## ■ Reference Documents

FlexRay Communications System Protocol Specification Version 2.1 (FlexRay Consortium)

## ■ Overall structure of this document

This document consists of the following chapters.

### CHAPTER 1 MB88121B

This chapter explains the features and basic specifications of the MB88121B.

### CHAPTER 2 FlexRay

This chapter explains the functions and operations of FlexRay.

### APPENDIX

These appendices explain the I/O registers and configuration parameters.

- The contents of this document are subject to change without notice.  
Customers are advised to consult with FUJITSU sales representatives before ordering.
- The information, such as descriptions of function and application circuit examples, in this document are presented solely for the purpose of reference to show examples of operations and uses of FUJITSU semiconductor device; FUJITSU does not warrant proper operation of the device with respect to use based on such information. When you develop equipment incorporating the device based on such information, you must assume any responsibility arising out of such use of the information. FUJITSU assumes no liability for any damages whatsoever arising out of the use of the information.
- Any information in this document, including descriptions of function and schematic diagrams, shall not be construed as license of the use or exercise of any intellectual property right, such as patent right or copyright, or any other right of FUJITSU or any third party or does FUJITSU warrant non-infringement of any third-party's intellectual property right or other right by using such information. FUJITSU assumes no liability for any infringement of the intellectual property rights or other rights of third parties which would result from the use of information contained herein.
- The products described in this document are designed, developed and manufactured as contemplated for general use, including without limitation, ordinary industrial use, general office use, personal use, and household use, but are not designed, developed and manufactured as contemplated (1) for use accompanying fatal risks or dangers that, unless extremely high safety is secured, could have a serious effect to the public, and could lead directly to death, personal injury, severe physical damage or other loss (i.e., nuclear reaction control in nuclear facility, aircraft flight control, air traffic control, mass transport control, medical life support system, missile launch control in weapon system), or (2) for use requiring extremely high reliability (i.e., submersible repeater and artificial satellite).  
Please note that FUJITSU will not be liable against you and/or any third party for any claims or damages arising in connection with above-mentioned uses of the products.
- Any semiconductor devices have an inherent chance of failure. You must protect against injury, damage or loss from such failures by incorporating safety design measures into your facility and equipment such as redundancy, fire protection, and prevention of over-current levels and other abnormal operating conditions.
- If any products described in this document represent goods or technologies subject to certain restrictions on export under the Foreign Exchange and Foreign Trade Law of Japan, the prior authorization by Japanese government will be required for export of those products from Japan.

# CONTENTS

<b>CHAPTER 1</b>	<b>MB88121B</b>	<b>1</b>
1.1	Features	2
1.2	Block Diagram	3
1.3	Package Dimensions	7
1.4	Pin Assignment	8
1.5	Pin Functions	11
1.6	I/O Circuit Types	18
1.7	Notes on Handling Devices	19
1.8	I/O Map	21
<b>CHAPTER 2</b>	<b>FlexRay</b>	<b>27</b>
2.1	Overview of FlexRay	28
2.2	Block Diagram of FlexRay	30
2.3	Configuration of FlexRay	33
2.3.1	Customer Registers	35
2.3.2	Special Registers	45
2.3.3	Interrupt-related Registers	46
2.3.4	Communication Controller (CC) Control Registers	61
2.3.5	Communication Controller (CC) Status Registers	78
2.3.6	Message Buffer Control Register	92
2.3.7	Message Buffer Status Register	97
2.3.8	Identification Register	108
2.3.9	Input Buffer	110
2.3.10	Output Buffer	117
2.4	FlexRay Operations	127
2.4.1	DMA Operations	138
2.4.2	SPI Bus	141
2.5	SPI Protocol Definition	144
2.5.1	Data Security Algorithm	153
2.5.2	SPI Status Output	155
2.6	FlexRay Controller Clock	158
2.6.1	FlexRay Controller Clock Control Procedure	160
2.6.2	Setting Example of the FlexRay Baud Rate	162
2.7	FlexRay Protocol Function	163
2.7.1	Communication Cycle	164
2.7.2	Communication Mode	167
2.7.3	Clock Synchronization	168
2.7.4	Error Handling	170
2.7.5	Communications Controller States	172
2.7.6	Network Management	187
2.7.7	Filtering and Masking	188
2.7.8	Transmission Procedure	192
2.7.9	Reception Procedure	195

2.7.10	FIFO Function .....	197
2.7.11	Message Handling .....	200
2.7.12	Message RAM .....	209
2.7.13	Interrupt .....	216
<b>APPENDIX</b>	<b>.....</b>	<b>219</b>
APPENDIX A	I/O Registers .....	220
APPENDIX B	Configuration Parameters .....	239
<b>INDEX</b>	<b>.....</b>	<b>243</b>

## Main changes in this edition

Page	Changes (For details, refer to main body.)
-	First edition



# **CHAPTER 1**

---

# **MB88121B**

**This chapter explains the features and basic specifications of the MB88121B.**

- 1.1 Features
- 1.2 Block Diagram
- 1.3 Package Dimensions
- 1.4 Pin Assignment
- 1.5 Pin Functions
- 1.6 I/O Circuit Types
- 1.7 Notes on Handling Devices
- 1.8 I/O Map

## 1.1 Features

---

**This section explains the features of the MB88121B.**

---

### ■ Features

The FlexRay controller has the following features.


- FlexRay specifications
  - Supports version 2.1 of the FlexRay specifications
- Provides up to a maximum of 128 message buffers
- 8 Kbytes of message RAM
  - When the data section is 48 bytes, Maximum of 128 message buffers
  - When the data section is 254 bytes, Maximum of 30 message buffers
- Provides variable length message buffers
- Each message buffer may be configured as a transmit buffer, receive buffer, or part of the receive FIFO
- Host access to message buffers via an input buffer and an output buffer
  - Input buffer: Stores a message to be transferred to message RAM
  - Output buffer: Stores a message that has been read out from message RAM
- Filtering by slot counter, cycle counter, and channel
- Each channel has a maximum bitrate of 10 Mbps
- Maskable interrupts
- 4 MHz / 5 MHz / 8 MHz / 10 MHz external oscillator circuit input
- Supports external clock input
- CPU interface:
  - 16-bit non-multiplexed parallel bus
  - 16-bit multiplexed bus
  - SPI interface
- Output lines for requesting DMA transfers
- Single 5V power supply
- Single 3.3V power supply

## 1.2 Block Diagram

This section shows the block diagram of the MB88121B.

### ■ Block Diagram of the MB88121B

Figure 1.2-1 Block Diagram of the MB88121B



## ■ Functional Description of Each Block

### ● CPU Interface (CIF)

Connects the host CPU to the FlexRay controller.

### ● Input Buffer (IBF)

Used to write to the message buffers in the message RAM.

The host CPU can write the header section and data section from the input buffer to a specific message buffer.

The message handler transfers data from the input buffer to the selected message buffer in message RAM.

### ● Output Buffer (OBF)

Used to read from the message buffers in the message RAM.

The message handler transfers data from the selected message buffer to the output buffer.

Once the data transfer is complete, the host CPU can read the header section and data section of the message buffer that was transferred from the output buffer.

### ● Message Handler (MHD)

The message handler controls the data transfers between the following components.

- Input/output buffer and message RAM
- The transient storage buffer RAM of the two FlexRay protocol controllers and message RAM

### ● Message RAM (MRAM)

The message RAM is composed of single-port RAM that is able to hold the configuration data for the built-in FlexRay message buffers (max. 128).

### ● Transient Buffer RAM (TBF A/B)

Stores the data sections of two messages.

### ● FlexRay Channel Protocol Controller (PRT A/B)

The FlexRay channel protocol controller is composed of a shift register and a FlexRay protocol FSM.

The protocol controller provides the following functions.

- Checking and controlling bit timings
- Receiving and transmitting FlexRay frames and symbols
- Checking the header CRC
- Generating and checking frame CRC
- Connecting to the bus driver

In addition, protocol controller block is connected to the following blocks.

- Physical layer (bus driver)
- Transient storage buffer RAM
- Message handler
- Global time unit
- System universal control
- Frame and symbol processing
- Network management
- Interrupt control

### ● Global Time Unit (GTU)

The global time unit provides the following functions.

- Generating microticks
- Generating macroticks
- Fault tolerant clock synchronization using the FTM algorithm
  - Rate correction
  - Offset correction
- Cycle counter
- Dynamic segment (microslot) timing control
- Support for external clock correction

### ● System Universal Control (SUC)

The system universal control controls the following functions.

- Configuration
- Wakeup
- Startup
- Normal operation
- Passive operation
- Monitor mode

● Frame and Symbol Processing (FSP)

Frame and symbol processing controls the following function.

- Checking that the timing of frames and symbols is correct
- Testing the syntactic and semantic validity of received frames
- Setting the slot status flag

● Network Management (NEM)

Sets the handling of the network management vector

● Interrupt Control (INT)


The following functions are available for controlling interrupts.


- Provision of error and interrupt flags
- Controlling the enabling/disabling of interrupt sources
- Controlling the allocation of interrupt sources to the two interrupt lines of the module
- Enabling/disabling the two interrupt lines of the module
- Managing the two interrupt timers
- Halting the capturing of watch times

# 1.3 Package Dimensions

This section shows the package dimensions of the MB88121B.

## ■ Package Dimensions

 <p>64-pin plastic LQFP</p> <p>(FPT-64P-M03)</p>	Lead pitch	0.50mm
	Package width × package length	10.0×10.0mm
	Lead shape	Gullwing
	Sealing method	Plastic mold
	Mounting height	1.70mm MAX
	Weight	0.32g
	Code(Reference)	P-LFQFP64-10 × 10-0.50



See the following URL for details on the latest package dimensions.  
<http://edevice.fujitsu.com/fj/DATASHEET/ef-ovpklv.html>


## 1.4 Pin Assignment

This section shows the pin assignment of the MB88121B.

### ■ Pin Assignment


- 16-bit non-multiplexed mode (MD2="H", MD1=MD0="L", MDE2="H", MDE1="H" or "L", MDE0="L")

Figure 1.4-1 Pin Assignment for 16-bit Non-multiplexed Mode




- 16-bit multiplexed parallel mode (MD2="H", MD1=MD0="L", MDE2=MDE1="L", MDE0="H" or "L")

**Figure 1.4-2 Pin Assignment for 16-bit Multiplexed Mode**



- SPI mode (MD2=MD1="H", MD0="L", MDE2="H" or "L", MDE1="H" or "L", MDE0="L")

**Figure 1.4-3 Pin Assignment for SPI Mode**



## 1.5 Pin Functions

This section explains the pin functions of the MB88121B.

### ■ Pin Functions

Table 1.5-1 Pin Functions (1 / 7)

Pin No.	Pin Name	Circuit Type	Function Description									
1, 17, 33, 49	V <sub>ss</sub>	-	GND pins									
16, 32, 48	V <sub>cc</sub>	-	5V or 3.3V power supply pins. Connect all of the power supply pins to the same potential.									
18	C	-	Power supply stabilization capacitor pin. Connect to a ceramic capacitor with a capacitance of 0.1 μF or more.									
2	X1	C	Oscillator pin									
3	X0		Oscillator pin. Also used as the external clock input pin.									
64, 4, 5	MD2 to MD0	B	Operation mode selection inputs.									
			<table border="1"> <thead> <tr> <th>MD2</th> <th>MD1</th> <th>MD0</th> <th>Mode</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>0</td> <td>0</td> <td>16-bit parallel bus</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>Serial bus</td> </tr> </tbody> </table> <p>See "2.4 FlexRay Operations" for details. Note: Operation is not guaranteed if settings other than those listed above are used.</p>	MD2	MD1	MD0	Mode	1	0	0	16-bit parallel bus	1
MD2	MD1	MD0	Mode									
1	0	0	16-bit parallel bus									
1	1	0	Serial bus									
6	$\overline{\text{RST}}$	A	External reset input. The device is initialized when this pin is set to "L". Note: Always set this pin to "L" when the power supply is connected, and maintain the "L" until the oscillation stabilization wait time has elapsed.									
7	SDS	B	Indicates the start of a dynamic segment. A dynamic segment is started and an "H" pulse is output when the SDSE bit of the Debug Support Register (DBGS) is set to "1". This pin is fixed at "L" when the SDSE bit of the Debug Support Register is set to "0".									
8	CYCS0	B	Indicates the start of cycle 0. Cycle 0 is started and an "H" pulse is output when the CYCS0E bit of the Debug Support Register (DBGS) is set to "1". This pin is fixed at "L" when the CYCS0E bit of the Debug Support Register is set to "0". Note: Cycle 0 does not output an "H" pulse on release from reset.									
9	STPW	B	Stop watch trigger input. Functions as the stop watch trigger as specified by the setting of Stop Watch Register 1 (STPW1).									

**Table 1.5-1 Pin Functions (2 / 7)**

Pin No.	Pin Name	Circuit Type	Function Description
10	INT0	B	Interrupt 0 output. This pin changes to "H" to indicate the occurrence of an interrupt. This interrupt is enabled and disabled using the EINT0 bit of the Interrupt Line Enable Register (ILE).
11	TXDA	B	Data output for ch.A.
12	$\overline{\text{TXENA}}$	B	Operation enable output for ch.A. Transmit data output is enabled when this pin is "L". This pin is set to "H" on reset.
13	RXDA	B	Data input for ch.A.
14	CYCS	B	Indicates the start of cycle. Cycle is started and "H" pulse is output when the CYCSE bit of the debug support register (DBGS) is set to "1". This pin is fixed at "L" when the CYCSE bit of the debug support register is set to "0".
15	BCLK	B	Bus clock input.
	-		In SPI mode, this pin is set to high impedance state. Use the device with this pin left open or fixed at "L".
19	$\overline{\text{CS}}$	B	Chip select input. The chip is selected when this pin is "L".
20	$\overline{\text{RD}}$	B	Read enable input. The register value is output to pins D15 to D0 when $\overline{\text{CS}}$ ="L" and this pin is "L". Do not set $\overline{\text{WR}}$ ="L" when $\overline{\text{RD}}$ ="L".
	-		In SPI mode, this pin is set to high impedance state. Use the device with this pin left open, or fixed at "H" or "L".
21	$\overline{\text{WR}}$	B	Write enable input. The data on pins D15 to D0 is written to the register when $\overline{\text{CS}}$ ="L" and this pin is "L". Do not set $\overline{\text{RD}}$ ="L" when $\overline{\text{WR}}$ ="L".
	-		In SPI mode, this pin is set to high impedance state. Use the device with this pin left open, or fixed at "H" or "L".
22	INT2	B	In the 16-bit non-multiplexed bus mode, this pin is the interrupt output of Timer 0 or Timer 1. This pin changes to "H" to indicate the occurrence of Interrupt 2 or Interrupt 3. A Timer 0 or Timer 1 interrupt occurs when the TINT0 bit or the TINT1 bit of the Interrupt Register (INT) is set to "1". Note: The output state of this pin is undefined when the power is turned on.
	$\overline{\text{AS}}$		In FR460 mode of the 16-bit multiplexed bus mode, this pin is the address strobe input. This signal is active low. Note: The output state of this pin is undefined when the power is turned on.
	ALE		In 16FX mode of the 16-bit multiplexed bus mode, this pin is the address latch enable input. This pin is active high. Note: The output state of this pin is undefined when the power is turned on.
	-		In SPI mode, this pin is set to high impedance state. Use the device with this pin left open, or fixed at "H" or "L". Note: The output state of this pin is undefined when the power is turned on.

**Table 1.5-1 Pin Functions (3 / 7)**

Pin No.	Pin Name	Circuit Type	Function Description
23	MT	B	Indicates the start of a macrotick. A macrotick is started and an "H" pulse is output when the MTE bit of the Debug Support Register (DBGSR) is set to "1". This pin is fixed at "L" when the MTE bit of the Debug Support Register is set to "0".
24	RXDB	B	Data input for ch.B.
25	$\overline{\text{TXENB}}$	B	Operation enable output for ch.B. Transmit data output is enabled when this pin is "L". This pin is set to "H" on reset.
26	TXDB	B	Data output for ch.B.
27	RDY	B	Ready output. The device is in the ready state when this pin is "H".
	-		In SPI mode, this pin is set to high impedance state. Use the device with this pin left open, or fixed at "H" or "L".
28 to 30	MDE2 to MDE0	B	Extended mode selection inputs.
31	DMA_REQ	B	DMA TRANSFER REQUEST OUTPUT. SET TO HIGH IMPEDANCE STATE ON RESET. This output is enabled by the DMAOE bit of the DMA Support Register (DMAS).
	-		In SPI mode, this pin is set to high impedance state. Use the device with this pin left open, or fixed at "H" or "L".
34	INT1	B	INTERRUPT 1 OUTPUT. THIS PIN CHANGES TO "H" TO INDICATE THE OCCURRENCE OF AN INTERRUPT. This interrupt is enabled and disabled using the EINT1 bit of the Interrupt Line Enable Register (ILE).
35	A10	B	In the 16-bit non-multiplexed bus mode, this pin is an address input. Note: The output state of this pin is undefined when the power is turned on.
	INT2		IN THE 16-BIT MULTIPLEXED BUS MODE, THIS PIN IS THE INTERRUPT 2 OUTPUT. This pin changes to "H" to indicate the occurrence of an interrupt. If the TINTE0 bit of the Interrupt Register (INT) is set to "1", "H" is output when a Timer 0 interrupt occurs. If the TINTE0 bit of the Interrupt Register (INT) is set to "0", this output is fixed at "L". Note: The output state of this pin is undefined when the power is turned on.
	-		In SPI mode, this pin is set to high impedance state. Use the device with this pin left open, or fixed at "H" or "L". Note: The output state of this pin is undefined when the power is turned on.

**Table 1.5-1 Pin Functions (4 / 7)**

Pin No.	Pin Name	Circuit Type	Function Description
36	A9	B	In the 16-bit non-multiplexed bus mode, this pin is an address input. Note: The output state of this pin is undefined when the power is turned on.
	INT3		In the 16-bit multiplexed bus mode, this pin is the Interrupt 3 output. This pin changes to "H" to indicate the occurrence of an interrupt. If the TINTE1 bit of the Interrupt Register (INT) is set to "1", "H" is output when a Timer 1 interrupt occurs. If the TINTE1 bit of the Interrupt Register (INT) is set to "0", this output is fixed at "L". Note: The output state of this pin is undefined when the power is turned on.
	-		In SPI mode, this pin is set to high impedance state. Use the device with this pin left open, or fixed at "H" or "L". Note: The output state of this pin is undefined when the power is turned on.
37	A8	B	In the 16-bit non-multiplexed bus mode, this pin is an address input. Note: The output state of this pin is undefined when the power is turned on.
	INT4		In the 16-bit multiplexed bus mode, this pin is the low-voltage detection interrupt output. This pin changes to "H" to indicate the occurrence of an interrupt. If the LVD5E bit or the LVD18E bit of the Interrupt Register (INT) is set to "1", this pin changes to "H" when the LVD5 bit or the LVD18 bit of the Interrupt Register (INT) changes to "1". If the LVD5E bit and the LVD18E bits of the Interrupt Register (INT) are set to "0", this output is fixed at "L". Note: The output state of this pin is undefined when the power is turned on.
	-		In SPI mode, this pin is set to high impedance state. Use the device with this pin left open, or fixed at "H" or "L". Note: The output state of this pin is undefined when the power is turned on.
38	A7	B	In the 16-bit non-multiplexed bus mode, this pin is an address input. Note: The output state of this pin is undefined when the power is turned on.
	MBSU_TX1		In the 16-bit multiplexed bus mode and SPI mode, this pin indicates changes in the message buffer status of the ch.A transmit buffer. If the MBSUE bit of the Debug Support Register (DBGS) is set to "1", this pin changes to "H" when the message buffer is updated. If the MBSUE bit of the Debug Support Register (DBGS) is set to "0", this pin is fixed at "L". Note: The output state of this pin is undefined when the power is turned on.

Table 1.5-1 Pin Functions (5 / 7)

Pin No.	Pin Name	Circuit Type	Function Description
39	A6	B	In the 16-bit non-multiplexed bus mode, this pin is an address input. Note: The output state of this pin is undefined when the power is turned on.
	MBSU_RX1		In the 16-bit multiplexed bus mode and SPI mode, this pin indicates changes in the message buffer status of the ch.A transmit buffer. If the MBSUE bit in the Debug Support Register (DBGS) is set to "1", this pin changes to "H" when the message buffer is updated. If the MBSUE bit of the Debug Support Register (DBGS) is set to "0", this pin is fixed at "L". Note: The output state of this pin is undefined when the power is turned on.
40	A5	B	In the 16-bit non-multiplexed bus mode, this pin is an address input.
	-		In the 16-bit multiplexed bus mode, this pin is set to high impedance state. Use the device with this pin left open, or fixed at "H" or "L".
	SCK		In SPI mode, this pin is the serial clock input. The operation mode is determined by the MDS1 and MDS0 settings.
41	A4	B	In the 16-bit non-multiplexed bus mode, this pin is an address input.
	-		In the 16-bit multiplexed bus mode, this pin is set to high impedance state. Use the device with this pin left open, or fixed at "H" or "L".
	SDI		In SPI mode, this pin is the serial data input. Input serial data to this pin synchronously with the serial clock according to the operation mode.
42	A3	B	In the 16-bit non-multiplexed bus mode, this pin is an address input.
	-		In the 16-bit multiplexed bus mode, this pin is set to high impedance state. Use the device with this pin left open, or fixed at "H" or "L".
	SDO		In SPI mode, this pin is the serial data output. When $\overline{CS}$ ="L", serial data is output synchronously with the serial clock according to the operation mode. When $\overline{CS}$ ="H", this pin is set to high impedance state.
43	A2	B	In the 16-bit non-multiplexed bus mode, this pin is an address input.
	-		In the 16-bit multiplexed bus mode and SPI mode, this pin is set to high impedance state. Use the device with this pin left open, or fixed at "H" or "L".
44	A1	B	In the 16-bit non-multiplexed bus mode, this pin is an address input. Note: The output state of this pin is undefined when the power is turned on.
	MBSU_TX2		In the 16-bit multiplexed bus mode, this pin indicates changes in the message buffer status of the ch.B transmit buffer. If the MBSUE bit in the Debug Support Register (DBGS) is set to "1", this pin changes to "H" when the message buffer is updated. If the MBSUE bit of the Debug Support Register (DBGS) is set to "0", this pin is fixed at "L". Note: The output state of this pin is undefined when the power is turned on.

**Table 1.5-1 Pin Functions (6 / 7)**

Pin No.	Pin Name	Circuit Type	Function Description
45	A0	B	In the 16-bit non-multiplexed bus mode, this pin is an address input. Note: The output state of this pin is undefined when the power is turned on.
	MBSU_RX2		In the 16-bit multiplexed bus mode and SPI mode, this pin indicates changes in the message buffer status of the ch.B transmit buffer. If the MBSUE bit in the Debug Support Register (DBGS) is set to "1", this pin changes to "H" when the message buffer is updated. If the MBSUE bit of the Debug Support Register (DBGS) is set to "0", this pin is fixed at "L". Note: The output state of this pin is undefined when the power is turned on.
46, 47	D15, D14	B	In the 16-bit non-multiplexed bus mode, these pins are data I/O pins. In the 16-bit multiplexed bus mode, these pins are data I/O pins. This data has no effect on the operation during the address cycle.
	-		In SPI mode, these pins are set to high impedance state. Use the device with this pin left open, or fixed at "H" or "L".
50 to 52	D13 to D11	B	In the 16-bit non-multiplexed bus mode, these pins are data I/O pins. In the 16-bit multiplexed bus mode, these pins are data I/O pins. This data has no effect on the operation during the address cycle.
	-		In SPI mode, these pins are set to high impedance state. Use the device with these pins left open, or fixed at "H" or "L".
53 to 55	D10 to D8	B	In the 16-bit non-multiplexed bus mode, these pins are data I/O pins.
	AD10 to AD8		In the 16-bit multiplexed bus mode, these pins are address/data I/O pins.
	MD2 to MD0		In SPI mode, these pins determine the SPI operation mode.
56, 57	D7, D6	B	In the 16-bit non-multiplexed bus mode, these pins are data I/O pins.
	AD7, AD6		In the 16-bit multiplexed bus mode, these pins are address/data I/O pins.
	-		In SPI mode, these pins are set to high impedance state. Use the device with these pins left open, or fixed at "H" or "L".
58	D5	B	In the 16-bit non-multiplexed bus mode, this pin is a data I/O pin. Note: The output state of this pin is undefined when the power is turned on.
	AD5		In the 16-bit multiplexed bus mode, this pin is an address/data I/O pin. Note: The output state of this pin is undefined when the power is turned on.
	INT2		In SPI mode, this pin is the Interrupt 2 output. This pin changes to "H" to indicate the occurrence of an interrupt. If the TINTE0 bit of the Interrupt Register (INT) is set to "1", "H" is output when a timer 0 interrupt occurs. If the TINTE0 bit of the Interrupt Register (INT) is set to "0", this output is fixed at "L". Note: The output state of this pin is undefined when the power is turned on.

**Table 1.5-1 Pin Functions (7 / 7)**



Pin No.	Pin Name	Circuit Type	Function Description
59	D4	B	In the 16-bit non-multiplexed bus mode, this pin is a data I/O pin. Note: The output state of this pin is undefined when the power is turned on.
	AD4		In the 16-bit multiplexed bus mode, this pin is an address/data I/O pin. Note: The output state of this pin is undefined when the power is turned on.
	INT3		In SPI mode, this pin is the Interrupt 3 output. This pin changes to "H" to indicate the occurrence of an interrupt. If the TINTE1 bit of the Interrupt Register (INT) is set to "1", "H" is output when a timer 1 interrupt occurs. If the TINTE1 bit of the Interrupt Register (INT) is set to "0", this output is fixed at "L". Note: The output state of this pin is undefined when the power is turned on.
60	D3	B	In the 16-bit non-multiplexed bus mode, this pin is a data I/O pin. Note: The output state of this pin is undefined when the power is turned on.
	AD3		In the 16-bit multiplexed bus mode, this pin is an address/data I/O pin. Note: The output state of this pin is undefined when the power is turned on.
	INT4		In SPI mode, this pin is the low-voltage detection interrupt output. This pin changes to "H" to indicate the occurrence of an interrupt. If the LVD5E bit or the LVD18E bit of the Interrupt Register (INT) is set to "1" and the LVD5 bit or the LVD18 bit of the Interrupt Register (INT) is set to "1", this pin changes to "H". If the LVD5E bit and the LVD18E bit of the Interrupt Register (INT) are set to "0", this output is fixed at "L". Note: The output state of this pin is undefined when the power is turned on.
61 to 63	D2 to D0	B	In the 16-bit non-multiplexed bus mode, these pins are data I/O pins. Note: The output state of these pins is undefined when the power is turned on.
	AD2 to AD0		In the 16-bit multiplexed bus mode, these pins are address/data I/O pins. Note: The output state of these pins is undefined when the power is turned on.
	-		In SPI mode, these pins are set to high impedance state. Use the device with these pins left open, or fixed at "H" or "L".

## 1.6 I/O Circuit Types

I/O circuit types of MB88121B are shown below.

### ■ I/O Circuit Types

Table 1.6-1 I/O Circuit Types

Type	Circuit
A	
B	
C	

## 1.7 Notes on Handling Devices

---

This section explains the notes when handling the devices.

---

### ■ Notes on Handling Devices

- When turning on the power supply

Always set the reset ( $\overline{\text{RST}}$ ) signal to "L" immediately after turning the power on in order to initialize the device.

- Undefined outputs at power-on

When the power is turned on, the state of input/output pins remain undefined until the power supply voltage reaches the recommended operating range.

- Preventing latch-up

Latch-up is a phenomenon that may occur if a voltage in excess of the maximum rated value is applied between the Vss pins and the input pins, output pins, or Vcc pins. When latch-up occurs, the power supply current increases dramatically and components may be burned out. Therefore, ensure that operating voltages do not exceed the absolute maximum rated values when the device is being used.

- Power supply pins

This device has multiple Vcc pins and multiple Vss pins. Ensure that these pins are all connected to the 5V power supply or to ground. Furthermore, use low impedance connections between the power supply source and the Vcc pins and Vss pins on the device to ensure that voltage differences do not occur.

- Handling unused pins

If unused input pins are left unconnected, malfunctions may occur and the device may be permanently damaged due to latch-up.

Handle unused input and input/output pins by connecting them to a pull-up or pull-down resistance of 2 k or more.


Leave unused output pins unconnected.

- Mode pins (MD0, MD1, MD2, MDE0, MDE1, MDE2)

Connect the mode pins directly to Vcc or Vss to prevent the device from entering the wrong mode due to noise on these pins. In addition, keep the length of the pattern on the printed circuit board between the mode pins and the Vcc or Vss pins as short as possible.

● Notes on using an external clock

When an external clock is used, supply the X1 pin with the inverted clock.




● Notes when the PLL clock is selected

If the clock input stops while the PLL clock is selected, the microcontroller may continue to operate using the PLL self-oscillations. However, the microcontroller is not guaranteed to operate under these conditions.


■ Noise Prevention

● Power supply pins

In addition to the capacitor that serves to stabilize the power supply, it is recommended that capacitors of 0.1  $\mu\text{F}$  or less be fitted near to the device (approximately 3 mm) on each of the power supply pins as a measure to reduce unwanted radiation noise. Furthermore, it is recommended that the pattern beneath the device be made into a solid ground plane, that the area of the ground plane be increased as much as possible, and that ground wire traces be made as thick as possible, as these are effective means of reducing unwanted radiation.



If there is an inductance between the power supply and the device, attach capacitors directly next to the power supply pins of the device. Furthermore, it is recommended that the inductance be placed near to the device (approximately 3 mm).



## 1.8 I/O Map

The I/O map of MB88121B is shown below.

### ■ I/O Map

Table 1.8-1 I/O Map (1 / 5)

Address	Symbol	Name	Initial Value	Access
Customer Registers				
0000 <sub>H</sub>	VER	Version Information Register	043079FF <sub>H</sub>	R
0004 <sub>H</sub>	CCNT	Clock Control Register	00000000 <sub>H</sub>	R/W
0008 <sub>H</sub>	DBGS DMAS	Debug Support Register DMA Support Register	00000000 <sub>H</sub>	R/W
000C <sub>H</sub>	INT	Interrupt Register	00000000 <sub>H</sub>	R/W
Special Registers				
0010 <sub>H</sub>	-	reserved (Write-prohibited)	00000300 <sub>H</sub>	R/W
0014 <sub>H</sub>	-	reserved (Write-prohibited)	00000000 <sub>H</sub>	R/W
0018 <sub>H</sub>	-	reserved	00000000 <sub>H</sub>	R/W
001C <sub>H</sub>	LCK	Lock Register	00000000 <sub>H</sub>	R/W
Interrupt-Related Registers				
0020 <sub>H</sub>	EIR	Error Interrupt Register	00000000 <sub>H</sub>	R/W
0024 <sub>H</sub>	SIR	Status Interrupt Register	00000000 <sub>H</sub>	R/W
0028 <sub>H</sub>	EILS	Error Interrupt Line Select Register	00000000 <sub>H</sub>	R/W
002C <sub>H</sub>	SILS	Status Interrupt Line Select Register	0303FFFF <sub>H</sub>	R/W
0030 <sub>H</sub>	EIES	Error Interrupt Enable Register (set)	00000000 <sub>H</sub>	R/W
0034 <sub>H</sub>	EIER	Error Interrupt Enable Register (reset)	00000000 <sub>H</sub>	R/W
0038 <sub>H</sub>	SIES	Status Interrupt Enable Register (set)	00000000 <sub>H</sub>	R/W
003C <sub>H</sub>	SIER	Status Interrupt Enable Register (reset)	00000000 <sub>H</sub>	R/W
0040 <sub>H</sub>	ILE	Interrupt Line Enable Register	00000000 <sub>H</sub>	R/W
0044 <sub>H</sub>	T0C	Timer 0 Configuration Register 0	00000000 <sub>H</sub>	R/W
0048 <sub>H</sub>	T1C	Timer 0 Configuration Register 1	00020000 <sub>H</sub>	R/W
004C <sub>H</sub>	STPW1	Stop Watch Register 1	00000000 <sub>H</sub>	R/W
0050 <sub>H</sub>	STPW2	Stop Watch Register 2	00000000 <sub>H</sub>	R

**Table 1.8-1 I/O Map (2 / 5)**

Address	Symbol	Name	Initial Value	Access
0054 <sub>H</sub> to 007C <sub>H</sub>	-	reserved	00000000 <sub>H</sub>	R
Communication Controller (CC) Control Registers				
0080 <sub>H</sub>	SUCC1	SUC Configuration Register 1	0C401000 <sub>H</sub>	R/W
0084 <sub>H</sub>	SUCC2	SUC Configuration Register 2	01000504 <sub>H</sub>	R/W
0088 <sub>H</sub>	SUCC3	SUC Configuration Register 3	00000003 <sub>H</sub>	R/W
008C <sub>H</sub>	NEMC	NEM Configuration Register	00000000 <sub>H</sub>	R/W
0090 <sub>H</sub>	PRTC1	PRT Configuration Register 1	084C0633 <sub>H</sub>	R/W
0094 <sub>H</sub>	PRTC2	PRT Configuration Register 2	0F2D0A0E <sub>H</sub>	R/W
0098 <sub>H</sub>	MHDC	MHD Configuration Register	00000000 <sub>H</sub>	R/W
009C <sub>H</sub>	-	reserved	00000000 <sub>H</sub>	R
00A0 <sub>H</sub>	GTUC1	GTU Configuration Register 1	00000280 <sub>H</sub>	R/W
00A4 <sub>H</sub>	GTUC2	GTU Configuration Register 2	0002000A <sub>H</sub>	R/W
00A8 <sub>H</sub>	GTUC3	GTU Configuration Register 3	02020000 <sub>H</sub>	R/W
00AC <sub>H</sub>	GTUC4	GTU Configuration Register 4	00080007 <sub>H</sub>	R/W
00B0 <sub>H</sub>	GTUC5	GTU Configuration Register 5	0E000000 <sub>H</sub>	R/W
00B4 <sub>H</sub>	GTUC6	GTU Configuration Register 6	00020000 <sub>H</sub>	R/W
00B8 <sub>H</sub>	GTUC7	GTU Configuration Register 7	00020004 <sub>H</sub>	R/W
00BC <sub>H</sub>	GTUC8	GTU Configuration Register 8	00000002 <sub>H</sub>	R/W
00C0 <sub>H</sub>	GTUC9	GTU Configuration Register 9	00000101 <sub>H</sub>	R/W
00C4 <sub>H</sub>	GTUC10	GTU Configuration Register 10	00020005 <sub>H</sub>	R/W
00C8 <sub>H</sub>	GTUC11	GTU Configuration Register 11	00000000 <sub>H</sub>	R/W
00CC <sub>H</sub> to 00FC <sub>H</sub>	-	reserved	00000000 <sub>H</sub>	R
Communication Controller (CC) Status Registers				
0100 <sub>H</sub>	CCSV	CC Status Vector Register	00104000 <sub>H</sub>	R
0104 <sub>H</sub>	CCEV	CC Error Vector Register	00000000 <sub>H</sub>	R
0108 <sub>H</sub> to 010C <sub>H</sub>	-	reserved	00000000 <sub>H</sub>	R
0110 <sub>H</sub>	SCV	Slot Counter Value Register	00000000 <sub>H</sub>	R

Table 1.8-1 I/O Map (3 / 5)

Address	Symbol	Name	Initial Value	Access
0114 <sub>H</sub>	MTCCV	Macrotick and Cycle Counter Value Register	00000000 <sub>H</sub>	R
0118 <sub>H</sub>	RCV	Rate Correction Value Register	00000000 <sub>H</sub>	R
011C <sub>H</sub>	OCV	Offset Correction Value Register	00000000 <sub>H</sub>	R
0120 <sub>H</sub>	SFS	Sync Frame Status Register	00000000 <sub>H</sub>	R
0124 <sub>H</sub>	SWNIT	Symbol Window and NIT Status Register	00000000 <sub>H</sub>	R
0128 <sub>H</sub>	ACS	Aggregated Channel Status Register	00000000 <sub>H</sub>	R/W
012C <sub>H</sub>	-	reserved	00000000 <sub>H</sub>	R
0130 <sub>H</sub> to 0168 <sub>H</sub>	ESIDn	Even Cycle Sync Frame ID Register	00000000 <sub>H</sub>	R
016C <sub>H</sub>	-	reserved	00000000 <sub>H</sub>	R
0170 <sub>H</sub> to 01A8 <sub>H</sub>	OSIDn	Odd numbered Cycle Sync Frame ID Register	00000000 <sub>H</sub>	R
01AC <sub>H</sub>	-	reserved	00000000 <sub>H</sub>	R
01B0 <sub>H</sub> to 01B8 <sub>H</sub>	NMVn	Network Management Registers 1 to 3	00000000 <sub>H</sub>	R
01BC <sub>H</sub> to 02FC <sub>H</sub>	-	reserved	00000000 <sub>H</sub>	R
Message Buffer Control Registers				
0300 <sub>H</sub>	MRC	Message RAM Configuration Register	01800000 <sub>H</sub>	R/W
0304 <sub>H</sub>	FRF	FIFO Rejection Filter Register	01800000 <sub>H</sub>	R/W
0308 <sub>H</sub>	FRFM	FIFO Rejection Filter Mask Register	00000000 <sub>H</sub>	R/W
030C <sub>H</sub>	FCL	FIFO Critical Level Register	00000080 <sub>H</sub>	R/W
Message Buffer Status Registers				
0310 <sub>H</sub>	MHDS	Message Handler Status Register	00000000 <sub>H</sub>	R/W
0314 <sub>H</sub>	LDTS	Last Dynamic Transmit Slot Register	00000000 <sub>H</sub>	R
0318 <sub>H</sub>	FSR	FIFO Status Register	00000000 <sub>H</sub>	R
031C <sub>H</sub>	MHDF	Message Handler Constraints Flags Register	00000000 <sub>H</sub>	R/W
0320 <sub>H</sub>	TXRQ1	Transmission Request Register 1	00000000 <sub>H</sub>	R
0324 <sub>H</sub>	TXRQ2	Transmission Request Register 2	00000000 <sub>H</sub>	R
0328 <sub>H</sub>	TXRQ3	Transmission Request Register 3	00000000 <sub>H</sub>	R
032C <sub>H</sub>	TXRQ4	Transmission Request Register 4	00000000 <sub>H</sub>	R

**Table 1.8-1 I/O Map (4 / 5)**

Address	Symbol	Name	Initial Value	Access
0330 <sub>H</sub>	NDAT1	New Data Register 1	00000000 <sub>H</sub>	R
0334 <sub>H</sub>	NDAT2	New Data Register 2	00000000 <sub>H</sub>	R
0338 <sub>H</sub>	NDAT3	New Data Register 3	00000000 <sub>H</sub>	R
033C <sub>H</sub>	NDAT4	New Data Register 4	00000000 <sub>H</sub>	R
0340 <sub>H</sub>	MBSC1	Message Buffer Status Changed Register 1	00000000 <sub>H</sub>	R
0344 <sub>H</sub>	MBSC2	Message Buffer Status Changed Register 2	00000000 <sub>H</sub>	R
0348 <sub>H</sub>	MBSC3	Message Buffer Status Changed Register 3	00000000 <sub>H</sub>	R
034C <sub>H</sub>	MBSC4	Message Buffer Status Changed Register 4	00000000 <sub>H</sub>	R
0350 <sub>H</sub> to 03EC <sub>H</sub>	-	reserved	00000000 <sub>H</sub>	R
<b>Identification Registers</b>				
03F0 <sub>H</sub>	CREL	Core Release Register	07260412 <sub>H</sub>	R
03F4 <sub>H</sub>	ENDN	Endian Register	87654321 <sub>H</sub>	R
03F8 <sub>H</sub> to 03FC <sub>H</sub>	-	reserved	00000000 <sub>H</sub>	R
<b>Input Buffers</b>				
0400 <sub>H</sub> to 04FC <sub>H</sub>	WRDSn	Write Data Section Registers 1 to 64	00000000 <sub>H</sub>	R/W
0500 <sub>H</sub>	WRHS1	Write Header Section Register 1	00000000 <sub>H</sub>	R/W
0504 <sub>H</sub>	WRHS2	Write Header Section Register 2	00000000 <sub>H</sub>	R/W
0508 <sub>H</sub>	WRHS3	Write Header Section Register 3	00000000 <sub>H</sub>	R/W
050C <sub>H</sub>	-	reserved	00000000 <sub>H</sub>	R/W
0510 <sub>H</sub>	IBCM	Input Buffer Command Mask Register	00000000 <sub>H</sub>	R/W
0514 <sub>H</sub>	IBCR	Input Buffer Command Request Register	00000000 <sub>H</sub>	R/W
0518 <sub>H</sub> to 05FC <sub>H</sub>	-	reserved	00000000 <sub>H</sub>	R
<b>Output Buffers</b>				
0600 <sub>H</sub> to 06FC <sub>H</sub>	RDDS <sub>n</sub>	Read Data Section Registers 1 to 64	00000000 <sub>H</sub>	R
0700 <sub>H</sub>	RDHS1	Read Header Section Register 1	00000000 <sub>H</sub>	R

**Table 1.8-1 I/O Map (5 / 5)**

Address	Symbol	Name	Initial Value	Access
0704 <sub>H</sub>	RDHS2	Read Header Section Register 2	00000000 <sub>H</sub>	R
0708 <sub>H</sub>	RDHS3	Read Header Section Register 3	00000000 <sub>H</sub>	R
070C <sub>H</sub>	MBS	Message Buffer Status Register	00000000 <sub>H</sub>	R
0710 <sub>H</sub>	OBCM	Output Buffer Command Mask Register	00000000 <sub>H</sub>	R/W
0714 <sub>H</sub>	OBCR	Output Buffer Command Request Register	00000000 <sub>H</sub>	R/W
0718 <sub>H</sub> to 07FC <sub>H</sub>	-	reserved	00000000 <sub>H</sub>	R



# CHAPTER 2

---

## *FlexRay*

**This chapter explains the functions and operations of FlexRay.**

- 2.1 Overview of FlexRay
- 2.2 Block Diagram of FlexRay
- 2.3 Configuration of FlexRay
- 2.4 FlexRay Operations
- 2.5 SPI Protocol Definition
- 2.6 FlexRay Controller Clock
- 2.7 FlexRay Protocol Function

## 2.1 Overview of FlexRay

---

**This section explains the overview of FlexRay.**

---

### ■ Overview of FlexRay

The FlexRay controller performs communications compliant with the FlexRay Protocol Specifications Version 2.1. When the maximum sample clock is specified, the bit rate is set to 10 Mbps.

The length of the message buffers for FlexRay network communications is configurable up to a maximum of 254 data bytes. The message storage region consists of single-port message RAM that holds up to 128 message buffers. The message handler provides the following functions related to all aspects of message processing.

- Acceptance filtering
- Message transfers between the two FlexRay channel protocol controllers and message RAM
- Transfer schedule management
- Providing message status information

The FlexRay controller registers can be accessed by the host. These registers are used to configure, control, and monitor the following.

- FlexRay channel protocol controllers
- Message handler
- Global time unit
- System universal control
- Frame and symbol processing
- Network management
- Interrupt control
- Accessing message RAM via input/output buffers

## ■ FlexRay Features

The FlexRay controller supports the following functions.


- Complies with FlexRay Protocol Specification Version 2.1
- Each channel has a maximum bitrate of 10 Mbps
- Up to a maximum of 128 message buffers can be configured
- 8 Kbytes of message RAM
  - 128 message buffers when the data section is 48 bytes
  - 30 message buffers when the data section is 254 bytes
- Variable length message buffer configuration
- Configurable receive FIFO
- Each message buffer may be configured as a transmit buffer, receive buffer, or part of the receive FIFO
- Host access to message buffers via an input buffer and an output buffer
  - Input buffer: Stores a message to be transferred to the message RAM
  - Output buffer: Stores a message that has been read out from the message RAM
- Filtering by slot counter, cycle counter, and channel
- Maskable interrupts
- Network management support

## 2.2 Block Diagram of FlexRay

The block diagram of FlexRay is shown below.

### ■ Block Diagram of FlexRay Controller

Figure 2.2-1 Block Diagram of FlexRay Controller



### ■ Function Description of Each Block

● CPU Interface (CIF)

Connects the host CPU to the FlexRay controller.

● Input Buffer (IBF)

Used to write to the message buffers in the message RAM.

The host CPU can write the header section and data section from the input buffer to a specific message buffer.

The message handler transfers data from the input buffer to the selected message buffer in the message RAM.

● Output Buffer (OBF)

Used to read from the message buffers in the message RAM.

The message handler transfers data from the selected message buffer to the output buffer.

Once the data transfer is complete, the host CPU can read the header section and data section of the message buffer that was transferred from the output buffer.

● Message Handler (MHD)

The message handler controls the data transfers between the following components.

- Input/output buffer and message RAM

- The transient storage buffer RAM of the two FlexRay protocol controllers and message RAM

### ● Message RAM (MRAM)

The message RAM is composed of single-port RAM that is able to hold the configuration data for the built-in FlexRay message buffers (max. 128).

### ■ Transient Buffer RAM (TBF A/B)

Stores the data sections of two messages.

### ■ FlexRay Channel Protocol Controller (PRT A/B)

The FlexRay channel protocol controller is composed of a shift register and a FlexRay protocol FSM.

The protocol controller provides the following functions.

- Checking and controlling bit timings
- Receiving and transmitting FlexRay frames and symbols
- Checking the header CRC
- Generating and checking frame CRC
- Connecting to the bus driver

In addition, protocol controller block is connected to the following blocks.

- Physical layer (bus driver)
- Transient storage buffer RAM
- Message handler
- Global time unit
- System universal control
- Frame and symbol processing
- Network management
- Interrupt control

### ■ Global Time Unit (GTU)

- The global time unit provides the following functions.
- Generating microticks
- Generating macroticks
- Fault-tolerant clock synchronization using the FTM algorithm
  - Rate correction
  - Offset correction
- Cycle counter
- Static segment timing control
- Dynamic segment (minislot) timing control
- Support for external clock correction

## ■ System Universal Control (SUC)

The system universal control controls the following functions.

- Configuration
- Wakeup
- Startup
- Normal operation
- Passive operation
- Monitor mode

## ■ Frame and Symbol Processing (FSP)

Frame and symbol processing controls the following function.

- Checking that the timing of frames and symbols is correct
- Testing the syntactic and semantic validity of received frames
- Setting the slot status flag

## ■ Network Management (NEM)

Configures the handling of the network management vector.

## ■ Interrupt Control (INT)

The following functions are available for controlling interrupts.

- Provision of error and interrupt flags
- Controlling the enabling/disabling of interrupt sources
- Controlling the allocation of interrupt sources to the two interrupt lines of the module
- Enabling/disabling the two interrupt lines of the module
- Managing the two interrupt timers
- Halting watch timer capturing

## 2.3 Configuration of FlexRay

---

This section explains the configuration of FlexRay.

---

### ■ Configuration of FlexRay

The FlexRay controller has an address space of 2 Kbytes (0000<sub>H</sub> to 07FF<sub>H</sub>) that is composed of 32-bit registers. Host access to the message RAM (access by the host CPU) is performed via the input buffer and output buffer. In order to prevent competition between host access and the reception and transmission of messages, these buffers are used to buffer data for transfer to the message RAM and data that has been transferred from the message RAM.

The number *N* of message buffers that can be used depends on the configured message buffer payload length. The maximum number of message buffers is 128 and the maximum payload length is 254 bytes.

The message buffers are allocated as shown in Figure 2.3-1. The message buffers are organized into three consecutive groups.

- Static buffers: Transmit and receive buffers allocated to static segments
- Static + dynamic buffers: Transmit and receive buffers allocated to static segments or dynamic segments
- FIFO: Receive FIFO

The allocation of message buffers can be changed by setting the Message RAM Configuration Register (MRC) while in the DEFAULT\_CONFIG or CONFIG states.


The first group operates as static message buffers.

The second group operates as static/dynamic message buffers. The message buffers that belong to this group can be reconfigured during operation from dynamic segments to static segments, or from static segments to dynamic segments depending on the state of MRC:SEC1 and SEC0.

Message buffers that belong to the third group are connected into receive FIFO.

Message buffer 0 is used to store and transmit startup, synchronization, or single slot frames (a frame that is sent in the single slot mode) depending on the setting of SUCC1:TXST, TXSY, and TSM. Message buffer 0 is required to have a key slot ID, which can only be configured (or reconfigured) in the DEFAULT\_CONFIG or CONFIG states.

**Figure 2.3-1 Allocation of Message Buffers**



Note:

All of the FlexRay controller registers are accessed as 32 bits.

## 2.3.1 Customer Registers


This section explains the bit configurations and functions of the customer registers.

### Customer Registers

The address space from 0000<sub>H</sub> to 000F<sub>H</sub> is for MB88121B customer registers. These are allocated to version information, clock control, debugging support, DMA support, and interrupt registers.

### Version Information Register (VER)

Figure 2.3-2 Version Information Register Details




**Table 2.3-1 Explanation of the Function of Each Bit in the Version Information Register**

No.	Bit Name	Function
bit 31 to bit 24	VID7 to VID0: JEDEC ID Code	Specifies the Fujitsu JEDEC ID code. On the MB88121B, reading these bits returns 04 <sub>H</sub> . Writing to these bits has no effect on the operation.
bit 23 to bit 16	INV7 to INV0: Revision Number Bits	Represents the revision number of the LSI. On the MB88121B, reading these bits returns 30 <sub>H</sub> . Writing to these bits has no effect on the operation.
bit 15 to bit 8	CIV7 to CIV0: LSI Identification Number Bits	Represents the identification number of the LSI. This is the lowest 3 digits of the MB number in hexadecimal notation. On the MB88121B, reading these bits returns 79 <sub>H</sub> . Writing to these bits has no effect on the operation.
bit 7 to bit 0	ECR7 to ECR0: FlexRay IP Identification Bits	Represents the FlexRay IP identification number. On the MB88121B, reading these bits returns FF <sub>H</sub> . If these bits return FF <sub>H</sub> , the IP information is stored in the CREL register. The CREL register there needs to be read as necessary. Writing to these bits has no effect on the operation.

## ■ Clock Control Register (CCNT)

Figure 2.3-3 Clock Control Register Details



**Table 2.3-2 Explanation of the Function of Each Bit in the Clock Control Register (1 / 2)**

No.	Bit Name	Function															
bit 31 to bit 9	RSV: Reserved bits	These bits are reserved. These bits always return "0" when read. Always write "0" to these bits.															
bit 8, bit 7	SDIV1, SDIV0: System Clock Division Bits	<p>Configures a frequency divider on the system clock (sclk<sup>*</sup>). The clock division from these bits is used as the FlexRay operating clock (f_sclk<sup>*</sup>).</p> <table border="1"> <thead> <tr> <th>SDIV1</th> <th>SDIV0</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>System clock</td> </tr> <tr> <td>0</td> <td>1</td> <td>System clock divided by 2</td> </tr> <tr> <td>1</td> <td>0</td> <td>System clock divided by 4</td> </tr> <tr> <td>1</td> <td>1</td> <td>System clock divided by 8</td> </tr> </tbody> </table>	SDIV1	SDIV0	Function	0	0	System clock	0	1	System clock divided by 2	1	0	System clock divided by 4	1	1	System clock divided by 8
SDIV1	SDIV0	Function															
0	0	System clock															
0	1	System clock divided by 2															
1	0	System clock divided by 4															
1	1	System clock divided by 8															
bit 6	RSV: Reserved bit	This bit is reserved. This bit always returns "0" when read. Always write "0" to this bit.															
bit 5	STOP: Clock Stop Bit	<p>Stops the system clock (sclk<sup>*</sup>). When this bit is set to "1", the system clock stops, but the oscillator circuit operates.</p> <p>Use the following procedures to set this bit to "1".</p> <ul style="list-style-type: none"> <li>- When using the PLL                             <ol style="list-style-type: none"> <li>1) Prohibit the FlexRay controller from transmitting and receiving.</li> <li>2) Set the SSEL bit to "0"</li> <li>3) Set the PON bit to "0"</li> <li>4) Set the STOP bit to "1"</li> </ol> </li> <li>- When not using the PLL                             <ol style="list-style-type: none"> <li>1) Prohibit the FlexRay controller from transmitting and receiving.</li> <li>2) Set the STOP bit to "1"</li> </ol> </li> </ul> <p>Use the following procedures to set this bit to "0".</p> <ul style="list-style-type: none"> <li>- When using the PLL                             <ol style="list-style-type: none"> <li>1) Set the PON bit to "1"</li> <li>2) Set the STOP bit to "0"</li> <li>3) After the PLL lock-up time (600 μs) has elapsed, set the SSEL bit to "1"</li> <li>4) Enable the FlexRay controller to transmit and receive.</li> </ol> </li> <li>- When not using the PLL                             <ol style="list-style-type: none"> <li>Set the STOP bit to "0"</li> </ol> </li> </ul>															
bit 4	RCLK: RAM Clock Selection Bit	This bit selects whether the system clock (sclk <sup>*</sup> ) is divided by two and used as the RAM clock (f_bclk <sup>*</sup> ) or used directly as the RAM clock.															

**Table 2.3-2 Explanation of the Function of Each Bit in the Clock Control Register (2 / 2)**

No.	Bit Name	Function															
bit 3, bit 2	PMUL1, PMUL0: PLL Multiplication Bits	<p>Determines the PLL multiplication factor. Set these bits such that the PLL clock becomes 80 MHz. In SPI mode, the configuration values of the MDE2 and MDE1 pins are loaded into these bits upon release from reset.</p> <table border="1"> <thead> <tr> <th>PMUL1</th> <th>PMUL0</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Multiply X0/X1 (4 MHz) by 20</td> </tr> <tr> <td>0</td> <td>1</td> <td>Multiply X0/X1 (5 MHz) by 16</td> </tr> <tr> <td>1</td> <td>0</td> <td>Multiply X0/X1 (8 MHz) by 10</td> </tr> <tr> <td>1</td> <td>1</td> <td>Multiply X0/X1 (10 MHz) by 8</td> </tr> </tbody> </table> <p>Note: Change these bits before setting the PON bit to "1".</p>	PMUL1	PMUL0	Function	0	0	Multiply X0/X1 (4 MHz) by 20	0	1	Multiply X0/X1 (5 MHz) by 16	1	0	Multiply X0/X1 (8 MHz) by 10	1	1	Multiply X0/X1 (10 MHz) by 8
PMUL1	PMUL0	Function															
0	0	Multiply X0/X1 (4 MHz) by 20															
0	1	Multiply X0/X1 (5 MHz) by 16															
1	0	Multiply X0/X1 (8 MHz) by 10															
1	1	Multiply X0/X1 (10 MHz) by 8															
bit 1	SSEL: System Clock (sclk*) Selection Bit	<p>This bit selects between the X0/X1 clock and the clock output from the PLL. "0": Selects the clock from X0/X1. "1": Selects the clock output from the PLL.</p> <p>Notes:</p> <ul style="list-style-type: none"> <li>When changing this bit from "0" to "1", first set the PON bit to "1" and then ensure the PLL lock-up time (600 <math>\mu</math>s) before changing this bit.</li> <li>To stop the PLL oscillator, first set this bit to "0" before setting the PON bit to "0".</li> </ul>															
bit 0	PON: PLL Oscillator Enable Bit	<p>This bit enables the PLL oscillator. In SPI mode, this bit is set to "1" upon release from reset. "0": Disables the PLL oscillator. "1": Enables the PLL oscillator.</p> <p>Note: Change this bit when the SSEL bit is "0".</p>															

\*: See "2.6 FlexRay Controller Clock".

**Note:**

The Clock Control Register can only be updated when the CCSV:POCS5 to POCS0 bits are in the DEFAULT\_CONFIG state or the CONFIG state.

When the mode pins are set to the SPI mode setting (MDE0 = 0), the initial values of the CCNT:PMUL1 and PMUL0 bits at power-on or reset reflect the settings of the external input frequency pins (MDE2 and MDE1). Furthermore, the SPI mode setting sets the CCNT:PON bit to "1".

■ Debug Support Register (DBGS)

Figure 2.3-4 Debug Support Register Details





Table 2.3-3 Explanation of the Function of Each Bit in the Debug Support Register (1 / 2)

No.	Bit Name	Function
bit 31	MBSUE: MBSU Output Enable Bit	This bit enables the internal MBSU_TX1, MBSU_RX1, MBSU_TX2, and MBSU_RX2 signals to be output on the MBSU_TX1, MBSU_RX1, MBSU_TX2, and MBSU_RX2 pins. When this bit is set to "1", the internal signals are output, and when set to "0", the pins are fixed at "L". Note: This setting is only active in SPI mode and multiplexed mode.
bit 30	CYCSE: CYCS Output Enable Bit	This bit enables the internal CYCS signal (cycle start) to be output on the CYCS pin. When this bit is set to "1", the internal CYCS signal is output, and when set to "0", the CYCS pin is fixed at "L".

**Table 2.3-3 Explanation of the Function of Each Bit in the Debug Support Register (2 / 2)**

No.	Bit Name	Function
bit 29	MTE: MT Output Enable Bit	This bit enables the internal MT signal (macro tick) to be output on the MT pin. When this bit is set to "1", the internal MT signal is output, and when set to "0", the MT pin is fixed at "L".
bit 28	SDSE: SDS Output Enable Bit	This bit enables the internal SDS signal (dynamic segment start) to be output on the SDS pin. When this bit is set to "1", the internal SDS signal is output, and when set to "0", the SDS pin is fixed at "L".
bit 27	CYCS0E: CYCS0 Output Enable Bit	This bit enables the internal CYCS0 signal (cycle 0 start) to be output on the CYCS0 pin. When this bit is set to "1", the internal CYCS0 signal is output, and when set to "0", the CYCS0 pin is fixed at "L".
bit 26 to bit 16	RSV: Reserved bits	These bits are reserved. These bits always return "0" when read. Always write "0" to these bits.

## ■ DMA Support Register (DMAS)

**Figure 2.3-5 DMA Support Register Details**

**Table 2.3-4 Explanation of the Function of Each Bit in the DMA Support Register**


No.	Bit Name	Function
bit 15 to bit 3	RSV: Reserved bits	These bits are reserved. These bits always return "0" when read. Always write "0" to these bits.
bit 2	DMAINV: DMA Transfer Request Inversion Bit	This bit inverts the DMA transfer request signal. "0": DMA transfers are requested by an "H" level. "1": DMA transfers are requested by an "L" level. Note: This setting is valid when the DMAOE bit is set to "1".
bit 1	DMARE: DMA Transfer Request Enable Bit	This bit enables DMA transfer requests. "0": DMA transfer requests are disabled. "1": DMA transfer requests are enabled. Note: This setting is valid when the DMAOE bit is set to "1".
bit 0	DMAOE: DMA Transfer Request Output Enable Bit	This bit enables outputs on the DMA transfer request pin (DMA_REQ). "0": The DMA transfer request pin (DMA_REQ) is set to high impedance state. "1": The DMA transfer request pin (DMA_REQ) is set as an output. Notes: <ul style="list-style-type: none"> <li>• If any pins are connected to the DMA transfer request pin (DMA_REQ), those pins need to be connected to either a pull-up resistance or to another output pin.</li> <li>• Simultaneously changing this bit from "0" to "1" and changing the DMAINV bit may create a hazard signal on the DMA transfer request pin (DMA_REQ). To avoid this, change the value of the DMAINV bit before changing this bit from "0" to "1".</li> </ul>

**Note:**

In SPI mode, the DMA transfer request pin (DMA\_REQ) does not exist. Setting this register in SPI mode therefore has no effect on the operation of the MB88121B.

■ Interrupt Register (INT)

Figure 2.3-6 Interrupt Register Details



**Table 2.3-5 Explanation of the Function of Each Bit of the Interrupt Register**

No.	Bit Name	Function
bit 31 to bit 8	RSV: Reserved bits	These bits are reserved. These bits always return "0" when read. Always write "0" to these bits.
bit 7	LVD18CL: LVD18 Clear Bit	This bit clears the INT:LVD18 bit. When a "1" is written to this bit, the INT:LVD18 bit is cleared, and when a "0" is written to this bit, the INT:LVD18 bit is left unchanged. This bit always returns "0" when read. Note: As the setting "1" data has higher priority, the INT:LVD18 bit is not cleared to "0" while a low voltage condition is detected on the 1.8V power supply.
bit 6	LVD5CL: LVD5 Clear Bit	This bit clears the INT:LVD5 bit. When a "1" is written to this bit, the INT:LVD5 bit is cleared, and when a "0" is written to this bit, the INT:LVD5 bit is left unchanged. This bit always returns "0" when read. Note: As the setting "1" data has higher priority, the INT:LVD5 bit is not cleared to "0" while a low voltage condition is detected on the 1.8V power supply.
bit 5	TINTE1: TINTE1 Interrupt Enable Bit	This bit enables interrupts by TINTE1. "0": Disables interrupts due to TINTE1. "1": Enables interrupts due to TINTE1.
bit 4	TINTE0: TINTE0 Interrupt Enable Bit	This bit enables interrupts by TINTE0. "0": Disables interrupts due to TINTE0. "1": Enables interrupts due to TINTE0.
bit 3	LVD18E: LVD18 Interrupt Enable Bit	This bit enables interrupts by the INT:LVD18 bit. "0": Disables interrupts due to the INT:LVD18 bit. "1": Enables interrupts due to the INT:LVD18 bit.
bit 2	LVD5E: LVD5 Interrupt Enable Bit	This bit enables interrupts by the INT:LVD5 bit. "0": Disables interrupts due to the INT:LVD5 bit. "1": Enables interrupts due to the INT:LVD5 bit.
bit 1	LVD18: 1.8V Low-Voltage Detect Bit	The voltage is judged to have dropped and this bit is set to "1" if the voltage of the 1.8V power supply, which is created by an internal step-down circuit, falls into the range of 1.7V to 1.5V. Write "1" to the INT:LVD18CL bit to clear this bit to "0". This bit is read-only. Writing to this bit has no effect on operation. Note: As the setting "1" data has higher priority, this bit cannot be cleared to "0" while a low voltage condition is detected on the 1.8V power supply.
bit 0	LVD5: 5V Low-Voltage Detect Bit	The voltage is judged to have dropped and this bit is set to "1" if the voltage of the 5V power supply falls into the range of 2.9V to 2.7V. Write "1" to the INT:LVD5CL bit to clear this bit to "0". This bit is read-only. Writing to this bit has no effect on operation. Note: As the setting "1" data has higher priority, this bit cannot be cleared to "0" while a low voltage condition is detected on the 5V power supply.

## 2.3.2 Special Registers

This section explains the bit configurations and functions of the special registers.

### ■ Lock Register (LCK)

The Lock Register is write-only. The value 00000000<sub>H</sub> is returned when the register is read.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
LCK 001C <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	W															
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	W									CLK7	CLK6	CLK5	CLK4	CLK3	CLK2	CLK1
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 7 to bit 0] CLK:Configuration Lock Key

Perform two consecutive writes to CLK7 to CLK0 (unlock sequence) before leaving the CONFIG state by writing 0010<sub>B</sub> (READY command) to SUCC1:CMD3 to CMD0. The write procedure is given below. In cases where write instructions may be interrupted by other write accesses, perform the following procedure repeatedly while the device remains in the CONFIG state.

First write: LCK:CLK7 to CLK0 = 1100 1110 (CE<sub>H</sub>)

Second write: LCK:CLK7 to CLK0 = 0011 0001 (31<sub>H</sub>)

Third write: SUCC1:CMD3 to CMD0 = 0010 (CHI Command READY)

#### Note:

The host should use 32-bit access for reads and writes to all of the bit fields. If the host uses 16-bit access, the program should perform sequential accesses.

## 2.3.3 Interrupt-related Registers

This section explains the bit configurations and functions of the interrupt-related registers.

### ■ Error Interrupt Register (EIR)

If the error is detected, the corresponding flag in this register is set to "1". This flag can be cleared to "0" by writing "1" to the corresponding bit. The flag will remain in the set state until it is cleared. Writing "0" has no effect. This register is cleared to "0" by a hard reset.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
EIR 0020 <sub>H</sub>	R	0	0	0	0				0	0	0	0	0			
	W					TABB	LTVB	EDB						TABA	LTVA	EDA
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	R	0	0	0	0											
	W					MHF	IOBA	IIBA	EFA	RFO	PERR	CCL	CCF	SFO	SFBM	CNA
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 26] TABB: Transmission Across Boundary ch.B Flag

Indicates that a transmission has occurred on ch.B that crosses the slot boundary.

"1" = Transmission detected on ch.B that crosses the slot boundary

"0" = No transmission detected on ch.B that cross the slot boundary

[bit 25] LTVB: Latest Transmit Violation ch.B

Indicates a failure in the most recent transmission on ch.B.

"1" = Failure detected in the most recent transmission on ch.B

"0" = No failure detected in the most recent transmission on ch.B

[bit 24] EDB: Error Detected on ch.B Flag

This flag is set to "1" when any of the ACS:SEDB, CEDB, CIB, or SBVB bits changes from "0" to "1".

"1" = Error detected on ch.B

"0" = No error detected on ch.B

[bit 18] TABA: Transmission Across Boundary ch.A Flag

Indicates that a transmission has occurred on ch.A that crosses the slot boundary.

"1" = Transmission detected on ch.A that crosses the slot boundary

"0" = No transmission detected on ch.A that cross the slot boundary

[bit 17] LTVA: Latest Transmit Violation ch.A Flag

Indicates a failure in the most recent transmission on ch.A.

"1" = Failure detected in the most recent transmission on ch.A

"0" = No failure detected in the most recent transmission on ch.A

#### [bit 16] EDA: Error Detected on ch.A Flag

This flag is set to "1" when any of the ACS:SEDA, CEDA, CIA, or SBVA bits changes from "0" to "1".

"1" = Error detected on ch.A

"0" = No error detected on ch.A

#### [bit 11] MHF: Message Handler Constraints Flag

This flag indicates the state of message handler constraints. This flag is set to "1" when any of the MHDF:SNUB, FNFA, FNFB or WAHP flags changes from "0" to "1".

"1" = Message handler failure detected

"0" = Message handler failure not detected

#### [bit 10] IOBA: Illegal Output Buffer Access Flag

This flag is set to "1" if the host makes a request to transfer a message buffer from message RAM to the output buffer while OBCR:OBSYS is set to "1".

"1" = Illegal host access to the output buffer occurred

"0" = There was no illegal host access to the output buffer

#### [bit 9] IIBA: Illegal Input Buffer Access Flag

This flag is set to "1" if the host makes a request to change a message buffer via the input buffer while the device is not in the CONFIG or DEFAULT\_CONFIG states.

- 1) The host writes to the input buffer command request register to make any of the following changes
  - If message buffer 0 is configured for transmitting key slots (sending startup frames or sync frames, or sending frames in single slot mode), and the buffer header section is changed
  - While MRC:SEC1, SEC0 = 01<sub>B</sub>, the header section of a static message buffer with a buffer number smaller than MRC:FDB7 to FDB0 is changed
  - While MRC:SEC1, SEC0 = 1x<sub>B</sub>, the header section of the static/dynamic message buffer is changed
  - The header section or data section of a message buffer that belongs to the receive FIFO is changed
- 2) While IBCR:IBSYH is set to "1", the host writes to one of the input buffer registers

"1" = Illegal host access to the input buffer occurred

"0" = There was no illegal host access to the input buffer

#### [bit 8] EFA: Empty FIFO Access Flag

This flag is set to "1" when the receive FIFO is empty and the host makes a request for a message to be transferred from the receive FIFO via the output buffer.

"1" = Host access occurred when the receive FIFO was empty

"0" = There have been no host accesses while the receive FIFO was empty

#### [bit 7] RFO: Receive FIFO Overrun Flag

This flag is set to "1" when a receive FIFO overrun is detected. This flag is cleared when the receive FIFO is read.

"1" = Receive FIFO overrun detected

"0" = Receive FIFO overrun not detected

#### [bit 6] PERR: Parity Error Flag

Indicates that a parity error occurred. If a parity error is detected while reading from a single RAM block of the FlexRay protocol controller, this flag is set to "1". This flag is cleared to "0" when the parity error

flag of the MHDS register is cleared to "0". See "■ Message Handler Status Register (MHDS)".

"1" = Parity error detected

"0" = Parity error not detected

**[bit 5] CCL: CHI Command Locked Flag**

Indicates that SUCC1:CMD3 to CMD0 has been reset to "0000<sub>B</sub>" as a result of a CHI command being executed at the same time as the POC status changed as a result of the FlexRay protocol function. The CNA bit is also set to "1" in this situation.

"1" = The CHI command was not accepted

"0" = The CHI command was accepted

**[bit 4] CCF: Clock Correction Error Flag**

This bit is set to "1" when the cycle finishes if any of the following errors occurs.

- Rate correction error
- Offset correction error
- Clock correction limit exceeded

The clock correction status can be monitored using the CCEV register and the SFS register. This flag may become set during startup. This flag should therefore be cleared after the device changes to the NORMAL\_ACTIVE state.

"1" = Clock correction error

"0" = No clock correction error

**[bit 3] SFO: Sync Frame Overflow Flag**

This bit is set to "1" if the number of sync frames received during the previous communication cycle exceeded the maximum number of sync frames as defined by GTUC2:SNM3 to SNM0.

"1" = The number of sync frames received was larger than the value of the GTUC2:SNM3 to SNM0 setting.

"0" = The number of sync frames received was less than or equal to the value of the GTUC2:SNM3 to SNM0 setting.

**[bit 2] SFBM: Sync Frames Below Minimum Flag**

This bit is set to "1" if the number of sync frames received during the previous communication cycle was less than the minimum required by the FlexRay protocol. This flag may become set during startup. This flag should therefore be cleared after the device changes to the NORMAL\_ACTIVE state.

"1" = The number of sync frames received was less than the minimum number required.

"0" = Synchronous node: One or more sync frames was received.

Asynchronous node: Two or more sync frames were received.

**[bit 1] CNA: Command Not Accepted Flag**

Indicates that SUCC1:CMD3 to CMD0 was reset to "0000<sub>B</sub>" because either the requested command cannot be used in the current POC state, or because CHI commands are locked (CCL = 1).

"1" = The CHI command was not accepted

"0" = The CHI command was accepted

**[bit 0] PEMC: POC Error Mode Changed Flag**

This bit is set to "1" if the error mode represented by CCEV:ERRM1 and ERRM0 is changed.

"1" = Error mode was changed

"0" = Error mode was not changed

## ■ Status Interrupt Register (SIR)

If any of the events listed below are detected, the corresponding flag in this register is set to "1". The flag can be cleared by writing "1" to the corresponding bit, and will remain in the set state until "0" is written to the bit. Writing "0" to this flag has no effect on operation. This register is cleared by a hardware reset.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0024 <sub>H</sub>	R	0	0	0	0	0	0	MTSB	WUPB	0	0	0	0	0	0	MTSA	WUPA
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R																
	W	SDS	MBSI	SUCS	SWE	TOBC	TIBC	TI1	TIO	NMVC	RFCL	RFNE	RXI	TXI	CYCS	CAS	WST
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

### [bit 25] MTSB: MTS Received on ch.B Flag

Indicates that a media access test symbol (MTS) was received on ch.B during the latest symbol window. This flag is updated when the symbol window finishes.

"1" = MTS symbol received on ch.B

"0" = MTS symbol not received on ch.B

### [bit 24] WUPB: Wakeup Pattern ch.B Flag

This flag is set to "1" if the CC is in the wakeup, ready, startup, or monitor modes, and a wakeup pattern is received on ch.B.

"1" = Wakeup pattern received on ch.B

"0" = Wakeup pattern not received on ch.B

### [bit 17] MTSA: MTS Received on ch.A Flag

Indicates that a media access test symbol (MTS) was received on ch.A during the latest symbol window. This flag is updated when the symbol window finishes.

"1" = MTS symbol received on ch.A

"0" = MTS symbol not received on ch.A

### [bit 16] WUPA: Wakeup Pattern ch.A Flag

This flag is set to "1" if the CC is in the wakeup, ready, startup, or monitor modes, and a wakeup pattern is received on ch.A.

"1" = Wakeup pattern received on ch.A

"0" = Wakeup pattern not received on ch.A

### [bit 15] SDS: Start of Dynamic Segment Flag

This flag is set to "1" when a dynamic segment is started.

"1" = A dynamic segment has started

"0" = A dynamic segment has not started

**[bit 14] MBSI: Message Buffer Status Interrupt Flag**

This flag is set to "1" if the MBI bit of a dedicated receive buffer is set to "1" and the message buffer status (MBS) changes (see Figure 2.7-15).

"1" = The message buffer status has changed in at least one message buffer where the MBI is set to "1"

"0" = The message buffer status has not changed in any of the message buffers where the MBI is set to "1"

**[bit 13] SUCS: Startup Completed Successfully Flag**

This flag is set to "1" when startup has completed successfully and the device is set to the NORMAL\_ACTIVE state.

"1" = Startup completed successfully

"0" = Startup not completed successfully

**[bit 12] SWE: Stop Watch Event Flag**

Stop watch events are generated by the trigger event when the STPW1:SSWT bit is set to enabled.

"1" = A stop watch event has occurred

"0" = A stop watch event has not occurred

**[bit 11] TOBC: Transfer Output Buffer Completed Flag**

This flag is set to "1" when a transfer from the message RAM to the output buffer is completed, or OBCR:OBSYS is reset.

"1" = A transfer between the message RAM and the output buffer has completed

"0" = A transfer between the message RAM and the output buffer is not complete

**[bit 10] TIBC: Transfer Input Buffer Completed Flag**

This flag is set to "1" when a transfer from the input buffer to the message RAM is completed, or IBCR:IBSYS is reset.

"1" = A transfer between the input buffer and the message RAM has completed

"0" = A transfer between the input buffer and the message RAM is not complete

**[bit 9] T1I: Timer 1 Interrupt Flag**

This flag is set to "1" when the value of Timer 1 matches the value of T1C.

"1" = The value of Timer 1 matches the value of T1C

"0" = The value of Timer 1 does not match the value of T1C

**[bit 8] T0I: Timer 0 Interrupt Flag**

This flag is set to "1" when the value of Timer 0 matches the value of T0C.

"1" = The value of Timer 0 matches the value of T0C

"0" = The value of Timer 0 does not match the value of T0C

**[bit 7] NMVC: Network Management Vector Changed Flag**

Indicates changes to the network management vector.

"1" = The network management vector has changed

"0" = The network management vector has not changed

**[bit 6] RFCL: Receive FIFO Critical Level Flag**

This flag is set to "1" when the receive FIFO level (FSR:RFFL7 to RFFL0) reaches or exceeds the critical level (FCL:CL7 to CL0).

"1" = The receive FIFO level has reached or exceeds the critical level

"0" = The receive FIFO level is less than the critical level

**[bit 5] RFNE: Receive FIFO Not Empty Flag**

This flag is set to "1" when a valid frame is stored in the receive FIFO.

"1" = The receive FIFO is not empty

"0" = The receive FIFO is empty

**[bit 4] RXI: Receive Interrupt Flag**

This flag is set to "1" when the payload segment of a received valid frame is stored in any receive buffer where the MBI bit of the message buffer is set to "1" (see Figure 2.7-15).

"1" = At least one data section has been updated in a receive buffer where the MBI bit is set to "1"

"0" = No data sections have been updated in any receive buffers where the MBI bit is set to "1"

**[bit 3] TXI: Transmit Interrupt Flag**

This flag is set to "1" after the successful transmission of a frame from any message buffer where the MBI bit is set to "1" (see Figure 2.7-15).

"1" = At least one frame has been transmitted successfully from a transmit buffer in which the MBI bit is set to "1"

"0" = No frames have been transmitted from transmit buffers in which the MBI bit is set to "1"

**[bit 2] CYCS: Communication Cycle Start Interrupt Flag**

This flag is set to "1" when the communication cycle starts.

"1" = The communication cycle has started

"0" = The communication cycle has not started

**[bit 1] CAS: Collision Avoidance Symbol Flag**

This flag is set to "1" when a CAS is received.

"1" = A collision avoidance symbol has been received

"0" = A collision avoidance symbol has not been received

**[bit 0] WST: Wakeup Status Flag**

This flag is set to "1" when there is a change in CCSV:WSV2 to WSV0.

"1" = The wakeup status has changed

"0" = The wakeup status has not changed

■ Error Interrupt Line Select Register (EILS)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0028 <sub>H</sub>	R	0	0	0	0				0	0	0	0	0				
	W					TABBL	LTVBL	EDBL						TABAL	LTVAL	EDAL	
Reset		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	0												
	W					MHFL	IOBAL	IIBAL	EFAL	RFOL	PERRL	CCLL	CCFL	SFOL	SFBML	CNAL	PEMCL
Reset		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

This register selects which of the following lines are used to generate the interrupts due to the error interrupt flags in the EIR register.

"1" = The interrupt is generated using the INT1 pin.

"0" = The interrupt is generated using the INT0 pin.

[bit 26] TABBL: Transmission Across Boundary ch.B Interrupt Line Selection

[bit 25] LTVBL: Latest Transmit Violation ch.B Interrupt Line Selection

[bit 24] EDBL: Error Detected on ch.B Interrupt Line Selection

[bit 18] TABAL: Transmission Across Boundary ch.A Interrupt Line Selection

[bit 17] LTVAL: Latest Transmit Violation ch.A Interrupt Line Selection

[bit 16] EDAL: Error Detected on ch.A Interrupt Line Selection

[bit 11] MHFL: Message Handler Constraints Flag Interrupt Line Selection

[bit 10] IOBAL: Illegal Output Buffer Access Interrupt Line Selection

[bit 9] IIBAL: Illegal Input Buffer Access Interrupt Line Selection

[bit 8] EFAL: Empty FIFO Access Interrupt Line Selection

[bit 7] RFOL: Receive FIFO Overrun Interrupt Line Selection

[bit 6] PERRL: Parity Error Interrupt Line Selection

[bit 5] CCLL: CHI Command Locked Interrupt Line Selection

[bit 4] CCFL: Clock Correction Failure Interrupt Line Selection

[bit 3] SFOL: Sync Frame Overflow Interrupt Line Selection

[bit 2] SFBML: Sync Frames Below Minimum Interrupt Line Selection

[bit 1] CNAL: Command Not Accepted Interrupt Line Selection

[bit 0] PEMCL: POC Error Mode Changed Interrupt Line Selection

## ■ Status Interrupt Line Select Register (SILS)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
002C <sub>H</sub>	R	0	0	0	0	0	0	MTSBL	WUPBL	0	0	0	0	0	0	MTSAL	WUPAL
	W																
Reset	0	0	0	0	0	0	1	1	0	0	0	0	0	0	1	1	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R																
	W	SDSL	MBSIL	SUCSL	SWEL	TOBCL	TIBCL	TI1L	TI0L	NMVCL	RFCLL	RFNEL	RXIL	TXIL	CYCSL	CASL	WSTL
Reset	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	

This register selects which of the following lines are used to generate the interrupts due to the error interrupt flags in the SIR register.

"1" = The interrupt is generated using the INT1 pin.

"0" = The interrupt is generated using the INT0 pin.

[bit 25] MTSBL: Media Access Test Symbol ch.B Interrupt Line Selection

[bit 24] WUPBL: Wakeup Pattern ch.B Interrupt Line Selection

[bit 17] MTSAL: Media Access Test Symbol ch.A Interrupt Line Selection

[bit 16] WUPAL: Wakeup Pattern ch.A Interrupt Line Selection

[bit 15] SDSL: Start of Dynamic Segment Interrupt Line Selection

[bit 14] MBSIL: Message Buffer Status Interrupt Line Selection

[bit 13] SUCSL: Startup Completed Successfully Interrupt Line Selection

[bit 12] SWEL: Stop Watch Event Interrupt Line Selection

[bit 11] TOBCL: Transfer Output Buffer Completed Interrupt Line Selection

[bit 10] TIBCL: Transfer Input Buffer Completed Interrupt Line Selection

[bit 9] TI1L: Timer 1 Interrupt Line Selection

[bit 8] TI0L: Timer 0 Interrupt Line Selection

[bit 7] NMVCL: Network Management Vector Changed Interrupt Line Selection

[bit 6] RFCLL: Receive FIFO Critical Level Interrupt Line Selection

[bit 5] RFNEL: Receive FIFO Not Empty Interrupt Line Selection

[bit 4] RXIL: Receive Interrupt Line Selection

[bit 3] TXIL: Transmit Interrupt Line Selection

[bit 2] CYCSL: Communication Cycle Start Interrupt Line Selection

[bit 1] CASL: Collision Avoidance Symbol Interrupt Line Selection

[bit 0] WSTL: Wakeup Status Interrupt Line Selection

### ■ Error Interrupt Enable Set/Reset Registers (EIES, EIER)

The configuration of these registers determines which status changes within the Error Interrupt Register (EIR) generate an interrupt.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0030 <sub>H</sub> 0034 <sub>H</sub>	R	0	0	0	0				0	0	0	0	0			
	W						TABBE	LTVBE	EDBE					TABAE	LTVAE	EDAE
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	R	0	0	0	0											
	W					MHFE	IOBAE	IIBAE	EFAE	RFOE	PERRE	CCLC	CCFE	SFOE	SFBME	CNAE
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

The interrupt enable flags can be enabled by writing "1" to address 0030<sub>H</sub> and disabled by writing "0" to address 0034<sub>H</sub>. Writing "0" to either address does not change the enabled flags. The same value is read from both registers (EIES/EIER). The value indicates the following meaning.

"1" = Interrupt enabled

"0" = Interrupt disabled

[bit 26] TABBE: Transmission Across Boundary ch.B Interrupt Enable Flag

[bit 25] LTVBE: Latest Transmit Violation ch.B Interrupt Enable Flag

[bit 24] EDBE: Error Detected on ch.B Interrupt Enable Flag

[bit 18] TABAE: Transmission Across Boundary ch.A Interrupt Enable Flag

[bit 17] LTVAE: Latest Transmit Violation ch.A Interrupt Enable Flag

[bit 16] EDAE: Error Detected on ch.A Interrupt Enable Flag

[bit 11] MHFE: Message Handler Constraints Flag Interrupt Enable Flag

[bit 10] IOBAE: Illegal Output Buffer Access Interrupt Enable Flag

[bit 9] IIBAE: Illegal Input Buffer Access Interrupt Enable Flag

[bit 8] EFAE: Empty FIFO Access Interrupt Enable Flag

[bit 7] RFOE: Receive FIFO Overrun Interrupt Enable Flag

[bit 6] PERRE: Parity Error Interrupt Enable Flag

[bit 5] CCLC: CHI Command Locked Interrupt Enable Flag

[bit 4] CCFE: Clock Correction Error Interrupt Enable Flag

[bit 3] SFOE: Sync Frame Overflow Interrupt Enable Flag

[bit 2] SFBME: Sync Frames Below Minimum Interrupt Enable Flag

[bit 1] CNAE: Command Not Accepted Interrupt Enable Flag

[bit 0]PEMCE: POC Error Mode Changed Interrupt Enable Flag

## ■ Status Interrupt Enable Set/Reset Registers (SIES, SIER)

The configuration of these registers determines which status changes within the Status Interrupt Register (SIR) generate an interrupt.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0038 <sub>H</sub> 003C <sub>H</sub>	R	0	0	0	0	0	0			0	0	0	0	0	0		
	W							MTSBE	WUPBE							MTSAE	WUPAE
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R																
	W	SDSE	MBSIE	SUCSE	SWEE	TOBCE	TIBCE	TI1E	TIOE	NMVCE	RFCLE	RFNEE	RXIE	TXIE	CYCSE	CASE	WSTE
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

The interrupt enable flags can be enabled by writing "1" to address 0038<sub>H</sub> and disabled by writing "1" to address 003C<sub>H</sub>. Writing "0" to either address does not change the enabled flags. The same value is read from both registers (SIES/SIER). The value indicates the following meaning.

"1" = Interrupt enabled

"0" = Interrupt disabled

[bit 25] MTSBE: MTS Received on ch.B Interrupt Enable Flag

[bit 24] WUPBE: Wakeup Pattern ch.B Interrupt Enable Flag

[bit 17] MTSAE: MTS Received on ch.A Interrupt Enable Flag

[bit 16] WUPAE: Wakeup Pattern ch.A Interrupt Enable Flag

[bit 15] SDSE: Start of Dynamic Segment Interrupt Enable Flag

[bit 14] MBSIE: Message Buffer Status Interrupt Enable Flag

[bit 13] SUCSE: Startup Completed Successfully Interrupt Enable Flag

[bit 12] SWEE: Stop Watch Event Interrupt Enable Flag

[bit 11] TOBCE: Transfer Output Buffer Completed Interrupt Enable Flag

[bit 10] TIBCE: Transfer Input Buffer Completed Interrupt Enable Flag

[bit 9] TI1E: Timer 1 Interrupt Enable Flag

[bit 8] TIOE: Timer 0 Interrupt Enable Flag

[bit 7] NMVCE: Network Management Vector Changed Interrupt Enable Flag

[bit 6] RFCLE: Receive FIFO Critical Level Interrupt Enable Flag

[bit 5] RFNEE: Receive FIFO Not Empty Interrupt Enable Flag

[bit 4] RXIE: Receive Interrupt Enable Flag

[bit 3] TXIE: Transmit Interrupt Enable Flag

[bit 2] CYCSE: Communication Cycle Start Interrupt Enable Flag

[bit 1] CASE: Collision Avoidance Symbol Interrupt Enable Flag

[bit 0] WSTE: Wakeup Status Interrupt Enable Flag

**Interrupt Line Enable Register (ILE)**

Interrupts can be enabled and disabled separately on the two interrupt lines (INT0 and INT1) by setting the EINT0 and EINT1 bits to "1".

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0040 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	W															
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	R	0	0	0	0	0	0	0	0	0	0	0	0	0	EINT1	EINT0
	W															
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

- [bit 1] EINT1: Enable Interrupt Line 1
  - "1" = Interrupt line (INT1) enabled
  - "0" = Interrupt line (INT1) disabled
- [bit 0] EINT0: Enable Interrupt Line 0
  - "1" = Interrupt line (INT0) enabled
  - "0" = Interrupt line (INT0) disabled

**Timer 0 Configuration Register (T0C)**

Specifies the time that Timer 0 generates an interrupt in units of cycle counts and macroticks. When the Timer 0 interrupt occurs, the INT2 interrupt output is set to "1" for a duration of 1 macrotick, and SIR:TIO is also set to "1".

Timer 0 is able to operate when the POC is in the NORMAL\_ACTIVE state or the NORMAL\_PASSIVE state. Timer 0 stops operating when the POC is in other states.

To reconfigure Timer 0, write "0" to the T0RC bit to stop the timer.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0044 <sub>H</sub>	R	0	0													
	W			T0MO13	T0MO12	T0MO11	T0MO10	T0MO9	T0MO8	T0MO7	T0MO6	T0MO5	T0MO4	T0MO3	T0MO2	T0MO1
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	R	0							0	0	0	0	0	0		
	W		T0CC6	T0CC5	T0CC4	T0CC3	T0CC2	T0CC1	T0CC0						T0MS	T0RC
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 29 to bit 16] T0MO13 to T0MO0: Timer 0 Macrotick Offset Setting

Configures the Timer 0 interrupt generation offset time from the cycle configured in the cycle set. This offset time is specified in units of macroticks. The cycle set is configured using T0CC6 to T0CC0.

[bit 14 to bit 8] T0CC6 to T0CC0: Timer 0 Cycle Code Setting

Configures the cycle set that is used to generate the Timer 0 interrupt.

[bit 1] T0MS: Timer 0 Mode Select

"1" = Continuous mode

"0" = Single-shot mode

[bit 0] T0RC: Timer 0 Run Control

"1" = Timer 0 running

"0" = Timer 0 stopped

---

#### Note:

In the event of a state transition from the NORMAL\_ACTIVE state or the NORMAL\_PASSIVE state to another state, or if Timer 0 is stopped by clearing T0RC to "0", the INT2 interrupt output immediately outputs "L".

---

### ■ Timer 1 Configuration Register (T1C)

The Timer 1 interrupt is generated when Timer 1 reaches the specified number of macroticks. When the Timer 1 interrupt occurs, the interrupt output (INT3) is set to "1" for a duration of 1 macrotick, and SIR:T1I is also set to "1".

Timer 1 is able to operate when the POC is in the NORMAL\_ACTIVE state or the NORMAL\_PASSIVE state. Timer 1 stops operating when the POC is in other states.

To reconfigure Timer 1, write a "0" to the T1RC bit to stop the timer.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0048 <sub>H</sub>	R	0	0	T1MC13	T1MC12	T1MC11	T1MC10	T1MC9	T1MC8	T1MC7	T1MC6	T1MC5	T1MC4	T1MC3	T1MC2	T1MC1	T1MC0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	0	0	0	0	0	0	0	0	0	0	T1MS	T1RC	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

[bit 29 to bit 16] T1MC13 to T1MC0:Timer 1 Macrotick Count

The Timer 1 interrupt is generated when Timer 1 matches the specified macrotick count. Timer 1 will not start if the specified macrotick count is outside of the permissible range.

Valid values: 2 to 16383 MT (continuous mode)

1 to 16383 MT (single-shot mode)

[bit 1] T1MS Timer 1 Mode Select

"1" = Continuous mode

"0" = Single-shot mode

[bit 0] T1RC Timer 1 Run Control

"1" = Timer 1 running

"0" = Timer 1 stopped

---

**Note:**

In the event of a state transition from the NORMAL\_ACTIVE state or the NORMAL\_PASSIVE state to another state, or if Timer 1 is stopped by clearing T1RC to "0", the interrupt output (INT3) immediately outputs "L".

---

## ■ Stop Watch Register 1 (STPW1)

The stop watch is triggered under the following conditions.

- A rising or falling edge is input on the STPW pin
- Interrupt "0" or "1" is generated
- "1" is written to the SSWT bit

The macrotick counter addition begins after the stop watch has been activated. The actual cycle counter value and macrotick value are stored in the stop watch registers. These values can be read by the host.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
004C <sub>H</sub>	R	0	0	SMTV13	SMTV12	SMTV11	SMTV10	SMTV9	SMTV8	SMTV7	SMTV6	SMTV5	SMTV4	SMTV3	SMTV2	SMTV1	SMTV0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	SCCV5	SCCV4	SCCV3	SCCV2	SCCV1	SCCV0	0	EINT1	EINT0	EETP	SSWT	EDGE	SWMS	ESWT
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 29 to bit 16] SMTV13 to SMTV0: Stopped Macrotick Value

The macrotick counter value when the stop watch event occurred. Valid values are in the range of 0 to 16000.

[bit 13 to bit 8] SCCV5 to SCCV0: Stopped Cycle Counter Value

The cycle counter value when the stop watch event occurred. Valid values are in the range of 0 to 63.

[bit 6] EINT1: Enable Interrupt 1 Trigger

If ESWT=1, the stop watch is triggered by interrupt 1 events.

"1" = Enabled

"0" = Disabled

[bit 5] EINT0: Enable Interrupt 0 Trigger

If ESWT=1, the stop watch is triggered by interrupt 0 events.

"1" = Enabled

"0" = Disabled

[bit 4] EETP: Enable External Trigger Pin

If ESWT=1, the stop watch is triggered by edge signals on the input pin (STPW).

"1" = Enabled

"0" = Disabled

[bit 3] SSWT: Software Stop Watch Trigger

The host can trigger the stop watch by setting this bit to "1". This bit is cleared to "0" after the actual cycle counter value and macrotick value are stored in the stop watch register.

This bit can be written to while ESWT=0.

"1" = The stop watch is triggered by the software trigger

"0" = The software trigger is cleared

[bit 2] EDGE: Stop Watch Trigger Edge Select

"1" = Rising edge

"0" = Falling edge

[bit 1] SWMS: Stop Watch Mode Select

"1" = Continuous

"0" = Single-shot

[bit 0] ESWT: Enable Stop Watch Trigger

When the stop watch is enabled, the stop watch is triggered by edge signals on the input pin (STPW), or by interrupts 0 or 1 (rising edge of INT0 or INT1). In single-shot mode, this bit is reset to "0" after the stop watch event occurs.

"1" = Enabled

"0" = Disabled

Note:

The ESWT bit and the SSWT bit cannot be set to "1" at the same time. The write access has no effect on the operation if this is attempted. Furthermore, both bits retain the values from prior to the write access. This applies irrespective of whether external stop watch triggers or software stop watch triggers are being used.

■ Stop Watch Register 2 (STPW2)

The host is able to read the stop watch counter value of ch.A and ch.B.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0050 <sub>H</sub>	R	0	0	0	0	0	SSCVB10	SSCVB9	SSCVB8	SSCVB7	SSCVB6	SSCVB5	SSCVB4	SSCVB3	SSCVB2	SSCVB1	SSCVB0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	0	0	SSCVA10	SSCVA9	SSCVA8	SSCVA7	SSCVA6	SSCVA5	SSCVA4	SSCVA3	SSCVA2	SSCVA1	SSCVA0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 26 to bit 16] SSCVB10 to SSCVB0: Stop Watch Counter Value ch.B

The value of the ch.B stop watch counter when the event occurred (0 to 2047)

[bit 10 to bit 0] SSCVA10 to SSCVA0: Stop Watch Counter Value ch.A

The value of the ch.A stop watch counter when the event occurred (0 to 2047)

## 2.3.4 Communication Controller (CC) Control Registers

This section explains the bit configurations and functions of the communication controller (CC) control registers.

### ■ Communication Controller (CC) Control Registers

This section explains the registers that control the FlexRay communication controller (CC). Under the FlexRay protocol specifications, the application configuration data must set while in the CONFIG state. Note that writes to the configuration registers are not locked while in the DEFAULT\_CONFIG state.

When a hard reset is initiated, the controller changes to the DEFAULT\_CONFIG state and each of the registers are initialized. The protocol operation controller (POC) sets CMD3 to CMD0 = 0001<sub>B</sub> (CHI command CONFIG) to change from the DEFAULT\_CONFIG state to the CONFIG state. Follow the procedure described in "■ Lock Register (LCK)" to change from the CONFIG state to the READY state.

All of the bits marked with an asterisk (\*) can only be updated in the DEFAULT\_CONFIG or CONFIG states.

### ■ SUC Configuration Register 1 (SUCC1)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0080 <sub>H</sub>	R	0	0	0	0	CCHB*	CCHA*	MTSB*	MTSA*	HCSE*	TSM*	WUCS*	PTA4*	PTA3*	PTA2*	PTA1*	PTA0*
	W																
Reset	0	0	0	0	1	1	0	0	0	1	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	CSA4*	CSA3*	CSA2*	CSA1*	CSA0*	0	TXSY*	TXST*	PBSY	0	0	0	CMD3	CMD2	CMD1	CMD0
	W																
Reset	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 27] CCHB: Connected to ch.B (pChannels)

Specifies whether or not the node is connected to ch.B.

"1" = The node is connected to ch.B

"0" = The node is not connected to ch.B

[bit 26] CCHA: Connected to ch.A (pChannels)

Specifies whether or not the node is connected to ch.A.

"1" = The node is connected to ch.A

"0" = The node is not connected to ch.A

**[bit 25] MTSB: Select ch.B for MTS Transmission**

Selects whether or not to use ch.B for MTS symbol transmission. The default is cleared to "0", and can only be changed in the DEFAULT\_CONFIG or CONFIG states.

"1" = ch.B is used to transmit the MTS symbol

"0" = ch.B is not used to transmit the MTS symbol

**[bit 24] MTSA: Select ch.A for MTS Transmission**

Selects whether or not to use ch.A for MTS symbol transmission. This bit is cleared to "0" by default, and can only be changed in the DEFAULT\_CONFIG or CONFIG states.

"1" = ch.A is used to transmit the MTS symbol

"0" = ch.A is not used to transmit the MTS symbol

**Note:**

If MTSA and MTSB are both set at the same time, the MTS symbol is transmitted on both channels when 1000<sub>B</sub> is written to CMD3 to CMD0.

**[bit 23] HCSE: Halt due to Clock Sync Error (pAllowHaltDueToClock)**

Controls the transition to the HALT state if a clock synchronization error occurs. This bit can change only the DEFAULT\_CONFIG or CONFIG states.

"1" = Change to the HALT state when a clock synchronization error occurs

"0" = Remain in the NORMAL\_PASSIVE state when a clock synchronization error occurs

**[bit 22] TSM: Transmission Slot Mode (pSingleSlotEnabled)**

Selects the initial slot mode. In single slot mode, transmission is only possible on the previously configured key slot. This slot is defined by the key slot ID configured in the header section of message buffer 0. In the all slot mode, all slots can be used for transmission.

This bit can change only the DEFAULT\_CONFIG or CONFIG states. However, it is possible to change to the all slot mode if the ALL\_SLOT command is executed by setting CMD3 to CMD0 to 0101<sub>B</sub> while in the NORMAL\_ACTIVE or NORMAL\_PASSIVE states. The TSM bit is write-only. The currently executing slot mode can be monitored using CCSV:SLM1 and SLM0.

"1" = Single slot mode

"0" = All slot mode

**[bit 21] WUCS: Wakeup Channel Select (pWakeupChannel)**

Selects the channel of the wakeup pattern transmission. Changes to this bit has no effect on the operation if the node is not in the DEFAULT\_CONFIG or CONFIG states.

"1" = Transmits the wakeup pattern on ch.B

"0" = Transmits the wakeup pattern on ch.A

**[bit 20 to bit 16] PTA4 to PTA0: Passive to Active (pAllowPassiveToActive)**

This parameter defines the valid clock correction time needed to change from NORMAL\_PASSIVE state to NORMAL\_ACTIVE state in the number of consecutive even/odd cycle pairs. If this parameter is set to "0000<sub>B</sub>", the node cannot change from NORMAL\_PASSIVE state to NORMAL\_ACTIVE state. This bit can be changed only the DEFAULT\_CONFIG or CONFIG states. Valid values are in the range of 0 to 31.

**[bit 15 to bit 11] CSA4 to CSA0: Cold Start Attempts (gColdStartAttempts)**

When a coldstart node is performing network startup, the startup is repeated if a valid response is not received from another node. This parameter defines the maximum number of retry attempts that are

allowed. This value can change only the DEFAULT\_CONFIG or CONFIG states. Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 2 to 31.

[bit 9] TXSY: Transmit Sync Frame in Key Slot (pKeySlotUsedForSync)

Determines whether or not the key slot is used to transmit a sync frame. This bit can change only the DEFAULT\_CONFIG or CONFIG states.

"1" = The key slot is used to transmit a sync frame. The node is in sync.

"0" = The key slot is not used to transmit a sync frame. The node is not in coldstart or sync.

[bit 8] TXST: Transmit Startup Frame in Key Slot (pKeySlotUsedForStartup)

Determines whether or not the key slot is used to transmit a startup frame. This bit can change only the DEFAULT\_CONFIG or CONFIG states.

"1" = The key slot is used to transmit a startup frame. The node is in coldstart.

"0" = The key slot is not used to transmit a startup frame. The node is not in coldstart.

Note:

Set both the TXST and TXSY bits to "1" to transmit a startup frame.

[bit 7] PBSY: POC Busy

This flag indicates that the POC is busy and is unable to receive commands. When PBSY=1, CMD3 to CMD0 are locked against write accesses. After a hardware reset, this flag is set to "1" during initialization of the internal RAM.

"1" = POC busy. CMD3 to CMD0 are locked

"0" = POC idle. CMD3 to CMD0 are writable

[bit 3 to bit 0] CMD3 to CMD0: CHI Command Vector

Although this CHI command vector is always writable, particular commands are only valid in particular POC states. If a command is invalid, the CHI command vectors CMD3 to CMD0 are reset to "0000<sub>B</sub>" (command\_not\_accepted) and EIR:CNA is set to "1" without executing the command. The CHI command needs to be repeated if EIR:CCL and EIR:CNA are both set to "1". If a command to change to a particular POC state is given while the device is already in that POC state, the command has no effect on the operation.

0000 = command\_not\_accepted

0001 = CONFIG

0010 = READY

0011 = WAKEUP

0100 = RUN

0101 = ALL\_SLOTS

0110 = HALT

0111 = FREEZE

1000 = SEND\_MTS

1001 = ALLOW\_COLDSTART

1010 = RESET\_STATUS\_INDICATORS

1011 = MONITOR\_MODE

1100 = CLEAR\_RAMs

1101 = reserved

1110 = reserved

1111 = reserved

Reading CMD3 to CMD0 returns the most recently accepted CHI command. The actual POC state can be monitored using CCSV:POCS5 to POCS0. The "reserved" CHI commands are used by hardware test functions.

#### command\_not\_accepted

Writing CMD3 to CMD0 = 0000<sub>B</sub> will reset CMD3 to CMD0 = 0000<sub>B</sub> under any of the following conditions.

- An invalid command is specified
- A command is specified during the internal POC state change period
- A new command is specified while a CHI command is executing
- command\_not\_accepted is specified

If a command is invalid, the CHI command vectors CMD3 to CMD0 are reset to "0000<sub>B</sub>" (command\_not\_accepted) and EIR:CNA is set to "1" without executing the command. An interrupt is generated if interrupts are enabled.

#### CONFIG

If CMD3 to CMD0 are set to 0001<sub>B</sub> while in the DEFAULT\_CONFIG, READY, or MONITOR\_MODE states, the device changes to the CONFIG state. If CMD3 to CMD0 are set to 0001<sub>B</sub> while in the HALT state, the device changes to the DEFAULT\_CONFIG state. If CMD3 to CMD0 are set to 0001<sub>B</sub> while in any other state, CMD3 to CMD0 are reset to 0000<sub>B</sub> (command\_not\_accepted).

#### READY

If CMD3 to CMD0 are set to 0010<sub>B</sub> while in the CONFIG, NORMAL\_ACTIVE, NORMAL\_PASSIVE, STARTUP, or WAKEUP states, the device changes to the READY state. If CMD3 to CMD0 are set to 0010<sub>B</sub> while in any other state, CMD3 to CMD0 are reset to 0000<sub>B</sub> (command\_not\_accepted).

#### WAKEUP

If CMD3 to CMD0 are set to 0011<sub>B</sub> while in the READY state, the device changes to the WAKEUP state. If CMD3 to CMD0 are set to 0011<sub>B</sub> while in any other state, CMD3 to CMD0 are reset to 0000<sub>B</sub> (command\_not\_accepted).

#### RUN

If CMD3 to CMD0 are set to 0100<sub>B</sub> while in the READY state, the device changes to the STARTUP state. If CMD3 to CMD0 are set to 0100<sub>B</sub> while in any other state, CMD3 to CMD0 are reset to 0000<sub>B</sub> (command\_not\_accepted).

#### ALL\_SLOTS

If CMD3 to CMD0 are set to 0101<sub>B</sub> while in the NORMAL\_ACTIVE or NORMAL\_PASSIVE states, the device changes from single slot mode to all slot mode after successfully completing the startup/integration in the completion following the present cycle. If CMD3 to CMD0 are set to 0101<sub>B</sub> while in any other state, CMD3 to CMD0 are reset to 0000<sub>B</sub> (command\_not\_accepted).

#### HALT

If CMD3 to CMD0 are set to 0110<sub>B</sub> while in the NORMAL\_ACTIVE or NORMAL\_PASSIVE states, the halt request bit CCSV:HRQ is set to "1", and the device changes to the HALT state in the completion following the present cycle. If CMD3 to CMD0 are set to 0110<sub>B</sub> while in any other state, CMD3 to CMD0 are reset to 0000<sub>B</sub> (command\_not\_accepted).

#### FREEZE

If CMD3 to CMD0 are set to 0111<sub>B</sub>, the freeze status indicator CCSV:FSI is set to "1" and the device immediately enters the HALT state. This command can be set while in any state.

**SEND\_MTS**

If CMD3 to CMD0 are set to 1000<sub>B</sub> while in the NORMAL\_ACTIVE state after setting the all slot mode (CCSV:SLM1, SLM0 = 11<sub>B</sub>), a single MTS symbol is transmitted on the channels specified by MTSA and MTSB during the following symbol window. If CMD3 to CMD0 are set to 1000<sub>B</sub> while in any other state, CMD3 to CMD0 are reset to 0000<sub>B</sub> (command\_not\_accepted).

**ALLOW\_COLDSTART**

If CMD3 to CMD0 are set to 1001<sub>B</sub> while in a state other than the DEFAULT\_CONFIG, CONFIG, and HALT states, the CCSV:CSI bit should be cleared to "0" to enable the node coldstart. If CMD3 to CMD0 are set to 1001<sub>B</sub> while in the DEFAULT\_CONFIG, CONFIG, or HALT states, CMD3 to CMD0 are reset to 0000<sub>B</sub> (command\_not\_accepted). TXST and TXSY both also need to be set in order to enable coldstart.

**RESET\_STATUS\_INDICATORS**

If CMD3 to CMD0 are set to 1010<sub>B</sub>, all of the CCSV:FSI, HRQ, CSNI, and CSAI status flags are reset. This command can be set while in any state.

**CLEAR\_RAMs**

If CMD3 to CMD0 are set to 1100<sub>B</sub> while in the DEFAULT\_CONFIG or CONFIG states, MHDS:CRAM is set to "1". If CMD3 to CMD0 are set to 1100<sub>B</sub> while in any other state, CMD3 to CMD0 are reset to 0000<sub>B</sub> (command\_not\_accepted). MHDS:CRAM is also set to "1" after a hardware reset. All of the internal RAM blocks are initialized to zero by setting MHDS:CRAM to "1". During the RAM initialization, PBSY indicates POC busy.

Initialization of the internal RAM blocks of the FlexRay controller requires 2048 f\_bclk cycles (configuration of f\_bclk is performed using CCNT:RCLK. See "■ Version Information Register (VER)"). After a hardware reset, or after setting CMD3 to CMD0 to 1100<sub>B</sub> (CHI command CLEAR\_RAMs), do not access the IBF or OBF while the internal RAM block is being initialized. Before setting CMD3 to CMD0 to 1100<sub>B</sub>, verify that there are no transfer in progress between the message RAM and the IBF/OBF.

This setting resets the message buffer status registers (MHDS, TXRQ1, TXRQ2, TXRQ3, TXRQ4, NDAT1, NDAT2, NDAT3, NDAT4, MBSC1, MBSC2, MBSC3, and MBSC4).

**Note:**

The configuration registers and status registers can be accessed while the CHI command CLEAR\_RAMs (CMD3 to CMD0 = 1100<sub>B</sub>) is executing.

**MONITOR\_MODE**

If CMD3 to CMD0 are set to 1011<sub>B</sub> while in the CONFIG state, the device changes to the MONITOR\_MODE state. In this mode, FlexRay frames and CAS/MTS symbols can be received, and coding errors can also be detected. However, the time of the received frames is not checked. This mode can be used for debugging purposes. For example, this mode can be used if the FlexRay network startup was failed to analyze the cause of the failure. If CMD3 to CMD0 are set to 1011<sub>B</sub> while in any other state, CMD3 to CMD0 are reset to 0000<sub>B</sub> (command\_not\_accepted).

### ■ SUC Configuration Register 2 (SUCC2)

This register can only be changed in the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0084 <sub>H</sub>	R	0	0	0	0	LTN3*	LTN2*	LTN1*	LTN0*	0	0	0	LT20*	LT19*	LT18*	LT17*	LT16*
	W																
Reset	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	LT 15*	LT 14*	LT 13*	LT 12*	LT 11*	LT 10*	LT9*	LT8*	LT7*	LT6*	LT5*	LT4*	LT3*	LT2*	LT1*	LT0*
	W																
Reset	0	0	0	0	0	1	0	1	0	0	0	0	0	1	0	0	

[bit 27 to bit 24] LTN3 to LTN0: Listen Timeout Noise (gListenNoise-1)

This value specifies the upper limit on the startup and wakeup listen timeout used in an environment where noise occurs as a multiplier of listen timeout.

Valid values are in the range of 2 to 16. Set LTN3 to LTN0 to the same value in every node in the cluster.

[bit 20 to bit 0] LT20 to LT0: Listen Timeout (pdListenTimeout)

Specifies the startup and wakeup listen timeout in units of  $\mu$ T. Valid values are in the range of 1284 to 1283846  $\mu$ T.

Note:

The length of time of the wakeup and startup noise timeout is calculated as follows.

$$\text{Listen Timeout} \times \text{Listen Timeout Noise} = [\text{LT20 to LT0}] \times ([\text{LTN3 to LTN0}] + 1)$$

### ■ SUC Configuration Register 3 (SUCC3)

This register can only be changed in the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0088 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	0	0	0	0	0	WCF3*	WCF2*	WCF1*	WCF0*	WCP3*	WCP2*	WCP1*	WCP0*
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	1	

[bit 7 to bit 4] WCF3 to WCF0: Maximum Time Without Clock Correction HALT  
(gMaxWithoutClockCorrectionFatal)

This parameter defines the clock correction failure that triggers a state transition from the NORMAL\_ACTIVE or NORMAL\_PASSIVE states to the HALT state in the number of consecutive even/odd cycle pairs. Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 1 to 15 cycle pairs.

[bit 3 to bit 0] WCP3 to WCP0: Maximum Time Without Clock Correction Passive  
(gMaxWithoutClockCorrectionPassive)

This parameter defines the clock correction failure that triggers a state transition from the NORMAL\_ACTIVE state to the NORMAL\_PASSIVE state in the number of consecutive even/odd cycle pairs. Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 1 to 15 cycle pairs.

## ■ NEM Configuration Register (NEMC)

This register can only be changed in the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
008C <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	W															
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	R	0	0	0	0	0	0	0	0	0	0	0	NML3*	NML2*	NML1*	NML0*
	W															
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 3 to bit 0] NML3 to NML0: Network Management Vector Length  
(gNetworkManagementVectorLength)

These bits set the length of the network management vector. All of the nodes in a cluster should be set to the same configuration length. Valid values are in the range of 0 to 12.

### ■ PRT Configuration Register 1 (PRTC1)

This register can only be changed in the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0090 <sub>H</sub>	R						0									
	W	RWP5*	RWP4*	RWP3*	RWP2*	RWP1*	RWP0*	RXW8*	RXW7*	RXW6*	RXW5*	RXW4*	RXW3*	RXW2*	RXW1*	RXW0*
Reset	0	0	0	0	1	0	0	0	0	1	0	0	1	1	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	R					0	CASM6									
	W	BRP1*	BRP0*	SPP1*	SPP0*		CASM5*	CASM4*	CASM3*	CASM2*	CASM1*	CASM0*	TSST3*	TSST2*	TSST1*	TSST0*
Reset	0	0	0	0	0	1	1	0	0	0	1	1	0	0	1	1

[bit 31 to bit 26] RWP5 to RWP0: Transmission Counts of Wakeup Pattern (pWakeupPattern)

Sets the number of times to transmit the wakeup symbol. Valid values are in the range of 2 to 63.

[bit 24 to bit 16] RXW8 to RXW0: Wakeup Symbol Receive Window Length (gdWakeupSymbolRxWindow)

Sets the length of the window for the node to receive the wakeup pattern as a number of bit-times. Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 76 to 301.

[bit 15, bit 14] BRP1, BRP0: Baud Rate Prescaler (gdSampleClockPeriod, pSamplePerMicrotick)

Sets the baud rate on the FlexRay bus. The duration of one bit is always composed of 8 samples. The sample clock  $f\_sclk^*$  is configured using CCNT:SDIV1 and SDIV0. See "2.6.2 Setting Example of the FlexRay Baud Rate" for detailed examples of baud rate settings.

"00<sub>B</sub>":

$$gdSampleClockPeriod = 1/f\_sclk(s)$$

$$pSamplesPerMicrotick = 2$$

"01<sub>B</sub>":

$$gdSampleClockPeriod = 2/f\_sclk(s)$$

$$pSamplesPerMicrotick = 1$$

"10<sub>B</sub>", "11<sub>B</sub>":

$$gdSampleClockPeriod = 4/f\_sclk(s)$$

$$pSamplesPerMicrotick = 1$$

\*: See "2.6 FlexRay Controller Clock".

[bit 13, bit 12] SPP1, SPP0: Strobe Point Position

This parameter defines the number of sample counts. Sampling is performed the number of times as defined by SPP1 and SPP0, and the value of the bit ("H"/"L") is determined from the majority of the sampled values ("H"/"L") measured in this way.

"00<sub>B</sub>", "11<sub>B</sub>" = 5 samples

"01<sub>B</sub>" = 4 samples

"10<sub>B</sub>" = 6 samples

[bit 10 to bit 4] CASM6 to CASM0: Collision Avoidance Symbol Max (gdCASRxLowMax)

This parameter defines the upper limit on the length of the acceptance window used for the collision avoidance symbol (CAS). CASM bit 6 is fixed at "1". Valid values are in the range of 67 to 99.

[bit 3 to bit 0] TSST3 to TSST0: Transmission Start Sequence Transmitter (gdTSSTransmitter)

This parameter defines the duration of the transmission start sequence (TSS) in units of bit-time (1 bit-time = 4  $\mu$ T = 100ns@10Mbps). Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 3 to 15.

\*: See "2.6 FlexRay Controller Clock".

## ■ PRT Configuration Register 2 (PRTC2)

This register can change only the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0094 <sub>H</sub>	R	0	0	TXL5*	TXL4*	TXL3*	TXL2*	TXL1*	TXL0*	TXI7*	TXI6*	TXI5*	TXI4*	TXI3*	TXI2*	TXI1*	TXI0*
	W																
Reset	0	0	0	0	1	1	1	1	0	0	1	0	1	1	0	1	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	RXL5*	RXL4*	RXL3*	RXL2*	RXL1*	RXL0*	0	0	RXI5*	RXI4*	RXI3*	RXI2*	RXI1*	RXI0*
	W																
Reset	0	0	0	0	1	0	1	0	0	0	0	0	0	1	1	1	0

[bit 29 to bit 24] TXL5 to TXL0: Wakeup Symbol Transmit "L" Time (gdWakeupSymbolTxLow)

Sets the length of the "L" time for the node to transmit the wakeup symbol as a number of bit-times. Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 15 to 60.

[bit 23 to bit 16] TXI7 to TXI0: Wakeup Symbol Transmit Idle Phase Time (gdWakeupSymbolIdle)

Sets the length of the idle phase for the node to transmit the wakeup symbol as a number of bit-times. Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 45 to 180.

[bit 13 to bit 8] RXL5 to RXL0: Wakeup Symbol Receive "L" Time (gdWakeupSymbolRxLow)

Sets the length of the "L" time for the node to receive the wakeup symbol as a number of bit-times. Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 10 to 55.

[bit 5 to bit 0] RXI5 to RXI0: Wakeup Symbol Receive Idle Phase Time (gdWakeupSymbolRxIdle)

Sets the length of the idle phase for the node to receive the wakeup symbol as a number of bit-times. Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 14 to 59.

### ■ MHD Configuration Register (MHDC)

This register can only be changed in the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0098 <sub>H</sub>	R	0	0	0	SLT12*	SLT11*	SLT10*	SLT9*	SLT8*	SLT7*	SLT6*	SLT5*	SLT4*	SLT3*	SLT2*	SLT1*	SLT0*
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	0	0	0	0	0	SFDL6*	SFDL5*	SFDL4*	SFDL3*	SFDL2*	SFDL1*	SFDL0*	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

[bit 28 to bit 16] SLT12 to SLT0: Start of Latest Transmit (pLatestTx)

Sets the maximum value of the minislot immediately before transmission of frames in the dynamic segment is disabled. If SLT12 to SLT0 is set to "0", data is not transmitted in the dynamic segment. Valid values are in the range of 0 to 7981.

[bit 6 to bit 0] SFDL6 to SFDL0: Static Frame Data Length (gPayloadLengthStatic)

Sets the payload length for the entire cluster for all frames transmitted in the static segment. The actual payload length is 2 times the value of these bits in bytes. Set the payload length to the same value on all of the nodes in a cluster. Valid values are in the range of 0 to 127.

### ■ GTU Configuration Register 1 (GTUC1)

This register can change only the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
00A0 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	UT19*	UT18*	UT17*	UT16*	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	UT15*	UT14*	UT13*	UT12*	UT11*	UT10*	UT9*	UT8*	UT7*	UT6*	UT5*	UT4*	UT3*	UT2*	UT1*	UT0*
	W																
Reset	0	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0	0

[bit 19 to bit 0] UT19 to UT0: Microticks per Cycle (gMicroPerCycle)

Sets the number of microticks in a communication cycle. Valid values are in the range of 640 to 640000  $\mu$ T.

### ■ GTU Configuration Register 2 (GTUC2)

This register can only be changed in the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
00A4 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	SNM3*	SNM2*	SNM1*	SNM0*
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	MPC13*	MPC12*	MPC11*	MPC10*	MPC9*	MPC8*	MPC7*	MPC6*	MPC5*	MPC4*	MPC3*	MPC2*	MPC1*	MPC0*
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	1	0	1	0	

[bit 19 to bit 16] SNM3 to SNM0: Sync Node Max (gSyncNodeMax)

Sets the maximum number of nodes that transmit sync frames (frames where the sync frame indicator SYN is set to "1"). Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 2 to 15.

[bit 13 to bit 0] MPC13 to MPC0: MacroTicks per Cycle (gMacroPerCycle)

Sets the number of macroticks in a communication cycle. Set the cycle length to the same value on all of the nodes in a cluster. Valid values are in the range of 10 to 16000 MT.

### ■ GTU Configuration Register 3 (GTUC3)

This register can change only the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
00A8 <sub>H</sub>	R	0	MIOB6*	MIOB5*	MIOB4*	MIOB3*	MIOB2*	MIOB1*	MIOB0*	0	MIOA6*	MIOA5*	MIOA4*	MIOA3*	MIOA2*	MIOA1*	MIOA0*
	W																
Reset	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	UIOB7*	UIOB6*	UIOB5*	UIOB4*	UIOB3*	UIOB2*	UIOB1*	UIOB0*	UIOA7*	UIOA6*	UIOA5*	UIOA4*	UIOA3*	UIOA2*	UIOA1*	UIOA0*
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

[bit 30 to bit 24] MIOB6 to MIOB0: MacroTICK Initial Offset ch.B (pMacroInitialOffset[B])

This parameter sets the number of macroticks between the macrotick boundary after the ch.B secondary time reference point and the static slot boundary.

This value is based on the nominal macrotick time length. Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 2 to 72 MT.

[bit 22 to bit 16] MIOA6 to MIOA0: Macrotick Initial Offset ch.A (pMacroInitialOffset[A])

This parameter sets the number of macroticks between the macrotick boundary after the ch.A secondary time reference point and the static slot boundary. This value is based on the nominal macrotick time length. Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 2 to 72 MT.

[bit 15 to bit 8] UIOB7 to UIOB0: Microtick Initial Offset ch.B (pMicroInitialOffset[B])

This parameter sets the number of microticks between the macrotick boundary after the ch.B secondary time reference point and the real time reference point. This parameter depends on Delay Compensation ch.B, and needs to be set independently for each channel. Valid values are in the range of 0 to 240 μT.

[bit 7 to bit 0] UIOA7 to UIOA0: Microtick Initial Offset ch.A (pMicroInitialOffset[A])

This parameter sets the number of microticks between the macrotick boundary after the ch.A secondary time reference point and the real time reference point. This parameter depends on Delay Compensation ch.A, and needs to be set independently for each channel. Valid values are in the range of 0 to 240 μT.

■ GTU Configuration Register 4 (GTUC4)

This register can only be changed in the DEFAULT\_CONFIG or CONFIG states. See "■ Starting NIT and Configuring the Offset Correction Start" for details on setting NIT13 to NIT0 and OCS13 to OCS0.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
00AC <sub>H</sub>	R	0	0													
	W			OCS13*	OCS12*	OCS11*	OCS10*	OCS9*	OCS8*	OCS7*	OCS6*	OCS5*	OCS4*	OCS3*	OCS2*	OCS1*
Reset	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	R	0	0													
	W			NIT13*	NIT12*	NIT11*	NIT10*	NIT9*	NIT8*	NIT7*	NIT6*	NIT5*	NIT4*	NIT3*	NIT2*	NIT1*
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	1

[bit 29 to bit 16] OCS13 to OCS0: Offset Correction Start (gOffsetCorrectionStart-1)

This parameter determines the offset correction start position within the NIT phase. The position is calculated by counting from the cycle start position. Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 8 to 15998 MT.

[bit 13 to bit 0] NIT13 to NIT0: Network Idle Time Start (gMacroPerCycle-gdNIT-1)

This parameter sets the start point of the network idle time (NIT) at the end of the communication cycle as the number of macroticks.

$$\text{Macrotick} = \text{gMacroPerCycle} - \text{gdNIT} - 1$$

The NIT starts when the above equation is satisfied. Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 7 to 15997 MT.

## ■ GTU Configuration Register 5 (GTUC5)

This register can only be changed in the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
00B0 <sub>H</sub>	R								0	0	0					
	W	DEC7*	DEC6*	DEC5*	DEC4*	DEC3*	DEC2*	DEC1*	DEC0*				CDD4*	CDD3*	CDD2*	CDD1*
Reset	0	0	0	0	1	1	1	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	R															
	W	DCB7*	DCB6*	DCB5*	DCB4*	DCB3*	DCB2*	DCB1*	DCB0*	DCA7*	DCA6*	DCA5*	DCA4*	DCA3*	DCA2*	DCA1*
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 31 to bit 24] DEC7 to DEC0: Decoding Correction (pDecodingCorrection)

This parameter sets the decoding correction value that is used to determine the primary time reference point. Valid values are in the range of 14 to 143  $\mu$ T.

[bit 20 to bit 16] CDD4 to CDD0: Cluster Drift Damping (pClusterDriftDamping)

This parameter sets the cluster drift damping that is used during clock synchronization to minimize the accumulated drift. Valid values are in the range of 0 to 20  $\mu$ T.

[bit 15 to bit 8] DCB7 to DCB0: Delay Compensation Ch.B (pDelayCompensation[B])

This parameter is used for compensating the receive delay on ch.B. This parameter is guaranteed up to the cPropagationDelayMax parameter that sets in units of microticks the expected propagation delay in the range of 0.0125 to 0.05  $\mu$ s. In practice, use the length of the minimum propagation delay across all of the synchronized nodes. Valid values are in the range of 0 to 200  $\mu$ T.

[bit 7 to bit 0] DCA7 to DCA0: Delay Compensation Ch.A (pDelayCompensation[A])

This parameter is used for compensating the receive delay on ch.A. This parameter is guaranteed up to the cPropagationDelayMax parameter that sets in units of microticks the expected propagation delay in the range of 0.0125 to 0.05  $\mu$ s. In practice, use the length of the minimum propagation delay across all of the synchronized nodes. Valid values are in the range of 0 to 200  $\mu$ T.

### ■ GTU Configuration Register 6 (GTUC6)

This register can change only the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
00B4 <sub>H</sub>	R	0	0	0	0	0										
	W						MOD10*	MOD9*	MOD8*	MOD7*	MOD6*	MOD5*	MOD4*	MOD3*	MOD2*	MOD1*
Reset		0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	R	0	0	0	0	0										
	W						ASR10*	ASR9*	ASR8*	ASR7*	ASR6*	ASR5*	ASR4*	ASR3*	ASR2*	ASR1*
Reset		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 26 to bit 16] MOD10 to MOD0: Maximum Oscillator Drift (pdMaxDrift)

This parameter sets the maximum drift offset between 2 asynchronous nodes in a single communication cycle in units of  $\mu\text{T}$ . Valid values are in the range of 2 to 1923  $\mu\text{T}$ .

[bit 10 to bit 0] ASR10 to ASR0: Accepted Startup Range (pdAcceptedStartupRange)

This parameter sets the extended range of measurement error of the startup frame as a number of microticks. Valid values are in the range of 0 to 1875  $\mu\text{T}$ .

### ■ GTU Configuration Register 7 (GTUC7)

This register can only be changed in the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
00B8 <sub>H</sub>	R	0	0	0	0	0										
	W						NSS9*	NSS8*	NSS7*	NSS6*	NSS5*	NSS4*	NSS3*	NSS2*	NSS1*	NSS0*
Reset		0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	R	0	0	0	0	0										
	W						SSL9*	SSL8*	SSL7*	SSL6*	SSL5*	SSL4*	SSL3*	SSL2*	SSL1*	SSL0*
Reset		0	0	0	0	0	0	0	0	0	0	0	0	1	0	0

[bit 25 to bit 16] NSS9 to NSS0: Number of Static Slots (gNumberOfStaticSlots)

This parameter sets the number of static slots in a cycle. A minimum of two coldstart nodes need to be configured in order to startup the FlexRay network. Set the number of static slots to the same value on all of the nodes in a cluster. Valid values are in the range of 2 to 1023.

**[bit 9 to bit 0] SSL9 to SSL0: Static Slot Length (gdStaticSlot)**

This parameter sets the duration of the static slot in macroticks. Set the static slot length to the same value on all of the nodes in a cluster. Valid values are in the range of 4 to 659 MT.

**■ GTU Configuration Register 8 (GTUC8)**

This register can only be changed in the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
00BC <sub>H</sub>	R	0	0	0	NMS12*	NMS11*	NMS10*	NMS9*	NMS8*	NMS7*	NMS6*	NMS5*	NMS4*	NMS3*	NMS2*	NMS1*	NMS0*
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	0	0	0	0	0	0	MSL5*	MSL4*	MSL3*	MSL2*	MSL1*	MSL0*	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	

**[bit 28 to bit 16] NMS12 to NMS0: Number of Minislots (gNumberOfMinislots)**

This parameter sets the number of minislots in the dynamic segment of one cycle. Set the number of minislots to the same value on all of the nodes in a cluster. Valid values are in the range of 0 to 7986.

**[bit 5 to bit 0] MSL5 to MSL0: Minislot Length (gdMinislot)**

This parameter sets the duration of the minislot in macroticks. Set the minislot length to the same value on all of the nodes in a cluster. Valid values are in the range of 2 to 63 MT.

**■ GTU Configuration Register 9 (GTUC9)**

This register can only be changed in the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
00C0 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	DSI1*	DSI0*	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	MAPO4*	MAPO3*	MAPO2*	MAPO1*	MAPO0*	0	0	APO5*	APO4*	APO3*	APO2*	APO1*	APO0*
	W																
Reset	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	1

[bit 17, bit 16] DSI1, DSI0: Dynamic Slot Idle Phase (gdDynamicSlotIdlePhase)

This parameter sets the duration of the idle phase in the dynamic slot. Set this duration greater than or equal to the idle detection time. Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 0 to 2 minislots.

[bit 12 to bit 8] MAPO4 to MAPO0: Minislot Action Point Offset (gdMinislotActionPointOffset)

This parameter sets the action point offset in the minislot of the dynamic segment in macroticks. Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 1 to 31 MT.

[bit 5 to bit 0] APO5 to APO0: Action Point Offset (gdActionPointOffset)

This parameter sets the action point offset in the static slot and symbol window in macroticks. Set this parameter to the same value on all of the nodes in a cluster. Valid values are in the range of 1 to 63 MT.

■ GTU Configuration Register 10 (GTUC10)

This register can only be changed in the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
00C4 <sub>H</sub>	R	0	0	0	0												
	W					MRC10*	MRC9*	MRC8*	MRC7*	MRC6*	MRC5*	MRC4*	MRC3*	MRC2*	MRC1*	MRC0*	
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0														
	W			MOC13*	MOC12*	MOC11*	MOC10*	MOC9*	MOC8*	MOC7*	MOC6*	MOC5*	MOC4*	MOC3*	MOC2*	MOC1*	MOC0*
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	1

[bit 26 to bit 16] MRC10 to MRC0: Maximum Rate Correction (pRateCorrectionOut)

This parameter sets the maximum permissible rate correction value used in the internal clock synchronization algorithm. The sum of the internal rate correction and the external rate correction (absolute value) is verified against this value. Valid values are in the range of 2 to 1923 μT.

[bit 13 to bit 0] MOC13 to MOC0: Maximum Offset Correction (pOffsetCorrectionOut)

This parameter sets the maximum permissible offset correction value used in the internal clock synchronization algorithm (absolute value). The sum of the internal offset correction and the external offset correction is verified against this value. Valid values are in the range of 5 to 15266 μT.

## ■ GTU Configuration Register 11 (GTUC11)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
00C8 <sub>H</sub>	R	0	0	0	0	0	ERC2*	ERC1*	ERC0*	0	0	0	0	0	EOC2*	EOC1*	EOC0*
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	0	0	0	ERCC1	ERCC0	0	0	0	0	0	0	EOCC1	EOCC0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 26 to bit 24] ERC2 to ERC0: External Rate Correction (pExternRateCorrection)

This parameter sets the external rate correction value used by the internal clock synchronization algorithm in microticks. This value is used to add to the calculated rate correction value or subtract from the rate correction value. The resulting value is applied during the NIT. This value can change only the DEFAULT\_CONFIG or CONFIG states. Valid values are in the range of 0 to 7  $\mu$ T.

[bit 18 to bit 16] EOC2 to EOC0: External Offset Correction (pExternOffsetCorrection)

This parameter sets the external offset correction value used by the internal clock synchronization algorithm in microticks. This value is used to add to the calculated offset correction value or subtract from the offset correction value. The resulting value is applied during the NIT. This value can change only the DEFAULT\_CONFIG or CONFIG states. Valid values are in the range of 0 to 7  $\mu$ T.

[bit 9, bit 8] ERCC1, ERCC0: External Rate Correction Control (vExternRateControl)

External rate correction is enabled if the following setting values are written to ERCC1, ERCC0. Change this value while outside of the NIT.

"00<sub>B</sub>", "01<sub>B</sub>" = No external rate correction value

"10<sub>B</sub>" = Subtracts the external rate correction value from the calculated rate correction value

"11<sub>B</sub>" = Adds the external rate correction value to the calculated rate correction value

[bit 1, bit 0] EOCC1, EOCC0: External Offset Correction Control (vExternOffsetControl)

External offset correction is enabled if the following setting values are written to EOCC1, EOCC0. Change this value while outside of the NIT.

"00<sub>B</sub>", "01<sub>B</sub>" = No external offset correction value

"10<sub>B</sub>" = Subtracts the external offset correction value from the calculated offset correction value

"11<sub>B</sub>" = Adds the external offset correction value to the calculated offset correction value

## 2.3.5 Communication Controller (CC) Status Registers

This section explains the bit configurations and functions of the communication controller (CC) status registers.

### ■ Communication Controller (CC) Status Registers

All of the internal counters and communication controller (CC) status flags are reset when the node changes from the CONFIG state to the READY state.

### ■ CC Status Vector Register (CCSV)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0100 <sub>H</sub>	R	0	0	PSL5	PSL4	PSL3	PSL2	PSL1	PSL0	RCA4	RCA3	RCA2	RCA1	RCA0	WSV2	WSV1	WSV0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	CSI	CSAI	CSNI	0	0	SLM1	SLM0	HRQ	FSI	POCS5	POCS4	POCS3	POCS2	POCS1	POCS0
	W																
Reset	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

[bit 29 to bit 24] PSL5 to PSL0: POC Status Log

Shows the POCS5 to POCS0 status prior to the HALT state. This is set while in the HALT state. These bits change to HALT if the FREEZE command is issued while in the HALT state, and are reset to "000000<sub>B</sub>" when a transition from the HALT state.

[bit 23 to bit 19] RCA4 to RCA0: Remaining Coldstart Attempts (vRemainingColdstartAttempts)

These bits indicate the number of coldstart attempts remaining. The maximum number of coldstart attempts is set by SUCC1:CSA4 to CSA0.

[bit 18 to bit 16] WSV2 to WSV0: Wakeup Status (vPoc!WakeupStatus)

These bits indicate the current wakeup state (see "■ WAKEUP State").

"000<sub>B</sub>" = UNDEFINED:

Wakeup has not been started from the CONFIG state.

"001<sub>B</sub>" = RECEIVED\_HEADER:

This status is set if the wakeup finishes due to a frame header being received on either channel without errors while in the WAKEUP\_LISTEN state.

"010<sub>B</sub>" = RECEIVED\_WUP:

This status is set if the wakeup finishes due to a valid wakeup pattern being received on the specified wakeup channel while in the WAKEUP\_LISTEN state.

"011<sub>B</sub>" = COLLISION\_HEADER:

This status is set if the wakeup is aborted due to a collision being detected as a result of a valid header being received on either channel while transmitting the wakeup pattern.

"100<sub>B</sub>" = COLLISION\_WUP:

This status is set if the wakeup is aborted due to a collision being detected as a result of a valid wakeup pattern being received on the specified channel while transmitting the wakeup pattern.

"101<sub>B</sub>" = COLLISION\_UNKNOWN:

This status is set if there is a state transition from the WAKEUP\_DETECT state and the wakeup is aborted due to the wakeup timer reaching the specified time without receiving a valid wakeup pattern or a valid frame header.

"110<sub>B</sub>" = TRANSMITTED:

This status is set if the transmission of the wakeup pattern completes normally.

"111<sub>B</sub>" = reserved

[bit 14] CSI: Cold Start Inhibit (vColdstartInhibit)

Indicates that the node has been prohibited from performing coldstart. This flag is always set to "1" while in the READY state. This flag is reset by setting SUCC1:CMD3 to CMD0 to 1001<sub>B</sub> (CHI command ALLOW\_COLDSTART).

"1" = Node coldstart prohibited

"0" = Node coldstart allowed

[bit 13] CSAI: Cold Start Abort Indicator

Indicates that the coldstart was aborted. This indicator is reset by setting CMD3 to CMD0 to 1010<sub>B</sub> (CHI command RESET\_STATUS\_INDICATORS).

[bit 12] CSNI: Cold Start Noise Indicator (vPoc!ColdstartNoise)

Indicates that the coldstart procedure executed under conditions where there was a lot of noise. This indicator is reset by setting CMD3 to CMD0 to 1010<sub>B</sub> (CHI command RESET\_STATUS\_INDICATORS).

[bit 9, bit 8] SLM1, SLM0: Slot Mode (vPoc!SlotMode)

Displays the current POC slot mode. The default value is the single slot mode, although this can be changed to all using SUCC1:TSM. If the CHI command CMD3 to CMD0 is set to 0101<sub>B</sub> (ALL\_SLOTS) while in the NORMAL\_ACTIVE or NORMAL\_PASSIVE states, the node changes from the single slot mode to the all slot mode via ALL\_PENDING mode. When the node is not in the NORMAL\_ACTIVE or NORMAL\_PASSIVE states, this changes to the value defined by SUCC1:TSM when CMD3 to CMD0 is set to 1010<sub>B</sub> (CHI command RESET\_STATUS\_INDICATORS).

"00<sub>B</sub>" = Single slot mode

"01<sub>B</sub>" = reserved

"10<sub>B</sub>" = ALL\_PENDING

"11<sub>B</sub>" = All slot mode

[bit 7] HRQ: Halt Request (vPoc!CHIHaltRequest)

Indicates that a request has been made from the host for a state transition to the HALT state at the end of the communication cycle. This indicator is reset by setting CMD3 to CMD0 to 1010<sub>B</sub> (CHI command RESET\_STATUS\_INDICATORS), or when the node changes from the HALT state to the DEFAULT\_CONFIG state or the READY state.

**[bit 6] FSI: Freeze Status Indicator (vPoc!Freeze)**

Indicates that the node has changed to the HALT state due to CMD3 to CMD0 being set to 0111<sub>B</sub> (CHI command FREEZE), or an error occurring that required the node to change to the HALT state. This indicator is reset by setting CMD3 to CMD0 to 1010<sub>B</sub> (CHI command RESET\_STATUS\_INDICATORS), or when the node changes from the HALT state to the DEFAULT\_CONFIG state.

**[bit 5 to bit 0] POCS5 to POCS0: Protocol Operation Control Status**

Displays the current POC execution state.

00 0000<sub>B</sub> = DEFAULT\_CONFIG state  
 00 0001<sub>B</sub> = READY state  
 00 0010<sub>B</sub> = NORMAL\_ACTIVE state  
 00 0011<sub>B</sub> = NORMAL\_PASSIVE state  
 00 0100<sub>B</sub> = HALT state  
 00 0101<sub>B</sub> = MONITOR\_MODE state  
 00 0110<sub>B</sub> to 00 1110<sub>B</sub> = reserved  
 00 1111<sub>B</sub> = CONFIG state

Displays the current POC status during the wakeup procedure.

01 0000<sub>B</sub> = WAKEUP\_STANDBY state  
 01 0001<sub>B</sub> = WAKEUP\_LISTEN state  
 01 0010<sub>B</sub> = WAKEUP\_SEND state  
 01 0011<sub>B</sub> = WAKEUP\_DETECT state  
 01 0100<sub>B</sub> to 01 1111<sub>B</sub> = reserved

Displays the current POC status during the startup procedure.

10 0000<sub>B</sub> = STARTUP\_PREPARE state  
 10 0001<sub>B</sub> = COLDSTART\_LISTEN state  
 10 0010<sub>B</sub> = COLDSTART\_COLLISION\_RESOLUTION state  
 10 0011<sub>B</sub> = COLDSTART\_CONSISTENCY\_CHECK state  
 10 0100<sub>B</sub> = COLDSTART\_GAP state  
 10 0101<sub>B</sub> = COLDSTART\_JOIN state  
 10 0110<sub>B</sub> = INTEGRATION\_COLDSTART\_CHECK state  
 10 0111<sub>B</sub> = INTEGRATION\_LISTEN state  
 10 1000<sub>B</sub> = INTEGRATION\_CONSISTENCY\_CHECK state  
 10 1001<sub>B</sub> = INITIALIZE\_SCHEDULE state  
 10 1010<sub>B</sub> = ABORT\_STARTUP state  
 10 1011<sub>B</sub> to 11 1111<sub>B</sub> = reserved

**Note:**

Each of the flags CCSV:FSI, SUCC1:HRQ, CSNI, CSAI, SLM1, SLM0, and WSV2 to WSV0 is reset by setting CMD3 to CMD0 to 1010<sub>B</sub> (CHI command RESET\_STATUS\_INDICATORS).

## ■ CC Error Vector Register (CCEV)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0104 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	W																
Reset		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	PTAC4	PTAC3	PTAC2	PTAC1	PTAC0	ERRM1	ERRM0	0	0	CCFC3	CCFC2	CCFC1	CCFC0
	W																
Reset		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

This register is reset by setting CMD3 to CMD0 to 1010<sub>B</sub> (CHI command RESET\_STATUS\_INDICATORS), or when the node changes from the HALT state to the DEFAULT\_CONFIG state or READY state.

[bit 12 to bit 8] PTAC4 to PTAC0: Passive to Active Count (vAllowPassiveToActive)

This counter indicates the number of consecutive even/odd cycle pairs that have passed while waiting for the node to change from the NORMAL\_PASSIVE state to the NORMAL\_ACTIVE state due to the rate correction time and offset correction time being effective. The state transition is performed when PTAC4 to PTAC0 are equal to SUCC1:PTA4 to PTA0.

[bit 7, bit 6] ERRM1, ERRM0: Error Mode (vPoc!ErrorMode)

Displays the current POC error mode.

"00<sub>B</sub>" = ACTIVE

"01<sub>B</sub>" = PASSIVE

"10<sub>B</sub>" = COMM\_HALT

"11<sub>B</sub>" = reserved

[bit 3 to bit 0] CCFC3 to CCFC0: Clock Correction Failed Counter (vClockCorrectionFailed)

This is incremented by 1 at the end of the odd numbered communication cycle if either an offset correction lost error or a rate correction lost error occurs. This is reset to "0" at the end of the odd numbered communication cycle if neither an offset correction lost error nor a rate correction lost error occurs. The Clock Correction Failed Counter stops at 15.

■ Slot Counter Value Register (SCV)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0110 <sub>H</sub>	R	0	0	0	0	0	SCCB10	SCCB9	SCCB8	SCCB7	SCCB6	SCCB5	SCCB4	SCCB3	SCCB2	SCCB1	SCCB0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	0	0	SCCA10	SCCA9	SCCA8	SCCA7	SCCA6	SCCA5	SCCA4	SCCA3	SCCA2	SCCA1	SCCA0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 26 to bit 16] SCCB10 to SCCB0: Slot Counter Ch.B (vSlotCounter[B])

These bits show the current value of the ch.B slot counter. This value is set to "1" when the communication cycle starts, and is incremented at the end of each static slot until the end of the cycle. Valid values are in the range of 0 to 2047.

[bit 10 to bit 0] SCCA10 to SCCA0: Slot Counter Ch.A (vSlotCounter[A])

These bits show the current value of the ch.A slot counter. This value is set to "1" when the communication cycle starts, and is incremented at the end of each static slot until the end of the cycle. Valid values are in the range of 0 to 2047.

■ Macrotick and Cycle Counter Value Register (MTCCV)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0114 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	CCV5	CCV4	CCV3	CCV2	CCV1	CCV0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	MTV13	MTV12	MTV11	MTV10	MTV9	MTV8	MTV7	MTV6	MTV5	MTV4	MTV3	MTV2	MTV1	MTV0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 21 to bit 16] CCV5 to CCV0: Cycle Counter Value (vCycleCounter)

These bits show the current value of the cycle counter. This value is incremented at the start of the communication cycle. Valid values are in the range of 0 to 63.

**[bit 13 to bit 0] MTV13 to MTV0: Macrotick Value (vMacrotick)**

These bits show the current macrotick value. This value is set to "0" when the communication cycle starts, and is incremented until the end the cycle. Valid values are in the range of 0 to 16000.

**■ Rate Correction Value Register (RCV)**

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0118 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	0	RCV11	RCV10	RCV9	RCV8	RCV7	RCV6	RCV5	RCV4	RCV3	RCV2	RCV1	RCV0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

**[bit 11 to bit 0] RCV11 to RCV0: Rate Correction Value (vRateCorrection)**

These bits show the rate correction (complement of 2). This is the rate correction value calculated internally by the controller before the maximum rate correction value GTUC10:MRC10 to MRC0 is applied. If this value exceeds the maximum rate correction value, the SFS:RCLR flag is set to "1".

**■ Offset Correction Value Register (OCV)**

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
011C <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	OCV18	OCV17	OCV16	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	OCV15	OCV14	OCV13	OCV12	OCV11	OCV10	OCV9	OCV8	OCV7	OCV6	OCV5	OCV4	OCV3	OCV2	OCV1	OCV0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

**[bit 18 to bit 0] OCV18 to OCV0: Offset Correction Value (vOffsetCorrection)**

These bits show the offset correction (complement of 2). This is the offset correction value calculated internally by the controller before the maximum offset correction value GTUC10:MOC10 to MOC0 is applied. If this value exceeds the maximum offset correction value, the SFS:OCLR flag is set to "1".

Note:

The external rate/offset correction values are added to the rate/offset correction values that are limited by the maximum rate/offset correction values.

■ Sync Frame Status Register (SFS)

The maximum number of valid sync frames in one communication cycle is 15.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0120 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	RCLR	MRCS	OCLR	MOCS	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	VSBO3	VSBO2	VSBO1	VSBO0	VSBE3	VSBE2	VSBE1	VSBE0	VSAO3	VSAO2	VSAO1	VSAO0	VSAE3	VSAE2	VSAE1	VSAE0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

[bit 19] RCLR: Rate Correction Limit Reached

This flag indicates that the rate correction value has exceeded the limit value defined by GTUC10:MRC10 to MRC0. This flag is updated at the start of the offset correction phase.

"1" = The rate correction value has exceeded the limiting value

"0" = The rate correction value has not exceeded the limiting value

[bit 18] MRCS: Missing Rate Correction Signal

This flag indicates that no even/odd sync frame pairs were received and the rate correction calculation was not performed. This flag is updated at the start of the offset correction phase.

"1" = Rate correction signal missing

"0" = Rate correction signal valid

[bit 17] OCLR: Offset Correction Limit Reached

This flag indicates that the offset correction value has exceeded the limit value defined by GTUC10:MOC13 to MOC0. This flag is updated at the start of the offset correction phase.

"1" = The offset correction value has exceeded the limiting value

"0" = The offset correction value has not exceeded the limiting value

[bit 16] MOCS: Missing Offset Correction Signal

This flag indicates that no sync frames were received and the offset correction calculation was not performed. This flag is updated at the start of the offset correction phase.

"1" = Offset correction signal missing

"0" = Offset correction signal valid

[bit 15 to bit 12] VSBO3 to VSBO0: Valid Sync Frames Ch.B, Odd Communication Cycle (vSyncFramesOddB)

These bits show the number of valid sync frames transmitted and received during odd numbered communication cycles on ch.B. This value is updated during the NIT period of each odd numbered communication cycle.

[bit 11 to bit 8] VSBE3 to VSBE0: Valid Sync Frames Ch.B, Even Communication Cycle (vSyncFramesEvenB)

These bits show the number of valid sync frames transmitted and received during even numbered communication cycles on ch.B. This value is updated during the NIT period of each even numbered communication cycle.

[bit 7 to bit 4] VSAO3 to VSAO0: Valid Sync Frames Ch.A, Odd Communication Cycle (vSyncFramesOddA)

These bits show the number of valid sync frames transmitted and received during odd numbered communication cycles on ch.A. This value is updated during the NIT period of each odd numbered communication cycle.

[bit 3 to bit 0] VSAE3 to VSAE0: Valid Sync Frames Ch.A, Even Communication Cycle (vSyncFramesEvenA)

These bits show the number of valid sync frames transmitted and received during even numbered communication cycles on ch.A. This value is updated during the NIT period of each even numbered communication cycle.

Note:

Bit15 to bit0 are only valid if each of the channels is allocated by SUCC1:CCHA or CCHB.

### ■ Symbol Window and NIT Status Register (SWNIT)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0124 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	0	SBNB	SENB	SBNA	SENA	MTSB	MTSA	TCSB	SBSB	SESB	TCSA	SBSA	SESA
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

The followings describe the bits that hold status information related to the NIT. These bits are updated at the end of the NIT of each channel.

[bit 11] SBNB: Slot Boundary Violation During NIT Ch.B (vSS!BViolationB)

"1" = A slot boundary violation was detected during the NIT on ch.B

"0" = No slot boundary violations were detected during the NIT on ch.B

[bit 10] SENB: Syntax Error During NIT Ch.B (vSS!SyntaxErrorB)

"1" = A syntax error was detected during the NIT on ch.B

"0" = No syntax errors were detected during the NIT on ch.B

[bit 9] SBNA: Slot Boundary Violation During NIT Ch.A (vSS!BViolationA)

"1" = A slot boundary violation was detected during the NIT on ch.A

"0" = No slot boundary violations were detected during the NIT on ch.A

[bit 8] SENA: Syntax Error During NIT Ch.A (vSS!SyntaxErrorA)

"1" = A syntax error was detected during the NIT on ch.A

"0" = No syntax errors were detected during the NIT on ch.A

The followings describe the bits that hold status information related to the symbol window. These bits are updated at the end of the symbol window of each channel. These are not updated during startup.

[bit 7] MTSB: MTS Received on Ch.B (vSS!ValidMTSB)

"1" = An MTS symbol was detected on ch.B

"0" = No MTS symbols were detected on ch.B

[bit 6] MTSA: MTS Received on Ch.A (vSS!ValidMTSA)

"1" = An MTS symbol was detected on ch.A

"0" = No MTS symbols were detected on ch.A

[bit 5] TCSB: Transmission Collision in Symbol Window Ch.B (vSS!TxConflictB)

"1" = A transmission collision was detected in ch.B symbol window

"0" = No transmission collisions were detected in ch.B symbol window

[bit 4] SBSB: Slot Boundary Violation in Symbol Window Ch.B (vSS!BViolationB)

"1" = A slot boundary violation was detected in ch.B symbol window

"0" = No slot boundary violations were detected in ch.B symbol window

[bit 3] SESB: Syntax Error in Symbol Window Ch.B (vSS!SyntaxErrorB)

"1" = A syntax error was detected in ch.B symbol window

"0" = No syntax errors were detected in ch.B symbol window

[bit 2] TCSA: Transmission Collision in Symbol Window Ch.A (vSS!TxConflictA)

"1" = A transmission collision was detected in ch.A symbol window

"0" = No transmission collisions were detected in ch.A symbol window

[bit 1] SBSA: Slot Boundary Violation in Symbol Window Ch.A (vSS!BViolationA)

"1" = A slot boundary violation was detected in ch.A symbol window

"0" = No slot boundary violations were detected in ch.A symbol window

[bit 0] SESA: Syntax Error in Symbol Window Ch.A (vSS!SyntaxErrorA)

"1" = A syntax error was detected in ch.A symbol window

"0" = No syntax errors were detected in ch.A symbol window

## ■ Aggregated Channel Status (ACS)

This register provides the status that occurs during the operation of all of the communication slot channels regardless of whether the communication slots are allocated for transmission or reception. This register also contains the status data from the symbol window and NIT. This status data is updated after each slot (the latest data at the end of the next slot).

Each of the flags in this register is cleared by writing "1" to the corresponding bit position. Writing "0" has no effect on these flags. All of the flags are cleared by a hardware reset.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0128 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	SBVB	CIB	CEDB	SEDB	VFRB	0	0	0	SBVA	CIA	CEDA	SEDA	VFRA
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

### [bit 12] SBVB: Slot Boundary Violation on Ch.B (vSS!BViolationB)

This bit indicates that at least one slot boundary violation has been observed between the static slot, dynamic slot, symbol window, or NIT on ch.B.

"1" = A slot boundary violation has been observed on ch.B

"0" = No slot boundary violations have been observed on ch.B

### [bit 11] CIB: Communication Indicator Ch.B

This bit indicates that at least one valid frame has been received in a slot that contained an additional communication on ch.B. In other words, this means that a valid frame has been received in at least one slot, and this was combined with either a syntax error, a contents error, or a slot boundary violation.

"1" = A frame containing an additional communication has been received on ch.B

"0" = No frames containing additional communications have been received on ch.B

### [bit 10] CEDB: Content Error Detected on Ch.B (vSS!ContentErrorB)

This bit indicates that at least one frame containing a content error has been received in a static slot or dynamic slot of ch.B.

"1" = A frame containing a content error has been received on ch.B

"0" = No frames containing content errors have been received on ch.B

### [bit 9] SEDB: Syntax Error Detected on Ch.B (vSS!SyntaxErrorB)

This bit indicates that at least one syntax error has been observed in a static slot, dynamic slot, symbol window, or NIT on ch.B.

"1" = A syntax error has been observed on ch.B

"0" = No syntax errors have been observed on ch.B

**[bit 8] VFRB: Valid Frame Received on Ch.B (vSS!ValidFrameB)**

This bit indicates that at least one valid frame has been received in a static slot or dynamic slot of ch.B.

"1" = A valid frame has been received on ch.B

"0" = No valid frames have been received on ch.B

**[bit 4] SBVA: Slot Boundary Violation on Ch.A (vSS!BViolationA)**

This bit indicates that at least one slot boundary violation has been observed between the static slot, dynamic slot, symbol window, or NIT on ch.A.

"1" = A slot boundary violation has been observed on ch.A

"0" = No slot boundary violations have been observed on ch.A

**[bit 3] CIA: Communication Indicator Ch.A**

This bit indicates that at least one valid frame has been received in a slot that contained an additional communication on ch.A. In other words, this means that a valid frame has been received in at least one slot, and this was combined with either a syntax error, a contents error, or a slot boundary violation.

"1" = A frame containing an additional communication has been received on ch.A

"0" = No frames containing additional communications have been received on ch.A

**[bit 2] CEDA: Content Error Detected on Ch.A (vSS!ContentErrorA)**

This bit indicates that at least one frame containing a content error has been received in a static slot or dynamic slot of ch.A.

"1" = A frame containing a content error has been received on ch.A

"0" = No frames containing content errors have been received on ch.A

**[bit 1] SEDA: Syntax Error Detected on Ch.A (vSS!SyntaxErrorA)**

This bit indicates that at least one syntax error has been observed in a static slot, dynamic slot, symbol window, or NIT on ch.A.

"1" = A syntax error has been observed on ch.A

"0" = No syntax errors have been observed on ch.A

**[bit 0] VFRA: Valid Frame Received on Ch.A (vSS!ValidFrameA)**

This bit indicates that at least one valid frame has been received in a static slot or dynamic slot of ch.A.

"1" = A valid frame has been received on ch.A

"0" = No valid frames have been received on ch.A

---

**Note:**

When any of the SEDB, CIB, CEDB, or SBVB flags change from "0" to "1", the interrupt flag EIR:EDB is set to "1". When any of the SEDA, CEDA, CIA, or SBVA flags change from "0" to "1", the interrupt flag EIR:EDA is set to "1".

---

## ■ Even Numbered Cycle Sync Frame ID Register (ESID1 to ESID15)

The 15 registers ESID1 to ESID15 store in ascending order the frame IDs of sync frames received during the even numbered communication cycles. The smallest sync frame ID received is therefore stored in ESID1 register. If the node transmits a sync frame during the even numbered communication cycle, the frame ID of the transmitted sync frame is stored in ESID1 register. The value of these registers is updated during the NIT of each even numbered communication cycle.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0130 <sub>H</sub> to 0168 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	RXEB	RXEA	0	0	0	0	EID9	EID8	EID7	EID6	EID5	EID4	EID3	EID2	EID1	EID0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

### [bit 15] RXEB: Received Even Numbered Sync ID on Ch.B

This bit indicates that a sync frame corresponding to the sync ID was received on ch.B during the even cycle.

"1" = A sync frame was received on ch.B

"0" = No sync frames were received on ch.B

### [bit 14] RXEA: Received Even Numbered Sync ID on Ch.A

This bit indicates that a sync frame corresponding to the sync ID was received on ch.A during the even numbered cycle.

"1" = A sync frame was received on ch.A

"0" = No sync frames were received on ch.A

### [bit 9 to bit 0] EID9 to EID0: Even Sync ID (vsSyncIDListA,Beven)

These bits show the sync frame ID of the even numbered communication cycle.

**■ Odd Numbered Cycle Sync Frame ID Register (OSID1 to OSID15)**

The 15 registers OSID1 to OSID15 store in ascending order the frame IDs of sync frames received during the odd numbered communication cycles. The smallest sync frame ID received is therefore stored in OSID1 register. If the node transmits a sync frame during the odd numbered communication cycle, the frame ID of the transmitted sync frame is stored in OSID1 register 1. The value of these registers is updated during the NIT of each odd numbered communication cycle.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0170 <sub>H</sub> to 01A8 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	RXOB	RXOA	0	0	0	0	OID9	OID8	OID7	OID6	OID5	OID4	OID3	OID2	OID1	OID0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

[bit 15] RXOB: Received Odd Numbered Sync ID on Ch.B

This bit indicates that a sync frame corresponding to the sync ID was received on ch.B during the odd numbered cycle.

"1" = A sync frame was received on ch.B

"0" = No sync frames were received on ch.B

[bit 14] RXOA: Received Odd Numbered Sync ID on Ch.A

This bit indicates that a sync frame corresponding to the sync ID was received on ch.A during the odd numbered cycle.

"1" = A sync frame was received on ch.A

"0" = No sync frames were received on ch.A

[bit 9 to bit 0] OID9 to OID0: Odd Numbered Sync ID (vsSyncIDListA,Bodd)

These bits show the sync frame ID of the odd numbered communication cycle.

**■ Network Management Vector (NMV1 to NMV3: [1 to 3])**

The three network management vector registers store the generated NM vector (configurable from 0 to 12 bytes). The NM vector is generated by performing a bitwise OR arithmetic operation of each of the NM vectors received on each channel (valid static frames where PPI=1). The NM vector is updated at the end of each communication cycle when the node is in either the NORMAL\_ACTIVE or NORMAL\_PASSIVE states.

The NMVn registers beyond the configured length of the NM vector are not valid.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
01B0 <sub>H</sub> to 01B8 <sub>H</sub>	R	NM 31	NM 30	NM 29	NM 28	NM 27	NM 26	NM 25	NM 24	NM 23	NM 22	NM 21	NM 20	NM 19	NM 18	NM 17	NM 16
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	NM 15	NM 14	NM 13	NM 12	NM 11	NM 10	NM 9	NM 8	NM 7	NM 6	NM 5	NM 4	NM 3	NM 2	NM 1	NM 0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Figure 2.3-7 below shows the allocation of the byte data in the network management vector.

**Figure 2.3-7 Allocation of Byte Data in the Network Management Vector**

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Word																																	
NMV1	Data3							Data2							Data1							Data0											
NMV2	Data7							Data6							Data5							Data4											
NMV3	Data11							Data10							Data9							Data8											

## 2.3.6 Message Buffer Control Register

This section explains the bit configurations and functions of the message buffer control register.

### ■ Message RAM Configuration Register (MRC)

The Message RAM Configuration Register defines the message buffers that are allocated to the static segment, dynamic segment, and FIFO. This register can only be written to while in the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0300 <sub>H</sub>	R	0	0	0	0												
	W					SPLM*	SEC1*	SEC0*	LCB7*	LCB6*	LCB5*	LCB4*	LCB3*	LCB2*	LCB1*	LCB0*	
Reset	0	0	0	0	0	0	0	1	1	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R																
	W	FFB7*	FFB6*	FFB5*	FFB4*	FFB3*	FFB2*	FFB1*	FFB0*	FDB7*	FDB6*	FDB5*	FDB4*	FDB3*	FDB2*	FDB1*	FDB0*
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 26] SPLM: Sync Frame Payload Multiplex

This bit is valid when the node is configured as a sync node (SUCC1:TXSY=1). When this bit is set to "1", message buffer 0 and 1 are dedicated to transmitting sync frames with different payload data on ch.A and ch.B. When this bit is set to "0", the sync frames contain the same payload data on both channels, and are transmitted from message buffer 0. Note that message buffer 1 must be selected according to the channel filter settings for message buffer 0.

"0" = Both message buffer 0 1 are locked against reconfiguration

"1" = Message buffer 0 is locked against reconfiguration

[bit 25, bit 24] SEC1, SEC0: Secure Buffers

These bits are ignored in the DEFAULT\_CONFIG and CONFIG states.

"00<sub>B</sub>" = The message buffers can be reconfigured

"01<sub>B</sub>" = Message buffers with a number smaller than FDB are locked from reconfiguration, and message buffers configured for the static segment that have a buffer number greater than or equal to FDB are unable to transmit.

"10<sub>B</sub>" = All of the message buffers are locked against reconfiguration

"11<sub>B</sub>" = All of the message buffers are locked against reconfiguration

Furthermore, message buffers that are configured for the static segment and that have a buffer number greater than or equal to FDB are unable to transmit

[bit 23 to bit 16] LCB7 to LCB0: Last Configured Buffer

0 to 127 = The number of message buffers is (LCB + 1)

1 to 127 = LCB message buffers from FFB are allocated to the FIFO area

128 to 255 = There are no message buffers configured

[bit 15 to bit 8] FFB7 to FFB0: First Buffer of FIFO

0 = All of the message buffers are allocated to the FIFO area

1 to 127 = FFB1 message buffer from 0 are allocated to the static segment area

128 to 255 = There are no message buffers allocated to the FIFO area


[bit 7 to bit 0] FDB7 to FDB0: First Dynamic Buffer

0 = There is no group of buffers that are configured exclusively for the static segment

128 to 255 = There are no buffers configured for the dynamic segment

Note:

If the node is configured as a sync node (SUCC1:TXSY=1), message buffer 0 and 1 are both used as sync frames and then need to be configured using the key slot ID of the node specifications. If the node is not configured as a sync node (SUCC1:TXSY=0), message buffer 0 and 1 are both handled the same as other message buffers.



Verify that FDB7 to FDB0, FFB7 to FFB0, and LCB7 to LCB0 are configured correctly. Operation is not guaranteed if these parameters are not configured correctly. The CC does not check for incorrect configurations.

The maximum number of header sections is 128. This means that a maximum of 128 message buffers can be configured. The maximum length of a single data section is 254 bytes. The length of the data section can be configured differently for each message buffer. See "2.7.12 Message RAM" for details.

Set the data section lengths and payloads of all of the message buffers that belong to the FIFO using WRHS2:PLC6 to PLC0 and WRHS3:DP10 to DPO to the same values.

The message buffers that belong to the FIFO are locked against reconfiguration when the CC is not in the DEFAULT\_CONFIG or CONFIG states.

### ■ FIFO Rejection Filter Register (FRF)

The FIFO Rejection Filter Register configures bit strings that are compared against the channel, frame ID, and cycle count of received frames. This register is used in conjunction with the FIFO Rejection Filter Mask Register to determine whether or not to reject messages from the FIFO. This register can only be written to while in the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0304 <sub>H</sub>	R	0	0	0	0	0	0		RNF*	RSS*	CYF6*	CYF5*	CYF4*	CYF3*	CYF2*	CYF1*	CYF0*
	W																
Reset	0	0	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	FID 10*	FID 9*	FID 8*	FID 7*	FID 6*	FID 5*	FID 4*	FID 3*	FID 2*	FID 1*	FID 0*	CH1*	CH0*
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 24] RNF: Reject Null Frames

When this bit is set to "1", null frames that are received are not stored in the FIFO.

"1" = Null frames are not stored in the FIFO

"0" = Null frames are stored in the FIFO

[bit 23] RSS: Reject Messages in Static Segment

When this bit is set to "1", the FIFO only receives messages from the dynamic segment.

"1" = Messages are not received from the static segment

"0" = Messages are received from the static segment and the dynamic segment

[bit 22 to bit 16] CYF6 to CYF0: Cycle Code Filter

This 7-bit cycle counter filter specifies the cycle set and determines the communication cycle to which the frame ID filter and channel filter are applied. No frames are received during cycles where the frame ID filter and channel filter are not applied due to the cycle set specified by this register. See "■ Cycle Counter Filtering" for details on configuring the cycle counter filter.

[bit 12 to bit 2] FID10 to FID0: Frame ID Filter

If the value of this filter is set to a frame ID of "0", the FIFO will receive all frame IDs.

0 to 2047 = Frame ID filter value

[bit 1, bit 0] CH1, CH0: Channel Filter

"11<sub>B</sub>" = Unable to receive

"10<sub>B</sub>" = Only receive on ch.A

"01<sub>B</sub>" = Only receive on ch.B

"00<sub>B</sub>" = Receive on both channels

**Note:**

When the FIFO is configured to receive on both channels, then if the same frame is received on both channels, both of the frames from the static segment (from ch.A and ch.B) are stored in the FIFO.

### ■ FIFO Rejection Filter Mask Register (FRFM)

The FIFO Rejection Filter Mask Register specifies the bits in FRF:FID10 to FID0 that are used for comparisons in order to perform rejection filtering. When a bit in this register is set to "1", comparisons are not performed on the corresponding bit in FRF:FID10 to FID0. This register can only be written to while in the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0308 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	MFID10*	MFID9*	MFID8*	MFID7*	MFID6*	MFID5*	MFID4*	MFID3*	MFID2*	MFID1*	MFID0*	0	0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

[bit 12 to bit 2] MFID10 to MFID0: Mask Frame ID Filter

"1" = The corresponding bit in the frame ID filter is ignored

"0" = The corresponding bit in the frame ID filter is used for rejection filtering

### ■ FIFO Critical Level Register (FCL)

This register can only be written to while in the DEFAULT\_CONFIG or CONFIG states.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
030C <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	W															
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	R	0	0	0	0	0	0	0								
	W									CL7*	CL6*	CL5*	CL4*	CL3*	CL2*	CL1*
Reset	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0

[bit 7 to bit 0] CL7 to CL0: Critical Level

The critical level flag FSR:RFCL is set when the Receive FIFO Fill Level FSR:RFFL7 to RFFL0 is greater than or equal to the value of this register. The critical level flag FSR:RFCL is not set if this register is set to 128 or more. In addition, the SIR:RFCL signal is set, and an interrupt is generated if the interrupt is enabled.

## 2.3.7 Message Buffer Status Register

This section explains the bit configurations and functions of the message buffer status register.

### ■ Message Handler Status Register (MHDS)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
R	0	MBU6	MBU5	MBU4	MBU3	MBU2	MBU1	MBU0	0	MBT6	MBT5	MBT4	MBT3	MBT2	MBT1	MBT0
W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	0	FMB6	FMB5	FMB4	FMB3	FMB2	FMB1	FMB0	CRAM							
W										MFMB	FMBD	PTBF2	PTBF1	PMR	POBF	PIBF
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

The bits in this register that are writable can be cleared by writing "1". Writing "0" has no effect on these bits. This register is cleared by a hardware reset.

#### [bit 30 to bit 24] MBU6 to MBU0: Message Buffer Updated

These bits show the number of the last message buffer that was updated. The ND127 to ND0 and MBS127 to MBS0 flags in the NDAT1, NDAT2, NDAT3, NDAT4, MBSC1, MBSC2, MBSC3, and MBSC4 registers that correspond to this message buffer are also updated.

#### [bit 22 to bit 16] MBT6 to MBT0: Message Buffer Transmitted

These bits show the number of the last message buffer that was transmitted correctly. If the message buffer is set to single shot mode, the TXR127 to TXR0 flags in the TXRQ1, TXRQ2, TXRQ3, and TXRQ4 registers are reset.

#### Note:

The MBT6 to MBT0 and MBU6 to MBU0 flags are reset when the node changes from the CONFIG state or changes to the STARTUP state.

#### [bit 14 to bit 8] FMB6 to FMB0: Faulty Message Buffer

These bits show the message buffer number if a parity error occurs in the following situations.

- When reading the message buffer
- While transferring data from the input buffer or transient buffer 1 or 2 to a message buffer

This value is only valid when one of the PIBF, PMR, PTBF1, PTBF2, or FMBD flags is set to "1". This flag is updated after the FMBD flag is reset.

[bit 7] CRAM: Clear All Internal RAM

This flag indicates whether the CHI command CLEAR\_RAMs (CMD3 to CMD0 = 1100<sub>B</sub>) is currently executing (all of the bits in all of the internal RAM blocks are being written to "0"). This bit is set to "1" by a hardware reset or by the CHI command CLEAR\_RAMs.

"1" = The CHI command CLEAR\_RAMs is currently executing

"0" = The CHI command CLEAR\_RAMs is not currently executing

[bit 6] MFMB: Multiple Faulty Message Buffers Detected

"1" = Another faulty message buffer was detected while the FMBD flag was set

"0" = Another faulty message buffer has not been found

[bit 5] FMBD: Faulty Message Buffer Detected

"1" = The message buffer pointed to by FMB6 to FMB0 has a failure error due to a parity error

"0" = There are no faulty message buffers

[bit 4] PTBF2: Parity Error Transient Buffer RAM B

"1" = A parity error occurred when reading from transient buffer RAM B

"0" = A parity error has not occurred

[bit 3] PTBF1: Parity Error Transient Buffer RAM A

"1" = A parity error occurred when reading transient buffer RAM A

"0" = A parity error has not occurred

[bit 2] PMR: Parity Error Message RAM

"1" = A parity error occurred when reading message RAM

"0" = A parity error has not occurred

[bit 1] POBF: Parity Error Output Buffer RAM 1, 2

"1" = A parity error occurred when reading output buffer RAM 1, 2

"0" = A parity error has not occurred

[bit 0] PIBF: Parity Error Input Buffer RAM 1, 2

"1" = A parity error occurred when reading input buffer RAM 1, 2

"0" = A parity error has not occurred

---

Note:

When any of the PIBF, POBF, PMR, PTBF1, or PTBF2 bits changes from "0" to "1", EIR:PERR is set to "1".

---

## ■ Last Dynamic Transmit Slot Register (LDTS)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0314 <sub>H</sub>	R	0	0	0	0	0	LDTB10	LDTB9	LDTB8	LDTB7	LDTB6	LDTB5	LDTB4	LDTB3	LDTB2	LDTB1	LDTB0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	0	0	LDTA10	LDTA9	LDTA8	LDTA7	LDTA6	LDTA5	LDTA4	LDTA3	LDTA2	LDTA1	LDTA0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

This register is reset when the node changes from the CONFIG state or changes to the STARTUP state.

[bit 26 to bit 16] LDTB10 to LDTB0: Last Dynamic Transmission Ch.B

These bits show the value of vSlotCounter[B] in the dynamic segment when the last frame was transmitted on ch.B. This field is updated at the end of the dynamic segment and is set to "0" if no frames are transmitted in the dynamic segment.

[bit 10 to bit 0] LDTA10 to LDTA0: Last Dynamic Transmission Ch.A

These bits show the value of vSlotCounter[A] in the dynamic segment when the last frame was transmitted on ch.A. This field is updated at the end of the dynamic segment and is set to "0" if no frames are transmitted in the dynamic segment.

## ■ FIFO Status Register (FSR)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0318 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	RFFL7	RFFL6	RFFL5	RFFL4	RFFL3	RFFL2	RFFL1	RFFL0	0	0	0	0	0	RFO	RFCL	RFNE
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

This register is reset when the node changes from the CONFIG state or changes to the STARTUP state.

[bit 15 to bit 8] RFFL7 to RFFL0: Receive FIFO Fill Level

This is the number of FIFO buffers that have not yet been read by the host. The maximum value is 128.

**[bit 2] RFO: Receive FIFO Overrun**

This flag is set if a receive FIFO overrun is detected. When an overrun occurs, the oldest messages are overwritten. The interrupt flag (EIR:RFO) is also set. The flag is cleared by read access to the FIFO.

"1" = The receive FIFO is overrun

"0" = The receive FIFO is not overrun

**[bit 1] RFCL: Receive FIFO Critical Level**

This flag is set when the receive FIFO fill level (RFFL7 to RFFL0) is greater than or equal to the configured critical level (FCL:CL7 to CL0). Furthermore, the flag is cleared immediately if the fill level drops below the critical level. If RFCL is changed from "0" to "1", then SIR:RFCL is set to "1" and an interrupt is generated if the interrupt is enabled.

"1" = The receive FIFO has reached the critical level

"0" = The receive FIFO is below the critical level

**[bit 0] RFNE: Receive FIFO Not Empty**

This bit is set when a valid frame (or a null frame depending on the data and rejection masks) is received and stored in the FIFO. The interrupt flag (SIR:RFNE) is also set. The host resets this bit after all of the messages have been read the FIFO.

"1" = The receive FIFO is not empty

"0" = The receive FIFO is empty

**■ Message Handler Constraints Flags (MHDF)**

The message handler is limited by a number of constraints related to the eray\_bclk frequency, the message RAM configuration, and FlexRay bus traffic. The constraints are indicated by setting the MHDF flags.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
031C <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	W															
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	R	0	0	0	0	0	0	WAHP	0	0	TBFB	TBFA	FNFB	FNFA	SNUB	SNUA
	W															
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

The bits in this register that are writable can be cleared by writing "1". Writing "0" to these bits has no effect. This register is cleared by a hardware reset.

This register is reset when the node changes from the CONFIG state or changes to the STARTUP state.

**[bit 8] WAHP: Write Attempt to Header Partition**

This flag is set if the message handler attempts to write message data to the header partition in the message RAM due to a defective message buffer configuration. The write is not executed in order to preserve the header partition from unintended write accesses.

"1" = Header partition written

"0" = Header partition unwritten

[bit 5] TBFB: Transient Buffer Access Failure Ch.B

This flag is set if the read or write access to TBF B requested by PRT B could not be completed within the available time.

"1" = Access to TBF B failed

"0" = Access to TBF B succeeded

[bit 4] TBFA: Transient Buffer Access Failure Ch.A

This flag is set if the read or write access to TBF A requested by PRT A could not be completed within the available time.

"1" = Access to TBF A failed

"0" = Access to TBF A succeeded

[bit 3] FNFB: Find Sequence Not Finished Ch.B

This flag is set if the find sequence (scanning the message RAM to find a matching message buffer) could not be completed for ch.B due to the message handler being overloaded.

"1" = An unfinished find sequence was detected on ch.B

"0" = No unfinished find sequences were detected on ch.B

[bit 2] FNFA: Find Sequence Not Finished Ch.A

This flag is set if the find sequence (scanning the message RAM to find a matching message buffer) could not be completed for ch.A due to the message handler being overloaded.

"1" = An unfinished find sequence was detected on ch.A

"0" = No unfinished find sequences were detected on ch.A

[bit 1] SNUB: Status Not Updated Ch.B

This flag is set if the status of the message buffer (MBS) for ch.B could not be updated due to the message handler being overloaded.

"1" = The MBS for ch.B has not been updated

"0" = The message handler was not overloaded when updating the MBS for ch.B

[bit 0] SNUA: Status Not Updated Ch.A

This flag is set if the status of the message buffer (MBS) for ch.A could not be updated due to the message handler being overloaded.

"1" = The MBS for ch.A has not been updated

"0" = The message handler was not overloaded when updating the MBS for ch.A

---

Note:

The EIR:MHF interrupt flag is set to "1" if any of the SNUA, SNUB, FNFA, FNFB, TBFA, TBF B, or WAHP flags change from "0" to "1".

---

■ **Transmission Request Register 1/2/3/4 (TXRQ1/TXRQ2/TXRQ3/TXRQ4)**

These four registers reflect the states of the TXR127 to TXR0 flags for all of the configured message buffers. If the number of message buffers configured is less than 128, the remaining TXR127 to TXR0 flags have no effect on operation.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
032C <sub>H</sub>	R	TXR127	TXR126	TXR125	TXR124	TXR123	TXR122	TXR121	TXR120	TXR119	TXR118	TXR117	TXR116	TXR115	TXR114	TXR113	TXR112
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	TXR111	TXR110	TXR109	TXR108	TXR107	TXR106	TXR105	TXR104	TXR103	TXR102	TXR101	TXR100	TXR99	TXR98	TXR97	TXR96
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0328 <sub>H</sub>	R	TXR95	TXR94	TXR93	TXR92	TXR91	TXR90	TXR89	TXR88	TXR87	TXR86	TXR85	TXR84	TXR83	TXR82	TXR81	TXR80
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	TXR79	TXR78	TXR77	TXR76	TXR75	TXR74	TXR73	TXR72	TXR71	TXR70	TXR69	TXR68	TXR67	TXR66	TXR65	TXR64
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0324 <sub>H</sub>	R	TXR63	TXR62	TXR61	TXR60	TXR59	TXR58	TXR57	TXR56	TXR55	TXR54	TXR53	TXR52	TXR51	TXR50	TXR49	TXR48
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	TXR47	TXR46	TXR45	TXR44	TXR43	TXR42	TXR41	TXR40	TXR39	TXR38	TXR37	TXR36	TXR35	TXR34	TXR33	TXR32
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0320 <sub>H</sub>	R	TXR31	TXR30	TXR29	TXR28	TXR27	TXR26	TXR25	TXR24	TXR23	TXR22	TXR21	TXR20	TXR19	TXR18	TXR17	TXR16
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	TXR15	TXR14	TXR13	TXR12	TXR11	TXR10	TXR9	TXR8	TXR7	TXR6	TXR5	TXR4	TXR3	TXR2	TXR1	TXR0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 127 to bit 0] TXR127 to TXR0: Transmission Request

When these flags are set to "1", it indicates that the corresponding message buffer is configured as a transmit buffer, and that a transmission of that buffer is in progress. In the single shot mode, the flag is reset after the transmission finishes.

### ■ New Data Register 1/2/3/4 (NDAT1/NDAT2/NDAT3/NDAT4)

These four registers reflect the states of the ND flags for all of the configured message buffers. When a message buffer is configured as a transmit buffer, the ND flag corresponding to that message buffer has no effect on operation. If the number of message buffers configured is less than 128, the remaining ND flags have no effect on operation.

This register is reset when the node changes from the CONFIG state or changes to the STARTUP state.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
033C <sub>H</sub>	R	ND127	ND126	ND125	ND124	ND123	ND122	ND121	ND120	ND119	ND118	ND117	ND116	ND115	ND114	ND113	ND112
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	ND111	ND110	ND109	ND108	ND107	ND106	ND105	ND104	ND103	ND102	ND101	ND100	ND99	ND98	ND97	ND96
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0338 <sub>H</sub>	R	ND95	ND94	ND93	ND92	ND91	ND90	ND89	ND88	ND87	ND86	ND85	ND84	ND83	ND82	ND81	ND80
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	ND79	ND78	ND77	ND76	ND75	ND74	ND73	ND72	ND71	ND70	ND69	ND68	ND67	ND66	ND65	ND64
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0334 <sub>H</sub>	R	ND63	ND62	ND61	ND60	ND59	ND58	ND57	ND56	ND55	ND54	ND53	ND52	ND51	ND50	ND49	ND48
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	ND47	ND46	ND45	ND44	ND43	ND42	ND41	ND40	ND39	ND38	ND37	ND36	ND35	ND34	ND33	ND32
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0330 <sub>H</sub>	R	ND31	ND30	ND29	ND28	ND27	ND26	ND25	ND24	ND23	ND22	ND21	ND20	ND19	ND18	ND17	ND16
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	ND15	ND14	ND13	ND12	ND11	ND10	ND9	ND8	ND7	ND6	ND5	ND4	ND3	ND2	ND1	ND0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 127 to bit 0] ND127 to ND0: New Data

These flags are set to "1" when the data sections of the corresponding message buffers are updated by valid frames being received that pass the configured message buffer filters. When an invalid frame is received, the flag is not set except for message buffers in the receive FIFO. The flag is cleared to "0" when the header section of the message buffer is reconfigured or the data section is transferred to the output buffer.

#### ■ Message Buffer Status Changed Register 1/2/3/4 (MBSC1/MBSC2/MBSC3/MBSC4)

These four registers reflect the states of the MBC flags for all of the configured message buffers. If the number of message buffers configured is less than 128, the remaining MBC flags have no effect on operation.

This register is reset when the node changes from the CONFIG state or changes to the STARTUP state.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
034C <sub>H</sub>	R	MBC127	MBC126	MBC125	MBC124	MBC123	MBC122	MBC121	MBC120	MBC119	MBC118	MBC117	MBC116	MBC115	MBC114	MBC113	MBC112
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	MBC111	MBC110	MBC109	MBC108	MBC107	MBC106	MBC105	MBC104	MBC103	MBC102	MBC101	MBC100	MBC99	MBC98	MBC97	MBC96
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0348 <sub>H</sub>	R	MBC95	MBC94	MBC93	MBC92	MBC91	MBC90	MBC89	MBC88	MBC87	MBC86	MBC85	MBC84	MBC83	MBC82	MBC81	MBC80
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	MBC79	MBC78	MBC77	MBC76	MBC75	MBC74	MBC73	MBC72	MBC71	MBC70	MBC69	MBC68	MBC67	MBC66	MBC65	MBC64
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0344 <sub>H</sub>	R	MBC63	MBC62	MBC61	MBC60	MBC59	MBC58	MBC57	MBC56	MBC55	MBC54	MBC53	MBC52	MBC51	MBC50	MBC49	MBC48
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	MBC47	MBC46	MBC45	MBC44	MBC43	MBC42	MBC41	MBC40	MBC39	MBC38	MBC37	MBC36	MBC35	MBC34	MBC33	MBC32
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0340 <sub>H</sub>	R	MBC31	MBC30	MBC29	MBC28	MBC27	MBC26	MBC25	MBC24	MBC23	MBC22	MBC21	MBC20	MBC19	MBC18	MBC17	MBC16
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	MBC15	MBC14	MBC13	MBC12	MBC11	MBC10	MBC9	MBC8	MBC7	MBC6	MBC5	MBC4	MBC3	MBC2	MBC1	MBC0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 127 to bit 0] MBC127 to MBC0: Message Buffer Status Changed

These flags are set to "1" if any of the corresponding message buffer status flags (VFRA, VFRB, SEOA,

SEOB, CEOA, CEOB, SVOA, SVOB, TCIA, TCIB, ESA, ESB, MLST, FTA, and FTB) are changed. The flags are cleared to "0" when the header section of the corresponding message buffer is reconfigured or the data section is transferred to the output buffer.

## 2.3.8 Identification Register

This section explains the bit configurations and functions of the identification register.

### ■ Core Release Register (CREL)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
03F0 <sub>H</sub>	R	REL3	REL2	REL1	REL0	STEP7	STEP6	STEP5	STEP4	STEP3	STEP2	STEP1	STEP0	YEAR3	YEAR2	YEAR1	YEAR0
	W																
Reset	release info																
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	MON7	MON6	MON5	MON4	MON3	MON2	MON1	MON0	DAY7	DAY6	DAY5	DAY4	DAY3	DAY2	DAY1	DAY0
	W																
Reset	release info																

[bit 31 to bit 28] REL3 to REL0: Core Release

1 digit (BCD)

[bit 27 to bit 20] STEP7 to STEP0: Step of Core Release

2 digits (BCD)

[bit 19 to bit 16] YEAR3 to YEAR0: Design Time Stamp, Year

1 digit (BCD)

[bit 15 to bit 8] MON7 to MON0: Design Time Stamp, Month

2 digits (BCD)

[bit 7 to bit 0] DAY7 to DAY0: Design Time Stamp, Day

2 digits (BCD)

■ Endian Register (ENDN)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
03F4 <sub>H</sub>	R	ETV31	ETV30	ETV29	ETV28	ETV27	ETV26	ETV25	ETV24	ETV23	ETV22	ETV21	ETV20	ETV19	ETV18	ETV17	ETV16
	W																
Reset	1	0	0	0	0	1	1	1	0	1	1	0	0	1	0	1	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	ETV15	ETV14	ETV13	ETV12	ETV11	ETV10	ETV9	ETV8	ETV7	ETV6	ETV5	ETV4	ETV3	ETV2	ETV1	ETV0
	W																
Reset	0	1	0	0	0	0	1	1	0	0	1	0	0	0	0	1	

[bit 31 to bit 0] ETV31 to ETV0: Endianness Test Value

Test value 87654321<sub>H</sub>

## 2.3.9 Input Buffer

**This section explains the bit configurations and functions of the input buffer.**

### ■ Input Buffer

The input buffer consists of a double buffer; the input buffer host and input buffer shadow. Data is transferred from the input buffer shadow to the message RAM while the host is able to write into the input buffer host. The header section and data section are stored into the input buffer before they are transferred to the selected message buffer. The input buffer is also used to update the configuration of the message buffer of the message RAM, and the data section of the transmit buffer.

The message buffer status is automatically reset to "0" when updating the header section in the message RAM from the input buffer as described in "■ Message Buffer Status Register (MBS)".

Modify the header section of a message buffer which belongs to the receive FIFO only in the DEFAULT\_CONFIG state or CONFIG state.

See "■ Data Transmission from the Message RAM to the Output Buffer" for details of data transfers between the input buffer (IBF) and the message RAM.

### ■ Write Data Section Register (WRDS1 to WRDS64)

The write data section register is set with data before it is transferred to the data section of the message buffer. The data (DW<sub>n</sub>) is written into the message RAM according to the order of transmission from DW<sub>1</sub> (byte 0, byte 1) to DW<sub>PL</sub> (PL = the number of data items in 2-byte units defined by the payload length).

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0400 <sub>H</sub> to 04FC <sub>H</sub>	R																
	W	MD31	MD30	MD29	MD28	MD27	MD26	MD25	MD24	MD23	MD22	MD21	MD20	MD19	MD18	MD17	MD16
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R																
	W	MD15	MD14	MD13	MD12	MD11	MD10	MD9	MD8	MD7	MD6	MD5	MD4	MD3	MD2	MD1	MD0
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 31 to bit 0] MD31 to MD0: Message Data

MD7 to MD0 = DW<sub>n</sub>, byte<sub>n-1</sub>

MD15 to MD8 = DW<sub>n</sub>, byte<sub>n</sub>  
 MD23 to MD16 = DW<sub>n+1</sub>, byte<sub>n+1</sub>  
 MD31 to MD24 = DW<sub>n+1</sub>, byte<sub>n+2</sub>

**Note:**

DW127 is assigned to WRDS64: MD15 to MD0. In this case, WRDS64: MD31 to MD16 is unused (undefined data). The input buffer RAM is initialized to "0" by either the completion of a hardware reset, or the CHI command CLEAR\_RAMs (CMD3 to CMD0 = 1100<sub>B</sub>).

**Write Header Section Register 1 (WRHS1)**

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0500 <sub>H</sub>	R	0	0	MBI	TXM	PPIT	CFG	CHB	CHA	0	CYC6	CYC5	CYC4	CYC3	CYC2	CYC1	CYC0
	W																
Reset		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	0	0	FID10	FID9	FID8	FID7	FID6	FID5	FID4	FID3	FID2	FID1	FID0
	W																
Reset		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

**[bit 29] MBI: Message Buffer Interrupt**

This bit enables transmission and reception interrupts to the message buffers. SIR:RXI or SIR:MBSI are set to "1" after a message is received into the receive buffer. Also, the SIR:TXI flag is set to "1" after a message is transmitted successfully from the transmit buffer.

"1" = Enable transmission and reception interrupts on the corresponding message buffer

"0" = Disable transmission and reception interrupts on the corresponding message buffer

**[bit 28] TXM: Transmission Mode**

This bit selects the transmission mode (see "Transmit Buffer").

"1" = Single shot mode

"0" = Continuous mode

**[bit 27] PPIT: Payload Preamble Indicator Transmit**

This bit is used to control the payload preamble indicator status for a transmit frame. When this bit is set to the static message buffer, each message buffer retains network management information. However, when this bit is set to the dynamic message buffer, the first 2 bytes of the payload segment are used for message ID filtering. The message ID filtering of receive frames is not supported by the FlexRay controller.

"1" = Set the payload preamble indicator

"0" = Not to set the payload preamble indicator

[bit 26] CFG: Message Buffer Configuration Bit

This bit is used to configure a buffer as a transmit buffer or a receive buffer. The message buffers which belong to the receive FIFO become invalid.

"1" = The corresponding buffer is configured as a transmit buffer.

"0" = The corresponding buffer is configured as a receive buffer.

[bit 25, bit 24] CHB, CHA Channel Filter Control

This 2-bit associated with each buffer functions as the filter for the receive buffer and also as the control field for the transmit buffer.

CHA	CHB	Transmit Buffer transmit frame on	Receive Buffer store frame received from
1	1	both channels (static segment only)	ch.A or ch.B (store first semantically valid frame, static segment only)
1	0	ch.A	ch.A
0	1	ch.B	ch.B
1	0	no transmission	ignore frame

Note:

When the message buffer is set for a dynamic segment and both channel filtering fields (CHA, CHB) are set to "1", the frame is not transmitted and the receive frame has no effect on the operation (the same function as for CHA = CHB = 0).

[bit 22 to bit 16] CYC6 to CYC0: Cycle Code

This 7-bit code determines the cycle set which is used for cycle counter filtering. See "■ Cycle Counter Filtering" for details on cycle code settings.

[bit 10 to bit 0] FID10 to FID0: Frame ID

These bits indicate the frame ID of the selected message buffer. The frame ID defines the slot number for each message transmission and reception. A message buffer with frame ID = 0 is invalid.

## ■ Write Header Section Register 2 (WRHS2)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0504 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	W									PLC6	PLC5	PLC4	PLC3	PLC2	PLC1	PLC0
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	R	0	0	0	0	0										
	W						CRC10	CRC9	CRC8	CRC7	CRC6	CRC5	CRC4	CRC3	CRC2	CRC1
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 22 to bit 16] PLC6 to PLC0: Payload Length Configured

These bits indicate the length of the data section (number of 2-byte units) configured by the host. The static frame payload length configured by MHDC:SFDL6 to SFDL0 defines the payload length for all static frames. When the payload length configured by PLC6 to PLC0 is shorter than the configuration by MHDC:SFDL6 to SFDL0, padding bytes are inserted to guarantee the payload length of the static frame. The padding byte is indicated as "0".

[bit 10 to bit 0] CRC10 to CRC0: Header CRC (vRF!Header!HeaderCRC)

Configuration is not required for receive buffers.

Header CRC is calculated and configured by the host for transmit buffers.

Pass on the payload length of the frame to the host in order to calculate the header CRC. The payload length is configured by MHDC: SFDL6 to SFDL0 for all frames in the static segment.

## ■ Write Header Section Register 3 (WRHS3)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0508 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	W															
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	R	0	0	0	0	0										
	W						DP10	DP9	DP8	DP7	DP6	DP5	DP4	DP3	DP2	DP1
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 10 to bit 0] DP10 to DP0: Data Pointer

These bits indicate the pointer to the first 32-bit of the data section of the message buffer.

■ **Input Buffer Command Mask Register (IBCM)**

This register configures the update method of the message buffer selected by the IBCR register. When the IBF host and IBF shadow is swapped, mask bit LSHH, LDSH, STXRH and mask bit LHSS, LDSS, STXRS are also swapped.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0510 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	STXRS	LDSS	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	0	0	0	0	0	0	0	0	0		STXRH	LDSH	LHSH
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

[bit 17] STXRS: Set Transmission Request Shadow

"1" = Flags TXR127 to TXR0 have been set and the message in the transmit buffer is being released. Or, these operations have completed.

"0" = Flags TXR127 to TXR0 are being reset.

[bit 16] LDSS: Load Data Section Shadow

"1" = Transfer of the data section from the input buffer to the message RAM is in progress. Or, the transfer has completed.

"0" = Transfer of the data section from the input buffer to the message RAM is not in progress

[bit 2] STXRH: Set Transmission Request Host

When this bit is set to "1", flags TXR127 to TXR0 of the selected message buffer are set to "1" within the TXRQ1/TXRQ2/TXRQ3/TXRQ4 registers and the message in that transmit buffer is released. These flags are cleared after completing the transmission in single shot mode.

"1" = Set flags TXR127 to TXR0 and release the message in the transmit buffer

"0" = Reset flags TXR127 to TXR0

[bit 1] LDSH: Load Data Section Host

"1" = Transfer the data section from the input buffer to the message RAM

"0" = Not to transfer the data section

[bit 0] LHSH: Load Header Section Host

"1" = Transfer the header section from the input buffer to the message RAM

"0" = Not to transfer the header section

## ■ Input Buffer Command Request Register (IBCR)

The IBF host and IBF shadow are swapped if the target message buffer number in the message RAM is written into IBRH6 to IBRH0. Also, message buffer numbers stored in IBRS6 to IBRS0 and IBRS6 to IBRS0 are swapped (see "■ Data Transmission from the Message RAM to the Output Buffer").

The IBSYS bit is set to "1" by this write operation. Afterwards, the message handler starts transferring the contents of the IBF shadow into the message buffer in the message RAM selected by IBRS6 to IBRS0.

The subsequent transmission message can be written to the IBF host while the data is transferred from the IBF shadow to the message buffer in the message RAM. IBSYS is cleared to "0" after completing the transfer from the IBF shadow to the message RAM. The next transfer to the message RAM starts when the target message buffer number for the subsequent transmission message is written into IBRH6 to IBRH0.

IBSYH is set to "1" when a write access to IBRH6 to IBRH0 occurs while IBSYS = 1. The IBF host and IBF shadow are swapped after completing the current data transfer from the IBF shadow to the message RAM, and the message buffer numbers stored in IBRH6 to IBRH0 and IBRS6 to IBRS0 are also swapped. Then IBSYH is reset to "0". If IBSYS still remains as "1" at that time, the next transfer to the message RAM starts.

The error flag EIR:IIBA is set to "1" if a write access to this input buffer register occurs while both IBSYS:IBSYH are set to "1". The content of the input buffer is unchanged in such a case.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0514 <sub>H</sub>	R	IBSYS	0	0	0	0	0	0	0	0	IBRS6	IBRS5	IBRS4	IBRS3	IBRS2	IBRS1	IBRS0
	W																
Reset		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	IBSYH	0	0	0	0	0	0	0								
	W									IBRH6	IBRH5	IBRH4	IBRH3	IBRH2	IBRH1	IBRH0	
Reset		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

### [bit 31] IBSYS: Input Buffer Busy Shadow

This flag is set to "1" after a write access to IBRH6 to IBRH0 has occurred. IBSYS is cleared to "0" after completing the transfer between the IBF shadow and the message RAM.

"1" = Transfer between the IBF shadow and the message RAM is in progress.

"0" = Transfer between the IBF shadow and the message RAM has completed.

### [bit 22 to bit 16] IBRS6 to IBRS0: Input Buffer Request Shadow

These bits indicate the target message buffer number which is currently being updated, or has recently been updated. Valid values are in the range of 0 to 127.

### [bit 15] IBSYH: Input Buffer Busy Host

This flag is set to "1" if a write access to IBRH6 to IBRH0 occurs while IBSYS is "1". This flag is cleared to "0" after completing the current data transfer from the IBF shadow to the message RAM.

"1" = Message transfer is being suspended.

"0" = Message transfer is not being suspended.

[bit 6 to bit 0] IBRH6 to IBRH0: Input Buffer Request Host

These bits select the target message buffer number in the message RAM in order to transfer data from the input buffer. Valid values are in the range of 0 to 127.

## 2.3.10 Output Buffer

This section explains the bit configurations and functions of the output buffer.

### ■ Output Buffer

The output buffer consists of a double buffer; the output buffer host and output buffer shadow, and is used to read the message buffer from the message RAM. The selected message buffer is transferred from the message RAM to the output buffer shadow while the host is able to read from the output buffer host. See "■ Data Transmission from the Message RAM to the Output Buffer" for details of data transfers between the message RAM and the output buffer (OBF).

### ■ Read Data Section Register (RDDS1 to RDDS64)

The read data section register is set with data read from the data section of the message buffer. The data ( $DW_n$ ) is read from the message RAM according to the order of reception from  $DW_1$  (byte 0, byte 1) to  $DW_{PL}$  ( $PL$  = the number of data items in 2-byte units defined by the payload length).

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0600 <sub>H</sub> to 06FC <sub>H</sub>	R	MD31	MD30	MD29	MD28	MD27	MD26	MD25	MD24	MD23	MD22	MD21	MD20	MD19	MD18	MD17	MD16
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	MD15	MD14	MD13	MD12	MD11	MD10	MD9	MD8	MD7	MD6	MD5	MD4	MD3	MD2	MD1	MD0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 31 to bit 0] MD31 to MD0: Message Data

- MD7 to MD0 =  $DW_n$ , byte<sub>n-1</sub>
- MD15 to MD8 =  $DW_n$ , byte<sub>n</sub>
- MD23 to MD16 =  $DW_{n+1}$ , byte<sub>n+1</sub>
- MD31 to MD24 =  $DW_{n+1}$ , byte<sub>n+2</sub>

#### Note:

$DW_{127}$  is assigned to RDDS64: MD15 to MD0. In this case, RDDS64: MD31 to MD16 is unused (undefined data).

The output buffer RAM is initialized to "0" by either the completion of a hardware reset, or the CHI command CLEAR\_RAMs (CMD3 to CMD0 = 1100<sub>B</sub>).

**Read Header Section Register 1 (RDHS1)**

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0700 <sub>H</sub>	R	0	0	MBI	TXM	PPIT	CFG	CHB	CHA	0	CYC6	CYC5	CYC4	CYC3	CYC2	CYC1	CYC0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	0	0	FID10	FID9	FID8	FID7	FID6	FID5	FID4	FID3	FID2	FID1	FID0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

The following values are set through WRHS1.

- FID10 to FID0      Frame ID
- CYC6 to CYC0      Cycle Code
- CHA, CHB          Channel Filter Control
- CFG                Message Buffer Configuration Bit
- PPIT                Payload Preamble Indicator Transmit
- TXM                Transmission Mode
- MBI                Message Buffer Interrupt

FID10 to FID0 retains the receive frame ID while CYC6 to CYC0, CHA, CHB , CFG, PPIT, TXM, MBI are reset to "0" when the message buffer read from the message RAM belongs to the receive FIFO.

**Read Header Section Register 2 (RDHS2)**

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0704 <sub>H</sub>	R	0	PLR6	PLR5	PLR4	PLR3	PLR2	PLR1	PLR0	0	PLC6	PLC5	PLC4	PLC3	PLC2	PLC1	PLC0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	0	0	CRC10	CRC9	CRC8	CRC7	CRC6	CRC5	CRC4	CRC3	CRC2	CRC1	CRC0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 30 to bit 24] PLR6 to PLR0: Payload Length Received (vRF!Header!Length)

These bits indicate the value of the payload length updated by the receive frame.

[bit 22 to bit 16] PLC6 to PLC0: Payload Length Configured

These bits indicate the length of the data section (number of 2-byte units) configured by the host.

The following operations take place when a message is stored in the message buffer in relation to the receive payload length or configuration payload length.

PLR6 to PLR0 > PLC6 to PLC0:

Payload data stored in the message buffer is shortened to a payload length configured in PLC6 to PLC0 or PLC6 to PLC0 + 1.

PLR6 to PLR60 > PLC6 to PLC0:

Receive payload data is stored in the data section of the message buffer. Remaining data bytes in the data section configured by PLC6 to PLC0 are filled with undefined data.

PLR6 to PLR0 = 0: The data section of the message buffer is filled with undefined data.

PLC6 to PLC0 = 0: There is no data section in the message buffer. Data is not stored in the data section of the message buffer.

[bit 10 to bit 0] CRC10 to CRC0: Header CRC (vRF!Header!HeaderCRC)

Header CRC is updated by the receive frame for the receive buffers.

Header CRC configured by the message transfer from the input buffer is displayed for the transmit buffers.

Note:

The message RAM consists of 4 bytes. When receive data is stored in the data section of the message buffer, the number of data words in 2-byte units written into the message buffer is the value in PLC6 to PLC0 rounded up to the nearest even number. PLC6 to PLC0 is configured identically for all message buffers to the receive FIFO. Header 2 is updated by the data frame.

■ Read Header Section Register 3 (RDHS3)

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0708 <sub>H</sub>	R	0	0	RES	PPI	NFI	SYN	SFI	RCI	0	0	RCC5	RCC4	RCC3	RCC2	RCC1	RCC0
	W																
Reset		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	0	0	0	0	0	DP 10	DP9	DP8	DP7	DP6	DP5	DP4	DP3	DP2	DP1	DP0
	W																
Reset		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 29] RES: Reserved Bit (vRF!Header!Reserved)

This bit reflects the status of the received reserved bit.

[bit 28] PPI: Payload Preamble Indicator (vRF!Header!PPIndicator)

This bit indicates whether the network management vector or the message ID is included in the payload segment of the receive frame.

"1" = The network management vector is included at the beginning of the payload if it is a static segment.

The message ID is included at the beginning of the payload if it is a dynamic segment.

"0" = Neither the network management vector nor the message ID is included in the payload segment of the receive frame.

[bit 27] NFI: Null Frame Indicator (vRF!Header!NFIndicator)

There is no valid data in the payload segment of the receive frame when this bit is "0".

"1" = The receive frame is not a null frame.

"0" = The receive frame is a null frame.

[bit 26] SYN: Sync Frame Indicator (vRF!Header!SyFIndicator)

This bit indicates that the receive frame is a sync frame.

"1" = The receive frame is a sync frame.

"0" = The receive frame is not a sync frame.

[bit 25] SFI: Startup Frame Indicator (vRF!Header!SuFIndicator)

This bit indicates that the receive frame is a startup frame.

"1" = The receive frame is a startup frame.

"0" = The receive frame is not a startup frame.

[bit 24] RCI: Received on Channel Indicator (vSS!Channel)

This bit indicates the channel where the receive frame that updates each receive buffer has been received.

"1" = The frame has been received through ch.A.

"0" = The frame has been received through ch.B.

[bit 21 to bit 16] RCC5 to RCC0: Receive Cycle Count (vRF!Header!CycleCounter)

These bits indicate the cycle counter value updated by the receive frame.

[bit 10 to bit 0] DP10 to DP0: Data Pointer

These bits indicate the pointer to the first 32-bit of the data section of the message buffer.

---

Note:

Header 3 is updated by the data frame.

---

## ■ Message Buffer Status Register (MBS)

The assigned channel is updated at the message buffer status channel at the end of the slot which is next to the one assigned to the message buffer. When only one channel (A or B) is assigned to a message buffer, the status flag for the other channel is cleared to "0". Whereas if both channels are assigned to a message buffer, status flags for both channels are updated.

The message buffer status always indicates the latest status of the slot assigned to the message buffer.

When the host updates the message buffer through the input buffer, all MBS flags are reset even when the IBCM bit is set. See "2.7.7 Filtering and Masking", "2.7.8 Transmission Procedure" and "2.7.9 Reception Procedure" for details on transmission and reception filtering. MBC flags of message buffers for MBSC1, MBSC2, MBSC3 and MBSC4 registers are always set when the message handler changes any one of the VFRA, VFRA, SEOA, SEOB, CEOA, SVOA, SVOB, TCIA, TCIB, ESA, ESB, MLST, FTA or FTB flags.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
070C <sub>H</sub>	R	0	0	RESS	PPIS	NFIS	SYNS	SFIS	RCIS	0	0	CCS5	CCS4	CCS3	CCS2	CCS1	CCS0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	FTB	FTA	0	MLST	ESB	ESA	TCIB	TCIA	SVOB	SVOA	CEOB	CEOA	SEOB	SEOA	VFRB	VFRA
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

● Status flags associated with receive buffers

[bit 29] RESS: Reserved Bit Status (vRF!Header!Reserved)

This bit indicates the status of the reserve bit for receptions. The reserved bit is set to "0" when it is transmitted.

[bit 28] PPIS: Payload Preamble Indicator Status (vRF!Header!PPIndicator)

The payload preamble indicator status defines whether the network management vector or message ID is included in the payload segment of the receive frame.

"1" = The network management vector is included if it is a static segment.

The message ID is included if it is a dynamic segment.

"0" = Not included.

[bit 27] NFIS: Null Frame Indicator Status (vRF!Header!NFIndicator)

"1" = The receive frame is not a null frame.

"0" = The receive frame is a null frame.

[bit 26] SYNS: Sync Frame Indicator Status (vRF!Header!SyFIndicator)

"1" = A sync frame has been received.

"0" = A sync frame has not been received.

[bit 25] SFIS: Startup Frame Indicator Status (vRF!Header!SuFIndicator)

"1" = A startup frame has been received.

"0" = A startup frame has not been received.

[bit 24] RCIS: Received on Channel Indicator Status (vSS!Channel)

"1" = A frame has been received through ch.A.

"0" = A frame has been received through ch.B.

[bit 21 to bit 16] CCS5 to CCS0 Cycle Count Status

A cycle count occurs when the status is updated.

The following status bits are updated by both the valid and invalid frame data. The previous value is retained if a valid frame is not received.

[bit 15] FTB: Frame Transmitted to ch.B

This bit indicates that a data frame has been transmitted to ch.B.

"1" = A data frame has been transmitted to ch.B.

"0" = A data frame has not been transmitted to ch.B.

[bit 14] FTA: Frame Transmitted to ch.A

This bit indicates that a data frame has been transmitted to ch.A.

"1" = A data frame has been transmitted to ch.A.

"0" = A data frame has not been transmitted to ch.A.

[bit 12] MLST: Message Lost

This bit indicates that the message was not read before the message buffer was overwritten by the new message. The reception of a null frame has no effect except on the message buffer for the receive FIFO.

"1" = Unread message has been overwritten.

"0" = No message has been lost.

---

Note:

Only the host can reset MLST, FTA and FTB. Therefore, the cycle count status (CCS5 to CCS0) is valid in the cycle that sets the bits to "1".

---

[bit 11] ESB: Empty Slot ch.B

An empty slot indicates an idle status of the bus, in other words, no frame transmission is detected . This status is checked on static slots and dynamic slots.

"1" = The bus is idle in the slot assigned for ch.B.

"0" = The bus is not idle in the slot assigned for ch.B.

[bit 10] ESA: Empty Slot ch.A

An empty slot indicates an idle status of the bus, in other words, no frame transmission is detected . This status is checked on static slots and dynamic slots.

"1" = The bus is idle in the slot assigned for ch.A.

"0" = The bus is not idle in the slot assigned for ch.A.

● Status flags associated with transmit buffers

[bit 9] TCIB: Transmission Collision Indication ch.B (vSS!TxConflictB)

This bit is set to "1" when a transmission collision is detected on ch.B.

"1" = A transmission collision has been detected on ch.B.

"0" = A transmission collision has not been detected on ch.B.

[bit 8] TCIA: Transmission Collision Indication ch.A (vSS!TxConflictA)

This bit is set to "1" when a transmission collision is detected on ch.A.

"1" = A transmission collision has been detected on ch.A.

"0" = A transmission collision has not been detected on ch.A.

● Status flags associated with receive and transmit buffers

[bit 7] SVOB: Slot Boundary Violation Observed on ch.B (vSS!BViolationB)

This bit indicates that a slot boundary violation has been detected on the slot assigned to ch.B. This means that the channel was active at the opening or closing of the configured slot.

"1" = A slot boundary violation has been detected on ch.B.

"0" = A slot boundary violation has not been detected on ch.B.

[bit 6] SVOA: Slot Boundary Violation Observed on ch.A (vSS!BViolationA)

This bit indicates that a slot boundary violation has been detected on the slot assigned to ch.A. This means that the channel was active at the opening or closing of the configured slot.

"1" = A slot boundary violation has been detected on ch.A.

"0" = A slot boundary violation has not been detected on ch.A.

[bit 5] CEOB: Content Error Observed on ch.B (vSS!ContentErrorB)

This bit indicates that a content error has been detected on the slot assigned to ch.B.

"1" = A content error has been detected on ch.B.

"0" = A content error has not been detected on ch.B.

[bit 4] CEOA: Content Error Observed on ch.A (vSS!ContentErrorA)

This bit indicates that a content error has been detected on the slot assigned to ch.A.

"1" = A content error has been detected on ch.A.

"0" = A content error has not been detected on ch.A.

[bit 3] SEOB: Syntax Error Observed on ch.B (vSS!SyntaxErrorB)

This bit indicates that a syntax error has been detected on the slot assigned to ch.B.

"1" = A syntax error has been detected on ch.B.

"0" = A syntax error has not been detected on ch.B.

[bit 2] SEOA: Syntax Error Observed on ch.A (vSS!SyntaxErrorA)

This bit indicates that a syntax error has been detected on the slot assigned to ch.A.

"1" = A syntax error has been detected on ch.A.

"0" = A syntax error has not been detected on ch.A.

[bit 1] VFRB: Valid Frame Received on ch.B (vSS!ValidFrameB)

This bit is set to "1" when a valid frame is received through ch.B.

"1" = A valid frame has been received through ch.B.

"0" = A valid frame has not been received through ch.B.

[bit 0] VFRA: Valid Frame Received on ch.A (vSS!ValidFrameA)

This bit is set to "1" when a valid frame is received through ch.A.

"1" = A valid frame has been received through ch.A.

"0" = A valid frame has not been received through ch.A.

### ■ Output Buffer Command Mask Register (OBCM)

This register configures the update method of the output buffer which is updated by the message buffer selected by the OBCR register. When the OBF host and OBF shadow are swapped, the mask bit RDSH:RHSH and the mask bit RDSS:RHSS are also swapped.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0710 <sub>H</sub>	R	0	0	0	0	0	0	0	0	0	0	0	0	0	RDSH	RHSH
	W															
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	R	0	0	0	0	0	0	0	0	0	0	0	0	0	RDSS	RHSS
	W															
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 17] Read Data Section Host (RDSH)

"1" = Transfer the data section from the message RAM to the output buffer.

"0" = The data section is not read.

[bit 16] Read Header Section Host (RHSH)

"1" = Transfer the header section from the message RAM to the output buffer.

"0" = The header section is not read.

[bit 1] RDSS Read Data Section Shadow

"1" = Transfer the data section from the message RAM to the output buffer.

"0" = The data section is not read.

[bit 0] RHSS Read Header Section Shadow

"1" = Transfer the header section from the message RAM to the output buffer.

"0" = The header section is not read.

Note:

The message buffer status update flag (MBS) of the selected message buffer within the MBSC1/MBSC2/MBSC3/MBSC4 registers is cleared to "0" after completing the transfer of the header section from the message RAM to the OBF shadow.

The new data flags (ND127 to ND0) of the selected message buffer within the NDAT1/NDAT2/NDAT3/NDAT4 registers are cleared to "0" after completing the transfer of the data section from the message RAM to the OBF shadow.

## ■ Output Buffer Command Request Register (OBCR)

The message buffer selected by OBR6 to OBR0 is transferred from the message RAM to the output buffer as soon as REQ is set to "1". The REQ bit can be set to "1" only when OBSYS is "0" (see "■ Data Transmission from the Message RAM to the Output Buffer").

OBSYS is set to "1" after REQ is set to "1". Then the message buffer selected by OBR6 to OBR0 is transferred from the message RAM to the OBF shadow. The OBSYS bit is cleared to "0" after completing the transfer from the message RAM to the OBF shadow.

The OBF host and OBF shadow are swapped when VIEW is set to "1" while OBSYS is "0". This enables reading from the message buffer which has been transferred from the OBF host while the next message is being transferred from the message RAM to the OBF shadow.

The error flag EIR:IOBA is set to "1" if a write access to this output buffer register occurs while OBSYS is set to "1". The content of the output buffer is unchanged in such a case.

bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
0714 <sub>H</sub>	R	0	0	0	0	0	0	0	0	OBR6	OBR5	OBR4	OBR3	OBR2	OBR1	OBR0	
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	R	OBSYS	0	0	0	0	0	REQ	VIEW	0	OBR6	OBR5	OBR4	OBR3	OBR2	PBR1	OBR0
	W																
Reset	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

[bit 22 to bit 16] OBR6 to OBR0: Output Buffer Transfer Request Host

These bits indicate the message buffer number which can be currently accessed via RDHS1 to RDHS3, MBS, RDDS1 to RDDS64. The transferred message buffer becomes accessible by setting "1" to VIEW and the OBF shadow and OBF host are subsequently swapped. Valid values are in the range of 0 to 127.

[bit 15] OBSYS: Output Buffer Shadow Busy

This flag is set to "1" after the REQ bit is set to "1". OBSYS is cleared to "0" after completing the transfer from the message RAM to the OBF shadow.

"1" = The transfer from the message RAM to the OBF shadow is in progress.

"0" = The transfer from the message RAM to the OBF shadow is not in progress.

[bit 9] REQ: Request Message RAM Transfer

This bit starts the transfer of the message buffer specified by OBR6 to OBR0 from the message RAM to the OBF shadow. This bit can be written only when OBSYS is set to "0".

"1" = The transfer from the message RAM to the OBF shadow is requested.

"0" = The transfer from the message RAM to the OBF shadow is not requested.

**[bit 8] VIEW: Swap Shadow Buffer and Host Buffer**

This bit swaps the OBF shadow and OBF host. This bit can be written only when OBSYS is set to "0".

"1" = Swap the OBF shadow and OBF host.

"0" = Not to swap the OBF shadow and OBF host.

**[bit 6 to bit 0] OBRS6 to OBRS0: Output Buffer Transfer Request Shadow**

These bits indicate the message buffer number for the transfer from the message RAM to the OBF shadow. Valid values are in the range of 0 to 127. When the first message number within the receive FIFO is written to this register, the message buffer specified by GET Index(GIDX), (See "2.7.10 FIFO Function") is transferred to the OBF shadow.

## 2.4 FlexRay Operations

This section explains the operation of the FlexRay.

### FlexRay Operations

MB88121B supports the 16-bit non-multiplex bus, 16-bit multiplex bus and SPI bus. The mode is determined as follows depending on the settings of the MD2 to MD0 pins and the MDE2 to MDE0 pins.

Table 2.4-1 Mode

MD2	MD1	MD0	MDE2	MDE1	MDE0	Mode	
1	0	0	0	0	0	16-bit multiplex bus	FR460
			0	0	1		16FX
			1	0	0	16-bit non-multiplex bus	FR460
			1	1	0		FR360
1	1	0	x	x	0	SPI bus	


Note: Any other pin settings are prohibited. "x" is undefined value.

### 16-bit Non-multiplex Parallel Bus Timing

The following illustrates the 16-bit non-multiplex parallel timing.


- Read operations

Figure 2.4-1 FR460 Mode Read Timing (16-bit Non-multiplex Bus Mode)



When the  $\overline{CS}$  pin and  $\overline{RD}$  pin become "L", data is output to the D15 to D0 pins, the RDY pin is set to "L" at the rising of the next BCLK pin and waits for the CPU. When data in the register is ready, the RDY pin is set to "H" at the rising of the BCLK pin and simultaneously data in the register selected by the A10 to A0 pins is output to the D15 to D0 pins. When the  $\overline{CS}$  or  $\overline{RD}$  pin is set to "H", the D15 to D0 pins are set to high impedance.


**Figure 2.4-2 FR360 Mode Read Timing (16-bit Non-multiplex Bus Mode)**



When the  $\overline{CS}$  pin and  $\overline{RD}$  pin become "L", data is output to the D15 to D0 pins, the RDY pin is set to "L" at the falling of the next BCLK pin and waits for the CPU. When data in the register is ready, the data is synchronized with the falling edge of the BCLK pin. When the RDY pin is set to "H", the data in the register selected by the A10 to A0 pins is output simultaneously to the D15 to D0 pins. When the  $\overline{CS}$  or  $\overline{RD}$  pin is set to "H", the D15 to D0 pins are set to high impedance.


● Write operations

**Figure 2.4-3 FR460 Mode Write Timing (16-bit Non-multiplex Bus Mode)**



When the  $\overline{CS}$  pin and  $\overline{WR}$  pin become "L", data in the D15 to D0 pins is written into the temporary register at the rising of the next BCLK pin, and simultaneously the RDY pin is set to "L" and waits for the CPU. When the data in the temporary register is written into the register specified by the A10 to A0 pins, the RDY pin is set to "H" synchronously at the rising of the BCLK pin.

Figure 2.4-4 FR360 Mode Write Timing (16-bit Non-multiplex Bus Mode)



When the  $\overline{CS}$  pin and  $\overline{WR}$  pin become "L", data in the D15 to D0 pins is written into the temporary register at the falling of the next BCLK pin, and simultaneously the RDY pin is set to "L" and waits for the CPU. When the data in the temporary register is written into the register specified by the A10 to A0 pins, the RDY pin is set to "H" synchronously at the falling of the BCLK pin.

### ■ RDY Wait Count

The largest cycle number of BCLK which makes RDY "L" is as follows.

- When the BCLK pin is 32 MHz and the  $f_{\text{blk}}$  (the clock for RAM/register) is 80 MHz,

Width of RDY "L" at read operations	Width of RDY "L" at write operations
Maximum 5 BCLK	Maximum 5 BCLK


- When the BCLK pin is 32 MHz and the  $f_{\text{blk}}$  (the clock for RAM/register) is 40 MHz,

Width of RDY "L" at read operations	Width of RDY "L" at write operations
Maximum 7 BCLK	Maximum 7 BCLK

### Register Read Operations

The register of the FlexRay controller consists of 32 bits. A 32-bit temporary register for read operations is prepared to support the 16-bit non-multiplex parallel bus. When reading with the 16-bit non-multiplex parallel bus, the register value specified by A10 to A0 is written into the temporary register for read operations at the first operation, and the upper 16 bits of the temporary register for operations are output to D15 to D0. The lower 16 bits which have been written into the temporary register for operations by the first operation are output to D15 to D0 at the second operation.

**Figure 2.4-5 Read Operations to the FlexRay Controller Register (FR460 Mode)**




Notes:

- When using the 16-bit non-multiplex bus to read from the register, always read the 16-bit data twice consecutively since the register of the FlexRay controller consists of 32 bits.
- When using non-multiplex mode, access bit 31 to bit 16 of the register for the address 4n+0, and access bit 15 to bit 0 of the register for the address 4n+2 since it is a big endian.

## Register Write Operations

The register of the FlexRay controller consists of 32 bits. A 32-bit temporary register for write operations is prepared to support the 16-bit non-multiplex parallel bus. When writing with the 16-bit non-multiplex parallel bus, data in D15 to D0 is written into the upper 16 bits of the temporary register for write operations at the first operation. When data in D15 to D0 is written into the lower 16 bits of the temporary register for write operations by the second operation, the data in the temporary register is written into the register of the FlexRay Controller.

**Figure 2.4-6 Write Operations to the FlexRay Controller Register (FR460 Mode)**



### Notes:


- When using the 16-bit non-multiplex bus to write to the register, always write the 16-bit data twice consecutively since the register of the FlexRay controller consists of 32 bits.
- When using non-multiplex mode, the address  $4n+0$  is written to bit 31 to bit 16 of the register, and the address  $4n+2$  is written to bit 15 to bit 0 of the register since it is a big endian.

### 16-bit Multiplex Parallel Bus Timing

The following illustrates the 16-bit multiplex parallel timing.


- Read operations

**Figure 2.4-7 FR460 Mode Read Timing (16-bit Multiplex Bus Mode)**



The address to select the register is retained at the rising of the  $\overline{AS}$  pin. When the  $\overline{CS}$  pin and  $\overline{RD}$  pin become "L", data is output to the D15 to D0 pins, the RDY pin is set to "L" at the rising of the next BCLK pin and waits for the CPU. When data in the register is ready, the RDY pin is set to "H" at the rising of the BCLK pin and simultaneously data in the selected register is output to the D15 to D0 pins. When the  $\overline{CS}$  or  $\overline{RD}$  pin is set to "H", the D15 to D0 pins are set to high impedance.


**Figure 2.4-8 16FX Mode Read Timing (16-bit Multiplex Bus Mode)**



The address to select the register is retained at the falling of the ALE pin. When the  $\overline{CS}$  pin and  $\overline{RD}$  pin become "L", data is output to the D15 to D0 pins, the RDY pin is set to "L" at the falling of the next BCLK pin and waits for the CPU. When data in the register is ready, the RDY pin is set to "H" at the rising of the BCLK pin and data in the selected register is output to the D15 to D0 pins. When the  $\overline{CS}$  or  $\overline{RD}$  pin is set to "H", the D15 to D0 pins are set to high impedance.


● Write operations

**Figure 2.4-9 FR460 Mode Write Timing (16-bit Multiplex Bus Mode)**



The address to select the register is retained at the rising of the  $\overline{AS}$  pin. When the  $\overline{CS}$  pin and  $\overline{WR}$  pin become "L", data in the D15 to D0 pins is written into the temporary register at the rising of the next BCLK pin and simultaneously the RDY pin is set to "L" and waits for the CPU. When the data in the temporary register is written into the register specified by the address, the RDY pin is set to "H" synchronously at the rising of the BCLK pin.

**Figure 2.4-10 16FX Mode Write Timing (16-bit Multiplex Bus Mode)**



The address to select the register is retained at the falling of the ALE pin. When the  $\overline{CS}$  pin and  $\overline{WR}$  pin become "L", data in the D15 to D0 pins is written into the temporary register at the falling of the next BCLK pin and simultaneously the RDY pin is set to "L" and waits for the CPU. When the data in the temporary register is written into the register specified by the address, the RDY pin is set to "H" synchronously at the rising of the BCLK pin.

**■ RDY Wait Count**

The largest cycle number of BCLK which makes RDY "L" is as follows.

- When the BCLK pin is 32 MHz and the f\_bclk (the clock for RAM/register) is 80 MHz.

Mode	Width of RDY "L" at read operations	Width of RDY "L" at write operations
FR460	Maximum 5 BCLK	Maximum 5 BCLK
16FX	Maximum 5 BCLK + Width of BCLK "L"	Maximum 5 BCLK + Width of BCLK "L"

- When the BCLK pin is 32 MHz and the f\_bclk (the clock for RAM/register) is 40 MHz.

Mode	Width of RDY "L" at read operations	Width of RDY "L" at write operations
FR460	Maximum 7 BCLK	Maximum 7 BCLK
16FX	Maximum 7 BCLK + Width of BCLK "L"	Maximum 7 BCLK + Width of BCLK "L"


**■ Register Read Operations**

The register of the FlexRay controller consists of 32 bits. A 32-bit temporary register for read operations is prepared to support the 16-bit multiplex parallel bus. When reading with the 16-bit multiplex parallel bus, the register value specified by the address is written into the temporary register for read operations at the first operation, and data in the temporary register for read operations is output to the D15 to D11 and AD10 to AD0 pins as follows.


In FR460 mode: the upper 16 bits of the temporary register for read operations is output to D15 to D11 and AD10 to AD0 at the first operation, and the lower 16 bits of the temporary register for read operations is output to D15 to D11 and AD10 to AD0 at the second operation.

In 16FX mode: the lower 16 bits of the temporary register for operations is output to D15 to D11 and AD10 to AD0 at the first operation, and the upper 16 bits of the temporary register for operations is output to D15 to D11 and AD10 to AD0 at the second operation.

**Figure 2.4-11 Read Operations to the FlexRay Controller Register (FR460 Mode)**



**Figure 2.4-12 Read Operations to the FlexRay Controller Register (16FX Mode)**



**Note:**

When using the 16-bit multiplex bus to read from the register, always read the 16-bit data twice consecutively since the register of the FlexRay controller consists of 32 bits.

### Register Write Operations

The register of the FlexRay controller consists of 32 bits. A 32-bit temporary register for write operations is prepared to support the 16-bit multiplex parallel bus. When writing with the 16-bit multiplex parallel bus, the temporary register for write operations is written as follows.

In FR460 mode: data in D15 to D11 and AD10 to AD0 is written into the upper 16 bits of the temporary register for write operations by the first operation, and data in D15 to D11 and AD10 to AD0 is written into the lower 16 bits of the temporary register for write operations by the second operation.

In 16FX mode: data in D15 to D11 and AD10 to AD0 is written into the lower 16 bits of the temporary register for write operations by the first operation, and data in D15 to D11 and AD10 to AD0 is written into the upper 16 bits of the temporary register for write operations by the second operation.

Data in the temporary register is written into the register for the FlexRay controller at the second write operation.

**Figure 2.4-13 Write Operations to the FlexRay Controller Register (FR460 Mode)**





Figure 2.4-14 Write Operations to the FlexRay Controller Register (16FX Mode)



Note:

When using the 16-bit multiplex bus to write to the register, always write the 16-bit data twice consecutively since the register of the FlexRay controller consists of 32 bits.

## 2.4.1 DMA Operations

---

**This section explains the operation of the DMA.**


---

### ■ DMA Operations

MB88121B supports the DMA transfer of input/output buffer data. When the host CPU is capable of a DMA transfer using the external bus, connect the DMA\_req pin of MB88121B to the DMA request input pin of the host CPU.


## ■ Input Buffer Data Transfer

Figure 2.4-15 Input Buffer Data Transfer



■ Output Buffer Data Transfer

Figure 2.4-16 Output Buffer Data Transfer



## 2.4.2 SPI Bus

---

This section explains the settings and operations of the SPI bus.

---

### ■ Operation Mode Settings

LSB/MSB first, multiplier of PLL, serial type, each serial clock operations are set by pins in SPI bus mode.

### ■ LSB/MSB Settings

The bit direction is defined by the pin (MDS2) setting.

MDS2	Function
L	Data is transmitted MSB first.
H	Data is transmitted LSB first.

### ■ PLL Multiplier Setting

After releasing a reset, set the setting value of the pin (MDE2, MDE1) to CCNT:PMUL1 and PMUL0 and "1" to CCNT:PON.

MDE2	MDE1	Oscillation frequency of X0/X1
L	L	4MHz
L	H	5MHz
H	L	8MHz
H	H	10MHz

Note:

When writing into the CCNT register, set the same value as the setting of the pins (MDE2, MDE1) to CCNT:PMUL1 and PMUL0.

After releasing a reset, CCNT:PON is set to "1" while CCNT:SSEL remains as "0". When using the PPL clock as the FlexRay controller clock, set "1" to CCNT:SSEL after locking PPL.

---

### ■ Serial Type

The serial type is defined by the pin (MDE0) setting.

MDE0	Type
L	SPI bus
H	Reserved

### Serial Clock Operations Setting

The serial clock operations are defined by the pins (MDS1, MDS0) setting.

MDS1	MDS0	Serial clock operations
L	L	SCK is "H" active and sampling is at the SCK rising edge.
L	H	SCK is "H" active and sampling is at the SCK falling edge.
H	L	SCK is "L" active and sampling is at the SCK falling edge.
H	H	SCK is "L" active and sampling is at the SCK rising edge.


### Serial Clock Operations

4 types of serial clock operations are supported in the SPI bus mode. When the  $\overline{CS}$  pin becomes "L", the pin (SDO) becomes an output, fetches data from the pin (SDI) and outputs the data to the pin (SDO). When the  $\overline{CS}$  pin becomes "H", the pin (SDO) is in a high impedance state and data is invalid even if the serial clock is entered to SCK.

### MDS1 Pin = "L", MDS0 Pin = "L"

SCK is "H" active and sampling is at the SCK rising edge. The following illustrates the operation timing.


Figure 2.4-17 Serial Clock Operation Timing when MDS1 Pin = "L" and MDS0 Pin = "L"



### ■ MDS1 Pin = "L", MDS0 Pin = "H"

SCK is "H" active and sampling is at the SCK falling edge. The following illustrates the operation timing.


**Figure 2.4-18 Serial Clock Operation Timing when MDS1 Pin = "L" and MDS0 Pin = "H"**



### ■ MDS1 Pin = "H", MDS0 Pin = "L"

SCK is "L" active and sampling is at the SCK falling edge. The following illustrates the operation timing.


**Figure 2.4-19 Serial Clock Operation Timing when MDS1 Pin = "H" and MDS0 Pin = "L"**



### ■ MDS1 Pin = "H", MDS0 Pin = "H"

SCK is "L" active and sampling is at the SCK rising edge. The following illustrates the operation timing.

**Figure 2.4-20 Serial Clock Operation Timing when MDS1 Pin = "H" and MDS0 Pin = "H"**



## 2.5 SPI Protocol Definition

This section explains the commands of the SPI protocol definition.

### ■ SPI Protocol Definition

SPI interface communications are performed by command frames.  $\overline{CS}$  is negated to "H" between command frames. A command frame consists of a command byte and an additional byte.

### ■ Command Byte Structure

bit	7	6	5	4	3	2	1	0
	C4	C3	C2	C1	C0	"0"	P	*

\* Bit 0 in the command byte is used as the address bit (A10) in the WR, RD commands. The bit is set to "0" for other commands.

C4=0:

Opcode	C4	C3	C2	C1	C0	P	Mnemonic	Command
00 <sub>H</sub>	0	0	0	0	0	0	NOP	Read Status
0A <sub>H</sub> /09 <sub>H</sub>	0	0	0	0	1	1/0	WR	Write 1w
12 <sub>H</sub>	0	0	0	1	0	1	WBI	Initialize & Write Input Buffer
18 <sub>H</sub>	0	0	0	1	1	0	WBC	Write Input Buffer continuously
22 <sub>H</sub> /21 <sub>H</sub>	0	0	1	0	0	1/0	RD	Read 1w
42 <sub>H</sub>	0	1	0	0	0	1	RBI	Initialize & Read Output Buffer
50 <sub>H</sub>	0	1	0	1	0	0	RBIWBI	Combination of RBI and WBI
5A <sub>H</sub>	0	1	0	1	1	1	RBIWBC	Combination of RBI and WBC
60 <sub>H</sub>	0	1	1	0	0	0	RBC	Read Output Buffer continuously
72 <sub>H</sub>	0	1	1	1	0	1	RBCWBI	Combination of RBC and WBI
78 <sub>H</sub>	0	1	1	1	1	0	RBCWBC	Combination of RBC and WBC


C4=1:

Opcode	C4	C3	C2	C1	C0	P	Mnemonic	Command
82 <sub>H</sub>	1	0	0	0	0	1	WIP	Write Input Buffer Pointer
88 <sub>H</sub>	1	0	0	0	1	0	WOP	Write Output Buffer Pointer
90 <sub>H</sub>	1	0	0	1	0	0	WRIBC	Write Input Buffer Command
9A <sub>H</sub>	1	0	0	1	1	1	WROBC	Write Output Buffer Command
A0 <sub>H</sub>	1	0	1	0	0	0	RDN	Read nw
AA <sub>H</sub>	1	0	1	0	1	1	WRHS	Write Input Buffer Header Section 1 to 3

Opcodes not included in the table are NOP commands.

P bit is the even numbered parity bit. The command becomes a NOP command in the event of a parity error.


### ■ WR: 1w Write (0A<sub>H</sub>/09<sub>H</sub>)



ACK=FF<sub>H</sub> is transmitted if an error does not occur at the CRC\_W check. ACK=00<sub>H</sub> is transmitted if an error occurs. If ACK=FF<sub>H</sub> is transmitted, the 32-bit data in WD3 to WD0 is written into the address (A10 to A0) at the  $\overline{CS}$  rising edge immediately after the ACK. The data is not written if an edge is not detected. The SPI master can transmit an additional byte (Abort) after receiving the ACK. MB88121B does not write data if it detects the clock edge at the  $\overline{CS}$  rising.

Payload	4 bytes
Command length	10 bytes
Overhead	150%
Efficiency	40%


### ■ RRD: 1w Read (22<sub>H</sub>/21<sub>H</sub>)



Data RD3 to RD0 can be read from the address (A10 to A0). ACK=FF<sub>H</sub> is transmitted if an error does not occur at the CRC\_W check. ACK=00<sub>H</sub> is transmitted if an error occurs.

Payload	4 bytes
Command length	10 bytes
Overhead	50%
Efficiency	40%


### ■ WBI: Write Input Buffer, Initialize (12<sub>H</sub>)



The IBP(= input buffer pointer) is cleared and data is written from the address 0400<sub>H</sub>. ACK=FF<sub>H</sub> is transmitted if an error does not occur at the CRC\_W check. ACK=00<sub>H</sub> is transmitted if an error occurs. If ACK=FF<sub>H</sub> is transmitted, the IBP is incremented by 1 at the  $\overline{CS}$  rising edge immediately after the ACK. The IBP is not incremented if there is no  $\overline{CS}$  rising immediately after the ACK. The SPI master can transmit an additional byte (Abort) after receiving the ACK. In this case, the IBP is not incremented even if MB88121B detects the clock edge at the  $\overline{CS}$  rising.

Payload	$4 \times (n+1)$ bytes
Command length	$6 + 4 \times (n + 1)$ bytes
Overhead	150% / (n + 1)
Efficiency	$100\% \times (1 - 3 / (2n + 5))$


■ **WBC: Write Input Buffer, Continue (18<sub>H</sub>)**



Data is written from the address 0400<sub>H</sub>+4×IBP (IBP = Input Buffer Pointer). ACK=FF<sub>H</sub> is transmitted if an error does not occur at the CRC\_W check. ACK=00<sub>H</sub> is transmitted if an error occurs. If ACK=FF<sub>H</sub> is transmitted, the IBP is incremented by 1 at the  $\overline{CS}$  rising edge immediately after the ACK. The IBP is not incremented if there is no  $\overline{CS}$  rising immediately after the ACK. The SPI master can transmit an additional byte (Abort) after receiving the ACK. In this case, the IBP is not incremented even if MB88121B detects the clock edge at the  $\overline{CS}$  rising.

Payload	$4 \times (n+1)$ bytes
Command length	$6 + 4 \times (n + 1)$ bytes
Overhead	150% / (n + 1)
Efficiency	$100\% \times (1 - 3 / (2n + 5))$

■ **RBI: Read Output Buffer, Initialize (42<sub>H</sub>)**






transmitted, the IBP and OBP are incremented by 1 at the  $\overline{CS}$  rising edge immediately after the ACK. The IBP and OBP are not incremented if there is no  $\overline{CS}$  rising immediately after the ACK. The SPI master can transmit an additional byte (Abort) after receiving the ACK. In this case, the IBP and OBP are not incremented even if MB88121B detects the clock edge at the  $\overline{CS}$  rising.

Payload	$8 \times (n+1)$ bytes
Command length	$6 + 4 \times (n + 1)$ bytes
Overhead	$75\% / (n + 1) - 50\%$
Efficiency	$200\% \times (1 - 3 / (2n + 5))$


■ **RBCWBI: Combination of RBC and WBI (72<sub>H</sub>)**



The IBP(= input buffer pointer) is cleared and data is written from the address (0400<sub>H</sub>). Also, data is read from the address 0600<sub>H</sub>+4× OBP (OBP = Output Buffer Pointer). ACK=FF<sub>H</sub> is transmitted if an error does not occur at the CRC\_W check. ACK=00<sub>H</sub> is transmitted if an error occurs. If ACK=FF<sub>H</sub> is transmitted, the IBP and OBP are incremented by 1 at the  $\overline{CS}$  rising edge immediately after the ACK. The IBP and OBP are not incremented if there is no  $\overline{CS}$  rising immediately after the ACK. The SPI master can transmit an additional byte (Abort) after receiving the ACK. In this case, the IBP and OBP are not incremented even if MB88121B detects the clock edge at the  $\overline{CS}$  rising.

Payload	$8 \times (n+1)$ bytes
Command length	$6 + 4 \times (n + 1)$ bytes
Overhead	$75\% / (n + 1) - 50\%$
Efficiency	$200\% \times (1 - 3 / (2n + 5))$

■ **RBIWBC: Combination of RBI and WBC (5A<sub>H</sub>)**




Data is written from the address 0400<sub>H</sub>+4×IBP (IBP = Input Buffer Pointer). Also, the OBP (= output buffer pointer) is cleared and data is read from the address (0600<sub>H</sub>). ACK=FF<sub>H</sub> is transmitted if an error does not occur at the CRC\_W check. ACK=00<sub>H</sub> is transmitted if an error occurs. If ACK=FF<sub>H</sub> is transmitted, the IBP and OBP are incremented by 1 at the  $\overline{CS}$  rising edge immediately after the ACK. The

IBP and OBP are not incremented if there is no  $\overline{CS}$  rising immediately after the ACK. The SPI master can transmit an additional byte (Abort) after receiving the ACK. In this case, the IBP and OBP are not incremented even if MB88121B detects the clock edge at the  $\overline{CS}$  rising.

Payload	$8 \times (n+1)$ bytes
Command length	$6 + 4 \times (n + 1)$ bytes
Overhead	$75\% / (n + 1) - 50\%$
Efficiency	$200\% \times (1 - 3 / (2n + 5))$


### ■ RBCWBC: Combination of RBC and WBC (78<sub>H</sub>)



Data is written from the address 0400<sub>H</sub>+4×IBP (IBP = Input Buffer Pointer). Also, data is read from the address 0600<sub>H</sub>+4×OBP (OBP = Output Buffer Pointer). ACK=FF<sub>H</sub> is transmitted if an error does not occur at the CRC\_W check. ACK=00<sub>H</sub> is transmitted if an error occurs. If ACK=FF<sub>H</sub> is transmitted, the IBP and OBP are incremented by 1 at the  $\overline{CS}$  rising edge immediately after the ACK. The IBP and OBP are not incremented if there is no  $\overline{CS}$  rising immediately after the ACK. The SPI master can transmit an additional byte (Abort) after receiving the ACK. In this case, the IBP and OBP are not incremented even if MB88121B detects the clock edge at the  $\overline{CS}$  rising.

Payload	$8 \times (n+1)$ bytes
Command length	$6 + 4 \times (n + 1)$ bytes
Overhead	$75\% / (n + 1) - 50\%$
Efficiency	$200\% \times (1 - 3 / (2n + 5))$

### ■ WIP: Write Input Buffer Pointer (82<sub>H</sub>)




ACK=FF<sub>H</sub> is transmitted if an error does not occur at the CRC\_W check. ACK=00<sub>H</sub> is transmitted if an error occurs. If ACK=FF<sub>H</sub> is transmitted, the IBP is written to at the  $\overline{CS}$  rising edge immediately after the ACK. The IBP is not written to if there is no  $\overline{CS}$  rising immediately after the ACK.

The SPI master can transmit an additional byte (Abort) after receiving the ACK. In this case, the IBP is not written to even if MB88121B detects the clock edge at the  $\overline{CS}$  rising.

The IBP is used by WBC, RBIWBC and RBCWBC commands.

Payload	0 byte
Command length	6 bytes
Overhead	6 bytes
Efficiency	0%

■ **WOP: Write Output Buffer Pointer (88<sub>H</sub>)**




ACK=FF<sub>H</sub> is transmitted if an error does not occur at the CRC\_W check. ACK=00<sub>H</sub> is transmitted if an error occurs. If ACK=FF<sub>H</sub> is transmitted, the OBP is written to at the  $\overline{CS}$  rising edge immediately after the ACK. The OBP is not written to if there is no  $\overline{CS}$  rising immediately after the ACK.

The PI master can transmit an additional byte (Abort) after receiving the ACK. In this case, the OBP is not written to even if MB88121B detects the clock edge at the  $\overline{CS}$  rising.

The OBP is used by RBC, RBCWBI and RBCWBC commands.

Payload	0 byte
Command length	6 bytes
Overhead	6 bytes
Efficiency	0%

■ **WRIBC: Write Input Buffer Command (90<sub>H</sub>)**




IBCM3 to IBCM0 are written into the IBCM register. ACK=FF<sub>H</sub> is transmitted if an error does not occur at the CRC\_W check. ACK=00<sub>H</sub> is transmitted if an error occurs. If ACK=FF<sub>H</sub> is transmitted, IBCR3 to IBCR0 are written into the IBCR register at the  $\overline{CS}$  rising edge immediately after the ACK. The IBCR register is not written to if there is no  $\overline{CS}$  rising immediately after the ACK. The SPI master can transmit an additional byte (Abort) after receiving the ACK. In this case, the IBCR register is not written to even if MB88121B detects the clock edge at the  $\overline{CS}$  rising.

The operation of writing to the IBCM register is unaffected even if a problem occurs during transmission. However, perform the processing after verifying that writing to the IBCR register does not affect transmission.

Payload	8 bytes
Command length	13 bytes

Overhead	62.5%
Efficiency	61.5%

### ■ WROBC: Write Output Buffer Command (9A<sub>H</sub>)




OBCM0 to OBCM3 are written into the OBCM register. ACK=FF<sub>H</sub> is transmitted if an error does not occur at the CRC\_W check. ACK=00<sub>H</sub> is transmitted if an error occurs. If ACK=FF<sub>H</sub> is transmitted, OBCR3 to OBCR0 are written into the OBCR register at the  $\overline{CS}$  rising edge immediately after the ACK. The OBCR register is not written to if there is no  $\overline{CS}$  rising immediately after the ACK. The SPI master can transmit an additional byte (Abort) after receiving the ACK. In this case, the OBCR register is not written to even if MB88121B detects the clock edge at the  $\overline{CS}$  rising.

The operation of writing to the OBCM register is unaffected even if a problem occurs during transmission. However, perform the processing after verifying that writing to the OBCR register does not affect transmission.

Payload	8 bytes
Command length	13 bytes
Overhead	62.5%
Efficiency	61.5%

### ■ RDN: Read Word n (A0<sub>H</sub>)




#### Note:

Read address should be in the range from 000<sub>H</sub> to 3FC<sub>H</sub>, and the number of words to be read should be up to 64 words.

Data RD[4n+3:4n] is read from the address A[9:0]+4n in 4-byte units according to the value in n. ACK=FF<sub>H</sub> is transmitted if an error does not occur at the CRC\_W check. ACK=00<sub>H</sub> is transmitted if an error occurs.

Payload	$4 \times (n+1)$ bytes
Command length	$6 + 4 \times (n + 1)$ bytes
Overhead	$150\% / (n + 1)$
Efficiency	$100\% \times (1 - 3 / (2n + 5))$

■ **WRHS: Write Input Buffer Header Section 1 to 3 (AA<sub>H</sub>)**




WRHS13 to WRHS10 are written to the WRHS1 register, and WRHS23 to WRHS20 are written to the WRHS2 register. ACK=FF<sub>H</sub> is transmitted if an error does not occur at the CRC<sub>W</sub> check. ACK=00<sub>H</sub> is transmitted if an error occurs. If ACK=FF<sub>H</sub> is transmitted, WRHS33 to WRHS30 is written into the WRHS3 register at the  $\overline{CS}$  rising edge immediately after the ACK. The WRHS3 register is not written to if there is no  $\overline{CS}$  rising immediately after the ACK. The SPI master can transmit an additional byte (Abort) after receiving the ACK. In this case, the WRHS3 register is not written to even if MB88121B detects the clock edge at the  $\overline{CS}$  rising.

The operation of writing to the WRHS1 and WRHS2 registers is unaffected even if a problem occurs during transmission.

Payload	12 bytes
Command length	17 bytes
Overhead	41.7%
Efficiency	70.6%

■ **NOP: Read Status (00<sub>H</sub>)**



Payload	0 byte
Command length	6 bytes
Overhead	6 bytes
Efficiency	0%

## 2.5.1 Data Security Algorithm

---

This section explains the data security algorithm.

---

### ■ Data Security Algorithm

**CRC\_x:** CRC\_W and CRC\_R fields are used for error detection. The CRC consists of 16 bits. The initial value is 0x1d0f and CRC polynomial is 0x1021 ( $X^{12}+X^5+1$ ) when the field is generated.

Example:

WR command:

1. 0x0a (Command)
2. 0x04 (Address)
3. 0x0F (WD0)
4. 0x00 (WD1)
5. 0x00 (WD2)
6. 0x00 (WD3)
7. CRC\_W
8. CRC\_W
9. 0xFF (Fill Byte)
10. 0xFF (Fill Byte)

Bytes 1 to 6 must be used for CRC\_W calculation.

Fill byte indicates arbitrary value (e.g. 0xFF, 0x00).

RD command:

1. 0x21 (Command)
2. 0x00 (Address)
3. 0xFF (Fill Byte)
4. 0xFF (Fill Byte)
5. 0xFF (Fill Byte)
6. 0xFF (Fill Byte)
7. CRC\_W
8. CRC\_W
9. 0xFF (Fill Byte)
10. 0xFF (Fill Byte)

Bytes 1, 2 must be used for CRC\_W calculation of RD command.

Fill byte indicates arbitrary value (e.g. 0xFF, 0x00).

---

Note:

CRC must be generated as data of MSB first. Note that CRC is used in the LSB first mode.

---

**ACK:** The ACK field consists of 8 bits. MB88121B notifies the host whether or not the CRC check on the received CRC\_W field has been successful using the ACK field. ACK=FF<sub>H</sub> is transmitted when successful, and ACK=00<sub>H</sub> is transmitted for an error.

The host can correct the error from cs (ACK) that adds each bits in the ACK field as shown in the following expression.

$$cs(ACK) = \sum_{i=0}^7 ACK[i]$$


For example, the error correction on an acknowledge ACK\_ecc is as follows.

If cs(ACK) ≥ 6, ACC\_ecc is "OK". In this case, the host determines that the transmission has been successful.

If cs(ACK) ≤ 5, ACC\_ecc is "NG". In this case, the host transmits the additional byte (abort command). Set CS to "H" and restart the transmission.

**Abort:** After receiving the correct CRC\_W, the MB88121B performs the appropriate processing (writing to a register or updating the IBP/OBP) on the rising edge of the  $\overline{CS}$  signal following the ACK byte (however, data is written into the input buffer as each word is read). MB88121B does not perform an action if there is no  $\overline{CS}$  rising, or on the other timings. The host cannot determine if MB88121B has received the message correctly if any bits are missing from the ACK byte. In this case, the host can transmit an Abort (interpreted by MB88121B) as an additional byte at the  $\overline{CS}$  timing. In such a case, the message is ignored and writing to the register or updating the IBP/OBP does not occur.

Example) Transmit Abort by WR command



**DMY:** Additional byte. The DMY value is arbitrarily. When the additional byte is added, the DMY is handled as Abort.

## 2.5.2 SPI Status Output

This section explains the SPI status output.

### ■ SPI Status Output

In the SPI interface protocol, the first 3 bytes in the command frame are status information.

#### ● Status 0


This register indicates the status of the input buffer and output buffer. The status is updated at the falling edge of  $\overline{CS}$ .

bit	7	6	5	4	3	2	1	0
	0	0	0	0	0	0	STO1	STO0

Bit	Bit name	Description
7	-	"0"
6	-	"0"
5	-	"0"
4	-	"0"
3	-	"0"
2	-	"0"
1	STO1	<b>OBSYS</b> When this bit is "1", the output buffer is in use. Also, writing into the OBCR register is not available. When this bit is set to "1" by the WROBC command, the command does not write into the OBCM and OBCR registers.
0	STO0	<b>IBSYH</b> When this bit is "1", the input buffer is in use. Writing into the input buffer is not available. When this bit is set to "1" by the WRIBC command, the command does not write into the IBCM and IBCR registers.

● Status 1

This register indicates the status of the previous SPI command. This status is cleared by hardware\_reset.



Bit	Bit name	Description
7	ST17	Command parity error "1": Error "0": No error
6	ST16	Command format error (Example: bit 2/bit 0 of the command is "1", except for A10 bit) "1": Error "0": No error
5	-	"0"
4	ST14	Undefined command (when C4 to C0=05 <sub>H</sub> to 07 <sub>H</sub> , 09 <sub>H</sub> , 0D <sub>H</sub> , 16 <sub>H</sub> to 1F <sub>H</sub> ) error
3	ST13	Eray busy error (Example: The CPU has attempted to write data into the input buffer or IBCM/IBCR register while the input buffer is busy. Or, the CPU has attempted to write data into the OBCM/OBCR register while the output buffer is busy. In such cases, an access error occurs and data is not written.) "1": Error "0": No error
2	ST12	Long message error "1" : Receive the long message. "0" : Receive the specified message or short message.
1	ST11	Short message error "1" : Receive the short message. "0" : Receive the specified message or long message.
0	ST10	CRC error "1": Error "0": No error

● Status 2

This register indicates the status of the interrupt request. The status is changed at the falling edge of  $\overline{CS}$ .

bit	7	6	5	4	3	2	1	0
	0	0	ST25	ST24	ST23	ST22	ST21	ST20

Bit	Bit name	Description
7	-	"0"
6	-	"0"
5	ST25	Timer 1 interrupt pin flag "1": Output "H" to timer 1 interrupt pin. "0": Output "L" to timer 1 interrupt pin.
4	ST24	Timer 0 interrupt pin flag "1": Output "H" to timer 0 interrupt pin. "0": Output "L" to timer 0 interrupt pin.
3	ST23	Interrupt 1 pin flag "1": Output "H" to interrupt 1 pin. "0": Output "L" to interrupt 1 pin.
2	ST22	Interrupt 0 pin flag "1": Output "H" to interrupt 0 pin. "0": Output "L" to interrupt 0 pin.
1	ST21	Status interrupt flag "1": Set any of the bits in the status interrupt register to "1". "0": Set all bits of the status interrupt register to "0".
0	ST20	Error interrupt flag "1": Set any of the bits in the error interrupt register to "1". "0": Set all bits of the error interrupt register to "0".

## 2.6 FlexRay Controller Clock

This section explains the FlexRay controller clock.

### FlexRay Controller Clock

Figure 2.6-1 illustrates the clock distribution diagram in non-multiplex bus mode and multiplex bus mode, and Figure 2.6-2 illustrates the clock distribution diagram in SPI bus mode. The following describes each clock (sclk, f\_bclk and f\_sclk).

- sclk : System clock
- f\_bclk : RAM/register clock
- f\_sclk : FlexRay operation clock (FlexRay sample clock)

**Figure 2.6-1 Clock Distribution Diagram in Non-multiplex Bus Mode and Multiplex Bus Mode**





Figure 2.6-2 Clock Distribution Diagram in SPI Bus Mode



## 2.6.1 FlexRay Controller Clock Control Procedure

---

This section explains the FlexRay controller clock control reference.

---

### ■ Switching Procedure to the PLL Clock

When switching from the reference clock (X0/X1) to the PLL clock, follow the procedure below to configure PLL before switching.

1. Configure multipliers to CCNT:PMUL1 and PMUL0 to adjust the PLL clock to 80 MHz.
  2. Set CCNT:PON=1.
  3. Set CCNT:SSEL=1 after the lockup time (600µs) has elapsed.
- 

Note:

The update is possible only when CCSV:POCS5 to POCS0 is in the DEFAULT\_CONFIG state or CONFIG state.

---

### ■ Switching Procedure to the Reference Clock

Follow the procedure below when switching from the PLL clock to the reference clock (X0/X1),

1. Set CCNT:SSEL=0.
  2. Set CCNT:PON=0 to stop PLL.
- 

Note:

The update is possible only when CCSV:POCS5 to POCS0 is in the DEFAULT\_CONFIG state or CONFIG state.

---

### ■ Switching Procedure to Stop Mode

Follow the procedure below when switching to stop mode.

- Set CCNT:STOP=1.

Follow the procedure below when stopping the oscillation of PPL and switching to stop mode .

1. Set CCNT:SSEL=0.
  2. Set CCNT:PON=0.
  3. Set CCNT:STOP=1.
- 

Note:

The update is possible only when CCSV:POCS5 to POCS0 is in the DEFAULT\_CONFIG state or CONFIG state.

---

## ■ Restoration Procedure from Stop Mode

Follow the procedure below when restoring from stop mode.

- Set CCNT:STOP=0.

## ■ Switching the System Clock Divider Value

Change the system clock divider value (CCNT:SDIV1 and SDIV0) when selecting the reference clock.

---

Note:

The update is possible only when CCSV:POCS5 to POCS0 is in the DEFAULT\_CONFIG state or CONFIG state.

---

## ■ RAM Clock Configuration

Change CCNT:RCLK to switch the RAM clock when selecting the reference clock to switch the RAM clock.

---

Note:

The update is possible only when CCSV:POCS5 to POCS0 is in the DEFAULT\_CONFIG state or CONFIG state.

---

## 2.6.2 Setting Example of the FlexRay Baud Rate

---

This section explains the setting example of the FlexRay baud rate.

---

### ■ Setting Example of the FlexRay Baud Rate

The following examples describe baud rate settings on each FlexRay sample clock  $f_{\text{sclk}}$ \* using values defined by PRTC1:BRP1 and BRP0.

1 bit time always consists of 8 samples. The sample clock  $f_{\text{sclk}}$  is configured by CCNT:SDIV1 and SDIV0.

#### ● When $f_{\text{sclk}} = 80\text{MHz}$

BRP1, BRP0 = 00<sub>B</sub> (default): Baud rate = 10 Mbps

$gdSampleClockPeriod = 1/f_{\text{sclk}} = 12.5 \text{ ns}$

$pSamplesPerMicrotick = 2 (1\mu\text{T} = 25 \text{ ns})$

BRP1, BRP0 = 01<sub>B</sub>: Baud rate = 5 Mbps

$gdSampleClockPeriod = 2/f_{\text{sclk}} = 25 \text{ ns}$

$pSamplesPerMicrotick = 1 (1\mu\text{T} = 25 \text{ ns})$

BRP1, BRP0 = 10<sub>B</sub>, 11<sub>B</sub>: Baud rate = 2.5 Mbps

$gdSampleClockPeriod = 4/f_{\text{sclk}} = 50 \text{ ns}$

$pSamplesPerMicrotick = 1 (1\mu\text{T} = 50 \text{ ns})$

#### ● When $f_{\text{sclk}} = 40\text{MHz}$

BRP1, BRP0 = 00<sub>B</sub> (default): Baud rate = 5 Mbps

$gdSampleClockPeriod = 1/f_{\text{sclk}} = 25 \text{ ns}$

$pSamplesPerMicrotick = 2 (1\mu\text{T} = 50 \text{ ns})$

BRP1, BRP0 = 01<sub>B</sub>: Baud rate = 2.5 Mbps

$gdSampleClockPeriod = 2/f_{\text{sclk}} = 50 \text{ ns}$

$pSamplesPerMicrotick = 1 (1\mu\text{T} = 50 \text{ ns})$

BRP1, BRP0 = 10<sub>B</sub>, 11<sub>B</sub>: Baud rate = 1.25 Mbps

$gdSampleClockPeriod = 4/f_{\text{sclk}} = 100 \text{ ns}$

$pSamplesPerMicrotick = 1 (1\mu\text{T} = 100 \text{ ns})$

## 2.7 FlexRay Protocol Function

---

This section explains the FlexRay protocol function.

---

### ■ FlexRay Protocol Function

This section explains FlexRay protocol function. See "the FlexRay Protocol Specifications V2.1" for further details on the FlexRay protocol.

## 2.7.1 Communication Cycle

This section explains the functions and settings of the communication cycle.


### ■ Communication Cycle

The FlexRay communication cycle consists of the following elements.

- Static segment
- Dynamic segment (optional)
- Symbol window (optional)
- Network idle time (NIT)

The network communication time (NCT) consists of static segment, dynamic segment and symbol window. The slot counter starts at "1" on each communication ch. and counts until the end of the dynamic segment. Also, both channels use synchronized identical macroticks.

**Figure 2.7-1 Communication Cycle Structure**



### ■ Static Segment

The static segment has the following features.

- The slot is (available) protected by the bus guardian.
- The frame transmission starts at the action point of each static slot.
- The payload length is the same among all frames on both channels.

Parameter:    Number of static slots GTUC7:NSS9 to NSS0  
                   Static slot length GTUC7:SSL9 to SSL0  
                   Static frame data length MHDC:SFDL6 to SFDL0  
                   Action point offset GTUC9:APO5 to APO0

## ■ Dynamic Segment

The dynamic segment has the following features.

- All controllers have bus access, and (available) the bus guardian is not valid.
- The slot length is variable and different between both channels.
- The transmission starts at the mini slot action point.

Parameter:    Number of mini slots GTUC8:NMS12 to NMS0  
                   Mini slot length GTUC8:MSL5 to MSL0  
                   Mini slot action point offset GTUC9:MAPO4 to MAPO0  
                   Transmission complete mini slot value MHDC:SLT12 to SLT0

## ■ Symbol Window

The FlexRay Protocol Specifications V2.1 defines 3 symbols.

- Wakeup symbol (WUS) is only transmitted in the WAKEUP state.
- Collision avoidance symbol (CAS) is only transmitted in the STARTUP state.
- Media access test symbol (MTS) is transmitted in the NORMAL\_ACTIVE state to test the bus guardian.

1 MTS symbol per channel is transmitted during the symbol window period.

The symbol window has the following features.

- Transmits 1 symbol.
- The transmission of MTS symbol starts at the symbol window action point.

Parameter:    Action point offset GTUC9:APO5 to APO0  
                   Network idle time start GTUC4:NIT13 to NIT0

## ■ Network Idle Time (NIT)

The FlexRay controller performs the following tasks during the network idle time (NIT).

- Calculates the clock correction time (offset and rate).
- Starts and performs the offset correction on each macrotick.
- Performs tasks associated with the cluster cycle.

Parameter:    Network idle time start GTUC4:NIT13 to NIT0  
                   Offset correction start GTUC4:OCS13 to OCS0



## 2.7.2 Communication Mode

---

This section explains the functions of the communication mode.

---

### ■ Communication Mode

The FlexRay protocol V2.1 supports time-triggered distributed (TT-D) mode. This section explains time triggered distributed (TT-D) communication mode.

### ■ Time-triggered Distributed (TT-D)

The following communication modes are available within TT-D mode.

- Pure static : Minimum 2 static slots + symbol window (optional)
- Mixed static/dynamic : Minimum 2 static slots + dynamic segment + symbol window (optional)

Time-triggered distributed mode operation requires a minimum of 2 cold start nodes. Also, the cluster startup requires 2 faultless cold start nodes. The startup frames should be sync frames. All cold start nodes become synchronized nodes.

## 2.7.3 Clock Synchronization

---

This section explains the clock synchronization.

---

### ■ Clock Synchronization

TT-D mode uses distributed clock synchronization. Each node synchronizes itself to the cluster by measuring the receive timing of sync frames from other nodes.

### ■ Global Time

Although each node has its own clock, these all operate on the concept of global time. The global time consists of a vector of 2 values, namely the cycle (cycle counter) and cycle time (macrotick counter).

- Macrotick (MT) = The base unit of the FlexRay network time measurement. (Macrotick is a multiple of microticks ( $\mu T$ ) (only by an integer))
- Cycle = The unit to represent the duration of 1 communication cycle (Cycles are expressed by macroticks (MT))

### ■ Local Time

The node operation time is regulated in microtick units internally to the node. A microtick is a controller specific time unit obtained from the oscillation clock of each node. Therefore, even if the node is the same, if the controllers are different then the time needs to be set and maintained separately. The accuracy of these local time errors is measured by microtick units ( $\mu T$ ).

- Microtick generation order: Oscillation clock to prescaler to microtick ( $\mu T$ )
- $\mu T$  = The base unit of measuring time in the FlexRay controller (clock correction is carried out in  $\mu T$  units)
- Cycle counter + macrotick counter = The local view of the node's global time

### ■ Synchronization Process

Sync frames are used for clock synchronization. Only previously configured synchronization nodes are able to transmit sync frames. For a 2 channel cluster, the synchronization node should transmit sync frames to both channels.

There are the following restriction in synchronization in FlexRay.

- A maximum of 1 sync frame per node per communication cycle.
- A maximum of 15 sync frames per cluster per communication cycle.
- Use the previously configured number of sync frames (GTUC2:SNM3 to SNM0) on all nodes for clock synchronization.
- A minimum of 2 synchronization nodes are required for clock synchronization and startup.

The time deviation between the expected sync frame receive time and observed receive time during the static segment period are measured for clock synchronization. The calculation for correction time is performed during NIT (offset: all cycles, rate: odd number cycles) using the FTM algorithm. See "the FlexRay Protocol Specifications V2.1 chapter 8" for details.

## ■ Offset (Phase) Correction

- Deviation of the current cycle time is measured.
- For nodes with 2 channels, the smaller value measured among these channels is used for the calculation.
- This is calculated for NIT periods of all communication cycles.
- The offset correction value calculated with even number cycles is used only for checking errors.
- The error check is carried out by comparing against the limit value.
- The correction value is an integer with a sign in  $\mu\text{T}$  units.
- The correction is carried out on odd number cycles. The offset correction is distributed over each macrotick from the start till the end of the cycle (till the end of NIT), by lengthening or shortening the current cycle by a few MTs by shifting the next cycle start position.

## ■ Rate (Frequency) Correction

- The difference in deviation of time is measured for even number cycles and odd number cycles.
- For nodes with 2 channels, the average deviation time differences measured among these channels are used for the calculation.
- This is calculated for NIT periods of odd number communication cycles.
- The cluster drift damping is carried out using the global damping value.
- The error check is carried out by comparing against the limit value.
- The correction value is a signed integer in  $\mu\text{T}$  units.
- The correction is carried out on the next even/odd number cycle pair. The correction is distributed over microticks forming 1 cycle, by lengthening or shortening the current cycle by a few  $\mu\text{T}$ s by shifting the next cycle pair starting position on each node.

## ■ Sync Frame Transmission

Sync frames can be transmitted only from the buffer 0 or 1. The message buffer 1 is used to transmit sync frames when the sync frame has different payloads on 2 channels. In this case, set MRC:SPLM bit to "1".

The message buffer to transmit sync frames must be structured with key slot IDs. This can be configured only in DEFAULT\_CONFIG state or CONFIG state.

Set SUCC1:TXSY to "1" on nodes which transmit sync frames.

## ■ External Clock Synchronization

A significant drift may occur in independent clusters during normal operations. When a synchronization operation is required within an independent cluster, synchronize to an external clock.

- External offset/rate correction values are signed integers.
- External offset/rate correction values are added to the calculated offset/rate correction values.
- The total offset/rate correction time (external and internal) are checked against the configured limit value.

## 2.7.4 Error Handling

This section explains the functions of the error handlings.

### ■ Error Handling

Error handling deployed in FlexRay assumes that communications among unaffected nodes are guaranteed while a lower layer protocol error is occurring among certain nodes. Implement an operation to restart normal operations of the FlexRay controller within application programs. EIR:PEMC is set to "1" when a transition to the error handling state occurs. Also, an interrupt occurs if an interrupt is valid. The actual error mode is displayed by CCEV:ERRM1 and ERRM0.

**Table 2.7-1 POC Error Modes**

Error mode	Operation
ACTIVE (green)	<p>Full operation State: NORMAL_ACTIVE</p> <p>The FlexRay controller is completely synchronized and supporting the clock synchronization for the entire clusters.</p> <p>The error status and status transition information can be obtained by reading the error interrupt flag and status interrupt flag from the EIR register and SIR register. An interrupt occurs if an interrupt is valid.</p>
PASSIVE (yellow)	<p>Limited operation State: NORMAL_PASSIVE, FlexRay controller self recovery possible</p> <p>The FlexRay controller stops transmitting frames and symbols, but is able to process received frames. The clock synchronization continues using receive frames, but an active clock synchronization among the entire cluster is not performed.</p> <p>The error status and status transition information can be obtained by reading the error interrupt flag and status interrupt flag from the EIR register and SIR register. An interrupt occurs if an interrupt is valid.</p>
COMM_HALT (red)	<p>Operation halted State: HALT, FlexRay controller self recovery impossible</p> <p>The FlexRay controller stops frame and symbol processing, clock synchronization processing and macrotick generation.</p> <p>The error status and status transition information can be obtained by reading the error interrupt flag and status interrupt flag from the EIR register and SIR register. The bus driver stops.</p>

### ■ Clock Correction Failed Counter

A transition from the NORMAL\_ACTIVE state to NORMAL\_PASSIVE state occurs when the clock correction failed counter has reached the Maximum Without Clock Correction Passive SUCC3:WCP3 to WCP0. Also, a transition from NORMAL\_PASSIVE state to HALT state occurs when the clock correction failed counter has reached the Maximum Without Clock Correction Fatal SUCC3:WCF3 to WCF0.

The clock correction failed counter CCEV:CCFC3 to CCFC0 monitors the duration where a node's clock correction time cannot be calculated after passing the startup phase. The clock correction failed counter is incremented at the end of odd number communication cycles if either the Missing Offset Correction Signal SFS:MOCS or Missing Rate Correction Signal SFS:MRCS is set to "1".

The clock correction failed counter is set to "0" at the end of odd number communication cycles if Missing Offset Correction Signal SFS:MOCS and Missing Rate Correction Signal SFS:MRCS are not set to "1".

The clock correction failed counter stops incrementing when it reaches the Maximum Without Clock Correction Fatal SUCC3:WCF3 to WCF0 (therefore, the counter does not return to "0" by incrementing it after reaching its maximum value). The clock correction failed counter is set to "0" at a transition from the CONFIG state to the READY state or NORMAL\_ACTIVE state.

### ■ Required Cycle Pair Counter for Status Transition between Passive and Active

The required cycle pair counter for status transition between Passive and Active, SUCC1:PTAC4 to PTAC0, controls the POC transition from the NORMAL\_PASSIVE state to NORMAL\_ACTIVE state.

SUCC1:PTA4 to PTA0 defines the number of even/odd cycle pairs whose clock correction time is valid before the transition from the NORMAL\_PASSIVE state to NORMAL\_ACTIVE state. The transition from the NORMAL\_PASSIVE state to NORMAL\_ACTIVE state is not allowed if SUCC1:PTA4 to PTA0 are set to "0".

### ■ HALT Command

A transition to the HALT state is enabled by setting SUCC1:CMD3 to CMD0 = 0110<sub>B</sub> (CHI command HALT) when the host detects an error status.

When this is carried out in the NORMAL\_ACTIVE state or NORMAL\_PASSIVE state, POC will transit to the HALT state at the end of the current cycle. If this is carried out in other states, SUCC1:CMD3 to CMD0 are set to "0000<sub>B</sub>" = command\_not\_accepted and EIR:CNA is set to "1". An interrupt occurs if an interrupt is valid.

### ■ FREEZE Command

A transition to the HALT state is enabled by setting SUCC1:CMD3 to CMD0 = 0111<sub>B</sub> (CHI command FREEZE) when the host detects a fatal error status. This command causes a transition to the HALT state regardless of the current state of POC.


The transition to the HALT state status can be read from CCSV:PSL5 to PSL0.

## 2.7.5 Communications Controller States

This section explains the configuration of the communication controller states and each of the states.

### ■ Diagram of the Communications Controller States

Figure 2.7-3 Overall Diagram of Communications Controller (CC) States



State transition is controlled by the  $\overline{RST}/RXDA/RXDB$  external pins, the POC state machine, and the CHI command vector (SUCC1:CMD3 to CMD0).

If SUCC1:CMD3 to CMD0 = 0111<sub>B</sub> (CHI command FREEZE) is set, all states will transit to the HALT state.

**Table 2.7-2 FlexRay Controller State Transition Table**

Tn	State	From	To
1	Hardware reset	All States	DEFAULT_CONFIG
2	CONFIG command SUCC1: CMD3 to CMD0 = 0001 <sub>B</sub> (CHI command CONFIG) settings	DEFAULT_CONFIG	CONFIG
3	Unlocking sequence (by the MONITOR_MODE command) SUCC1: CMD3 to CMD0 = 1011 <sub>B</sub> (CHI command MONITOR_MODE) settings	CONFIG	MONITOR_MODE
4	CONFIG command SUCC1: CMD3 to CMD0 = 0001 <sub>B</sub> (CHI command CONFIG) settings	MONITOR_MODE	CONFIG
5	Unlocking sequence (by the READY command) SUCC1: CMD3 to CMD0 = 0010 <sub>B</sub> (CHI command READY) settings	CONFIG	READY
6	CONFIG command SUCC1: CMD3 to CMD0 = 0001 <sub>B</sub> (CHI command CONFIG) settings	READY	CONFIG
7	WAKEUP command SUCC1: CMD3 to CMD0 = 0011 <sub>B</sub> (CHI command WAKEUP) settings	READY	WAKEUP
8	<ul style="list-style-type: none"> <li>• Normal wakeup pattern transmission</li> <li>• Receive WUP</li> <li>• Receive the frame header</li> <li>• Wakeup collision occurs</li> <li>• READY command</li> </ul> SUCC1: CMD3 to CMD0 = 0010 <sub>B</sub> (CHI command READY) settings	WAKEUP	READY
9	RUN command SUCC1: CMD3 to CMD0 = 0100 <sub>B</sub> (CHI command RUN) settings	READY	STARTUP
10	Startup successful	STARTUP	NORMAL_ACTIVE
11	The clock correction fail counter has reached the value set in SUCC3: WCP3 to WCP0.	NORMAL_ACTIVE	NORMAL_PASSIVE
12	Number of valid cycle pairs of the clock correction time has reached the value set in SUCC1: PTA 4 to PTA0.	NORMAL_PASSIVE	NORMAL_ACTIVE
13	READY command SUCC1: CMD3 to CMD0 = 0010 <sub>B</sub> (CHI command READY) settings	STARTUP, NORMAL_ACTIVE, NORMAL_PASSIVE	READY
14	<ul style="list-style-type: none"> <li>• The clock correction fail counter has reached the value set in SUCC3: WCF3 to WCF0 and SUCC1: HCSE is set to "1".</li> <li>• HALT command</li> </ul> SUCC1: CMD3 to CMD0 = 0110 <sub>B</sub> (command HALT) settings	NORMAL_ACTIVE	HALT
15	<ul style="list-style-type: none"> <li>• The clock correction fail counter has reached the value set in SUCC3: WCF3 to WCF0 and SUCC1: HCSE is set to "1".</li> <li>• HALT command</li> </ul> SUCC1: CMD3 to CMD0 = 0110 <sub>B</sub> (command HALT) settings	NORMAL_PASSIVE	HALT
16	FREEZE command SUCC1: CMD3 to CMD0 = 0111 <sub>B</sub> (CHI command FREEZE) settings	All States	HALT
17	CONFIG command SUCC1: CMD3 to CMD0 = 0001 <sub>B</sub> (CHI command CONFIG) settings	HALT	DEFAULT_CONFIG

## ■ DEFAULT\_CONFIG State

The FlexRay controller is disabled in the DEFAULT\_CONFIG state. All configuration registers are accessible, but the RXDA/RXDB/TXDA/TXDB/ $\overline{\text{TXENA}}$  and  $\overline{\text{TXENB}}$  pins are inactive.

The state transition to this state occurs in the following conditions.

- At a hardware reset
- At a transition from the HALT state

To change from the DEFAULT\_CONFIG state to the CONFIG state, write SUCC1:CMD3 to CMD0=0001<sub>B</sub>.

## ■ CONFIG State

The CONFIG state disables the FlexRay controller. All configuration registers are accessible, but the RXDA/RXDB/TXDA/TXDB/TXEN pins are inactive. This state is used to initialize the FlexRay controller settings.

The state transition to this state occurs in the following conditions.

- At a transition from the DEFAULT\_CONFIG state
- At a transition from the MONITOR\_MODE state or READY state

Status information and settings can be analyzed if a transition to this state has occurred via the HALT state and DEFAULT\_CONFIG state. Check no configurations are missing before a transition from the CONFIG state.

Execute the unlocking sequence described in "■ Lock Register (LCK)" in order to transit from the CONFIG state. After unlocking the CONFIG state, write to SUCC1:CMD in order to transit to the next state.

All internal counters and CC status flags are reset when a transition from the CONFIG state occurs.

---

### Note:

A transition from the CONFIG state to the READY state does not affect the status data stored in the message buffer status register (MHDS, TXRQ1/TXRQ2/TXRQ3/TXRQ4, NDAT1/NDAT2/NDAT3/NDAT4, MBSC1/MBSC2/MBSC3/MBSC4) and the message RAM.

---

A transition to the POWER SAVE mode is possible by disabling the module clocks (f\_sclk\*, f\_bclk\*) in the CONFIG state. Check that all the message RAM transfers have completed before disabling the clock.

## ■ MONITOR\_MODE

A transition to the MONITOR\_MODE takes place after unlocking of the CONFIG state and the writing of SUCC1:CMD= 1011<sub>B</sub>. Reception of FlexRay frames and CAS/MTS symbols, and detection of coding errors are enabled in this mode. However, the integrity of the time of the received frames is not checked. And the consistency of temporary receive frames is not checked. Therefore, cycle counter filtering is not supported. This mode can be used, for example, for debugging purposes when the FlexRay network fails to startup. A transition to the CONFIG state occurs after writing SUCC1:CMD= 0001<sub>B</sub>.

The first operation is always invalid in the MONITOR\_MODE. This is because a buffer is created on one of the channels for receiving messages. A receive frame is stored into the message buffer of the frame ID and receives the channel. Invalid frames are handled as data frames. State bits MBS:VFRA, MBS:VFRB, MBS:MLST, MBS:RCIS, MBS:SFIS, MBS:SYNS, MBS:NFIS, MBS:PPIS and MBS:RESS become valid values only after receiving a frame.

The receive FIFO cannot be used in MONITOR\_MODE.

## ■ READY State

A transition to the READY mode takes place after unlocking of the CONFIG state and the writing of SUCC1:CMD= 0010<sub>B</sub>. A cluster wakeup by a transition from this state to the WAKEUP state, a cold start by a transition from this state to the STARTUP state, or joining a running cluster from this state are possible.

A state transition to the READY state occurs when writing SUCC1:CMD= 0010<sub>B</sub> (CHI command READY) from the following states.

- CONFIG state
- WAKEUP state
- STARTUP state
- NORMAL\_ACTIVE state
- NORMAL\_PASSIVE state

A transition from the READY state to respective states occurs when the followings are written.

- SUCC1:CMD=0001<sub>B</sub> (CHI command CONFIG) ⇒ CONFIG state
- SUCC1:CMD=0011<sub>B</sub> (CHI command WAKEUP) ⇒ WAKEUP state
- SUCC1:CMD=0100<sub>B</sub> (CHI command RUN) ⇒ STARTUP state

---

### Note:

Changes of POC from the READY state to the STARTUP state do not affect the status data of status bits (MHDS14 to MHDS0), the register (TXRQ1/TXRQ2/TXRQ3/TXRQ4) or the message RAM.

---

## ■ WAKEUP State

The following explains wakeup settings for the FlexRay controller.

A transition from the READY state to the WAKEUP state occurs when SUCC1:CMD3 to CMD0 = 0011<sub>B</sub> (CHI command WAKEUP) is written.

A transition from the WAKEUP state to the READY state occurs in the following conditions.

- After completing a transmission of a normal wakeup pattern.
- After receiving WUP.
- After detecting a WUP collision.
- After receiving a frame header.
- When SUCC1:CMD3 to CMD0 = 0010<sub>B</sub> (CHI command READY) is written.

In order to perform WAKEUP on a cluster, WAKEUP needs to be executed before the communication startup for the cluster. When the bus driver receives a wakeup pattern over a channel, it wakes up the components other than nodes. At least 1 node within a cluster generates the wakeup pattern.

The host controls the whole wakeup procedure. First, it references the states of the cluster from the bus driver and FlexRay controller, configures the FlexRay controller (and the bus guardian when it is available), and wakes up the cluster. This FlexRay controller configuration enables sending separate special wakeup patterns to each available channel. The FlexRay controller should recognize wakeup patterns only during the WAKEUP state.

WAKEUP can be carried out only on 1 ch. at a time. Configure the wakeup ch. by writing SUCC1:WUCS during the CONFIG state. It is impossible to check normal operations on all nodes from the startup phase. Therefore, it cannot be guaranteed whether all nodes connecting to the wakeup ch. are woken up by the wakeup pattern transmission. The wakeup pattern can only be transmitted from 1 channel on 2-channel systems. The cold start node, which requires the system startup, wakes up remaining channels before the communication startup.

In this wakeup procedure, it appears that one node is transmitting the wakeup pattern even when multiple nodes connecting to a single ch. are transmitting wakeup patterns simultaneously. The wakeup pattern can wake up other nodes even after a collision by two nodes transmitting wakeup patterns simultaneously since it is quick in recovering from signal collisions.

After the transition to the READY state following WAKEUP, the FlexRay controller notifies the change in the WAKEUP status by setting "1" to the flag SIR:WST. The WAKEUP status vector can be read from CCSV:WSV2 to WSV0. If a valid wakeup pattern is received, the flag on either SIR:WUPA or SIR:WUPB is set to "1".

Figure 2.7-4 POC Structure in the WAKEUP State




Table 2.7-3 WAKEUP State Transition

Tn	Condition	From	To
Enter	WAKEUP command SUCC1:CMD3 to :CMD0 = 0011 <sub>B</sub> (CHI command WAKEUP) settings	READY	WAKEUP
1	WAKEUP command SUCC1:CMD3 to :CMD0 = 0011 <sub>B</sub> (CHI command WAKEUP) settings	WAKEUP_STANDBY	WAKEUP_LISTEN
2	<ul style="list-style-type: none"> <li>WUP has been received on the wakeup channel selected by SUCC1:WUCS.</li> <li>A frame header has been received on one of the valid channels.</li> </ul>	WAKEUP_LISTEN	WAKEUP_STANDBY
3	A timer event has occurred.	WAKEUP_LISTEN	WAKEUP_SEND
4	A transmission of a wakeup pattern has completed normally.	WAKEUP_SEND	WAKEUP_STANDBY
5	A collision has been detected.	WAKEUP_SEND	WAKEUP_DETECT
6	<ul style="list-style-type: none"> <li>The wakeup timer has timed out.</li> <li>WUP has been received on the wakeup channel selected by SUCC1:WUCS.</li> <li>A frame header has been received on one of the valid channels.</li> </ul>	WAKEUP_DETECT	WAKEUP_STANDBY
Exit	<ul style="list-style-type: none"> <li>Wakeup has completed (after T2, T4, T6)</li> <li>READY command SUCC1:CMD3 to :CMD0 = 0010<sub>B</sub> (CHI command READY) settings (This CHI command simultaneously resets to the WAKEUP_STANDBY state)</li> </ul>	WAKEUP	READY

The WAKEUP\_LISTEN state is controlled by the wakeup timer and wakeup noise timer. These two timers

are controlled by parameters; Listen Timeout SUCC2:LT20 to LT0 and Listen Timeout Noise SUCC2:LTN3 to LTN0. Listen Timeout is effective in quick cluster wakeups in a noiseless environment, whereas Listen Timeout Noise is effective in wakeups in environments with noise interference.

Wakeup patterns are transmitted on configured channels to check their collisions in the WAKEUP\_SEND state. After a transition from the WAKEUP state to READY state, set CMD3 to CMD0 = 0100<sub>B</sub> (CHI command RUN) to switch to the STARTUP state.

The cause of a wakeup collision detected in the WAKEUP\_SEND state can be identified in the WAKEUP\_DETECT state. The identification stops when it has exceeded Listen Timeout configured by SUCC2:LT20 to LT0. A direct transition to the READY state occurs either on detection of a wakeup pattern from other nodes, or reception of a frame header. If neither detection nor reception is performed, a transition from the WAKEUP\_DETECT state occurs after the Listen Timeout has elapsed. In this case, the cause of the wakeup collisions is unknown.

It is recommended that the startup of a node that will cause a wakeup be delayed for the minimum duration required for another cold start node to wake up and initialize.

The FlexRay Protocol Specifications V2.1 recommends to wake up two channels using two separate FlexRay controllers.

## ■ Host Operations

The host must adjust to the waking up of two channels and determine whether or not to wake up specific channels. The transmission of wakeup patterns is commenced by the host. The receiving bus driver detects the wakeup pattern and notifies it to the local host.

The host controls the following wakeup procedure (the wakeup procedure for one channel).

- Configures the FlexRay controller in the CONFIG state. Selects the wakeup channel configured by the SUCC1:WUCS bit.
- Checks the bus driver whether it has received WUP or not.
- Activates the bus driver on the selected wakeup channel.
- Writes SUCC1:CMD3 to CMD0 = 0010<sub>B</sub> in order to transit to the READY state.
- Writes SUCC1:CMD3 to CMD0 = 0011<sub>B</sub> to start waking up the configured channel.
  - The FlexRay controller transits to the WAKEUP state.
  - After completing a wakeup, the FlexRay controller transits to the READY state and displays the wakeup status (CCSV:POCS5 to POCS0).
- Waits for a previously determined duration till other nodes can be woken up and configured.
- The following procedure applies for the cold start node.
  - Waits till other channels become WUP in a two channel cluster configuration.
  - Write SUCC1:CMD3 to CMD0 = 1001<sub>B</sub> (CHI command ALLOW\_COLDSTART) to reset the cold start inhibit flag CCSV:CSI.
- Writes SUCC1:CMD3 to CMD0 = 0100<sub>B</sub> (CHI command RUN) to transit to the STARTUP state.

The following wakeup procedure is caused by the bus driver.


- The bus driver identifies a wakeup.
- The bus driver notifies the wakeup event to the host.
- The host configures the FlexRay controller.
- The host may carry out the following if necessary.
  - Issues a wakeup command for the second channel.
  - Waits for a previously determined duration till other nodes wake up and configure themselves.
- Writes SUCC1:CMD3 to CMD0 = 0100<sub>B</sub> (CHI command RUN) to transit to the STARTUP state.

## ■ Wakeup Pattern (WUP)

The wakeup pattern (WUP) consists of at least two wakeup symbols (WUS). The wakeup symbol and wakeup pattern are configured by the PRTC1 register and PRTC2 register.

- The single channel wakeup and wakeup symbol cannot be transmitted on both channels at the same time.
- The wakeup symbol is quick in recovering from signal collisions (two overlapping wakeup symbols are always identifiable) in an environment where there are at least two nodes which transmit wakeup patterns.
- Standardize the wakeup symbol on all nodes in a cluster.
- The "L" time of the wakeup symbol is configured by PRTC2:TXL5 to TXL0.
- The wakeup symbol idle time which is used to listen to activities on the bus is configured by PRTC2:TXI7 to TXI0.
- The wakeup pattern consists of at least two transmission wakeup symbols necessary for the wakeup.
- The number of repetitions (repetitions between 2 and 63) can be configured by PRTC1:RWP5 to RWP0.
- The length of the wakeup symbol reception window is configured by PRTC1:RXW8 to RXW0.
- The "L" time of the wakeup reception is configured by PRTC2:RXL5 to RXL0.
- The wakeup reception idle phase time is configured by PRTC2:RXI5 to RXI0.

**Figure 2.7-5 Wakeup Pattern Timing**



## ■ STARTUP State

A node that has been cold started should check while it is in the STARTUP state that both of the initially connected channels have been woken up.

The time required for all nodes and all clusters to wake up and complete configuration cannot be estimated. It is recommended that a startup of the node which causes a wakeup be delayed for the minimum duration required by another cold start node to wakeup, initialize and startup since at least two nodes are

required for the communications startup.

The time delay caused by all nodes and all clusters to completely wakeup and finish configuration is approximately several 100 ms (however, this depends on the hardware used).

The startup is carried out on all channels simultaneously. Nodes transmit the startup frames only during the startup.

The procedure for the error resistant distributed startup is prepared for the initialization synchronization on all nodes. Generally, nodes transit to the `NORMAL_ACTIVE` state through the following procedure (see Figure 2.7-6).

- The cold start procedure to start the scheduled synchronization (leading cold start node).
- The cold start procedure to participate in other cold start nodes (following cold start nodes).
- The integration procedure to join the existing communications schedule (all other nodes).

The attempt at a cold start starts with a transmission of collision avoidance symbols (CAS). Only the cold start node which transmitted CAS transmits frames during the first four cycles after CAS. Afterwards, other cold start nodes participate and then all other nodes participate in the cluster.

The cold start node transmits synchronization frames to the key slot by setting "1" to `SUCC1:TXST` and `SUCC1:TXSY`. The message buffer 0 contains the key slot ID which defines the slot number where the startup frames are transmitted from. The startup frame indicator is set to "1" in the frame header of the startup frame.

The transmission request flag `TXRQ1:TXR0` in the message buffer 0 is reset to "0" after the transmission of the startup frame. In order to transmit data frames from the message buffer 0, set "1" to `TXRQ1:TXR0` via the `IBCR` register after the transition to the `NORMAL_ACTIVE` state. Otherwise, a null frame is transmitted into the slot corresponding to the frame ID stored in the message buffer 0.


Be sure to configure at least three nodes as the cold start node in a cluster consisting of three or more nodes. Configure both nodes as the cold start node in a cluster consisting of two nodes. At least two faultless cold start nodes are required to startup a cluster.

The startup frames should be sync frames. Therefore, all cold start nodes are also synchronized nodes. The number of the cold start attempts is configured by `SUCC1:CSA4` to `CSA0`.

In order for a non-cold start node to join a cluster, at least two startup frames from other nodes are required. Those non-cold start nodes never complete startup until at least two cold start nodes complete startup.

If a non-cold start node and a cold start node both obtain TDMA (time division multiple access) schedule information and receive a sync frame, they will soon start a passive join following the integration procedure. While joining, the nodes adjust their own clock to the global clock (rate and offset) and their own cycle time to the network global cycle. Afterwards, these configurations are checked on every available node. Nodes are able to actively join communications only when they have passed these checks.

Figure 2.7-6 State Diagram for the Time Triggered Startup



### ■ Cold Start Inhibit Mode

Nodes cannot initialize cluster communications in the cold start inhibit mode (CCSV:CSI=1). This means it is prohibited to commence a startup by the cold start procedure. Such nodes can either join a running cluster or transmit startup frames after other cold start nodes have started initializing the cluster communications.

The cold start inhibit bit CCSV:CSI can be configured while POC is in the **READY** state. Clear this bit by setting SUCC1:CMD3 to CMD0 = 1001<sub>B</sub> (CHI command ALLOW\_COLDSTART).

## ■ Startup Timeout

The FlexRay controller provides two different  $\mu$ T timers which support two timeout values (startup timeout and startup noise timeout). These two timers start at the transition to the COLDSTART\_LISTEN state.

When one of these two timers ends, the node terminates the other node detection phase (a transition from the COLDSTART\_LISTEN state to another state) in order to start communications.

### Note:

The startup timer and startup noise timer are the same as the wakeup timer and wakeup noise timer respectively and SUCC2:LT20 to LT0 and SUCC2:LTN3 to LTN0 are used.

### ● Startup Timeout

The startup timeout limits the listen time used by nodes in order to determine whether communications are already established between other nodes, or at least one cold start node is requesting to join other nodes.

The startup timer is configured by SUCC2:LT20 to LT0 (pdListenTimeout).

The startup timer is  $\text{pdListenTimeout} = \text{SUCC2:LT20 to LT0}$ .

The startup timer is restarted by the following.

- A transition to the COLDSTART\_LISTEN state
- When both channels reach the idle state in the COLDSTART\_LISTEN state

The startup timer is stopped by the following.

- When communications are detected on one configured channel while in the COLDSTART\_LISTEN state
- A transition from the COLDSTART\_LISTEN state to another state

Once the startup timer passes the restricted time, neither a timer overflow nor periodical restarts occur. The timer status is retained for future processes.

### ● Startup Noise Timeout

The startup timer and startup noise timer start when a transition from the STARTUP\_PREPARE state to the COLDSTART\_LISTEN state occurs. The startup noise timeout is used to improve the reliability of the startup procedure in a noisy environment. The startup noise timeout is determined by SUCC2:LTN3 to LTN0.

The startup noise timer is  $\text{SUCC2:LT20 to LT0} \times (\text{SUCC2:LTN3 to LTN0} + 1)$ .

The startup noise timeout is calculated as follows.

$\text{SUCC2:LT20 to LT0} + (\text{SUCC2:LTN3 to LTN0} \times \text{SUCC2:LT20 to LT0})$

The startup noise timer is restarted in the following conditions.

- A transition to the COLDSTART\_LISTEN state
- A reception of a header or CAS symbol which has been decoded normally in the COLDSTART\_LISTEN state

The startup noise timer stops at a transition from the COLDSTART\_LISTEN state to another state.

Once the startup timer passes the restricted time, neither a timer overflow nor periodical restarts occur. The timer status is retained for future processes. The startup noise timer does not restart when communication is detected in any channels.

### ■ Startup process of the leading cold start node (starting a cold start)

When a cold start node is in the COLDSTART\_LISTEN state, the node monitors the state of the connected channels.

If communication is not detected, the node transits to the COLDSTART\_COLLISION\_RESOLUTION state and starts a cold start. The first transmission of the CAS symbol is performed in the normal first cycle. This cycle is called cycle 0.

The node transmits its startup frames from cycle 0. Before all cold start nodes become eligible for a cold start, some nodes may transmit CAS symbols simultaneously to commence a startup following the cold start procedure. This state is resolved within the first four cycles after the transmission of CAS.

If any nodes which are starting the cold start receive a CAS symbol or a frame header within these four cycles, they transit again to the COLDSTART\_LISTEN state. As a result, only one node within the cluster continues the cold start procedure. Other cold start nodes start transmitting their own startup frames in cycle 4.

Nodes which commence the cold start after four cycles in the COLDSTART\_COLLISION\_RESOLUTION state transit to the COLDSTART\_CONSISTENCY\_CHECK state. These nodes gather all startup frames from cycle 4 and cycle 5, and adjust the clocks. When the clock correction is carried out without an error and at least one valid startup frame pair is received, they will transit from the COLDSTART\_CONSISTENCY\_CHECK state to the NORMAL\_ACTIVE state.

The number of cold start attempts is configured by SUCC1:CSA4 to CSA0. The remaining number of cold start attempts can be read from CCSV:RCA4 to RCA0. The remaining number of cold start attempts is decremented each time an attempt is made. When the remaining number of attempts is larger than 1, a transition to the COLDSTART\_LISTEN state is possible, whereas the remaining number of attempts is larger than "0", a transition to the COLDSTART\_COLLISION\_RESOLUTION state is possible. Joining a cluster is possible when the remaining number of cold start attempts is "1", but a cold start is prohibited.

### ■ Startup process of following cold start nodes (reacting to the leading cold start node)

When a cold start node transits to the COLDSTART\_LISTEN state, it attempts to receive a valid pair of startup frames in order to obtain the cycle schedule and clock correction from the leading cold state node.

On reception of the first valid startup frame, it immediately transits to the INITIALIZE\_SCHEDULE state. When it receives the second valid startup frame and obtained the cycle schedule, it transits to the INTEGRATION\_COLDSTART\_CHECK state.

An accurate clock correction and the use of the leading cold start node (following cold start nodes initialize their schedule according to this node) are guaranteed in the `INTEGRATION_COLDSTART_CHECK` state. Following cold start nodes gather all sync frames and carry out the clock correction in the following cycle pair. When the clock correction does not show an error and the node continues to receive sufficient frames from the same node, it transits to the `COLDSTART_JOIN` state.

Following cold start nodes start transmitting their own startup frames in the `COLDSTART_JOIN` state and continue to transmit these frames in the next cycle. This enables the leading cold start node and participating nodes to check whether their cycle schedules are synchronized. If an error is detected in the clock correction, the participating node stops the cluster integration. A node in this state transits from the `COLDSTART_JOIN` state to the `NORMAL_ACTIVE` state if it receives at least one valid startup frame in even number cycles and receives at least one valid pair of startup frames in all cycle pairs. Therefore, following cold start nodes transit from the `STARTUP` state to the `NORMAL_ACTIVE` state at least one cycle later than the leading cold start node.

### ■ Startup process of non-cold start nodes

When a non-cold start node is in the `INTEGRATION_LISTEN` state, the node monitors the state of connected channels.

On reception of the first valid startup frame, it immediately transits to the `INITIALIZE_SCHEDULE` state. When it receives the second valid startup frame and has obtained the cycle schedule, it transits to the `INTEGRATION_CONSISTENCY_CHECK` state.

The non-cold start node checks if the clock correction is correctly operating, and if a sufficient number of cold start nodes (at least two) are transmitting startup frames with synchronized cycle schedules in the `INTEGRATION_CONSISTENCY_CHECK` state. If an error is detected while the clock correction is in operation, the integration is stopped.

Be sure that this non-cold start node receives two valid startup frames, or receives a valid startup frame from other integrated nodes within the first even number cycle in this state. Otherwise, the node cancels the integration.

Be sure that this non-cold start node receives two valid pairs of startup frames, or receives a valid pair of startup frames from other integrated nodes within the first cycle pair in this state. Otherwise, the node cancels the integration.

The startup is canceled if two or more valid startup frames are not received within the even number cycle after the first cycle pair, or if two or more valid pairs of startup frames are not received within one cycle pair.

In order for a node in this state to transit from the `STARTUP` state to the `NORMAL_ACTIVE` state, it must receive two valid pairs of startup frames each in two cycle pairs. As a result, the node transits from the `STARTUP` state to the `NORMAL_ACTIVE` state at least one cycle pair after a node which has started a cold start, or at the end of an odd number cycle.

## ■ NORMAL\_ACTIVE State

The startup phase of the entire cluster completes soon after the node which transmits the first CAS symbol and one additional node transmits to the NORMAL\_ACTIVE state. The transmission timing for all transmission messages is determined in the NORMAL\_ACTIVE state. This includes all data frames as well as sync frames. Measurement of the rate and offset starts in all even number cycles (even/odd number cycle pairs are required).

The FlexRay controller supports normal communication functions in the NORMAL\_ACTIVE state.

- Transmission and reception on the FlexRay bus according to the configuration
- Operation of the clock correction

The FlexRay controller transits to the following states from the NORMAL\_ACTIVE state.

- SUCC1:CMD3 to CMD0 = 0110<sub>B</sub> (CHI command HALT) ⇒ Change to HALT state after the current cycle ends
- SUCC1:CMD3 to CMD0 = 0111<sub>B</sub> (CHI command FREEZE) ⇒ Immediately change to the HALT state
- The error state changes from ACTIVE to COMM\_HALT ⇒ Change to HALT state
- The error state changes from ACTIVE to PASSIVE ⇒ Change to NORMAL\_PASSIVE state
- SUCC1:CMD3 to CMD0 = 0010<sub>B</sub> (CHI command READY) ⇒ Change to READY state

## ■ NORMAL\_PASSIVE State

A transition from the NORMAL\_ACTIVE state to the NORMAL\_PASSIVE state occurs when the error state changes from ACTIVE to PASSIVE.

Nodes can receive all frames in the NORMAL\_PASSIVE state (nodes can be completely synchronized and can perform the clock correction). However, nodes do not actively participate in communication unlike in the NORMAL\_ACTIVE state. This means that neither symbols nor frames are transmitted.

The following operations take place in the NORMAL\_PASSIVE state.

- Reception of frames on the FlexRay bus
- No transmissions of frames and symbols on the FlexRay bus
- Operation of the clock correction

The FlexRay controller transits to the following states from the NORMAL\_PASSIVE state.

- SUCC1:CMD3 to CMD0 = 0110<sub>B</sub> (CHI command HALT) ⇒ Change to HALT state after the current cycle ends
- SUCC1:CMD3 to CMD0 = 0111<sub>B</sub> (CHI command FREEZE) ⇒ Immediately change to the HALT state
- The error state changes from PASSIVE to COMM\_HALT ⇒ Change to HALT state
- The error state changes from PASSIVE to ACTIVE ⇒ Change to NORMAL\_ACTIVE state (This change in the error state occurs when CCEV:PTAC4 to PTAC0 and SUCC1:PTA4 to PTA0-1 become equal.)
- SUCC1:CMD3 to CMD0 = 0010<sub>B</sub> (CHI command READY) ⇒ Change to READY state

## ■ HALT State

All communications (transmission and reception) are halted in this state.

The FlexRay controller transits to the HALT state in the following cases.

- From the NORMAL\_ACTIVE state or the NORMAL\_PASSIVE state when SUCC1:CMD3 to CMD0 = 0110<sub>B</sub> (CHI command HALT) is written
- From any states when SUCC1:CMD3 to CMD0 = 0111<sub>B</sub> (CHI command FREEZE) is written
- From the NORMAL\_ACTIVE state when the clock correction failed counter has reached the Maximum Without Clock Correction Fatal WCF3 to WCF0
- From the NORMAL\_PASSIVE state when the clock correction failed counter has reached the Maximum Without Clock Correction Fatal WCF3 to WCF0

The FlexRay controller transits from this state to the DEFAULT\_CONFIG state in the following case.

- When SUCC1:CMD3 to CMD0 = 0001<sub>B</sub> (CHI command CONFIG) is written

When SUCC1:CMD3 to CMD0 = 0110<sub>B</sub> (CHI command HALT) is written, the controller sets "1" to the CCSV:HRQ bit and transits to the HALT state after completing the current communication cycle.

When SUCC1:CMD3 to CMD0 = 0111<sub>B</sub> (CHI command FREEZE) is written, the controller immediately transits to the HALT state and sets "1" to the CCSV:FSI bit.

The transition to the HALT state status can be read from CCSV:PSL5 to PSL0.

## 2.7.6 Network Management

---

**This section explains the network management.**

---

### ■ Network Management

Generated network management (NM) vectors can be read from the register (NMV1 to NMV3). The FlexRay controller performs a bit OR operation on all NM vectors in all valid receive NM frames where the payload preamble indicator (PPI) is set. Only static frames can be configured as NM frames. Also, NM vectors are updated after completing each cycle.

The length of the NM vector can be configured between 0 and 12 bytes by NEMC:NML3 to NML0. Be sure to configure the NM vector length the same on all nodes in the cluster.

Set the PPIT bit in the header section of each transmit buffer to WRHS1:PPIT in order to configure the frame transmit buffer which is set with the PPIT bit. Also, write NM information into the data section of each transmit buffer.

---

#### Note:

When the message buffer is configured for transmission/reception of the network management frames, configure the payload length in the header 2 of the message buffer equal to or larger than the NM vector length configured in NEMC:NML3 to NML0.

---

## 2.7.7 Filtering and Masking

---

**This section explains the filtering and masking.**

---

### ■ Filtering and Masking

Filtering is performed by comparing configurations of the current slot, cycle counter value, channel ID (ch.A, ch.B) and message buffer. An update or transmission of the message buffer occurs when information match occurs in this comparison.

Filtering is performed on the followings.

- Slot counter
- Cycle counter
- Channel ID

The following filter combinations are available for filtering at transmission and reception.

- Slot counter + channel ID
- Slot counter + channel ID + cycle counter

Be sure to match all configured filters with receive message information in order to store a receive message in the message buffer.

---

Note:

The FIFO acceptance filter is configured by the FIFO rejection filter and the FIFO rejection filter mask.

---

The time slot corresponding to the frame ID is transmitted on the configured channel. Match the configured cycle filter value when the cycle counter filtering is available.

### ■ Slot Counter Filtering

All transmit and receive buffers include the frame ID within the header section. The frame ID is compared with the current slot counter value in order to assign it to the slot corresponding to the transmit or receive buffer.

The message buffer with the smallest buffer number is used when two or more buffers are configured with the same frame ID, and there are matching cycle counter filter values for the same slot on these buffers.

## ■ Cycle Counter Filtering

The concept of cycle counter filtering is based on the cycle set. A match to the filter is detected when an element of the cycle set matches. The cycle set is defined by the cycle code field in the header section 1 in each message buffer.

Disable the cycle counter filtering in the message buffer 0 when the message buffer 0 is configured to store startup/sync frames or single slot frames by bits of SUCC1:TXST, TXSY and TSM.

### Note:

Sharing of a static time slot by cycle counter filtering between different nodes in the FlexRay network is not permitted.

The configuration of the number of cycles of a cycle set is described in Table 2.7-4.

**Table 2.7-4 Cycle Set Definitions**

Cycle Code	Matching Cycle Counter Values
000000 <sub>x</sub> <sub>B</sub>	all Cycles
000001 <sub>c</sub> <sub>B</sub>	every second Cycle      at (Cycle Count) mod2 = c
00001 <sub>cc</sub> <sub>B</sub>	every fourth Cycle      at (Cycle Count) mod4 = cc
0001 <sub>ccc</sub> <sub>B</sub>	every eighth Cycle      at (Cycle Count) mod8 = ccc
001 <sub>cccc</sub> <sub>B</sub>	every sixteenth Cycle    at (Cycle Count) mod16 = cccc
01 <sub>ccccc</sub> <sub>B</sub>	every thirty-second Cycle at (Cycle Count) mod32 = ccccc
1 <sub>cccccc</sub> <sub>B</sub>	every sixty-fourth Cycle at (Cycle Count) mod64 = ccccc

The following Table 2.7-5 indicates some examples of valid cycle sets used for cycle counter filtering.

**Table 2.7-5 Examples of Valid Cycle Set**

Cycle Code	Matching Cycle Counter Values
0000011 <sub>B</sub>	1-3-5-7- ... -63 ↵
0000100 <sub>B</sub>	0-4-8-12- ... -60 ↵
0001110 <sub>B</sub>	6-14-22-30- ... -62 ↵
0011000 <sub>B</sub>	8-24-40-56 ↵
0100011 <sub>B</sub>	3-35 ↵
1001001 <sub>B</sub>	9 ↵

A receive message is stored only when the cycle counter value during the cycle when the message is received, and the element of the cycle set of the receive buffer match. Satisfy other filter criteria in the same way.

Contents of the transmit buffer are transmitted to the configured channel when the element of the cycle configuration and the current cycle counter value match. Satisfy other filter criteria in the same way.

**■ Channel ID Filtering**

2-bit channel filtering fields (CHA, CHB) are included in the header section of the message buffers in the message RAM. They act as filters for the receive buffer, and as control fields for the transmit buffer (see Table 2.7-6).

**Table 2.7-6 Channel Filtering Configuration**

CHA	CHB	Transmit Buffer transmit frame	Receive Buffer store valid receive frame
1	1	on both channels (static segment only)	received on ch.A or ch.B (store first semantically valid frame, static segment only)
1	0	on ch.A	received on ch.A
0	1	on ch.B	received on ch.B
0	0	on transmission	ignore frame

Contents of the transmit buffer are transmitted to the channel specified by the channel filtering field when slot counter filtering and cycle counter filtering criteria are satisfied. However, a configuration to transmit to both channels (CHA and CHB) is only permitted in static segments.

Once slot counter filtering and cycle counter filtering criteria are satisfied, valid receive frames are stored if they are received by the channel specified by the channel filtering field. However, a configuration to receive frames by both channels (CHA and CHB) is only permitted in static segments.

Note:

Frames are not transmitted and receive frames are ignored when the message buffer is configured for a dynamic segment and both channel filtering field bits (CHA, CHB) are set to "1" (the same function as for CHA = CHB = 0).

**■ FIFO Filtering**

One reject filter and one reject filter mask are prepared as FIFO filtering. The reject filter consists of the channel filter (FRF:CH1 and CH0), frame ID filter (FRF:FID10 to FID0), and cycle counter filter (FRF:CYF6 to CYF0). The FRF register and FRFM register can be configured only in the DEFAULT\_CONFIG state or the CONFIG state. The filter configuration in the header section of the message buffer which is a member of a FIFO group, is ignored.

The 7-bit cycle counter filter (FRF:CYF6 to CYF0) specifies the cycle set and determines the

communication cycle where the frame ID and channel filter is applied on. No frames are received during the cycle where the frame ID and channel filter are not applied by the cycle set specified by this register.

Valid receive frames are stored in FIFO when the channel ID, frame ID and cycle counter are not rejected by filtering configured by the rejection filter and rejection filter mask, and also they do not match the dedicated receive buffer.

## 2.7.8 Transmission Procedure

---

**This section explains the procedures for each of the transmissions.**

---

### ■ Static Segment

When the messages are suspended in a static segment, the message with the frame ID corresponding to the next transmission slot is selected to be the next transmission message.

The data section of the transmit buffer assigned to a static segment can be updated by the end of the previous time slot. This means that the starting of a message transmission from the input buffer is done by writing into the input buffer command request register at the end of the time slot.

### ■ Dynamic Segment

When the messages are suspended in a dynamic segment, the message with the highest priority (the smallest frame ID) is selected to be the next transmission message. Also, different slot counter columns may occur on ch.A and ch.B in a dynamic segment (when transmitting simultaneously with different frame IDs from two channels).

The data section of the transmit buffer assigned to a dynamic segment can be updated by the end of the previous slot. A message transmission from the input buffer is done by writing into the input buffer command request register at the end of the time slot.

The transmission complete minislot value (MHDC:SLT12 to SLT0) defines the maximum minislot value which can be transmitted before prohibiting frame transmissions in the dynamic segment in the current cycle.

### ■ Transmit Buffer

A message buffer can be used as a transmit buffer by setting "1" to the CFG bit in the header section of each message buffer.

The following methods can be used to assign a transmit buffer to a FlexRay controller channel.

- Static segment: ch.A or ch.B, ch.A and ch.B.
- Dynamic segment: ch.A or ch.B.

The message buffer 0 is set by SUCC1:TXST, TXSY and TSM and can be used as a dedicated buffer for storing startup frames and sync frames or as a dedicated buffer for specified single slot frames. In this case, the message buffer 0 can be reconfigured only in the DEFAULT\_CONFIG state or the CONFIG state. A transmission of startup frames/sync frames from other message buffers is not possible.

All message buffers configured for static segments or dynamic segments transmission except buffer 0 can be reconfigured on the fly by the settings of MRC:SEC1 and SEC0. However, the data partition in the message RAM is referenced by the data pointer in the header partition. Therefore, care needs to be taken to

avoid an incorrect message buffer structure if the payload length and data pointer in the header section of a message buffer are reconfigured.

Care needs to be taken if a message buffer is reconfigured on the fly (when the header section is updated), as the message buffer might not be transmitted by each communication cycle.

Be sure to provide the header CRC to all transmit buffers since the FlexRay controller is not equipped with a function to calculate the header CRC. When network management is required, the host should set "1" to the PPIT bit in the header section of each message buffer and write network management information into the data section of these message buffers.

A 2-byte unit payload length is stored into the payload length field. When the payload length of the configured static transmit buffer is shorter than the configuration by MHDC:SFDL6 to SFDL0, padding bytes are inserted to guarantee the payload length of the static frame. The padding byte is indicated as "0". The transmission mode can be configured on each transmit buffer by the transmission mode flag ((TXM). The transmit message is transmitted in single shot mode when this bit is set to "1". The transmit message is transmitted in continuous mode when this bit is set to "0".

The TXR127 to TXR0 flags in each message buffer are cleared to "0" after completing the transmission in single shot mode. After that, overwriting the transmit buffer by the next transmission message becomes possible.

The TXR127 to TXR0 flags in each message buffer are not cleared to "0" after completing the transmission in continuous mode. In this case, frames are transmitted each time the filter criteria match. The TXR127 to TXR0 flags can be cleared to "0" by writing each message buffer number into the IBCR register while the IBCM:STXRH bit is set to "0".

The transmit buffer with the lowest buffer number is transmitted in each slot when two or more transmit buffers satisfy the filter criteria.

## ■ Frame Transmission

The following procedure is required to prepare the message buffer for transmissions.

1. Configure the transmit buffer in the message RAM using WRHS1, WRHS2 and WRHS3.
2. Write data into the data section of the transmit buffer using WRDSn.
3. Write the target buffer number into the IBCR register to set the input buffer into the message RAM and transfer the message data.
4. When the IBCM register is configured for message transmissions, the transmission request flag (TXR) on each message buffer is set to "1" as soon as the transfer from the input buffer is complete and the message buffer waits for the transmission.
5. Whether the message buffer has completed the transmission or not can be verified by checking the TXR bit (TXR= 0) in the TRXQ1/TRXQ2/TRXQ3/TRXQ4 registers (only in single shot mode).

The TSR127 to TXR0 flags in the TXRQ1/TXRQ2/TXRQ3/TXRQ4 registers are cleared to "0" after completing the transmission (in single shot mode). Also, SIR:TXI is set to "1" if the MBI bit of the header section in the message buffer is set to "1". An interrupt occurs if an interrupt is valid.

## ■ Null Frame Transmission

The FlexRay controller transmits a null frame with the null frame indicator set to "0" and payload data cleared to "0", if the transmission request flag is not set to "1" before the transmission time and no other transmission buffers satisfy the filter criteria in a static segment.

A null frame is transmitted in the following cases.

- When the transmission request flag is not set ( $TXR = 0$ ) on the message buffer which matches the filter criteria and has the smallest buffer number.
- When all transmit buffers include a cycle counter filter which does not match the current cycle. In this case, the message buffer status (MBS) is updated on the transmit buffer which matches the current slot counter value and has the smallest buffer number.

Null frames are not transmitted in a dynamic segment.

## 2.7.9 Reception Procedure

---

**This section explains the procedures for each of the receptions.**

---

### ■ Receive Buffer

A message buffer can be used as a receive buffer by setting "0" to the CFG bit in the header section of the message buffer.

The following methods can be used to assign a receive buffer to a FlexRay controller channel.

- Static segment: ch.A or ch.B  
ch.A and ch.B
- Dynamic segment: ch.A or ch.B

The FlexRay controller stores all elements (except the frame CRC) of the frame which matches the filter criteria for receive buffers.

All receive message buffers configured for static segments or dynamic segments can be reconfigured on the fly by MRC:SEC1 and SEC0. However, receive messages in each communication cycle might be lost if the header section in the message buffer is reconfigured on the fly.

The receive buffer with the smallest message buffer number is updated by the receive message if two or more buffers match the filter criteria.

### ■ Frame Reception

The following procedure is required to prepare the message buffer for receptions.

- Configure the receive buffer in the message RAM using WRHS1, WRHS2 and WRHS3.
- Transfer the configuration from the input buffer to the message RAM by writing the target message buffer number into the IBCR register.

When these steps are carried out, the message buffer starts to function as an active receive buffer and the acceptance filtering process is performed each time a message is received. The receive buffer which matches the filter criteria first is updated by the receive message.

Each ND flag in the NDAT1/NDAT2/NDAT3/NDAT4 registers is set to "1" when a valid payload segment is stored into the data section in the message buffer. Also, the SIR:RXI flag is set to "1" if the MBI bit of the header section in the message buffer is set to "1". An interrupt occurs if an interrupt is valid.

If the ND bit is already set to "1" when the message buffer is updated, MBS:MLST in the receive message buffer is set and unprocessed message data is lost.

If there is no frame in a slot, or if a slot receives a null frame or a corrupted frame, no update is performed

on the data section in the message buffer which is configured for this slot. In this case, only each message buffer status flag is updated.

Each MBS flag in the MBSC1/MBSC2/MBSC3/MBSC4 registers is set to "1" when the status flag in the header section in the message buffer is updated. Also, the SIR:MBSI flag is set to "1" if the MBI bit of the header section in the message buffer is set to "1". An interrupt occurs if an interrupt is valid.

If the payload length (PLR6 to PLR0) of a receive frame is longer than the value configured in PLC6 to PLC0 in the header section in each message buffer, the data field stored in the message buffer is shortened to that length.

Follow the description in "■ Data Transmission from the Message RAM to the Output Buffer" to read the receive buffer from message RAM through the output buffer.

---

Note:

ND and MBS flags are cleared to "0" when the payload data and the header of the receive message are transferred to the output buffer respectively.

---

### ■ Null Frame Reception

The payload segment of a received null frame is not reflected in the receive buffer. If a null frame is received, the header section of the receive buffer is updated by the received null frame. The null frame indicator (NFI) in the header section in the received message buffer is cleared to "0".

Each MBS flag in the MBSC1/MBSC2/MBSC3/MBSC4 registers is set to "1" when the status flag in the header section in the message buffer is updated. Also, the SIR:MBSI flag is set to "1" if the MBI bit of the header section in the message buffer is set to "1". An interrupt occurs if an interrupt is valid.

## 2.7.10 FIFO Function

---

**This section explains the functions of the FIFO.**

---

### ■ Details


One group of message buffers can be configured as the FIFO buffer. Message buffers belonging to a FIFO message group are adjacent in the register map. Starting from the message buffer referenced as MRC:FFB7 to FFB0 and ending with the message buffer referenced as MRC:LCB7 to LCB0 is available. A maximum of 128 message buffers can be assigned to FIFO.

All valid receive messages which do not match the filter criteria of dedicated receive buffers and match the configured FIFO filter criteria are stored in FIFO. In this case, the frame ID, payload length, receive cycle count and status bit in the specified FIFO message buffer are overwritten by the receive frame. Also, the SIR:RFNE bit indicates that FIFO is not empty, and the SIR:RFF bit is set to "1" when the receive FIFO is becoming full, and the EIR:RFO bit indicates a detection of a FIFO overrun. An interrupt occurs if an interrupt is valid.

FIFO has two index registers tied to the FIFO, the PUT Index (PIDX) register and the GET Index (GIDX) register. The PIDX register indicates the position to store the next message in FIFO. When a new message is received, the message is written into the message buffer specified by the PIDX register. Then the value of the PIDX register is incremented to point to be stored the message buffer for the next message. When the value in the PIDX register exceeds the largest message buffer number in the FIFO, it returns to the smallest message buffer number in the FIFO. The GIDX register is used to specify the next message buffer to be read in FIFO. The value of the GIDX register is incremented after transferring the contents of the message buffer belonging to the FIFO message group to the output buffer. Access to the PIDX register and the GIDX register is not available.

FIFO is full when the value of the PIDX register reaches the value of the GIDX register. When a new message is written before reading the oldest message in FIFO, both values in the PIDX register and the GIDX register are incremented and the newest message overwrites the oldest message. This sets "1" to the EIR:RFO flag.

**Figure 2.7-7 FIFO Status: Empty, not Empty and Overrun**



When the value of the PIDX register and the value of the GIDX register are different, the FIFO not empty status is detected and the SIR:RFNE flag is set to "1". This indicates that at least one receive message is present in FIFO. Figure 2.7-7 illustrates the FIFO empty, FIFO not empty and FIFO overrun statuses when a FIFO contains three message buffers.

The FIFO rejection filter (FRF) defines the filter pattern to reject messages. The filter consists of the channel filter, frame ID and cycle counter filter. All messages received in a static segment are rejected by that FIFO filter when the FRF:RSS bit is set to "1". Received null frames are not stored in FIFO when the FRF:RNF bit is set to "1".

Do not perform rejection filtering using the FIFO Rejection Filter Mask (FRFM) while frame ID filtering is being performed using the FIFO Rejection Filter register.

### ■ FIFO Configuration

Configure the payload length PLC6 to PLC0 to the same value on all message buffers belonging to FIFO. Also, configure the data pointer to the top 32-bit word of the data section in each message buffer in the message RAM.

All information required for the acceptance filter is configured by the FIFO rejection filter and FIFO rejection filter mask. There is no need to configure the filter criteria on the header section in each message buffer belonging to FIFO.

**Note:**

When the payload length of the receive frame exceeds the setting value PLC6 to PLC0 in the header section in each message buffer, the data field stored in the FIFO message buffer is shortened to the length specified in PLC6 to PLC0.

## ■ Access to FIFO

When reading from FIFO, transfer the data from the message RAM to the output buffer by writing the first message buffer number of FIFO (referenced by MRC:FFB7 to FFB0) into the OBCR register. The message buffer specified by the GIDX register is transferred to the output buffer. After this transfer, the value of the GIDX register is incremented.

## 2.7.11 Message Handling

---

**This section explains the message handling.**

---

### ■ Message Handling

The message handler controls data transfer between the input/output buffer and the message RAM, and between the message RAM and two transient buffer RAMs. Every access to the internal RAM is performed by 32+1 bits unit. The additional bit is used for the parity check.

Access to the message buffer stored in the message RAM is performed under control of the message handler state machine. This prevents access collisions between hosts to two FlexRay channel protocol controllers and the message RAM.

Be sure to keep the frame ID of the message buffer assigned to a static segment in the range from 1 to GTUC7:NSS9 to NSS0. Be sure to keep the frame ID of the message buffer assigned to a dynamic segment in the range from GTUC7:NSS9 to NSS0 +1 to 2047.

The receive message is stored into receive FIFO (if it is configured so) when it does not match the filter criteria of the dedicated receive buffer (static segment or dynamic segment) and it matches the filter criteria of the FIFO rejection filter.

### ■ Message Buffer Reconfiguration

The static message buffer and dynamic message buffer may be reconfigured while the FlexRay controller is still operating if the application requires more than 128 message buffers. This can be performed by updating the header section in each message buffer via the input buffer register (WRHS1 to WRHS3).

Be sure to enable the reconfiguration using the control bits MRC:SEC1 and SEC0 in the message RAM setting register.

The message is lost if the message buffer has not been updated by a receive frame, or a transmission message has not been transmitted from the message buffer before the reconfiguration starts.

The timing when transmission or reception is enabled by a reconfiguration of the frame ID for the reconfigured message buffer depends on the state of the current slot counter when the update of the header section is complete.

Although the message RAM scan is not complete, it ends at the start of NIT. The message RAM scan for 2 to 15 slots starts from the beginning of slot 1 of the actual cycle. The message RAM scan on slot 1 is performed before the cycle by checking parallel with each scan on the message RAM even when there is a message buffer configured for slot 1 of the next cycle.

The first dynamic message buffer number is configured by MRC:FDB7 to FDB0. If a message RAM scan starts while CC is in the dynamic segment, the scan starts from the message buffer number set in MRC:FDB7 to FDB0.

Follow the following procedure to reconfigure a message buffer in order to use it in slot 1 of the next cycle.

- If the message buffer to be reconfigured for slot 1 is a static buffer, reconfigure the message buffer before it is evaluated by the final message RAM scan in the static segment of the actual cycle.
- If the message buffer to be reconfigured for slot 1 is a static + dynamic buffer, reconfigure the message buffer before it is evaluated by the final message RAM scan in the actual cycle.
- The message RAM scan finishes when the NIT starts. If the message RAM scan was not able to find the reconfigured message buffer, the message buffer is not executed during the next cycle.

---

Note:

Take care when reconfiguring a message buffer since it may result in a message loss.

---

## ■ Host Access to the Message RAM


Message transfers between the input buffer and the message RAM and between the message RAM and the output buffer start by writing the message buffer number into the IBCR register or the OBCR register respectively.

The IBCM register and the OBCM register can be used separately to read/write the header section and data section of the selected message buffer.

When the IBCM:STXRH bit is set to "1", the transmission request flag (TXR) of the message buffer is automatically set to "1" after the IBCM:STXRS is set to "1" and the selected message buffer is updated. When the IBCM:STXRH bit is set to "0", the IBCM:STXRS bit is cleared to "0" and the transmission request flag (TXR) of the selected message buffer is cleared to "0". This clearing operation can be used to stop a transmission on the message buffer which is operating in continuous mode.

The input buffer (IBF) and output buffer (OBF) consist of a double buffer. Among this double buffer structure, the IBF host/OBF host can be accessed from the host and another IBF shadow/OBF shadow is accessed by the message handler for data transfer between IBF/OBF and the message RAM.

Figure 2.7-8 Host Access to the Message RAM




### ■ Data Transmission from the Input Buffer to the Message RAM

To configure or update the message buffers in the message RAM, write the data to WRDSn and write the header to WRHS1 to WRHS3. A specific operation is selected by setting IBCM.


The IBF host and IBF shadow are swapped by writing the target message buffer number of the message RAM to IBCR:IBRH6 to IBRH0 (see Figure 2.7-9).

**Figure 2.7-9 Double Buffer Structure of the Input Buffer**



Also, bits in the IBCM register and the IBCR register are swapped in order to retain the association with each section in IBF (see Figure 2.7-10).

**Figure 2.7-10 Bit Swapping in the IBCM Register and IBCR Register**



IBCR:IBSYS is set to "1" by this write operation. The message handler starts transmitting the contents of the IBF shadow into the message buffer in the message RAM selected by IBCR:IBRS6 to IBRS0.

The next message can be written into the IBF host while the data is transferred from the IBF shadow to the target message buffer in the message RAM. After completing the transfer between the IBF shadow and the message RAM and the IBCR:IBSYS bit is cleared to "0", the next transfer to the message RAM is started by writing the next target message buffer number into IBCR:IBRH6 to IBRH0.

If IBCR:IBRH6 to IBRH0 is written while IBCR:IBSYS=1, IBCR:IBSYH is set to "1". When a data transfer from the IBF shadow to the message RAM is complete, IBCR:IBSYH is cleared to "0" and "1" is retained in IBCR:IBSYS, then the next transfer to the message RAM starts. Also, the message buffer number and the command mask flag stored in IBCR:IBRH6 to IBRH0 and IBCR:IBRS6 to IBRS0 are swapped simultaneously.

An example of the input buffer configuration procedure:

Configure/update the first message buffer via IBF.

- Write the data section to WRDSn.
- Write the header section to WRHS1 to WRHS3.
- Writing the command mask: write to IBCM:LHSH, LDSH and STXRH.
- Data transfer request to the target message buffer: write to IBCR:IBRH6 to IBRH0.

Configure/update the second message buffer via IBF.

- Write the data section to WRDSn.
- Write the header section to WRHS1 to WRHS3.
- Writing the command mask: write to IBCM:LHSH, LDSH and STXRH.
- Data transfer request to the target message buffer: write to IBCR:IBRH6 to IBRH0 after IBCR:IBSYH is cleared to "0".

Configure/update the third message buffer via IBF.

...(Repeat the same procedure for the second message buffer)

Note:

An access to the input buffer while IBCR:IBSYH is "1" sets the error flag (EIR:IIBA) to "1". In this case, access is disabled.

**Table 2.7-7 Input Buffer Command Mask Bit Assignment**

Pos.	Access	Bit	Function
18	R	STXRS	Set Transmission Request Shadow ongoing or finished
17	R	LDSS	Load Data Section Shadow ongoing or finished
16	R	LHSS	Load Header Section Shadow ongoing or finished
2	R/W	STXRH	Set Transmission Request Host
1	R/W	LDSH	Load Data Section Host
0	R/W	LHSH	Load Header Section Host


**Table 2.7-8 Input Buffer Request Mask Bit Assignment**

Pos.	Access	Bit	Function
31	R	IBSYS	IBF Busy Shadow, signals ongoing transfer from IBF Shadow to Message RAM
22 to 16	R	IBRS6 to BRS0	IBF Request Shadow, number of message buffer currently updated
15	R	IBSYH	IBF Busy Host, transfer request pending for message buffer referenced by IBRH[6:0]
6 to 0	R/W	IBRH6 to IBRH0	IBF Request Host, number of message buffer to be updated next
1	R/W	LDSH	Load Data Section Host
0	R/W	LHSH	Load Header Section Host

### ■ Data Transmission from the Message RAM to the Output Buffer

Do not write into the OBCR register when reading the message buffer from the message RAM since it causes a data transfer as configured in OBCM. After the transfer is complete, the data transferred from RDSSn, RDHS1 to RDHS3 and MBS can be read.

Configure the buffer number of the transfer source message buffer in the message RAM by OBCR:OBRS6 to OBRS0.


**Figure 2.7-11 Double Buffer Structure of the Output Buffer**

As well as each bit in OBCM:RHSS, RDSS, RHSH and RDSH, and each bit in OBCR:OBRS6 to OBRS0 and OBCR:OBRH6 to OBRH0, the OBF host and OBF shadow are swapped according to the configuration of the OBCR:VIEW bit and OBCR:REQ bit.

Each bit in OBCM:RHSS, RDSS, and OBCR:OBRS6 to OBRS0 are copied into the internal register by setting the OBCR:REQ bit to "1" (see Figure 2.7-12).

After setting OBCR:REQ to "1", OBCR:OBSYS is set to "1" and the transfer from the message RAM of the message buffer selected by OBCR:OBRS6 to OBRS0 to the OBF shadow starts. The OBCR:OBSYS bit is cleared to "0" after completing the transfer from the message RAM to the OBF shadow. OBCR:REQ and OBCR:VIEW can be set to "1" while OBCR:OBSYS is "0".

**Figure 2.7-12 Bit Swapping in the OBCM Register and OBCR Register**



The OBF host and OBF shadow can be swapped by setting OBCR:VIEW to "1" while the OBCR:OBSYS bit is "0" (see Figure 2.7-11). Also, bits of OBCR:OBRH6 to OBRH0, OBCM:RHSH and OBCM:RDSH are swapped with the internal registers. The internal registers store the values that were copied from OBCR:OBRS6 to OBRS0, OBCM:RHSS and OBCM:RDSS before OBCR:VIEW was set to "1". By swapping the internal registers, the message buffer number read from OBCR:OBRH6 to OBRH0 and the mask configuration read from OBCM:RHSH and OBCM:RDSH are guaranteed to match the transfer data read from the OBF host (see Figure 2.7-12).

The message buffer which is already transferred can be read from the OBF host after these swaps while the message handler is able to transfer the next message from the message RAM to the OBF shadow.

An example of the output buffer configuration procedure:

- Transfer request of the first message buffer for the OBF shadow.
- Writing the command mask: write to OBCM:RHSS and OBCM:RDSS.
- Transfer request of the first message buffer: write to OBCR:OBRS6 to OBRS0 and OBCR:REQ.
- Wait until OBCR:OBSYS is cleared to "0".

Transfer request of the second message buffer for the OBF shadow and reading the first message buffer from the OBF host.

- Writing the command mask: write to OBCM:RHSS and RDSS.
- Swapping the OBF host and shadow for the first message, and transfer request of the second message: write to OBCR:VIEW, REQ and OBRS6 to OBRS0.
- Read the first message.
- Wait until OBCR:OBSYS is cleared to "0".

Transfer request of the third message buffer for the OBF shadow and reading the second message buffer from the OBF host.

- Writing the command mask: write to OBCM:RHSS and RDSS.
- Swapping the OBF host and shadow for the second message, and transfer request of the third

message: write to OBCR:VIEW, REQ and OBRS6 to OBRS0.

- Read the second message.
- Wait until OBCR:OBSYS is cleared to "0".

(Repeat the same procedure)

Reading the n-th message buffer from the OBF host (when no more message buffer transfer is requested)

- Swapping the OBF host and shadow for the n-th message, and write to OBCR:VIEW (not writing to OBCR:OBRS6 to OBRS0).
- Read the n-th message.

**Table 2.7-9 Output Buffer Command Mask Bit Assignment**

Pos.	Access	Bit	Function
17	R	RDSH	Data Section available for Host access
16	R	RHSH	Header Section available for Host access
1	R/W	RDSS	Read Data Section Shadow
0	R/W	RHSS	Read Header Section Shadow

**Table 2.7-10 Output Buffer Request Mask Bit Assignment**

Pos.	Access	Bit	Function
22 to 16	R	IBRH6 to IBRH0	OBF Request Host, number of message buffer available for Host access
15	R	OBSYH	OBF Busy Shadow, signals ongoing transfer from Message RAM to OBF Shadow
9	R/W	REQ	Request transfer from Message RAM to OBF Shadow
9	R/W	VIEW	View OBF Shadow, swap OBF Shadow and OBF Host
6 to 0	R/W	OBR6 to OBR0	OBF Request Shadow, number of message buffer for next request

## ■ The FlexRay Protocol Controller Access to the Message RAM


Two transient buffer RAMs (TBF A and B) are used as data buffers for transfers between two FlexRay channel protocol controllers and the message RAM.

The two transient buffer RAMs consist of double buffers and they can store two complete FlexRay messages. While one buffer is accessible by the message handler, another buffer is assigned to the corresponding channel protocol controller.

For example, the FlexRay channel protocol controller can store the currently receiving message into the transient buffer Rx while the message handler is writing a transmit message into the transient buffer Tx. The message handler (if it passes the acceptance filter) transfers the latest receive message stored in the transient buffer Rx to the message RAM and updates the message buffer while the message stored in the transient buffer Tx is being transmitted.

The data transfer between the transient buffer RAM and the shift register of the FlexRay channel protocol controller is performed in 32-bit word units. This enables the use of 32-bit shift register which has an independent the length of the FlexRay messages.

**Figure 2.7-13 Access to the Transient Buffer RAM**



## 2.7.12 Message RAM

This section explains the settings and functions of the message RAM.


### ■ Message RAM

Direct access to the message buffer in the message RAM is not available in order to avoid collisions between the host access to the message RAM and transmission and reception of FlexRay messages. Access is processed via the input buffer and output buffer. The message RAM can store up to 128 message buffers.

The message RAM consists of  $2048 \text{ bytes} \times 33 \text{ bits} = 67,584 \text{ bits}$  and each 32-bit data is protected by a parity bit. As the structure of the message RAM is illustrated in Figure 2.7-14, each FlexRay frame can have variable (0 to 254) number of data bytes.

The data partition starts from  $(\text{MRC:LCB}+1) \times 4$  words in the message RAM (1 word = 32+1 bits).

**Figure 2.7-14 Example of the Message Buffer Configuration in the Message RAM**



#### Header partition

The header partition stores the header section of the configured message buffer.

- A maximum of 128 message buffers are supported.
- Each message buffer has a 4-word (1 word = 32+1 bits) header section.
- The header 3 of each message buffer has a 11-bit data pointer for each data section within the data partition.

#### Data partition

The data partition is a variable length memory area which stores data sections with different data length.

The followings describe the maximum number of message buffers for various data lengths.

- Up to 30 message buffers when each data section is 254 bytes.
- Up to 56 message buffers when each data section is 128 bytes.
- Up to 128 message buffers when each data section is 48 bytes.

---

Note:

Be sure to configure that the required area of the header partition + data partition is 2048 words (1 word = 33 bits) or less.

---

## ■ Header Partition

The message buffer status and message buffer configuration elements are stored in the header partition of the message RAM as indicated in Figure 2.7-15. The configuration of the header section of the message buffer is carried out via IBF (WRHS1 to WRHS3) and reading from the header section is carried out via OBF (RDHS1 to RDHS3 + MBS). Configure the data pointer in the header section in order to define the starting position of the data section in each message buffer. Also, do not modify the data pointer while transferring. Perform reconfigurations on message buffers belonging to the FIFO message group in the DEFAULT\_CONFIG state or the CONFIG state.

The header section of each message buffer occupies 4 words (1 word = 32+1 bits) in the header partition in the message RAM. The header section of the message buffer 0 starts from the top of the message RAM.

Calculate the header CRC for the transmit buffer.

The received payload length (PLR6 to PLR0), receive cycle count (RCC5 to RCC0), receive channel indicator (RCI), startup frame indicator (SFI), sync frame indicator (SYN), null frame indicator (NFI), payload preamble indicator (PPI) and reserved bit (RES) are updated by valid receive frames (including valid null frames).

The 4-word area in the header of configured each message buffer contains the message buffer status (MBS).

**Figure 2.7-15 Header Section of the Message Buffer in the Message RAM**

Bit Word	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	P			MBI	TXM	PPIT	CFG	CHB	CHA		Cycle Code										Frame ID												
1	P	Payload Length Received						Payload Length Configured						Tx Buffer: Header CRC Configured Rx Buffer: Header CRC Received																			
2	P			RES	PPI	NFI	SYN	SFI	RCI		Receive Cycle Count						Data Pointer																
3	P			RES	PPI	NFI	SYN	SFI	RCI		Cycle Count						FTB	FTA	MLST	ESB	ESA	TCIB	TCIA	SVOB	SVOA	CEOB	CEOA	SEOB	SEOA	VFRB	VFRA		
...	P	...																															
...	P	...																															

- Frame Configuration (PPIT, CFG, FrameID, Payload Length Configured)
- Filter Configuration (CHB, CHA, Cycle Code)
- Message Buffer Control (MBI, TXM)
- Message RAM Configuration (Data Pointer)
- Updated from received Frame (Payload Length Received, RES, PPI, NFI, SYN, SFI, RCI, Receive Cycle Count)
- Message Buffer Status MBS (MLST, ESB, ESA, TCIB, TCIA, SVOB, SVOA, CEOB, CEOA, SEOB, SEOA, VFRB, VFRA)
- Parity Bit
- unused

**Header 1**

The following parameters are written via WRHS1 and read via RDHS1.

- Frame ID : Configuration of slot counter filtering
- Cycle code : Configuration of cycle counter filtering
- CHA, CHB : Configuration of channel filtering
- CFG : Configuration of the message buffer - reception/transmission
- PPIT : Transmission of the payload preamble indicator
- TXM : Configuration of transmission mode - single shot/continuous
- MBI : Enable flag for the message buffer transmission and reception interrupt

**Header 2**

The following parameters are written via WRHS2 and read via RDHS2.

- Header CRC : Transmit buffer - to be calculated from the frame header segment  
: Receive buffer - updated by the receive frame
- Configured payload length : Configured data section length (2-byte units)
- Receive payload length : Payload segment length stored in the receive frame (2-byte units)

### Header 3

The following parameters are written via WRHS3 and read via RDHS3.

- Data pointer : Pointer to the starting position of the corresponding data section in the data partition

The following parameters are read via RDHS3.

These are valid only for receive buffers and updated by receive frames.

- Receive cycle count : Cycle count value stored from the receive frame
- RCI : Receive channel indicator
- SFI : Startup frame indicator
- SYN : Sync frame indicator
- NFI : Null frame indicator
- PPI : Payload preamble indicator
- RES : Reserved bit

### Header 4

The header 4 is read via MBS. It is updated at the end of the configured slot.

The following parameters are valid on the transmit buffer and receive buffer.

- VFRA : ch.A valid receive frame
- VFRB : ch.B valid receive frame
- SEOA : ch.A syntax error
- SEOB : ch.B syntax error
- CEOA : ch.A contents error
- CEOB : ch.B contents error
- SVOA : ch.A slot boundary error
- SVOB : ch.B slot boundary error

The following parameters are valid on the transmit buffer only.

- TCIA : ch.A transmission collision indicator
- TCIB : ch.B transmission collision indicator

The following parameters are valid on the receive buffer only.

- ESA : ch.A empty slot
- ESB : ch.B empty slot
- MLST : Message lost
- FTA : ch.A frame transmission
- FTB : ch.B frame transmission
- Cycle Count Status : Actual cycle count at the status update
- RCIS : Channel indicator reception
- SFIS : Startup frame indicator status
- SYNS : Sync frame indicator status
- NFIS : Null frame indicator status
- PPIS : Payload preamble indicator status
- RESS : Reserved bit status

## ■ Data Partition

The data partition of the message RAM stores the data section of the message buffer which is configured for reception or transmission as defined in the header partition. The number of data bytes for each message buffer can be configured in the range from 0 to 254 bytes. The bit width of the message RAM is configured as 32 bits + 1 parity bit in order to optimize the whole data transfer between the host interface and the message RAM, and the shift register of 2 FlexRay channel protocol controllers and the message RAM.

The data partition starts immediately after the header partition. Be sure to set the data pointer pointing to the address within the data partition when configuring the message buffer in the message RAM.

Figure 2.7-16 indicates a storing example to the data partition in the message RAM for the data section of the configured message buffer.

The starting position and ending position of the data section in the message buffer are determined by the data pointer and payload length configured in the header section in the message buffer. This enables the flexible use of RAM space in a message buffer with various data lengths.

When the data section size is an odd number of 2-byte units, the remaining 16 bits in the last 32-bit word are not used (see Figure 2.7-16).

**Figure 2.7-16 Example of the Data Section Structure in the Message RAM**

Bit Word	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
...	P	unused								unused								unused								unused							
...	P	unused								unused								unused								unused							
...	P	MBn Data3								MBn Data2								MBn Data1								MBn Data0							
...	P	...								...								...								...							
...	P	...								...								...								...							
...	P	MBn Data(m)								MBn Data(m-1)								MBn Data(m-2)								MBn Data(m-3)							
...	P	...								...								...								...							
...	P	...								...								...								...							
...	P	...								...								...								...							
...	P	MB1 Data3								MB1 Data2								MB1 Data1								MB1 Data0							
...	P	...								...								...								...							
...	P	MB1 Data(k)								MB1 Data(k-1)								MB1 Data(k-2)								MB1 Data(k-3)							
2046	P	MB0 Data3								MB0 Data2								MB0 Data1								MB0 Data0							
2047	P	unused								unused								MB0 Data5								MB0 Data4							


## ■ Parity Check

The FlexRay controller is equipped with a parity check mechanism to guarantee the integrity of the data stored in seven RAM blocks. These RAM blocks include the parity generator/checker connected as indicated in Figure 2.7-17 and the parity generator generates the parity bit as data is written into the RAM block. The FlexRay controller employs the even number parity (The parity bit is generated as "0" when the number of "1"s in the 32-bit word is an even number). The parity bit is stored with the each data. Also, the parity bit is checked when the data is read from the RAM block. The bit width of the FlexRay controller's internal data bus is 32 bits.

Each error flag is set to "1" if a parity error is detected. The message handler status register contains the parity error flag (MHDS:PIBF, POBF, PMR, PTBF1 and PTBF2) and the faulty message buffer indicator (MHDS:FMBD, MFMB and FMB6 to FMB0). These error flags control the error interrupt flag EIR:PERR.

Figure 2.7-17 indicates the data path between RAM blocks and the parity generator/checker.

**Figure 2.7-17 Parity Generation and Check**



**Note:**

The parity generator and parity checker are blocks independent from the RAM block.

The following operations are performed when a parity error is detected.

On all cases:

- The corresponding parity error flag in the MHDS register is set.
- The parity error flag EIR:PERR is set. An interrupt occurs if an interrupt is valid.

Special cases:

- 1) A parity error during a data transfer from the input buffer RAM1, 2 to the message RAM.
  - The MHDS:PIBF bit is set.
  - The MHDS:FMBD bit is set to indicate that MHDS:FMB6 to FMB0 have been updated.
  - MHDS:FMB6 to FMB0 indicate the message buffer number with an error.
  - The transmission request bit is not set for the transfer buffer with the parity error.

- 2) A parity error during a data transfer from the input buffer RAM1, 2 to the host.
  - The MHDS:PIBF bit is set.
- 3) A parity error during a header section scan in the message RAM.
  - The MHDS:PMR bit is set.
  - The MHDS:FMBD bit is set to indicate that MHDS:FMB6 to FMB0 have been read.
  - MHDS:FMB6 to FMB0 indicate the message buffer number with an error.
  - The message buffer with the parity error is ignored.
- 4) A parity error during a data transfer from the message RAM to the transient buffer RAM1, 2.
  - The MHDS:PMR bit is set.
  - The MHDS:FMBD bit is set to indicate that MHDS:FMB6 to FMB0 have been read.
  - MHDS:FMB6 to FMB0 indicate the message buffer number with an error.
  - The frame transmission from the message buffer with an error is halted.
- 5) A parity error during a data transfer from the transient buffer RAM1, 2 to the channel protocol controller 1, 2.
  - The MHDS:PTBF1 and PTBF2 bits are set.
  - The frame transmission from the transient buffer with an error is halted.
- 6) A parity error during a data transfer from the transient buffer RAM1, 2 to the message RAM.
  - The MHDS:PTBF1 and PTBF2 bits are set.
  - The MHDS:FMBD bit is set to indicate that MHDS:FMB6 to FMB0 have been updated.
  - MHDS:FMB6 to FMB0 indicate the message buffer number with an error.
- 7) A parity error during a data transfer from the message RAM to the output buffer RAM.
  - The MHDS:PMR bit is set.
  - The MHDS:FMBD bit is set to indicate that MHDS:FMB6 to FMB0 have been read.
  - MHDS:FMB6 to FMB0 indicate the message buffer number with an error.
- 8) A parity error during a data transfer from the output buffer RAM to the host.
  - The MHDS:POBF bit is set.
- 9) A parity error while reading data from the transient buffer RAM 1, 2.

The network management vector NMV1 to NMV3 are not updated if a parity error has occurred while the message handler was reading a frame with network management information (PPI=1) from the transient buffer RAM1, 2, or if that frame has no message buffer.

## 2.7.13 Interrupt

---

**This section explains the interrupt operations.**

---

### ■ Interrupt

An interrupt pin is provided for generating interrupts in the event that an error occurs, a status change is detected, a frame is transmitted or received, or a timer event occurs. This enables an immediate measure to be taken against errors, status changes and timer events. However, the application may not achieve the required performance if too many interrupts are generated. Therefore, the FlexRay controller supports a function to configure each interrupt enabled or disabled.

An interrupt occurs in the following cases.

- An error has been detected.
- A status flag has been set.
- The timer has reached the configured value.
- A message transfer from the input buffer to the message buffer, or the message RAM to the output buffer has completed.
- A stop watch event has occurred.

The event display and interrupt generation for status changes or errors operate as two independent tasks. Each event is displayed regardless whether the interrupt is enabled or not. Current error information and status information can be obtained by reading the EIR register and SIR register.

**Table 2.7-11 Module Interrupt Flag and Interrupt Line Enable Flag Table (1 / 2)**

Register	Bit	Function
EIR	PEMC	Protocol Error Mode Changed
	CNA	Command Not Valid
	SFBM	Sync Frames Below Minimum
	SFO	Sync Frame Overflow
	CCF	Clock Correction Failure
	CCL	CHI Command Locked
	PERR	Parity Error
	RFO	Receive FIFO Overflow
	EFA	Empty FIFO Access
	IIBA	Illegal Input Buffer Access
	IOBA	Illegal Output Buffer Access
	MHF	Message Handler Constraints Flag
	EDA	Error Detected on ch.A
	LTVA	Latest Transmit Violation ch.A
	TABA	Transmission Across Boundary ch.A
	EDB	Error Detected on ch.B
	LTVB	Latest Transmit Violation ch.B
	TABB	Transmission Across Boundary ch.B
SIR	WST	Wakeup Status
	CAS	Collision Avoidance Symbol
	CYCS	Cycle Start Interrupt
	TXI	Transmit Interrupt
	RXI	Receive Interrupt
	RFNE	Receive FIFO not Empty
	RFF	Receive FIFO Full
	NMVC	Network Management Vector Changed
	TI0	Timer Interrupt 0
	TI1	Timer Interrupt 1
	TIBC	Transfer Input Buffer Completed
	TOBC	Transfer Output Buffer Completed
	SWE	Stop Watch Event
	SUCS	Startup Completed Successfully
	MBSI	Message Buffer Status Interrupt
	SDS	Start of Dynamic Segment
	WUPA	Wakeup Pattern ch.A
	NTSA	MTS Received on ch.A
WUPB	Wakeup Pattern ch.B	
NTSB	MTS Received on ch.B	

**Table 2.7-11 Module Interrupt Flag and Interrupt Line Enable Flag Table (2 / 2)**

Register	Bit	Function
ILE	EINT0	Enable Interrupt Line 0
	EINT1	Enable Interrupt Line 1

The interrupt pin INT0, INT1 are controlled by a valid interrupt. Also, two interrupt pins INT0 and INT1 can be enabled or disabled separately by configuring ILE:EINT0 and ILE:EINT1.

The two timer interrupts generated by the interrupt timer 0 and timer 1 can be used by the pin INT2 in 16-bit non-multiplex bus mode and pins INT2 and INT3 in 16-bit multiplex bus mode. These can be configured via the T0C register and T1C register.

The stop watch event is generated by the input pin STPW.

The SIR:TIBC and TOBC bits are set to "1" when the data transfer between IBF/OBF and the message RAM is complete.

# ***APPENDIX***

---

**These appendices explain the I/O registers and configuration parameters.**

APPENDIX A I/O Registers

APPENDIX B Configuration Parameters

# APPENDIX A I/O Registers

This section shows the I/O registers of the MB88121B.

## ■ I/O Registers

Table A-1 I/O Registers (1 / 19)

<b>LCK</b> 001C <sub>H</sub>	<b>Lock Register</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W									CLK7	CLK6	CLK5	CLK4	CLK3	CLK2	CLK1	CLK0
<b>EIR</b> 0020 <sub>H</sub>	<b>Error Interrupt Register</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	TABB	LTVB	EDB	0	0	0	0	0	TAB A	LTVA	EDA
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	0	0	0	0	MHF	IOBA	IIBA	EFA	RFO	PERR	CCL	CCF	SFO	SFBM	CNA	PEM C
W																
<b>SIR</b> 0024 <sub>H</sub>	<b>Status Interrupt Register</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	MTS B	WUP B	0	0	0	0	0	0	MTS A	WUP A
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	SDS	MBSI	SUCS	SWE	TOBC	TIBC	TI1	TI0	NMV C	RFCL	RFNE	RXI	TXI	CYCS	CAS	WST
W																
<b>EILS</b> 0028 <sub>H</sub>	<b>Error Interrupt Line Select</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	TABB L	LTVB L	EDBL	0	0	0	0	0	TAB AL	LTVA L	EDAL
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	0	0	0	0	MHF L	IOBA L	IIBAL	EFAL	RFOL	PERR L	CCLL	CCFL	SFOL	SFBM L	CNA L	PEM CL
W																

Table A-1 I/O Registers (2 / 19)

<b>SILS</b> 0028 <sub>H</sub>	<b>Status Interrupt Line Select</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	MTS BL	WUP BL	0	0	0	0	0	0	MTS AL	WUP AL
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	SDSL	MBSI L	SUCS L	SWE L	TOBC L	TIBC L	TIIL	TIOL	NMV CL	RFCL L	RFNE L	RXIL	TXIL	CYCS L	CASL	WST L
W																
<b>EIES</b> <b>EIER</b> 0030 <sub>H</sub> 0034 <sub>H</sub>	<b>Error Interrupt Enable Set Error Interrupt Enable Reset</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	TABB E	LTVB E	EDBE	0	0	0	0	0	TABAE	LTVA E	EDAE
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	0	0	0	0	MHF E	IOBA E	IIBAE	EFAE	RFOE	PERR E	CCLE	CCFE	SFOE	SFBM E	CNA E	PEM CE
W																
<b>SIES</b> <b>SIER</b> 0038 <sub>H</sub> 003C <sub>H</sub>	<b>Status Interrupt Enable Set Status Interrupt Enable Reset</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	MTS BE	WUP BE	0	0	0	0	0	0	MTS AE	WUP AE
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	SDSE	MBSI E	SUCS E	SWE E	TOBC E	TIBC E	TIIE	TIIE	NMV CE	RFCL E	RFNE E	RXIE	TXIE	CYCS E	CASE	WST E
W																
<b>ILE</b> 0040 <sub>H</sub>	<b>Interrupt Line Enable</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	0	0	0	0	0	0	0	0	0	0	0	0	0	0	EINT 1	EINT 0
W																

**Table A-1 I/O Registers (3 / 19)**

<b>T0C</b> 0044 <sub>H</sub>		<b>Timer 0 Configuration</b>															
R		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	W	0	0	TOM O13	TOM O12	TOM O11	TOM O10	TOM O9	TOM O8	TOM O7	TOM O6	TOM O5	TOM O4	TOM O3	TOM O2	TOM O1	TOM O0
R		15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	W	0	T0CC 6	T0CC 5	T0CC 4	T0CC 3	T0CC 2	T0CC 1	T0CC 0	0	0	0	0	0	0	TOMS	TORC
<b>T1C</b> 0048 <sub>H</sub>		<b>Timer 1 Configuration</b>															
R		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	W	0	0	T1M O13	T1M O12	T1M O11	T1M O10	T1M O9	T1M O8	T1M O7	T1M O6	T1M O5	T1M O4	T1M O3	T1M O2	T1M O1	T1M O0
R		15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	W	0	0	0	0	0	0	0	0	0	0	0	0	0	0	T1MS	T1RC
<b>STPW1</b> 004C <sub>H</sub>		<b>Stop Watch Register 1</b>															
R		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	W	0	0	SMT V13	SMT V12	SMT V11	SMT V10	SMT V9	SMT V8	SMT V7	SMT V6	SMT V5	SMT V4	SMT V3	SMT V2	SMT V1	SMT V0
R		15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	W	0	0	SCCV 5	SCCV 4	SCCV 3	SCCV 2	SCCV 1	SCCV 0	0	EINT 1	EINT 0	EETP	SSWT	EDGE	SWS	ESWT
<b>STPW2</b> 0050 <sub>H</sub>		<b>Stop Watch Register 2</b>															
R		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	W	0	0	0	0	0	SSCV B10	SSCV B9	SSCV B8	SSCV B7	SSCV B6	SSCV B5	SSCV B4	SSCV B3	SSCV B2	SSCV B1	SSCV B0
R		15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	W	0	0	0	0	0	SSCV A10	SSCV A9	SSCV A8	SSCV A7	SSCV A6	SSCV A5	SSCV A4	SSCV A3	SSCV A2	SSCV A1	SSCV A0

Table A-1 I/O Registers (4 / 19)

<b>SUCC1</b> 0080 <sub>H</sub>	<b>SUC Configuration Register 1</b>															
R W	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	CCH B*	CCH A*	MTS B*	MTS A*	HCSE *	TSM*	WUC S*	PTA4 *	PTA3 *	PTA2 *	PTA1 *	PTA0 *
R W	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	CSA4 *	CSA3 *	CSA2 *	CSA1 *	CSA0 *	0	TXSY *	TXST *	PBSY *	0	0	0	CMD 3	CMD 2	CMD 1	CMD 0
<b>SUCC2</b> 0084 <sub>H</sub>	<b>SUC Configuration Register 2</b>															
R W	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	LTN3 *	LTN2 *	LTN1 *	LTN0 *	0	0	0	LT20 *	LT19 *	LT18 *	LT17 *	LT16 *
R W	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	LT15 *	LT14 *	LT13 *	LT12 *	LT11 *	LT10 *	LT9* *	LT8* *	LT7* *	LT6* *	LT5* *	LT4* *	LT3* *	LT2* *	LT1* *	LT0* *
<b>SUCC3</b> 0088 <sub>H</sub>	<b>SUC Configuration Register 3</b>															
R W	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R W	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	0	0	0	0	0	WCF3 *	WCF2 *	WCF1 *	WCF0 *	WCP3 *	WCP2 *	WCP1 *	WCP0 *
<b>NEMC</b> 008C <sub>H</sub>	<b>NEM Configuration Register</b>															
R W	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R W	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	0	0	0	0	0	0	0	0	0	NML 3*	NML 2*	NML 1*	NML 0*
<b>PRTC1</b> 0090 <sub>H</sub>	<b>PRT Configuration Register 1</b>															
R W	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RWP5 *	RWP4 *	RWP3 *	RWP2 *	RWP1 *	RWP0 *	0	RXW 8*	RXW 7*	RXW 6*	RXW 5*	RXW 4*	RXW 3*	RXW 2*	RXW 1*	RXW 0*
R W	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	BRP1 *	BRP0 *	SPP1* *	SPP0* *	0	CAS M6*	CAS M5*	CAS M4*	CAS M3*	CAS M2*	CAS M1*	CAS M0*	TSST 3*	TSST 2*	TSST 1*	TSST 0*

**Table A-1 I/O Registers (5 / 19)**

<b>PRTC2</b> 0094 <sub>H</sub>	<b>PRT Configuration Register 2</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	TXL5*	TXL4*	TXL3*	TXL2*	TXL1*	TXL0*	TXI7*	TXI6*	TXI5*	TXI4*	TXI3*	TXI2*	TXI1*	TXI0*
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	0	0	RXL5*	RXL4*	RXL3*	RXL2*	RXL1*	RXL0*	0	0	RXI5*	RXI4*	RXI3*	RXI2*	RXI1*	RXI0*
W																
<b>MHDC</b> 0098 <sub>H</sub>	<b>MHD Configuration Register</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	SLT12*	SLT11*	SLT10*	SLT9*	SLT8*	SLT7*	SLT6*	SLT5*	SLT4*	SLT3*	SLY2*	SLT1*	SLT0*
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	0	0	0	0	0	0	0	0	0	SFDL6*	SFDL5*	SFDL4*	SFDL3*	SFDL2*	SFDL1*	SFDL0*
W																
<b>GTUC1</b> 00A0 <sub>H</sub>	<b>GTUC Configuration Register 1</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	UT19*	UT18*	UT17*	UT16*
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	UT15*	UT14*	UT13*	UT12*	UT11*	UT10*	UT9*	UT8*	UT7*	UT6*	UT5*	UT4*	UT3*	UT2*	UT1*	UT0*
W																
<b>GTUC2</b> 00A4 <sub>H</sub>	<b>GTUC Configuration Register 2</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	SNM3*	SNM2*	SNM1*	SNM0*
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	0	0	MPC13*	MPC12*	MPC11*	MPC10*	MPC9*	MPC8*	MPC7*	MPC6*	MPC5*	MPC4*	MPC3*	MPC2*	MPC1*	MPC0*
W																
<b>GTUC3</b> 00A8 <sub>H</sub>	<b>GTUC Configuration Register 3</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	MIOB6*	MIOB5*	MIOB4*	MIOB3*	MIOB2*	MIOB1*	MIOB0*	0	MIOA6*	MIOA5*	MIOA4*	MIOA3*	MIOA2*	MIOA1*	MIOA0*
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	UIOB7*	UIOB6*	UIOB5*	UIOB4*	UIOB3*	UIOB2*	UIOB1*	UIOB0*	UIOA7*	UIOA6*	UIOA5*	UIOA4*	UIOA3*	UIOA2*	UIOA1*	UIOA0*
W																

Table A-1 I/O Registers (6 / 19)

<b>GTUC4</b> 00AC <sub>H</sub>		<b>GTUC Configuration Register 4</b>															
R		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	W	0	0	OCS 13*	OCS 12*	OCS 11*	OCS 10*	OCS9 *	OCS8 *	OCS7 *	OCS6 *	OCS5 *	OCS4 *	OCS3 *	OCS2 *	OCS1 *	OCS0 *
R		15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	W	0	0	NIT 13*	NIT 12*	NIT 11*	NIT 10*	NIT9 *	NIT8 *	NIT7 *	NIT6 *	NIT5 *	NIT4 *	NIT3 *	NIT2 *	NIT1 *	NIT0 *
<b>GTUC5</b> 00B0 <sub>H</sub>		<b>GTUC Configuration Register 5</b>															
R		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	W	DEC7 *	DEC6 *	DEC5 *	DEC4 *	DEC3 *	DEC2 *	DEC1 *	DEC0 *	0	0	0	CDD4 *	CDD3 *	CDD2 *	CDD1 *	CDD0 *
R		15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	W	DCB7 *	DCB6 *	DCB5 *	DCB4 *	DCB3 *	DCB2 *	DCB1 *	DCB0 *	DCA7 *	DCA6 *	DCA5 *	DCA4 *	DCA3 *	DCA2 *	DCA1 *	DCA0 *
<b>GTUC6</b> 00B4 <sub>H</sub>		<b>GTUC Configuration Register 6</b>															
R		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	W	0	0	0	0	0	MOD 10*	MOD 9*	MOD 8*	MOD 7*	MOD 6*	MOD 5*	MOD 4*	MOD 3*	MOD 2*	MOD 1*	MOD 0*
R		15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	W	0	0	0	0	0	ASR 10*	ASR9 *	ASR8 *	ASR7 *	ASR6 *	ASR5 *	ASR4 *	ASR3 *	ASR2 *	ASR1 *	ASR0 *
<b>GTUC7</b> 00B8 <sub>H</sub>		<b>GTUC Configuration Register 7</b>															
R		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	W	0	0	0	0	0	0	NSS9 *	NSS8 *	NSS7 *	NSS6 *	NSS5 *	NSS4 *	NSS3 *	NSS2 *	NSS1 *	NSS0 *
R		15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	W	0	0	0	0	0	0	SSL9 *	SSL8 *	SSL7 *	SSL6 *	SSL5 *	SSL4 *	SSL3 *	SSL2 *	SSL1 *	SSL0 *
<b>GTUC8</b> 00BC <sub>H</sub>		<b>GTUC Configuration Register 8</b>															
R		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	W	0	0	0	NMS 12*	NMS 11*	NMS 10*	NMS9 *	NMS8 *	NMS7 *	NMS6 *	NMS5 *	NMS4 *	NMS3 *	NMS2 *	NMS1 *	NMS0 *
R		15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	W	0	0	0	0	0	0	0	0	0	0	MSL5 *	MSL4 *	MSL3 *	MSL2 *	MSL1 *	MSL0 *

**Table A-1 I/O Registers (7 / 19)**

<b>GTUC9</b> 00C0 <sub>H</sub>	<b>GTUC Configuration Register 9</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	DSI1*	DSI0*
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	0	0	0	MAP O4*	MAP O3*	MAP O2*	MAP O1*	MAP O0*	0	0	APO5*	APO4*	APO3*	APO2*	APO1*	APO0*
W																
<b>GTUC10</b> 00C4 <sub>H</sub>	<b>GTUC Configuration Register 10</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	MRC 10*	MRC 9*	MRC 8*	MRC 7*	MRC 6*	MRC 5*	MRC 4*	MRC 3*	MRC 2*	MRC 1*	MRC 0*
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	MOC 13*	MOC 12*	MOC 11*	MOC 10*	MOC 9*	MOC 8*	MOC 7*	MOC 6*	MOC 5*	MOC 4*	MOC 3*	MOC 2*	MOC 1*	MOC 0*
W																
<b>GTUC11</b> 00C8 <sub>H</sub>	<b>GTUC Configuration Register 11</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	ERC2*	ERC1*	ERC0*	0	0	0	0	0	0	EOC2*	EOC1*
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	0	0	0	ERCC 1*	ERCC 0*	0	0	0	0	0	0	EOCC 1*	EOCC 0*
W																
<b>CCSV</b> 0100 <sub>H</sub>	<b>CC Status Vector</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	PSL5	PSL4	PSL3	PSL2	PSL1	PSL0	RCA4	RCA3	RCA2	RCA1	RCA0	WSV 2	WSV 1	WSV 0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	CSI	CSAI	CSNI	0	0	SLM1	SLM0	HRQ	FSI	POCS 5	POCS 4	POCS 3	POCS 2	POCS 1	POCS 0
W																

**Table A-1 I/O Registers (8 / 19)**

<b>CCEV</b> 0104 <sub>H</sub>	<b>CC Error Vector</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	PTAC 4	PTAC 3	PTAC 2	PTAC 1	PTAC 0	ERR M1	ERR M0	0	0	CCFC 3	CCFC 2	CCFC 1	CCFC 0
W																
<b>SCV</b> 0110 <sub>H</sub>	<b>Slot Counter Value</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	SCCB 10	SCCB 9	SCCB 8	SCCB 7	SCCB 6	SCCB 5	SCCB 4	SCCB 3	SCCB 2	SCCB 1	SCCB 0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	0	0	SCCA 10	SCCA 9	SCCA 8	SCCA 7	SCCA 6	SCCA 5	SCCA 4	SCCA 3	SCCA 2	SCCA 1	SCCA 0
W																
<b>MTCCV</b> 0114 <sub>H</sub>	<b>Macrotick and Cycle Counter Value</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	CCV5	CCV4	CCV3	CCV2	CCV1	CCV0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	MTV 13	MTV 12	MTV 11	MTV 10	MTV 9	MTV 8	MTV 7	MTV 6	MTV 5	MTV 4	MTV 3	MTV 2	MTV 1	MTV 0
W																
<b>RCV</b> 0118 <sub>H</sub>	<b>Rate Correction Value</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	0	RCV 11	RCV 10	RCV9	RCV8	RCV7	RCV6	RCV5	RCV4	RCV3	RCV2	RCV1	RCV0
W																

**Table A-1 I/O Registers (9 / 19)**

<b>OCV</b> 011C <sub>H</sub>	<b>Offset Correction Value</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	OCV 18	OCV 17	OCV 16
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	OCV 15	OCV 14	OCV 13	OCV 12	OCV 11	OCV 10	OCV9	OCV8	OCV7	OCV6	OCV5	OCV4	OCV3	OCV2	OCV1	OCV0
W																
<b>SFS</b> 0120 <sub>H</sub>	<b>Synch Frame Status</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	RCLR	MRC S	OCLR
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	VSBO 3	VSBO 2	VSBO 1	VSBO 0	VSBE 3	VSBE 2	VSBE 1	BSVE 0	VSA O3	VSA O2	VSA O1	VSA O0	VSAE 3	VSAE 2	VSAE 1	VSAE 0
W																
<b>SWNIT</b> 0124 <sub>H</sub>	<b>Symbol Window and NIT Status</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	0	SBN B	SEN B	SBNA	SENA	MTS B	MTS A	TCSB	SBSB	SESB	TCSA	SBSA	SESA
W																
<b>ACS</b> 0128 <sub>H</sub>	<b>Aggregated Channel Status</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	SBVB	CIB	CEDB	SEDB	VFRB	0	0	0	SBVA	CIA	CED A	SEDA	VFRA
W																

**Table A-1 I/O Registers (10 / 19)**

<b>ESIDn</b> 0130 <sub>H</sub> to 0168 <sub>H</sub>	<b>ESIDn Even Synch ID [1...15]</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	RXEB	RXE A	0	0	0	0	EID9	EID8	EID7	EID6	EID5	EID4	EID3	EID2	EID1	EID0
W																
<b>OSIDn</b> 0170 <sub>H</sub> to 01A8 <sub>H</sub>	<b>OSIDn Odd Synch ID [1...15]</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	RXO B	RXO A	0	0	0	0	OID9	OID8	OID7	OID6	OID5	OID4	OID3	OID2	OID1	OID0
W																
<b>NMVn</b> 01B0 <sub>H</sub> to 01B8 <sub>H</sub>	<b>Network Management Vector [1...15]</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	NM31	NM30	NM29	NM28	NM27	NM26	NM25	NM24	NM23	NM 22	NM21	NM 20	NM19	NM18	NM 17	NM 16
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	NM 15	NM 14	NM 13	NM 12	NM 11	NM 10	NM9	NM8	NM7	NM6	NM5	NM4	NM3	NM2	NM1	NM0
W																
<b>MRC</b> 0300 <sub>H</sub>	<b>MRC Message RAM Configuration</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	SPLM *	SEC1 *	SEC0 *	LCB7 *	LCB6 *	LCB5 *	LCB4 *	LCB3 *	LCB2 *	LCB1 *	LCB0 *
W																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	FFB7 *	FFB6 *	FFB5 *	FFB4 *	FFB3 *	FFB2 *	FFB1 *	FFB0 *	FDB7 *	FDB6 *	FDB5 *	FDB4 *	FDB3 *	FDB2 *	FDB1 *	FDB0 *
W																

**Table A-1 I/O Registers (11 / 19)**

<b>FRF</b> 0304 <sub>H</sub>	<b>FIFO Rejection Filter</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	RNF*	RSS*	CYF6*	CYF5*	CYF4*	CYF3*	CYF2*	CYF1*	CYF0*
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	FID10*	FID9*	FID8*	FID7*	FID6*	FID5*	FID4*	FID3*	FID2*	FID1*	FID0*	CH1*	CH0*
W																
<b>FRFM</b> 0308 <sub>H</sub>	<b>FIFO Rejection Filter Mask</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	MFID10*	MFID9*	MFID8*	MFID7*	MFID6*	MFID5*	MFID4*	MFID3*	MFID2*	MFID1*	MFID0*	0	0
W																
<b>FCL</b> 030C <sub>H</sub>	<b>FIFO Critical Level</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	0	0	0	0	0	CL7*	CL6*	CL5*	CL4*	CL3*	CL2*	CL1*	CL0*
W																
<b>MHDS</b> 0310 <sub>H</sub>	<b>Message Handler Status</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	MBU6	MBU5	MBU4	MBU3	MBU2	MBU1	MBU0	0	MBT6	MBT5	MBT4	MBT3	MBT2	MBT1	MBT0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	FMB6	FMB5	FMB4	FMB3	FMB2	FMB1	FMB0	CRA M	MFM B	FMB D	PTBF 2	PTBF 1	PMR	POBF	PIBF
W																

**Table A-1 I/O Registers (12 / 19)**

<b>LDTS</b> 0314 <sub>H</sub>	<b>Last Dynamic Transmit Slot</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	LDTB 10	LDTB 9	LDTB 8	LDTB 7	LDTB 6	LDTB 5	LDTB 4	LDTB 3	LDTB 2	LDTB 1	LDTB 0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	0	0	LDTA 10	LDTA 9	LDTA 8	LDTA 7	LDTA 6	LDTA 5	LDTA 4	LDTA 3	LDTA 2	LDTA 1	LDTA 0
W																
<b>FSR</b> 0318 <sub>H</sub>	<b>FIFO Status Register</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RFFL 7	RFFL 6	RFFL 5	RFFL 4	RFFL 3	RFFL 2	RFFL 1	RFFL 0	0	0	0	0	0	RFO	RFCL	RFNE
W																
<b>MHDF</b> 031C <sub>H</sub>	<b>Message Handler Constraints Flags</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	0	0	0	0	WAH P	0	0	TBFB	TBFA	FNFB	FNFA	SNUB	SNU A
W																
<b>TXRQ1</b> 0320 <sub>H</sub>	<b>Transmission Request 1</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TXR 31	TXR 30	TXR 29	TXR 28	TXR 27	TXR 26	TXR 25	TXR 24	TXR 23	TXR 22	TXR 21	TXR 20	TXR 19	TXR 18	TXR 17	TXR 16
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TXR 15	TXR 14	TXR 13	TXR 12	TXR 11	TXR 10	TXR9	TXR8	TXR7	TXR6	TXR5	TXR4	TXR3	TXR2	TXR1	TXR0
W																

**Table A-1 I/O Registers (13 / 19)**

<b>TXRQ2</b> 0324 <sub>H</sub>	<b>Transmission Request 2</b>															
R W	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TXR 63	TXR 62	TXR 61	TXR 60	TXR 59	TXR 58	TXR 57	TXR 56	TXR 55	TXR 54	TXR 53	TXR 52	TXR 51	TXR 50	TXR 49	TXR 48
R W	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TXR 47	TXR 46	TXR 45	TXR 44	TXR 43	TXR 42	TXR 41	TXR 40	TXR 39	TXR 38	TXR 37	TXR 36	TXR 35	TXR 34	TXR 33	TXR 32
<b>TXRQ3</b> 0328 <sub>H</sub>	<b>Transmission Request 3</b>															
R W	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TXR 95	TXR 94	TXR 93	TXR 92	TXR 91	TXR 90	TXR 89	TXR 88	TXR 87	TXR 86	TXR 85	TXR 84	TXR 83	TXR 82	TXR 81	TXR 80
R W	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TXR 79	TXR 78	TXR 77	TXR 76	TXR 75	TXR 74	TXR 73	TXR 72	TXR 71	TXR 70	TXR 69	TXR 68	TXR 67	TXR 66	TXR 65	TXR 64
<b>TXRQ4</b> 032C <sub>H</sub>	<b>Transmission Request 4</b>															
R W	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TXR 127	TXR 126	TXR 125	TXR 124	TXR 123	TXR 122	TXR 121	TXR 120	TXR 119	TXR 118	TXR 117	TXR 116	TXR 115	TXR 114	TXR 113	TXR 112
R W	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TXR 111	TXR 110	TXR 109	TXR 108	TXR 107	TXR 106	TXR 105	TXR 104	TXR 103	TXR 102	TXR 101	TXR 100	TXR 99	TXR 98	TXR 97	TXR 96
<b>NDAT1</b> 0330 <sub>H</sub>	<b>New Data 1</b>															
R W	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	ND31	ND30	ND29	ND28	ND27	ND26	ND25	ND24	ND23	ND22	ND21	ND20	ND19	ND18	ND17	ND16
R W	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	ND15	ND14	ND13	ND12	ND11	ND10	ND9	ND8	ND7	ND6	ND5	ND4	ND3	ND2	ND1	ND0

**Table A-1 I/O Registers (14 / 19)**

<b>NDAT2</b> 0334 <sub>H</sub>	<b>New Data 2</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	ND63	ND62	ND61	ND60	ND59	ND58	ND57	ND56	ND55	ND54	ND53	ND52	ND51	ND50	ND49	ND48
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	ND47	ND46	ND45	ND44	ND43	ND42	ND41	ND40	ND39	ND38	ND37	ND36	ND35	ND34	ND33	ND32
W																
<b>NDAT3</b> 0338 <sub>H</sub>	<b>New Data 3</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	ND95	ND94	ND93	ND92	ND91	ND90	ND89	ND88	ND87	ND86	ND85	ND84	ND83	ND82	ND81	ND80
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	ND79	ND78	ND77	ND76	ND75	ND74	ND73	ND72	ND71	ND70	ND69	ND68	ND67	ND66	ND65	ND64
W																
<b>NDAT4</b> 033C <sub>H</sub>	<b>New Data 4</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	ND127	ND126	ND125	ND124	ND123	ND122	ND121	ND120	ND119	ND118	ND117	ND116	ND115	ND114	ND113	ND112
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	ND111	ND110	ND109	ND108	ND107	ND106	ND105	ND104	ND103	ND102	ND101	ND100	ND99	ND98	ND97	ND96
W																
<b>MBSC1</b> 0340 <sub>H</sub>	<b>Message Buffer Status Changed 1</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	MBC31	MBC30	MBC29	MBC28	MBC27	MBC26	MBC25	MBC24	MBC23	MBC22	MBC21	MBC20	MBC19	MBC18	MBC17	MBC16
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	MBC15	MBC14	MBC13	MBC12	MBC11	MBC10	MBC9	MBC8	MBC7	MBC6	MBC5	MBC4	MBC3	MBC2	MBC1	MBC0
W																

**Table A-1 I/O Registers (15 / 19)**

<b>MBSC2</b> 0344 <sub>H</sub>		<b>Message Buffer Status Changed 2</b>															
R		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC
W		63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48
R		15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC
W		47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32
<b>MBSC3</b> 0348 <sub>H</sub>		<b>Message Buffer Status Changed 3</b>															
R		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC
W		95	94	93	92	91	90	89	88	87	86	85	84	83	82	81	80
R		15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC
W		79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64
<b>MBSC4</b> 034C <sub>H</sub>		<b>Message Buffer Status Changed 4</b>															
R		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC
W		127	126	125	124	123	122	121	120	119	118	117	116	115	114	113	112
R		15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC	MBC
W		111	110	109	108	107	106	105	104	103	102	101	100	99	98	97	96
<b>CREL</b> 03F0 <sub>H</sub>		<b>Core Release Register</b>															
R		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	REL3	REL2	REL1	REL0	STEP7	STEP6	STEP5	STEP4	STEP3	STEP2	STEP1	STEP0	YEA R3	YEA R2	YEA R1	YEA R0	
W																	
R		15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	MON7	MON6	MON5	MON4	MON3	MON2	MON1	MON0	DAY7	DAY6	DAY5	DAY4	DAY3	DAY2	DAY1	DAY0	
W																	

**Table A-1 I/O Registers (16 / 19)**

<b>ENDN</b> 03F4 <sub>H</sub>	<b>Endian Register</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	ETV 31	ETV 30	ETV 29	ETV 28	ETV 27	ETV 26	ETV 25	ETV 24	ETV 23	ETV 22	ETV 21	ETV 20	ETV 19	ETV 18	ETV 17	ETV 16
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	ETV 15	ETV 14	ETV 13	ETV 12	ETV 11	ETV 10	ETV9	ETV8	ETV7	ETV6	ETV5	ETV4	ETV3	ETV2	ETV1	ETV0
W																
<b>WRDSn</b> 0400 <sub>H</sub> to 04FC <sub>H</sub>	<b>Write Data Section [1...64]</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	MD31	MD30	MD29	MD28	MD27	MD26	MD25	MD24	MD23	MD22	MD21	MD20	MD19	MD18	MD17	MD16
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	MD15	MD14	MD13	MD12	MD11	MD10	MD9	MD8	MD7	MD6	MD5	MD4	MD3	MD2	MD1	MD0
W																
<b>WRHS1</b> 0500 <sub>H</sub>	<b>Write Header Section 1</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	MBI	TXM	PPIT	CFG	CHB	CHA	0	CYC6	CYC5	CYC4	CYC3	CYC2	CYC1	CYC0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	0	0	FID10	FID9	FID8	FID7	FID6	FID5	FID4	FID3	FID2	FID1	FID0
W																
<b>WRHS2</b> 0504 <sub>H</sub>	<b>Write Header Section 2</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	PLC6	PLC5	PLC4	PLC3	PLC2	PLC1	PLC0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	0	0	CRC 10	CRC9	CRC8	CRC7	CRC6	CRC5	CRC4	CRC3	CRC2	CRC1	CRC0
W																

**Table A-1 I/O Registers (17 / 19)**

<b>WRHS3</b> 0508 <sub>H</sub>	<b>Write Header Section 3</b>																
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
W																	
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
R	0	0	0	0	0	DP10*	DP9*	DP8*	DP7*	DP6*	DP5*	DP4*	DP3*	DP2*	DP1*	DP0*	
W																	
<b>IBCM</b> 0510 <sub>H</sub>	<b>Input Buffer Command Mask</b>																
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
	0	0	0	0	0	0	0	0	0	0	0	0	0	STXRS	LDSS	LHSS	
W																	
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
R	0	0	0	0	0	0	0	0	0	0	0	0	0	STXRH	LDSH	LHSH	
W																	
<b>IBCR</b> 0514 <sub>H</sub>	<b>Input Buffer Command Request</b>																
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
	IBSYS	0	0	0	0	0	0	0	0	0	IBRS6	IBRS5	IBRS4	IBRS3	IBRS2	IBRS1	IBRS0
W																	
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
R	IBSYH	0	0	0	0	0	0	0	0	IBRH6	IBRH5	IBRH4	IBRH3	IBRH2	IBRH1	IBRH0	
W																	
<b>RDDSn</b> 0600 <sub>H</sub> to 06FC <sub>H</sub>	<b>Read Data Section [1...64]</b>																
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
	MD31	MD30	MD29	MD28	MD27	MD26	MD25	MD24	MD23	MD22	MD21	MD20	MD19	MD18	MD17	MD16	
W																	
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
R	MD15	MD14	MD13	MD12	MD11	MD10	MD9	MD8	MD7	MD6	MD5	MD4	MD3	MD2	MD1	MD0	
W																	

**Table A-1 I/O Registers (18 / 19)**

<b>RDHS1</b> 0700 <sub>H</sub>	<b>Read Header Section 1</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	MBI	TXM	PPIT	CFG	CHB	CHA	0	CYC6	CYC5	CYC4	CYC3	CYC2	CYC1	CYC0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	0	0	FID10	FID9	FID8	FID7	FID6	FID5	FID4	FID3	FID2	FID1	FID0
W																
<b>RDHS2</b> 0704 <sub>H</sub>	<b>Read Header Section 2</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	PLR6	PLR5	PLR4	PLR3	PLR2	PLR1	PLR0	0	PLC6	PLC5	PLC4	PLC3	PLC2	PLC1	PLC0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	0	0	CRC10	CRC9	CRC8	CRC7	CRC6	CRC5	CRC4	CRC3	CRC2	CRC1	CRC0
W																
<b>RDHS3</b> 0708 <sub>H</sub>	<b>Read Header Section 3</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	RES	PPI	NFI	SYN	SFI	RCI	0	0	RCC5	RCC4	RCC3	RCC2	RCC1	RCC0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	0	0	DP10	DP9	DP8	DP7	DP6	DP5	DP4	DP3	DP2	DP1	DP0
W																
<b>MBS</b> 070C <sub>H</sub>	<b>Message Buffer Status</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	RESS	PPIS	NFIS	SYNS	SFIS	RCIS	0	0	CCS5	CCS4	CCS3	CCS2	CCS1	CCS0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	FTB	FTA	0	MLST	ESB	ESA	TCIB	TCIA	SVOB	SVOA	CEOB	CEOA	SEOB	SEOA	VFRB	VFRA
W																

**Table A-1 I/O Registers (19 / 19)**

<b>OBCM 0710<sub>H</sub></b>	<b>Output Buffer Command Mask</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	RDSH	RHSH
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	RDSS	RHSS
W																
<b>OBCR 0714<sub>H</sub></b>	<b>Output Buffer Command Request</b>															
R	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	0	0	0	0	0	0	0	0	0	OBR H6	OBR H5	OBR H4	OBR H3	OBR H2	OBR H1	OBR H0
W																
R	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	OBSY S	0	0	0	0	0	REQ	VIEW	0	OBR S6	OBR S5	OBR S4	OBR S3	OBR S2	OBR S1	OBR S0
W																

\* : It can only be written to while in the DEFAULT\_CONFIG or CONFIG states.

## APPENDIX B Configuration Parameters

This section describes the configuration parameters.

### ■ Configuration Parameters

**Table B-1 Allocation of Configuration Parameters to Registers (1 / 4)**

Parameter	Bit (field)	Description	Range
pKeySlotUsedForStartup	SUCC1:TXST	Flag that indicates whether the key slot is used to send a startup frame	Boolean
pKeySlotUsedForSync	SUCC1:TXSY	Flag that indicates whether the key slot is used to send a synchronization frame	Boolean
gColdStartAttempts	SUCC1:CSA4 to CSA0	The maximum number of attempts when a node within a cluster attempts to start schedule synchronization	2 to 31
pAllowPassiveToActive	SUCC1:PTA4 to PTA0	The number of cycle pairs required for clock correction before the CC is permitted to change from normal passive state to active state. If set to "0", the state change is not permitted.	0 to 31 cycle pairs
pWakeupChannel	SUCC1:WUCS	The channel over which the node sends the wake up pattern	[A, B]
pSingleSlotEnabled	SUCC1:TSM	A flag that indicates whether the node will enter single slot mode after startup	Boolean
pAllowHaltDueToClock	SUCC1:HCSE	Controls the transition to halt state if a clock synchronization error occurs. True: Permitted; False: Not permitted, or holds in passive state (able to recover automatically).	Boolean
pChannels	SUCC1:CCHA SUCC1:CCHB	Node connection channels	[A, B, A&B]
pdListenTimeOut	SUCC2:LT20 to LT0	The upper limit on the startup listen timeout and the wakeup listen timeout	1284 to 1283846 $\mu$ T
gListenNoize	SUCC2:LTN3 to LTN0	The upper limit on the startup listen timeout and the wakeup listen timeout when there is noise. This is a multiplier of the pdListenTimeout cluster parameter.	2 to 16

**Table B-1 Allocation of Configuration Parameters to Registers (2 / 4)**

Parameter	Bit (field)	Description	Range
gMaxWithoutClockCorrectionPassive	SUCC3:WCP3 to WCP0	The threshold value of the vClockCorrectionFailed counter test. The number of cycle pairs for clock correction when beginning a transition from normal active state to passive state. Note that $gMaxWithoutClockCorrectionPassive \leq gMaxWithoutClockCorrectionFatal \leq 15$ .	1 to 15 cycle pairs
gMaxWithoutClockCorrectionFatal	SUCC3:WCF3 to WCF0	The threshold value of the vClockCorrectionFailed counter test. The number of cycle pairs for clock correction when beginning a transition from normal active state or passive state to halt state.	gMaxWithoutClockCorrectionPassive to 15
gNetworkManagementVectorLength	NEMC:NML3 to NML0	The length of the cluster network management vector	0 to 12 bytes
gdTSSTransmitter	PRTC1:TSST3 to TSST0	The number of bits in the transmission start sequence	3 to 15 gdBIt
gdCASRxLowMax	PRTC1:CASM6 to CASM0	The upper limit on the CAS receive window	67 to 99 gdBIt
gdSampleClockPeriod	PRTC1:BRP1, BRP0	The period of the sample clock	12.5ns, 25.0ns, 50.0ns
pSamplesPerMicrotick	PRTC1:BRP1, BRP0	The number of samples per microtick	[1, 2, 4]
gdWakeupSymbolRxWindow	PRTC1:RXW8 to RXW0	The number of bits for testing the symbol length of received wakeup symbols. $=30\mu s + \alpha$	76 to 301 gdBIt
pWakeupPattern	PRTC1:RWP5 to RWP0	The number of repetitions of the wakeup symbol generated by the wakeup pattern when the node enters the wakeup send state.	2 to 63
gdWakeupSymbolRxIdle	PRTC2:RXI5 to RXI0	The number of bits for testing the idle length of received wakeup symbols. $=6\mu s - \alpha$	14 to 59 gdBIt
gdWakeupSymbolRxLow	PRTC2:RXL5 to RXL0	The number of bits for testing the low length of received wakeup symbols. $=6\mu s - \alpha$	10 to 55 gdBIt
gdWakeupSymbolTxIdle	PRTC2:TXI7 to TXI0	The number of bits to send in the idle portion of the wakeup symbol. $=6\mu s$	45 to 180 gdBIt
gdWakeupSymbolTxLow	PRTC2:TXL5 to TXL0	The number of bits to send in the "L" portion of the wakeup symbol. $=6\mu s$	15 to 60 gdBIt
gPayloadLengthStatic	MHDC:SFDL6 to SFDL0	The payload length of static frames	0 to cPayloadLengthMax two-byte words
pLatestTx	MHDC:SLT12 to SLT0	The final minislot number within a dynamic segment at which frame transmission can be started	Minislot 0 to 7981

**Table B-1 Allocation of Configuration Parameters to Registers (3 / 4)**

Parameter	Bit (field)	Description	Range
pMicroPerCycle	GTUC1:UT19 to UT0	The number of microticks in the local node communication cycle.	640 to 640000 $\mu$ T
gMacroPerCycle	GTUC2:MPC13 to MPC0	The number of macroticks in the communication cycle	10 to 16000 MT
gSyncNodeMax	GTUC2:SNM3 to SNM0	The number of nodes that can send frames that have the sync frame bit set	2 to cSyncNodeMax
pMicroInitialOffset[A]	GTUC3:UOIA7 to UOIA0	The number of microticks in each of the macrotick boundaries defined by the gMacroInitialOffset and the secondary reference point. Configured separately for each channel.	0 to 240 $\mu$ T
pMicroInitialOffset[B]	GTUC3:UOIB7 to UOIB0	do.	0 to 240 $\mu$ T
pMacroInitialOffset[A]	GTUC3:MIOA6 to MIOA0	The number of macroticks between the static slot boundary and the next macrotick boundary.	2 to 72 MT
pMacroInitialOffset[B]	GTUC3:MIOB6 to MIOB0	do.	2 to 72 MT
gdNIT	GTUC4:NIT13 to NIT0	The length of the network idle time	2 to 767 MT
gOffsetCorrectionStart	GTUC4:OCS13 to OCS0	The starting point of the internal NIT offset correction phase. This is the number of microticks from the starting point of the cycle.	9 to 15999 MT
pDelayCompensation[A]	GTUC5:DCA7 to DCA0	The receive delay compensation value for ch.A. The microticks from 0.0125 $\mu$ s to 0.05 $\mu$ s correspond to the propagation delay up to cPropagationDelayMax.	0 to 200 $\mu$ T
pDelayCompensation[B]	GTUC5:DCB7 to DCB0	The receive delay compensation value for ch.B. The microticks from 0.0125 $\mu$ s to 0.05 $\mu$ s correspond to the propagation delay up to cPropagationDelayMax.	0 to 200 $\mu$ T
pClusterDriftDamping	GTUC5:CDD4 to CDD0	The local cluster drift damping factor used for rate correction	0 to 20 $\mu$ T
pDecodingCorrection	GTUC5:DEC7 to DEC0	The number of microticks for calculations between time reference points.	14 to 143 $\mu$ T
pdAcceptedStartupRange	GTUC6:ASR10 to ASR0	The maximum variation in the real-time clock permitted in the startup frame during integration	0 to 1875 $\mu$ T
pdMaxDrift	GTUC6:MOD10 to MOD0	The maximum drift offset between two nodes that are operating on unsynchronized clocks in a single communication cycle	2 to 1923 $\mu$ T
gdStaticSlot	GTUC7:SSL9 to SSL0	Static slot length	4 to 659 MT

**Table B-1 Allocation of Configuration Parameters to Registers (4 / 4)**

Parameter	Bit (field)	Description	Range
gNumberOfStaticSlots	GTUC7:NSS9 to NSS0	The number of static slots in a static segment	2 to cStaticSlotIDMax
gdMinislot	GTUC8:MSL5 to MSL0	Minislot length	2 to 63 MT
gNumberOfMinislots	GTUC8:NMS12 to NMS0	The number of minislots in a dynamic slot	0 to 7986
gdActionPointOffset	GTUC9:APO5 to APO0	The number of action point offsets from the beginning of a static slot or a symbol window	1 to 63 MT
gdMinislotActionPointOffset	GTUC9:MAPO4 to MAPO0	The number of minislot action point offsets from the beginning of a minislot	1 to 31 MT
gdDynamicSlotIdlePhase	GTUC9:DSI1, DSI0	The dynamic slot idle phase length	0 to 2 Minislot
pOffsetCorrectionOut	GTUC10:MOC13 to MOC0	The upper limit of the permissible offset correction	5 to 15266 $\mu$ T
pRateCorrectionOut	GTUC10:MRC10 to MRC0	The upper limit of the permissible offset correction	2 to 1923 $\mu$ T
pExternOfsetCorrecton	GTUC11:EOC2 to EOC0	The number of microticks that the host adds to or subtracts from the NIT for external offset correction	0 to 7 $\mu$ T
pExternRateCorrection	GTUC11:ERC2 to ERC0	The number of microticks that the host adds to or subtracts from the NIT for external rate correction	0 to 7 $\mu$ T

# INDEX

---

**The index follows on the next page.  
This is listed in alphabetic order.**

---

# Index

## Numerics

16-bit Multiplex Parallel Bus  
 16-bit Multiplex Parallel Bus Timing ..... 132

16-bit Non-multiplex Parallel Bus  
 16-bit Non-multiplex Parallel Bus Timing ..... 127

## A

ACS  
 Aggregated Channel Status (ACS)..... 87

Aggregated Channel Status  
 Aggregated Channel Status (ACS)..... 87

Algorithm  
 Data Security Algorithm..... 153

## B

Baud Rate  
 Setting Example of the FlexRay Baud Rate  
 ..... 162

Block Diagram  
 Block Diagram of FlexRay controller ..... 30  
 Block Diagram of the MB88121B ..... 3

Byte Structure  
 Command Byte Structure..... 144

## C

CC  
 Communication Controller (CC) Control Registers  
 ..... 61  
 Communication Controller (CC) Status Registers  
 ..... 78

CC Error Vector Register  
 CC Error Vector Register (CCEV)..... 81

CC Status Vector Register  
 CC Status Vector Register (CCSV)..... 78

CCEV  
 CC Error Vector Register (CCEV)..... 81

CCNT  
 Clock Control Register (CCNT) ..... 37

CCSV  
 CC Status Vector Register (CCSV)..... 78

Channel ID Filtering  
 Channel ID Filtering ..... 190

Clock  
 Clock Correction Failed Counter ..... 170  
 Clock Synchronization ..... 168  
 External Clock Synchronization ..... 169  
 FlexRay Controller Clock ..... 158  
 RAM Clock Configuration..... 161  
 Serial Clock Operations ..... 142  
 Serial Clock Operations Setting..... 142  
 Switching Procedure to the PLL Clock..... 160  
 Switching Procedure to the Reference Clock  
 ..... 160  
 Switching the System Clock Divider Value ..... 161

Clock Control Register  
 Clock Control Register (CCNT) ..... 37

Cold Start Inhibit Mode  
 Cold Start Inhibit Mode ..... 181

Cold Start Node  
 Startup process of following cold start nodes  
 (reacting to the leading cold start node)  
 ..... 183

Startup process of the leading cold start node  
 (starting a cold start)..... 183

Combination of RBC and WBC  
 RBCWBC: Combination of RBC and WBC (78<sub>H</sub>)  
 ..... 149

Combination of RBC and WBI  
 RBCWBI: Combination of RBC and WBI (72<sub>H</sub>)  
 ..... 148

Combination of RBI and WBC  
 RBIWBC: Combination of RBI and WBC (5A<sub>H</sub>)  
 ..... 148

Combination of RBI and WBI  
 RBIWBI: Combination of RBI and WBI (50<sub>H</sub>)  
 ..... 147

Command  
 Command Byte Structure..... 144  
 FREEZE Command ..... 171  
 HALT Command ..... 171  
 WRIBC: Write Input Buffer Command (90<sub>H</sub>)  
 ..... 150  
 WROBC: Write Output Buffer Command (9A<sub>H</sub>)  
 ..... 151

Communication Controller  
 Communication Controller (CC) Control Registers  
 ..... 61  
 Communication Controller (CC) Status Registers  
 ..... 78

Communication Cycle  
 Communication Cycle ..... 164

Communication Mode  
 Communication Mode ..... 167

Communications Controller States  
 Diagram of the Communications Controller States  
 ..... 172

CONFIG State  
 CONFIG State ..... 174

Configuration Parameters  
 Configuration Parameters ..... 239

Continue  
 RBC: Read Output Buffer,Continue (60<sub>H</sub>)..... 147  
 WBC: Write Input Buffer,Continue (18<sub>H</sub>) ..... 146

Core Release Register  
 Core Release Register (CREL) ..... 108

Correction  
 Offset (Phase) Correction..... 169  
 Rate (Frequency) Correction ..... 169

CREL  
 Core Release Register (CREL).....108

Customer Registers  
 Customer Registers .....35

Cycle Counter Filtering  
 Cycle Counter Filtering .....189

**D**

Data Partition  
 Data Partition .....213

Data Security Algorithm  
 Data Security Algorithm..... 153

DBGS  
 Debug Support Register (DBGS) .....40

Debug Support Register  
 Debug Support Register (DBGS) .....40

DEFAULT\_CONFIG State  
 DEFAULT\_CONFIG State ..... 174

Divider Value  
 Switching the System Clock Divider Value  
 ..... 161

DMA Operations  
 DMA Operations .....138

DMA Support Register  
 DMA Support Register (DMAS) .....41

DMAS  
 DMA Support Register (DMAS) .....41

Dynamic Segment  
 Dynamic Segment .....165, 192

**E**

EIER  
 Error Interrupt Enable Set/Reset Registers  
 (EIES,EIER) .....54

EIES  
 Error Interrupt Enable Set/Reset Registers  
 (EIES,EIER) .....54

EILS  
 Error Interrupt Line Select Register (EILS) .....52

EIR  
 Error Interrupt Register (EIR) .....46

Endian Register  
 Endian Register (ENDN).....109

ENDN  
 Endian Register (ENDN).....109

Error Handling  
 Error Handling ..... 170

Error Interrupt Enable Set/Reset Registers  
 Error Interrupt Enable Set/Reset Registers  
 (EIES,EIER) .....54

Error Interrupt Line Select Register  
 Error Interrupt Line Select Register (EILS) .....52

## INDEX

Error Interrupt Register	
Error Interrupt Register (EIR).....	46
ESID	
Even Numbered Cycle Sync Frame ID Register (ESID1 to ESID15) .....	89
Even Numbered Cycle Sync Frame ID Register	
Even Numbered Cycle Sync Frame ID Register (ESID1 to ESID15) .....	89
External Clock	
External Clock Synchronization.....	169
<b>F</b>	
Failed Counter	
Clock Correction Failed Counter.....	170
FCL	
FIFO Critical Level Register (FCL) .....	96
FIFO	
Access to FIFO .....	199
FIFO Configuration.....	198
FIFO Critical Level Register	
FIFO Critical Level Register (FCL) .....	96
FIFO Filtering	
FIFO Filtering.....	190
FIFO Rejection Filter Mask Register	
FIFO Rejection Filter Mask Register (FRFM) .....	95
FIFO Rejection Filter Register	
FIFO Rejection Filter Register (FRF) .....	94
FIFO Status Register	
FIFO Status Register (FSR).....	99
Filtering	
Channel ID Filtering.....	190
Cycle Counter Filtering.....	189
FIFO Filtering.....	190
Filtering and Masking.....	188
Slot Counter Filtering .....	188
FlexRay	
Block Diagram of FlexRay controller.....	30
Configuration of FlexRay.....	33
FlexRay Channel Protocol Controller (PRT A/B) .....	31
FlexRay Controller Clock .....	158
FlexRay Features.....	29
FlexRay Operations .....	127
FlexRay Protocol Function.....	163
Overview of FlexRay.....	28
Setting Example of the FlexRay Baud Rate .....	162
The FlexRay Protocol Controller Access to the Message RAM .....	207
FlexRay Channel Protocol Controller	
FlexRay Channel Protocol Controller (PRT A/B) .....	31
FlexRay Controller	
Block Diagram of FlexRay controller .....	30
FlexRay Controller Clock .....	158
FlexRay Protocol Controller	
The FlexRay Protocol Controller Access to the Message RAM.....	207
Frame	
Frame Reception.....	195
Frame Transmission.....	193
Null Frame Reception .....	196
Null Frame Transmission.....	194
Sync Frame Transmission.....	169
Frame and Symbol Processing	
Frame and Symbol Processing (FSP) .....	32
FREEZE Command	
FREEZE Command .....	171
Frequency	
Rate (Frequency) Correction .....	169
FRF	
FIFO Rejection Filter Register (FRF).....	94
FRFM	
FIFO Rejection Filter Mask Register (FRFM) .....	95
FSP	
Frame and Symbol Processing (FSP) .....	32
FSR	
FIFO Status Register (FSR) .....	99
Functional Description	
Functional Description of Each Block.....	4
<b>G</b>	
Global Time	
Global Time .....	168
Global Time Unit (GTU) .....	31
GTU Configuration Register	
GTU Configuration Register 1 (GTUC1) .....	70
GTU Configuration Register 10 (GTUC10).....	76
GTU Configuration Register 11 (GTUC11).....	77
GTU Configuration Register 2 (GTUC2) .....	71
GTU Configuration Register 3 (GTUC3) .....	71
GTU Configuration Register 4 (GTUC4) .....	72
GTU Configuration Register 5 (GTUC5) .....	73
GTU Configuration Register 6 (GTUC6) .....	74
GTU Configuration Register 7 (GTUC7) .....	74
GTU Configuration Register 8 (GTUC8) .....	75
GTU Configuration Register 9 (GTUC9) .....	75
GTUC	
GTU Configuration Register 1 (GTUC1) .....	70
GTU Configuration Register 10 (GTUC10).....	76
GTU Configuration Register 11 (GTUC11).....	77
GTU Configuration Register 2 (GTUC2) .....	71
GTU Configuration Register 3 (GTUC3) .....	71
GTU Configuration Register 4 (GTUC4) .....	72
GTU Configuration Register 5 (GTUC5) .....	73

GTU Configuration Register 6 (GTUC6).....	74	Input Buffer Command Mask Register	
GTU Configuration Register 7 (GTUC7).....	74	Input Buffer Command Mask Register (IBCM)	
GTU Configuration Register 8 (GTUC8).....	75	.....	114
GTU Configuration Register 9 (GTUC9).....	75	Input Buffer Command Request Register	
		Input Buffer Command Request Register (IBCR)	
		.....	115
<b>H</b>		<b>INT</b>	
HALT Command		Interrupt Control (INT) .....	32
HALT Command .....	171	Interrupt Register (INT) .....	43
HALT State		Interrupt	
HALT State .....	186	Interrupt.....	216
Handling Devices		Interrupt Control (INT) .....	32
Notes on Handling Devices .....	19	Interrupt Control	
Header Partition		Interrupt Control (INT) .....	32
Header Partition .....	210	Interrupt Line Enable Register	
Header Section		Interrupt Line Enable Register (ILE) .....	56
WRHS: Write Input Buffer Header Section 1 to 3		Interrupt Register	
(AA <sub>H</sub> ) .....	152	Interrupt Register (INT) .....	43
Host		<b>L</b>	
Host Access to the Message RAM .....	201	Last Dynamic Transmit Slot Register	
Host Operations .....	178	Last Dynamic Transmit Slot Register (LDTS)	
		.....	99
<b>I</b>		LCK	
I/O Circuit		Lock Register (LCK) .....	45
I/O Circuit Types .....	18	LDTS	
I/O Map		Last Dynamic Transmit Slot Register (LDTS)	
I/O Map .....	21	.....	99
I/O Registers		Local Time	
I/O Registers .....	220	Local Time .....	168
IBCM		Lock Register	
Input Buffer Command Mask Register (IBCM)		Lock Register (LCK) .....	45
.....	114	LSB	
IBCR		LSB/MSB Settings .....	141
Input Buffer Command Request Register (IBCR)		<b>M</b>	
.....	115	Macrotick and Cycle Counter Value Register	
Idle Time		Macrotick and Cycle Counter Value Register	
Network Idle Time (NIT).....	165	(MTCCV) .....	82
ILE		Masking	
Interrupt Line Enable Register (ILE).....	56	Filtering and Masking .....	188
Initialize		MB88121B	
RBI: Read Output Buffer,Initialize (42 <sub>H</sub> ) .....	146	Block Diagram of the MB88121B .....	3
WBI: Write Input Buffer,Initialize (12 <sub>H</sub> ).....	145	MBS	
Input Buffer		Message Buffer Status Register (MBS).....	120
Data Transmission from the Input Buffer to the		MBSC	
Message RAM.....	203	Message Buffer Status Changed Register 1/2/3/4	
Input Buffer.....	110	(MBSC1/MBSC2/MBSC3/MBSC4)	
Input Buffer Data Transfer .....	139	.....	105
WBC: Write Input Buffer,Continue (18 <sub>H</sub> ) .....	146	MDS	
WBI: Write Input Buffer,Initialize (12 <sub>H</sub> ).....	145	MDS1 Pin= "H" ,MDS0 Pin= "H" .....	143
WIP: Write Input Buffer Pointer (82 <sub>H</sub> ).....	149	MDS1 Pin= "H" ,MDS0 Pin= "L" .....	143
WRHS: Write Input Buffer Header Section 1 to 3		MDS1 Pin= "L" ,MDS0 Pin= "H" .....	143
(AA <sub>H</sub> ) .....	152		
WRIBC: Write Input Buffer Command (90 <sub>H</sub> )			
.....	150		

## INDEX

MDS1 Pin= "L" ,MDS0 Pin= "L" .....	142
Message	
Data Transmission from the Input Buffer to the Message RAM .....	203
Data Transmission from the Message RAM to the Output Buffer.....	205
Host Access to the Message RAM .....	201
Message Handling .....	200
Message RAM .....	209
The FlexRay Protocol Controller Access to the Message RAM .....	207
Message Buffer	
Message Buffer Reconfiguration.....	200
Message Buffer Status Changed Register	
Message Buffer Status Changed Register 1/2/3/4 (MBSC1/MBSC2/MBSC3/MBSC4) .....	105
Message Buffer Status Register	
Message Buffer Status Register (MBS) .....	120
Message Handler Constraints Flags	
Message Handler Constraints Flags (MHDF) .....	100
Message Handler Status Register	
Message Handler Status Register (MHDS) .....	97
Message RAM Configuration Register	
Message RAM Configuration Register (MRC) .....	92
MHD Configuration Register	
MHD Configuration Register (MHDC) .....	70
MHDC	
MHD Configuration Register (MHDC) .....	70
MHDF	
Message Handler Constraints Flags (MHDF) .....	100
MHDS	
Message Handler Status Register (MHDS) .....	97
Mode	
Cold Start Inhibit Mode .....	181
Communication Mode .....	167
Operation Mode Settings.....	141
Restoration Procedure from Stop Mode .....	161
Switching Procedure to Stop Mode .....	160
MONITOR_MODE	
MONITOR_MODE.....	175
MRC	
Message RAM Configuration Register (MRC) .....	92
MSB	
LSB/MSB Settings .....	141
MTCCV	
Macrotick and Cycle Counter Value Register (MTCCV).....	82
Multiplex Parallel Bus	
16-bit Multiplex Parallel Bus Timing .....	132
Multiplier	
PLL Multiplier Setting .....	141
<b>N</b>	
NDAT	
New Data Register 1/2/3/4 (NDAT1/NDAT2/NDAT3/NDAT4) .....	103
NEM	
Network Management (NEM).....	32
NEM Configuration Register	
NEM Configuration Register (NEMC).....	67
NEMC	
NEM Configuration Register (NEMC).....	67
Network Idle Time	
Network Idle Time (NIT).....	165
Network Management	
Network Management .....	187
Network Management (NEM).....	32
Network Management Vector (NMV1 to NMV3: [1 to 3]).....	90
New Data Register	
New Data Register 1/2/3/4 (NDAT1/NDAT2/NDAT3/NDAT4) .....	103
NIT	
Network Idle Time (NIT).....	165
Starting NIT and Configuring the Offset Correction Start.....	166
NMV	
Network Management Vector (NMV1 to NMV3: [1 to 3]).....	90
Node	
Startup process of following cold start nodes (reacting to the leading cold start node) .....	183
Startup process of the leading cold start node (starting a cold start).....	183
Noise	
Noise Prevention.....	20
Non-cold Start	
Startup process of non-cold start nodes .....	184
Non-multiplex Parallel Bus	
16-bit Non-multiplex Parallel Bus Timing .....	127
NOP	
NOP: Read Status (00 <sub>H</sub> ) .....	152
NORMAL_ACTIVE State	
NORMAL_ACTIVE State.....	185
NORMAL_PASSIVE State	
NORMAL_PASSIVE State .....	185
Null Frame	
Null Frame Reception .....	196
Null Frame Transmission.....	194

<b>O</b>	
OBCM	
Output Buffer Command Mask Register (OBCM)	124
OBCR	
Output Buffer Command Request Register (OBCR)	125
OCV	
Offset Correction Value Register (OCV)	83
Odd Numbered Cycle Sync Frame ID Register	
Odd Numbered Cycle Sync Frame ID Register (OSID1 to OSID15)	90
Offset	
Offset (Phase) Correction	169
Offset Correction Start	
Starting NIT and Configuring the Offset Correction Start	166
Offset Correction Value Register	
Offset Correction Value Register (OCV)	83
Operation Mode	
Operation Mode Settings	141
OSID	
Odd Numbered Cycle Sync Frame ID Register (OSID1 to OSID15)	90
Output Buffer	
Data Transmission from the Message RAM to the Output Buffer	205
Output Buffer	117
Output Buffer Data Transfer	140
RBC: Read Output Buffer,Continue (60 <sub>H</sub> )	147
RBI: Read Output Buffer,Initialize (42 <sub>H</sub> )	146
WOP: Write Output Buffer Pointer (88 <sub>H</sub> )	150
WROBC: Write Output Buffer Command (9A <sub>H</sub> )	151
Output Buffer Command Mask Register	
Output Buffer Command Mask Register (OBCM)	124
Output Buffer Command Request Register	
Output Buffer Command Request Register (OBCR)	125
<b>P</b>	
Package Dimensions	
Package Dimensions	7
Parallel Bus	
16-bit Multiplex Parallel Bus Timing	132
16-bit Non-multiplex Parallel Bus Timing	127
Parity Check	
Parity Check	213
Partition	
Data Partition	213
Header Partition	210
Phase	
Offset (Phase) Correction	169
Pin Assignment	
Pin Assignment	8
Pin Functions	
Pin Functions	11
PLL Clock	
Switching Procedure to the PLL Clock	160
PLL Multiplier	
PLL Multiplier Setting	141
Pointer	
WIP: Write Input Buffer Pointer (82 <sub>H</sub> )	149
WOP: Write Output Buffer Pointer (88 <sub>H</sub> )	150
Protocol	
FlexRay Protocol Function	163
SPI Protocol Definition	144
The FlexRay Protocol Controller Access to the Message RAM	207
PRT	
FlexRay Channel Protocol Controller (PRT A/B)	31
PRT Configuration Register	
PRT Configuration Register 1 (PRTC1)	68
PRT Configuration Register 2 (PRTC2)	69
PRTC	
PRT Configuration Register 1 (PRTC1)	68
PRT Configuration Register 2 (PRTC2)	69
<b>R</b>	
RAM	
Data Transmission from the Input Buffer to the Message RAM	203
Data Transmission from the Message RAM to the Output Buffer	205
Host Access to the Message RAM	201
Message RAM	209
RAM Clock Configuration	161
The FlexRay Protocol Controller Access to the Message RAM	207
Transient Buffer RAM (TBF A/B)	31
Rate	
Rate (Frequency) Correction	169
Rate Correction Value Register	
Rate Correction Value Register (RCV)	83
RBC	
RBC: Read Output Buffer,Continue (60 <sub>H</sub> )	147
RBCWBC: Combination of RBC and WBC (78 <sub>H</sub> )	149
RBCWBI: Combination of RBC and WBI (72 <sub>H</sub> )	148
RBCWBC	
RBCWBC: Combination of RBC and WBC (78 <sub>H</sub> )	149

## INDEX

RBCWBI	
RBCWBI: Combination of RBC and WBI (72 <sub>H</sub> )	148
RBI	
RBI: Read Output Buffer,Initialize (42 <sub>H</sub> )	146
RBIWBC: Combination of RBI and WBC (5A <sub>H</sub> )	148
RBIWBI: Combination of RBI and WBI (50 <sub>H</sub> )	147
RBIWBC	
RBIWBC: Combination of RBI and WBC (5A <sub>H</sub> )	148
RBIWBI	
RBIWBI: Combination of RBI and WBI (50 <sub>H</sub> )	147
RCV	
Rate Correction Value Register (RCV)	83
RDDS	
Read Data Section Register (RDDS1 to RDDS64)	117
RDHS	
Read Header Section Register 1 (RDHS1)	118
Read Header Section Register 2 (RDHS2)	118
Read Header Section Register 3 (RDHS3)	119
RDN	
RDN: Read Word n (A0 <sub>H</sub> )	151
RDY	
RDY Wait Count	129, 134
Read Data Section Register	
Read Data Section Register (RDDS1 to RDDS64)	117
Read Header Section Register	
Read Header Section Register 1 (RDHS1)	118
Read Header Section Register 2 (RDHS2)	118
Read Header Section Register 3 (RDHS3)	119
Read Operations	
Register Read Operations	130, 134
Read Output Buffer,Continue	
RBC: Read Output Buffer,Continue (60 <sub>H</sub> )	147
Read Output Buffer,Initialize	
RBI: Read Output Buffer,Initialize (42 <sub>H</sub> )	146
Read Word	
RDN: Read Word n (A0 <sub>H</sub> )	151
READY State	
READY State	175
Receive Buffer	
Receive Buffer	195
Reception	
Frame Reception	195
Null Frame Reception	196
Reference Clock	
Switching Procedure to the Reference Clock	160
Register	
CC Error Vector Register (CCEV)	81
CC Status Vector Register (CCSV)	78
Clock Control Register (CCNT)	37
Communication Controller (CC) Control Registers	61
Communication Controller (CC) Status Registers	78
Core Release Register (CREL)	108
Debug Support Register (DBGS)	40
DMA Support Register (DMAS)	41
Endian Register (ENDN)	109
Error Interrupt Enable Set/Reset Registers (EIES,EIER)	54
Error Interrupt Line Select Register (EILS)	52
Error Interrupt Register (EIR)	46
Even Numbered Cycle Sync Frame ID Register (ESID1 to ESID15)	89
FIFO Critical Level Register (FCL)	96
FIFO Rejection Filter Mask Register (FRFM)	95
FIFO Rejection Filter Register (FRF)	94
FIFO Status Register (FSR)	99
GTU Configuration Register 1 (GTUC1)	70
GTU Configuration Register 10 (GTUC10)	76
GTU Configuration Register 11 (GTUC11)	77
GTU Configuration Register 2 (GTUC2)	71
GTU Configuration Register 3 (GTUC3)	71
GTU Configuration Register 4 (GTUC4)	72
GTU Configuration Register 5 (GTUC5)	73
GTU Configuration Register 6 (GTUC6)	74
GTU Configuration Register 7 (GTUC7)	74
GTU Configuration Register 8 (GTUC8)	75
GTU Configuration Register 9 (GTUC9)	75
Input Buffer Command Mask Register (IBCM)	114
Input Buffer Command Request Register (IBCR)	115
Interrupt Line Enable Register (ILE)	56
Interrupt Register (INT)	43
Last Dynamic Transmit Slot Register (LDTS)	99
Lock Register (LCK)	45
Macrotick and Cycle Counter Value Register (MTCCV)	82
Message Buffer Status Changed Register 1/2/3/4 (MBSC1/MBSC2/MBSC3/MBSC4)	105
Message Buffer Status Register (MBS)	120
Message Handler Status Register (MHDS)	97
Message RAM Configuration Register (MRC)	92
MHD Configuration Register (MHDC)	70
NEM Configuration Register (NEMC)	67
New Data Register 1/2/3/4 (NDAT1/NDAT2/NDAT3/NDAT4)	103

Odd Numbered Cycle Sync Frame ID Register (OSID1 to OSID15) .....	90
Offset Correction Value Register (OCV) .....	83
Output Buffer Command Mask Register (OBCM) .....	124
Output Buffer Command Request Register (OBCR) .....	125
PRT Configuration Register 1 (PRTC1) .....	68
PRT Configuration Register 2 (PRTC2) .....	69
Rate Correction Value Register (RCV).....	83
Read Data Section Register (RDDS1 to RDDS64) .....	117
Read Header Section Register 1 (RDHS1).....	118
Read Header Section Register 2 (RDHS2).....	118
Read Header Section Register 3 (RDHS3).....	119
Register Read Operations.....	130, 134
Register Write Operations.....	131, 136
Slot Counter Value Register (SCV).....	82
Status Interrupt Enable Set/Reset Registers (SIES,SIER) .....	55
Status Interrupt Line Select Register (SILS) .....	53
Status Interrupt Register (SIR) .....	49
Stop Watch Register 1 (STPW1) .....	59
Stop Watch Register 2 (STPW2) .....	60
SUC Configuration Register 1 (SUCC1) .....	61
SUC Configuration Register 2 (SUCC2) .....	66
SUC Configuration Register 3 (SUCC3) .....	66
Symbol Window and NIT Status Register (SWNIT) .....	85
Sync Frame Status Register (SFS) .....	84
Timer 0 Configuration Register (T0C) .....	56
Timer 1 Configuration Register (T1C) .....	57
Transmission Request Register 1/2/3/4 (TXRQ1/TXRQ2/TXRQ3/TXRQ4) .....	102
Version Information Register (VER).....	35
Write Data Section Register (WRDS1 to WRDS64) .....	110
Write Header Section Register 1 (WRHS1) .....	111
Write Header Section Register 2 (WRHS2) .....	113
Write Header Section Register 3 (WRHS3) .....	113
<b>Required Cycle</b>	
Required Cycle Pair Counter for Status Transition between Passive and Active .....	171
<b>Restoration Procedure</b>	
Restoration Procedure from Stop Mode .....	161
<b>RRD</b>	
RRD: 1w Read (22 <sub>H</sub> /21 <sub>H</sub> ).....	145
<b>S</b>	
<b>SCV</b>	
Slot Counter Value Register (SCV).....	82
<b>Security</b>	
Data Security Algorithm .....	153
<b>Segment</b>	
Dynamic Segment .....	165, 192
Static Segment .....	164, 192
<b>Serial Clock</b>	
Serial Clock Operations.....	142
Serial Clock Operations Setting .....	142
<b>Serial Type</b>	
Serial Type .....	141
<b>SFS</b>	
Sync Frame Status Register (SFS) .....	84
<b>SIER</b>	
Status Interrupt Enable Set/Reset Registers (SIES,SIER).....	55
<b>SIES</b>	
Status Interrupt Enable Set/Reset Registers (SIES,SIER).....	55
<b>SILS</b>	
Status Interrupt Line Select Register (SILS) .....	53
<b>SIR</b>	
Status Interrupt Register (SIR) .....	49
<b>Slot Counter Filtering</b>	
Slot Counter Filtering.....	188
<b>Slot Counter Value Register</b>	
Slot Counter Value Register (SCV) .....	82
<b>SPI</b>	
SPI Protocol Definition .....	144
SPI Status Output .....	155
<b>STARTUP State</b>	
STARTUP State .....	179
<b>Startup Timeout</b>	
Startup Timeout.....	182
<b>State</b>	
CONFIG State.....	174
DEFAULT_CONFIG State .....	174
HALT State .....	186
NORMAL_ACTIVE State .....	185
NORMAL_PASSIVE State .....	185
READY State.....	175
STARTUP State .....	179
WAKEUP State.....	176
<b>Static Segment</b>	
Static Segment .....	164, 192
<b>Status Interrupt Enable Set/Reset Registers</b>	
Status Interrupt Enable Set/Reset Registers (SIES,SIER).....	55
<b>Status Interrupt Line Select Register</b>	
Status Interrupt Line Select Register (SILS) .....	53
<b>Status Interrupt Register</b>	
Status Interrupt Register (SIR) .....	49
<b>Status Registers</b>	
Communication Controller (CC) Status Registers .....	78
<b>Stop Mode</b>	
Restoration Procedure from Stop Mode .....	161

## INDEX

Switching Procedure to Stop Mode .....	160
Stop Watch Register	
Stop Watch Register 1 (STPW1).....	59
Stop Watch Register 2 (STPW2).....	60
STPW	
Stop Watch Register 1 (STPW1).....	59
Stop Watch Register 2 (STPW2).....	60
SUC	
System Universal Control (SUC) .....	32
SUC Configuration Register	
SUC Configuration Register 1 (SUCC1).....	61
SUC Configuration Register 2 (SUCC2).....	66
SUC Configuration Register 3 (SUCC3).....	66
SUCC	
SUC Configuration Register 1 (SUCC1).....	61
SUC Configuration Register 2 (SUCC2).....	66
SUC Configuration Register 3 (SUCC3).....	66
Switching Procedure	
Switching Procedure to Stop Mode .....	160
Switching Procedure to the PLL Clock .....	160
Switching Procedure to the Reference Clock .....	160
SWNIT	
Symbol Window and NIT Status Register (SWNIT) .....	85
Symbol Window	
Symbol Window .....	165
Symbol Window and NIT Status Register	
Symbol Window and NIT Status Register (SWNIT) .....	85
Sync Frame	
Sync Frame Transmission .....	169
Sync Frame Status Register	
Sync Frame Status Register (SFS).....	84
Synchronization	
Clock Synchronization.....	168
External Clock Synchronization.....	169
Synchronization Process .....	168
System Clock	
Switching the System Clock Divider Value .....	161
System Universal Control	
System Universal Control (SUC) .....	32
<b>T</b>	
T0C	
Timer 0 Configuration Register (T0C).....	56
T1C	
Timer 1 Configuration Register (T1C).....	57
TBF	
Transient Buffer RAM (TBF A/B) .....	31
Timeout	
Startup Timeout .....	182
Timer 0 Configuration Register	
Timer 0 Configuration Register (T0C) .....	56
Timer 1 Configuration Register	
Timer 1 Configuration Register (T1C) .....	57
Time-triggered Distributed	
Time-triggered Distributed (TT-D) .....	167
Transfer	
Input Buffer Data Transfer .....	139
Output Buffer Data Transfer .....	140
Transient Buffer	
Transient Buffer RAM (TBF A/B).....	31
Transition	
Required Cycle Pair Counter for Status Transition between Passive and Active .....	171
Transmission	
Data Transmission from the Input Buffer to the Message RAM.....	203
Data Transmission from the Message RAM to the Output Buffer .....	205
Frame Transmission .....	193
Null Frame Transmission.....	194
Sync Frame Transmission.....	169
Transmission Request Register	
Transmission Request Register 1/2/3/4 (TXRQ1/TXRQ2/TXRQ3/TXRQ4) .....	102
Transmit	
Transmit Buffer .....	192
TT-D	
Time-triggered Distributed (TT-D) .....	167
TXRQ	
Transmission Request Register 1/2/3/4 (TXRQ1/TXRQ2/TXRQ3/TXRQ4) .....	102
<b>V</b>	
VER	
Version Information Register (VER).....	35
Version Information Register	
Version Information Register (VER).....	35
<b>W</b>	
Wakeup Pattern	
Wakeup Pattern (WUP) .....	179
WAKEUP State	
WAKEUP State .....	176
WBC	
RBCWBC: Combination of RBC and WBC (78 <sub>H</sub> ) .....	149
RBIWBC: Combination of RBI and WBC (5A <sub>H</sub> ) .....	148
WBC: Write Input Buffer,Continue (18 <sub>H</sub> ) .....	146

WBI	
RBCWBI: Combination of RBC and WBI (72 <sub>H</sub> )	148
RBIWBI: Combination of RBI and WBI (50 <sub>H</sub> )	147
WBI: Write Input Buffer,Initialize (12 <sub>H</sub> )	145
Window	
Symbol Window	165
WIP	
WIP: Write Input Buffer Pointer (82 <sub>H</sub> )	149
WOP	
WOP: Write Output Buffer Pointer (88 <sub>H</sub> )	150
WR	
WR: 1w Write (0A <sub>H</sub> /09 <sub>H</sub> )	145
WRDS	
Write Data Section Register (WRDS1 to WRDS64)	110
WRHS	
WRHS: Write Input Buffer Header Section 1 to 3 (AA <sub>H</sub> )	152
Write Header Section Register 1 (WRHS1)	111
Write Header Section Register 2 (WRHS2)	113
Write Header Section Register 3 (WRHS3)	113
WRIBC	
WRIBC: Write Input Buffer Command (90 <sub>H</sub> )	150
Write Data Section Register	
Write Data Section Register (WRDS1 to WRDS64)	110
Write Header Section Register	
Write Header Section Register 1 (WRHS1)	111
Write Header Section Register 2 (WRHS2)	113
Write Header Section Register 3 (WRHS3)	113
Write Input Buffer Command	
WRIBC: Write Input Buffer Command (90 <sub>H</sub> )	150
Write Input Buffer Header Section	
WRHS: Write Input Buffer Header Section 1 to 3 (AA <sub>H</sub> )	152
Write Input Buffer Pointer	
WIP: Write Input Buffer Pointer (82 <sub>H</sub> )	149
Write Input Buffer,Continue	
WBC: Write Input Buffer,Continue (18 <sub>H</sub> )	146
Write Input Buffer,Initialize	
WBI: Write Input Buffer,Initialize (12 <sub>H</sub> )	145
Write Operations	
Register Write Operations	131, 136
Write Output Buffer Command	
WROBC: Write Output Buffer Command (9A <sub>H</sub> )	151
Write Output Buffer Pointer	
WOP: Write Output Buffer Pointer (88 <sub>H</sub> )	150
WROBC	
WROBC: Write Output Buffer Command (9A <sub>H</sub> )	151
WUP	
Wakeup Pattern (WUP)	179



AM15-11201-1E

---

FUJITSU SEMICONDUCTOR • ASSP MANUAL

FlexRay ASSP

MB88121B

User's Manual

---

October 2007 the first edition

Published **FUJITSU LIMITED** Electronic Devices

Edited Strategic Business Development Dept.

---

