IMPORTANT: Do Not Return Dispenser to Store. If you have questions or issues please contact 1-866-429-7566 for expert assistance.



Bottom Loading Water Dispenser

Model # 900130

TO REDUCE THE RISK OF INJURY AND PROPERTY DAMAGE, USER MUST READ THIS MANUAL BEFORE ASSEMBLING, INSTALLING & OPERATING DISPENSER.

SAVE THIS MANUAL FOR FUTURE USE



PRIMO \$ @ Q

FEATURES & FUNCTIONS

Function Lights – Green light below ON icon indicates the dispenser is plugged in. Green light below snowflake indicates the dispenser is cooling water. Green light below wavy lines indicates the dispenser is heating water. Blinking red light below the bottle icon indicates the bottle is empty.

Cold Pushbutton Control – Depress control to dispense. Release to stop.

Cool Pushbutton Control – Depress control to dispense. Release to stop.

Hot Pushbutton Control with Child Safety Feature - Slide red button away from you and depress control to dispense. Release to stop.

Bottle Support – Helps align sports bottles and glasses with spout to eliminate spills.

Spouts Cold water comes out here.

Cool water comes out here.

Hot water comes out here.

LED Nightlight – Located behind bottle support. Helps in low light situations. **Probe Assembly** – Located inside cabinet. Connects to bottle to allow water to be pumped into hot and cold tanks.

Probe Hanger – Located inside door at top. To keep probe assembly clean when changing bottles, rest it here.

Drip Tray & Grid – Dishwasher safe. Snaps in and out. Position glass, cup or pot over center hole in grid to avoid spills.

Water Bottle – Not included. Uses 3, 4 or 5 gallon bottles. Go to www.PrimoWater.com to find Primo Water at a store near you.

Energy Saver Switches – Located on back. Switch red control to off to stop heating. Switch green control to off to stop cooling.

Nightlight Switch – Located on back. Allows you to choose to have the nightlight ON or OFF.

GETTING STARTED

Locate Dispenser

- 1. Place dispenser upright.
- Locate dispenser on a hard and level surface in a cool shaded location near a grounded wall outlet.

Notice: Do NOT plug in power cord yet.

3. Position dispenser so the back is at least 4 inches from wall and there are at least 4 inches of clearance on both sides.

Assemble


- 1. Remove drip tray from door and place the grid on top.
- 2. Snap drip tray and grid assembly into door.

Install Water Bottle

- 1. Open dispenser door.
- 2. Place probe assembly on probe hanger.
- 3. Place fresh bottle outside of cabinet.
- 4. Remove entire plastic cap from top of bottle.
- 5. Clean outside of new bottle with a cloth.
- 6. Place probe into bottle.
- 7. Slide collar down until it clicks in place.
- 8. Push head down until tubes hit bottom of bottle.
- Slide bottle into cabinet and close door. 9.

Provide Electricity

Plug cord into a properly grounded wall outlet. At this time the pump will begin to move water from the bottle to the hot and cold tanks. It will take up to 12 minutes to fill the tanks for the first time. During this period the pump will run continuously. This is normal.





Activate Heating & Cooling

Notice: This unit will not dispense hot or cold water until the switches are activated.

To activate, push top side of power switches in to start heating and cooling water.

- If you do not want to heat water, push bottom side of red switch in.
- If you do not want to cool water, push bottom side of green switch in.

Activate Nightlight

Push top side of blue power switch in to turn light on. Push bottom side in to turn light off.

Register Online

While you wait for the water to get hot and cold, please register your dispenser. This will be helpful should you need customer service assistance in the future.

Go to www.PrimoWater.com and click on Customer Care.

DISPENSING WATER

This unit has been tested and sanitized prior to packing and shipping. During transit dust and odors can accumulate in the tank and lines. Dispense and dispose at least one quart of water prior to drinking any water.

Dispensing Cold Water (37°F – 50°F)

After setup, it will take up to 1 hour to get water to maximum cold temperature. During this time the compressor could run continuously. This is normal.

- 1. Position bottle, glass, pitcher or cooking pot below spout.
- 2. Depress cold water control downward to start cold water flow.
- 3. Release control once desired fill level is achieved.

SAFETY PRECAUTIONS

A WARNING

personal injury or property damage.

- accordance with this manual.
- sunlight. Do NOT use outdoors.

- Use only properly grounded outlets.
- power cord.

- 866-429-7566 for assistance.

Dispensing Cool Water

- 1. Position bottle, glass, pitcher or cooking pot below spout.

unsupervised use by children.

Changing Bottles

- 1. Open dispenser door.
- probe hanger.
- 4. Set empty bottle aside.

- To reduce risk of injury and property damage, user must read this entire guide before assembling, installing & operating dispenser. Failure to execute the instructions in this manual can cause
- This product dispenses water at very high temperatures. Failure to use properly can cause personal injury.
- When operating this dispenser, always exercise basic safety precautions, including the following:
- Prior to use, this dispenser must be properly assembled and installed in
- This dispenser is intended for water dispensing only. Do NOT use other liquids. Do NOT use for other purposes. Never use any other liquid in the dispenser other than known and microbiologically safe bottled water.
- For indoor use only. Keep water dispenser in a dry place away from direct
- Install and use only on a hard, flat and level surface.
- Do NOT place dispenser into an enclosed space or cabinet.
- Do NOT operate dispenser in the presence of explosive fumes.
- Position back of dispenser no closer than 4 inches from wall and permit free airflow between wall and dispenser. There must be at least 4 inches clearance on the sides of the dispenser to permit airflow.
- Do not use an extension cord with your water dispenser.
- Always grasp plug and pull straight out from outlet. Never unplug by pulling on
- Do NOT use dispenser if cord becomes frayed or otherwise damaged. • To protect against electric shock, do NOT immerse cord, plug, or any other part of dispenser in water or other liquids.
- Ensure dispenser is unplugged prior to cleaning.
- Never allow children to dispense hot water without proper and direct supervision. Unplug unit to prevent unsupervised use by children.
- Service should be performed only by a certified technician. Please contact us at

- 2. Depress cool water control downward to start cool water flow.
- 3. Release control once desired fill level is achieved.

Dispensing Hot Water (185°F – 210°F)

- This unit dispenses water at temperatures that can cause severe burns. Avoid direct contact with hot water. Keep children and pets away from unit while dispensing. Never allow children to dispense hot water without proper and direct supervision. Unplug unit to prevent
- After setup, hot water will be available in 15-20 minutes.
- 1. Position bottle, glass, pitcher or cooking pot below spout.
- 2. Slide red button away from you and depress hot water control downward to start hot water flow.
- 3. Release control once desired fill level is achieved.
- A flashing red light on your function lights alerts you when your bottle is empty. Replace the bottle as soon as possible.
- Notice: Do not dispense hot, cool or cold water if the red light is flashing as you could empty the tanks and cause the dispenser to overheat.
- 2. Slide empty bottle out of cabinet.
- 3. Remove probe assembly from empty bottle. Place probe assembly on

- 5. Place fresh bottle outside of cabinet. Remove entire plastic cap from top of bottle. Clean outside of new bottle with a cloth.
- 6. Place probe into bottle. Slide collar down until it clicks in place. Push head down until tubes hit bottom of bottle.
- 7. Slide bottle into cabinet and close door.

LIMITED WARRANTY

Primo Water Corporation, ("Vendor") warrants to the original purchaser of this dispenser, and to no other person, that if this dispenser is assembled and operated in accordance with the printed instructions accompanying it, then for a period of one (1) year from the date of purchase, all parts in such dispenser shall be free from defects in material and workmanship. Vendor may require reasonable proof of your date of purchase from an authorized retailer or distributor. Therefore, you should retain your sales slip or invoice. The Limited Warranty shall be limited to repair or replacement of parts, which prove defective under normal use and service and which Vendor shall determine in its reasonable discretion upon examination to be defective. Before returning any parts, you should contact Vendor's Customer Service Department using the contact information listed below. If Vendor confirms, after examination, a defect covered by this Limited Warranty in any returned part, and if Vendor approves claim, Vendor will replace such defective part without charge. If you return defective parts, transportation charges must be prepaid by you. Vendor will return replacement parts to original purchaser, freight or postage prepaid.

The Limited Warranty does not cover any failures or operating difficulties due to accident, abuse, misuse, alteration, misapplication, improper installation or improper maintenance or service by you or any third party, or failure to perform normal and routine maintenance on the dispenser, as set out in the User's Manual. In addition, the Limited Warranty does not cover damages to the finish, such as scratches, dents, discoloration or rust after purchase.

The Limited Warranty is in lieu of all other express warranties. Vendor disclaims all warranties for products that are purchased from seller other than authorized retailers or distributors. AFTER THE PERIOD OF THE ONE (1) YEAR EXPRESS WARRANTY, VENDOR DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. FURTHER, VENDOR SHALL HAVE NO LIABILITY WHATSOEVER TO PURCHASER OR ANY THIRD PARTY FOR ANY SPECIAL, INDIRECT, PUNITIVE, INCIDENTAL, OR CONSEQUENTAL DAMAGES. Vendor assumes no responsibility for any defects caused by third parties. This Limited Warranty gives the purchaser specific legal rights; a purchaser may have other rights depending upon where he or she lives. Some jurisdictions do not allow exclusion or limitation of special, incidental or consequential damages, or limitations on how long a warranty lasts, so the above exclusion and limitations may not apply to you.

Primo Water Corporation 104 Cambridge Plaza Drive Winston-Salem, NC 27104 866-429-7566 www.PrimoWater.com

TROUBLESHOOTING

Water is leaking.

Unplug dispenser, remove bottle and call 866-429-7566 for assistance.

No water is coming from the spout.

- Make sure the bottle is not empty. If empty, replace it.
- Make sure to completely depress the pushbutton controls.

Cold water is not cold.

- It takes up to one hour after setup to dispense cold water.
- Make sure the power cord is properly connected to a working outlet.
- Make sure the back of the dispenser is at least 4 inches from a wall and there is free airflow on all 4 sides of the dispenser.
- Make sure green power switch on back of dispenser is ON.
- If water still isn't cold, please call 866-429-7566 for assistance.

Hot water is not hot.

- It takes 15-20 minutes after setup to dispense hot water.
- Make sure the power cord is properly connected to a working outlet.
- Make sure red power switch on back of dispenser is ON.

Nightlight Isn't Working

- Make sure the power cord is properly connected to a working outlet.
- Make sure nightlight power switch on back of dispenser is ON.

Dispenser Is Noisy

Make sure the dispenser is positioned on a level surface.