

**newair** CC-280E

---

# Thermoelectric Cigar Cooler



## **OWNERS MANUAL**

*Read and save these instructions.*

## READ AND SAVE THESE INSTRUCTIONS

Thank you for choosing this NewAir appliance. At NewAir, we're dedicated to providing comfortable and convenient solutions for your home and office needs. This guide contains important information about the care and operation of your new appliance. Please take the time to read through this material thoroughly. With proper care and maintenance, this appliance will provide you with many years of trouble-free use.

## QUESTIONS?

NewAir is here to help. As a small, family run business, we understand you don't have time to spare dealing with unresponsive, unhelpful customer service. Our Customer Service team has years of experience answering questions about appliances and can help you solve your problem quickly and effortlessly. Contact us today!

**NewAir USA**  
 855-963-9247  
 support@newair.com  
<http://www.NewAir.com>

**For future reference, we recommend you attach a copy of your sales receipt below and record the following information, located on the manufacturer's nameplate on the rear of the unit. You will need this information if it becomes necessary to contact the manufacturer for service inquiries.**

**Date of Purchase:** \_\_\_\_\_

**Serial Number:** \_\_\_\_\_

**Model Number:** \_\_\_\_\_

*Attach receipt here.*

## TABLE OF CONTENTS

Safety Information & Warnings.....	3
Safe Operation Guidelines .....	3
Specifications .....	4
Parts List.....	4
Parts Diagram.....	5
Assembly & Installation.....	5
Handle Assembly.....	5
Installation.....	6
Operating Instructions.....	7
Operating Environment.....	7
How to Use the Buttons on the Display Panel.....	7
Cleaning & Maintenance.....	8
Cleaning Your Cooler.....	8
Moving Your Cooler.....	8
Cigar Storage Guide.....	8
Troubleshooting.....	9
Warranty.....	11

## SAFETY INFORMATION & WARNINGS

### SAFE OPERATION GUIDELINES



When using any electrical appliance, basic safety precautions must be followed in order to reduce the risk of fire, electrical shock and/or injury to persons or property. Be sure to read all instructions before using this appliance and observe the following safety tips:

- **Attention: To prevent the risk of child entrapment, do not allow children to operate, play with, or crawl inside the unit.** If the unit will not be used for an extended period of time, remove the door and leave the shelves in place so that children cannot crawl inside. Also remove the door when disposing of the unit.
- Never clean the appliance parts with flammable fluids, as the fumes can create a fire hazard or explosion.

- Do not store or use gasoline or any other flammable vapors and liquids near this or any other appliance, as the fumes can create a fire hazard or explosion
- Do not store perishable foods in the wine cooler, as the interior temperature will not be low enough to prevent food spoilage.



### **Shock Hazard – Electrical Grounding Required**

- Improper use of the grounded plug can result in electrical shock. If the power cord appears to be damaged, have it replaced by an authorized service center.
- This cooler should be properly grounded for your safety, and in order to minimize the possibility of electrical shock, the power cord of this unit is equipped with a 3-pin plug which fits 3-pin wall outlets.
- Never cut or remove the ground wire from the supplied power cord.
- The use of an extension cord is not recommended.
- The cord should be secured behind the cooler. Also, to prevent accidental injury, do not expose or dangle the cord.

## SPECIFICATIONS

<b>MODEL NO.</b>	CC-280E
<b>RATED VOLTAGE:</b>	115V / 60Hz
<b>POWER CONSUMPTION:</b>	70W
<b>STORAGE CAPACITY:</b>	400 cigars
<b>TEMPERATURE RANGE:</b>	54°F - 66°F

## PARTS LIST


When you receive your unit, carefully remove the exterior and interior packaging. It is recommended that you retain the packaging for future use.

Check to make sure the following parts are included:

NEWAIR CC-280E THERMOELECTRIC CIGAR COOLER

- 4 slide-out shelves
- 2 drawers
- Door handle and 2 screws
- 1 instruction manual

## PARTS DIAGRAM



1. Rear cover
2. Light
3. Fan Mask
4. Shelves

5. Feet
6. Temperature Control Panel
7. Light Switch
8. Magnetic Seal

9. Glass Door
10. Door Handle
11. Door Frame

## ASSEMBLY & INSTALLATION

### HANDLE ASSEMBLY

**Tools Required for Assembly:** Phillips screwdriver (not included)

**Estimated Assembly Time:** 5 minutes

NEWAIR CC-280E THERMOELECTRIC CIGAR COOLER

Before installation, attach the handle to the front of the unit with the included screws. It may be necessary to push aside the rubber seal on the inside of the door to reveal the screw holes.

**Caution:** Avoid over-tightening the screws, or you may cause damage to the unit.

---

## INSTALLATION

This cooler is freestanding unit and should not be installed inside a cabinet or other built-in enclosure.

For proper ventilation, allow 5 inches clearance between the back of the unit and any adjacent walls.

Before operating your wine cooler for the first time, follow these steps:

- Before connecting the unit to a power source, allow it to stand upright for approximately 2 hours. This will reduce the possibility of any system malfunctions which may have occurred from handling during transportation.
- Clean the interior surface of the unit with lukewarm water and a soft cloth.
- Place the cooler on a level surface that will be strong enough to support the unit when it is fully loaded. To level your cooler, adjust the front feet located at the bottom of the unit.
- Install the cooler away from direct sunlight and heat sources such as stoves, heaters, or radiators. Direct sunlight may affect the unit's acrylic coating, and nearby heat sources can increase electrical consumption. Extreme cold or hot ambient temperatures may also prevent proper performance.
- Please note: this cooler is only designed for home use, and is not designed to be placed in a garage, basement, or outdoor area.

## FACTORY ODOR REMOVAL

Wash the interior of the cooler with a mild detergent and warm water. Leave the door open and allow it to air dry thoroughly. If a "plastic" smell persists, place a dish of baking soda in the unit or stuff the cooler with newspapers

overnight. When finished, let the unit run a full day to complete the airing out process.

## DRAWER SET-UP

The drawers and shelves included with this cooler are designed to sit flush with the front edge of the cabinet. This will allow air to circulate freely through the unit. When inserting the drawers and shelves, avoid pushing them all the way against the rear wall of the cabinet.


## OPERATING INSTRUCTIONS


### OPERATING ENVIRONMENT


It is recommended that the wine cooler be installed in an area where the ambient temperature is between 50°- 80°F (10°-26°C). If the ambient temperature is above or below the recommended ranges, the unit's performance may be affected, and extreme cold or hot conditions may cause the interior temperature to fluctuate. This will prevent the optimal range of 50°- 60°F (10°-16°C) from being reached. In addition, keep in mind that the temperature may fluctuate depending on whether the interior light is on or off, and whether the bottles are located on the upper, middle, or lower racks.


### HOW TO USE THE BUTTONS ON THE DISPLAY PANEL



 Select Centigrade or Fahrenheit temperature scale.

 Raise the desired temperatures.\*

 Turn the light on and off.

 Lower the desired temperature.\*

\* The interior temperature can be adjusted in increments of 1 degree between 54° and 66°F (10° - 18°C).

## CLEANING & MAINTENANCE

### CLEANING YOUR COOLER

To clean your cooler:

- Unplug the cooler and remove anything inside.
- Wash the inside of the unit with a solution made of warm water and baking soda solution (2 tablespoons of baking soda to one quart of water).
- Unscrew the water reservoir at the bottom of the unit and rinse with water.
- To clean the outside of the unit, use a mild detergent and warm water.

### MOVING YOUR COOLER

To move your cooler:

- Remove anything stored inside.
- Securely tape down all loose parts located inside the unit.
- Turn the leveling feet up to the base in order to avoid damage.
- Tape the door shut.
- Be sure the cooler stays in an upright position during transportation.

## CIGAR STORAGE GUIDE

- The ideal temperature for storing cigars is between 65° and 73°F.
- The ideal relative humidity (RH) for storing cigars is between 65% and 75% RH. To properly monitor and maintain RH in the CC-280E, you will need to add a hygrometer (humidity gauge) and some variety of humidifier to the cooler.
- Keep cigars out of direct sunlight, to avoid exposure to damaging UV rays.
- It is recommended to keep cigars in their original boxes and packaging as long as possible. Keep unwrapped cigars separate in your cooler to avoid unwanted mingling of flavors.



- Check cigars regularly for signs of tobacco beetles and mold, and take preventative measures if necessary.
- Properly stored cigars can improve with age for as long as 5-10 years, and can be kept even longer in ideal conditions.

## TROUBLESHOOTING

<b>Problem</b>	<b>Possible Causes</b>	<b>Solution</b>
<b>The cooler will not operate.</b>	The unit may be plugged in using a different voltage.	Check if using the wrong voltage.
	The circuit breaker may be tripped or there is a blown fuse.	Reset the circuit breaker or check for a broken fuse.
<b>The cooler is not cold enough.</b>	The external environment may require a higher setting.	Lower the temperature of the cooler.
	The door may be opened too frequently.	Open the door less frequently.
	The door is not closed completely.	Make sure the door is closed securely.
	The door seal does not seal properly.	Replace the seal on the door. Replacements can be acquired from the manufacturer.
	The wine cooler does not have sufficient clearance.	Make sure there is at least 5 inches clearance between the back of the unit and any adjacent walls.
<b>The light does not work.</b>	There may be a problem with the display board.	Contact the manufacturer.

<b>Problem</b>	<b>Possible Causes</b>	<b>Solution</b>
<b>The cooler vibrates while operating.</b>	The unit is not sitting on a level floor, or the unit's feet are not correctly installed.	Make sure the unit's feet are in the proper position and tightened securely.
<b>The cooler produces a lot of noise.</b>	The unit is not leveled.	See above.
	Check the fan.	Check the fan to make sure there is no debris or obstruction. If not, contact the manufacturer.
<b>The door will not close properly.</b>	The unit is not leveled.	See above.
	The door is not properly installed.	Check the door hinges to make sure they are properly installed.
	The seal is weak.	Replace the seal on the door. Replacements can be acquired from the manufacturer.
	The shelves are out of position.	Make sure the shelves slide all the way into the unit.
<b>The LED display does not work.</b>	There may be a problem with the main control board.	Contact the manufacturer.
	There is a problem with the plug.	Contact the manufacturer.
<b>There is an LED display error, or the LED displays "LO".</b>	The cooling kit is no longer working properly.	Contact the manufacturer.
	The PC Board is faulty.	Contact the manufacturer.
<b>The buttons do not function.</b>	The temperature control panel may be damaged.	Contact the dealer or an authorized service center.

## LIMITED MANUFACTURER'S WARRANTY

This appliance is covered by a limited manufacturer's warranty. For one year from the original date of purchase, the manufacturer will repair or replace any parts of this appliance that prove to be defective in materials and workmanship, provided the appliance has been used under normal operating conditions as intended by the manufacturer.

### **Warranty Terms:**

During the first year, any components of this appliance found to be defective due to materials or workmanship will be repaired or replaced, at the manufacturer's discretion, at no charge to the original purchaser. The purchaser will be responsible for any removal or transportation costs.

### **Warranty Exclusions:**

The warranty will not apply if damage is caused by any of the following:

- Power failure
- Damage in transit or when moving the appliance
- Improper power supply such as low voltage, defective household wiring or inadequate fuses
- Accident, alteration, misuse or abuse of the appliance such as using non-approved accessories, inadequate air circulation in the room or abnormal operating conditions (extreme temperatures)
- Use in commercial or industrial applications
- Fire, water damage, theft, war, riot, hostility or acts of God such as hurricanes, floods, etc.
- Use of force or damage caused by external influences
- Partially or completely dismantled appliances

### **Obtaining Service:**

When making a warranty claim, please have the original bill of purchase with purchase date available. Once confirmed that your appliance is eligible for warranty service, all repairs will be performed by a NewAir™ authorized repair facility. The purchaser will be responsible for any removal or transportation costs. Replacement parts and/or units will be new, re-manufactured or refurbished and is subject to the manufacturer's discretion. For technical support and warranty service, please email [support@newairusa.com](mailto:support@newairusa.com).