



Hexagon Application Kit

For XMC4000 Family

CPU_45B-V1

CPU Board XMC4500 SDRAM

Board User's Manual

Revision 1.0, 2013-02-20

Microcontroller

Edition 2013-02-20

**Published by
Infineon Technologies AG
81726 Munich, Germany
© 2013 Infineon Technologies AG
All Rights Reserved.**

Legal Disclaimer

The information given in this document shall in no event be regarded as a guarantee of conditions or characteristics. With respect to any examples or hints given herein, any typical values stated herein and/or any information regarding the application of the device, Infineon Technologies hereby disclaims any and all warranties and liabilities of any kind, including without limitation, warranties of non-infringement of intellectual property rights of any third party.

Information

For further information on technology, delivery terms and conditions and prices, please contact the nearest Infineon Technologies Office (www.infineon.com).

Warnings

Due to technical requirements, components may contain dangerous substances. For information on the types in question, please contact the nearest Infineon Technologies Office.

Infineon Technologies components may be used in life-support devices or systems only with the express written approval of Infineon Technologies, if a failure of such components can reasonably be expected to cause the failure of that life-support device or system or to affect the safety or effectiveness of that device or system. Life support devices or systems are intended to be implanted in the human body or to support and/or maintain and sustain and/or protect human life. If they fail, it is reasonable to assume that the health of the user or other persons may be endangered.

Revision History

Page or Item	Subjects (major changes since previous revision)
Revision 1.0 2013-02-20	

Trademarks of Infineon Technologies AG

AURIX™, C166™, CanPAK™, CIPOS™, CIPURSE™, EconoPACK™, CoolMOS™, CoolSET™, CORECONTROL™, CROSSAVE™, DAVE™, EasyPIM™, EconoBRIDGE™, EconoDUAL™, EconoPIM™, EiceDRIVER™, eupec™, FCOS™, HITFET™, HybridPACK™, I²RF™, ISOFACE™, IsoPACK™, MIPAQ™, ModSTACK™, my-d™, NovalithIC™, OptiMOS™, ORIGA™, PRIMARION™, PrimePACK™, PrimeSTACK™, PRO-SIL™, PROFET™, RASIC™, ReverSave™, SatRIC™, SIEGET™, SINDRION™, SIPMOS™, SmartLEWIS™, SOLID FLASH™, TEMPFET™, thinQ!™, TRENCHSTOP™, TriCore™.

Other Trademarks

Advance Design System™ (ADS) of Agilent Technologies, AMBA™, ARM™, MULTI-ICE™, KEIL™, PRIMECELL™, REALVIEW™, THUMB™, μVision™ of ARM Limited, UK. AUTOSAR™ is licensed by AUTOSAR development partnership. Bluetooth™ of Bluetooth SIG Inc. CAT-iq™ of DECT Forum. COLOSSUS™, FirstGPS™ of Trimble Navigation Ltd. EMV™ of EMVCo, LLC (Visa Holdings Inc.). EPCOS™ of Epcos AG. FLEXGO™ of Microsoft Corporation. FlexRay™ is licensed by FlexRay Consortium. HYPERTERMINAL™ of Hilgraeve Incorporated. IEC™ of Commission Electrotechnique Internationale. IrDA™ of Infrared Data Association Corporation. ISO™ of INTERNATIONAL ORGANIZATION FOR STANDARDIZATION. MATLAB™ of MathWorks, Inc. MAXIM™ of Maxim Integrated Products, Inc. MICROTEC™, NUCLEUS™ of Mentor Graphics Corporation. Mifare™ of NXP. MIPI™ of MIPI Alliance, Inc. MIPS™ of MIPS Technologies, Inc., USA. muRata™ of MURATA MANUFACTURING CO., MICROWAVE OFFICE™ (MWO) of Applied Wave Research Inc., OmniVision™ of OmniVision Technologies, Inc. Openwave™ Openwave Systems Inc. RED HAT™ Red Hat, Inc. RFMD™ RF Micro Devices, Inc. SIRIUS™ of Sirius Satellite Radio Inc. SOLARIS™ of Sun Microsystems, Inc. SPANSION™ of Spansion LLC Ltd. Symbian™ of Symbian Software Limited. TAIYO YUDEN™ of Taiyo Yuden Co. TEAKLITE™ of CEVA, Inc. TEKTRONIX™ of Tektronix Inc. TOKO™ of TOKO KABUSHIKI KAISHA TA. UNIX™ of X/Open Company Limited. VERILOG™, PALLADIUM™ of Cadence Design Systems, Inc. VLYNQ™ of Texas Instruments Incorporated. VXWORKS™, WIND RIVER™ of WIND RIVER SYSTEMS, INC. ZETEX™ of Diodes Zetex Limited.

Last Trademarks Update 2011-02-24

Table of Contents

Introduction	7
1 Overview	7
1.1 Key Features	7
1.2 Block Diagram	8
2 Hardware Description	9
2.1 Power Supply	9
2.2 Reset	12
2.3 Clock Generation.....	13
2.4 Boot Option	13
2.5 Debug Interface.....	14
2.5.1 On-board USB Debugger.....	15
2.5.2 Cortex Debug Connector (10-pin).....	16
2.5.3 Cortex Debug+ETM Connector (20-pin)	17
2.6 Serial Flash Memory	19
2.7 SDRAM	20
2.8 USB	20
2.9 RTC	22
2.10 User LEDs and User Button.....	23
2.11 Potentiometer	23
2.12 Satellite Connectors	24
2.12.1 COM Connector	25
2.12.2 HMI Connector	26
2.12.3 ACT Satellite Connector.....	27
3 Production Data	27
3.1 Schematics.....	27
3.2 Component Placement and Geometry.....	32
3.3 Bill of Material (BOM)	33

List of Figures

Figure 1	CPU_45B-V1 Board Block Diagram.....	8
Figure 2	CPU Board XMC4500 SDRAM (CPU_45B-V1).....	9
Figure 3	Powering option.....	10
Figure 4	Block Diagram Of Power Supply.....	10
Figure 5	Reset Circuit.....	12
Figure 6	Reset LED and Reset Button.....	12
Figure 7	Clock Generation Circuit.....	13
Figure 8	Boot Options Switch.....	13
Figure 9	Installation of Serial Port Driver.....	15
Figure 10	On-Board USB Debugger.....	15
Figure 11	Cortex Debug Connector (10-pin).....	16
Figure 12	Cortex Debug Connector (10-pin) Layout.....	17
Figure 13	Cortex Debug+ETM Connector (20-pin).....	17
Figure 14	Cortex Debug+ETM Connector (20-pin) Layout.....	18
Figure 15	Quad SPI Flash Interface.....	19
Figure 16	SDRAM Interface.....	20
Figure 17	USB Connector.....	20
Figure 18	USB power generation - Host/OTG mode.....	21
Figure 19	Battery Holder for Coin Cells.....	22
Figure 20	XMC4500 Power Domains and Real Time Clock.....	22
Figure 21	User LEDs and User Buttons.....	23
Figure 22	Satellite Connectors.....	24
Figure 23	Satellite Connector Type COM.....	25
Figure 24	Satellite Connector Type HMI.....	26
Figure 25	Satellite Connector Type ACT.....	27
Figure 26	Satellite Connectors, USB-OTG.....	28
Figure 27	XMC4500.....	29
Figure 28	Power, Debug Connector, Reset, SDRAM.....	30
Figure 29	On-board Debugger.....	31
Figure 30	Component Placement and Geometry.....	32

List of Tables

Table 1	Power status LEDs.....	10
Table 2	Power Measurement.....	11
Table 3	Boot Options Settings.....	13
Table 4	Cortex Debug Connector (10 Pin).....	16
Table 5	Cortex Debug+ETM Connector (20 Pin).....	18
Table 6	Quad SPI Signals.....	19
Table 7	USB micro AB connector Pinout.....	21
Table 8	User LEDs.....	23
Table 9	User Buttons.....	23
Table 10	Potentiometer.....	23
Table 11	BOM of CPU_45B-V1 Board.....	33

Introduction

This document describes the features and hardware details of the CPU board “CPU Board XMC4500 SDRAM” (CPU_45B-V1) designed to work with Infineon’s XMC4500 Microcontroller. This board is part of Infineon’s Hexagon Application Kits. Please visit www.infineon.com/xmc-dev for more information about the Hexagon Application Kit family.

1 Overview

The CPU board CPU_45B-V1 houses the XMC4500 Microcontroller and three satellite connectors (HMI, COM, ACT) for application expansion. The board along with satellite cards (e.g. HMI_OLED-V1, COM_ETH-V1, AUT_ISO-V1 boards) demonstrates the capabilities of XMC4500.

The main use case of this board is to demonstrate the external bus unit (EBU) of the XMC4500 device including the tool chain. For this purpose a 64 Mbit SDRAM is connected to the XMC4500 and for external bus extension an asynchronous 16-bit wide bus interface is available at the COM satellite connector.

Attention: This board (CPU_45B) has not been designed to work with the “General Purpose Motor Drive Card” (MOT_GPDLV). For this purpose please use the CPU boards CPU_45A, CPU_44A or CPU_42A.

The focus is safe operation under evaluation conditions. The board is neither cost nor size optimized and does not serve as a reference design.

1.1 Key Features

The CPU_45B-V1 board is equipped with the following features


- XMC4500 (ARM[®] Cortex™-M4-based) Microcontroller, 1 MByte Flash, 160 kByte SRAM, LFBGA-144
- 8 MByte On-board SDRAM, 1 Mbit x 16 bits x 4 banks
- Connection to satellite cards via satellite connectors COM, HMI and ACT
- USB OTG Host/Device support via micro USB connector
- Debug options
 - On-board Debugger via the Debug USB connector
 - Cortex Debug connector 10-pin (0.05”)
 - Cortex Debug+ETM connector 20-pin (0.05”)
- Reset push button
- 32 MBit quad SPI flash memory
- Boot option switch
- PowerScale Connector: Ready for power consumption analysis
- Two User Buttons connected to P5.10 and P0.10
- 7 LED's
 - 3 Power indicating LED's
 - 2 User LEDs (P5.2 and P1.1)
 - 1 RESET LED
 - 1 Debug LED
- Potentiometer, connected to analog input P14.1
- Power supply
 - Via Debug USB connector
 - Via Micro-USB connector in USB device mode
 - Via satellite connector pins (COM/ACT satellites cards can supply power to CPU board)
 - RTC backup battery

1.2 Block Diagram

Figure 1 shows the functional block diagram of the CPU_45B-V1 board. For more information about the power supply please refer to chapter 2.1.

The CPU board has got the following building blocks:

- 3 Satellite Connectors (COM, HMI ACT)
- 2 User LEDs connected to GPIOs P5.2 and P1.1
- 2 User Buttons connected to GPIOs P5.10 and P0.10.
- Quad SPI flash memory (32 Mbit)
- Synchronous Dynamic RAM (SDRAM, 64Mbit)
- 2 Cortex Debug Connectors
- Variable resistor (POTI) connected to GPIO P14.1
- USB On-The-Go Connector (Micro-USB)
- On-board Debugger via USB connector (Micro-USB)



Block_Diag.emf

Figure 1 CPU_45B-V1 Board Block Diagram

2 Hardware Description

The following sections give a detailed description of the hardware and how it can be used.




Figure 2 CPU Board XMC4500 SDRAM (CPU_45B-V1)

2.1 Power Supply

The CPU_45B-V1 board can be powered via either of the USB plugs (5 V); however, there is a current limit that can be drawn from the host PC through USB. If the CPU_45B-V1 board is used to drive other satellite cards (e.g. AUT_ISO-V1 or MOT_GPDLV-V2) and the total current required exceeds 500 mA, then the board needs to be powered by a satellite card, which supports external power supply like e.g. AUT_ISO-V1, MOT_GPDLV-V2, COM_ETH-V1.

The typical current drawn by the CPU board without any satellite cards connected is about 220 mA (@5V).

For powering the board through an USB interface, connect the USB cable provided with the kit to either of the Micro-USB connector on board as shown in Figure 3.




Figure 3 Powering option

To indicate the power status of CPU_45B-V1 board three power indicating LED's are provided on board (see Figure 3). The LED will be "ON" when the corresponding power rail is powered.

Table 1 Power status LEDs

LED Reference	Power Rail	Voltage	Note
V401	VDD5	5 V	Must always be "ON"
V402	VDD5USB	5 V	"ON" if powered by USB OTG connector X203 "OFF" in all other supply cases
V403	VDD3.3	3.3 V	Must always be "ON"




Figure 4 Block Diagram Of Power Supply

Hitex PowerScale probe is provided on the CPU_45B-V1 board to measure the power consumption of the XMC4500 device.

Table 2 **Power Measurement**

Jumper	Function	Description
JP300	PowerScale	A Hitex PowerScale probe can be connected for current sensing the VDD3.3 (CPU power source). Default: pos. 1-2 (closed) <i>Note: On the PCB there is a shorting trace between pin 1-2. This trace has to be cut first, before using PowerScale. Pin 3 is GND.</i>

2.2 Reset

A reset signal connected to the low-active PORST# pin of the target CPU (U300) can be issued by

- an on-board Reset Button (SW400, RESET)
- an on-board debug device (U500)
- an external debugger connected to either Cortex Debug connector X400 or X401

The RESET signal is routed to all satellite connectors. The reset circuit includes a red LED (V407) to indicate the reset status: The Reset LED (V407) will be "ON" during active reset state and will be "OFF" if reset is not active.

Be aware that PORST# is a bidirectional reset pin of the XMC4000 family which can also be pulled low by the XMC4000 device itself.




Figure 5 Reset Circuit



Figure 6 Reset LED and Reset Button

2.3 Clock Generation

An external 12 MHz crystal provides the clock signal to the XMC4500 microcontroller. The drive strength of the oscillator is set to maximum by software, in order to ensure a safe start-up of the oscillator even under worst case conditions. A serial 510 Ohm resistor will attenuate the oscillations during operations.

For the RTC clock a separate external 32.768 kHz crystal is used on board.




Figure 7 Clock Generation Circuit

2.4 Boot Option

During power-on-reset the XMC4500 latches the dip switch SW300 settings via the TCK and the TMS pin. Based on the values latched different boot options are possible.

Table 3 Boot Options Settings

BSL (TMS)	CAN/UART (TCK)	Boot Option
OFF (1)	UART (0)	Normal Mode (Boot from flash)
ON (0)	UART (0)	ASC BSL Enabled (Boot from UART)
OFF (1)	CAN (1)	BMI Customized Boot Enabled
ON (0)	CAN (1)	CAN BSL Enabled (Boot from CAN)




Figure 8 Boot Options Switch

2.5 Debug Interface

The CPU_45B-V1 board supports debugging via 3 different channels:

- On-board Debugger
- Cortex Debug Connector (10-pin)
- Cortex Debug+ETM Connector (20-pin)

The Hexagon Application Boards are designed to use “Serial Wire Debug” as debug interface. JTAG debug is not supported by default because the GPIO P0.7, where the required TDI function is mapped to also, is used by the on-board SDRAM device and various Actuator boards connected to the ACT satellite connector.

Attention: It is strongly recommended not to use JTAG debug mode, especially if satellites boards are connected, which uses the GPIO 0.7. For the same reason also do not use the on-board debugger in JTAG mode.

If you want to use the JTAG debug mode through the cortex debug connectors (X400, X401) anyway, enable the JTAG interface of the XMC device by assembling the pull-up resistor R427 (4k7 Ohm) and the resistor R410 (0 - 33 Ohm).

2.5.1 On-board USB Debugger

The on-board debugger [1] supports

- Serial Wire Debug
- Serial Wire Viewer [2]
- Full Duplex UART communication via a USB Virtual COM

[1] Newer firmware versions of the on-board debugger require the latest J-Link driver (V4.62 or higher) and a Serial Port Driver (CDC driver) installed on your computer. Please check “Install J-Link Serial Port Driver” when installing the latest J-Link driver (see Figure 9)

[2] Serial Wire Viewer operation does not work during use of the on-board SDRAM.




Figure 9 Installation of Serial Port Driver

The on-board debugger can be accessed through the Debug USB connector shown in Figure 10. The Debug LED V502 shows the status during debugging.




Figure 10 On-Board USB Debugger

When using an external debugger connected to the 10pin/20pin Cortex Debug Connector, the on-board debugger is switched off.

When using the USB virtual COM port function of the on-board debugger (connected to P1.4 and P1.5 of the XMC4500) the UART interface to the COM satellite is disabled through the switches U301 and U306.

2.5.2 Cortex Debug Connector (10-pin)

The CPU_45B-V1 board supports Serial Wire Debug operation through the 10-pin Cortex Debug Connector.

By default the board does not support Serial Wire Viewer operation through the 10-pin Cortex Debug Connector, because the required SWO pin mapped to P2.1 is used for the connection to the on-board SDRAM. If Serial Wire Viewer operation is required anyway the resistor R404 needs to be assembled.

JTAG operation additionally would require the TDI (P0.7) signal. By default the TDI signal is disconnected from the Cortex Debug Connectors by a not assembled resistor R410, because the pin P0.7 can be used by the on-board SDRAM, by Actuator boards connected to the ACT satellite connector and by boards connected to the COM satellite connector.




Figure 11 Cortex Debug Connector (10-pin)

Table 4 Cortex Debug Connector (10 Pin)

Pin No.	Signal Name	Serial Wire Debug	JTAG Debug
1	VCC	+3.3 V	+3.3 V
2	SWDIO / TMS	Serial Wire Data I/O	Test Mode Select
3	GND	Ground	Ground
4	SWDCLK / TCK	Serial Wire Clock	Test Clock
5	GND	Ground	Ground
6	SWO / TDO	Trace Data OUT	Test Data OUT
7	KEY	KEY	KEY
8	NC / TDI	Not connected	Test Data IN
9	GNDDetect	Ground Detect	Ground Detect
10	nRESET	Reset (Active Low)	Reset (Active Low)



Figure 12 Cortex Debug Connector (10-pin) Layout

2.5.3 Cortex Debug+ETM Connector (20-pin)

The CPU_45B-V1 board supports Serial Wire Debug operation and Instruction Trace operation through the 20-pin Cortex Debug+ETM Connector.

The board does not support Serial Wire Viewer operation through the Cortex Debug Connectors by default, because the required SWO pin mapped to P2.1 is used for the connection to the on-board SDRAM. If Serial Wire Viewer operation is required anyway the resistor R404 needs to be assembled.

JTAG operation additionally would require the TDI (P0.7) signal. By default the TDI signal is disconnected from the Cortex Debug Connectors by a not assembled resistor R410, because the pin P0.7 can be used by the on-board SDRAM, by Actuator boards connected to the ACT satellite connector and by boards connected to the COM satellite connector.

Cortex Debug+ETM Connector (20-pin)				
VCC	1	⊗	⊗	2 SWDIO / TMS
GND	3	⊗	⊗	4 SWDCLK / TCK
GND	5	⊗	⊗	6 SWO / TDO / EXTa / TRACECTL (NC)
KEY	7	□	⊗	8 NC/EXTb/TDI (NC)
GNDDetect	9	⊗	⊗	10 nRESET
GND/TgtPwr+Cap	11	⊗	⊗	12 TRACECLK
GND/TgtPwr+Cap	13	⊗	⊗	14 TRACEDATA[0]
GND	15	⊗	⊗	16 TRACEDATA[1]
GND	17	⊗	⊗	18 TRACEDATA[2]
GND	19	⊗	⊗	20 TRACEDATA[3]

cortex-20pin.emf

Figure 13 Cortex Debug+ETM Connector (20-pin)

Table 5 Cortex Debug+ETM Connector (20 Pin)

Pin No.	Signal Name	Serial Wire Debug	JTAG Debug
1	VCC	+3.3 V	+3.3 V
2	SWDIO / TMS	Serial Wire Data I/O	Test Mode Select
3	GND	Ground	Ground
4	SWDCLK / TCK	Serial Wire Clock	Test Clock
5	GND	Ground	Ground
6	SWO / TDO	Trace Data OUT	Test Data OUT
7	KEY	KEY	KEY
8	NC / TDI	Not connected	Test Data IN
9	GNDDetect	Ground Detect	Ground Detect
10	nRESET	Reset (Active Low)	Reset (Active Low)
11	GND/TgtPwr+Cap	Ground	Ground
12	TRACECLK	Trace Clock	Trace Clock
13	GND/TgtPwr+Cap	Ground	Ground
14	TRACEDATA[0]	Trace Data 0	Trace Data 0
15	GND	Ground	Ground
16	TRACEDATA[1]	Trace Data 1	Trace Data 1
17	GND	Ground	Ground
18	TRACEDATA[2]	Trace Data 2	Trace Data 2
19	GND	Ground	Ground
20	TRACEDATA[3]	Trace Data 3	Trace Data 3




Figure 14 Cortex Debug+ETM Connector (20-pin) Layout

2.6 Serial Flash Memory

The CPU_45B-V1 board has 32Mbit serial flash memory interfaced to XMC4500 through a SPI interface. The SPI interface can be configured as single, dual or quad SPI.

Table 6 Quad SPI Signals

Pin No.	Signal Name	Signal Description
P0.13	CLK	Clock
P3.3	CS#	Active Low Chip Select
P3.15	DI	Data Input of Flash (MTSR)
P3.14	DO	Data Output of Flash (MRST)
P0.14	Data I/O	Data Input/Output
P0.15	Data I/O	Data Input/Output




Figure 15 Quad SPI Flash Interface

2.7 SDRAM

The CPU_45B-V1 board has a 64 Mbit SDRAM interfaced to the XMC4500. The SDRAM interface is shown in Figure 16.




Figure 16 SDRAM Interface

2.8 USB

The XMC4500 supports USB interface in host only mode, device only mode or as an OTG Dual Role Device (DRD). In USB device mode, power is expected through VBUS (pin 1 of X203) from an external host (e.g. PC). When the current consumption of the application running on the Hexagon Application system is higher than 500 mA, power from an external source through satellite cards shall be used.

Note: Some PCs, notebooks or hubs have a weak USB supply which is not sufficient for proper supply. In this case use an external 5 Volt power supply or a powered USB hub.




Figure 17 USB Connector

The USB ID pin of the USB connector is connected to the port pin P15.2 of the XMC4500. This pin must be polled by software, because this pin does not support USB_ID detection.

An OTG device will detect whether a USB 3.0 Micro-A or Micro-B plug is inserted by checking the ID pin. When the ID = FALSE, Micro-A connector is plugged and when ID = TRUE a Micro-B connector is plugged in. When ID is true the XMC4500 acts as USB host else as USB device.

Table 7 USB micro AB connector Pinout

Pin No.	Pin Name	Pin Description
1	VBUS	5 V
2	D-	Data Minus
3	D+	Data Plus
4	ID	Identification
5	GND	Ground




Figure 18 USB power generation - Host/OTG mode

In the host only mode and OTG mode the CPU_45B-V1 board is capable of supplying power to the connected device (e.g. USB mouse). The board has a power-switch which is controlled by the USB.BUSDRIVE signal of XMC4500. USB.BUSDRIVE is mapped to Port P0.1 (active high).

In the Host/OTG mode a low active FAULT signal indicates to XMC4500 via HIB_IO_0 signal, if more than 500 mA current is drawn by the external device. HIB_IO_0 signal is used as general purpose input pin for this implementation.

Diode V200 will allow powering the board through USB in all USB modes via e.g. a PC.

2.9 RTC

The XMC4500 CPU has two power domains, the Core Domain and Hibernate Domain.

The Core Domain (VDDP pins) is connected to the VDD3.3 rail. An on-board LDO voltage regulator generates VDD3.3 (3.3 V) from VDD5 (5 V).

The Hibernate Domain is powered via the auxiliary supply pin VBAT, which is supplied by either a 3 V coin cell (size 1216, 1220, 1225) plugged into the battery holder or 3.3 V (VDD3.3) generated by the on-board voltage regulator.



Figure 19 Battery Holder for Coin Cells

The Real Time Clock (RTC) is located in the hibernate domain. The XMC4500 uses the HIB_IO_1 signal (active low) to shutdown the external LDO voltage regulator which generates VDD3.3 (core domain). Even if the Core Domain is not powered the Hibernate Domain will operate if VBAT is available. The RTC keeps running as long as the Hibernate Domain is powered via the auxiliary supply VBAT. The RTC is capable to wake-up the whole system from Hibernate mode by setting HIB_IO_1 to high.




Figure 20 XMC4500 Power Domains and Real Time Clock

2.10 User LEDs and User Button

The port pins P5.2 and P1.1 of XMC4500 on the CPU_45B-V1 board are connected to the LEDs V300 and V301 respectively. More User LED's are available through the I2C GPIO expander on most of the satellite cards.

Table 8 User LEDs

LED	Connected to Port Pin
LED1 / V300	GPIO P5.2
LED2 / V301	GPIO P1.1

Two User Buttons, SW401 and SW402 are connected to P5.10 and P0.10 of XMC4500

Table 9 User Buttons

Button	Connected to Port Pin
Button1 / SW401	GPIO P5.10
Button2 / SW402	GPIO P0.10




Figure 21 User LEDs and User Buttons

2.11 Potentiometer

The CPU_45B-V1 board provides a potentiometer for ease of use and testing of the on-chip analog to digital converter. The potentiometer is connected to the analog input G0_CH1 (P14.1). The analog output of the potentiometer ranges from 0 V to 3.3 V.

Table 10 Potentiometer

Potentiometer	Connected to Port Pin
R300	P14.1/ G0_CH1 (Group 0, channel 1)

2.12 Satellite Connectors

The CPU_45B-V1 board provides three satellite connectors for application expansion by satellite cards:

- COM satellite connector (Communication)
- HMI satellite connector (Human Machine Interface)
- ACT satellite connector (Actuator)

Note: Satellite cards shall be connected to their matching connectors only. (For e.g. COM satellite cards shall be connected to COM satellite connector only)




Figure 22 Satellite Connectors

2.12.1 COM Connector

The COM satellite connector on the CPU_45B-V1 board allows interface expansion through COM satellite cards (e.g. COM_ETH-V1)

CPU_45B-V1 (SDRAM)		Satellite Connector		CPU_45B-V1 (SDRAM)	
XMC Pin	XMC Function	Function	Pin	Function	XMC Pin
VSS	GND	GND	1	GND	VSS
P0.13	U1C1_SCLKOUT	qSPI_SCLK	2	qSPI_D0	P3.15
P0.12	U1C1_SELO0	qSPI_CS	3	qSPI_D1	P3.14
P3.3 *	U1C1_SELO1	qSPI_CS	4	qSPI_D2	P0.15
nc	nc	RSVD	5	qSPI_D3	P0.14
nc	nc	RSVD	6	RSVD	nc
P5.1	ETH0_RXD1D	ETH_RMII	7	ETH_RMII	P2.13
P5.0	ETH0_RXD0D	ETH_RMII	8	ETH_RMII	P2.12
P1.11	ETH0_MDO	ETH_RMII	9	ETH_RMII	P15.9
P1.10	ETH0_MDC	ETH_RMII	10	ETH_RMII	P0.11
P5.9	ETH0_TX_EN	ETH_RMII	11	ETH_RMII	P15.8
nc	nc	RSVD	12	GND	VSS
nc	nc	ASC_DIR	13	RSVD	nc
P1.4 **	U0C0_DX0B	ASC_RXD	14	CAN_TXD	P2.7
P1.5 **	U0C0_DOUT0	ASC_TXD	15	CAN_RXD	P2.6
nc	nc	nc	16	CAN_RXD	nc
nc	nc	SPI_CSC0	17	SPI_MSTR	nc
nc	nc	SPI_CSC1	18	SPI_MSTR	nc
nc	nc	SPI_CSC2	19	SPI_SCLK	nc
P3.11/P3.12	U2C1_DOUT0/DX0D	I2C_SDA	20	I2C_SCL	P3.13
P14.13	P14.13	COM_GPIO1	21	GPIO	P6.3
P0.0	P0.0	COM_GPIO0	22	RESET	PORST
		VDD5	23	VDD5	
		VDD5	24	VDD5	
P0.6	EBU_ADV	EBU_ADV	45	EBU_AD	P0.2
P3.1	EBU_RD/EBU_nWR	EBU_WR	46	EBU_AD	P0.3
P3.0	EBU_RD	EBU_RD	47	EBU_AD	P0.4
P2.15	EBU_nBC1	EBU_BC	48	EBU_AD	P0.5
P2.14	EBU_nBC0	EBU_BC	49	EBU_AD	P3.5
nc	nc	EBU_CS	50	EBU_AD	P3.6
P0.9	EBU_nCS1	EBU_CS	51	EBU_AD	P0.7
VSS	GND	GND	52	EBU_AD	P0.8
nc	nc	EBU_A	53	EBU_AD	P4.0
nc	nc	EBU_A	54	EBU_AD	P4.1
nc	nc	EBU_A	55	EBU_AD	P1.6
nc	nc	EBU_A	56	EBU_AD	P1.7
nc	nc	EBU_A	57	EBU_AD	P1.8
P6.4	EBU_A19	EBU_A	58	EBU_AD	P1.9
P6.2	EBU_A18	EBU_A	59	EBU_AD	P1.2
P6.1	EBU_A17	EBU_A	60	EBU_AD	P1.3
P6.0	EBU_A16	EBU_A	61	EBU_AD	VSS
VSS	GND	GND	62	GND	
		GND	63	GND	
		GND	64	GND	
		GND	65	GND	
		GND	66	GND	
		GND	67	GND	
		GND	68	GND	
		GND	69	GND	
		GND	70	GND	
		GND	71	GND	
		GND	72	GND	
		GND	73	GND	
		GND	74	GND	
		GND	75	GND	
		GND	76	GND	
		GND	77	GND	
		GND	78	GND	
		GND	79	GND	
		GND	80	GND	

Figure 23 Satellite Connector Type COM

Attention: * This pin is used as chip select signal for the on-board EEPROM and therefore disconnected by solder jumper SJ1

Attention: ** This pin is connected with the satellite connector via an analog switch

2.12.2 HMI Connector

The HMI satellite connector on the CPU_45B-V1 board allows interface expansion through HMI satellite cards.

CPU_45B-V1 (SDRAM)		Satellite Connector		CPU_45B-V1 (SDRAM)	
XMC Pin	XMC Function	Function	Pin	Function	XMC Function
VSS	GND	GND	1	GND	VSS
nc	nc	MMC_CLK	2	MMC_nRST	nc
nc	nc	MMC_DATA1	3	MMC_DATA0	nc
nc	nc	MMC_DATA3	5	MMC_DATA2	nc
nc	nc	MMC_DATA5	7	MMC_DATA4	nc
nc	nc	MMC_DATA7	9	MMC_DATA6	nc
nc	nc	MMC_BUSPOW	11	MMC_CMD	nc
nc	nc	MMC_nSDCD	13	MMC_LED	nc
nc	nc	RSVD	15	MMC_SDWC	nc
nc	nc	RSVD	17	RSVD	nc
nc	nc	RSVD	19	RSVD	nc
nc	nc	RSVD	21	RSVD	nc
P4.2	P4.2	AudiorST	22	OLED_CMD	P5.11
P3.4	U1C1_SELO2	I2S_WA	23	I2S_MTSR	U1C1_DOUT0 P3.15
nc	nc	I2S_WCLK	25	I2S_MRST	U1C1_DX0B P3.14
nc	nc	I2S_SYNCCLK	27	I2S_SCLK	U1C1_SCLKOUT P0.13
P3.10	U2C0_SELO0	SPI_CSH0	30	SPI_MTSR	U2C0_DOUT0 P3.8
P5.6	U2C0_SELO3	SPI_CSH1	31	SPI_MRST	U2C0_DX0C P3.7
nc	nc	SPI_CSH2	33	SPI_SCLK	U2C0_SCLKOUT P3.9
P3.11/P3.12	U2C1_DOUT0/DX0D	I2C_SDA	34	I2C_SCL	U2C1_SCLKOUT P3.13
P15.5	P15.5 Input	HMI_GPIO1	35	HMI_GPIO1	P6.3
P5.7	P5.7	HMI_GPIO0	39	HMI_GPIO0	RESET# P6.3
		VDD5	41	VDD5	POSRT
		VDD5	42	VDD5	VDD5
		VDD5	43	VDD5	VDD5
		VDD5	44	VDD5	VDD5
VAGND	AGND	VDD5	45	VDD5	VAREF
P14.9	DAC_OUT1	AGND	46	AREF	VAREF
nc	nc	DAC0/ADC1	47	DAC1/ADCO	VADC_G1CHO P14.8
P14.12	VADC_G1CH4	ADC3/ORCO	49	ADC2/DACREF	VADC_G0CH4 P14.4
P15.13	VADC_G3CH5	ADC15	51	ADC14	VADC_G0CH3 P14.3
P15.12	VADC_G3CH4	ADC17	53	ADC16	VADC_G2CH3 P15.3
nc	nc	ADC19	55	ADC18	nc
nc	nc	RSVD	56	RSVD	nc
nc	nc	RSVD	57	RSVD	nc
nc	nc	RSVD	59	RSVD	nc
nc	nc	RSVD	60	RSVD	nc
nc	nc	RSVD	61	RSVD	nc
nc	nc	TPA1	62	TP7	nc
nc	nc	TPX0	63	TP6	nc
nc	nc	COL3	65	TP5	nc
nc	nc	COL1	66	TP4	nc
nc	nc	COL2	67	TP3	nc
nc	nc	COL1	68	TP2	nc
nc	nc	COL0	69	TP1	nc
nc	nc	COLA	70	TP0	nc
VSS	GND	GND	71	GND	VSS
		GND	72	GND	GND
		GND	73	GND	GND
		GND	74	GND	GND
		GND	75	GND	GND
		GND	76	GND	GND
		GND	77	GND	GND
		GND	78	GND	GND
		GND	79	GND	GND
		GND	80	GND	GND

Figure 24 Satellite Connector Type HMI

2.12.3 ACT Satellite Connector

The ACT satellite connector on the CPU_45B-V1 board allows interface expansion through ACT satellite cards.

CPU_45B-V1 (SDRAM)		Satellite Connector		CPU_45B-V1 (SDRAM)	
XMC Pin	XMC Function	Pin	Function	XMC Pin	XMC Function
VSS	GND	1	GND	VAGND	AGND
P14.7	PIFO_IN0B	2	PIFOIN1	P14.9	VADC_G1CH1
P4.16	PIFO_IN1B	3	PIFOIN2	nc	nc
P14.5	PIFO_IN2B	4	PIFOIN3	nc	nc
nc	nc	5	DSDIN0	P14.0	VADC_G0CH0
nc	nc	6	DSDIN1	nc	nc
nc	nc	7	DSDIN2	nc	nc
nc	nc	8	DSDIN3	P15.4	P15.4 Input
nc	nc	9	RSVD	P4.7	P4.7
nc	nc	10	CC_IN0	VSS	GND
nc	nc	11	CC_IN1	VAGND	AGND
nc	nc	12	CC_IN2	P14.9	VADC_G1CH1
nc	nc	13	ENA_A	nc	nc
P6.5 (3)	DSD_DIN3A	14	ENA_B	nc	nc
nc	nc	15	ENA_X	nc	nc
nc	nc	16	SPI_MTSR	P14.0	VADC_G0CH0
nc	nc	17	SPI_MRST	nc	nc
nc	nc	18	SPI_SCLK	P15.14	VADC_G3CH6
nc	nc	19	I2C_SCL	P15.15	VADC_G3CH7
nc	nc	20	GPIO	nc	nc
nc	nc	21	RESET	nc	nc
nc	nc	22	VDD5	nc	nc
nc	nc	23	VDD5	nc	nc
nc	nc	24	VDD5	nc	nc
nc	nc	25	VDD5	nc	nc
nc	nc	26	VDD5	nc	nc
nc	nc	27	VDD5	nc	nc
nc	nc	28	VDD5	nc	nc
nc	nc	29	VDD5	nc	nc
nc	nc	30	VDD5	nc	nc
P5.6 (5)	U2C0_DOUT0	31	SPI_CSA0	nc	nc
P3.7	U2C0_DX0C	32	SPI_CSA1	nc	nc
P3.9	U2C0_SCLKOUT	33	SPI_CSA2	nc	nc
P3.13	U2C1_SCLKOUT	34	I2C_SDA	nc	nc
P6.3	P6.3	35	ACT_GPIO1	nc	nc
PORTS	RESET#	36	ACT_GPIO0	nc	nc
		37	VDD5	nc	nc
		38	VDD5	nc	nc
		39	VDD5	nc	nc
		40	VDD5	nc	nc
		41	VDD5	nc	nc
		42	VDD5	nc	nc
		43	VDD5	nc	nc
		44	VDD5	nc	nc
		45	VDD5	nc	nc
		46	VDD5	nc	nc
		47	AREF	nc	nc
		48	DAC1/ADC0	nc	nc
		49	DAC2/DACREF	nc	nc
		50	ADC3/ORC0	nc	nc
		51	ADC4/ORC1	nc	nc
		52	ADC5/ORC2	nc	nc
		53	ADC6/ORC3	nc	nc
		54	ADC8	nc	nc
		55	ADCL0	nc	nc
		56	ADCL1	nc	nc
		57	ADCL2	nc	nc
		58	ADCL3	nc	nc
		59	PWMBO_H	nc	nc
		60	PWMBO_L	nc	nc
		61	PWMA0_H	nc	nc
		62	PWMA0_L	nc	nc
		63	PWMA1_H	nc	nc
		64	PWMA1_L	nc	nc
		65	PWMA2_H	nc	nc
		66	PWMA2_L	nc	nc
		67	PWMX2	nc	nc
		68	PWMX3	nc	nc
		69	PWMX1	nc	nc
		70	GND	nc	nc
		71	GND	nc	nc
		72	GND	nc	nc
		73	GND	nc	nc
		74	GND	nc	nc
		75	GND	nc	nc
		76	GND	nc	nc
		77	GND	nc	nc
		78	GND	nc	nc
		79	GND	nc	nc
		80	GND	nc	nc

Figure 25 Satellite Connector Type ACT

- (1) P0.7 can also be used for JTAG Debugging (TDI)
- (2) P0.8 is used as TRST in order to enable JTAG Debug
- (3) This pin is connected with the satellite connector via an analog switch
- (4) This ADC input does not support "Out of Range Detection"
- (5) This pin is disconnected by a solder jumper
- (6) Support High Resolution PWM

3 Production Data

3.1 Schematics

This chapter contains the schematics for the CPU board:

- Satellite Connectors, USB-OTG
- XMC4500
- Power, Debug Connector, Reset
- On-board Debugger

The board has been designed with Eagle. The full PCB design data of this board can also be downloaded from www.infineon.com/xmc-dev.




Figure 26 Satellite Connectors, USB-OTG




Figure 27 XMC4500




Figure 28 Power, Debug Connector, Reset, SDRAM




Figure 29 On-board Debugger

3.2 Component Placement and Geometry




Figure 30 Component Placement and Geometry

3.3 Bill of Material (BOM)

Table 11 BOM of CPU_45B-V1 Board

Pos No.	Qty	Value	Device	Reference Des.
1	1	0R/0603	Resistor	R416
2	2	1M/0402	Resistor	R200, R505
3	2	1k5/0603	Resistor	R405, R406
4	3	2k2/0603	Resistor	R306, R307, R420
5	3	4k7/0402	Resistor	R302, R304, R506
6	1	4u7F/0805	Capacitor, ceramic	C212
7	17	10k/0402	Resistor	R204, R206, R207, R303, R309, R310, R400, R401, R408, R414, R419, R422, R429, R430, R431, R503, R507
8	2	10nF/0402	Capacitor	C406, C415
9	8	10uF/10V/0805	Capacitor, ceramic	C308, C323, C324, C325, C405, C407, C506, C510
10	2	12MHZ/S/3.2X2.5	Crystal, NX3225GD, NDK	Q302, Q500
11	6	15pF/0402	Capacitor	C312, C315, C316, C317, C500, C501
12	1	22R/0402	Resistor	R432
13	1	32.768KHZ	Crystal, NX3215SA, NDK	Q301
14	11	33R/0402	Resistor	R202, R203, R402, R403, R421, R423, R424, R425, R426, R501, R502
15	4	74LVC1G66DCK	IC, Single Analog Switch	U301, U303, U304, U306
16	40	100nF/0402	Capacitor	C200, C202, C204, C205, C208, C210, C211, C300, C301, C302, C305, C306, C307, C309, C310, C311, C318, C319, C321, C322, C413, C416, C417, C430, C431, C432, C433, C434, C435, C436, C400, C401, C502, C504, C505, C507, C508, C509, C511, C512
17	2	100uF/T/10V/C	Capacitor, bipolar	C213, C414
18	1	219-02	Dual DIP-Switch, 0.1" SMD	SW300
19	1	270k/0402	Resistor	R415
20	2	510R/0603	Resistor	R313, R500
21	4	680R/0603	Resistor	R301, R305, R407, R504
22	3	BAS3010A-03W	Diode, SOD323, Infineon	V200, V408, V501
23	2	BAT54-02V	Diode, SC79, Infineon	V404, V405
24	1	BAV70	Diode, SOT23-3, Infineon	V406
25	1	BC858C	Transistor, SOT23-3, Infineon	Q404

Production Data

26	1	BK-885	Battery Holder, 12mm Coin Cell	X402
27	4	BLM18PG600	Ferrite Bead, 0603, Murata	L201, L300, L301, L500
28	2	ESD8V0L2B-03L	Diode, TSLP-3-1, Infineon	V201, V500
29	3	HSEC8_MATING-CARD	Connector, Edgecard, Samtec	X200, X201, X202
30	1	IFX1763_PADNOP	Voltage Regulator, 3.3V LDO, Infineon	U401
31	2	LED-GE/D/0603	LED, yellow	V300, V301
32	4	LED-GN/D/0603	LED, green	V401, V402, V403, V502
33	1	LED-RT/D/0603	LED, red	V407
34	1	IS42S16400F-7BL	Synchronous Dynamic RAM, ISSI	U430
35	1	NC7WZ07P6X	IC, Dual Buffer OD, SC70-6	U501
36	1	POTI/10K/VERT	Potentiometer, K09K1130A8G, ALPS	R300
37	1	S2*10/1.27SO	Connector, FTSH-110-01-L-DV-K-P, Samtec	X400
38	1	S25FL032P0XMF101	IC, qSPI Flash Memory, SPANSION	U302
39	3	TMPS2-SMD	Switch, tactile	SW400, SW401, SW402
40	1	TPS2051BDBV	IC, Power Switch, SOT23-5	U200
41	1	XE3K_DM2+CTX	Connector, FTSH-105-01-LM-DV-K, w/o pin 7, Samtec Connector, FLE-103-01-G-DV, Samtec	X401
42	1	XMC4200_QFN48	IC, XMC4200, QFN48, Infineon	U500
43	1	XMC4500_LFBGA144	IC, XMC4500, LFBGA144, Infineon	U300
44	2	ZX62-AB-5PA	Connector, Micro-USB, Hirose	X203, X500
45	1	no ass.	Pinheader, 4-pin, 0.1" TH	X501
46	4	no ass.	Pinheader, 1-pin, 0.1" TH	TP404, TP405, TP406, TP407
47	1	no ass./0R/0603	Resistor	R417
48	1	no ass./4k7/0402	Resistor	R427
49	2	no ass./10k/0402	Resistor	R205, R413
50	1	no ass./10nF/0402	Capacitor	C503
51	2	no ass./33R/0402	Resistor	R404, R410
52	1	no ass.	Pinheader, 3-pin, 0.1" TH, Hitex PowerScale	JP300
53	3	no ass.	Solder Bridge (open)	SJ1, SJ2, SJ3
54	2	0R/0402	Solder Bridge (closed by resistor)	SJ4, SJ5

www.infineon.com

Published by Infineon Technologies AG