



MODEL 9830-PCD PLUG CHUTE DETECTOR

User Manual

Arjay Engineering Ltd.
Oakville (Toronto), Canada, L6H 6C9

Tel . ++1 (905) 829-2418
Fax. ++1 (905) 829-4701

North America 1-800-387-9487



www.arjayeng.com
arjay@arjayeng.com

Plugged Chute Detector

Non-intrusive monitoring of chutes and hoppers for bulk material detection

Over 30 years of Arjay's field proven HF capacitance technology has been applied to the 9830-PCD plugged chute detectors. The flush mount sensor continuously monitors the change from a normal material chute condition to a plugged condition.

- capacitance technology responds to any material type
- no moving parts
- remote alarm unit mounts safely away from pipe
- no intrusion into chute or hopper



9830-PCD

The 9830-PCD sensor monitors the capacitance field in front of the sensor plate. The sensing plate forms part of the chute or hopper wall to sense the product within. The increased presence of product in front of the sensor due to a plugging condition increases the capacitance field and initiates an alarm.

The sensing plates are embedded into a polyethylene plate which provides monitoring without any intrusion into the product flow

■ Features and Benefits

- flush mount sensor forms part of the chute wall
- adjustable time delay and sensitivity to eliminate nuisance alarms
- remote electronics via standard twisted pair
- available with Intrinsic Safety Barrier for Hazardous Locations
- high erosion resistant polyethylene resists wear
- capacitance technology responds to all types of bulk materials
- non-intrusive sensor design does not restrict product movement

■ Technical Specifications - Control Unit

Operating Temperature	-20°C to 60°C
Power Input	24 vdc or 110 vac or 220 vac
Alarm Relay	5 amp, DPDT, dry
Standards	UL, CSA
Enclosure	Type 4X, IP65
Optional	Lights and Buzzer

■ Technical Specifications - Sensor

Operating Temperature	0°C to 50°C
Approval	CSA Class 1, Zone 2, Div 2, Groups A,B,C,D (also available with an Intrinsic Barrier Option)



All calibration, control relays and power wiring is available at the main control unit. This can be safely mounted up to 1 km away from the chute.



The unique PMC circuit design, exclusive to Arjay, immediately converts the sensor signal to a frequency pulse for furtherance to the controller.



Alternate probe designs are available for specialty applications

Arjay SS-06



Arjay Engineering Ltd.
2851 Brighton Road
Oakville, Ontario
Canada L6H 6C9

tel
fax
N. America
email
web

++1 905-829-2418
++1 905-829-4701
1-800-387-9487
arjay@arjayeng.com
www.arjayeng.com



TABLE OF CONTENTS

- 1.0 INSTRUMENT OVERVIEW..... 3
 - 1.1 FEATURES 3
 - 1.2 DESCRIPTION 3
- 2.0 INSTALLATION 5
 - 2.1 FLUSH MOUNT SENSOR 5
 - 2.2 ELECTRICAL INSTALLATION..... 6
- 3.0 STARTUP AND CALIBRATION 7
 - 3.1 POWERUP 7
 - 3.2 CONTROL AND FUNCTION SWITCHES 7
 - 3.2.1 Failsafe 7
 - 3.2.2 Alarm Time Delay 7
 - 3.2.3 Sensitivity 8
 - 3.2.4 Dielectric 8
 - 3.3 CALIBRATION..... 8
- 4.0 TROUBLESHOOTING 9

1.0 INSTRUMENT OVERVIEW

1.1 FEATURES

- Push-button calibration
- RF Technology
- Double pole Double Throw (DPDT) 5A relay contacts
- 0 – 20 second time delay
- Adjustable sensitivity
- High or Low relay action
- No moving parts
- For use with any Arjay Flush mount sensor

1.2 DESCRIPTION

The **ARJAY** 9830-PCD Level Alarm is specifically designed as a means to monitor the product within a chute for a plugged condition. A sensor is mounted flush with the wall to eliminate intrusion into the chute. The sensor does not use moving components that can cause mechanical maintenance concerns. When a plugged condition occurs in front of the sensing plate, the remote 9830 initiates a relay alarm to interface with motor controls, alarms, etc. The 9830 can be mounted up to 1 km away from the chute using inexpensive 2-conductor shielded wire.

Chute sensor locations can often be awkward and are usually accompanied by high vibration equipment. The remote control unit means no calibration or high voltage control wiring is required at the sensor, making the unit safe and easy to maintain.

The unit senses presence of liquid using a RF capacitance measurement technique together with microcontroller technology for high resolution measurements.

The control relay is always in failsafe mode. The relay action may be set for high or low acting.

OPERATION

The unit uses an RF Capacitance measurement technique for high resolution measurements. When the presence of material builds up, the plug chute detector senses the change in capacitance and the control unit will indicate an alarm condition and change the state of it's dry relay contacts.

USER INTERFACE

Instrument status	2 color indicator: Green for normal operation, Red = instrument error, Red/Green (orange) for calibration confirmation.
Alarm Status	Red indicator: On when not in alarm, Off when in alarm.
Time delay	0 – 20 seconds.
Relay action	High or Low relay action. For high action, the relay is energized under normal conditions and de-energizes there is a presence of product buildup. For low action, the relay is de-energized under normal conditions and energizes when there is a presence of product buildup.
Dielectric switch	Primarily used in low dielectric where there is no product buildup at time of calibration.

PERFORMANCE

The unit measures capacitance in pF. Capacitance to Level translation depends on the surroundings and the type of material being measured.

RESOLUTION

Capacitance: 0.4% of measured capacitance. Example: at 50pF, the resolution is 0.2pF and at 100pF, the resolution is 0.4pF.

SENSOR CONNECTION

2 wire + shielded cable from PMC 2000 to controller.

RELAY CONTACTS

Failsafe. DPDT 5A (resistive load) /250VAC/30VDC dry contacts. Selectable high or low acting alarm.

POWER

115VAC or 220VAC @ 25mA max.
24VDC @ 60mA max.

MECHANICAL SPECIFICATIONS

Enclosure	Standard: Nema 4x
Dimensions /Weight	10" (254mm) x 8" (203.2mm) x 4" (101.6mm)depth / 4lbs. (1.81kg)

ENVIRONMENTAL SPECIFICATIONS

Operating Temp.	-20 to 60°C for Controller only. For remote sensor:-40 to 80°C
Relative Humidity	90% max. with no condensation.

2.0 INSTALLATION

NOTE: If any damage to the instrument is found, please notify an Arjay Engineering representative as soon as possible prior to installation.

Choose the mounting location in accordance with good instrument practice.

1. The sensing plate is mounted to the chute using ¼-20 bolts and is typically ordered for the thickness of the chute.
2. Check that the circuit card (PMC-2000) is installed into the probe head according to the installation drawing. Both circuit mounting screws are required to insure a good electrical ground. Check that the sensor lead is secured to the PMC circuit terminal marked "P".
3. Wire the circuit card to the main control unit using two-wire shielded instrument cable 16-18awg (EG.BELDON 8760). DO NOT run these wires along side of high voltage wires. Connect the + & - terminals on the pulse card to the probe terminals marked + & - at the controller. Connect the shield of the cable to the 'S' terminal at the controller side only. Make sure that the PMC junction box is electrically grounded.
4. Connect 115 VAC power to the main control unit. The STATUS LED should be green indicating that power is on and unit is getting no fault conditions. If the status led is red then unit is showing fault. Check to make sure unit is properly wired to the pulse card. A wiring fault or pulse card failure will cause the status LED to be red. Check the wiring for continuity and proper polarity.

2.1 FLUSH MOUNT SENSOR

The flush mount sensor consists of a sensor potted in a square plastic plate. The material of this plate is normally ultra high molecular polyethenlye(UHPHE) so that it can withstand high abrasion and resist material build up on the plate. Enclosed in a junction box is a pulse module circuit (PMC 2000) which changes the capacitance signal to a pulse signal, thus allowing the control electronics to be mounted up to one kilometre away.

2.2 ELECTRICAL INSTALLATION




Figure 2.2

NOTE:

115VAC power is standard. Other power supply voltages are supported (220VAC, 24VDC) and must be specified at time of order.

APPLYING POWER THAN THAT MEANT FOR THE UNIT MAY CAUSE DAMAGE AND OR INJURY.

3.0 STARTUP AND CALIBRATION




Figure 3.0

3.1 POWERUP

After the unit has been installed as per the installation procedure in section 2, power up the unit. The Status indicator should be Green. The red Alarm indicator may be on or off and is not valid until a successful calibration has been done.

If the Status indicator is red refer to the troubleshooting procedure in section 4.0 for details.

3.2 CONTROL AND FUNCTION SWITCHES

Set up the control and function switches as follows:

3.2.1 Failsafe

Put the selector in the "HI FAILSAFE" position. This will keep the relay energized during a normal dry condition. On alarm; the relay will de-energize. A power failure will also cause the relay to de-energize, signalling an alarm condition.

3.2.2 Alarm Time Delay

This is set via the Alarm Delay switch. An alarm based on the Relay Action switch must be present for at least the time delay value for the relay to switch to the alarm state. There is no delay when switching off the alarm. The delay range is 0 – 20 seconds.

DELAY SWITCH SETTING	TIME DELAY
0	0 seconds
1	2 seconds
2	4 seconds
3	6 seconds
4	8 seconds
5	10 seconds
6	15 seconds
7	20 seconds
8 & 9	Not used and act as 0 seconds.

False alarms from disturbances can therefore be ignored. Position 8 & 9 are not used and are the equivalent to 0 seconds.

3.2.3 Sensitivity

This selector switch determines the amount of material buildup necessary to cause an alarm. The switch has a "0" to "9" range with "0" being most sensitive. "1" is used for most applications. If false alarms are occurring, make sure there is time delay on . If unit still has false alarms adjust the sensitivity to the next number up. Position 8 & 9 are not used and are the equivalent to 0 sensitivity. ****INCREASING THE NUMBER WILL DECREASE SENSITIVITY****

3.2.4 Dielectric

The plug chute detector should be calibrated with the process operating(product moving thru the chute). The switch should be set to "LO" for this calibration.

3.3 CALIBRATION

With the unit wired as per the drawing #990190, power on the unit. The status LED should be green indicating that power is on and unit is getting no fault conditions. If the status led is red then unit is showing a fault. Check to make sure unit is properly wired to the pulse card. A wiring fault or pulse card failure will cause the status LED to be red. Check the wiring for continuity and proper polarity. To calibrate, verify the following function switch positions:

"TIME DELAY	Position "6" (15 seconds)
"SENS"	Position "1"
"FAILSAFE"	Hi failsafe
"DIELECTRIC"	low dielectric

With the product moving through the chute(normal condition), push the CALIBRATE BUTTON. The status LED will turn red momentarily. Release the button. The status led should be green and flashing on and off showing that it is in calibration mode. Push the calibration button one more time until it goes red. Release the button. Calibration is complete and status LED should be green and alarm status LED red showing that the relay is energized under normal conditions. The unit will alarm when material builds up on the sensing plate. Verify the operation by causing a plugged chute condition.





THIS COMPLETES THE SETUP AND CALIBRATION PROCEDURE FOR THE 9830 PCD

4.0 TROUBLESHOOTING

**Under normal conditions the status light on 9830 electronics (inside enclosure) should be Green and relay light should be Red. **

CONDITION	DO THIS
1. No indicators on at powerup	<ul style="list-style-type: none"> • Check power to unit • Make sure power applied is as specified for the unit. (e.g. 120VAC) • If power is ok, check the fuse. If the fuse is blown, call an Arjay representative to analyze why the fuse has blown.
2. Status indicator is RED (Fault Condition)	<ul style="list-style-type: none"> • Make sure there is a PMC 2000 card mounted in the remote junction box. • This indicates that the controller is not receiving a signal from pulse card (PMC 2000) and is weak, unstable, out of legal range, or is not present. • Verify that the polarity of the two wire shielded connection is correct such that "+" at controller to "+" at pulse card (PMC 2000) and "-" at controller to "-" at pulse card (PMC 2000). Measure with DC volt meter across "+" and "-" at pulse card (PMC 2000), it should read positive 9-10 Volts when plugged in. • Make sure there is no break in the wiring between controller and PMC 2000 card. • Disconnect probe (sensor) from "p" terminal of pulse card (PMC 2000). Verify if status LED goes to Green. • Replace the PMC 2000 card with a spare if available.
3. False alarms	<ul style="list-style-type: none"> • Add some time delay to unit. • If coax cable is used from sensors to pulse card (PMC 2000), make sure it is not coiled (may cause an increase in inductance). • Make sure there is no outside interference that may be causing false alarms such as an agitator, high voltage interference, or input flow to the tank affecting the probe. • Adjust the sensitivity switch to next setting to decrease the 9830's sensitivity. Test sensor after the setting has been increased to make sure the sensor can still reliably sense the presence of liquid. • Make sure separator or grease trap is filled up with water above the white Teflon (sensing area) of probe.

SELECTION GUIDE				
DIMENSION	STANDARD MODELS			CUSTOM
ALL DIMENSIONS ARE IN INCHES	Dimensions A,B,C are fixed Customer selects Chute Thickness (D)			Customer selects ALL dimensions (A,B,C,D)
	F-4	F-6	F-8	
CHUTE CUTOUT (A)	4	6	8	
OVERALL SIZE (B)	5	7	9	
MOUNTING HOLES (C)	2.25	3.25	4.25	
CHUTE THICKNESS (D)	MUST BE SPECIFIED AT ORDER			



NOTE:
INPUT VOLTAGE PER ORDER
24VDC, 115VAC, 220VAC

TYPE 4X POLYCARBONATE
DIMENSIONS ARE IN INCHES (mm)
ENCLOSURE IS A INTEGRA H8064HLL
ENCLOSURE DIMENSIONS ARE 8 X 6 X 4D (203.2 X 152.4 X 101.6D)
ENCLOSURE MOUNTING DIMENSIONS ARE 8.5 x 4 (215.9 X 101.6)

REV	DATE	DESCRIPTION	CHK'D	APP'D
4	1/28/10	CHANGED ENCLOSURE MANUFACTURE		
3	1/17/05	CHANGED CABLE SIZE, CHANGED PMC-9050 TO PMC-2000		
2	1/20/03	ENCLOSURE CHANGED FROM A FIBOX TO A HOFFMAN		
1	7/27/00	ENCLOSURE CHANGED FROM A VYNCKIER TO A FIBOX		

REVISIONS				PROJECT:	
				PLUGGED CHUTE DETECTOR	
			ARJAY ENGINEERING LIMITED		
DWG. STATUS: C.M.P. 3 11 99			TITLE: 9830-PCD DIMENSIONAL & ELECTRICAL		
SCALE: N.T.S.			REF. DWGS.		DWG. NO. 990190
			SHIT. 1		REV. 4