



**Thunder K8WE**



**S2895**

**Version 1.01**

### **Copyright**

Copyright © TYAN Computer Corporation, 2004-2005. All rights reserved. No part of this manual may be reproduced or translated without prior written consent from TYAN Computer Corp.

### **Trademark**

All registered and unregistered trademarks and company names contained in this manual are property of their respective owners including, but not limited to the following.

TYAN, Taro and Thunder K8WE are trademarks of TYAN Computer Corporation.

AMD, Opteron, and combinations thereof are trademarks of AMD Corporation.

Microsoft, Windows are trademarks of Microsoft Corporation.

SuSE, is a trademark of SuSE AG.

Linux is a trademark of Linus Torvalds

IBM, PC, AT, and PS/2 are trademarks of IBM Corporation.

Winbond is a trademark of Winbond Electronics Corporation.

### **Notice**

Information contained in this document is furnished by TYAN Computer Corporation and has been reviewed for accuracy and reliability prior to printing. TYAN assumes no liability whatsoever, and disclaims any express or implied warranty, relating to sale and/or use of TYAN products including liability or warranties relating to fitness for a particular purpose or merchantability. TYAN retains the right to make changes to product descriptions and/or specifications at any time, without notice. In no event will TYAN be held liable for any direct or indirect, incidental or consequential damage, loss of use, loss of data or other malady resulting from errors or inaccuracies of information contained in this document.

---

## Table of Contents

### Chapter 1: Introduction

1.1	Congratulations	Page 3
1.2	Hardware Specifications	Page 3
1.3	Software Specifications	Page 5

### Chapter 2: Board Installation

2.1	Board Image	Page 8
2.2	Block Diagram	Page 9
2.3	Board Parts, Jumpers and Connectors	Page 10
2.4	Installing the Processor(s)	Page 18
2.5	Heatsink Retention Frame Installation	Page 19
2.6	Thermal Interface Material	Page 20
2.7	Heatsink Installation Procedures	Page 21
2.8	Finishing Installing the Heatsink	Page 23
2.9	Tips on Installing Motherboard in Chassis	Page 24
2.10	Installing the Memory	Page 25
2.11	Attaching Drive Cables	Page 28
2.12	Installing Add-In Cards	Page 30
2.13	Connecting External Devices	Page 31
2.14	Installing the Power Supply	Page 32
2.15	Finishing Up	Page 33

### Chapter 3: BIOS

3.1	BIOS Setup Utility	Page 35
3.2	BIOS Menu Bar	Page 36
3.3	BIOS Legend Bar	Page 36
3.4	Getting Help	Page 36
3.5	BIOS Main Menu	Page 37
3.6	BIOS Advanced Menu	Page 38
3.7	BIOS Memory Menu	Page 52
3.8	BIOS Boot Menu	Page 54
3.9	BIOS Exit Menu	Page 56

### Chapter 4: Diagnostics

4.1	Beep Codes	Page 57
4.2	Flash Utility	Page 57
4.3	BIOS Post Code	Page 58

	<b>Glossary</b>	Page 61
--	-----------------	---------

	<b>Technical Support</b>	Page 67
--	--------------------------	---------

---

# Chapter 1: Introduction

---

## 1.1 - Congratulations

You have purchased one of the most powerful workstation mainboard solutions. The Thunder K8WE (S2895) is a high-end workstation mainboard, based on Nvidia nForce Professional 2200 Media and Communications Processor (MCP), Nvidia nForce Professional 2050, and AMD 8131 PCI-X HyperTransport™ Tunnel.

Designed to support up to two AMD Opteron™ (Opteron 2xx) processors and 16GB of DDR333 or DDR400 memory, the S2895 is ideal for CPU, memory, and video intensive applications such as CAD, Graphics Design, High Bandwidth Video Editing, etc.

Remember to visit TYAN's Website at <http://www.TYAN.com>. There you can find information on all of TYAN's products with FAQs, online manuals and BIOS upgrades.

## 1.2 - Hardware Specifications

### Processor

- Supports one or two AMD Opteron™ 2xx processors
- Two onboard 4-phase VRMS
- Three HyperTransport™ links per CPU, support up to 6.4GB/s data transfer rate each link
- 144-bit DDR interface (128-bit data + 16 bit ECC)
- Scalable 32bit and 64bit computing
- Secure computing with Nx register support

### Chipset

- Nvidia nForce Professional 2200 (CK8-04)-connected to CPU1
- Nvidia nForce Professional 2050# (I/O-4)-connected to CPU2
- AMD 8131™ PCI-X Tunnel
- SMsC Super I/O

#Optional

### Integrated ATA-133 (from nForce Professional 2200)

- One ATA-133 IDE Channel for up to two devices

### Integrated SATAII Generation 1 Controllers (from nForce Professional 2200)

- Two integrated dual port SATA II controllers
- Four SATA connectors support up to four drives
- 3 Gb/s per direction per channel
- NvRAID v2.0 support
- Supports RAID 0, 1, 5, 0+1 and JBOD

### Integrated Secure Network Processor

- Two IEEE 802.3 Nvidia MAC 1000/100/10 Ethernet (*First from PRO 2200, Second from PRO 2050*)

---

## Memory

- 128-bit dual channel (interleaved) memory bus
- Total Eight DDR-1 DIMM sockets (Four per CPU)
- Supports up to 16GB Registered DDR
- Supports ECC with CHIPKil technology
- Supports DDR400, DDR333, or DDR266

## Expansion Slots

- Two x16 PCI Express full speed expansion slots
  - Slot 1 PCI-E x16 from nForce PRO 2200
  - Slot 3 PCI-E x16 from nForce PRO 2050
- Two independent 64-bit PCI-X buses
  - Slot 4 and slot 5 support PCI-X 100MHz max
  - Slot 6 supports PCI-X 133MHz max
- One 32-bit 33Mhz PCI v2.3 (Slot 2)
- Total of six usable slots

## Integrated I/O

- One floppy connector
- One serial port connector
- Eight USB 2.0 EHCI ports (four rear connectors & four pin headers)
- PS/2 mouse and keyboard connectors
- Two FireWire (IEEE 1394a) ports (one rear connector and one internal pin header)

## System Management

- Total six 4-pin fan headers with PWM and tachometer monitoring

- Two Marvell Gigabit PHY
- Supports WOL and PXE
- Supports Ethernet Jumbo Frames (9018 Bytes)
- Full Duplex Gigabit Ethernet support
- Nvidia Firewall for secure network communications

## Integrated FireWire (IEEE 1394a) Controller

- TI<sup>®</sup> TSB43AB22A IEEE 1394a PCI controller
- Two FireWire ports (one rear connector and one internal pin header)

## Integrated Audio

- Enhanced AC'97 2.3 compliant audio link
- Analog Devices 1981B codec
- 16 bit Stereo Full Duplex
- CD-in/Aux-in connectors

## Integrated SCSI Controller (Mfg. Option)

- LSI 53C1030 U320 SCSI controller
  - Two U320 68-pin SCSI connectors
  - Connected to PCI-X Bridge B

## Form Factor

- SSI EEB v3.5 Footprint (12" x 13", 304.8x330.2mm)
- EPS 12V/SSI v3.5 Workstation (24 + 8) power connectors (Split Plane design recommended)
- Serial (one)
- Stacked PS/2 keyboard and mouse connectors
- Two dual port USB2.0 connectors (total 4 ports)
- Two RJ-45 LAN connectors with LEDs

- 
- Temperature, voltage and fan monitoring

- Audio Line-in, Line-out, Mic-in jacks
- One IEEE 1394a port

#### **BIOS**

- PhoenixBIOS® on 8Mbit LPC Flash ROM
- ACPI 2.0
- Serial Console Redirect
- USB device boot
- WOL and PXE support
- 48-bit LBA support

## **1.3 - Software Specifications**

### **OS (Operating System) Support**

Microsoft Windows XP (32-bit/64-bit)

Microsoft Windows Server 2003 (32-bit/64-bit)

SUSE Professional 9.x and SLES 9 SP2

RHEL3 Update 4

RHEL4 Update 1

TYAN reserves the right to add support or discontinue support for any OS with or without notice.

---

## NOTES:

---

---

---

## Chapter 2: Board Installation

---

You are now ready to install your motherboard. The mounting hole pattern of the Thunder K8WE matches the SSI EEB 3.51 specification. Before continuing with installation, confirm that your chassis supports an SSI EEB v3.51 motherboard.

### How to install our products right... the first time


The first thing you should do is read this user's manual. It contains important information that will make configuration and setup much easier. Here are some precautions you should take when installing your motherboard:

- (1) Ground yourself properly before removing your motherboard from the antistatic bag. Unplug the power from your computer power supply and then touch a safely grounded object to release static charge (i.e. power supply case). For the safest conditions, TYAN recommends wearing a static safety wrist strap.
- (2) Hold the motherboard by its edges and do not touch the bottom of the board, or flex the board in any way.
- (3) Avoid touching the motherboard components, IC chips, connectors, memory modules, and leads.
- (4) Place the motherboard on a grounded antistatic surface or on the antistatic bag that the board was shipped in.
- (5) Inspect the board for damage.

The following pages include details on how to install your motherboard into your chassis, as well as installing the processor, memory, disk drives and cables.

<b>NOTE</b>	<b>DO NOT APPLY POWER TO THE BOARD IF IT HAS BEEN DAMAGED</b>
-------------	---

## 2.1- Board Image




**This picture is representative of the latest board revision available at the time of publishing. The board you receive may or may not look exactly like the above picture.**


The following page includes details on the vital components of this motherboard.

## 2.2 - Block Diagram

S2895 Thunder K8WE Block Diagram



## 2.3 - Board Parts, Jumpers and Connectors




This diagram is representative of the latest board revision available at the time of publishing. The board you receive may not look exactly like the above diagram.

### Jumper Legend

	<b>OPEN</b> - Jumper OFF, without jumper cover
	<b>CLOSED</b> – Jumper ON, with jumper cover

---

<b>Jumper/Connector</b>	<b>Function</b>
J14	Chassis Speaker Header
J69	FireWire Disable Jumper
J92	PCI-X-Bridge B Bus Speed Override
J93	COM2 Header
J109	FireWire (IEEE 1394A) Pin Header
J139	Front Panel Header
J142	Reset Button
J143	Power Button
P23	Front Audio Header
P24/P25	USB Front Panel Header
P29	External SCSI LED Header
SW50	Reset CMOS Button



**J139: Front Panel Header**

HDDLED+	1	2	PWR LED+
HDDLED-	3	4	PWR LED-
Reset SW	5	6	PWR SW
Reset SW	7	8	PWR SW
+5V	9	10	SLEEP SW
NC	11	12	SLEEP SW
+5V Standby	13	14	NC (KEY)
SMBUS DATA	15	16	GND
SMBUS CLOCK	17	18	Chassis Intr# (Active Low)

**SW50: Reset CMOS Button**

?	<p>In certain cases it may be necessary to reset system CMOS. Follow these steps:</p> <p>1) Power off system</p>
---	--

- 2) Press SW50 for 5 seconds
- 3) Power system and enter BIOS setup

### P24, P25: USB Front Panel Header

	<table border="1"> <thead> <tr> <th>Signal</th> <th>Pin</th> <th>Pin</th> <th>Signal</th> </tr> </thead> <tbody> <tr> <td>VCC</td> <td>1</td> <td>2</td> <td>VCC</td> </tr> <tr> <td>Data -</td> <td>3</td> <td>4</td> <td>Data -</td> </tr> <tr> <td>Data +</td> <td>5</td> <td>6</td> <td>Data +</td> </tr> <tr> <td>GND</td> <td>7</td> <td>8</td> <td>GND</td> </tr> <tr> <td>KEY</td> <td>9</td> <td>10</td> <td>GND</td> </tr> </tbody> </table>	Signal	Pin	Pin	Signal	VCC	1	2	VCC	Data -	3	4	Data -	Data +	5	6	Data +	GND	7	8	GND	KEY	9	10	GND
Signal	Pin	Pin	Signal																						
VCC	1	2	VCC																						
Data -	3	4	Data -																						
Data +	5	6	Data +																						
GND	7	8	GND																						
KEY	9	10	GND																						

### J92: PCI-X Bridge Bus Speed Override


	<p><b>Open</b>-(Default) Allows PCI Bridge B (Slots 4, 5 &amp; Devices) to operate at up to 100MHz</p> <p><b>Closed</b>- Force PCI Bridge B (Slots 4, 5 &amp; Devices) to operate at a maximum 66MHz</p> <p>NOTE: This jumper affects integrated SCSI on the same bus.</p>
---	--

### J109: FireWire (IEEE1394A) Pin Header

	<table border="1"> <thead> <tr> <th>Signal</th> <th>Pin</th> <th>Pin</th> <th>Signal</th> </tr> </thead> <tbody> <tr> <td>NC1</td> <td>1</td> <td>2</td> <td>Key</td> </tr> <tr> <td>TPA +</td> <td>3</td> <td>4</td> <td>TPA -</td> </tr> <tr> <td>GND</td> <td>5</td> <td>6</td> <td>GND</td> </tr> <tr> <td>TPB +</td> <td>7</td> <td>8</td> <td>TPB -</td> </tr> <tr> <td>+12V</td> <td>9</td> <td>10</td> <td>+12V</td> </tr> <tr> <td>GND</td> <td>11</td> <td>12</td> <td>GND</td> </tr> <tr> <td>NC2</td> <td>13</td> <td>14</td> <td>Key</td> </tr> </tbody> </table>	Signal	Pin	Pin	Signal	NC1	1	2	Key	TPA +	3	4	TPA -	GND	5	6	GND	TPB +	7	8	TPB -	+12V	9	10	+12V	GND	11	12	GND	NC2	13	14	Key
Signal	Pin	Pin	Signal																														
NC1	1	2	Key																														
TPA +	3	4	TPA -																														
GND	5	6	GND																														
TPB +	7	8	TPB -																														
+12V	9	10	+12V																														
GND	11	12	GND																														
NC2	13	14	Key																														

### J93: COM2 Header

	<p><b>Use these pin definitions to connect a port to COM2*</b></p> <p>Pin1 COM2 Receive</p> <p>Pin2 COM2 Ground</p> <p>Pin3 COM2 Transfer</p> <p>*TYAN does NOT provide cable for this header. It is designed for OEM use only.</p>
---	---



## P23: Front Audio Header

Signal	Pin	Pin	Signal
MIC_L	1	2	GND
MIC_R	3	4	VCC-
LINE_FPOUT_R	5	6	LINE_OUT_R
AUD_DET	7	8	KEY
LINE_FPOUT_L	9	10	LINE_OUT_L

The front panel Audio comes preinstalled with jumpers on pins 5-6 and 9-10. Remove these jumpers to place a front panel audio cable

**WARNING:** Do not place jumper covers on this header in any other configuration. Doing so could result in damage to the motherboard

## J69: FireWire Disable Jumper


	Open- (Default) Enables onboard FireWire controller Closed- Disables onboard FireWire controller
---	---

## J14: Onboard Buzzer/Speaker Header

	<b>Close Pin-3 and 4</b> (Default)-Onboard buzzer enabled.
	<b>Open Pin-3 and 4</b> -Disable onboard buzzer or connect to chassis speaker

## P29: External SCSI LED Header

	Use to connect external SCSI LED Pin 1: NC, Pin 2: LED, Pin 3: LED, Pin 4: NC
---	--



## Fan Connectors

The S2895 uses the standard 4-wire cooling fan connector pin-out. The connector is keyed to prevent damage to the mainboard and fan due to misalignment during insertion. Fans are 12V nominally rated with fan speed modulated by the control signal. The Sense signal is a fan tachometer output signal with two pulses per revolution. The Control signal is a 25KHz Pulse Width Modulated (PWM) signal from the baseboard control circuitry.

The 4-wire fan is forward and backward compatible to the 3-wire fan. This means an older 3-wire fan will plug into a 4-wire fan header. However, there is no speed control for a wire fan. It will always run at full RPM

<b>1 2 3 4</b> 	<p>Use these headers to connect the processor or chassis cooling fan to your motherboard to keep the system stable and reliable.</p> <p>* For 3-pin fans connect to pin 1-3.</p>
<b>Pin1=GROUND</b> <b>Pin2= +12v</b> <b>Pin3= Tachometer</b> <b>Pin4= Speed Control</b>	

## Hardware Monitor

### Temperature sensor

Senor chip: LM95221 (SMB address: 010 1011x)

CPU1 temperature: U92 pin1, 2

CPU2 temperature: U92 pin3, 4

### FAN speed detect and control

CPU1 FAN	CPU1 FAN PWM: SIO PIN34 GP11 CPU1 FAN TACH: SIO PIN7 GP85
CPU2 FAN	CPU2 FAN PWM: SIO PIN43 GP22 CPU2 FAN TACH: SIO PIN110 FAN_TACH4
FAN 1	FAN1 PWM: CK804 PINAB4 FANCTL1 FAN1 TACH: CK804 PINAA3 FANRPM
FAN 2	FAN2 PWM: SIO PIN104 GP74 FAN2 TACH: SIO PIN35 FAN_TACH2
FAN 3	FAN3 PWM: SIO PIN104 GP74 FAN3 TACH: SIO PIN103 FAN TACH3
FAN 4	FAN4 PWM: CK804 PINAA2 FANCTL0 FAN4 TACH: CK804 PINAA3 FANRPM

## 2.4 - Installing the Processor(s)


Your brand new Thunder K8WE supports the latest 64-bit processor technology from AMD. Only AMD Opteron™ processor 200 series are certified and supported with this motherboard.

Check our website for latest processor support. <http://www.tyan.com>

### NOTE

If using a single processor, it MUST be installed in socket CPU1. When using a single processor only CPU1 memory banks are addressable.

**TYAN is not liable for damage as a result of operating an unsupported configuration.**



The diagram is provided as a visual guide to help you install socket processors and may not be an exact representation of the processors you have.

**Step 1:** Lift the lever on the socket until it is approximately 90° or as far back as possible to the socket.

**Step 2:** Align the processor with the socket. There are keyed pins underneath the processor to ensure that the processor's installed correctly.

**Step 3:** Seat the processor firmly into the socket by gently pressing down until the processor sits flush with the socket.

**Step 4:** Place the socket lever back down until it locks into place. The installation is finished.

Repeat these steps for the second processor if you are using two processors.

Take care when installing processors as they have very fragile connector pins below the processor and can bend and break if inserted improperly.

### NOTE

In order to access PCI Express x16 slot 3 and second Nvidia MAC, TWO CPUs must be installed.


## 2.5 - Heatsink Retention Frame Installation

After you are done installing the processor(s), you should proceed to installing the retention frame and heatsink. The CPU heatsink will ensure that the processors do not overheat and continue to operate at maximum performance for as long as you own them. Overheated processors are also dangerous to the motherboard.


The backplate assembly prevents excessive motherboard flexing in the area near the processor and provides a base for the installation of the heatsink retention bracket and heatsink.

Because there are many different types of heatsinks available from many different manufacturers, a lot of them have their own method of installation. For the safest method of installation and information on choosing the appropriate heatsink, use heatsinks validated by AMD. Please refer to AMD's website at [www.amd.com](http://www.amd.com).

The following diagram will illustrate how to install the most common CPU back plates:




## 2.6 - Thermal Interface Material



There are two types of thermal interface materials designed for use with the AMD Opteron processor.

The most common material comes as a small pad attached to the heatsink at the time of purchase. There should be a protective cover over the material. Take care not to touch this material. Simply remove the protective cover and place the heatsink on the processor.




The second type of interface material is usually packaged separately. It is commonly referred to as 'thermal compound'. Simply apply a thin layer on to the CPU lid (applying too much will actually reduce the cooling).

### NOTE


Always check with the manufacturer of the heatsink & processor to ensure the Thermal Interface material is compatible with the processor & meets the manufacturer's warranty requirements

## 2.7 - Heatsink Installation Procedures


### Type A: CAM LEVER (TYPE) INSTALLATION



1. After placing backplate and interface material under motherboard place heatsink retention frame on top of motherboard. Align plastic retention bracket screw holes with CPU backplate standoffs. Tighten screws to secure plastic retention bracket. Repeat for the other side. **DO NOT OVER TIGHTEN.**




2. After tightening screws secure metal clip to plastic retention bracket center tab. Repeat for the other side of heatsink.




3. After securing metal clip to plastic retention bracket center tab, push down on plastic clip to lock plastic clip to side tab.


## Type B: SCREW RETENTION TYPE HEATSINK



1. After placing CPU back-plate and adhesive interface material under motherboard, place heatsink retention frame on top of motherboard. Align heatsink retention frame screw hole with backplate assembly standoffs. Place heatsink inside plastic retention bracket. Place metal clip over retention frame tab. Repeat for other side.



2. Insert screw through metal clip. **BE SURE METAL CLIP IS LOCKED ONTO RETENTION FRAME TAB.**




3. Tighten screw through metal clip. Repeat on the other side. **DO NOT OVER TIGHTEN.**

---

## 2.8 - Finishing Installing the Heatsink

After you have finished installing the heatsink onto the processor and socket, attach the end wire of the fan (which should already be attached to the heatsink) to the motherboard. The following diagram illustrates how to connect fans onto the motherboard.



Once you have finished installing all the fans you can connect your drives (hard drives, CD-ROM drives, etc.) to your motherboard.

## 2.9 - Tips on Installing Motherboard in Chassis


Before installing your motherboard, make sure your chassis has the necessary motherboard support studs installed. These studs are usually metal and are gold in color. Usually, the chassis manufacturer will pre-install the support studs. If you are unsure of stud placement, simply lay the motherboard inside the chassis and align the screw holes of the motherboard to the studs inside the case. If there are any studs missing, you will know right away since the motherboard will not be able to be securely installed.

**Pay attention when installing board in chassis. Some components are near the mounting holes and can be damaged.**

Some chassis' include plastic studs instead of metal. Although the plastic studs are usable, TYAN recommends using metal studs with screws that will fasten the motherboard more securely in place.

Below is a chart detailing what the most common motherboard studs look like and how they should be installed.


Mounting the Motherboard



## 2.10 - Installing the Memory

Before attempting to install any memory, make sure that the memory you have is compatible with the motherboard as well as the processor.

The following diagram shows common types of DDR SDRAM modules:




Here are a few key points to note before installing memory into your Thunder K8WE:

- **Always install memory beginning with CPU1 DIMM-A1.**
- **In order to access memory on CPU2, both processors must be installed.**
- **Single, pairs, or four modules are supported on each CPU.**
- **Configure memory symmetrically on each CPU for best performance.**
- **AMD Opteron™ processors support 64bit (non-interleaved) or 128bit (interleaved) memory configurations**
- **At least ONE Registered DDR SDRAM module must be installed for the system to turn on and POST (power on self test)**
- 128MB, 256MB, 512MB, 1GB, and 2GB\* Registered PC3200/PC2700/PC2100 DDR SDRAM memory modules are supported
- All installed memory will be automatically detected
- The Thunder K8WE supports up to 16GB\* with two CPU's installed.  
\* *Not validated at the time of print; subject to change.*




## Memory Installation Procedure

When you install the memory modules, make sure the module aligns properly with the memory slot. The modules are keyed to ensure that it is inserted only one way. The method of installing memory modules are detailed by the following diagrams.



Once the memory modules are firmly seated in the slot, two latches on either side will close and secure the module into the slot. Sometimes you may need to close the latches yourself.



To remove the memory module, simply push the latches outwards until the memory module pops up. Then remove the module.

### NOTE


**YOU MUST ALWAYS** unplug the power connector from the motherboard before performing system hardware changes. Otherwise you may damage the board and/or expansion device.

## 2.11 - Attaching Drive Cables

### Attaching IDE Drive Cable

Attaching the IDE drive cable is simple. The cable is “keyed” to only allow it to be connected in the correct manner.

Attaching IDE cable to the IDE connector is illustrated below:



Simply plug in the BLUE END of the IDE cable into the motherboard IDE connector, and the other end into the drive. Each standard IDE cable has three connectors, two of which are closer together. The BLUE connector that is furthest away from the other two is the end that connects to the motherboard. The other two connectors are used to connect to drives.

Note: Always remember to properly set the drive jumpers. If only using one device on a channel, it must be set as Master for the BIOS to detect it.


**TIP: Pin 1 on the IDE cable (usually designated by a colored wire) faces the drive's power connector.**

### Attaching Serial ATA Cables

The Thunder K8WE is also equipped with 4 Serial ATA (SATA) channels. Connections for these drives are also very simple.


There is no need to set Master/Slave jumpers on SATA drives.

The following pictures illustrate how to connect an SATA drive



### Attaching Floppy Drive Cables


Attaching floppy diskette drives are done in a similar manner to hard drives. See the picture below for an example of a floppy cable. Most of the current floppy drives on the market require that the cable be installed with the colored stripe positioned next to the power connector. In most cases, there will be a key pin on the cable which will force a proper connection of the cable.



Attach first floppy drive (drive **A:**) to the end of the cable with the twist in it. Drive **B:** is usually connected to the next possible connector on the cable (the second or third connector after you install Drive **A:**).

## 2.12 - Installing Add-In Cards

Before installing add-in cards, it's helpful to know if they are fully compatible with your motherboard. For this reason, we've provided the diagrams below, showing the most common slots that may appear on your motherboard. Not all of the slots shown will necessarily appear on your motherboard.



Simply find the appropriate slot for your add-in card and insert the card firmly. Do not force any add-in cards into any slots if they do not seat in place. It is better to try another slot or return the faulty card rather than damaging both the motherboard and the add-in card.

**NOTE**

If the board has a single CPU installed, you can only use PCI Express Slot 1 and one Nvidia MAC Ethernet is enabled. If both CPUs are installed, you can use both PCI Express slots and both MAC Ethernets are enabled.

## PCI IDESELs and IRQ Assignments


Slot or Device	IDESEL#	Bus#	PIRQ	PIRQ	PIRQ	PIRQ
PCI-X Slot #1 (64bit)	PCIXB AD20	PCIX- B	G0_B_ INTA_L	G0_B_ INTB_L	G0_B_ INTC_L	G0_B_ INTD_L
PCI-X Slot#2 (64bit)	PCIXB AD25	PCIX- B	G0_B_ INTB_L	G0_B_ INTC_L	G0_B_ INTD_L	G0_A_ INTA_L
PCI-X Slot#3 (64bit)	PCIXA AD20	PCIX- A	G0_A_ INTA_L	G0_A_ INTB_L	G0_A_ INTC_L	G0_A_ INTD_L
PCI 32/33 (64bit)	PCI AD20	PCI Bus	T0_PC_ INTA_L	T0_PC_ INTB_L	T0_PC_ INTC_L	T0_PC_ INTD_L
Onboard LSI53C1030 U320SCSI	PCIXB AD22	PCIX- B	G0_B_ INTC_L	G0_B_ INTD_L		
Onboard IEEE1394	PCI AD21	PCI Bus	T0_PC_ INTD_L			

### NOTE

**YOU MUST ALWAYS** unplug the power connector from the motherboard before performing system hardware changes. Otherwise you may damage the board and/or expansion device.

## 2.13 - Connecting External Devices

The following diagrams will detail the rear port stack for this S2895 motherboard:



## 2.14 - Installing the Power Supply

There are three power connectors on your Thunder K8WE.

The Thunder K8WE requires an EPS12V/SSI EEB 3.51 (24 pin + 8 pin) power supply to boot. TYAN recommends using a split plane power supply because of the amount of power the S2895 requires.

You also have an option of using an SSI v3.51 workstation power supply. This is recommended when running both PCI Express slots.


### WARNING

**NEVER plug the 8-pin power connector into the 6-pin connector.** Doing so will damage the motherboard and/or other components.


Please be aware that ATX 2.x and ATXGES power supplies are not compatible with the board and can damage the motherboard and/or CPU(s).

This chart represents SSI EEB 3.51 split plane power supply.

EPS12V Main Power 24-Pin  
(Chipsets & Components)



12	+3.3V	24	GND
11	+12V3	23	+5V
10	+12V3	22	+5V
9	+5VSB	21	+5V
8	PWR OK	20	RESVD
7	GND	19	GND
6	+5V	18	GND
5	GND	17	GND
4	+5V	16	PSON#
3	GND	15	GND
2	+3.3V	14	-12V
1	+3.3V	13	+3.3V



EPS 12V 8-pin (CPU Power)

4	GND	8	+12V2
3	GND	7	+12V2
2	GND	6	+12V1
1	GND	5	+12V1



SSI Workstation 6-pin

3	+12V2	6	+12V2
2	3.3VDC	5	GND
1	3.3VDC	4	GND

---

### Applying power to the board

1. Connect the SSI Workstation 6-pin power connector (if needed).
2. Connect the 8-pin CPU Power connector.
3. Connect the 24-pin Main Power connector.
4. Connect power cable to power supply and power outlet

#### NOTE

**YOU MUST** unplug the power supply before plugging the power cables to motherboard connectors.

## 2.15 – Finishing Up

Congratulations on making it this far! You're finished setting up the hardware aspect of your computer. Before closing up your chassis, make sure that all cables and wires are connected properly, especially IDE cables and most importantly, jumpers. You may have difficulty powering on your system if the motherboard jumpers are not set correctly.

In the rare circumstance that you have experienced difficulty, you can find help by asking your vendor for assistance. If they are not available for assistance, please find setup information and documentation online at our website or by **calling your vendor's support line.**

---

**NOTES:**

---

---

---

## Chapter 3: BIOS Setup

---

### 3.1 - BIOS Setup Utility

With the BIOS setup utility, you can modify BIOS settings and control the special features of your computer. The setup utility uses a number of menus for making changes and turning the special features on or off.

**NOTE**

All menus are based on a typical system. The actual menus displayed on your screen may be different and depend on the hardware and features installed in your computer.

To start the BIOS setup utility:

- a. Turn on or reboot your system
- b. Press <F2> during POST (F4 on remote console) to start BIOS setup utility

**To select an item**

Use the left/right (← →) arrow keys to make a selection

**To display a sub-menu** (A pointer “▶” marks all sub menus)

Use the arrow keys to move the cursor to the sub menu you want. Then press <Enter>.

## 3.2 - BIOS Menu Bar

The menu bar at the top of the windows lists these selections:

Main	To configure basic system setups
Advanced	To configure the advanced chipset features
Memory	To configure system memory features
Boot	To configure system boot order
Exit	To exit setup utility

**NOTE** Options written in **bold type** represent the BIOS setup default

## 3.3 - BIOS Legend Bar

The chart describes the legend keys and their alternates:

Key	Function
<F1> or <Alt-H>	General help window
<ESC>	Exit current menu
← → arrow keys	Select a different menu
↑ or ↓ arrow keys	Select different item
<+> or <->	Change values
<F9>	Load the Optimal default configuration values of the menu
<F10>	Select the previous value/setting of the field
<Enter>	Execute command or select submenu

## 3.4 - Getting Help

Pressing [F1] will display a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help window, press [ESC] or [F1] key again.

### 3.5 - BIOS Main Menu

The Main BIOS Menu is the first screen that you can navigate. The Main BIOS setup menu screen has two main frames. The left frame displays all the options that can be configured. "Grayed-out" options cannot be configured, options in blue can be changed.

The right frame displays the key legend. Above the key legend is an area reserved for a text message. When an option is selected in the left frame, it is highlighted in white. Often, a text message will accompany it.

PhoenixBIOS Setup Utility			
Main			
BIOS Date	09/22/04	Item Specific Help	
BIOS Version:	0.12.2895		
CPU Type	AMD Opteron™		
CPU Speed	2000 Mhz		
System Memory	[XXXX KB]		
Extended Memory	[XXXX KB]		
System Time	[11:33:23]		
System Date	[09/22/2004]		
F1: Help : Select Item -/+ : Change Values F9: Setup Defaults Esc: Exit : Select Screen Enter: Select ▶ Sub-Menu F10: Previous Values			

Feature	Option	Description
System Time	<b>HH:MM:SS</b>	Set the system time
System Date	<b>MM:DD: YYYY</b>	Set the system date

### 3.6 - BIOS Advanced Menu

You can select any of the items in the left frame of the screen, such as Hammer Configuration, to go to the sub menu for that item. You can display an Advanced BIOS Setup option by highlighting it using the <Arrow> keys. All Advanced BIOS Setup options are described in this section. The Advanced BIOS Setup screen is shown below. The sub menus are described on the following pages.

PhoenixBIOS Setup Utility		
Advanced		
Installed O/S:	[Win98]	Item Specific Help
Secured Setup Configurations	[No]	
Reset Configuration Data:	[No]	
<ul style="list-style-type: none"> <li>▶ Hammer Configuration</li> <li>▶ Integrated Devices</li> <li>▶ FirstWare Configuration</li> <li>▶ PCI Configuration</li> <li>▶ IDE Configuration</li> <li>▶ Floppy Configuration</li> <li>▶ I/O Device Configuration</li> </ul>		
F1: Help           : Select Item   -/+ : Change Values   F9: Setup Defaults Esc: Exit           : Select Menu   Enter: Select   ▶ Sub-Menu F10: Previous Values		

Feature	Option	Description
Hammer Configuration	<b>800MHz</b>	Set frequency of HT-LDT link between K8 and CK8S.
	200MHz	
	400MHz	
	600MHz	
	1000MHz	
	Auto	
Integrated Devices	<b>Menu Item</b>	Set integrated devices.
FirstWare Configuration	<b>Menu Item</b>	Configure FirstWare options.

PCI Configuration	<b>Menu Item</b>	Configure PCI devices.
IDE Configuration	<b>Menu Item</b>	Configure IDE interface.
Floppy Configuration	<b>Menu Item</b>	Configure floppy interface.
I/O Device Configuration	<b>Menu Item</b>	Peripheral configuration

### 3.6.1 - Integrated Devices Sub-Menu

You can use this screen to select options for the Integrated Devices settings. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

PhoenixBIOS Setup Utility		
Advanced		
USB Control	[USBA+USBB+USB2]	Item Specific Help
USB BIOS Legacy Support:	[Disabled]	
MAC LAN:	[Enabled]	
MAC LAN Bridge:	[Enabled]	
Audio Codec:	[Enabled]	
SATA0 Internal PHY:	[Enabled]	
SATA1 External PHY:	[Enabled]	
Interrupt Mode:	[APIC]	
▶ Slave Devices Configuration		
▶ NV RAID Configuration		
F1: Help : Select Item -/+ : Change Values F9: Setup Defaults Esc: Exit : Select Screen Enter: Select ▶ Sub-Menu F10: Previous Values		

Feature	Option	Description
USB Control	<b>USBA+ USBB+USB2</b>	Set USB controllers.
	USBA+USBB	
	Disabled	
USB BIOS Legacy Support	<b>Disabled</b>	Set support for USB Keyboard/Mouse.
	Enabled	
MAC LAN	<b>Enabled</b>	Set MAC LAN device.
	Disabled	

MAC LAN Bridge	<b>Enabled</b>	Enable MAC LAN Bridge.
	Disabled	
Audio Codec	<b>Enabled</b>	Auto detect/disable AC97 interface.
	Disabled	
SATA0 Internal PHY	<b>Enabled</b>	Set First Serial ATA device.
	Disabled	
SATA1 External PHY	<b>Enabled</b>	Set Second Serial ATA device.
	Disabled	
Interrupt Mode	<b>APIC</b>	Select Interrupt Mode.
	8529/PIC	
Slave Devices Configuration	<b>Menu Item</b>	Configure Slave Devices.
NV RAID Configuration	<b>Menu Item</b>	Set Nvidia RAID control.

### Slave Devices Configuration

You can use this screen to select options for the Slave Devices Configuration settings. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

PhoenixBIOS Setup Utility		
Advanced		
MAC LAN: MAC LAN Bridge:	[Enabled] [Enabled]	Item Specific Help
F1: Help       : Select Item   -/+ : Change Values   F9: Setup Defaults Esc: Exit       : Select Screen   Enter: Select   ▶ Sub-Menu F10: Previous Values		

Feature	Option	Description
MAC LAN	<b>Enabled</b>	Configure MAC LAN device.
	Disabled	
MAC LAN Bridge	<b>Enabled</b>	Enable MAC LAN Bridge.
	Disabled	

## NV Configuration

You can use this screen to select options for the NV Configuration settings. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

PhoenixBIOS Setup Utility		
Advanced		
NV Configuration	[Enabled]	Item Specific Help
IDE Primary Master	[Disabled]	
IDE Primary Slave	[Disabled]	
IDE Secondary Master	[Disabled]	
IDE Secondary Slave	[Disabled]	
Internal SATA Primary	[Disabled]	
Internal SATA Secondary	[Disabled]	
External SATA Primary	[Disabled]	
External SATA Secondary	[Disabled]	
F1: Help           : Select Item   -/+ : Change Values   F9: Setup Defaults Esc: Exit           : Select Screen   Enter: Select   ▶ Sub-Menu F10: Previous Values		

Feature	Option	Description
NV Configuration	<b>Enabled</b>	Set Nvidia RAID control.
	Disbled	
IDE Primary/Secondary Master/Slave	<b>Disabled</b>	Enable the drive as RAID.
	Enabled	
Internal SATA Primary/Secondary	<b>Disabled</b>	Enable the drive as RAID.
	Enabled	
External SATA Primary/Secondary	<b>Disabled</b>	Enable the drive as RAID.
	Enabled	

### 3.6.2 - FirstWare Configuration Sub-Menu

You can use this screen to select options for the FirstWare Configuration settings. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

PhoenixBIOS Setup Utility		
Advanced		
FirstWare Language:	[English]	Item Specific Help
FirstWare Authentication Level	[High]	
FirstWare Video Mode	[800x600]	
F1: Help       : Select Item   -/+ : Change Values   F9: Setup Defaults Esc: Exit       : Select Screen   Enter: Select   ▶ Sub-Menu F10: Previous Values		

Feature	Option	Description
FirstWare Language	<b>English</b>	Set the current FirstWare language to the selected language.
	Japanese	
	Chinese (S)	
	Spanish	
	French	
	German	
FirstWare Authentication Level	<b>High</b>	Select the FirstWare Authentication level.
	Medium	
	Low	
FirstWare Video Mode	<b>800x600</b>	Select the FirstWare Video Mode.
	640x480	
	1024x768	
	1280x1024	

### 3.6.3 - PCI Configuration Sub-Menu

You can use this screen to select options for the PCI Configuration settings. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

PhoenixBIOS Setup Utility	
Advanced	
Note PCI Slot Layout Convent in Help Window	Item Specific Help
<ul style="list-style-type: none"> <li>▶ PCI Device, Slot # 1</li> <li>▶ PCI Device, Slot # 2</li> <li>▶ PCI Device, Slot # 3</li> <li>▶ PCI Device, Slot # 4</li> <li>▶ PCI Device, Slot # 5</li> <li>▶ PCI Device, Slot # 6</li>   <li>▶ PCI/PNP ISA UHB Region Exclusion</li> <li>▶ PCI/PNP ISA IRQ Resource Exclusion</li> </ul>	
F1: Help : Select Item -/+ : Change Values F9: Setup Defaults Esc: Exit : Select Screen Enter: Select ▶ Sub-Menu F10: Previous Values	

Feature	Option	Description
PCI Device, Slot #1~6	<b>Menu Item</b>	Select PCI slot configuration.
PCI/PNP ISA UHB Region Exclusion	<b>Menu Item</b>	Reserve specific upper memory blocks for use by legacy ISA devices.
PCI/PNP ISA IRQ Resource Exclusion	<b>Menu Item</b>	Reserve the specific IRQs for use by legacy ISA devices.

## PCI Device, Slot #1~6

You can use this screen to select options for the PCI Device, Slot #1~6 settings. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

PhoenixBIOS Setup Utility		
Advanced		
Option ROM Scan:	[Enabled]	Item Specific Help
Enable Master:	[Enabled]	
Latency Timer	[0040h]	
F1: Help           : Select Item   -/+: Change Values   F9: Setup Defaults Esc: Exit           : Select Screen   Enter: Select   ▶ Sub-Menu F10: Previous Values		

Feature	Option	Description
Option ROM Scan	<b>Enabled</b>	Initialize device expansion ROM.
	Disabled	
Enable Master	<b>Enabled</b>	Enable selected device as a PCI bus master.
	Disabled	
Latency Timer	<b>0040h</b>	Minimum guaranteed time slice allotted for bus master in units of PCI bus clocks.
	0020h	

## PCI/PNP ISA UHB Region Exclusion

You can use this screen to select options for the PCI/PNP ISA UHB Region Exclusion settings. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

PhoenixBIOS Setup Utility		
Advanced		
C800-CBFF:	[Available]	Item Specific Help
CC00-CFFF:	[Available]	
D000-D3FF:	[Available]	
D400-D7FF:	[Available]	
D800-DBFF:	[Available]	
DC00-DFFF:	[Available]	
F1: Help           : Select Item   -/+: Change Values   F9: Setup Defaults Esc: Exit           : Select Screen   Enter: Select   ▶ Sub-Menu F10: Previous Values		

Feature	Option	Description
C800-CBFF, CC00-CFFF D000-D3FF, D400-D7FF D800-D8FF, DC00-DFFF	Available	Reserves the specified block of upper memory for use by legacy ISA devices.
	Reserved	

## PCI/PNP ISA IRQ Resource Exclusion

You can use this screen to select options for the PCI/PNP IRQ Resource Exclusion settings. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

PhoenixBIOS Setup Utility		
Advanced		
IRQ3	[Available]	Item Specific Help
IRQ4	[Available]	
IRQ5:	[Available]	
IRQ7	[Available]	
IRQ9	[Available]	
IRQ10	[Available]	
IRQ11	[Available]	
IRQ15	[Available]	
F1: Help : Select Item -/+ : Change Values F9: Setup Defaults Esc: Exit : Select Screen Enter: Select ▶ Sub-Menu F10: Previous Values		

Feature	Option	Description
IRQ3/4/5/7/9/10/11/15	Available	Reserves the specified IRQ for use by legacy ISA devices.
	Reserved	

### 3.6.4 - IDE Configuration Sub-Menu

You can use this screen to select options for the IDE Configuration settings. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

PhoenixBIOS Setup Utility		
Advanced		
Large Disk Access Mode:	[DOS]	Item Specific Help
Local Bus IDE adapter:	[Both]	
<ul style="list-style-type: none"> <li>▶ IDE Channel 0 Master</li> <li>▶ IDE Channel 0 Slave</li> <li>▶ IDE Channel 1 Master</li> <li>▶ IDE Channel 1 Slave</li> <li>▶ IDE Channel 2 Master</li> <li>▶ IDE Channel 3 Master</li> </ul>		
F1: Help : Select Item -/+ : Change Values F9: Setup Defaults Esc: Exit : Select Screen Enter: Select ▶ Sub-Menu F10: Previous Values		

Feature	Option	Description
Large Disk Access Mode	<b>DOS</b>	Select the IDE access mode.
	Other	
Local Bus IDE adapter	<b>Both</b>	Enable the integrated local bus IDE adapter.
	Disabled	
	Primary	
	Secondary	
IDE Channel 0/1 Master/Slave	<b>Menu Item</b>	Configure the IDE channel.
IDE Channel 2/3 Master	<b>Menu Item</b>	Configure the IDE channel.

## IDE Channel 1/0 Master/Slave

The following screen shows the information of IDE channel 1/0 Master/Slave.

PhoenixBIOS Setup Utility		
Advanced		
Type:		Item Specific Help
CHS Format		
Cylinders:		
Cylinders:		
Heads:	[ 1 ]	
Heads:		
Sectors:		
Sectors:		
Maximum Capacity:		
Maximum Capacity:		
LBA Format'		
Total Sectors:		
Maximum Capacity:		
Multi-Sector Transfers:	[Disabled]	
LBA Mode Control:	[Disabled]	
32 Bit I/O:	[Disabled]	
Transfer Mode:	[Disabled]	
Ultra DMA Mode:	[Disabled]	
F1: Help : Select Item -/+ : Change Values F9: Setup Defaults Esc: Exit : Select Screen Enter: Select ▶ Sub-Menu F10: Previous Values		

Feature	Option	Description
Multi-Sector Transfers	<b>Disabled</b>	Specify the number of sectors per block for multiple sector transfer.
	Enabled	
LBA Mode Control	<b>Disabled</b>	Enabling LBA causes Logical Block Addressing to be used in place of Cylinders, Heads_Sectors.
	Enabled	
32 Bit I/O	<b>Disabled</b>	This setting enables or disables 32 bit IDE data transfers.
	Enabled	
Transfer Mode	<b>Disabled</b>	Select the method for moving data to/from the drive.
	Enabled	

Ultra DMA Mode	<b>Disabled</b>	Select the Ultra DMA mode used for moving data to/from the drive.
	Enabled	

### IDE Channel 2/3 Master

The following screen shows the information of IDE Channel 2/3 Master.

PhoenixBIOS Setup Utility		
Advanced		
Type: LBA Format' Total Sectors: Maximum Capacity:		Item Specific Help
Multi-Sector Transfers:	[Disabled]	
LBA Mode Control:	[Disabled]	
32 Bit I/O:	[Disabled]	
Transfer Mode:	[Disabled]	
Ultra DMA Mode:	[Disabled]	
F1: Help : Select Item -/+ : Change Values F9: Setup Defaults Esc: Exit : Select Screen Enter: Select ▶ Sub-Menu F10: Previous Values		

### 3.6.5 - Floppy Configuration Sub-Menu

You can use this screen to select options for the Floppy Configuration settings. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

PhoenixBIOS Setup Utility		
Advanced		
Floppy disk controller:	[Auto]	Item Specific Help
Base I/O address:	[Primary]	
Legacy Diskette A:	[1.44/1.25 MB 3 [Disabled]	
F1: Help : Select Item -/+ : Change Values F9: Setup Defaults Esc: Exit : Select Screen Enter: Select ▶ Sub-Menu F10: Previous Values		

Feature	Option	Description
Floppy disk controller	<b>Auto</b>	Configure using floppy disk controller.
	Disabled	
	Enabled	
	OS Controlled	
Base I/O address	<b>Primary</b>	Set the base I/O address for the floppy disk controller.
	NULL	
Legacy Diskette A	<b>Auto</b>	Select floppy type
	Disabled	
	Enabled	
	Enabled	

### 3.6.6 - I/O Device Configuration Sub-Menu

You can use this screen to select options for the I/O Device Configuration settings. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

PhoenixBIOS Setup Utility		
Advanced		
Serial port A:	[Auto]	Item Specific Help
Base I/O address:	[3F8]	
Interrupt:	[IRQ 4]	
Indicates a DMA, interrupt, I/O, or memory resource conflict with another device.		
F1: Help           : Select Item   -/+: Change Values   F9: Setup Defaults Esc: Exit           : Select Screen   Enter: Select   ▶ Sub-Menu F10: Previous Values		

Feature	Option	Description
Serial port A	<b>Auto</b>	Configure serial port A.
	Disabled	
	Enabled	
	OS Controlled	
Base I/O address	<b>3F8</b>	Set the base I/O address for serial port A.
	2F8	
	3E8	
Interrupt	<b>IRQ4</b>	Set the interrupt for serial port A.
	IRQ3	

### 3.7 - BIOS Memory Menu

This menu has options for memory speed & latency. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

PhoenixBIOS Setup Utility		
Memory		
Cache Ram	[XXXX KB]	Item Specific Help
System Memory:	[XXXX KB]	
Extended Memory:	[Enabled]	
Memory Cache:	[Write Back]	
Cache System BIOS area:	[Write Back]	
Cache Video BIOS area:	[Write Back]	
Cache Base 0-512k:	[Write Back]	
Cache Base 512k-640k:	[Write Back]	
Cache Extended Memory Area:	[Write Back]	
Cache A000 – AFFF:	[Disabled]	
Cache B000 – BFFF:	[Disabled]	
Cache C800 – CBFF:	[Disabled]	
Cache CC00 – CFFF:	[Disabled]	
Cache D000 – D3FF:	[Disabled]	
Cache D400 – D7FF:	[Disabled]	
Cache D800 – DBFF:	[Disabled]	
Cache DC00 – DFFF:	[Write Back]	
Cache E000 – E3FF:	[Write Protect]	
Cache E400 – E7FF:	[Write Protect]	
Cache E800 – E8FF:	[Write Protect]	
Cache EC00 – EFFF:	[Write Protect]	
F1: Help       : Select Item   -/+: Change Values   F9: Setup Defaults Esc: Exit       : Select Screen   Enter: Select   ▶ Sub-Menu F10: Previous Values		

Feature	Option	Description
Memory Cache	<b>Enabled</b>	Set the state of memory cache.
	Disabled	
Cache System BIOS area	<b>Write Back</b>	Control caching of system BIOS area.
	Write Through	
	Write Protect	

	Uncached	
Cache Video BIOS area	<b>Write Back</b>	Control caching of video BIOS area.
	Write Through	
	Write Back	
	Uncached	
Cache Base 0-512K	<b>Write Back</b>	Control caching of 512K base memory.
	Write Through	
	Write Back	
	Uncached	
Cache Base 512K-640K	<b>Write Back</b>	Control caching of 512K-640K base memory.
	Write Through	
	Write Back	
	Uncached	
Cache Extended Memory Area	<b>Write Back</b>	Control caching of system memory above one megabyte.
	Write Through	
	Write Back	
	Uncached	
Cache A000-AFFF Cache B000-BFFF	<b>Disabled</b>	Control caching of the memory blocks.
	USHC	
	Write Through	
	Write Protect	
Cache C800-CBFF Cache CC00-CFFF Cache D000-D3FF Cache D400-D7FF Cache D800-DBFF	<b>Disabled</b>	Control caching of the memory blocks.
	Write Through	
	Write Protect	
	Write Back	
Cache DC00-DFFF	<b>Write Back</b>	Control caching of the memory blocks.
	Write Through	
	Write Protect	
	Disabled	
Cache E000-E3FF Cache E400-E7FF Cache E800-E8FF Cache EC00-EFFF	<b>Write Protect</b>	Control caching of the memory blocks.
	Write Through	
	Disabled	
	Write Back	

### 3.8 - BIOS Boot Menu

This menu has options for the Boot Device Priority. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

PhoenixBIOS Setup Utility		
Boot		
QuickBoot Mode:	[Enabled]	Item Specific Help
Boot-time Diagnostic Screen	[Disabled]	
Summary screen	[Disabled]	
▶ Boot Device Priority		
F1: Help : Select Item -/+ : Change Values F9: Setup Defaults Esc: Exit : Select Screen Enter: Select ▶ Sub-Menu F10: Previous Values		

Feature	Option	Description
QuickBoot Mode	<b>Enabled</b>	Allow the system to skip certain tests while booting.
	Disabled	
Boot-time Diagnostic Screen	<b>Disabled</b>	Display the diagnostic screen during boot.
	Enabled	
Summary screen	<b>Disabled</b>	Display system configuration on boot.
	Enabled	
Boot Device Priority	<b>Menu Item</b>	Select the search order for the types of boot devices.

### 3.8.1 - Boot Device Priority

You can use this screen to select options for the Boot Device Priority settings. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

PhoenixBIOS Setup Utility	
Boot	
CD-ROM Drive +Removable Devices +Hard Drive Network Boot	Item Specific Help
	Keys used to view or configure devices:  <Enter> expands or collapse devices with a '+' or '-'  <Ctrl+Enter> expands all modes.  <+> and <-> moves the device up and down.
F1: Help : Select Item -/+ : Change Values F9: Setup Defaults Esc: Exit : Select Screen Enter: Select ▶ Sub-Menu F10: Previous Values	

The boot menu will list all bootable devices. Use <Enter> to expand or collapses devices with a '+' or '-'. Use <+> or <-> to arrange the priorities of all bootable devices.

## 3.9 - BIOS Exit Menu

This menu has options for the Exit Priority. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

PhoenixBIOS Setup Utility	
Exit	
Exit Saving Charges Exit Discarding Changes	Item Specific Help
Load Setup Defaults Discard Changes Save Changes	Exit System Setup and save your changes to CMOS.
F1: Help : Select Item -/+ : Change Values F9: Setup Defaults Esc: Exit : Select Screen Enter: Select ▶ Sub-Menu F10: Previous Values	

### Exit Saving Changes

Use this option to exit setup utility and re-boot. All new selections you have made are stored into CMOS. System will use the new settings to boot up.

### Exit Discarding Changes

Use this option to exit setup utility and re-boot. All new selections you have made are not stored into CMOS. System will use the old settings to boot up.

### Load Setup Defaults

Use this option to load default setup values.

### Discard Changes

Use this option to restore all new setup values that you have made but not saved in CMOS.

### Save Changes

Use this option to restore all new setup values that you have made and saved in CMOS.

---

## Chapter 4: Diagnostics

---

Note: if you experience problems with setting up your system, always check the following things in the following order:

### Memory, Video, CPU

By checking these items, you will most likely find out what the problem might have been when setting up your system. For more information on troubleshooting, check the TYAN website at: <http://www.tyan.com>.

## 4.1 Beep Codes

Fatal errors, which halt the boot process, are communicated through a series of audible beeps. For example, if the BIOS POST can initialize the video but an error occurs, an error message will be displayed. If it cannot display the message, it will report the error as a series of beeps.

The most common type of error is a memory error.

Before contacting your vendor or TYAN Technical Support, be sure that you note as much as you can about the beep code length and order that you experience. Also, be ready with information regarding add-in cards, drives and O/S to speed the support process and come to a quicker solution.

## 4.2 Flash Utility

Every BIOS file is unique for the motherboard it was designed for. For Flash Utilities, BIOS downloads, and information on how to properly use the Flash Utility with your motherboard, please check the TYAN web site: <http://www.tyan.com/>

**Note:** Please be aware that by flashing your BIOS, you agree that in the event of a BIOS flash failure, you must contact your dealer for a replacement BIOS. There are no exceptions. TYAN does not have a policy for replacing BIOS chips directly with end users. In no event will TYAN be held responsible for damages done by the end user.

## 4.3 BIOS Post Code

Code	Beeps / Description	Code	Beeps / Description
02h	Verify Real Mode	32h	Test CPU bus-clock frequency
03h	Disable Non-Maskable Interrupt (NMI)	33h	Initialize Phoenix Dispatch Manager
04h	Get CPU type	36h	Warm start shut down
06h	Initialize system hardware	38h	Shadow system BIOS ROM
08h	Initialize chipset with initial POST values	3Ah	Autosize cache
09h	Set IN POST flag	3Ch	Advanced configuration of chipset registers
0Ah	Initialize CPU registers	3Dh	Load alternate registers with CMOS values
0Bh	Enable CPU cache	42h	Initialize interrupt vectors
0Ch	Initialize caches to initial POST values	45h	POST device initialization
0Eh	Initialize I/O component	46h	2-1-2-3. Check ROM copyright notice
0Fh	Initialize the local bus IDE	48h	Check video configuration against CMOS
10h	Initialize Power Management	49h	Initialize PCI bus and devices
11h	Load alternate registers with initial POST values	4Ah	Initialize all video adapters in system
12h	Restore CPU control word during warm boot	4Bh	QuietBoot start (optional)
13h	Initialize PCI Bus Mastering devices	4Ch	Shadow video BIOS ROM
14h	Initialize keyboard controller	4Eh	Display BIOS copyright notice
16h	1-2-2-3. BIOS ROM checksum	50h	Display CPU type and speed
17h	Initialize cache before memory autosize	51h	Initialize EISA board
18h	8254 timer initialization	52h	Test keyboard
1Ah	8237 DMA controller initialization	54h	Set key click if enabled
1Ch	Reset Programmable Interrupt Controller	58h	2-2-3-1. Test for unexpected interrupts
20h	1-3-1-1. Test DRAM refresh	59h	Initialize POST display service
22h	1-3-1-3. Test 8742 KBD Controller	5Ah	Display prompt "Press F2 to enter SETUP"
24h	Set ES segment register to 4 GB	5Bh	Disable CPU cache
26h	Enable A20 line	5Ch	Test RAM between 512 and 640 KB
28h	Autosize DRAM	60h	Test extended memory
29h	Initialize POST Memory Manager	62h	Test extended memory address lines
2Ah	Clear 512 KB base RAM	64h	Jump to UserPatch1
2Ch	1-3-4-1. RAM failure on address	66h	Configure advanced cache registers

2Eh	1-3-4-3. RAM failure on data bits of low byte of memory bus	67h	Initialize Multi Processor APIC
2Fh	Enable cache before system BIOS shadow	68h	Enable external and CPU caches
30h	1-4-1-1. RAM failure on data bits of high byte of memory bus	69h	Setup System Management Mode (SMM) area
<b>Code</b>	<b>Beeps / Description</b>	<b>Code</b>	<b>Beeps / Description</b>
6Ah	Display external L2 cache size	A2h	Check key lock
6Bh	Load custom defaults (optional)	A4h	Initialize Typematic rate
6Ch	Display shadow-area message	A8h	Erase F2 prompt
6Eh	Display possible high address for UMB recovery	AAh	Scan for F2 key stroke
70h	Display error messages	ACH	Enter SETUP
72h	Check for configuration errors	Aeh	Clear Boot flag
76h	Check for keyboard errors	B0h	Check for errors
7Ch	Set up hardware interrupt vectors	B2h	POST done - prepare to boot operating system
7Eh	Initialize coprocessor if present	B4h	One short beep before boot
80h	Disable onboard Super I/O ports and IRQs	B5h	Terminate QuietBoot (optional)
81h	Late POST device initialization	B6h	Check password (optional)
82h	Detect and install external RS232 ports	B9h	Prepare Boot
83h	Configure non-MCD IDE controllers	BAh	Initialize DMI parameters
84h	Detect and install external parallel ports	BBh	Initialize PnP Option ROMs
85h	Initialize PC-compatible PnP ISA devices	BCh	Clear parity checkers
86h.	Re-initialize onboard I/O ports.	BDh	Display MultiBoot menu
87h	Configure Motherboard Devices	BEh	Clear screen (optional)
88h	Initialize BIOS Data Area	BFh	Check virus and backup reminders
89h	Enable Non-Maskable Interrupts (NMIs)	C0h	Try to boot with INT 19
8Ah	Initialize Extended BIOS Data Area	C1h	Initialize POST Error Manager (PEM)
8Bh	Test and initialize PS/2 mouse	C2h	Initialize error logging
8Ch	Initialize floppy controller	C3h	Initialize error display function
8Fh	Determine number of ATA drives (optional)	C4h	Initialize system error handler
90h	Initialize hard-disk controllers	C5h	PnPnd dual CMOS (optional)
91h	Initialize local-bus hard-disk controllers	C6h	Initialize notebook docking (optional)

92h	Jump to UserPatch2	C7h	Initialize notebook docking late
93h	Build MPTABLE for multi-processor boards	C8h	Force check (optional)
95h	Install CD ROM for boot	C9h	Extended checksum (optional)
96h	Clear huge ES segment register	D2h	BIOS Boot Block
97h	Fixup Multi Processor table	E0h	BIOS Boot Block
98h	1-2. Search for option ROMs.	E1h	BIOS Boot Block
99h	Check for SMART Drive (optional)	E2h	Initialize the CPU
9Ah	Shadow option ROMs	E3h	Initialize system timer
9Ch	Set up Power Management	E4h	Initialize system I/O
9Dh	Initialize security engine (optional)	E5h	Check force recovery boot
9Eh	Enable hardware interrupts	E6h	Checksum BIOS ROM
9Fh	Determine number of ATA and SCSI drives	E7h	Go to BIOS
A0h	Set time of day	E8h	Set Huge Segment
<b>Code</b>	<b>Beeps / Description</b>	<b>Code</b>	<b>Beeps / Description</b>
E9h	Initialize Multi Processor	F1h	Initialize Run Time Clock
EAh	Initialize OEM special code	F2h	Initialize video
EBh	Initialize PIC and DMA	F3h	Initialize System Management Mode
ECh	Initialize Memory type	F4h	Output one beep before boot
EDh	Initialize Memory size	F5h	Boot to Mini DOS
EEh	Shadow Boot Block	F6h	Clear Huge Segment
EFh	System memory test	F7h	Boot to Full DOS
F0h	Initialize interrupt vectors		

---

# Glossary

---

**ACPI (Advanced Configuration and Power Interface):** a power management specification that allows the operating system to control the amount of power distributed to the computer's devices. Devices not in use can be turned off, reducing unnecessary power expenditure.

**AGP (Accelerated Graphics Port):** a PCI-based interface which was designed specifically for demands of 3D graphics applications. The 32-bit AGP channel directly links the graphics controller to the main memory. While the channel runs only at 66 MHz, it supports data transmission during both the rising and falling ends of the clock cycle, yielding an effective speed of 133 MHz.

**ATAPI (AT Attachment Packet Interface):** also known as IDE or ATA; a drive implementation that includes the disk controller on the device itself. It allows CD-ROMs and tape drives to be configured as master or slave devices, just like HDDs.

**ATX:** the form factor designed to replace the AT form factor. It improves on the AT design by rotating the board 90 degrees, so that the IDE connectors are closer to the drive bays, and the CPU is closer to the power supply and cooling fan. The keyboard, mouse, USB, serial, and parallel ports are built-in.

**Bandwidth:** refers to carrying capacity. The greater the bandwidth, the more data the bus, phone line, or other electrical path can carry. Greater bandwidth results in greater speed.

**BBS (BIOS Boot Specification):** a feature within the BIOS that creates, prioritizes, and maintains a list of all Initial Program Load (IPL) devices, and then stores that list in NVRAM. IPL devices have the ability to load and execute an OS, as well as provide the ability to return to the BIOS if the OS load process fails. At that point, the next IPL device is called upon to attempt loading of the OS.

**BIOS (Basic Input/Output System):** the program that resides in the ROM chip, which provides the basic instructions for controlling your computer's hardware. Both the operating system and application software use BIOS routines to ensure compatibility.

**Buffer:** a portion of RAM which is used to temporarily store data; usually from an application though it is also used when printing and in most keyboard drivers. The CPU can manipulate data in a buffer before copying it to a disk drive. While this improves system performance (reading to or writing from a disk drive a single time is much faster than doing so repeatedly) there is the possibility of

---

losing your data should the system crash. Information in a buffer is temporarily stored, not permanently saved.

**Bus:** a data pathway. The term is used especially to refer to the connection between the processor and system memory, and between the processor and PCI or ISA local buses.

**Bus mastering:** allows peripheral devices and IDEs to access the system memory without going through the CPU (similar to DMA channels).

**Cache:** a temporary storage area for data that will be needed often by an application. Using a cache lowers data access times since the information is stored in SRAM instead of slower DRAM. Note that the cache is also much smaller than your regular memory: a typical cache size is 512KB, while you may have as much as 4GB of regular memory.

**Closed and open jumpers:** jumpers and jumper pins are active when they are “on” or “closed”, and inactive when they are “off” or “open”.

**CMOS (Complementary Metal-Oxide Semiconductors):** chips that hold the basic startup information for the BIOS.

**COM port:** another name for the serial port, which is called as such because it transmits the eight bits of a byte of data along one wire, and receives data on another single wire (that is, the data is transmitted in serial form, one bit after another). Parallel ports transmit the bits of a byte on eight different wires at the same time (that is, in parallel form, eight bits at the same time).

**DDR (Double Data Rate):** a technology designed to double the clock speed of the memory. It activates output on both the rising and falling edge of the system clock rather than on just the rising edge, potentially doubling output.

**DIMM (Dual In-line Memory Module):** faster and more capacious form of RAM than SIMMs, and do not need to be installed in pairs.

**DIMM bank:** sometimes called DIMM socket because the physical slot and the logical unit are the same. That is, one DIMM module fits into one DIMM socket, which is capable of acting as a memory bank.

**DMA (Direct Memory Access):** channels that are similar to IRQs. DMA channels allow hardware devices (like soundcards or keyboards) to access the main memory without involving the CPU. This frees up CPU resources for other tasks. As with IRQs, it is vital that you do not double up devices on a single line. Plug-n-Play devices will take care of this for you.

---

**DRAM (Dynamic RAM):** widely available, very affordable form of RAM which loses data if it is not recharged regularly (every few milliseconds). This refresh requirement makes DRAM three to ten times slower than non-recharged RAM such as SRAM.

**ECC (Error Correction Code or Error Checking and Correcting):** allows data to be checked for errors during run-time. Errors can subsequently be corrected at the same time that they're found.

**EEPROM (Electrically Erasable Programmable ROM):** also called Flash BIOS, it is a ROM chip which can, unlike normal ROM, be updated. This allows you to keep up with changes in the BIOS programs without having to buy a new chip. TYAN's BIOS updates can be found at <http://www.tyan.com>

**ESCD (Extended System Configuration Data):** a format for storing information about Plug-n-Play devices in the system BIOS. This information helps properly configure the system each time it boots.

**Firmware:** low-level software that controls the system hardware.

**Form factor:** an industry term for the size, shape, power supply type, and external connector type of the Personal Computer Board (PCB) or motherboard. The standard form factors are the AT and ATX.

**Global timer:** onboard hardware timer, such as the Real-Time Clock (RTC).

**HDD:** stands for Hard Disk Drive, a type of fixed drive.

**H-SYNC:** controls the horizontal synchronization/properties of the monitor.

**HyperTransport™:** a high speed, low latency, scalable point-to-point link for interconnecting ICs on boards. It can be significantly faster than a PCI bus for an equivalent number of pins. It provides the bandwidth and flexibility critical for today's networking and computing platforms while retaining the fundamental programming model of PCI.

**IC (Integrated Circuit):** the formal name for the computer chip.

**IDE (Integrated Device/Drive Electronics):** a simple, self-contained HDD interface. It can handle drives up to 8.4 GB in size. Almost all IDEs sold now are in fact Enhanced IDEs (EIDEs), with maximum capacity determined by the hardware controller.

**IDE INT (IDE Interrupt):** a hardware interrupt signal that goes to the IDE.

---

**I/O (Input/Output):** the connection between your computer and another piece of hardware (mouse, keyboard, etc.)

**IRQ (Interrupt Request):** an electronic request that runs from a hardware device to the CPU. The interrupt controller assigns priorities to incoming requests and delivers them to the CPU. It is important that there is only one device hooked up to each IRQ line; doubling up devices on IRQ lines can lock up your system. Plug-n-Play operating systems can take care of these details for you.

**Latency:** the amount of time that one part of a system spends waiting for another part to catch up. This occurs most commonly when the system sends data out to a peripheral device and has to wait for the peripheral to spread (peripherals tend to be slower than onboard system components).

**NVRAM:** ROM and EEPROM are both examples of Non-Volatile RAM, memory that holds its data without power. DRAM, in contrast, is volatile.

**Parallel port:** transmits the bits of a byte on eight different wires at the same time.

**PCI (Peripheral Component Interconnect):** a 32 or 64-bit local bus (data pathway) which is faster than the ISA bus. Local buses are those which operate within a single system (as opposed to a network bus, which connects multiple systems).

**PCI PIO (PCI Programmable Input/Output) modes:** the data transfer modes used by IDE drives. These modes use the CPU for data transfer (in contrast, DMA channels do not). PCI refers to the type of bus used by these modes to communicate with the CPU.

**PCI-to-PCI bridge:** allows you to connect multiple PCI devices onto one PCI slot.

**Pipeline burst SRAM:** a fast secondary cache. It is used as a secondary cache because SRAM is slower than SDRAM, but usually larger. Data is cached first to the faster primary cache, and then, when the primary cache is full, to the slower secondary cache.

**PnP (Plug-n-Play):** a design standard that has become ascendant in the industry. Plug-n-Play devices require little set-up to use. Devices and operating systems that are not Plug-n-Play require you to reconfigure your system each time you add or change any part of your hardware.

---

**PXE (Preboot Execution Environment):** one of four components that together make up the Wired for Management 2.0 baseline specification. PXE was designed to define a standard set of preboot protocol services within a client with the goal of allowing networked-based booting to boot using industry standard protocols.

**RAID (Redundant Array of Independent Disks):** a way for the same data to be stored in different places on many hard drives. By using this method, the data is stored redundantly and multiple hard drives will appear as a single drive to the operating system. RAID level 0 is known as striping, where data is striped (or overlapped) across multiple hard drives, but offers no fault-tolerance. RAID level 1 is known as mirroring, which stores the data within at least two hard drives, but does not stripe. RAID level 1 also allows for faster access time and fault-tolerance, since either hard drive can be read at the same time. RAID level 0+1 is both striping and mirroring, providing fault-tolerance, striping, and faster access all at the same time.

**RAIDIOS:** RAID I/O Steering (Intel)

**RAM (Random Access Memory):** technically refers to a type of memory where any byte can be accessed without touching the adjacent data and is often referred to the system's main memory. This memory is available to any program running on the computer.

**ROM (Read-Only Memory):** a storage chip which contains the BIOS; the basic instructions required to boot the computer and start up the operating system.

**SDRAM (Synchronous Dynamic RAM):** called as such because it can keep two sets of memory addresses open simultaneously. By transferring data alternately from one set of addresses and then the other, SDRAM cuts down on the delays associated with non-synchronous RAM, which must close one address bank before opening the next.

**Serial port:** called as such because it transmits the eight bits of a byte of data along one wire, and receives data on another single wire (that is, the data is transmitted in serial form, one bit after another).

**SCSI Interrupt Steering Logic (SISL):** Architecture that allows a RAID controller, such as AcceleRAID 150, 200 or 250, to implement RAID on a system board-embedded SCSI bus or a set of SCSI busses. SISL: SCSI Interrupt Steering Logic ( LSI ) (only on LSI SCSI boards)

**Sleep/Suspend mode:** in this mode, all devices except the CPU shut down.

---

**SDRAM (Static RAM):** unlike DRAM, this type of RAM does not need to be refreshed in order to prevent data loss. Thus, it is faster and more expensive.

**Standby mode:** in this mode, the video and hard drives shut down; all other devices continue to operate normally.

**UltraDMA-33/66/100:** a fast version of the old DMA channel. UltraDMA is also called UltraATA. Without a proper UltraDMA controller, your system cannot take advantage of higher data transfer rates of the new UltraDMA/UltraATA hard drives.

**USB (Universal Serial Bus):** a versatile port. This one port type can function as a serial, parallel, mouse, keyboard or joystick port. It is fast enough to support video transfer, and is capable of supporting up to 127 daisy-chained peripheral devices.

**VGA (Video Graphics Array):** the PC video display standard

**V-SYNC:** controls the vertical scanning properties of the monitor.

**ZCR (Zero Channel RAID):** PCI card that allows a RAID card to use the onboard SCSI chip, thus lowering cost of RAID solution

**ZIF Socket (Zero Insertion Force socket):** these sockets make it possible to insert CPUs without damaging the sensitive CPU pins. The CPU is lightly placed in an open ZIF socket, and a lever is pulled down. This shifts the processor over and down, guiding it into the board and locking it into place.

---

## Technical Support

---

If a problem arises with your system, you should turn to your dealer for help first. Your system has most likely been configured by them, and they should have the best idea of what hardware and software your system contains. Furthermore, if you purchased your system from a dealer near you, you can bring your system to them to have it serviced instead of attempting to do so yourself (which can have expensive consequences).

### Help Resources:

1. See the beep codes section of this manual.
2. See the TYAN website for FAQ's, bulletins, driver updates, and other information: <http://www.tyan.com>
3. Contact your dealer for help BEFORE calling TYAN.
4. Check the TYAN user group:  
[alt.comp.periphs.mainboard.TYAN](mailto:alt.comp.periphs.mainboard.TYAN)

### Returning Merchandise for Service

During the warranty period, contact your distributor or system vendor FIRST for any product problems. This warranty only covers normal customer use and does not cover damages incurred during shipping or failure due to the alteration, misuse, abuse, or improper maintenance of products.

**NOTE: A receipt or copy of your invoice marked with the date of purchase is required before any warranty service can be rendered. You may obtain service by calling the manufacturer for a Return Merchandise Authorization (RMA) number. The RMA number should be prominently displayed on the outside of the shipping carton and the package should be mailed prepaid. TYAN will pay to have the board shipped back to you.**



### **Notice for the USA**

Compliance Information Statement (Declaration of Conformity Procedure) DoC  
FCC Part 15: This device complies with part 15 of the FCC Rules

Operation is subject to the following conditions:

This device may not cause harmful interference, and  
This device must accept any interference received including interference that may cause undesired operation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try one or more of the following measures:

Reorient or relocate the receiving antenna.  
Increase the separation between the equipment and the receiver.  
Plug the equipment into an outlet on a circuit different from that of the receiver.  
Consult the dealer on an experienced radio/television technician for help.

### **Notice for Canada**

This apparatus complies with the Class B limits for radio interference as specified in the Canadian Department of Communications Radio Interference Regulations. (Cet appareil est conforme aux normes de Classe B d'interference radio tel que specifie par le Ministere Canadien des Communications dans les reglements d'interference radio.)



### **Notice for Europe (CE Mark)**

This product is in conformity with the Council Directive 89/336/EEC, 92/31/EEC (EMC).

**CAUTION:** Lithium battery included with this board. Do not puncture, mutilate, or dispose of battery in fire. Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by manufacturer. Dispose of used battery according to manufacturer instructions and in accordance with your local regulations.

Document #: D1629-100