

CELESTRON

Quick Set-up Guide



Your NexStar 60SLT includes: optical tube; fork arm; pre-assembled tripod; computerized hand control; hand control holder; star diagonal; two eyepieces; finderscope; accessory tray; documentation including an owner's manual, The Sky[®] CD and NSOL Telescope Control Software.



Assemble tripod by spreading the legs out until the center leg brace is fully extended.



Extend tripod legs 6 to 8 inches by loosening the tripod leg locking knob and pulling the leg to desired length and re-tightening knob.



All three legs should be the same length to provide a level platform for the telescope. A bubble level is included (inset) to assist in leveling.



Hold the telescope fork arm and place the bottom of the base inside the tripod mounting platform as shown.



Place accessory tray on top of center leg brace by lining up the grooves on the tray to the post on the brace.



Thread the coupling screw into the hole at the bottom of the fork arm base. Tighten screw to secure the entire fork arm.



Once grooves are aligned, turn accessory tray until it snaps into the clips on each leg brace.



Slide the optical tube dovetail into the fork arm as shown above.

Quick Set-up Guide [cont]



Secure optical tube to fork arm by tightening the screw located on the inside of the fork arm assembly.

13



To attach the finderscope, loosen the silver screw and slide finderscope into mounting platform.



Secure finderscope to mounting platform by tightening the silver screw. The glass window of the finderscope should be facing towards the front of the telescope.



Attach plastic hand control holder to the tripod leg.



diagonal into the focuser and tighten the two silver screws to secure in place.



Select the low power (25mm) eyepiece and insert it as shown above. Tighten silver screw to secure.



Slide Computerized Hand Control into the hand control holder as shown above.



Plug Computerized Hand Control into the "Hand Control" port on the fork arm.



Before you begin viewing, please remember to remove tube lens cap.



While observing, tube should be positioned as shown above.



Before you can use your telescope, you must insert 8 AA batteries.



Place AA batteries inside the battery compartment located at the base of the fork arm.

Before you can begin observing, you must setup your hand control, align your finderscope and align your telescope. Step by step instructions are included in the following Hand Control Setup section.

Hand Control Guide

Before you can begin using your NexStar 60SLT, you must setup your computerized hand control and go through the SkyAlign alignment procedure. In order for the NexStar to accurately point to the objects in the sky, it must first be aligned with known positions (stars) in the sky. With this information, the telescope can create a model of the sky, which it uses to locate any object in its database



Turn power switch (located on the side of the fork arm) to "on" position. The light will come on and the hand control will display "NexStar SLT".



Use the hand control direction arrow buttons to point telescope at a distant land object, like a telephone pole or at night you can use the moon. Center and focus the object in the 25mm eyepiece of the telescope.



You will notice that there are directional arrows in the center of the hand control. These **only** move the telescope. **They cannot be used to scroll through menu features.**



In order to accurately center an object in the eyepiece it may be necessary to change the slew speed of the motors. To change the slew speed, press the RATE button then select a number from 1 (slowest) to 9 (fastest).



Now you will need to align the finderscope. Turn on the red LED light by turning the knob shown above. When used for the first time, remove the clear plastic disk that is located between the battery clip and the battery. See inset.



With the object centered in the eyepiece, use the azimuth (right/left) and altitude (up/down) adjustment knobs on the finderscope to place the red alignment dot directly over the centered object.



Once you have aligned your finderscope, make sure to turn off the LED light to conserve the battery. Now you are ready to align the telescope. This will have to be done at night.



When the display reads NexStar SLT, press ENTER to begin the alignment procedure.



Use the UP and DOWN scroll buttons (located on #6 and #9) to select "SkyAlign" then press ENTER. Now you will need to enter your site/time information.



The hand control will display the last entered time and site information. Since this is your first time using the NexStar, press UNDO to enter your site and time information.



Press ENTER to select City Database. Use the Up and Down scroll buttons (located on #6 and #9) and choose the closest city to your present location. Press ENTER after selecting the country, state and city.



Using the numeric key pad enter your time information. Press ENTER to continue. Press UNDO to backspace.

Hand Control Guide [cont]



Now, using the Up and Down scroll buttons (located on #6 and #9), verify the time zone you are in and press ENTER.



Using the numeric key pad enter the date. Press ENTER to continue. Press UNDO to backspace.



Use the directional arrow keys on the hand control to slew (move) the telescope towards any bright celestial object in the sky. Center the object in the finderscope and press ENTER.



If the finderscope has been properly aligned, the alignment star should now be visible in the field of view of the eyepiece.



The hand control will prompt you to center the bright alignment star in the center of the eyepiece. Once centered, press ALIGN. This will accept the star as your first alignment position.



For the second alignment object, choose a bright star or planet as far from the first alignment object as possible. Once again use the directional arrow buttons to center the object in the finderscope and press ENTER. Once object is centered in the eyepiece, press ALIGN.



Repeat the process for the third alignment star. When the telescope has been aligned to the final star, the display will read "Match Confirmed". Press UNDO to display the names of the three bright objects you aligned to, or press ENTER to accept these three objects for alignment.



Now that your telescope is properly aligned, you are ready to find your first object. Press the TOUR button on the hand control. The hand control will display a list of objects that are visible for the date and location entered.



Press INFO to read information about the object displayed. Press the DOWN scroll key to display the next object. Press ENTER to slew (move) to the displayed object.

For general usage information, please consult your user's manual.

If you have questions or problems with set-up, please contact Celestron Technical Support: 310-803-5955



NexStar Observer List

Installation Instructions

Linking to your NexStar SLT Telescope

The NexStar has a RS-232 port located on the bottom of the hand control that allows it to communicate with the NexStar Observer List software. Establishing a link with your NexStar will require the use of an optional RS-232 cable (#93920) available through your local Celestron dealer. Before attempting to create a link with your computer, you must do the following:

- 1. Connect the RS-232 cable Connect the phone jack end of the RS-232 cable to the port on the bottom of the hand control and connect the 9-pin connector to the back of your computer.
- 2. Do a star alignment- Complete any of the star alignment procedures as described in the Instruction manual.

Installation

Very Important: If you currently have an older version of NexStar Observer List installed, you **must** uninstall it prior to installing this new version. Go to the Start Menu, Control Panel, Add/Remove Programs and double-click NexStar Observer List. **If you are prompted whether you want to remove shared components, answer no**. This will leave your current observation lists and User Supplied Objects intact as well as other components that may be used by other programs in your computer.

To install NexStar Observer List Version 2, run the file Setup.exe on the NSOL CD.

Very Important: During the installation process, you may be presented with dialog boxes stating that the installation is trying to replace an already existing file on your system and the existing file is newer. You will be asked if you want to keep the existing file: answer **YES**. Many programs will present you with this option during installation and 99% of the time you should answer yes to keep your existing file. Additionally, you may be presented with a dialog box stating that certain system files are out-of-date on your computer and need to be updated to continue. These files have been updated by Microsoft and are needed to access the database in NexStar Observer List. The updated files address security concerns that have been discovered in many Microsoft products that access databases. If you wish to use NexStar Observer List you will need to allow the setup program to update these files.

The first time you run the program (you will find it was added to Programs on the Start menu), you will be presented with the operating instructions. Please take the time to read the instructions. After the instructions, you will be prompted for basic setup information such as type of telescope, communication port the scope will be connected to, etc. Make sure that your Observing Location and Altitude Control (slew limits) are the same as you entered into the hand control when you aligned the telescope.

If the program won't start after installing and your computer uses Windows 95 or Windows 98, look in the DCOM files on the CD and double-click the DCOM file for your version of Windows. DCOM is a database patch for Windows that comes directly from Microsoft[®].

Uninstalling

If you decide to uninstall NexStar Observer List, simply open Control Panel on the Windows Start Menu, then open Add/Remove Programs. Look for NexStar Observer List and double-click to remove. **Very, very important:** when you are prompted about removing shared files, click the button "Remove None". This will leave components that might be in use by other programs in place and it will also leave any observing lists and the file containing your User Supplied Objects in your data folder (generally C:\Program Files\NSObserverList\Data).

Technical Support

I provide support via email for any questions or problems you might have regarding NexStar Observer List. To contact me, simply send an email to swanson.michael@usa.net. If you received an error message on the screen, please describe what you where doing when you got the error, **provide the full text of the error**, and let me know if you can recreate the error. You may also visit the NexStar Resource Site at www.angelfire.com/ns/nexstar and check the Downloads page for program updates.

Clear Skies and Happy Computing! Mike Swanson

NexStar Communication Protocol

This document describes the serial commands supported by the Celestron NexStar hand control. This information applies to the NexStar GPS, NexStar GPS-SA, NexStar iSeries, NexStar SE Series, NexStar GT, CPC, SLT, Advanced-GT, and CGE mounts.

Communication to the hand control is 9600 bits/sec, no parity and one stop bit via the RS-232 port on the base of the hand control.

Note: the GT hand control prior to version 104.0 should be treated as version 1.2 in the tables below. Version 104.0 should be treated as version 4.03.

Get Position Commands

The following commands retrieve the position of the telescope in either RA/DEC or AZM-ALT coordinates.

The position is returned as a hexadecimal value that represents the fraction of a revolution around the axis. Two examples are given below:

- If the Get RA/DEC command returns 34AB,12CE then the DEC value is 12CE in hexadecimal. As a percentage of a revolution, this is 4814/65536 = 0.07346. To calculate degrees, simply multiply by 360, giving a value of 26.4441 degrees.
- If the precise GET AZM-ALT command returns 12AB0500,40000500 then the AZM value is 12AB0500 in hexadecimal. As a percentage of a revolution, this is 313197824/4294967296 = 0.0729 or 26.252 degrees.

The standard commands offer a precision of 1/65536 * 360 * 60 * 60 = about 19.8 arcseconds per unit while the precise commands offer a precision of 1/16777216 * 360 * 60 = about 0.08 arcseconds per unit (only the upper 24 bits are used).

Note: if the telescope has not been aligned, the RA/DEC values will not be meaningful and the AZM-ALT values will be relative to where the telescope was powered on. After alignment, RA/DEC values will reflect the actual sky, azimuth will be indexed to North equals 0 and altitude will be indexed with 0 equal to the orientation where the optical tube is perpendicular to the azimuth axis.

Command Function	PC Command	Hand Control	Applies to
		Response	Versions
Get RA/DEC	"E″	"34AB,12CE#"	1.2+
Get precise RA/DEC	"e"	"34AB0500,12CE0500#"	1.6+
Get AZM-ALT	"Ζ″	"12AB,4000#"	1.2+
Get precise AZM-ALT	"Z"	"12AB0500,40000500#"	2.2+

GOTO Commands

The following commands direct the telescope to GOTO a specified RA/DEC or AZM-ALT position. As with the Get Position commands, the values are in hexadecimal and represent the fraction of a rotation around the axis.

Trote. Go To To To DEC commands will not work amends the telescope is anglied.	Note:	GOTO RA/DEC	commands will	not work unles	ss the telescop	e is aligned.
--	-------	-------------	---------------	----------------	-----------------	---------------

Command Function	PC Command	Hand Control Response	Applies to Versions
GOTO RA/DEC	"R34AB,12CE"	``# ″	1.2+
GOTO precise RA/DEC	"r34AB0500,12CE0500"	``# ″	1.6+
GOTO AZM-ALT	"B12AB,4000"	``# ″	1.2+

GOIO Precise AZM-ALI "DIZABOSOO,40000500" "#" 2.2+
--

Sync

To Sync to an object via serial commands, the user should center a known object in an eyepiece. Then the Sync serial command should be sent, using the celestial coordinates (RA and DEC) for that object. This causes future GOTO or Get Position commands to use coordinates relative to the Sync'd position, improving pointing accuracy to nearby objects. (we probably don't need to mention "from the planetarium package" since it also improves pointing accuracy if they GoTo objects via the hand control.) The format for the RA/DEC positions in the Sync command is identical to the GOTO RA/Dec command.

Command Function	PC Command	Hand Control Response	Applies to Versions
Sync RA/DEC	"S34AB,12CE"	``# ″	4.10+
Sync precise RA/DEC	"s34AB0500,12CE0500"	``# ″	4.10+

Tracking Commands

The following commands retrieve or set the tracking mode.

Depending on the mount type, following tracking modes are available:

0 = Off

1 = Alt/Az

2 = EQ North

3 = EQ South

Note: On the CGE and Advanced GT hand control versions 3.01 through 3.04 the value for EQ North is 1 and EQ South is 2. This has been corrected to match the other models in current hand control versions.

Command Function	PC Command	Hand Control Response	Applies to Versions
Get Tracking Mode	"t"	chr(mode) & "#"	2.3+
Set Tracking Mode	"T" & chr(mode)	``# ″	1.6+

Slewing Commands

The following commands allow you to slew (move) the telescope at fixed or variable rates.

For **variable rates**, multiply the desired rate by 4 and then separate it into a high and low byte. For example if the desired tracking rate is 150 arcseconds/second, then:

trackRateHigh = $(150 * 4) \setminus 256 = 2$, and trackRateLow = $(150 * 4) \mod 256 = 88$

For fixed rates, simply use a value from 1-9 (or 0 to stop) to mimic the equivalent hand control rates.

Note: in most configurations, issuing the slew commands will override (or conflict with) the tracking mode of the mount. Hence it is always best to disable tracking first using the **Tracking Commands**, issue the slew command, then re-enable tracking. The main exception to this is when tracking equatorially - the **fixed rate** slews at 1 or 2 will not override tracking. This can be useful to simulate autoguiding.

Note: on GT models, the fixed rate slews at rate 9 move at 3 degrees per second instead of the maximum rate.

Command Function	PC Command	Hand Control	Applies to
		Response	Versions
Variable rate Azm (or RA) slew in positive	"P" & chr(3) &	``# ″	1.6+
direction	chr(16) & chr(6) &		
	chr(trackRateHigh) &		
	chr(0) &		
	chr(0)		
Variable rate Azm (or	"P" &	``# ″	1.6+
direction	chr(3) & chr(16) &		
	chr(7) &		
	chr(trackRateHign) & chr(trackRateLow) &		
	chr(0) &		
	chr(0)		
Variable rate Alt (or	"P" &	``# <i>'</i> '	1.6+
direction	chr(3) & chr(17) &		
	chr(6) &		
	chr(trackRateHigh) & chr(trackRateLow) &		
	chr(0) &		
	chr(0)		
Variable rate Alt (or	P'' &	``# ″	1.6+
direction	chr(17) &		
	chr(7) &		
	chr(trackRateHigh) & chr(trackRateLow) &		
	chr(0) &		
	chr(0)		
Fixed rate Azm (or RA)	"P" &	``# ″	1.6+
direction	chr(16) &		
	chr(36) &		
	chr(rate) &		
	chr(0) &		
Fired note Jam (an DJ)	chr(0)	N##	1 6
slew in negative	r^{α}	H	1.0+
direction	chr(16) &		
	chr(37) &		
	chr(rate) &		
	$\operatorname{cnr}(0) \&$ $\operatorname{chr}(0) \&$		
	chr(0)		
Fixed rate Alt (or DEC)	"P" &	``# ″	1.6+

slew in positive	chr(2) &		
direction	chr(17) &		
	chr(36) &		
	chr(rate) &		
	chr(0) &		
	chr(0) &		
	chr(0)		
Fixed rate ALT (or DEC)	"P″ &	``# ″	1.6+
slew in negative	chr(2) &		
direction	chr(17) &		
	chr(37) &		
	chr(rate) &		
	chr(0) &		
	chr(0) &		
	chr(0)		

Time/Location Commands (Hand Control)

The following commands set the time and location in the hand control.

The format of the location commands is: ABCDEFGH, where:

A is the number of degrees of latitude.

B is the number of minutes of latitude.

C is the number of seconds of latitude.

D is 0 for north and 1 for south.

E is the number of degrees of longitude.

F is the number of minutes of longitude.

G is the number of seconds of longitude.

H is 0 for east and 1 for west.

For example, to set the location to $118^{\circ}20'17"$ W, $33^{\circ}50'41"$ N, you would send (note that latitude is before longitude): "W" & chr(33) & chr(50) & chr(41) & chr(0) & chr(118) & chr(20) & chr(17) & chr(1)

The format of the time commands is: QRSTUVWX, where:

Q is the hour (24 hour clock).

R is the minutes.

S is the seconds.

T is the month.

U is the day.

V is the year (century assumed as 20).

W is the offset from GMT for the time zone. Note: if zone is negative, use 256-zone.

X is 1 to enable Daylight Savings and 0 for Standard Time.

For example, to set the time to 3:26:00 PM on April 6, 2005 in the Eastern time zone (-5 UTC: 256-5 = 251) you would send:

"H" & chr(15) & chr(26) & chr(0) & chr(4) & chr(6) & chr(5) & chr(251) & chr(1)

Note: All values are sent in binary format, not ASCII.

Note: The Get commands do **not** retrieve the time and location from the GPS unit (if one is present). The time and location are retrieved from the hand control. You must first enter the View Time/Site menu to update the hand control time if you want the time from the GPS or, use the GPS Commands in the next section.

Command Function	PC Command	Hand	Applies to
		Control	Versions

		Response	
Get Location	"w"	chr(A) &	2.3+
		chr(B) &	
		chr(C) &	
		chr(D) &	
		chr(E) &	
		chr(F) &	
		chr(G) &	
		chr(H) &	
		``# ″	
Set Location	"W" &	``# ″	2.3+
	chr(A) &		
	chr(B) &		
	chr(C) &		
	chr(D) &		
	chr(E) &		
	chr(F) &		
	chr(G) &		
	chr(H)		
Get Time	"h"	chr(Q) &	2.3+
		chr(R) &	
		chr(S) &	
		chr(T) &	
		chr(U) &	
		chr(V) &	
		chr(W) &	
		chr(X) &	
		` # <i>'</i>	
Set Time	"H" &	``# ″	2.3+
	chr(Q) &		
	chr(R) &		
	chr(S) &		
	chr(T) &		
	chr(U) &		
	chr(V) &		
	chr(W) &		
	chr(X)		

GPS Commands

The following table shows various commands that can be sent to a GPS unit. Note: all units of time are in UT.

Command Function	PC Command	Hand Control	Applies to
		Response	Versions
Is GPS Linked?	"P″ &	chr(x) &	1.6+
	chr(1) &	``# ″	
X > 0 if linked, 0 if	chr(176) &		
not linked	chr(55) &		
	chr(0) &		
	chr(0) &		
	chr(0) &		
	chr(1)		
Get Latitude	"P" &	chr(x) &	1.6+
	chr(1) &	chr(y) &	
((x*65536)+(y*256)+z)/(2	chr(176) &	chr(z) &	

^24) is a fraction of a rotation. To convert to degrees, multiply by 360.	chr(1) & chr(0) & chr(0) & chr(0) & chr(3)	"# <i>"</i>	
<pre>Get Longitude ((x*65536)+(y*256)+z)/(2 ^24) is a fraction of a rotation. To convert to degrees, multiply by 360.</pre>	<pre>"P" & chr(1) & chr(176) & chr(2) & chr(0) & chr(0) & chr(0) & chr(0) & chr(3)</pre>	chr(x) & chr(y) & chr(z) & "#"	1.6+
Get Date x is month (1-12) y is day (1-31)	<pre>"P" & chr(1) & chr(176) & chr(3) & chr(0) & chr(0) & chr(0) & chr(0) & chr(2)</pre>	chr(x) & chr(y) & "#"	1.6+
Get Year (x * 256) + y = year	<pre>"P" & chr(1) & chr(176) & chr(4) & chr(0) & chr(0) & chr(0) & chr(2)</pre>	chr(x) & chr(y) & "#"	1.6+
Get Time x is the hours y is the minutes z is the seconds	<pre>"P" & chr(1) & chr(176) & chr(51) & chr(0) & chr(0) & chr(0) & chr(10) & chr(10)</pre>	chr(x) & chr(y) & chr(z) & "#"	1.6+

RTC Commands

The following table shows various RTC commands on the CGE mount.

Command Function	PC Command	Hand Control	Applies to
		Response	Versions
Get Date	"P″ &	chr(x) &	1.6+
	chr(1) &	chr(y) &	
x is month (1-12)	chr(178) &	``# ″	
y is day (1-31)	chr(3) &		
	chr(0) &		
	chr(0) &		
	chr(0) &		

	chr(2)		
Get Year (x * 256) + y = year	<pre>"P" & chr(1) & chr(178) & chr(4) & chr(0) & chr(0) & chr(0) & chr(0) & chr(2)</pre>	chr(x) & chr(y) & "#"	1.6+
Get Time x is the hours y is the minutes z is the seconds	<pre>"P" & chr(1) & chr(178) & chr(51) & chr(0) & chr(0) & chr(0) & chr(0) & chr(3)</pre>	chr(x) & chr(y) & chr(z) & "#"	1.6+
Set Date x is month (1-12) y is day (1-31)	<pre>"P" & chr(3) & chr(178) & chr(131) & chr(x) & chr(y) & chr(0) & chr(0)</pre>	" #"	3.01+
Set Year (x * 256) + y = year	<pre>"P" & chr(3) & chr(178) & chr(178) & chr(132) & chr(x) & chr(y) & chr(0) & chr(0)</pre>	"# <i>"</i>	3.01+
Set Time x is the hours y is the minutes z is the seconds	<pre>"P" & chr(4) & chr(178) & chr(179) & chr(x) & chr(y) & chr(z) & chr(0)</pre>	``# <i>"</i>	3.01+

Miscellaneous Commands

Command Function	PC Command	Hand Control Response	Applies to Versions
Get Version	"V"	chr(major) & chr(minor) & "#"	1.2+

Get Device Version	"P″&	chr(major) &	1.6+
	chr(1) &	chr(minor) &	
Devices include:	chr(dev) &	``# ″	
16 = AZM/RA Motor	chr(254) &		
17 = ALT/DEC Motor	chr(0) &		
176 = GPS Unit	chr(0) &		
178 = RTC (CGE only)	chr(0) &		
	chr(2)		
Get Model	"m"	chr(model) &	2.2+
1 = GPS Series		``# ″	
3 = i-Series			
4 = i-Series SE			
5 = CGE			
6 = Advanced GT			
7 = SLT			
9 = CPC			
10 = GT			
11 = 4/5 SE			
12 = 6/8 SE			
Echo	"K" &	chr(x) & "#"	1.2+
- useful to check	chr(x)		
communication			
Is Alignment Complete?	"J"	chr(align) &	1.2+
- align=1 if aligned and		#	
0 if not			
Is GOTO in Progress?	"L″	prog & "#"	1.2+
- Response is ASCII "O"			
or "1"			
Cancel GOTO	"M"	``# ″	1.2+

Developer Notes

Timeouts

If the hand control is sent a command that requires it to communicate with another device, then the hand control will make multiple attempts to get the message through in the event of communications problems. Examples include "Get Position" commands, "GOTO in Progress" commands, etc.

Software drivers should be prepared to wait up to 3.5s (worst case scenario) for a hand control response. If serial commands are "blindly" sent without waiting for a response, then some commands may be dropped or the software driver could see responses that are for earlier commands.

Pass-through Commands with No Response

Commands that start with 'P' are special pass-through commands that communicate with a specific telescope device. For instance, the Slew commands talk directly to the motor control. If a 'P' command is sent but no response is returned (because the device is not there or the command is unknown or there was a communication problem) then one extra data byte is returned before the '#' terminating character and any returned data is garbage. This is done to give software drivers a flag that something went wrong so appropriate action can be taken. It is particularly useful if you want to check for the existence of a device: for instance, check the time from the GPS unit, and look for an error response. Software drivers should check for the '#' termination character and if it is a different character then the next character (hopefully '#') should be consumed and any command-specific handling should be done.





NexStar SLT

NexStar 60 . NexStar 80 . NexStar 102 . NexStar 114 . NexStar 130

TABLE OF CONTENTS

INTRODUCTION	
Warning	
ASSEMBLY	7
Assembling the NexStar	
Attaching the Hand Control Holder	
Attaching the Fork Arm to the Tripod	
Attaching the Telescope to the Fork Arm	
The Star Diagonal	
The Eyepiece	9
Focusing	9
The Star Pointer Finderscope	9
Star Pointer Installation	
Star Pointer Operation	
Attaching the Hand Control	
Powering the NexStar	
HAND CONTROL	
The Hand Control	
Hand Control Operation	
Alignment Procedure	
Sky Align	
Auto Two-Star Align	
Two Star Alignment	
One-Star Align	
Solar System Align	
NexStar Re-Alignment	
Object Catalog	
Selecting an Object	
Slewing to an Object	
Finding Planets	
Tour Mode	
Constellation Four	
Direction Buttons	
Kate Button	
Tracking Made	
Tracking Mode	
View Time Site	
View Time-Site	
Get R A /DEC	
Goto R A/Dec	
Identify	
Scone Setur Features	
Anti-hacklash	
Slew I imits	
Filter Limits	22
Direction Buttons	23
Goto Approach	23
Cordwrap	23
Utility Features	
GPS On/Off	
Light Control.	
Factory Setting	
Version	
Get Alt-Az	
Goto Alt-Az	
Hibernate	
Sun Menu	
Scrolling Menu	
TELESCOPE BASICS	

Focusing	
Image Orientation	
Calculating Magnification	
Determining Field of View	
General Observing Hints	
CELESTIAL OBSERVING	
Observing the Moon	
Lunar Observing Hints	
Observing the Planets	
Planetary Observing Hints	
Observing the Sun	
Solar Observing Hints	
Observing Deep Sky Objects	
Seeing Conditions	
Transparency	
Sky Illumination	
Seeing	
TELESCOPE MAINTENANCE	
Care and Cleaning of the Optics	
Collimation	
OPTIONAL ACCESSORIES	
APPENDIX A - TECHNICAL SPECIFICATIONS	
APPENDIX B – GLOSSARY OF TERMS	
APPENDIX C - RS-232 CONNECTION	
APPENDIX D - TIME ZONE MAPS	
SKY MAPS	

Cellistrow Introduction

Congratulations on your purchase of the Celestron NexStar telescope! The NexStar ushers in a whole new generation of computer automated technology. Simple and friendly to use, the NexStar is up and running after locating just three bright celestial objects. It's the perfect combination of power and portability. If you are new to astronomy, you may wish to start off by using the NexStar's built-in Sky Tour feature, which commands the NexStar to find the most interesting objects in the sky and automatically slews to each one. Or if you are more experienced , you will appreciate the comprehensive database of over 4,000 objects, including customized lists of all the best deep-sky objects, planets bright double stars. No matter at what level you are starting out, the NexStar will unfold for you and your friends all the wonders of the Universe.

Some of the many standard features of the NexStar include:

- Incredible 4°/second slew speed.
- Fully enclosed motors and optical encoders for position location.
- Computerized hand controller with 4,000 object database.
- Storage for programmable user defined objects; and
- Many other high performance features!

The NexStar's deluxe features combined with Celestron's legendary optical standards give amateur astronomers one of the most sophisticated and easy to use telescopes available on the market today.

Take time to read through this manual before embarking on your journey through the Universe. It may take a few observing sessions to become familiar with your NexStar, so you should keep this manual handy until you have fully mastered your telescope's operation. The NexStar hand control has built-in instructions to guide you through all the alignment procedures needed to have the telescope up and running in minutes. Use this manual in conjunction with the on-screen instructions provided by the hand control. The manual gives detailed information regarding each step as well as needed reference material and helpful hints guaranteed to make your observing experience as simple and pleasurable as possible.

Your NexStar telescope is designed to give you years of fun and rewarding observations. However, there are a few things to consider before using your telescope that will ensure your safety and protect your equipment.

Warning



- □ Never look directly at the sun with the naked eye or with a telescope (unless you have the proper solar filter). Permanent and irreversible eye damage may result.
- Never use your telescope to project an image of the sun onto any surface. Internal heat build-up can damage the telescope and any accessories attached to it.
- □ Never use an eyepiece solar filter or a Herschel wedge. Internal heat build-up inside the telescope can cause these devices to crack or break, allowing unfiltered sunlight to pass through to the eye.
- □ Never leave the telescope unsupervised, either when children are present or adults who may not be familiar with the correct operating procedures of your telescope.



1	Objective Lens	8	On/Off Switch
2	Fork Arm	9	Focuser Knob
3	Battery Compartment	10	Star Diagonal
4	Hand Control	11	Eyepiece
5	Tripod	12	Star Pointer Finderscope (not shown)
6	Tripod Leg Extension Clamp	13	Dovetailed Mounting Clamp
7	Accessory Tray	14	Telescope Tube



1	Eyepiece	7	Tripod Leg Extension Clamp
2	Secondary Mirror	8	Accessory Tray
3	Fork Arm	9	On/Off Switch
4	Battery Compartment	10	Collimation Adjustment Knobs
5	Tripod	11	Optical Tube
6	Hand Control	12	Star Pointer Finderscope



The NexStar comes partially assembled and can be operational in a matter of minutes. The NexStar is conveniently packaged in one reusable shipping carton that contains the following accessories:

- 25mm and 9mm Eyepieces 1¹/₄"
- 1¹/₄" Star Diagonal (NexStar 60, 80 & 102 only)
- Star Pointer Finderscope and Mounting Bracket
- Deluxe Accessory Tray
- The SkyTM Level 1 Astronomy Software
- NSOL Telescope Control Software
- NexStar Hand Control w/ Object Database

Assembling the NexStar

Your NexStar comes in three major sections: the optical tube, the fork arm and the tripod. These sections can be attached in seconds using the quick release coupling screw located under the tripod mounting platform and the dovetail mounting clamp located on the inside of the fork arm. To begin, remove all of the accessories from their individual boxes. Remember to save all of the containers so that they can be used to transport the telescope. Before attaching the visual accessories, the telescope tube should be mounted to its tripod. First, install the accessory tray onto the tripod legs:

- 1. Remove the tripod from the box and spread the legs apart until the center leg brace is fully extended.
- 2. Locate the accessory tray, and place it on top of the tripod center support brace in between the tripod legs (see figure 2-1)
- 3. Rotate the accessory tray so that the central hole in the tray slides over the flange post in the center of the support bracket.
- 4. Finally, rotate the tray so that the locking tabs slide under the locking clips on support bracket. You will here the tray snap into place.



Figure 2-1

It is a good idea to level the tripod and adjust the height of the tripod legs before attaching the fork arm and tube. Minor adjustments can be made later. To adjust the height of the tripod legs:

- 1. Loosen the tripod leg locking bolt located on the side of each leg.
- 2. Slide the inner portion of each leg down 6" to 8" inches.
- 3. Adjust the tripod height until the bubble level on the tripod leg is centered.
- 4. Tighten the tripod locking bolts to hold each leg in place.



Figure 2-2

Attaching the Hand Control Holder

The NexStar comes with a snap-on hand control holder that conveniently attaches to any of the tripod legs. To attach the hand control holder simply position the holder with the square plastic tab facing up and push against the tripod leg until it snaps in to place.

Attaching the Fork Arm to the Tripod

With the tripod properly assembled, the telescope tube and fork arm can easily be attached using the quick release coupling screw located underneath the tripod mounting platform:

- 1. Place the fork arm base inside the tripod mounting platform.
- 2. Thread the coupling screw into the hole at the bottom of the fork arm base and hand tighten.



Figure 2-4

Attaching the Telescope to the Fork Arm

Your telescope optical tube has a built on dovetail mounting bar used to attach the tube to the fork arm. To attach the telescope tube:

- 1. Loosen the tube clamp tightening knob.
- 2. Slide the dovetail mounting bar of the telescope tube into the fork arm clamp. Make sure that the logo on the side of the tube is right side up when the tube is aligned with the fork arm.
- 3. Tighten the tube clamp knob by hand to secure the tube to the fork arm.

Your NexStar is fully assembled and is ready to attach the accessories.

The Star Diagonal

(For 60, 80 and 102mm Models Only)

The star diagonal diverts the light at a right angle from the light path of the telescope. For astronomical observing, this allows you to observe in positions that are more comfortable than if you were to look straight through. To attach the star diagonal:

- 1. Turn the thumbscrew on the eyepiece adapter at the end of the focuser barrel until it no longer extends into (i.e., obstructs) the inner diameter of the focus barrel. Remove the protective dust cap from the focuser barrel.
- 2. Slide the chrome portion of the star diagonal into the eyepiece adapter.
- 3. Tighten the thumbscrew on the eyepiece adapter to hold the star diagonal in place.



Figure 2-3



Figure 2-5

If you wish to change the orientation of the star diagonal, loosen the thumbscrew on the eyepiece adapter until the star diagonal rotates freely. Rotate the diagonal to the desired position and tighten the thumbscrew.

The Eyepiece

The eyepiece, is the optical element that magnifies the image focused by the telescope. The eyepiece fits either directly into the focuser (114mm and 130mm models) or into the star diagonal (60, 80, or 102mm models). To install the eyepiece:

For 60, 80, and 102mm models:

- 1. Loosen the thumbscrew on the star diagonal so it does not obstruct the inner diameter of the eyepiece end of the diagonal. Remove the protective dust cap from the star diagonal's barrel.
- 2. Slide the chrome portion of the low power 25mm eyepiece into the star diagonal.
- 3. Tighten the thumbscrew to hold the eyepiece in place.

To remove the eyepiece, loosen the thumbscrew on the star diagonal and slide the eyepiece out.

For 114 and 130mm models:

- 1. Loosen the thumb screw on the eyepiece adapter at the end of the focuser barrel and remove the protective dust cap from the focuser barrel.
- 2. Slide the chrome portion of the low power 25mm eyepiece into the eyepiece adapter.
- 3. Tighten the thumbscrew to hold the eyepiece in place.

To remove the eyepiece, loosen the thumbscrew on the eyepiece barrel and slide the eyepiece out.

Eyepieces are commonly referred to by focal length and barrel diameter. The focal length of each eyepiece is printed on the eyepiece barrel. The longer the focal length (i.e., the larger the number) the lower the eyepiece power or magnification; and the shorter the focal length (i.e., the smaller the number) the higher the magnification. Generally, you will use low-tomoderate power when viewing. For more information on how to determine power, see the section on "Calculating Magnification."



Focusing

To focus your telescope, simply turn either of the focus knobs at the eyepiece end of the optical tube (see figures 2-6 and 2.7). Turn the focus knob until the image is sharp. Once sharp, turn the knob towards you to focus on an object that is closer than the one you are currently observing. Turn the knob away from you to focus on a more distant object than the one you are currently observing.

The Star Pointer Finderscope

The Star Pointer is the quickest and easiest way to point your telescope exactly at a desired object in the sky. It's like having a laser pointer that you can shine directly onto the night sky. The Star Pointer is a zero magnification pointing tool that uses a coated glass window to superimpose the image of a small red dot onto the night sky. While keeping both eyes open when looking through the Star Pointer, simply move your telescope until the red dot, seen through the Star Pointer, merges with the object as seen with your unaided eye. The red dot is produced by a light-emitting diode (LED); it is not a laser beam and will not damage the glass window or your eye.





The Star Pointer comes equipped with a variable brightness control, two axes alignment control and mounting brackets. Before the Star Pointer is ready to be used, it must be attached to the telescope tube and properly aligned:



Star Pointer Installation

- 1. Slide the Star Pointer onto the dovetail mounting platform on top of the focuser assembly so that the sight tube is facing towards the front of the tube.
- 2. Tighten the mounting screw to secure the Star Pointer in place.

Star Pointer Operation

The star pointer is powered by a long life 3-volt lithium battery (#CR2032) located underneath the front portion of the Star Pointer. Like all finderscopes, the Star Pointer must be properly aligned with the main telescope before it can be used. This is a simple process using the azimuth and altitude control knobs located on the side and bottom of the Star Pointer. The alignment procedure is best done at night since the LED dot will be difficult to see during the day.

To align the Star Pointer finderscope:

- 1. Before using the StarPointer, you must first remove the protective plastic cover between the battery and the battery clip.
- 2. To turn on the Star Pointer, slide the On/Off switch to the 1 "On" position. To increase the brightness level of the red dot, slide the switch to the 2 "On" position.
- 3. Locate a bright star or the Moon and center it in a low power eyepiece in the main telescope.
- 4. With both eyes open, look through the glass window at the alignment star.
- 5. If the Star Pointer is perfectly aligned, you will see the red LED dot overlap the alignment star. If the Star Pointer is not aligned, take notice of where the red dot is relative to the bright star.
- 6. Without moving the main telescope, turn the Star Pointer's azimuth and altitude adjustment knobs until the red dot is directly over the alignment star.

The Star Pointer is now ready to be used. **Remember to always turn the power off after you have found an object. This will extend the life of both the battery and the LED.**

Attaching the Hand Control

The NexStar SLT hand control has a phone jack type connector at the end of its cord. Plug the phone jack connector into the outlet at the base of the telescope's fork arm. Push the connector into the outlet until it clicks into place and place the hand control into its holder as described previously in the Assembly section of the manual



Powering the NexStar

The NexStar SLT can be powered by 8 user supplied AA size alkaline batteries or an optional 12v AC adapter. To install batteries into the NexStar:

- 1. Squeeze the tabs on both sides of the battery compartment cover while lifting upward.
- 2. Insert 8 AA batteries in to battery compartment holders.
- 3. Place the battery compartment cover over the batteries and push down until the cover snaps in place.
- 4. Flip the power switch to the "On" position. The light on the power button should come on.

In case of a loss of power, the optical tube can be moved by hand. However, when powered on, the telescope should always be controlled via the hand control. The NexStar will lose its star alignment if moved by hand when powered on.





The Hand Control

The NexStar SLT's hand controller is designed to give you instant access to all the functions the NexStar has to offer. With automatic slewing to over 4,000 objects, and common sense menu descriptions, even a beginner can master its variety of features in just a few observing sessions. Below is a brief description of the individual components of the NexStar SLT hand controller:

- 1. Liquid Crystal Display (LCD) Window: Has a dual-line, 16 character display screen that is backlit for comfortable viewing of telescope information and scrolling text.
- 2. Align: Instructs the NexStar to use a selected star or object as an alignment position.
- 3. **Direction Keys:** Allows complete control of the NexStar in any direction. Use the direction keys to center objects in the StarPointer finderscope and eyepiece.
- 4. **Catalog Keys:** The NexStar has a key on the hand control to allow direct access to each of the catalogs in its 4,000+ object database. The NexStar contains the following catalogs in its database:

Messier – Complete list of all Messier objects.

NGC - Many of the brightest deep sky objects from the Revised New General Catalog.

Caldwell - A combination of the best NGC and IC objects.

Planets - All 8 planets in our Solar System plus the Moon and Sun.

Stars – A compiled list of the brightest stars from the SAO catalog.

List – For quick access, all of the best and most popular objects in the NexStar database have been broken down into lists based on their type and/or common name:

Named Stars	Common name listing of the brightest stars in the sky.			
Named Objects	Alphabetical listing of over 50 of the most popular deep			
	sky objects.			
Double Stars	Alphabetical listing of the most visually stunning double, triple and quadruple stars in the sky.			
Variable Stars	Select list of the brightest variable stars with the shortest period of changing magnitude.			
Asterisms	A unique list of some of the most recognizable star patterns in the sky.			



- 5. Info: Displays coordinates and useful information about objects selected from the NexStar database.
- 6. **Tour:** Activates the tour mode, which seeks out all the best objects for a given month and automatically slews the NexStar to those objects.
- 7. Enter: Pressing *Enter* allows you to select any of the NexStar functions, accept entered parameters and slew the telescope to displayed objects.
- 8. **Undo:** *Undo* will take you out of the current menu and display the previous level of the menu path. Press *Undo* repeatedly to get back to a main menu or use it to erase data entered by mistake.
- 9. Menu: Displays the many setup and utilities functions such as tracking rate and user defined objects and many others.
- 10. **Scroll Keys:** Used to scroll up and down within any of the menu lists. A double arrow symbol on the right side of the LCD indicates that the scroll keys can be used to view additional information.
- 11. Rate: Instantly changes the rate of speed of the motors when the direction buttons are pressed.
- 12. RS-232 Jack: Allows use with a computer and software programs for point and click slewing capability.

Hand Control Operation

This section describes the basic hand control procedures needed to operate the NexStar. These procedures are grouped into three categories: Alignment, Setup and Utilities. The alignment section deals with the initial telescope alignment as well as finding objects in the sky; the setup section discusses changing parameters such as tracking mode and tracking rate; finally, the last section reviews all of the utility functions such as adjusting the telescopes slew limits and backlash compensation.

Alignment Procedure

In order for the NexStar to accurately point to objects in the sky, it must first be aligned to known positions (stars) in the sky. With this information, the telescope can create a model of the sky, which it uses to locate any object with known coordinates. There are many ways to align the NexStar with the sky depending on what information the user is able to provide: **SkyAlign** uses your current date, time and city to create an accurate model of the sky. Then the user can simply point the telescope to any three bright celestial objects to accurately align the telescope with the sky. **Auto Two-Star Align** will ask the user to choose and center the first alignment star, then the NexStar will automatically select and slew to a second star for alignment. **Two-Star Alignment** requires the user to identify and manually slew the telescope to the two alignment stars. **One-Star Align** is the same as Two-Star Align however only requires you to align to one known star. Although not as accurate as the other alignment methods, One-Star Align is the quickest way to find and track bright planets and objects in Altazimuth mode. Finally, **Solar System Align** will display a list of visible daytime objects (planets and the moon) available to align the telescope. Each alignment method is discussed in detail below.

Definition

"Altazimuth" or "Alt-Az" refers to a type of mounting that allows a telescope to move in both altitude (up and down) and azimuth (left and right) with respect to the ground. This is the simplest form of mounting in which the telescope is attached directly to a tripod.

Sky Align

Sky Align is the easiest way to get your NexStar aligned and ready to observe. Even if you do not know a single star in the sky, the NexStar will have you aligned in minutes by asking for basic information like the date, time and location. Then you simply need to aim the telescope to any three bright celestial objects in the sky. Since Sky Align requires no knowledge of the night sky it is not necessary to know the name of the stars at which you are aiming. You may even select a planet or the moon. The NexStar is then ready to start finding and tracking any of the objects in its 4,000+ object database. Before the telescope is ready to be aligned, it should be set up in an outside location with all accessories (eyepiece, diagonal and finderscope) attached and lens cover removed as described in the Assembly section of the manual. To begin Sky Align:

- *I.* Power on the NexStar by flipping the switch located on the side of the fork arm, to the "on" position. Once turned on the hand control display will say NexStar SLT. Press ENTER to choose *Sky Align*. Pressing the ALIGN key will bypass the other alignment options and the scrolling text and automatically begins *Sky Align*.
- 2. Once *Sky Align* has been selected, the hand control will display "Enter if OK", "Undo to edit" and "Saved Site". The bottom line of the LCD will display either the current time or the time when you last used the telescope. Since this is your first time using the NexStar, press UNDO to enter current time/site information.

The hand control display will then ask for the following information:

- *Location* The NexStar will display a list of cities to choose from. Choose the city from the database that is closest to your current observing site. The city you choose will be remembered in the hand controls memory so that it will be automatically displayed the next time an alignment is done. Alternatively, if you know the exact longitude and latitude of your observing site, it can be entered directly into the hand control and remembered for future use as well. To choose a location city:
- □ Use the Up and Down scroll keys to choose between *City Database* and *Custom Site*. *City Database* will allow you to select the closest city to your observing site from a list of either international or U.S. location. *Custom Site* allows you to enter the exact longitude and latitude of your observing site. Select *City Database* and press ENTER.
- □ The hand control will allow you to choose from either U.S. or international locations. For a listing of U.S. locations by state and then by city, press ENTER while United States is displayed. For international locations, use the Up or Down scroll key to select International and press ENTER.
- □ Use the Up and Down Scroll buttons to choose your current state (or country if International locations was selected) from the alphabetical listing and press ENTER.
- □ Use the Up and Down Scroll buttons to choose the closest city to your location from the displayed list and press ENTER.

- *Time* Enter the current time for your area. You can enter either the local time (i.e. 8:00), or you can enter military time (i.e. 20:00).
- □ Select PM or AM. If military time was entered, the hand control will bypass this step.
- □ Choose between Standard time or Daylight Savings time. Use the Up and Down scroll buttons (10) to toggle between options.
- □ Select the time zone that you are observing from. Again, use the Up and Down buttons (10) to scroll through the choices. For time zone information, refer to the Time Zone map in the appendix of this manual.
- Date Enter the month, day and year of your observing session. The display will read: mm/dd/yy.
- If the wrong information has been input into the hand control, the UNDO button will act as a backspace allowing the user to re-enter information.
- The next time that your NexStar is aligned, the hand control will automatically display the last location (either a city or longitude/latitude) that was entered. Press ENTER to accept these parameters if they still apply. Pressing the UNDO button will allow you to go back and select a new city location or longitude/latitude.
- 3. Use the arrow buttons on the hand control to slew (move) the telescope towards any bright celestial object in the sky. Align the object with the red dot of the finderscope and press ENTER.
- 4. If the finderscope has been properly aligned with the telescope tube, the alignment star should now be visible inside the field of view of the eyepiece. The hand control will ask that you center the bright alignment star in the center of the eyepiece and press the ALIGN button. This will accept the star as the first alignment position. (There is no need to adjust the slewing rate of the motors after each alignment step. The NexStar automatically selects the best slewing rate for aligning objects in both the finderscope and the eyepiece).
- 5. For the second alignment object, choose a bright star or planet as far as possible from the first alignment object. Once again use the arrow button to center the object in the finderscope and press ENTER. Then once centered in the eyepiece press the ALIGN button.
- 6. Repeat the process for the third alignment star. When the telescope has been aligned to the final stars, the display will read "Match Confirmed". Press UNDO to display the names of the three bright objects you aligned to, or press ENTER to accept these three objects for alignment. You are now ready to find your first object.

Tips for Using Sky Align

Remember the following alignment guidelines to make using Sky Align as simple and accurate as possible.

- Be sure to level the tripod before you begin alignment. The time/site information along with a level tripod will help the telescope better predict the available bright stars and planets that are above the horizon.
- Remember to select alignment stars that are as far apart in the sky as possible. For best results make sure that the third alignment star does not lie in a straight line between the first two stars. This may result in a failed alignment.
- Don't worry about confusing planets for stars when selecting alignment objects. SkyAlign works with the four brightest planets (Venus, Jupiter, Saturn and Mars) as well as the Moon. In addition to the planets, the hand control has over 80 bright alignment stars to choose from (down to 2.5 magnitude).
- Rarely SkyAlign will not be able to determine what three alignment objects were centered. This sometime happens when a bright planet or the Moon passes near one of the brighter stars. In situations like these it is best to try to avoid aligning to either object if possible.
- Be sure to center the objects with the same final movements as the direction of the GoTo Approach. For example, if the scope normally finishes a GoTo with the front of the scope moving right and up, you should center all three alignment objects in the eyepiece using the right and up arrow buttons (the up/down arrows reverse at slew rates of 6 or lower). Approaching the star from this direction when looking through the eyepiece will eliminate much of the backlash between the gears and assure the most accurate alignment possible.



Auto Two-Star Align

As with Sky Align, Auto Two-Star Align requires you to enter all the necessary time/site information as before. Once this information is entered, NexStar will prompt you to select and point the telescope at one known star in the sky. The NexStar now has all the information it needs to automatically choose a second star that will assure the best possible alignment. Once selected the telescope will automatically slew to that second alignment star to complete the alignment. With the NexStar set up outside with all accessories attached and the tripod leveled, follow the steps below to align the telescope:

- 1. Once the NexStar is powered on, Press ENTER to begin alignment.
- 2. Use the Up and Down scroll keys (10) to select Auto Two-Star Align and press ENTER.
- 3. The hand control will display the last time and location information that was entered into the hand control. Use the Up and Down buttons to scroll through the information. Press ENTER to accept the current information or press UNDO to manually edit the information (see Sky Align section for detailed instruction on entering time/site information).
- 4. The display will now prompt you to select a bright star from the displayed list on the hand control. Use Up and Down buttons (6 and 9 on the keypad) to scroll to the desired star and then press ENTER.
- 5. Use the arrow buttons to slew the telescope to the star you selected. Center the star in the finderscope and press ENTER. Finally, center the star in the eyepiece and press ALIGN.
- 6. Based on this information, the NexStar will automatically display the most suitable second alignment star that is above the horizon. Press ENTER to automatically slew the telescope to the displayed star. If for some reason you do not wish to select this star (perhaps it is behind a tree or building), you can either:
 - Press the UNDO button to display the next most suitable star for alignment.
 - Use the UP and DOWN scroll buttons to manually select any star you wish from the entire list of available stars.

Once finished slewing, the display will ask you to use the arrow buttons to align the selected star with the red dot of the finderscope. Once centered in the finder, press ENTER. The display will then instruct you to center the star in the field of view of the eyepiece. When the star is centered, press ALIGN to accept this star as your second alignment star. When the telescope has been aligned to both stars the display will read Align Success, and you are now ready to find your first object.

Two Star Alignment

With the two-star alignment method, the NexStar requires the user to know the positions of two bright stars in order to accurately align the telescope with the sky and begin finding objects. Here is an overview of the two-star alignment procedure:

- 1. Once the NexStar is powered on, use the Up and Down scroll keys (10) to select Two-Star Align, and press ENTER.
- 2. Press ENTER to accept the time/site information displayed on the display, or press UNDO to enter new information.
- 3. The SELECT STAR 1 message will appear in the top row of the display. Use the Up and Down scroll keys (10) to select the star you wish to use for the first alignment star. Press ENTER.
- 4. NexStar then asks you to center in the eyepiece the alignment star you selected. Use the direction arrow buttons to slew the telescope to the alignment star and carefully center the star in the finderscope. Press ENTER when centered.
 - 5. Then, center the star in the eyepiece and press ALIGN.

In order to accurately center the alignment star in the eyepiece, you may wish to decrease the slew rate of the motors for fine centering. This is done by pressing the RATE key (11) on the hand controller then selecting the number that corresponds to the speed you desire. (9 = fastest, 1 = slowest).

6. NexStar will then ask you to select and center a second alignment star and press the ALIGN key. It is best to choose alignment stars that are a good distance away from one another. Stars that are at least 40° to 60° apart from each other will give you a more accurate alignment than stars that are close to each other.

Helpful Hint

Once the second star alignment is completed properly, the display will read Align Successful, and you should hear the tracking motors turn-on and begin to track.

One-Star Align

One-Star Align requires you to input all the same information as you would for the Two-Star Align procedure. However, instead of slewing to two alignment stars for centering and alignment, the NexStar uses only one star to model the sky based on the information given. This will allow you to roughly slew to the coordinates of bright objects like the moon and planets and gives the NexStar the information needed to track objects in altazimuth in any part of the sky. One-Star Align is not meant to be used to accurately locate small or faint deep-sky objects or to track objects accurately for photography.

To use One-Star Align:

- 1. Select One-Star Align from the alignment options.
- 2. Press ENTER to accept the time/site information displayed on the display, or press UNDO to enter new information.
- 3. The SELECT STAR 1 message will appear in the top row of the display. Use the Up and Down scroll keys (10) to select the star you wish to use for the first alignment star. Press ENTER.
- 4. NexStar then asks you to center in the eyepiece the alignment star you selected. Use the direction arrow buttons to slew the telescope to the alignment star and carefully center the star in the finderscope. Press ENTER when centered.
- 5. Then, center the star in the eyepiece and press ALIGN.
- 6. Once in position, the NexStar will model the sky based on this information and display Align Successful.

Note: Once a One-Star Alignment has been done, you can use the Re-alignment feature (later in this section) to improve your telescope's pointing accuracy.

Solar System Align

Solar System Align is designed to provide excellent tracking and GoTo performance by using solar system objects (Sun, Moon and planets) to align the telescope with the sky. Solar System Align is a great way to align your telescope for daytime viewing as well as a quick way to align the telescope for night time observing.



Never look directly at the sun with the naked eye or with a telescope (unless you have the proper solar filter). Permanent and irreversible eye damage may result.

- 1. Select *Solar System Align* from the alignment options.
- 2. Press ENTER to accept the time/site information displayed on the display, or press UNDO to enter new information.
- 3. The SELECT OBJECT message will appear in the top row of the display. Use the Up and Down scroll keys (10) to select the daytime object (planet, moon or sun) you wish to align. Press ENTER.
- 4. NexStar then asks you to center in the eyepiece the alignment object you selected. Use the direction arrow buttons to slew the telescope to the alignment object and carefully center it in the finderscope. Press ENTER when centered.
- 5. Then, center the object in the eyepiece and press ALIGN.

Once in position, the NexStar will model the sky based on this information and display Align Successful.

Tips for Using Solar System Align

- For safety purposes, the Sun will not be displayed in any of the hand control's customer object lists unless it is enabled from the Utilities Menu. To allow the Sun to be displayed on the hand control, do the following:
- 1. Press the UNDO button until the display reads "NexStar SLT"
- 2. Press the MENU button and use the Up and Down keys to select the Utilities menu. Press ENTER.
- 3. Use the UP and Down keys to select *Sun Menu* and press ENTER.
- 4. Press ENTER again to allow the Sun to appear on the hand control display.

The Sun can be removed from the display by using the same procedure as above.

To improve the telescope pointing accuracy, you can use the Re-Align feature as described below.

NexStar Re-Alignment

The NexStar has a re-alignment feature which allows you to replace either of the original alignment stars with a new star or celestial object. This can be useful in several situations:

- If you are observing over a period of a few hours, you may notice that your original two alignment stars have drifted towards the west considerably. (Remember that the stars are moving at a rate of 15° every hour). Aligning on a new star that is in the eastern part of the sky will improve your pointing accuracy, especially on objects in that part of the sky.
- If you have aligned your telescope using the One-star align method, you can use *re-align* to align to an additional object in the sky. This will improve the pointing accuracy of your telescope without having to reenter addition information.

To replace an existing alignment star with a new alignment star:

- 1. Select the desired star (or object) from the database and slew to it.
- 2. Carefully center the object in the eyepiece.
- 3. Once centered, press the UNDO button until you are at the main menu.
- 4. With NexStar SLT displayed, press the ALIGN key on the hand control.
- 5. The display will then ask you which alignment star you want to replace.
- 6. Use the UP and Down scroll keys to select the alignment star to be replaced, and press ENTER. It is usually best to replace the star closest to the new object. This will space out your alignment stars across the sky. If you have used one of the single object alignment methods then it is always best to replace the object that is "unassigned" with an actual object.
- 7. Press ALIGN to make the change.

Object Catalog

Selecting an Object

Now that the telescope is properly aligned, you can choose an object from any of the catalogs in the NexStar's database. The hand control has a key designated for each of the catalogs in its database. There are two ways to select objects from the database; scrolling through the named object lists and entering object numbers:

- Pressing the LIST key on the hand control will access all objects in the database that have common names or types. Each list is broken down into the following categories: Named Stars, Named Object, Double Stars, Variable Stars and Asterisms. Selecting any one of these options will display an alpha-numeric listing of the objects under that list. Pressing the Up and Down keys (10) allows you to scroll through the catalog to the desired object.
- Pressing any of the catalog keys (M, CALD, NGC, or STAR) will display a blinking cursor below the name of the catalog chosen. Use the numeric key pad to enter the number of any object within these standardized catalogs. For example, to find the Orion Nebula, press the "M" key and enter "042".
- Pressing the PLANET button will allow you to use the UP and DOWN arrow keys to scroll through and select the eight planets as well as the moon.

When scrolling through a long list of objects, holding down either the Up or Down key will allow you to scroll through the catalog at a rapid speed.

When entering the number for a SAO star, you are only required to enter the first four digits of the objects six digit SAO number. Once the first four digits are entered, the hand control will automatically list all the available SAO objects beginning with those numbers. This allows you to scroll through only the SAO stars in the database. For example, in searching for the SAO star 40186 (Capella), the first four digits would be "0401". Entering this number will display the closest match from the SAO stars available in the database. From there you can scroll down the list and select the desired object.

Slewing to an Object

Once the desired object is displayed on the hand control screen, you have two options:

- **Press the INFO Key**. This will give you useful information about the selected object such as magnitude, constellation and fascinating facts about many of the objects.
- **Press the ENTER Key.** This will automatically slew the telescope to the coordinates of the object. While the telescope is slewing to the object, the user can still access many of the hand control functions (such as displaying information about the object).

If you slew to an object that is below the horizon, NexStar will notify you by displaying a message reminding you that you have selected an object outside of your slew limits (see Slew Limits in the Scope Setup section of the manual). Press UNDO to go back and select a new object. Press ENTER to ignore the message and continue the slew. The NexStar hand control will only display objects that are below the horizon if the Filter Limits are set below 0° in altitude. See Filter Limits in the Utility Feature section of the manual for more information on setting the filter limits.

Caution: Never slew the telescope when someone is looking into the eyepiece. The telescope can move at fast slew speeds and may hit an observer in the eye.

Object information can be obtained without having to do a star alignment. After the telescope is powered on, pressing any of the catalog keys allows you to scroll through object lists or enter catalog numbers and view the information about the object as described above.

Finding Planets

The NexStar can locate all 8 of our solar systems planets plus the Sun and Moon. However, the hand control will only display the solar system objects that are above the horizon (or within its filter limits). To locate the planets, press the PLANET key on the hand control. The hand control will display all solar system objects that are above the horizon:

- Use the **Up and Down** keys to select the planet that you wish to observe.
- Press INFO to access information on the displayed planet.
- Press ENTER to slew to the displayed planet.

To allow the Sun to be displayed as an option in the database, see Sun Menu in the Utilities section of the manual.

Tour Mode

The NexStar includes a tour feature which automatically allows the user to choose from a list of interesting objects based on the date and time in which you are observing. The automatic tour will display only those objects that are within your set filter limits. To activate the Tour mode, press the TOUR key on the hand control. The NexStar will display the best objects to observe that are currently in the sky.

- To see information and data about the displayed object, press the INFO key.
- To slew to the object displayed, press ENTER.
- To see the next tour object, press the Down key.

Constellation Tour

In addition to the Tour Mode, the NexStar telescope has a Constellation Tour that allows the user to take a tour of all the best objects within a particular constellation. Selecting *Constellation* from the LIST menu will display all the constellation names that are above the user defined horizon (filter limits). Once a constellation is selected, you can choose from any of the database object catalogs to produce a list of all the available objects in that constellation.

- To see information and data about the displayed object, press the INFO key.
- To slew to the object displayed, press ENTER.
- To see the next tour object, press the Up key.

Direction Buttons

The NexStar has four direction buttons in the center of the hand control which controls the telescope motion in altitude (up and down) and azimuth (left and right). The telescope can be controlled at nine different speed rates.

1 = 2x	$6 = .5^{\circ} / sec$		
2 = 4x	$7 = 1^{\circ}/sec$		
3 = 8x	$8 = 2^{\circ}/sec$		
4 = 16x	$9 = 4^{\circ} / sec$		
5 = 32x			
Nine available slew speeds			

Rate Button

Pressing the RATE key (11) allows you to instantly change the speed rate of the motors from high speed slew rate to precise guiding rate or anywhere in between. Each rate corresponds to a number on the hand controller key pad. The number 9 is the fastest rate (approximately 4° per second, depending on power source) and is used for slewing between objects and locating alignment stars. The number 1 on the hand control is the slowest rate (2x sidereal) and can be used for accurate centering of objects in the eyepiece. To change the speed rate of the motors:

- Press the RATE key on the hand control. The LCD will display the current speed rate.
- Press the number on the hand control that corresponds to the desired speed.

The hand control has a "double button" feature that allows you to instantly speed up the motors without having to choose a speed rate. To use this feature, simply press the arrow button that corresponds to the direction that you want to move the telescope. While holding that button down, press the opposite directional button. This will increase the speed to the maximum slew rate.

When using the Up and Down buttons on the NexStar 60 and 80, the slower slew rates (6 and lower) move the motors in the opposite direction than the faster slew rates (7-9). This is done so that an object will move in the appropriate direction when looking into the eyepiece (i.e. pressing the up arrow button will move the star upwards in the field of view of the eyepiece). However, if any of the slower slew rates (rate 6 and below) are used to center an object in the Star Pointer, you may need to press the opposite directional button to make the telescope move in the correct direction.

Set Up Procedures

The NexStar contains many user defined setup functions designed to give the user control over the telescope's many advanced features. All of the set up and utility features can be accessed by pressing the MENU key and scrolling through the options:

Tracking Mode	Once the NexSta sky. However,	ar is aligned the tracking motors will automatically turn on and begin tracking the the tracking can be turned off for terrestrial use:		
	This is the default tracking rate and is used when the telescope has been properly aligned.			
	EQ North	Used to track the sky when the telescope is polar aligned using an equatorial wedge in the Northern Hemisphere.		
	EQ South Used to track the sky when the telescope is polar align equatorial wedge in the Southern Hemisphere.			
	Off	When using the telescope for terrestrial (land) observation the tracking can be turned off so that the telescope never moves.		

Note: The EQ North and EQ South tracking modes are only needed with telescopes that can be polar aligned. The NexStar SLT series are exclusively Alt-Az mounted telescopes and do not require equatorial tracking.

- *Tracking Rate* In addition to being able to move the telescope with the hand control buttons, the NexStar will continually track a celestial object as it moves across the night sky. The tracking rate can be changed depending on what type of object is being observed:
 - **Sidereal** This rate compensates for the rotation of the earth by moving the telescope at the same rate as the rotation of the earth, but in the opposite direction. When tracking in Alt-Az mode, the telescope must make corrections in both altitude and azimuth.
 - Lunar Used for tracking the moon when observing the lunar landscape.
 - Solar Used for tracking the Sun when solar observing using a proper solar filter.

View Time-Site - View Time-Site will display the last saved time and longitude/latitude entered in the hand control.

User Defined Objects - The NexStar can store up to 50 different user defined objects in its memory. The objects can be daytime land objects or an interesting celestial object that you discover that is not included in the regular database. There are several ways to save an object to memory depending on what type of object it is:

Save Sky Object: The NexStar stores celestial objects to its database by saving its right ascension and declination in the sky. This way the same object can be found each time the telescope is aligned. Once a desired object is centered in the eyepiece, simply scroll to the "Save Sky Obj" command and press ENTER. The display will ask you to enter a number between 1-25 to identify the object. Press ENTER again to save this object to the database.

Save Database (Db)

Object: This feature allows you to create your own custom tour of database objects by allowing you to record the current position of the telescope and save the name of the object by selecting it from any one of the database catalogs. These objects then can be accessed by selecting *GoTo Sky Object*.

- **Save Land Object:** The NexStar can also be used as a spotting scope on terrestrial objects. Fixed land objects can be stored by saving their altitude and azimuth relative to the location of the telescope at the time of observing. Since these objects are relative to the location of the telescope, they are only valid for that exact location. To save land objects, once again center the desired object in the eyepiece. Scroll down to the "Save Land Obj" command and press ENTER. The display will ask you to enter a number between 1-25 to identify the object. Press ENTER again to save this object to the database.
- Enter R.A. Dec: You can also store a specific set of coordinates for an object just by entering the R.A. and declination for that object. Scroll to the "Enter RA-DEC " command and press ENTER. The display will then ask you to enter first the R.A. and then the declination of the desired object.
- **GoTo Object:** To go to any of the user defined objects stored in the database, scroll down to either GoTo Sky Obj or Goto Land Obj and enter the number of the object you wish to select and press ENTER. NexStar will automatically retrieve and display the coordinates before slewing to the object.

To replace the contents of any of the user defined objects, simply save a new object using one of the existing identification numbers; NexStar will replace the previous user defined object with the current one.

Get RA/DEC - Displays the right ascension and declination for the current position of the telescope.

Goto R.A/ Dec - Allows you to input a specific R.A. and declination and slew to it.

Identify

Identify Mode will search any of the NexStar database catalogs or lists and display the name and offset distances to the nearest matching objects. This feature can serve two purposes. First, it can be used to identify an unknown object in the field of view of your eyepiece. Additionally, *Identify Mode* can be used to find other celestial objects that are close to the objects you are currently observing. For example, if your telescope is pointed at the brightest star in the constellation Lyra, choosing *Identify* and then searching the *Named Star* catalog will no doubt return the star Vega as the star you are observing. However, by selecting *Identify* and searching by the *Named Object* or *Messier* catalogs, the hand control will let you know that the Ring Nebula (M57) is approximately 6° from your current position. Searching the Double Star catalog will reveal that Epsilon Lyrae is only 1° away from Vega. To use the *Identify* feature:

- Press the Menu button and select the Identify option.
- Use the Up/Down scroll keys to select the catalog that you would like to search.
- Press ENTER to begin the search.

Note: Some of the databases contain thousands of objects, and can therefore take a minute or two to return the closest object.

Scope Setup Features

Setup Time-Site - Allows the user to customize the NexStar display by changing time and location parameters (such as time zone and daylight savings).

Anti-backlash – All mechanical gears have a certain amount of backlash or play between the gears. This play is evident by how long it takes for a star to move in the eyepiece when the hand control arrow buttons are pressed (especially when changing directions). The NexStar's anti-backlash features allows the user to compensate for backlash by inputting a value which quickly rewinds the motors just enough to eliminate the play between gears. The amount of compensation needed depends on the slewing rate selected; the slower the slewing rate the longer it will take for the star to appear to move in the eyepiece. Therefore, the anti-backlash compensation will have to be set higher. You will need to experiment with different values; a value between 20 and 50 is usually best for most visual observing, whereas a higher value may be necessary for photographic guiding. Positive backlash compensation is applied when the mount changes its direction of movement from backwards to forwards. Similarly, negative backlash compensation is applied when the mount changes its direction of movement from forwards to backwards. When tracking is enabled, the mount will be moving in one or both axes in either the positive or negative direction, so backlash compensation will always be applied when a direction button is released and the direction moved is opposite to the direction of travel.

To set the anti-backlash value, scroll down to the anti-backlash option and press ENTER. Enter a value from 0-100 for both azimuth and altitude directions and press ENTER after each one to save these values. NexStar will remember these values and use them each time it is turned on until they are changed.

Slew Limits – Sets the limits in altitude that the telescope can slew without displaying a warning message. The slew limits prevent the telescope tube from slewing to an object below the horizon or slewing to an object that is high enough that the tube might hit one of the tripod legs. However, the slew limits can be customized depending on your needs. For example, if you would like to slew to an object that is close to the zenith and are certain that the tube will not hit the tripod legs, you can set the slew limits to 90° in altitude. This will allow the telescope to slew to any object above the horizon without warning.

Filter Limits – When an alignment is complete, the NexStar automatically knows which celestial objects are above the horizon. As a result, when scrolling through the database lists (or selecting the Tour function), the NexStar hand control will display only those objects that are known to be above the horizon when you are observing. You can customize the object database by selecting altitude limits that are appropriate for your location and situation. For example, if you are observing from a mountainous location where the horizon is partially obscured, you can set your minimum altitude limit to read +20°. This will make sure that the hand control only displays objects that are higher in altitude than 20°.

Observing Tip!

If you want to explore the entire object database, set the maximum altitude limit to 90° and the minimum limit to -90° . This will display every object in the database lists regardless of whether it is visible in the sky from your location or not.

Direction Buttons – The direction a star moves in the eyepiece varies depending on the accessories being used. This can create confusion when guiding on a star using an off-axis guider versus a straight through guide scope. To compensate for this, the direction of the drive control keys can be changed. To reverse the button logic of the hand control, press the MENU button and select *Direction Buttons* from the Utilities menu. Use the Up/Down arrow keys (10) to select either the Azimuth buttons (left and right) or Altitude buttons (up and down) and press ENTER. Pressing ENTER again will reverse the direction of the hand control buttons from their current state. Direction Buttons will only change the eyepiece rates (rate 1-6) and will not affect the slew rates (rate 7-9).

Goto Approach - lets the user define the direction that the telescope will approach when slewing to an object. This allows the user the ability to minimize the effects of backlash For example, if your telescope is back heavy from using heavy optical or photographic accessories attached to the back, you would want to set your altitude approach to the negative direction. This would ensure that the telescope always approaches an object from the opposite direction as the load pulling on the scope.

To change the goto approach direction, simply choose *Goto Approach* from the *Scope Setup* menu, select either Altitude or Azimuth approach, choose positive or negative and press Enter.

Cordwrap - - Cord wrap safeguards against the telescope slewing more than 360° in azimuth and wrapping accessory cables around the base of the telescope. This is useful any time that the telescope is powered using an external power supply. By default, the cord wrap feature is turned off when the telescope is aligned in altazimuth and turn on when aligned on a wedge.

Utility Features

Scrolling through the MENU options will also provide access to several advanced utility functions such as anti-backlash compensation and slew limits.

 $GPS \ On/Off$ - This feature is only available when using your telescope in conjunction with the optional CN 16 GPS accessory. Allows you to turn off the GPS module. If you want to use the NexStar database to find the coordinates of a celestial object for a future date you would need to turn the GPS module off in order to manually enter a date and time other than the present.

Light Control – This feature allows you to turn off both the red key pad light and LCD display for daytime use to conserve power and to help preserve your night vision.

Factory Setting – Returns the NexStar hand control to its original factory setting. Parameters such as backlash compensation values, initial date and time, longitude/latitude along with slew and filter limits will be reset. However, stored parameters such as PEC and user defined objects will remain saved even when *Factory Settings* is selected. The hand control will ask you to press the "0" key before returning to the factory default setting.

Version - Selecting this option will allow you to see the current version number of the hand control and motor control software. The first set of numbers indicate the hand control software version. For the motor control, the hand control will display two sets of numbers; the first numbers are for azimuth and the second set are for altitude.

Get Alt-Az - Displays the relative altitude and azimuth for the current position of the telescope.

Goto Alt-Az - Allows you to enter a specific altitude and azimuth position and slew to it.

Hibernate - Hibernate allows the NexStar to be completely powered down and still retain its alignment when turned back on. This not only saves power, but is ideal for those that have their telescopes permanently mounted or leave their telescope in one location for long periods of time. To place your telescope in Hibernate mode:

- 1. Select Hibernate from the Utility Menu.
- 2. Move the telescope to a desire position and press ENTER.
- 3. Power off the telescope. Remember to never move your telescope manually while in Hibernate mode.

Once the telescope is powered on again the display will read Wake Up. After pressing Enter you have the option of

scrolling through the time/site information to confirm the current setting. Press ENTER to wake up the telescope.

Pressing UNDO at the Wake Up screen allows you to explore many of the features of the hand control without waking the

Helpful Hint telescope up from hibernate mode. To wake up the telescope after UNDO has been pressed, select Hibernate from the Utility menu and press ENTER. Do not use the direction buttons to move the telescope while in hibernate mode.

Sun Menu

For safety purposes the Sun will not be displayed as a database object unless it is first enabled. The enable the Sun, go to the *Sun Menu* and press ENTER. The Sun will now be displayed in the Planets catalog as can be used as an alignment object when using the Solar System Alignment method. To remove the Sun from displaying on the hand control, once again select the Sun Menu from the Utilities Menu and press ENTER.

Scrolling Menu

This menus allows you to change the rate of speed that the text scrolls across the hand control display.

- Press the Up (number 6) button to increase the speed of the text.
- Press the Down (number 9) button to decrease the speed of the text.





Callismon Telescope Basics

A telescope is an instrument that collects and focuses light. The nature of the optical design determines how the light is focused. Some telescopes, known as refractors, use lenses. Other telescopes, known as reflectors, use mirrors. The NexStar 60, 80 and 102 telescopes are refractor telescopes that use an objective lens to collect its light. The NexStar 114 and 130 are reflecting telescopes with a primary and secondary mirror to gather and focus light.

Focusing

Once you have found an object in the telescope, turn the focusing knob until the image is sharp. To focus on an object that is nearer than your current target, turn the focusing knob toward the eyepiece (i.e., so that the focusing tube moves away from the front of the telescope). For more distant objects, turn the focusing knob in the opposite direction. To achieve a truly sharp focus, never look through glass windows or across objects that produce heat waves, such as asphalt parking lots.

Image Orientation

The image orientation of any telescope changes depending on how the eyepiece is inserted into the telescope. When observing through the NexStar 60, 80 or 102 using the diagonal, the image will be right side up, but reversed from left to right. When observing straight through, with the eyepiece inserted directly into the telescope, the image will be inverted.



When observing through the NexStar 114 or 130, a reflecting telescope, the image will reversed (mirror image) when looking through the eyepiece.

For astronomical viewing, out of focus star images are very diffuse, making them difficult to see. If you turn the focus knob too quickly, you can go right through focus without seeing the image. To avoid this problem, your first astronomical target should be a bright object (like the Moon or a planet) so that the image is visible even when out of focus.

Calculating Magnification

You can change the power of your telescope just by changing the eyepiece (ocular). To determine the magnification of your telescope, simply divide the focal length of the telescope by the focal length of the eyepiece used. In equation format, the formula looks like this:

Focal Length of Telescope (mm)

Magnification = Focal Length of Eyepiece (mm)

Let's say, for example, you are using the 25mm eyepiece. To determine the magnification you simply divide the focal length of your telescope (for example, the NexStar 114 has a focal length of 1000mm) by the focal length of the eyepiece, 25mm. Dividing 1000 by 25 yields a magnification of 40 power.

Although the power is variable, each instrument under average skies has a limit to the highest useful magnification. The general rule is that 60 power can be used for every inch of aperture. For example, the NexStar 80 is 3.2" (80mm) in diameter. Multiplying 3.2 by 60 gives a maximum useful magnification of 192 power. Although this is the maximum useful magnification, most observing is done in the range of 20 to 35 power for every inch of aperture which is 64 to 112 times for the NexStar 80 telescope.

Determining Field of View

Determining the field of view is important if you want to get an idea of the angular size of the object you are observing. To calculate the actual field of view, divide the apparent field of the evepiece (supplied by the evepiece manufacturer) by the magnification. In equation format, the formula looks like this:

Apparent Field of Eyepiece True Field = ______ Magnification

As you can see, before determining the field of view, you must calculate the magnification. Using the example in the previous section, we can determine the field of view using the same 25mm eyepiece. The 25mm eyepiece has an apparent field of view of 50° . Divide the 50° by the magnification, which is 40 power. This yields an actual field of view of 1.25° .

To convert degrees to feet at 1,000 vards, which is more useful for terrestrial observing, simply multiply by 52.5. Continuing with our example, multiply the angular field 1.4° by 52.5. This produces a linear field width of 66 feet at a distance of one thousand yards. The apparent field of each eyepiece that Celestron manufactures is found in the Celestron Accessory Catalog (#93685).

General Observing Hints

When working with any optical instrument, there are a few things to remember to ensure you get the best possible image:

- Never look through window glass. Glass found in household windows is optically imperfect, and as a result, may vary in thickness from one part of a window to the next. This inconsistency can and will affect the ability to focus your telescope. In most cases you will not be able to achieve a truly sharp image, while in some cases, you may actually see a double image.
- Never look across or over objects that are producing heat waves. This includes asphalt parking lots on hot summer days or building rooftops.
- Hazy skies, fog, and mist can also make it difficult to focus when viewing terrestrially. The amount of detail seen under these conditions is greatly reduced. Also, when photographing under these conditions, the processed film may come out a little grainier than normal with lower contrast and underexposed.
- If you wear corrective lenses (specifically glasses), you may want to remove them when observing with an eyepiece attached to the telescope. When using a camera, however, you should always wear corrective lenses to ensure the sharpest possible focus. If you have astigmatism, corrective lenses must be worn at all times.

Celestial Observing

With your telescope set up, you are ready to use it for observing. This section covers visual observing hints for both solar system and deep sky objects as well as general observing conditions which will affect your ability to observe.

Observing the Moon



Often, it is tempting to look at the Moon when it is full. At this time, the face we see is fully illuminated and its light can be overpowering. In addition, little or no contrast can be seen during this phase.

One of the best times to observe the Moon is during its partial phases (around the time of first or third quarter). Long shadows reveal a great amount of detail on the lunar surface. At low power you will be able to see most of the lunar disk at one time. Change to higher power (magnification) to focus in on a smaller area. Choose the *lunar* tracking rate from the NexStar's MENU tracking rate options to keep the moon centered in the eyepiece even at high magnifications.

Lunar Observing Hints

• To increase contrast and bring out detail on the lunar surface, use eyepiece filters. A yellow filter works well at improving contrast while a neutral density or polarizing filter will reduce overall surface brightness and glare.

Observing the Planets

Other fascinating targets include the five naked eye planets. You can see Venus go through its lunar-like phases. Mars can reveal a host of surface detail and one, if not both, of its polar caps. You will be able to see the cloud belts of Jupiter and the great Red Spot (if it is visible at the time you are observing). In addition, you will also be able to see the moons of Jupiter as they orbit the giant planet. Saturn, with its beautiful rings, is easily visible at moderate power.

Planetary Observing Hints

• Remember that atmospheric conditions are usually the limiting factor on how much planetary detail will be visible. So, avoid observing the planets when they are low on the horizon or when they are directly over a source of radiating heat, such as a rooftop or chimney. See the "*Seeing Conditions*" section later in this section.



• To increase contrast and bring out detail on the planetary surface, try using Celestron eyepiece filters.

Observing the Sun

Although overlooked by many amateur astronomers, solar observation is both rewarding and fun. However, because the Sun is so bright, special precautions must be taken when observing our star so as not to damage your eyes or your telescope.

Never project an image of the Sun through the telescope. Tremendous heat build-up may result inside the optical tube. This can damage the telescope and/or any accessories attached to the telescope.

For safe solar viewing, use a Celestron solar filter (see *Optional Accessories* section of manual) that reduces the intensity of the Sun's light, making it safe to view. With a filter you can see sunspots as they move across the solar disk and faculae, which are bright patches seen near the Sun's edge.

Solar Observing Hints

- The best time to observe the Sun is in the early morning or late afternoon when the air is cooler.
- To center the Sun without looking into the eyepiece, watch the shadow of the telescope tube until it forms a circular shadow.
- To ensure accurate tracking on SLT models, be sure to select solar tracking rate.

Observing Deep Sky Objects

Deep sky objects are simply those objects outside the boundaries of our solar system. They include star clusters, planetary nebulae, diffuse nebulae, double stars and other galaxies outside our own Milky Way. Most deep sky objects have a large angular size. Therefore, low-to-moderate power is all you need to see them. Visually, they are too faint to reveal any of the color seen in long exposure photographs. Instead, they appear black and white. And, because of their low surface brightness, they should be observed from a dark sky location. Light pollution around large urban areas washes out most nebulae making them difficult, if not impossible, to observe. Light Pollution Reduction filters help reduce the background sky brightness, thus increasing contrast.

Seeing Conditions

Viewing conditions affect what you can see through your telescope during an observing session. Conditions include transparency, sky illumination, and seeing. Understanding viewing conditions and the effect they have on observing will help you get the most out of your telescope.

Transparency

Transparency is the clarity of the atmosphere which is affected by clouds, moisture, and other airborne particles. Thick cumulus clouds are completely opaque while cirrus can be thin, allowing the light from the brightest stars through. Hazy skies absorb more light than clear skies making fainter objects harder to see and reducing contrast on brighter objects. Aerosols ejected into the upper atmosphere from volcanic eruptions also affect transparency. Ideal conditions are when the night sky is inky black.

Sky Illumination

General sky brightening caused by the Moon, aurorae, natural airglow, and light pollution greatly affect transparency. While not a problem for the brighter stars and planets, bright skies reduce the contrast of extended nebulae making them difficult, if not impossible, to see. To maximize your observing, limit deep sky viewing to moonless nights far from the light polluted skies found around major urban areas. LPR filters enhance deep sky viewing from light polluted areas by blocking unwanted light while transmitting light from certain deep sky objects. You can, on the other hand, observe planets and stars from light polluted areas or when the Moon is out.

Seeing

Seeing conditions refers to the stability of the atmosphere and directly affects the amount of fine detail seen in extended objects. The air in our atmosphere acts as a lens which bends and distorts incoming light rays. The amount of bending depends on air density. Varying temperature layers have different densities and, therefore, bend light differently. Light rays from the same object arrive slightly displaced creating an imperfect or smeared image. These atmospheric disturbances vary from time-to-time and place-to-place. The size of the air parcels compared to your aperture determines the "seeing" quality. Under good seeing conditions, fine detail is visible on the brighter planets like Jupiter and Mars, and stars are pinpoint images. Under poor seeing conditions, images are blurred and stars appear as blobs.

The conditions described here apply to both visual and photographic observations.



Seeing conditions directly affect image quality. These drawing represent a point source (i.e., star) under bad seeing conditions (left) to excellent conditions (right). Most often, seeing conditions produce images that lie some where between these two extremes.

Callisticov Telescope Maintenance

While your NexStar telescope requires little maintenance, there are a few things to remember that will ensure your telescope performs at its best.

Care and Cleaning of the Optics

Occasionally, dust and/or moisture may build up on the lens of your telescope. Special care should be taken when cleaning any instrument so as not to damage the optics.

If dust has built up on the optics, remove it with a brush (made of camel's hair) or a can of pressurized air. Spray at an angle to the lens for approximately two to four seconds. Then, use an optical cleaning solution and white tissue paper to remove any remaining debris. Apply the solution to the tissue and then apply the tissue paper to the lens. Low pressure strokes should go from the center of the corrector to the outer portion. **Do NOT rub in circles!**

You can use a commercially made lens cleaner or mix your own. A good cleaning solution is isopropyl alcohol mixed with distilled water. The solution should be 60% isopropyl alcohol and 40% distilled water. Or, liquid dish soap diluted with water (a couple of drops per one quart of water) can be used.

To minimize the need to clean your telescope, replace all lens covers once you have finished using it. This will prevent contaminants from entering the optical tube.

Collimation

(For NexStar 114 and 130)

The optical performance of your NexStar telescope is directly related to its collimation, that is the alignment of its optical system. Your NexStar was collimated at the factory after it was completely assembled. However, if the telescope is dropped or jarred severely during transport, it may have to be collimated. The NexStar 60, 80 and 102 are refractor type telescopes that have fixed optical systems that should not come out of collimation. The NexStar 114 and 130, however has three collimation screws that can be used to adjust the alignment of the primary mirror.

To check if your telescope is in collimation the following diagram will help you. If you look into the eyepiece adapter (without an eyepiece) at the top of the focuser, this is what you should see. If the reflection of your eye is off center, then collimation is necessary.

Adjustments to the collimation of the telescope can be made by turning the collimation adjustment knobs located at the rear of the optical tube. First loosen the three Phillips head screws on the rear cell of the tube. Turn each collimation knobs, one at a time, until the reflected image of your eye in the secondary mirror is centered in the primary mirror. Once the telescope is collimated, tighten the Phillips head screws until you feel a slight resistance. Do not over tighten the screw.



If your telescope is out of collimation, the best way to re-collimate it is

with a good collimation tool. Celestron offers a Newtonian Collimation Tool (#94183) with detailed instructions that make it an easy chore.

Optional Accessories

You will find that additional accessories enhance your viewing pleasure and expand the usefulness of your telescope. For ease of reference, all the accessories are listed in alphabetical order.

Adapter, Car Battery (#18769) - Celestron offers the Car Battery Adapter that allows you to run the NexStar drive off an external power source. The adapter attaches to the cigarette lighter of your car, truck, van, or motorcycle.



Barlow lens, OMNI 1.25" (#93326) - Double the magnification of any of your Celestron eyepieces with this fully multi-coated, low profile Barlow lens

Carrying Case, Soft NexStar 60/80/102 (#302160) - Lightweight yet durable, this nylon case is ideal for transporting your NexStar telescope. The shoulder and back straps provide hands-free convenience to make carrying your telescope anywhere even easier.

Erect Image Diagonal (#94112-A) - This accessory is an Amici prism arrangement that allows you to look into the telescope at a 45° angle with images that are oriented properly (upright and correct from left-to-right). It is useful for daytime, terrestrial viewing with the NexStar 60, 80 and 102

Eyepieces - Like telescopes, eyepieces come in a variety of designs. Each design has its own advantages and disadvantages. For the 1-1/4" barrel diameter there are four different eyepiece designs available:

- **OMNI Plössl** Plössl eyepieces have a 4-element lens designed for low-to-high power observing. The Plössls offer razor sharp views across the entire field, even at the edges! In the 1-1/4" barrel diameter, they are available in the following focal lengths: 4mm, 6mm, 9mm, 12.5mm, 15mm, 20mm, 25mm, 32mm and 40mm.
- X-Cel This 6 element design allows each X-Cel Eyepiece to have 20mm of eye relief, 55° field of view and more than 25mm of lens aperture (even with the 2.3mm). In order to maintain razor sharp, color corrected images across its 50° field of view, extra-low dispersion glass is used for the most highly curved optical elements. The excellent refractive properties of these high grade optical elements, make the X-Cel line especially well suited for high magnification planetary viewing where sharp, color-free views are most appreciated. X-Cel eyepiece come in the following focal length: 2.3mm, 5mm, 8mm, 10mm, 12.5mm, 18mm, 21mm, 25mm.



• Ultima - Ultima is not really a design, but a trade name for our 5-element, wide field eyepieces. In the 1-1/4" barrel diameter, they are available in the following focal length: 5mm, 7.5mm, 10mm 12.5mm, 18mm, 30mm, 35mm, and 42mm. These eyepieces are all parfocal.



The Eyepiece and Filter Kit (#94303) – contains Five Superior Grade Plössl Eyepieces - 1.25". Barlow Lens - 2x 1.25". Six Colored Eyepiece (Lunar & Planetary) Filters. Moon Filter. Aluminum Carrying Case

Flashlight , Night Vision - (#93588) - Celestron's premium model for astronomy, using two red LEDs to preserve night vision better than red filters or other devices. Brightness is adjustable. Operates on a single 9 volt battery (included).

Filter, Light Pollution Reduction –UHC/LPR (#94123) - These filters are designed to enhance your views of deep sky astronomical objects when viewed from

urban areas. LPR Filters selectively reduce the transmission of certain wavelength of light, specifically those produced by artificial lights. This includes mercury and high and low pressure sodium vapor lights. In addition, they also block unwanted natural light (sky glow) caused by neutral oxygen emission in our atmosphere.



Filter, Solar - The AstroSolar® filter is a safe and durable filter that covers the front opening of the telescope. View sunspots and other solar features using this double-sided metal coated filter for uniform density and good color balance across the entire field. The Sun offers constant changes and will keep your observing interesting and fun.

PowerTank (#18774) – 12v 7Amp hour rechargeable power supply. Comes with two 12v output cigarette outlets, built-in red flash light , Halogen emergency spotlight. AC adapter and cigarette lighter adapter included.

RS-232 Cable (#93920) – Allows your NexStar telescope to be controlled using a laptop computer or PC. Once connected, the NexStar can be controlled using popular astronomy software programs.

Sky Maps (#93722) - Celestron Sky Maps are the ideal teaching guide for learning the night sky. You wouldn't set off on a road trip without a road map, and you don't need to try to navigate the night sky without a map either. Even if you already know your way around the major constellations, these maps can help you locate all kinds of fascinating objects.



T-adapter (**#93625**) - A T-Adapter allows you to attach your 35mm SLR camera to the prime focus of your telescope. Universal 1¹/₄" T-Adapter. Fits (drop in style) any type of telescope that uses a 1¹/₄" focuser or visual back.

Vibration Suppression Pads (#93503) - These pads rest between the ground and tripod feet of your telescope. They reduce the amplitude and vibration time of your telescope when shaken by the wind or an accidental bump.

A full description of all Celestron accessories can be found on our web site at www.celestron.com

APPENDIX A - TECHNICAL SPECIFICATIONS

Optical Specification

	NexStar 60mm	NexStar 80mm	NexStar 102mm	NexStar 114mm	NexStar 130mm
Design	Refractor	Refractor	Refractor	Reflector	Reflector
Aperture	60mm	80mm	102mm	114mm	130mm
Focal Length	700mm	900mm	660mm	1000mm	650mm
F/ratio of the Optical System	12	11	6.5	9	5
Optical Coatings	Fully Coated	Fully Coated	Multi Coated	Aluminum	Aluminum
Highest Useful Magnification	175x	189x	240x	269x	306x
Resolution: Rayleigh Criterion	2.31 arc seconds	1.73 arc seconds	1.36 arc seconds	1.21 arc seconds	1.06 arc seconds
Dawes Limit	1.93 arc seconds	1.45 arc seconds	1.14 arc seconds	1.02 arc seconds	.89 arc seconds
Light Gathering Power	73x unaided eye	131x unaided eye	212x unaided eye	265x unaided eye	345x unaided eye
Field of View: Standard Eyepiece	1.6°	1.3°	1.7°	1.1°	1.7°
Linear Field of View (at 1000	84feet	66 feet	91 feet	59 feet	91 feet
yds)					
Eyepiece Magnification:	28x (25mm)	36x (25mm)	26x (25mm)	40x (25mm)	26x (25mm)
	78x (9mm)	100x (9mm)	73x (9mm)	111x (9mm)	62x (9mm)
Optical Tube Length	28 inches	34 inches	23 inches	19 inches	21 inches

Electronic Specifications

Input Voltage	12 V DC Nominal
Batteries Required	8 AA Alkaline
Power Supply Requirements	12 VDC-750 mA (Tip positive)

Mechanical Specifications

Motor: Type	DC Servo motors with encoders, both axes
Resolution	.26 arc sec
Slew speeds	Nine slew speeds: 4° /sec, 2° /sec, 1°/sec, .5 /sec, 32x, 16x, 8x, 4x, 2x
Hand Control	Double line, 16 character Liquid Crystal Display
	19 fiber optic backlit LED buttons
Fork Arm	Cast aluminum

Software Specifications

Software Precision	16 bit, 20 arc sec. calculations
Ports	RS-232 communication port on hand control
Tracking Rates	Sidereal, Solar and Lunar
Tracking Modes	Alt-Az, EQ North & EQ South
Alignment Procedures	Sky Align, Auto 2-Star, 2-Star, One-Star, Solar System Align
Database	99 user defined programmable object.
	Expanded information on over 100 objects
Total Object Database	4,033 Objects

GLOSSARY OF TERMS

A-

Absolute magnitude Airy disk	The apparent magnitude that a star would have if it were observed from a standard distance of 10 parsecs, or 32.6 light-years. The absolute magnitude of the Sun is 4.8. at a distance of 10 parsecs, it would just be visible on Earth on a clear moonless night away from surface light. The apparent size of a star's disk produced even by a perfect optical system. Since the star can never
	be focused perfectly, 84 per cent of the light will concentrate into a single disk, and 16 per cent into a system of surrounding rings.
Alt-Azimuth Mounting	A telescope mounting using two independent rotation axes allowing movement of the instrument in Altitude and Azimuth.
Altitude	In astronomy, the altitude of a celestial object is its Angular Distance above or below the celestial horizon.
Aperture	The diameter of a telescope's primary lens or mirror; the larger the aperture, the greater the telescope's light-gathering power.
Apparent Magnitude	A measure of the relative brightness of a star or other celestial object as perceived by an observer on Earth.
Arc minute	A unit of angular size equal to 1/60 of a degree.
Arc second	A unit of angular size equal to 1/3,600 of a degree (or 1/60 of an arc minute).
Asterism	A small unofficial grouping of stars in the night sky.
Asteroid	A small, rocky body that orbits a star.
Astrology	The pseudoscientific belief that the positions of stars and planets exert an influence on human affairs; astrology has nothing in common with astronomy.
Astronomical unit (AU)	The distance between the Earth and the Sun. It is equal to 149,597,900 km., usually rounded off to 150,000,000 km.
Aurora	The emission of light when charged particles from the solar wind slams into and excites atoms and molecules in a planet's upper atmosphere.
Azimuth	The angular distance of an object eastwards along the horizon, measured from due north, between the astronomical meridian (the vertical line passing through the center of the sky and the north and south points on the horizon) and the vertical line containing the celestial body whose position is to
R _	be measured
Binary Stars	Binary (Double) stars are pairs of stars that, because of their mutual gravitational attraction, orbit around a common center of mass. If a group of three or more stars revolve around one another, it is called a multiple system. It is believed that approximately 50 percent of all stars belong to binary or multiple systems. Systems with individual components that can be seen separately by a telescope are called visual binaries or visual multiples. The nearest "star" to our solar system, Alpha Centauri, is actually our nearest example of a multiple star system, it consists of three stars, two very similar to our Sun and one dim, small, red star orbiting around one another.
C -	
Celestial Equator	The projection of the Earth's equator on to the celestial sphere. It divides the sky into two equal hemispheres.
Celestial pole	The imaginary projection of Earth's rotational axis north or south pole onto the celestial sphere.
Celestial Sphere	An imaginary sphere surrounding the Earth, concentric with the Earth's center.
Collimation	The act of putting a telescope's optics into perfect alignment.
D -	
Declination (DEC)	The angular distance of a celestial body north or south of the celestial equator. It may be said to correspond to latitude on the surface of the Earth.
E -	•
Ecliptic	The projection of the Earth's orbit on to the celestial sphere. It may also be defined as "the apparent yearly path of the Sun against the stars".
Equatorial mount	A telescope mounting in which the instrument is set upon an axis which is parallel to the axis of the Earth; the angle of the axis must be equal to the observer's latitude.
F -	
Focal length	The distance between a lens (or mirror) and the point at which the image of an object at infinity is brought to focus. The focal lenSLTh divided by the aperture of the mirror or lens is termed the focal ratio.

G	
боТо	Term used to refer to a computerized telescope or to the act of slewing (moving) a computerized telescope
J -	
Jovian Planets	Any of the four gas giant planets that are at a greater distance form the sun than the terrestrial planets.
K -	
Kuiper Belt	A region beyond the orbit of Neptune extending to about 1000 AU which is a source of many short period comets.
L -	
Light-Year (ly)	A light-year is the distance light traverses in a vacuum in one year at the speed of 299,792 km/ sec. With 31,557,600 seconds in a year, the light-year equals a distance of 9.46 X 1 trillion km (5.87 X 1 trillion mi).
M -	
Magnitude	Magnitude is a measure of the brightness of a celestial body. The brightest stars are assigned magnitude 1 and those increasingly fainter from 2 down to magnitude 5. The faintest star that can be seen without a telescope is about magnitude 6. Each magnitude step corresponds to a ratio of 2.5 in brightness. Thus a star of magnitude 1 is 2.5 times brighter than a star of magnitude 2, and 100 times brighter than a magnitude 5 star. The brightest star, Sirius, has an apparent magnitude of -1.6, the full moon is -12.7, and the Sun's brightness, expressed on a magnitude scale, is -26.78. The zero point of the apparent magnitude scale is arbitrary.
Meridian	A reference line in the sky that starts at the North celestial pole and ends at the South celestial pole and passes through the zenith. If you are facing South, the meridian starts from your Southern horizon and passes directly overhead to the North celestial pole.
Messier	A French astronomer in the late 1700's who was primarily looking for comets. Comets are hazy diffuse objects and so Messier cataloged objects that were not comets to help his search. This catalog became the Messier Catalog, M1 through M110.
N -	
Nebula	Interstellar cloud of gas and dust. Also refers to any celestial object that has a cloudy appearance.
North Celestial Pole	The point in the Northern hemisphere around which all the stars appear to rotate. This is caused by the fact that the Earth is rotating on an axis that passes through the North and South celestial poles. The star Polaris lies less than a degree from this point and is therefore referred to as the "Pole Star".
Nova	Although Latin for "new" it denotes a star that suddenly becomes explosively bright at the end of its life cycle.
0 -	
Open Cluster	One of the groupings of stars that are concentrated along the plane of the Milky Way. Most have an asymmetrical appearance and are loosely assembled. They contain from a dozen to many hundreds of stars.
P -	
Parallax	Parallax is the difference in the apparent position of an object against a background when viewed by an observer from two different locations. These positions and the actual position of the object form a triangle from which the apex angle (the parallax) and the distance of the object can be determined if the lenSLTh of the baseline between the observing positions is known and the angular direction of the object from each position at the ends of the baseline has been measured. The traditional method in astronomy of determining the distance to a celestial object is to measure its parallax.
Parfocal	Refers to a group of eyepieces that all require the same distance from the focal plane of the telescope to be in focus. This means when you focus one parfocal eyepiece all the other parfocal events in a particular line of events will be in focus.
Parsec	The distance at which a star would show parallax of one second of arc. It is equal to 3.26 light-years, 206,265 astronomical units, or 30,8000,000,000 km. (Apart from the Sun, no star lies within one parsec of us.)
Point Source	An object which cannot be resolved into an image because it to too far away or too small is considered a point source. A planet is far away but it can be resolved as a disk. Most stars cannot be resolved as disks, they are too far away.
R -	
Reflector	A telescope in which the light is collected by means of a mirror.
Resolution	The minimum detectable angle an optical system can detect. Because of diffraction, there is a limit to the minimum angle, resolution. The larger the aperture, the better the resolution.
Right Ascension: (RA)	The angular distance of a celestial object measured in hours, minutes, and seconds along the Celestial Equator eastward from the Vernal Equinox.
S -	
Sidereal Rate	This is the angular speed at which the Earth is rotating. Telescope tracking motors drive the

telescope at this rate. The rate is 15 arc seconds per second or 15 degrees per hour.
The boundary line between the light and dark portion of the moon or a planet.
The totality of astronomical things, events, relations and energies capable of being described objectively.
A star whose brightness varies over time due to either inherent properties of the star or something eclipsing or obscuring the brightness of the star.
The period of the moon's cycle between full and new, when its illuminated portion is decreasing.
The period of the moon's cycle between new and full, when its illuminated portion is increasing.
The point on the Celestial Sphere directly above the observer.
The zodiac is the portion of the Celestial Sphere that lies within 8 degrees on either side of the Ecliptic. The apparent paths of the Sun, the Moon, and the planets, with the exception of some portions of the path of Pluto, lie within this band. Twelve divisions, or signs, each 30 degrees in width, comprise the zodiac. These signs coincided with the zodiacal constellations about 2,000 years ago. Because of the Precession of the Earth's axis, the Vernal Equinox has moved westward by about 30 degrees since that time; the signs have moved with it and thus no longer coincide with the constellations.

Appendix C - RS-232 Connection

Using the included NSOL software you can control your NexStar telescope with a computer via the RS-232 port located on the computerized hand control and using the RS-232 cable (#93920). For information about using NSOL to control your telescope, refer to the instruction sheet that came with the CD and the help files located on the disk. In addition to NSOL, the telescope can be controlled using other popular astronomy software programs. For detailed information about controlling NexStar via the RS-232 port, Communication protocols and the RS-232 cable, refer to the NexStar SLT section of the Celestron web site at: http://www.celestron.com.

APPENDIX D – MAPS OF TIME ZONES

















CELESTRON TWO YEAR WARRANTY

- A. Celestron warrants this telescope to be free from defects in materials and workmanship for two years. Celestron will repair or replace such product or part thereof which, upon inspection by Celestron, is found to be defective in materials or workmanship. As a condition to the obligation of Celestron to repair or replace such product, the product must be returned to Celestron together with proof-of-purchase satisfactory to Celestron.
- B. The Proper Return Authorization Number must be obtained from Celestron in advance of return. Call Celestron at (310) 328-9560 to receive the number to be displayed on the outside of your shipping container.

All returns must be accompanied by a written statement setting forth the name, address, and daytime telephone number of the owner, together with a brief description of any claimed defects. Parts or product for which replacement is made shall become the property of Celestron.

The customer shall be responsible for all costs of transportation and insurance, both to and from the factory of Celestron, and shall be required to prepay such costs.

Celestron shall use reasonable efforts to repair or replace any telescope covered by this warranty within thirty days of receipt. In the event repair or replacement shall require more than thirty days, Celestron shall notify the customer accordingly. Celestron reserves the right to replace any product which has been discontinued from its product line with a new product of comparable value and function.

This warranty shall be void and of no force of effect in the event a covered product has been modified in design or function, or subjected to abuse, misuse, mishandling or unauthorized repair. Further, product malfunction or deterioration due to normal wear is not covered by this warranty.

CELESTRON DISCLAIMS ANY WARRANTIES, EXPRESS OR IMPLIED, WHETHER OF MERCHANTABILITY OF FITNESS FOR A PARTICULAR USE, EXCEPT AS EXPRESSLY SET FORTH HEREIN.

THE SOLE OBLIGATION OF CELESTRON UNDER THIS LIMITED WARRANTY SHALL BE TO REPAIR OR REPLACE THE COVERED PRODUCT, IN ACCORDANCE WITH THE TERMS SET FORTH HEREIN. CELESTRON EXPRESSLY DISCLAIMS ANY LOST PROFITS, GENERAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES WHICH MAY RESULT FROM BREACH OF ANY WARRANTY, OR ARISING OUT OF THE USE OR INABILITY TO USE ANY CELESTRON PRODUCT. ANY WARRANTIES WHICH ARE IMPLIED AND WHICH CANNOT BE DISCLAIMED SHALL BE LIMITED IN DURATION TO A TERM OF TWO YEARS FROM THE DATE OF ORIGINAL RETAIL PURCHASE.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitation on how long an implied warranty lasts, so the above limitations and exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Celestron reserves the right to modify or discontinue, without prior notice to you, any model or style telescope.

If warranty problems arise, or if you need assistance in using your telescope contact:

Celestron Customer Service Department 2835 Columbia Street Torrance, CA 90503 Tel. (310) 328-9560 Fax. (310) 212-5835 Monday-Friday &AM-4PM PST

This warranty supersedes all other product warranties.

NOTE: This warranty is valid to U.S.A. and Canadian customers who have purchased this product from an Authorized Celestron Dealer in the U.S.A. or Canada. Warranty outside the U.S.A. and Canada is valid only to customers who purchased from a Celestron Distributor or Authorized Celestron Dealer in the specific country and please contact them for any warranty service.



Celestron 2835 Columbia Street Torrance, CA 90503 Tel. (310) 328-9560 Fax. (310) 212-5835 Web site at http://www.celestron.com

Copyright 2005 Celestron All rights reserved.

(Products or instructions may change without notice or obligation.)

This device complies with Part 15 of the FCC Rule. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) This device must accept any interference received, including interference that may cause undesired operations.

22076-INST 04-05 Printed in China \$10.00