

# User's Manual



## MSC Q7-A50M Qseven Module

Rev. 0.6  
June 27th, 2013



**MICROCOMPUTERS · SYSTEMS · COMPONENTS · VERTRIEBS GMBH**

*... embedding excellence*

## Preface

### **Copyright Notice**

Copyright © 2008 MSC Vertriebs GmbH. All rights reserved.

Copying of this document, and giving it to others and the use or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages.

All rights are reserved in the event of the grant of a patent or the registration of a utility model or design.

### **Important Information**

This documentation is intended for qualified audience only. The product described herein is not an end user product. It was developed and manufactured for further processing by trained personnel.

### **Disclaimer**

Although this document has been generated with the utmost care no warranty or liability for correctness or suitability for any particular purpose is implied. The information in this document is provided "as is" and is subject to change without notice.

### **EMC Rules**

This unit has to be installed in a shielded housing. If not installed in a properly shielded enclosure, and used in accordance with the instruction manual, this product may cause radio interference in which case the user may be required to take adequate measures at his or her own expense.

### **Trademarks**

All used product names, logos or trademarks are property of their respective owners.

### **Certification**

MSC Vertriebs GmbH is certified according to DIN EN ISO 9001:2000 standards.

### **Life-Cycle-Management**

MSC products are developed and manufactured according to high quality standards. Our life-cycle-management assures long term availability through permanent product maintenance. Technically necessary changes and improvements are introduced if applicable. A product- change-notification and end-of-life management process assures early information of our customers.

### **Product Support**

MSC engineers and technicians are committed to provide support to our customers whenever needed.

Before contacting Technical Support of MSC Vertriebs GmbH, please consult the respective pages on our web site at [www.mscedded.com](http://www.mscedded.com) for the latest documentation, drivers and software downloads.

If the information provided there does not solve your problem, please contact our Technical Support:

Phone: +49 - 8165 906 - 200

Fax: +49 - 8165 906 - 201

Email: [support@mscedded.com](mailto:support@mscedded.com)

## Content

1	General Information.....	4
1.1	Revision History .....	4
1.2	Reference Documents .....	4
1.3	Introduction.....	5
2	Technical Description .....	6
2.1	Key Features .....	6
2.2	Block Diagram .....	8
2.3	Power Supply .....	9
2.4	Power Dissipation .....	9
2.5	Mechanical Dimensions .....	10
2.6	Thermal Specifications .....	11
2.7	Signal description .....	12
2.7.1	High Definition Audio .....	12
2.7.2	Ethernet .....	12
2.7.3	Serial ATA.....	13
2.7.4	PCI Express Lanes .....	13
2.7.5	USB.....	13
2.7.6	LVDS Flat Panel .....	14
2.7.7	LPC Bus.....	15
2.7.8	HDMI.....	15
2.7.9	DisplayPort.....	15
2.7.10	Express card support.....	16
2.7.11	Miscellaneous .....	16
2.7.12	Power and System Management.....	17
2.7.13	Power and GND.....	17
2.8	Connectors.....	19
2.8.1	Module connector .....	19
2.8.2	USB Port assignment .....	22
3	System Resources .....	23
3.1	SMB Address Map .....	23
3.2	PCI Express Lanes .....	23
3.3	USB .....	23
3.4	PCI Interrupt Routing Table .....	24
3.5	IRQ Lines in Legacy IRQ Mode .....	24
3.6	IRQ Lines in APIC Mode .....	25
4	<b>BIOS</b> .....	26
4.2.2	The Main Menu .....	29
4.2.3	The Advanced Menu.....	30
4.3	Chipset .....	40
4.3.2	Boot.....	46
4.3.3	Security .....	47
4.3.4	The Save & Exit Menu .....	48
4.4	BIOS and Firmware Update .....	49
4.8	EAPI .....	51

# 1 General Information

## 1.1 Revision History

Rev.	Date	Description
0.1	Dec 23 <sup>th</sup> 2012	Initial version
0.2	April 11 <sup>th</sup> , 2012	Corrections and Enhancements
0.3	October 5 <sup>th</sup> , 2012	Added Bios chapter according to Rev. X1.00c ALPHA; LVDS path
0.4	March 1 <sup>st</sup> , 2013	Updated Bios chapter
0.5	April 8 <sup>th</sup> , 2013	Updated Bios chapter
0.6	June 27 <sup>th</sup> , 2013	Enhancements

## 1.2 Reference Documents

- [1] Qseven Specification  
Revision 1.11  
Last update: Nov. 26<sup>th</sup> 2008
- [2] PCI Local Bus Specification Rev. 2.1  
PCI21.PDF  
Last update: June 1<sup>st</sup>, 1995  
<http://www.pcisig.com>
- [3] Serial ATA Specification  
Serial ATA 1.0 gold.pdf  
Last update: August 29<sup>th</sup>, 2002 Rev.1.0  
<http://www.sata-io.org/>
- [4] IEEE Std. 802.3-2002  
802.3-2002.pdf  
<http://www.ieee.org>
- [5] Universal Bus Specification  
usb\_20.pdf  
Last update: April 27<sup>th</sup>, 2000  
<http://www.usb.org>

## 1.3 Introduction

Qseven modules are compact, highly integrated Single Board Computers.

Typically a Qseven module consists of CPU, chipset, memory, Ethernet controller,

BIOS flash, SATA- and USB controller. Interface controllers (e.g. for PCMCIA) or connectors (e.g. RJ45) are implemented on a base board on to which the Qseven module can be mounted.

In addition to the power supply PCIe, SATA, USB, LPC etc. interfaces are present on the connector.

Thanks to the standardized mechanics and interfaces the system can be scaled arbitrarily. Despite the modular concept the system design is very flat and compact.

Qseven modules require a base board to build a working system. For evaluation purposes MSC recommends the official Qseven Reference Platform MSC Q7-MB-RP.

This documentation describes the Qseven module Revision 1.

## 2 Technical Description

### 2.1 Key Features

**Core:****Processors:**

AMD G-SeriesT40E dual core (1.0 GHz) on MSC-Q7-A50M-002 and -004

AMD G-SeriesT40R single core (1.0 GHz) on MSC-Q7-A50M-001

AMD G-SeriesT16R single core (615 MHz) on MSC-Q7-A50M-003

**Chipset:**

AMD A50M

**Memory:**

DDR3 533MHz, soldered down.

2GB

**PCI Express Interface:**

Four PCIe x1 channel

**Video:**

Built-in AMD Radeon™ HD 6250

18-24 Bit dual or single channel LVDS via ANX3110 DP-to-LVDS Converter

1x DVI / DisplayPort™

**Ethernet:**

10/100/1000 Base –T ( Intel 82574, Device ID 8086/10D3 )

**Audio:**

High-Definition Audio

**USB:**

8x USB Ports 2.0

**I2C Bus****SMBus****LPC Bus****SATA**

2x SATA ports

**FLASHDrive**

Optional FerriSSD SATA FLASH

**BIOS:**

AMI BIOS with optional TPM support.  
Supports SPI ROM on base board

**EEPROM:**

An SMBus EEPROM is implemented for backup of the CMOS data including user BIOS setup.

**Realtime Clock:**

An RTC (integrated in A50M chipset) is available.

**Watchdog**

- Watchdog with programmable time-out
- Watchdog enabled via BIOS or application programs

**System Monitoring:**

Monitored values:

- Temperatures (CPU and Board)
- CPU and system fan speed

**Fan support:**

Optional connector on module to run active cooling fan or system fan.  
Speed control via monitoring device

**TPM:**

Optional Infineon TPM 1.2

**SuperIO support:**

The Bios supports the following Super IO chips:

Winbond 82627 HF  
SMSC SCH3114-NU

## 2.2 Block Diagram




Fig. 1: MSC Q7-A50M-001 (T40R) / MSC Q7-A50M-002 (T40E) / MSC Q7-A50M-003 (T16R) Block Diagram



## 2.3 Power Supply

- **+5V primary power supply input**
- **+5V standby**
- **3.3V RTC power supply**  
 BIOS SETUP data is stored in a non volatile backup memory device (EEPROM), therefore configuration data will be retained during RTC-Power loss (except for time and date information)

Voltage	Input range	Current
+5V	+4.75V - 5.25V	See next table
+5V Standby	+4.75V - 5.25 V	
+3V RTC power supply	+2.0V - 3.3V	ca. 4uA/ max 6uA

## 2.4 Power Dissipation

CPU: T40E 1.0 GHz

RAM: 2GByte

Test software: Performance Test



		Idle	Calculation	Memory	Graphic	Graphic
		Idle	Find prime Number	Block read	2D Graphic complex test	3D Graphic complex test
DOS		7.2 W				
Windows	S0	6.0 W	8.4 W	8.4 W	8.6 W	9.7 W
	S3	0.3 W				

CPU: T40R 1 GHz

RAM: 2GByte

		Idle	Calculation	Memory	Graphic	Graphic
		Idle	Find prime number	Block read	2D Graphic complex test	3D Graphic complex test
DOS		8.75 W				
Windows	S0	6.0 W	9.0 W	10.0 W	9.25 W	9.75 W
	S3	0.5 W				

## 2.5 Mechanical Dimensions



The height is dependent on the MXM connector used on the baseboard.

Fig. 2: MSC Q7-A50M Mechanical Dimensions

## 2.6 Thermal Specifications

The cooling solution for a Qseven module is based on a heatspreader concept.

A heatspreader is a metal plate (typically aluminium) mounted on top of the module. The connection between this plate and the module components is typically made using thermal interface materials such as phase change foils, gap pads and copper or aluminium blocks. A very good thermal conductivity is required in order to transfer the heat from the cpu and the chipset to the heatspreader plate.

The heatspreader used by the MSC module is thermally attached using phase change materials and small aluminium blocks filling the gap between cpu and chipset dies and heatspreader plate.

**The heatspreader is not a heatsink!** It is a defined thermal interface for the system designer with fixed mechanical dimensions, so it should be possible to use different module types without problem.

The main goal for the thermal design of a system is that each device on the module is operated within its specified thermal limits. The max temperature of CPU and chipset are 90°C, so there may be system implementations where the heatspreader temperature could be higher.

In any case it has to be validated that there are no thermal spec violations of any assembled part over the system temperature range even under worst case conditions.

## 2.7 Signal description

In the following tables signals are marked with the power rail associated with the pin, and, for input and I/O pins, with the input voltage tolerance. The pin power rail and the pin input voltage tolerance **may** be different.

An additional label, "Suspend", indicates that the pin is active during suspend states (S3, S4, S5). If suspend modes are used, then care must be taken to avoid loading signals that are active during suspend to avoid excessive suspend mode current draw.

### 2.7.1 High Definition Audio

Signal	Pin Type	Signal Level	Power Rail	Power Tolerance	PU/PD	Description	Source / Target
HDA_RST#	Output	CMOS	Core	3.3V		Reset output to CODEC, active low.	A50M
HDA_SYNC	Output	CMOS	Core	3.3V		48kHz fixed-rate, sample-synchronization signal to the CODEC(s).	A50M
HDA_CLK	Output	CMOS	Core	3.3V		24.00 MHz serial data clock	A50M
HDA_SDO	Output	CMOS	Core	3.3V		Serial TDM data output to the CODEC.	A50M
HDA_SDI	Input	CMOS	Core	3.3V		Serial TDM data inputs from up to 3 CODECs.	A50M

### 2.7.2 Ethernet

Signal	Pin Type	Signal Level	Power Rail	Power Tolerance	PU/PD	Description	Source / Target
GBE0_MDI[0:3]+ GBE0_MDI[0:3]-	Input/ Output	Analog	3.3V Sus.			Gigabit Ethernet Controller 0: Media Dependent Interface Differential Pairs 0,1,2,3. The MDI can operate in 1000, 100 and 10 Mbit / sec modes.  MDI[0]+/-      B1_DA+/- MDI[1]+/-      B1_DB+/- MDI[2]+/-      B1_DC+/- MDI[3]+/-      B1_DD+/-	82574
GBE0_ACT#	Open Drain	CMOS	3.3V Sus.	3.3V		Gigabit Ethernet Controller 0 activity indicator, active low.	82574
GBE0_LINK100#	Open Drain	CMOS	3.3V Sus.	3.3V		Gigabit Ethernet Controller 0 100 Mbit / sec link indicator, active low.	82574
GBE0_LINK1000#	Open Drain	CMOS	3.3V Sus.	3.3V		Gigabit Ethernet Controller 0 1000 Mbit / sec link indicator, active low.	82574
GBE0_CTREF	REF			GND min 3.3V max		82574 (1000MBit) : 1,9V	LDO

### 2.7.3 Serial ATA

Signal	Pin Type	Signal Level	Power Rail	Remark	PU/PD	Description	Source / Target
SATA0_TX+ SATA0_TX-	O	SATA	3.3V	AC coupled on module		Serial ATA Channel 0 transmit differential pair.	A50M
SATA0_RX+ SATA0_RX-	I	SATA	3.3V	AC coupled on module		Serial ATA Channel 0 receive differential pair.	A50M
SATA1_TX+ SATA1_TX-	O	SATA	3.3V	AC coupled on module		Serial ATA Channel 1 transmit differential pair.	A50M
SATA1_RX+ SATA1_RX-	I	SATA	3.3V	AC coupled on module		Serial ATA Channel 1 receive differential pair.	A50M
SATA_ACT#	O	CMOS	3.3V	3.3V		SATA activity indicator, active low.	A50M

### 2.7.4 PCI Express Lanes

Signal	Pin Type	Signal Level	Power Rail	Remark / Power Tol.	PU/PD	Description	Source / Target
PCIE_TX[0:3]+ PCIE_TX[0:3]-	O	PCIe	Core	AC coupled on module		PCI Express Differential Transmit Pairs 0 to 3	APU
PCIE_RX[0:3]+ PCIE_RX[0:3]-	I	PCIe	Core	AC coupled off module		PCI Express Differential Receive Pairs 0 to 3	APU
PCIE_WAKE#	I	CMOS	3.3V Sus.			PCI Express wake event signal	
PCIE_RST#	O	CMOS	3.3V			Reset signal for external devices	

### 2.7.5 USB

Signal	Pin Type	Signal Level	Power Rail	Remark / Power Tol.	PU/PD	Description	Source / Target
USB[0:7]+ USB[0:7]-	I/O	USB	3.3V Sus.	3.3V		USB differential pairs, channels 0 through 7	A50M

Signal	Pin Type	Signal Level	Power Rail	Remark / Power Tol.	PU/PD	Description	Source / Target
USB_0_1_OC#	I	CMOS	3.3V Sus.	3.3V	10k PU	USB over-current sense, USB channels 0 and 1. A pull-up for this line is present on the module. An open drain driver from a USB current monitor on the Carrier Board may drive this line low. Do not pull this line high on the Carrier Board.	A50M
USB_2_3_OC#	I	CMOS	3.3V Sus.	3.3V	10k PU	USB over-current sense, USB channels 2 and 3. A pull-up for this line is present on the module. An open drain driver from a USB current monitor on the Carrier Board may drive this line low. Do not pull this line high on the Carrier Board.	A50M
USB_4_5_OC#	I	CMOS	3.3V Sus.	3.3V	10k PU	USB over-current sense, USB channels 4 and 5. A pull-up for this line is present on the module. An open drain driver from a USB current monitor on the Carrier Board may drive this line low. Do not pull this line high on the Carrier Board.	A50M
USB_6_7_OC#	I	CMOS	3.3V Sus.	3.3V	10k PU	USB over-current sense, USB channels 6 and 7. A pull-up for this line is present on the module. An open drain driver from a USB current monitor on the Carrier Board may drive this line low. Do not pull this line high on the Carrier Board.	A50M

### 2.7.6 LVDS Flat Panel

Signal	Pin Type	Signal Level	Power Rail	Remark / Power Tol.	PU/PD	Description	Source / Target
LVDS_A[0:3]+ LVDS_A[0:3]-	O	LVDS	Core			LVDS Channel A differential pairs	ANX3110
LVDS_A_CK+ LVDS_A_CK-	O	LVDS	Core			LVDS Channel A differential clock	ANX3110
LVDS_B[0:3]+ LVDS_B[0:3]-	O	LVDS	Core			LVDS Channel B differential pairs	ANX3110
LVDS_B_CK+ LVDS_B_CK-	O	LVDS	Core			LVDS Channel B differential clock	ANX3110
LVDS_PPEN	O	CMOS	Core	3.3V		LVDS panel power enable	ANX3110
LVDS_BLEN	O	CMOS	Core	3.3V		LVDS panel backlight enable	ANX3110
LVDS_BKLT_CTRL	O	CMOS	Core	3.3V		LVDS panel backlight brightness control	ANX3110
LVDS_DID_CLK	I/O OD	CMOS	3.3V	3.3V	10k PU	I2C clock output for LVDS display use	ANX3110
LVDS_DID_DAT	I/O OD	CMOS	3.3V	3.3V	10k PU	I2C data line for LVDS display use	ANX3110

### 2.7.7 LPC Bus

Signal	Pin Type	Signal Level	Power Rail	Remark / Power Tol.	PU/PD	Description	Source / Target
LPC_AD[0:3]	I/O	CMOS	Core	3.3V		LPC multiplexed address, command and data bus	A50M
LPC_FRAME#	O	CMOS	Core	3.3V		LPC frame indicates the start of an LPC cycle	A50M
LPC_LDRQ#	I	CMOS	Core	3.3V	10k PU	LPC serial DMA request, not supported	A50M
SERIRQ	I/O	CMOS	Core	3.3V	10k PU	LPC serial interrupt	A50M
LPC_CLK	O	CMOS	3.3V	3.3V		LPC clock output - 33MHz nominal	A50M

### 2.7.8 HDMI

Signal	Pin Type	Signal Level	Power Rail	Remark / Power Tol.	PU/PD	Description	Source / Target
TMDS_LANE2+ TMDS_LANE2-	O	TMDS		AC coupled on module		Serial Digital Video output differential pair shared with signal SDVO_RED+ / SDVO_RED-	APU
TMDS_LANE1+ TMDS_LANE1-	O	TMDS		AC coupled on module		Serial Digital Video output differential pair shared with signal SDVO_GREEN+ / SDVO_GREEN-	APU
TMDS_LANE0+ TMDS_LANE0-	O	TMDS		AC coupled on module		Serial Digital Video output differential pair shared with signal SDVO_BLUE+ / SDVO_BLUE-	APU
TMDS_CLK+ TMDS_CLK-	O	TMDS		AC coupled on module		Serial Digital Video clock output differential pair. shared with signal SDVO_BCLK+ / SDVO_BCLK-	APU
HDMI_CTRL_CLK	I/O	CMOS	Core	3.3V	4K7 PU	HDMI I2C clock line - to set up HDMI peripherals. shared with signal SDVO_CTRL_CLK	APU
HDMI_CTRL_DAT	I/O	CMOS	Core	3.3V	4K7 PU	HDMI I2C data line - to set up HDMI peripherals. shared with signal SDVO_CTRL_DAT	APU

### 2.7.9 DisplayPort

Signal	Pin Type	Signal Level	Power Rail	Remark / Power Tol.	PU/PD	Description	Source / Target
DP_LANE0+ DP_LANE0-	O	PCIe		AC coupled on module		DisplayPort output differential pair shared with signal SDVO_RED+ / SDVO_RED-	APU
DP_LANE1+ DP_LANE1-	O	PCIe		AC coupled on module		DisplayPort output differential pair shared with signal SDVO_GREEN+ / SDVO_GREEN-	APU

Signal	Pin Type	Signal Level	Power Rail	Remark / Power Tol.	PU/PD	Description	Source / Target
DP_LANE2+ DP_LANE2-	O	PCIe		AC coupled on module		DisplayPort output differential pair shared with signal SDVO_BLUE+ / SDVO_BLUE-	APU
DP_LANE3+ DP_LANE3-	O	PCIe		AC coupled on module		DisplayPort output differential pair. shared with signal SDVO_BCLK+ / SDVO_BCLK-	APU
DP_AUX+ DP_AUX-	I/O	PCIe		AC coupled off module		Auxiliary channel differential pair shared with signal SDVO_FLDSTALL+ / SDVO_FLDSTALL-	APU
DP_HPD#	I	CMOS	Core	3.3V		Hot plug detection signal that serves as an interrupt request	APU

### 2.7.10 Express card support

Signal	Pin Type	Signal Level	Power Rail	Remark / Power Tol.	PU/PD	Description	Source / Target
EXCD0_CPPE#	I	3.3V	Core	3.3V		Express card slot 0 card request	A50M
EXCD0_PERST#	O	3.3V	Core	3.3V		Express card slot 0 reset	A50M
EXCD1_CPPE#	I	3.3V	Core	3.3V		Express card slot 1 card request	A50M
EXCD1_PERST#	O	3.3V	Core	3.3V		Express card slot 1 reset	A50M

### 2.7.11 Miscellaneous

Signal	Pin Type	Signal Level	Power Rail	Remark / Power Tol.	PU/PD	Description	Source / Target
I2C_CLK	I/O	CMOS	3.3V	3.3V		General purpose I2C port clock output	
I2C_DAT	I/O	CMOS	3.3V	3.3V		General purpose I2C port data I/O line	
SPKR	O	CMOS	3.3V	3.3V		Output for audio enunciator - the "speaker" in PC-AT systems	
BIOS_DISABLE#	I	CMOS	3.3V	3.3V	10k PU	Module BIOS disable input. Pull low to disable module BIOS.	
WDOUT	O	CMOS	3.3V	3.3V		Output indicating that a watchdog time-out event has occurred.	Microcontroller
WDTRIG#	I	CMOS	3.3V	3.3V		Watchdog trigger input. This signal restarts the watchdog timer	Microcontroller
FAN_TACHOIN	I	CMOS	3.3V			Tachometer input	A50M
FAN_PWMOUT	O	CMOS	3.3V			Pulse width modulation output for fan speed control	A50M



### 2.7.12 Power and System Management

Signal	Pin Type	Signal Level	Power Rail	Remark / Power Tol.	PU/PD	Description	Source / Target
PWRBTN#	I	CMOS	3.3V Sus.	3.3V	10k PU	Power button to bring system into a power state. (Negative pulse)	
RSTBTN#	I	CMOS	3.3V Sus.	3.3V	10k PU	Reset button input. Active low input. System is held in hardware reset while this input is low, and comes out of reset upon release. (Negative pulse)	
SUS_STAT#	O	CMOS	3.3V Sus.	3.3V		Indicates low power suspend operation	
SUS_S3#	O	CMOS	3.3V Sus.	3.3V		Indicates system is in Suspend to RAM state. Active low output.	
SUS_S5#	O	CMOS	3.3V Sus.	3.3V		Indicates system is in Soft Off state. Also known as "PS_ON" and can be used to control an ATX power supply.	
WAKE#	I	CMOS	3.3V Sus.	3.3V	10k PU	External system wake up signal.	
BATLOW#	I	CMOS	3.3V Sus.	3.3V	10k PU	Indicates that external battery is low.	
THRM#	I	CMOS	3.3V	3.3V	8k2 PU	Input from off-module temp sensor indicating an over-temp situation.	
THERMTRIP#	O	CMOS	3.3V	3.3V		Active low output indicating that the CPU has entered thermal shutdown.	
SMB_CLK	I/O	CMOS		3.3V	10k PU	System management clock line	
SMB_DAT	I/O	CMOS		3.3V	10k PU	System management data line	
SMB_Alert	I/O	CMOS		3.3V		System management bus alert input	
SLP_BTN#	I	CMOS		3.3V Sus	10k PU	Sleep button. Low active signal to bring the system in sleep state. (Negative pulse)	
LID_BTN#	I	CMOS		3.3V Sus	10k PU	LID button. Low active signal detect a LID switch to bring the system in sleep state or wake up again.(Low signal)	
BATLOW#	I	CMOS		3.3V Sus		Battery low input indicates a external battery low state	
PWGIN	I	Low<0.6V High>0.8V		5V	120k PD	Indicates that the external power supply is ready	


### 2.7.13 Power and GND

Signal	Pin Type	Signal Level	Power Rail	Remark / Power Tol.	PU/PD	Description	Source / Target
VCC_5V	Power		5V (±5%)			Primary power input: +5V (±5%)	Voltage Regulators
VCC_5V_SBY	Power		5V (±5%)			Standby power input: +5.0V (±5%) All available VCC_5V_SBY pins on the connector(s) shall be used. Used for microcontroller and standby and suspend functions. If no standby power is available connect to VCC_5V	VCC3.3V SUS regulator
VCC_RTC	Power					Real-time clock circuit-power input : +3.0V (+2.0V to +3.3V)	

Signal	Pin Type	Signal Level	Power Rail	Remark / Power Tol.	PU/PD	Description	Source / Target
GND	Power					Ground - DC power and signal and AC signal return path. All available GND connector pins shall be used and tied to Carrier Board GND plane.	

## 2.8 Connectors

Qseven Edge Module Connector



### 2.8.1 Module connector

Row A		Row B	
1	GND	2	GND
3	GBE_MDI3-	4	GBE_MDI2-
5	GBE_MDI3+	6	GBE_MDI2+
7	GBE_LINK100#	8	GBE_LINK1000#
9	GBE_MDI1-	10	GBE_MDI0-
11	GBE_MDI1+	12	GBE_MDI0+
13	NC	14	GBE_ACT#
15	GBE_CTREF	16	SUS_S5#
17	WAKE#	18	SUS_S3#
19	SUS_STAT#	20	PWRBTN#
21	SLP_BTN#	22	LID_BTN#
23	GND	24	GND
KEY		KEY	
25	GND	26	PWGIN
27	BATLOW#	28	RSTBTN#
29	SATA0_TX+	30	SATA1_TX+
31	SATA0_TX-	32	SATA1_TX-
33	SATA_ACT#	34	GND
35	SATA0_RX+	36	SATA1_RX+
37	SATA0_RX-	38	SATA1_RX-
39	GND	40	GND
41	BIOS_DISABLE#	42	NC
43	NC	44	NC
45	NC	46	NC
47	NC	48	NC
49	NC	50	NC

51	NC	52	NC
53	NC	54	NC
55	NC	56	NC
57	GND	58	GND
59	HDA_SYNC	60	SMB_CLK
61	HDA_RST#	62	SMB_DAT
63	HDA_BITCLK	64	SMB_ALERT#
65	HDA_SDI	66	I2C_CLK
67	HDA_SDO	68	I2C_DAT
69	THRM#	70	WDTRIG#
71	THRMTRIP#	72	WDOUT
73	GND	74	GND
75	USB_P7-	76	USB_P6-
77	USB_P7+	78	USB_P6+
79	USB_6_7_OC#	80	USB_4_5_OC#
81	USB_P5-	82	USB_P4-
83	USB_P5+	84	USB_P4+
85	USB_2_3_OC#	86	USB_0_1_OC#
87	USB_P3-	88	USB_P2-
89	USB_P3+	90	USB_P2+
91	USB_CL_PRES	92	USB_HC_SEL
93	USB_P1-	94	USB_P0-
95	USB_P1+	96	USB_P0+
97	GND	98	GND
99	LVDS_A0+	100	LVDS_B0+
101	LVDS_A0-	102	LVDS_B0-
103	LVDS_A1+	104	LVDS_B1+
105	LVDS_A1-	106	LVDS_B1-
107	LVDS_A2+	108	LVDS_B2+
109	LVDS_A2-	110	LVDS_B2-
111	LVDS_PPEN	112	LVDS_BLEN
113	LVDS_A3+	114	LVDS_B3+
115	LVDS_A3-	116	LVDS_B3-
117	GND	118	GND
119	LVDS_A_CLK+	120	LVDS_B_CLK+
121	LVDS_A_CLK-	122	LVDS_B_CLK-
123	LVDS_BLT_CTRL	124	RSVD
125	LVDS_DID_DAT	126	LVDS_BLC_DAT
127	LVDS_DID_CLK	128	LVDS_BLC_CLK
129	RSVD	130	RSVD
131	TMDS_CLK+	132	NC
133	TMDS_CLK-	134	NC
135	GND	136	GND
137	TMDS_LANE1+	138	DP_AUX+
139	TMDS_LANE1-	140	DP_AUX-
141	GND	142	GND
143	TMDS_LANE0+	144	NC

145	TMDS_LANE0-	146	NC
147	GND	148	GND
149	TMDS_LANE2+	150	HDMI_CTRL_DAT
151	TMDS_LANE2-	152	HDMI_CTRL_CLK
153	DP1_HPD	154	DP1_HPD
155	PCIE_CLK_REF+	156	PCIE_WAKE#
157	PCIE_CLK_REF-	158	PCIE_RST#
159	GND	160	GND
161	PCIE3_TX+	162	PCIE3_RX+
163	PCIE3_TX-	164	PCIE3_RX-
165	GND	166	GND
167	PCIE2_TX+	168	PCIE2_RX+
169	PCIE2_TX-	170	PCIE2_RX-
171	EXCD0_PERST#	172	EXCD1_PERST#
173	PCIE1_TX+	174	PCIE1_RX+
175	PCIE1_TX-	176	PCIE1_RX-
177	EXCD0_CPPE#	178	EXCD1_CPPE#
179	PCIE0_TX+	180	PCIE0_RX+
181	PCIE0_TX-	182	PCIE0_RX-
183	GND	184	GND
185	LPC_AD0	186	LPC_AD1
187	LPC_AD2	188	LPC_AD3
189	LPC_CLK	190	LPC_FRAME#
191	SERIRQ	192	LPC_LDRQ#
193	VCC_RTC	194	SPKR
195	FAN_TACHOIN	196	FAN_PWMOUT
197	GND	198	GND
199	SPI_MOSI	200	SPI_CS0
201	SPI_MISO	202	RSVD
203	SPI_SCK	204	RSVD
205	VCC_5V_SB	206	VCC_5V_SB
207	NC	208	NC
209	NC	210	NC
211	VCC	212	VCC
213	VCC	214	VCC
215	VCC	216	VCC
217	VCC	218	VCC
219	VCC	220	VCC
221	VCC	222	VCC
223	VCC	224	VCC
225	VCC	226	VCC
227	VCC	228	VCC
229	VCC	230	VCC

## 2.8.2 USB Port assignment

Note: The assignment of the USB Ports from Chipset to Q7 connector is as follows:

Chipset	Q7 Connector
Port 0	Port 5
Port 1	Port 3
Port 2	Port 0
Port 3	Port 2
Port 4	Port 6
Port 5	Port 4
Port 6	Port 1
Port 7	Port 7

In Bios setup, all USB port numbers are related to the chipset

## 3 System Resources

### 3.1 SMB Address Map

Device	A6	A5	A4	A3	A2	A1	A0	R/W	address *)
CMOS backup EEPROM	1	0	1	0	1	0	0	x	A8h / 54h
SPD EEPROM (SO-DIMM)	1	0	1	0	0	0	0	x	A0h / 50h

\*) 8 bit address (with R/W) / 7 bit address (without R/W)

### 3.2 PCI Express Lanes

Signal /Slot	Source
PCIE_TX[0] PCIE_RX[0]	PCIe-Channel 3 APU
PCIE_TX[1] PCIE_RX[1]	PCIe-Channel 2 APU
PCIE_TX[2] PCIE_RX[2]	PCIe-Channel 1 APU
PCIE_TX[3] PCIE_RX[3]	PCIe-Channel 0 APU

### 3.3 USB

Signal	Source / Target	Remark
USB[0]+ USB[0]-	USB0 A50M	USB1.1/2.0
USB[1]+ USB[1]-	USB2 A50M	USB1.1/2.0 )
USB[2]+ USB[2]-	USB1 A50M	USB1.1/2.0
USB[3]+ USB[3]-	USB3 A50M	USB1.1/2.0
USB[4]+ USB[4]-	USB4 A50M	USB1.1/2.0
USB[5]+ USB[5]-	USB5 A50M	USB1.1/2.0
USB[6]+ USB[6]-	USB6 A50M	USB1.1/2.0
USB[7]+ USB[7]-	USB7 A50M	USB1.1/2.0

### 3.4 PCI Interrupt Routing Table

Qseven			Interrupts of Controller (TCTC)							
Slot Number (or Onboard Device)	Dev / Func	Bus #	PIRQ 0 (INT A)	PIRQ 1 (INT B)	PIRQ 2 (INT C)	PIRQ 3 (INT D)	PIRQ 4 (INT E)	PIRQ 5 (INT F)	PIRQ 6 (INT G)	PIRQ 7 (INT H)
Internal Graphic Device	01h/01	0			A					
HD Audio	14h/02	0	A							
PCI Express Root Port 0	15h/0	0	A							
USB OHCI Host Controller	12h/0	0			A					
USB OHCI Host Controller	13h/0	0			A					
USB EHCI Host Controller	12h/02	0		B						
USB EHCI Controller	13h/02	0		B						
SATA	11h/0	0				A				
PCI to PCI Host Bridge	0h/07	0				A				
HD Audio AMD	01h/01	0				B				

### 3.5 IRQ Lines in Legacy IRQ Mode

IRQ#	Available	Typical Interrupt Source
0	No	Counter 0
1	No	Keyboard
2	No	Cascade Interrupt from Slave PIC
3	Yes	
4	Yes	
5	Yes	
6	Yes	
7	Yes	
8	No	RTC
9	Limited	In ACPI mode used for SCI
10	Yes	
11	Yes	



IRQ#	Available	Typical Interrupt Source
12	Yes	
13	No	Math coprocessor
14	Yes	
15	Yes	

### 3.6 *IRQ Lines in APIC Mode*

IRQ#	Available	Typical Interrupt Source	Connected to Pin
0	No	Counter 0	
1	No	Keyboard	
2	No	Cascade Interrupt from Slave PIC	
3	Yes		
4	Yes		
5	Yes		
6	Yes		
7	Yes		
8	No	RTC	
9	Yes	shared SCI	
10	Yes		
11	Yes		
12	No		
13	No	Math processor	
14	Yes		
15	Yes		
16	Yes		PIRQA
17	Yes		PIRQB
18	Yes		PIRQC
19	Yes		PIRQD
20	No		
21	No		
22	No		
23	No		

## **4 BIOS**

### **4.1 Introduction**

This guide describes the AMI Aptio Setup Startup screen and contains information on how to access Aptio setup to modify the settings which control AMI pre-OS (operating system) functions.

#### **4.1.1 Startup Screen Overview**

The AMI Aptio Startup screen is a graphical user interface (GUI) that is included in AMI Aptio products. The default bios behavior is to show an informational text screen during bios POST phase, but the graphical boot screen can be enabled in the bios setup. The standard boot screen is a black screen without any logo.

#### **4.1.2 Activity Detection Background**

While the startup screen is displayed, press the Setup Entry key (F2 or DEL). The system acknowledges the input, and at the end of POST, the screen clears and setup launches.

### **4.2 Aptio Setup Utility**

With the AMI Aptio Setup program, you can modify Aptio settings and control the special features of your computer. The setup program uses a number of menus for making changes and turning the special features on or off. This chapter provides an overview of the setup utility and describes at a high-level how to use it.

#### **4.2.1 Configuring the System BIOS**

To start the AMI Aptio Setup utility, press [F2 or DEL] to launch Setup. The setup main menu appears.

# The BIOS Menu Structure

The BIOS Menu is structured in the following way:

	<b>Main</b>
	MSC Board Info
	Hardware Monitoring Measurement
	<b>Advanced</b>
	PCI Subsystem Settings
	ACPI Settings
	Trusted Computing
	CPU Configuration
	SATA Configuration
	USB Configuration
	WB627 SIO Configuration
	AMI Graphic Output Protocol Policy
	<b>Chipset</b>
	North Bridge
	LVDS Config Select
	South Bridge
	<b>Boot</b>
	<b>Security</b>
	<b>Save &amp; Exit</b>

## The Menu Bar

The Menu Bar at the top of the window lists these selections:

Menu Items	Description
Main	Use this menu for basic system information.
Advanced	Use this menu to set the Advanced Features available on your system's chipset.
Chipset	Use this menu to set Chipset Features.
Security	Use this menu to set User and Supervisor Passwords and the Backup and Virus-Check reminders.
Boot	Use this menu to set the boot order in which the BIOS attempts to boot to OS.
Save & Exit	Saves and Exits the Aptio setup utility.

Use the left and right arrow keys on your keyboard to make a menu selection.

## The Legend Bar

Use the keys listed in the legend bar on the right side of the screen to make your selections, or to exit the current menu. The following table describes the legend keys and their alternates:

Key	Function
Esc	Exit submenu / Exit Setup utility without saving..
Left and right arrow keys	Select Screen.
Up and down arrow keys	Select Item.
+/-	Change Option.
F1	General Help window.
F2	Previous Values
F3	Optimized Defaults
F4	Save and Exit

## Select an item

To select an item, use the arrow keys to move the cursor to the field you want. Then use the plus-and-minus value keys to select a value for that field. Alternatively the Enter key can be used to select a value from a Pop Up menu. The Save Values commands in the Exit Menu save the values currently displayed in all the menus.

## Display a submenu

To display a submenu, use the arrow keys to move the cursor to the sub menu you want. Then press Enter. A pointer marks all submenus.

### 4.2.2 The Main Menu

You can make the following selections on the Main Menu itself. Use the sub menus for other selections.

Feature	Options	Description
Bios Vendor	Informative	Shows the Bios Vendor
Core Version	Informative	Shows the Aptio Core Version
Compliancy	Informative	Shows the UEFI Compliance Version
Project Version	Informative	Shows the Project Version
Build Date	Informative	Shows the Build Date
Total Memory	Informative	Shows the amount of RAM
MSC Board Info	Submenu	Shows board specific information
System Date	Enter Date ( MM:DD:YYYY)	Set the system date on the real time clock.
System Time	Enter Time (HH:MM:SS)	Set the system time on the real time clock.
Access Level	Informative	This feature shows what kind of user has entered the Aptio setup. It depends on the Security Tab if a Administrator and/or User password is set.

#### 4.2.2.1 MSC Board Info

Feature	Options	Description
Manufacturer	MSC Vertriebs GmbH	
Board Name	Informative	Shows the board name
Board Revision	Informative	Shows the board revision
Bios Version	Informative	Shows the bios version
Serial Number	Informative	Shows the boards serial number
Boot Counter	Informative	Shows the amount of boots
EC Bootloader Version	Informative	Shows the Embedded Controller Bootloader version
EC Firmwaer Version	Informative	Shows the Embedded Controller Firmware version
Onboard Lan MAC adresse	Informative	Shows the onboard Lan MAC adresse
UUID	Informative	Shows the UUID of the system

#### 4.2.2.2 Hardware Monitoring Measurement

Feature	Options	Description
CPU Temperature	Informative	Shows CPU Temperature
Chipset Temperature	Informative	Shows Chipset Temperature
CPU Fan Speed	Informative	Shows the current fan speed

#### 4.2.3 The Advanced Menu

Feature	Options	Description
PCI Subsystem Settings	Submenu	PCI, PCI-X and PCI Express settings
ACPI Settings	Submenu	System ACPI Parameters
Trusted Computing	Submenu	Trusted Computing ( TPM ) settings
CPU Configuration	Submenu	CPU Configuration Parameters
SATA Configuration	Submenu	AHCI SATA Configuration settings
USB Configuration	Submenu	USB configuration parameters

Feature	Options	Description
WB627 SIO Configuration	Submenu	Submenu for Super-IO Winbond W82627
Embedded Controller Features	Submenu	Embedded Controller Features
Serial Port Console Redirection	Submenu	Serial Port Console Redirection
AMI Graphic Output Protocol Policy	Submenu	Graphic Output adjustment ( appears only if Video Oprom policy is set to UEFI )

#### 4.2.3.1 PCI Subsystem Settings Submenu

Feature	Options	Description
PCI Latency Timer	32, 64, 96, 128, 160, 192, 224, 248 PCI Clocks	Value to be programmed into PCI latency timer register
VGA Palette Snoop	Enabled, Disabled	Enables or disables VGA Palette registers snooping
PERR# Generation	Enabled, Disabled	Enables or disables PCI device to generate PERR#
SERR# Generation	Enabled, Disabled	Enables or disables PCI device to generate SERR#
PCI Express Settings	Submenu	Configure PCI Express

##### 4.2.3.1.1 PCI Express Settings

Feature	Options	Description
Relaxed Ordering	Enabled, Disabled	Enables or disables PCI Express Device Relaxed Ordering..
Extended Tag	Enabled, Disabled	If enabled allows device to use 8-bit Tag field as a requester
No Snoop	Enabled, Disabled	Enables or disables PCI Express Device No Snoop option
Maximum Payload	Auto, 128, 256, 512, 1024, 2048. 4096 Bytes	Set maximum payload of PCI Express Device or allow system Bios to select the value
Maximum Read Request	Auto, 128, 256, 512, 1024, 2048. 4096 Bytes	Set read request size of PCI Express Device or allow system Bios to select the value

Feature	Options	Description
ASPM Support	Disabled, Auto, Force L0s	Set the ASPM level: Force L0s State: Auto: Bios configures ASPM Force L0s: L0s will be forced Disabled: No ASPM will be used
Extended Synchronization	Enabled, Disabled	Enabled allows generation of extended synchronization patterns
Link Training Retry	Disabled, 2, 5, 10	Defines number of retry. Attempt software will take to retrain the link if previous training attempt was unsuccessful.
Link Training Timeout	10us to 1000us	Defines number of microseconds software will wait before polling "Link Training" bit in link status register. Value range from 10 to 1000us.
Unpopulated Links	Kepp Link ON, Disable Link	In order to save power, software will disable unpopulated PCI Express links, if this option set to disabled.
Restore PCIe Register	Enabled, Disabled	On non-PCI Express aware OS 's ( Pre Windows Vista) some devices may not be correctly reinitialized after S3. Enabling this restores PCIe device configurations on S3 resume.



### 4.2.3.2 ACPI Settings

Feature	Options	Description
Enable ACPI Auto Conf	Enabled, Disabled	Enables or disables BIOS ACPI Auto Configuration.
Enable Hibernation	Enabled, Disabled	Enables or disables system ability to Hibernate (OS/S4 Sleep State). This option may not effective with some OS.
ACPI Sleep State	Suspend Disabled, S1 (CPU Stop Clock), S3 (Suspend to RAM)	Select the highest ACPI Sleep state the system will enter, when the Suspend button is pressed.
Lock Legacy Resources	Enabled, Disabled	Enables or disables lock of Legacy parameters.
LID Switch Support	Disabled, Active High, Active Low	Define the behavior of the LID switch. Active High = Lid is open with high level Active low= Lid is open with low level

### 4.2.3.3 TPM

Feature	Options	Description
TPM Support	Enabled, Disabled	Enables or disables TPM support. OS will not show TPM. Reset of platform is required For more information see also technotes in chapter 4.9
TPM state	Enabled, Disabled	Turn TPM Enable/Disable. NOTE: Your Computer will reboot during restart in order to change State of TPM.
Pending Operation	None, Enable take ownership Disable take ownership TPM clear	Schedule an operation for the Security Device. <b>Note</b> : Your computer will reboot during restart in order to change State of Security Device.

#### 4.2.3.4 CPU Configuration

**Note: Dependent on used CPU, available setup options may vary**

Feature	Options	Description
PSS Support	Enabled, Disabled	Enables or disables the generation of the _PPC, _PSS and _PCT objects.
PState Adjustment	PState 0, PState 1	Provide to adjust startup P_state level
PPC Adjustment	PState 0, PState 1	Provide to adjust _PPC object for ACPI OS.
NX Mode	Enabled, Disabled	Enables or disables NO-execute page protection function.
SVM Mode	Enabled, Disabled	Enable or disables CPU virtualization.
C6 Mode	Enabled, Disabled	Enables or disables C6
CPB Mode	Auto, Disabled	Auto/disable CPB
Node 0 Information	Submenu	View CPU and Cache Information related to Node 0

#### 4.2.3.5 SATA Configuration

Feature	Options	Description
SATA Port 0	Informative	Shows the SATA Device on Port 0
SATA Port 1	Informative	Shows the SATA Device on Port 1
SATA Port 2	Informative	Shows the SATA Device on Port 2

#### 4.2.3.6 USB Configuration

Feature	Options	Description
Legacy USB Support	Enabled, Disabled	Enables Legacy USB support. AUTO option disables legacy support if no USB devices are connected. DISABLE option will keep USB devices available only for EFI applications.
EHCI Hand-off	Enabled, Disabled	This is a workaround for OSes without EHCI hand-off support. The EHCI ownership change should be claimed by EHCI driver.
Port 60/64 Emulation	Enabled, Disabled	Enables I/O port 60h/64h emulation support. This should be enabled for the complete USB keyboard legacy support for non-USB aware OSes.
USB transfer time-out	1,5,10,20 sec	The time-out value for Control, Bulk, and Interrupt transfers.
Device reset time-out	10,20,30,40 sec	USB mass storage device Start Unit command time-out.
Device power-up delay	Auto, Manual	Maximum time the device will take before it properly reports itself to the Host Controller. 'Auto' uses default value: for a Root port it is 100 ms, for a Hub port the delay is taken from Hub descriptor.
Device power-up delay	Value 1-40	Delay range is 1...40 seconds, in one second increments.
USB Mass Storage Device ( e.g USB Stick)	Auto, Floppy, Forced FDD, Hard Disk, CD-ROM	Select Mass storage device emulation type.  Auto enumerates devices according to their media format. Optical drives are emulated as CDROM, drives with no media will be emulated according to a drive

#### 4.2.3.7 Winbond WB627 / SMSC3114 SuperIO Configuration (if available on carrier board)

Feature	Options	Description
COM A:	Enabled, Disabled	Enable or disable COM A on Winbond SIO
COM A Setting:	Auto, I/O 3F8h, IRQ 4 I/O 3F8h, IRQ 3, 4, 5, 6, 7, 8, 10, 11, 12 I/O 2F8h, IRQ 3, 4, 5, 6, 7, 8, 10, 11, 12 I/O 3E8h, IRQ 3, 4, 5, 6, 7, 8, 10, 11, 12 I/O 2E8h, IRQ 3, 4, 5, 6, 7, 8, 10, 11, 12	Resource setting for COM A on Winbond SIO
COM B:	Enabled, Disabled	Resource setting for COM A on Winbond SIO
COM B Setting:	Auto, I/O 2F8h, IRQ 3 I/O 3F8h, IRQ 3, 4, 5, 6, 7, 8, 10, 11, 12 I/O 2F8h, IRQ 3, 4, 5, 6, 7, 8, 10, 11, 12 I/O 3E8h, IRQ 3, 4, 5, 6, 7, 8, 10, 11, 12 I/O 2E8h, IRQ 3, 4, 5, 6, 7, 8, 10, 11, 12	Resource setting for COM A on Winbond SIO
LPT:	Disabled, Enabled	Enable or disable LPT on Winbond SIO
LPT Setting:	Auto, I/O 378h, IRQ 5, 7 I/O 278, IRQ 5, 7	Resource setting for LPT A on Winbond SIO

Feature	Options	Description
LPT Mode:	SPP, EPP 1.9, ECP, ECP + EPP 1.9, Printer Mode, EPP 1.7, ECP+EPP 1.7	Mode setting for LPT on Winbond SIO

#### 4.2.3.8 Embedded Controller Features

Feature	Options	Description
Watchdog Start on Boot	No, Yes	Start the watchdog after BIOS Post if enabled.
Startup Delay Value	1s, 10s, 30s, 1min, 5min	Select the initial delay value. This is an additional one-time delay before the standard timeout timer is started.
Event Timeout Value	1s, 10s, 30s, 1min, 5min	Select the timeout value after which the watchdog will be executing its event action
Reset Timeout Value	1s, 10s, 30s, 1min, 5min	Select the timeout value after which the watchdog will be executing its reset action. This timeout will start to countdown after the event timeout expired.
After Power Fail	Stay Off, Power On, Last State	Define the behaviour of the system after a power failure

#### 4.2.3.9 Serial Port Console Redirection

Feature	Options	Description
Com 0 Console Redirection	Enabled, Disabled	Console Redirection Enable or Disable
Console Redirection settings Com 0	Submenu	The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings.
Serial Port for Out-of-Band Management/Windows Emergency Management Service (EMS) Console Redirection	Enabled, Disabled	Console Redirection Enable or Disable

Feature	Options	Description
Console Redirection Settings	Submenu	The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings.

#### 4.2.3.9.1 Console Redirection Settings COM0 Submenu

Feature	Options	Description
Terminal Type	ANSI, VT100, VT100+, VT-UTF8	Emulation: ANSI: Extended ASCII char set. VT100: ASCII char set. VT100+: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.
Bits per second	9600, 19200, 38400, 57600, 115200	Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.
Data Bits	7, 8	Data Bits
Parity	None, Even, Odd, Mark, Space	A parity bit can be sent with the data bits to detect some transmission errors. Even: parity bit is 0 if the num of 1's in the data bits is even. Odd: parity bit is 0 if num of 1's in the data bits is odd. Mark: parity bit is always 1. Space: Parity bit is always 0. Mark and Space Parity do not allow for error detection. They can be used as an additional data bit.
Stop Bits	1,2	Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.
Flow Control	None, Hardware RTS/CTS,	Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a 'stop' signal can be sent to stop the data flow. Once the buffers are empty, a 'start' signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.
VTUF8 Combo Key Support	Enabled, Disabled,	Enable VT-UF8 Combination Key Support for ANSI/VT100 terminals
Recorder Mode	Disabled, Enabled	With this mode enabled only text will be sent. This is to capture Terminal data.
Resolution 100x31	Disabled, Enabled	Enables or disables extended terminal resolution
Legacy OS Redirection	80x24, 80x25	On Legacy OS, the number of rows and Columns supported redirection

Feature	Options	Description
Putty KeyPad	VT100, Linux, XTERMR6, SCO, ESCN, VT400	Select FunctionKey and KeyPad on Putty.
Redirection after Bios Post	Always Enable, Boot Loader	The settings specify if Bootloader is selected than legacy console redirection is disabled before booting to legacy OS.

#### 4.2.3.9.2 Console Redirection EMS

Feature	Options	Description
Out-of-Band Mgmt Port	COM0, COM1	Microsoft Windows Emergency Management Services (EMS) allows for remote management of a Windows Server OS through a serial port.
Terminal Type	ANSI, VT100, VT100+, VT-UTF8	Emulation: ANSI: Extended ASCII char set. VT100: ASCII char set. VT100+: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.
Bits per second	9600, 19200, 57600, 115200	Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.
Flow Control	None, Hardware RTS/CTS, Software Xon/Xoff	Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a 'stop' signal can be sent to stop the data flow. Once the buffers are empty, a 'start' signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.

#### 4.2.3.10 AMI Graphic Output Protocol Policy

Note: This setup item appears only if Video Oprom Policy under CSM settings is set to UEFI.

Feature	Options	Description
Output Select	DFP1_DVI, LCD1_LVDS	Select what first (on Boot) output interface should be used

## 4.3 Chipset

Feature	Options	Description
North Bridge	Submenu	North Bridge Parameters
LVDS Config Select	Submenu	LVDS Settings
South Bridge	Submenu	South Bridge Parameters

### 4.3.1 North Bridge

Feature	Options	Description
Primary Video Device	IGD Video, NB PCIe slot device	Select Primary Video device that BIOS will use for output
Memory Clock	Auto, 400 MHz, 533 MHz, 667 MHz	This option allows user to select different memory clocks. SPD : 400 MHz: DDR 800 533 MHz: DDR 1066 667 MHz: DDR 1333
Memory Clear	Not cleared, Cleared	Memory clear functionality control
Memory Information	Informative	Shows Information about size and clock of the memory
GFX / PCIe Configuration	Submenu	GFX / PCIe configuration
Socket 0 Information	Informative	View information related to socket 0



### 4.3.1.1 GFX / PCIe Configuration

Feature	Options	Description
NB GPP Core Config	Disabled, GPP_Core_x4x4; GPP_CORE_x4x2x2; GPP_CORE_x4x2x1x1; GPP_CORE_x4x1x1x1x1	NB GPP Core configuration
DP0 Output Mode	DP, eDP, Single Link DVI-D, HDMI, Travis DP-to-LVDS, Single Link DVI-I, LVDS, Disabled	NB PCIe connect type ( Display device )
DP1 Output Mode	DP, Single Link DVI-D, HDMI, Travis DP-to-LVDS, Single Link DVI-I, Disabled	NB PCIe connect type ( Display device )
Port 4-7 Control	Enabled, Disabled	Port 4/5/6/7 enabled/disabled
ASPM Mode Control	Disabled, L0s Entry, L1 Entry, L0s and L1 Entry	NB root port ASPM mode control
Hotplug Mode Control	Disabled, Hotplug-Basic, -Server, -Enhanced, -Inboard	NB root port hotplug mode
Link Speed	Max Speed, Gen1, Gen2	NB root port Pcie link speed, the link speed may overwritten by Pssp settings
PSP Policy	Disabled, Performance, Balanced-High, Balanced-Low, Power Saving	PCIe speed power policy

### 4.3.1.2 LVDS Config Select

Feature	Options	Description
LVDS Parameters Method	EDID EEPROM, LVDS Panel Type List	Select Method to get LVDS Timing
LVDS Panel Type	640x480, 800x480, 800x600, 1024x768, 1280x720, 1280x800, 1280x1024, 1366x768, 1440x900, 1600x900, 1920x1080	Select LVDS Panel resolution
LVDS Mapping	18 bit, 24 bit, 24bit FPGI	Select LVDS mapping type
LVDS Backlight Brightness Control	Enabled, Disabled	Enable / Disable Brightness Control
LVDS Backlight Brightness Polarity	Normal Inverted	Set PWM Polarity for Brightness Control
LVDS Backlight Brightness	0%-100% in 10% steps	Select the initial backlight brightness for the LFP panel. Note: Graphics driver may change this brightness setting.

### 4.3.1.3 South Bridge

Feature	Options	Description
SB SATA Configuration	Submenu	Options for SATA Configuration
SB USB Configuration	Submenu	Options for USB Configuration
SB GPP Port Configuration	Submenu	Options for GPP Port Configuration
SB HD Azalia Configuration	Submenu	Options for SB HD Azalia Configuration
SB Debug Configuration	Submenu	Options for SB Debug Configuration
SB Hardware Monitor Control	Submenu	SB Hardware Monitor Control
SB Clock Spread Spectrum	Disabled, Enabled	Enable SB Clock spread spectrum

#### 4.3.1.3.1 SB SATA Configuration

Feature	Options	Description
OnChip SATA Channel	Enabled, Disabled	Enable or Disabled SATA
OnChip SATA Type	AHCI, Legacy IDE, Native IDE	Select the SATA controller operating mode
SATA ESP on Port 0	Disabled, Enabled	Enable or disable SATA ESP on Port 0
SATA ESP on Port 1	Disabled, Enabled	Enable or disable SATA ESP on Port 1
SATA ESP on Port 2	Disabled, Enabled	Enable or disable SATA ESP on Port 2
SATA Power on Port 0	Disabled, Enabled	Enable or disable SATA Power on Port 0
SATA Power on Port 1	Disabled, Enabled	Enable or disable SATA Power on Port 1
SATA Power on Port 2	Disabled, Enabled	Enable or disable SATA Power on Port 2
SATA Port0 Mode	Auto, Gen1, Gen2	Forces the SATA Port to run at Gen1 mode if this option is set. Setting to Auto will leave the Port to run at default mode.
SATA Port1 Mode	Auto, Gen1, Gen2	Forces the SATA Port to run at Gen1 mode if this option is set. Setting to Auto will leave the Port to run at default mode.
SATA Port2 Mode	Auto, Gen1, Gen2	Forces the SATA Port to run at Gen1 mode if this option is set. Setting to Auto will leave the Port to run at default mode.
SATA Ports Auto Clock	Disabled, Enabled	SATA Ports Auto Clock Control

#### 4.3.1.3.2 SB USB Configuration

Feature	Options	Description
OHCI HC (Bus 0 Dev 18)	Enabled	This Port is always enabled
OHCI HC (Bus 0 Dev 19)	Enabled, Disabled	Enable or disable OHCI HC (Bus 0 Dev 19)

Feature	Options	Description
USB Port 0	Enabled, Disabled	Enable or disable Port 0
USB Port 1	Enabled	Enable or disable Port 1
USB Port 2	Enabled, Disabled	Enable or disable Port 2
USB Port 3	Enabled, Disabled	Enable or disable Port 3
USB Port 4	Enabled, Disabled	Enable or disable Port 4
USB Port 5	Enabled, Disabled	Enable or disable Port 5
USB Port 6	Enabled, Disabled	Enable or disable Port 6
USB Port 7	Enabled, Disabled	Enable or disable Port 7
USB Device Wakeup from S3 or S4	Enabled, Disabled	Enable or disable USB Device Wake up from S3 or S4.

#### 4.3.1.3.3 SB GPP Port Configuration

Feature	Options	Description
SB GPP Function	Enabled, Disabled	Enable or disable SB GPP Function
NB-SB PHY PLL Power Down	Enabled, Disabled	Enable or Disable NB-SB PHY PLL Power Down
SB GPP PHY PLL Power Down	Enabled, Disabled	Enable or Disable SB PHY PLL Power Down
SB GPP Port A ASPM	Enabled, Disabled	Enable or Disable SB GPP Port A ASPM

#### 4.3.1.3.4 HD Audio Azalia Configuration

Feature	Options	Description
HD Audio Azalia Device	Enabled, Disabled, Auto	Enable or Disable HD Audio Azalia Device
HD Onboard Pin Config	Enabled, Disabled	Enable or Disable HD Onboard Pin Config
Azalia Snoop	Enabled, Disabled	Enable or Disable Azalia Snoop

#### 4.3.1.3.5 Hardware Monitor Control

Feature	Options	Description
IMC Fan Control	Enabled, Disabled	IMC Fan Control ( if disabled, EC is also disabled )
Zone 0 Support	Enabled, Disabled	Zone 0 Support Help
Zone 0 Config	Submenu	Zone 0 Config

#### 4.3.1.3.6 Zone 0 Config

Feature	Options	Description
Zone 0 Fan Speed Mode	Linear Mode, Step Mode	Set fan speed to linear mode or step mode
Fan Frequency	From 11Hz up to 28,64Khz	Fan PWM Frequency
Zone 0 Temperature Average	Enabled, Disabled	Enable temperature averaging for the temperature sensor
Zone 0 Hysteresis	0-16	Active cooling hysteresis temperature in degree Celsius
Zone 0 PWM Step Rate	0-100	Fan PWM stepping rate in unit of PWM level percentage ( 0 to 100% )
CPU _AC0	0-100	AC0 is the 1 <sup>st</sup> or highest temperature threshold in degrees of Celsius
CPU _AC1	0-100	AC1 is the 2 <sup>nd</sup> temperature threshold in degrees of Celsius
CPU _AC2	0-100	AC3 is the 3th temperature threshold in degrees of Celsius

Feature	Options	Description
CPU _AC3	0-100	AC4 is the 4 <sup>th</sup> temperature threshold in degrees of Celsius
CPU _CRT	0-100	CRT is the critical temperature threshold in degrees of Celsius
CPU AL0	0-100	AL0 PWM level in percentage ( 0 to 100% ). This is to be applied when temperature threshold _AC0 is reached. The value is meaningful only if that threshold is defined.
CPU AL1	0-100	AL1 PWM level in percentage ( 0 to 100% ). This is to be applied when temperature threshold _AC1 is reached. The value is meaningful only if that threshold is defined.
CPU AL2	0-100	AL2 PWM level in percentage ( 0 to 100% ). This is to be applied when temperature threshold _AC2 is reached. The value is meaningful only if that threshold is defined.
CPU AL3	0-100	AL3 PWM level in percentage ( 0 to 100% ). This is to be applied when temperature threshold _AC3 is reached. The value is meaningful only if that threshold is defined.

#### 4.3.2 Boot

Feature	Options	Description
Setup Prompt Timeout	0-65535sec	Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.
Bootup NumLock State	On, Off	Select the keyboard NumLock state
Quiet Boot	Enabled, Disabled	Enables/Disables Quiet Boot option
Fast Boot	Enabled, Disabled	Enables/Disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options.  For more information see also technotes in chapter 4.9
Boot Option#	Bootdevice x	Set the system boot order  Note: The number of available Boot options is dependent on the devices which are connected.
CSM16 Parameters	Submenu	CSM16 configuration: Enable/Disable Option Rom execution settings, etc.
CSM Parameters	Submenu	Oprom execution, boot options filter, etc.

### 4.3.2.1 CSM16 Parameters

Feature	Options	Description
GateA20 Active	Upon Request, Always	UPON Request – GA20 can be disabled using BIOS services. Always – do not allow disabling GA20; this option is useful when any RT code is executed above 1MB
Option ROM Messages	Force Bios, Keep current	Set display mode for option ROM
Interrupt 19 Capture	Enabled, Disabled	Enabled: Allows option ROMs to trap Int 19

### 4.3.2.2 CSM Parameters

Feature	Options	Description
Launch CSM	Auto, Always, Never	This option controls if CSM will be launched
Boot option filter	UEFI and Legacy, Legacy only, UEFI only	This option controls what devices system can boot to.
Launch PXE OPROM policies	Do not launch, UEFI only, Legacy only	Controls the execution of UEFI and Legacy PXE OPROM
Launch Storage OPROM	Do not launch, UEFI only, Legacy only	Controls the execution of UEFI and Legacy Storage OPROM
Launch Video OPROM	Do not launch, UEFI only, Legacy only	Controls the execution of UEFI and Legacy Video OPROM.  IF set to UEFI, Graphic output can be adjusted in Menu “Advanced / AMI Graphic Output Protocol Policy”
Other PCI device ROM	UEFI OpROM, Legacy OpROM	For PCI devices other than Network, Mass storage or Video defines which OpROM to launch.

### 4.3.3 Security

Feature	Options	Description
Administrator Password	Set Password	Set Setup Administrator Password
User Password	Set Password	Set User Password

## 4.3.4 The Save & Exit Menu

The following sections describe each of the options on this menu.

### Save Changes and Exit

After making your selections in the setup menus, always select "Exit Saving Changes". This procedure stores the selections displayed in the menus in a flash. The next time you boot your computer, the BIOS configures your system according to the setup selections stored in flash. If you attempt to exit without saving, the program asks if you want to save before exiting. During boot-up, the Aptio BIOS attempts to load the values saved in flash. If those values cause the system boot to fail, reboot and press <ESC or DEL> to enter Setup. In Setup, you can get the Default Values (as described below) or try to change the selections that caused the boot to fail.

### Discard Changes and Exit

Exit system setup without saving any changes.

### Save Changes and Reset

When you have completed the system configuration changes, select this option to save the changes and reboot the system, so the new system configuration parameters can take effect.

### Discard Changes and Reset

Select this option to quit Aptio™ TSE without making any modifications to the system configuration

### Save Changes

Selecting "Save Options" saves all the selections without exiting Setup. You can return to the other menus if you want to review and change your selections.

### Discard Changes

Discard changes done so far to any of the setup options

### Restore Defaults

Restore/load default values for all the setup options

### Restore User Defaults

Restore the User defaults to all the setup options.

### Save as User Defaults



Save changes done so far as User defaults.

## **Boot Override**

It will display all the available boot options from the Boot Option List. The user can select any of the options to select to the particular device and boot directly from it.

## **Launch EFI Shell from filesystem device**

Attempts to Launch EFI Shell application (Shellx64.efi) from one of the available filesystem devices.

## **4.4 BIOS and Firmware Update**

If a System-BIOS update is required please follow these instructions:

### **- Bios Update from DOS:**

Create a bootable DOS disk, USB Stick or hard disk and unpack the update tool AFUDOS.exe from AFUx64\_301.msi

Copy the files "afudos.exe", "uefi.rom" and "update.bat" to this device.

Boot the system from this device.

Type "update" to update the System Bios.

When the Bios update has finished, reboot the system.

### **- Bios Update under Windows:**

Copy the afuwingui.exe, amifldr32.sys and the bios image uefi.rom to a storage media (e.g USB stick).

Boot Windows XP or Windows 7.

Copy the 3 files from your storage media to your Harddisk

Run afuwingui.exe. Make sure that no other application is running to avoid crashes during the update procedure.

Select "Open" and choose the bios image file uefi.rom.

After it has opened, a new Tab Window will be displayed where you can choose what block options should be updated. To make sure all relevant updates will be updated, select "Program all Blocks". All Blocks should be marked now.

Click the Button "Flash" and Bios update will start.

After update is finished ( all blocks are green ), restart your system.

**Note:** The Amiflash tool for windows can be downloaded from [www.ami.com](http://www.ami.com)

#### - **Bios Update from EFI Shell**

Create a FAT32 formatted removable device and unpack the update tool AfuEfix64.efi from AFUx64\_301.msi

Copy an EFI Shell ( shellx64.efi) into the root directory of the device.

Copy the files "AfuEfix64.efi", "uefi.rom", "update.nsh" to this device.

Enter System setup and under the menu bar "Save and Exit" choose Launch EFI Shell from filesystem device.

After Shell is loaded, type:

- fs0:

- update.nsh

When the Bios update has finished, reboot the system.

**Note: If an EFI Shell is needed for Bios updates, please contact MSC Technical support.**

**Note:** After the system has been updated, the setup settings will be changed to defaults and therefore it may be necessary to enter Setup to reconfigure the system settings.

### **4.5 Blind Restoration of Bios default settings (no display available)**

- Power up the System
- Repeatedly press DEL for several seconds
- Press F3 for default settings or F2 for previous values.
- Press Enter
- Press F4
- Press Enter
- System will restart

### **4.6 Restore Bios settings from file**

It is possible to save configured Bios settings and copy these settings to other boards which have the same Bios version.

- Configure the setup as required
- Load DOS or EFI Shell with afudos.exe ( for DOS ) or afuefix64.efi ( for EFI Shell ).
- Run afudos.exe/afuefix64.efi with following switch to save current Bios:  
Afudos.exe filename /o  
AfuEfix64.efi filename /o
- To copy these Bios settings onto another module run afudos.exe or afuefix64.efi with following switch:  
Afudos.exe filename /n /R  
AfuEfix64.efi filename /n /R

Only the Bios settings will be updated without flashing the complete Bios.

If complete Bios update is also needed, additional switches are needed :

Afudos.exe uefi.rom /gan

AfuEfix64.efi filename /p /b /n /x

## 4.7 Post Codes

For Post Code information please contact MSC Technical Support

Phone: +49 - 8165 906 - 200

Fax: +49 - 8165 906 - 201

Email: [support@mscembedded.com](mailto:support@mscembedded.com)

## 4.8 EAPI

The "Embedded Application Programming Interface" (EAPI) used by this module provides a standardized interface for customer applications. This interface allows a user mode application access to hardware specific information as well as hardware resources. Following features are supported:

- view board information
- access to NVRAM
- access to I2C
- control backlight
- set watchdog timer
- view sensor values of hardware monitor

MSC provides a software package which is downloadable here after registration

<http://www.mscembedded.com/de/support-center/qseven/msc-q7-a50m.html>

**Note:** I2C function is realized by using GPIO's, so I2C Clock speed is dependent on CPU speed, system load and power scheme. Normally it is round about 90 KHz.

## 4.9 Tech Notes

### 1. Trusted Platform Module (TPM)

A TPM is a cryptoprocessor that can store cryptographic keys that protect information.

The Trusted Platform Module offers facilities for the secure generation of cryptographic keys, and limitation of their use, in addition to a hardware pseudo-random number generator. It also includes capabilities such as remote attestation and sealed storage.

"Remote attestation" creates a nearly unforgeable hash-key summary of the hardware and software configuration. The program encrypting the data determines the extent of the summary of the software. This allows a third party to verify that the software has not been changed.

"Binding" encrypts data using the TPM endorsement key, a unique RSA key burned into the chip during its production, or another trusted key descended from it.

"Sealing" encrypts data in similar manner to binding, but in addition specifies a state in which the TPM must be in order for the data to be decrypted (unsealed).

Software can use a Trusted Platform Module to authenticate hardware devices. Since each TPM chip has a unique and secret RSA key burned in as it is produced, it is capable of performing platform authentication. For example, it can be used to verify that a system seeking access is the expected system.

### 2. ASPM ( Active State Power Management )

Active State Power Management or ASPM is a power management protocol used to manage PCI Express-based serial link devices as links become less active over time. As serial-based PCIe bus devices, such as IEEE1394 (FireWire), become less active, it is possible for the computer's power management system to take the opportunity to reduce overall power consumption by placing the link PHY into a low-power mode and instructing other devices on the link to follow suit.

#### List of references

5. ASPM

[http://en.wikipedia.org/wiki/Active\\_State\\_Power\\_Management](http://en.wikipedia.org/wiki/Active_State_Power_Management)

10. TPM

[http://en.wikipedia.org/wiki/Trusted\\_Platform\\_Module](http://en.wikipedia.org/wiki/Trusted_Platform_Module)

For additional help contact MSC Technical Support:

Phone: +49 - 8165 906 - 200

Fax: +49 - 8165 906 - 201

Email: [support@mscembedded.com](mailto:support@mscembedded.com)

