

THANK YOU FOR PURCHASING YOUR TIMEX WATCH.

EXTENDED WARRANTY

Available in U.S. only. Extend your warranty for an additional 4 years from date of purchase for \$5. You can pay with AMEX, Discover, Visa or MasterCard by calling 1 800-448-4639 during normal business hours. Payment must be made within 30 days of purchase. Name, address, telephone number, purchase date, and 5-digit model number required. You can also mail a check for \$5 to: Timex Extended Warranty, P.O. Box 1676, Dept. EF, Little Rock, AR 72203.

Please read instructions carefully to understand how to operate your Timex watch.

Your model may not have all of the features described in this booklet.



FEATURES

Time and date (12/24-hour format) • Hourly chime • Daily alarm • 24-hour chronograph • INDIGLO® night-light

BASIC OPERATIONS




SET TIME-DATE

1. Press MODE until Time display appears.
2. Press SET. Seconds will flash. Press START/STOP to set to 00.
3. Press MODE. Second digit of minutes will flash. Press START/STOP to advance.
4. Press MODE. First digit of minutes will flash. Press START/STOP to advance.
5. Press MODE. Hour (with A/P) will flash. Press START/STOP to advance. Press SPLIT/RESET to switch between 12- and 24-hour format.
6. Press MODE to continue setting month, date, day of week.
7. Press SET to exit at any time.

In Time display, press START/STOP to turn hourly chime on/off. Colon will flash when on.

ALARM


1. Press MODE until "ALARM" appears in upper left of display. Alarm time appears at top of display.
2. Press SET. Hour will flash. Press START/STOP to advance.
3. Press MODE. First digit of minutes will flash. Press START/STOP to advance.
4. Press MODE. Second digit of minutes will flash. Press START/STOP to advance.
5. Press SET to exit at any time. Alarm is automatically armed.

When alarm is armed,  appears here and in Time display.

In Alarm mode, press START/STOP to arm/disarm alarm.

When alarm sounds, press any button to silence. Alarm remains armed and will continue to occur daily.

CHRONOGRAPH



1. Press MODE until "CHR" appears.
2. Press START/STOP to start chrono.
3. Press START/STOP to stop. Press again to continue.
4. When chrono is stopped, press SPLIT/RESET to reset chrono to zero.

Taking Splits

While the chrono is running, you may freeze the display, to see your time at a particular point. This is called "taking a split." To take a split, press SPLIT/RESET while the chrono is running. "SPLIT" appears and the display will freeze for ten seconds before showing the running chrono again. You may skip the ten-second freeze by pressing MODE.

If you exit Chrono mode with the chrono running, it will continue to run. In the Time display, "CHR" will flash.

INDIGLO® NIGHT-LIGHT

Press INDIGLO (SPLIT/RESET) when time of day or alarm time is displayed (but not while setting) to activate night-light. Electroluminescent technology used in INDIGLO® night-light illuminates entire watch face at night and in low-light conditions. Release INDIGLO to turn light off.

WATER RESISTANCE

If your watch is water-resistant, meter marking or () is indicated.

Water-Resistance Depth	p.s.i.a. * Water Pressure Below Surface
30m/98ft	60

*pounds per square inch absolute

WARNING: TO MAINTAIN WATER-RESISTANCE, DO NOT PRESS ANY BUTTONS UNDER WATER.

1. Watch is water-resistant only as long as lens, push buttons and case remain intact.
2. Watch is not a diver watch and should not be used for diving.
3. Rinse watch with fresh water after exposure to salt water.

BATTERY

Timex strongly recommends that a retailer or jeweler replace battery. If applicable, push reset button when replacing battery. Battery type is indicated on caseback. Battery life estimates are based on certain assumptions regarding usage; battery life may vary depending on actual usage.

DO NOT DISPOSE OF BATTERY IN FIRE. DO NOT RECHARGE. KEEP LOOSE BATTERIES AWAY FROM CHILDREN.

(warranty information on reverse)

TIMEX INTERNATIONAL WARRANTY

(U.S. – LIMITED WARRANTY – PLEASE SEE FRONT OF INSTRUCTION BOOKLET
FOR TERMS OF EXTENDED WARRANTY OFFER)

Your TIMEX watch is warranted against manufacturing defects by Timex Corporation for a period of ONE YEAR from the original purchase date. Timex and its worldwide affiliates will honor this International Warranty.

Please note that Timex may, at its option, repair your watch by installing new or thoroughly reconditioned and inspected components or replace it with an identical or similar model. **IMPORTANT — PLEASE NOTE THAT THIS WARRANTY DOES NOT COVER DEFECTS OR DAMAGES TO YOUR WATCH:**

- 1) after the warranty period expires;
- 2) if the watch was not originally purchased from an authorized Timex retailer;
- 3) from repair services not performed by Timex;
- 4) from accidents, tampering or abuse; and
- 5) lens or crystal, strap or band, watch case, attachments or battery. Timex may charge you for replacing any of these parts.

THIS WARRANTY AND THE REMEDIES CONTAINED HEREIN ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE. TIMEX IS NOT LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some countries and states do not allow limitations on implied warranties and do not allow exclusions or limitations on damages, so these limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from country to country and state to state.

To obtain warranty service, please return your watch to Timex, one of its affiliates or the Timex retailer where the watch was purchased, together with a completed original Watch Repair Coupon or, in the U.S. and Canada only, the completed original Watch Repair Coupon or a written statement identifying your name, address, telephone number and date and place of purchase. Please include the following with your watch to cover postage and handling (this is not a repair charge): a US\$ 7.00 check or money order in the U.S.; a CAN\$6.00 cheque or money order in Canada; and a UK£2.50 cheque or money order in the U.K. In other countries, Timex will charge you for postage and handling. NEVER INCLUDE A SPECIAL WATCHBAND OR ANY OTHER ARTICLE OF PERSONAL VALUE IN YOUR SHIPMENT.

For the U.S., please call 1-800-448-4639 for additional warranty information. For Canada, call 1-800-263-0981. For Brazil, call 0800-168787. For Mexico, call 01-800-01-060-00. For Central America, the Caribbean, Bermuda and the Bahamas, call (501) 370-5775 (U.S.). For Asia, call 852-2815-0091. For the U.K., call 44 208 687 9620. For Portugal, call 351 212 946 017. For France, call 33 3 81 63 42 00. For Germany, call 49 7 231 494140. For the Middle East and Africa, call 971-4-310850. For other areas, please contact your local Timex retailer or Timex distributor for warranty information. In Canada, the U.S. and in certain other locations, participating Timex retailers can provide you with a postage-paid, pre-addressed Watch Repair Mailer for your convenience in obtaining factory service.