


www.cleveracoustics.co.uk




VC 20 100V 20W VOLUME CONTROL Code: CRVOL01 VC 40 100V 40W VOLUME CONTROL Code: CRVOL02 VC 60 100V 60W VOLUME CONTROL Code: CRVOL03 VC 20R 100V 20W VOLUME CONTROL + RELAY Code: CRVOL04 VC 40R 100V 40W VOLUME CONTROL + RELAY Code: CRVOL05 VC 60R 100V 60W VOLUME CONTROL + RELAY Code: CRVOL05

USER MANUAL

WARNING


FOR YOUR OWN SAFETY, PLEASE READ THIS USER MANUAL CAREFULLY BEFORE YOUR INITIAL START-UP!



SAFETY INSTRUCTIONS

Every person involved with the installation, operation & maintenance of this equipment should:

- Be competent
 - Follow the instructions of this manual



Before your initial start-up, please make sure that there is no damage caused during transportation. Should there be any, consult your dealer and do not use the equipment.

To maintain the equipment in good working condition and to ensure safe operation, it is necessary for the user to follow the safety instructions and warning notes written in this manual.

Please note that damages caused by user modifications to this equipment are not subject to warranty.



IMPORTANT:

The manufacturer will not accept liability for any resulting damages caused by the non-observance of this manual or any unauthorised modification to the equipment.

- Never let the power-cable come into contact with other cables. Handle the power-cable and all mains voltage connections with particular caution!
- Never remove warning or informative labels from the equipment.
- · Do not open the equipment and do not modify the equipment.
- Do not switch the equipment on and off in short intervals, as this will reduce the system's life.
- · Do not expose to flammable sources or gases.
- Make sure that the speaker-cable is never crimped or damaged. Check the equipment and the speaker-cable periodically.
- If the equipment is dropped or damaged, disconnect the mains power supply immediately. Have a qualified engineer inspect the equipment before operating again.
- If your product fails to function correctly, discontinue use immediately. Pack the unit securely (preferably in the original packing material), and return it to your Prolight dealer for service.
- Repairs, servicing and power connection must only be carried out by a qualified technician. THIS UNIT CONTAINS NO USER SERVICEABLE PARTS.
- WARRANTY; One year from date of purchase.

OPERATING DETERMINATIONS

If this equipment is operated in any other way, than those described in this manual, the product may suffer damage and the warranty becomes void.

Incorrect operation may lead to danger e.g.: short-circuit, burns, electric shocks, lamp failure etc.

Do not endanger your own safety and the safety of others! Incorrect installation or use can cause serious damage to people and property. The 100V VC volume controls are designed specifically for use in permanent audio installations with optional 24V relay input (VC 20R, 40R & 60R) for emergency override.

This 100V volume controller warranted from defects for one year from the date of purchase. Should your 100V volume control require service, either within or beyond that warranty period, please contact your Prolight Dealer.


This unit includes a host of features, along with an impressive list of specifications, which are detailed over the next pages. Please take the time to read this document completely prior to installation of this product.

Features:

- Built-in 100V line transformer
- 11 volume positions (10 + off)
- Rugged plastic housing
- Rotary volume control
- 70V/100V inputs (from mixer amplifier)
- 70V/100V outputs (to speakers)
- DC 24V input (VC 20R/40R/60R only)
- Wall screws included (2 x M3 screws)
- Suitable for, schools, industrial and commercial applications where background music, announcements and paging is required

Product	VC 20	VC 40	VC 60	VC 20R	VC 40R	VC 60R
Rated power:	20W	40W	60W	20W	40W	60W
Line input:	70V/100V	70V/100V	70V/100V	70V/100V	70V/100V	70V/100V
Attenuation per step:	3dB	3dB	3dB	3dB	3dB	3dB
Total attenuation:	33dB	33dB	33dB	33dB	33dB	33dB
Attenuation positions:	10 + off					
DC 24V relay:	No	No	No	Yes	Yes	Yes
Dimensions (mm)	80 x 80 x 48					

Overview:



Identification:

- 1. 100V transformer
- 2. Screw mounting holes Use these to attached the controller to the controller wall back box.
- 3. +ve 100V line input Use this input to connect the speaker cable from the amplifier.
- 4. Input ground
- 5. Output ground
- 6. +ve 100V line output Use this output to connect to the speakers from the volume control.
- 7. -ve 24V alarm ground
- 8. + ve 24V alarm input Use this to connect to the fire alarm. (VC 20R/40R and 60R only).
- 9. Volume control Use this to increase or decrease the output volume.
- 10. Volume control housing


Wall Installation


The VC Volume Control is designed to be installed using standard 45mm deep pattress boxes.

Before installing the volume control, make sure that the installation area can hold a minimum point load of 10 times the installations weight.(e.g.12Kg 130Kgs point load).

The durability of the installation depends very much on the material used at the installation area (building material), such as wood, concrete and brick etc.

This is why the fixing material must be chosen to suit the ceiling material. Always ask a specialist for the correct plug/screw combination indicating the maximum load and building material.






.....

.....

5.



Cleaning and Maintenance

We recommend a frequent cleaning of the product. Please use a soft lint free and moistened cloth. Never use alcohol or solvents.

There are no serviceable parts inside the product except for the fuse. Maintenance and service operations are only to be carried out by authorised dealers.

