



BroadSoft Partner Configuration Guide

Grandstream GXV-3000
IP Video Phone
&
GXP-2000 SIP Enterprise Phone
&
BT-200 SIP Phone

BroadWorks® Guide

Copyright Notice

Copyright © 2007 Grandstream Networks, Inc.

All rights reserved.

Any technical documentation that is made available by Grandstream Networks, Inc. is proprietary and confidential and is considered the copyrighted work of Grandstream Networks, Inc.

Trademarks

BroadWorks® and BroadWorks Assistant™ are trademarks of BroadSoft, Inc.

Microsoft, MSN, Windows, and the Windows logo are registered trademarks of Microsoft Corporation. Other product names mentioned in this manual may be trademarks or registered trademarks of their respective companies and are hereby acknowledged.

This document is printed in the United States of America.

Document Revision History

Version	Reason for Change
1.1	Introduced document.

Table of Contents

1	Overview.....	5
2	BroadWorks Validation Package Support Level	6
3	Device Capabilities and Known Interoperability Issues.....	7
3.1	Capabilities.....	7
3.2	Interoperability Issues.....	9
4	BroadWorks Device Identity/Profile	10
5	BroadWorks Device Type	11
6	Configuration.....	12
6.1	System Level Configuration	13
6.2	Subscriber Level Configuration Parameters	14
7	Enhanced IP Phone Configuration.....	15

1 Overview

This document describes the configuration procedures required for both the Grandstream GXV-3000 / GXP-2000 / BT-200 to maximize the capabilities of BroadWorks.

The GXV-3000 / GXP-2000 are a few of the many access devices that interoperate with BroadWorks.

The GXV-3000 / GXP-2000 uses the Session Initiation Protocol (SIP) to communicate with BroadWorks for call control. It also translates voice to audio packets for transmission across a packet network.

This guide describes the specific configuration items that are important for use with BroadWorks. It does not describe the purpose and use of all configuration items on the GXV-3000 / GXP-2000 / BT-200. For those details, see the *GXV-3000 / GXP-2000 / BT-200 User Manual* supplied by Grandstream [\[1\]](#).

2 BroadWorks Validation Package Support Level

Devices are validated according to *BroadWorks Validation Packages*. Each package validates a subset of features or items. This section describes the device's support level for a *BroadWorks Validation Package* as well as the features or items in the package that are not supported. Packages not applicable to the device are marked "Not applicable" in the *Items Not Supported* column. For specific issues, see section [3.2 Interoperability Issues](#). For a complete list of items validated per package, see [Appendix B: BroadWorks Validation Package Test Items](#).

BroadWorks Package	Support Level	Items Not Supported
Basic Call	Full	
BroadWorks Enhanced Services	Full	
DUT Services – Call Control	Full	
DUT Services – Registration and Authentication	Full	
DUT Services – FAX	None	
DUT Services – Busy Lamp Field	GXV-3000: None GXP-2000: Full	
Redundancy	Full	
SBC/ALG	Full	
Shared Call Appearance	None	
Video	GXV-3000: Full GXP-2000: None	Video Add-On (N/A)
TCP	GXV-3000: None GXP-2000: Full	

3 Device Capabilities and Known Interoperability Issues

This section describes the features supported by the GXV-3000 / GXP-2000 / BT-200, as well as BroadWorks interoperability issues and impact. The following table describes capabilities.

Verified Revisions shows the results of partner (vendor) testing of a specific BroadWorks version with a specific partner's device under test (DUT) version.

Compatible Revisions indicates the maintenance versions that should interface properly with BroadWorks.

3.1 Capabilities

Device Type	SIP Phone
Lines and Appearances	GXV-3000 / GXP-2000 / BT-200: 3 lines / 4 lines / 1 line
Speaker/Power/Bridge	Yes/No/Yes
Verified Revisions	BroadWorks Release 14.0 GXV-3000: Grandstream 1.0.0.41 GXP-2000: Grandstream 1.1.2.14 BT-200: Grandstream 1.1.1.14
Compatible Revisions	BroadWorks Release 14.0 GXV-3000: Grandstream Any maintenance version of 1.0.0.41 GXP-2000: Grandstream Any maintenance version of 1.1.2.14 BT-200: Grandstream Any maintenance version of 1.1.1.14
SIP Proxy FQDN DNS Lookup (A, SRV, NAPTR)	A, SRV
Outbound Proxy Configurable	Yes
Outbound Proxy FQDN DNS Lookup (A, SRV, NAPTR)	A, SRV
BroadWorks Redundancy Enabled	Yes
BroadWorks Shared Call Appearance	No
BroadWorks Enhanced IP Phone Configuration	No
Device Services	Call Forwarding, Attended/Blind Call Transfer, 3-way Call, Call Waiting, Call Hold, Mute, Camera Bloc(GXV only).
Device Call Control (Device-Controlled or Flash INFO-based)	Device-Controlled

Codecs	PCMU, PCMA, GSM, G.729A/B, G.723.1, G.726-32, G.711 (μ /A), G.722, iLBC, H.264 video (GXV only)
RFC 2833 DTMF	Yes
T.38 Fax	N/A
TCP	GXV-3000: Yes GXP-2000: Yes BT-200: Yes
TLS	Pending (BT-200 / GXV-3000) GXP-2000

3.2 Interoperability Issues

This section lists the known interoperability issues between BroadWorks and partner release(s). For more information on issues related to the particular software release, see the partner release notes (*generally, this should only be for GA partner releases*).

None.

4 BroadWorks Device Identity/Profile

BroadWorks configurable device identify/profile is introduced in BroadWorks Release 14.0. **This section applies only to BroadWorks Release 14.0 and later.**

The following table identifies the required BroadWorks device identity/profile settings for interoperability between the GXV-3000 / GXP-2000 / BT-200 and BroadWorks. For an explanation of the profile parameters, refer to the *BroadWorks Device Inventory Guide* [4].

For most of the parameters below, an “X” indicates the parameter function is supported and/or required. If the item is blank, it is not supported.

Grandstream GXV-3000/GXP-2000 Identify/Device Profile	
Signaling Address Type	IntelligentProxy Addressing
Number of Lines	GXV-3000: 3 lines GXP-2000: 4 lines BT-200: 1 line
Registration Capable	X
Static Registration Capable	
E.164 Capable	
Trusted	
Authentication Override	
Video Capable	X
RFC 3264 Hold	X
Route Advance	
Wireless Integration	
PBX Integration	
Use Business Trunking Contact	
Forwarding Override	
Conference Device	
Music On Hold Device	
Web Based Configuration URL	http://:%BWIPADDRESS%
Auto Configuration Type	2 Config File
Reset Event	checkSync
Enable Monitoring	
CPE System File Name	gxvSystem.txt / gxpSystem.txt
Device File Format	%BWMACADDRESS%.txt

5 BroadWorks Device Type

This section applies to BroadWorks Release 14.0 and before.

The following BroadWorks device type should be used for Grandstream GXV-3000 / GXP-2000 / BT-200, respectively.

- Grandstream GXV-3000
- Grandstream GXP-2000
- Grandstream BT-200

The above device types require BroadWorks Release 13 MP<TBD>. If the BroadWorks system is currently at a lower patch level, either apply the necessary patch or use the following generic device type until the system can be patched accordingly.

- Generic SIP Phone

6 Configuration

Grandstream GXV-3000 / GXP-2000 / BT-200 can be configured via Web GUI Interface as well as via Configuration File through TFTP or HTTP.

The GXV-3000 / GXP-2000 / BT-200 accepts configuration files in a proprietary binary format which is produced by the Grandstream configuration tool. The configuration tool creates a device configuration file based on a configuration template and the device's MAC address. All Grandstream products' sample configuration templates are available on Grandstream's web site. A configuration template file contains all configuration parameters available for a product, with comments describing allowed values of the parameters. For a detailed parameter list, please refer to the corresponding firmware release configuration template [2].

When Grandstream device boots up or reboots, it will issue request for a binary configuration file named "cfgxxxxxxxxxx", where "xxxxxxxxxx" is the MAC address of the device, i.e., "cfg000b820102ab". The configuration file name should be in lower cases.

Grandstream offers free Configuration File generator software in both Linux/Unix and Windows platform. Both Configuration File Generators can be downloaded from Grandstream official web site at http://www.grandstream.com/DOWNLOAD/Configuration_Tool/ [2].

The following examples describe how to set the parameters using a configuration file. The GXV-3000 / GXP-2000 / BT-200 should be configured to load the configuration file each time it resets or re-synchronizes. For detailed information on automated provisioning, please check the *GXV-3000 / GXP-2000 / BT-200 User Manual* [1] and the Grandstream configuration tool user guide [2].

The capabilities of the GXV-3000 / GXP-2000 / BT-200 have been verified for use with BroadWorks based on the settings described in the following table. For more information on the meaning, purpose, and applicability of the individual configuration items, see the *GXV-3000 / GXP-2000 / BT-200 configuration template* [2].

Configuration Files

Files Provided by Partner	Level	Description
GXV-3000 / GXP-2000 / BT-200 Configuration Template Example: g xv3000_ config_ 1.0.0.41.txt g xp2000_ config_ 1.1.2.25.txt	System and Subscriber	Contains configurable parameters that apply to an individual device in a deployment.
cfgMAC Example: cfg000b82000000	System and Subscriber	Binary configuration file generated from configuration template and an individual device's MAC address

6.1 System Level Configuration

This section describes system-wide configuration requirements for each GXV-3000 / GXP-2000 / BT-200 to work with BroadWorks. Subscriber-specific settings are described in the next section.

Step	Command	Purpose
System Configuration Items		
Step 1	Set SIP Proxy/Domain. SIP Server = as.broadworks.net	Set the GXV-3000 / GXP-2000 / BT-200 SIP server to the Fully Qualified Domain Name (FQDN) for the BroadWorks Application Server cluster. The domain must match the domain configured for the BroadWorks subscriber's line/port domain.
Step 2	Set Outbound Proxy. OutBound Proxy = alg.broadworks.net	Set the outbound proxy to the session border controller (SBC) if one is deployed between the GXV-3000 / GXP-2000 / BT-200 and BroadWorks. If there are redundant SBCs, set it to the FQDN for the SBC cluster.
Step 3	Enable DNS SRV lookup. Use DNS SRV = "Yes"	Enable DNS SRV lookups.
Step 4	Set register mode. SIP Registration = "Yes"	Enable SIP register.
Step 5	Set SIP Timers. Register Expiration = 60	The default registration period is 60 minutes.
Step 6	Enable reliable response. Enable 100rel = "Yes"	Reliable provisional response (PRACK) should be enabled.
Step 7	Enable negotiated DTMF type. Send DTMF = "via RTP (RFC2833)"	Set the GXV-3000 / GXP-2000 / BT-200 to enable inband or RFC 2833 negotiated DTMF.
Step 8	Enable BroadSoft mode. Special Feature = "Broadsoft"	Set the GXV-3000 / GXP-2000 / BT-200 in BroadSoft mode.

6.2 Subscriber Level Configuration Parameters

This section identifies the device-specific parameters, including registration and authentication. These settings must be unique across devices in order to be matched with the settings for a BroadWorks subscriber.

Provisioning a subscriber to register with BroadWorks allows calls to terminate to the subscriber's line. Registration requires that a unique address of record (AoR) is provisioned on BroadWorks and the phone; provisioning an AoR on BroadWorks consists of setting the line/port parameter to a unique value within the Application Server cluster.

Grandstream GXV-3000 / GXP-2000 / BT-200 supports three SIP accounts (lines), four SIP accounts, and 1 SIP account respectively. The follow example shows how to configure subscriber elements for an account.

Step	Command	Purpose
Subscriber Configuration Items		
Step 1	Enable a line to be used. Account Active = "Yes" ;	Enable a line of GXV-3000 / GXP-2000 / BT-200 in use.
Step 2	Set Register User ID for a line. Example: SIP User_ID = "2405551111" ;	The register user ID must correspond with the line/port setting on BroadWorks.
Step 3	Enable SIP Authentication for a line. Example: Authenticate ID = "1111@as.mycompany.com" ; Authenticate Password = "welcome" ;	If the Authentication service is configured on BroadWorks, these parameters must be configured to match the BroadWorks settings.
Step 4	Configure display name for a line. Example: Name = "Claire Smith" ;	For a line, configure the name to be displayed on the device.

7 Enhanced IP Phone Configuration

Enhanced IP Phone Configuration is a BroadWorks feature that enables automatic generation of device configuration files, given administrator-supplied templates.

For more information on the Enhanced IP Phone Configuration feature, see the *Enhanced IP Phone Configuration Guide* [3].

NOTE: BroadSoft does not manage or distribute template files for use with the Enhanced IP Phone Configuration feature. Obtain template files from Grandstream or use the configuration files obtained from Grandstream for the specific GXV-3000 / GXP-2000 / BT-200 firmware release to create template files appropriate for your installation.

Since the GXV-3000 / GXP-2000 / BT-200 SIP phones require the configuration files be converted into a binary format, an extra step must be performed when using this feature. After the configuration files have been sent to the TFTP server and before the phone is reset, the configuration files must be converted to binary format using Grandstream's configuration tool. For detailed information on automated provisioning, please check the Grandstream configuration tool user guide [2].

The GXV-3000 / GXP-2000 / BT-200 use only a phone-specific file to configure the device. However, the Enhanced IP Phone Configuration feature requires a system and a phone-specific file for each device. To satisfy the system file requirement, an empty file (*gxpDefault.txt*, *gxvDefault.txt*) will need to be uploaded to BroadWorks as the system file. This file will be sent to the FTP server but will not actually be used for the configuration file generation. The group template file is used to build the configuration files for the devices of this device type assigned to the group. For a sample GXV-3000 / GXP-2000 / BT-200 group template file, see Appendix A.

Appendix A: Sample GXV-3000 / GXP-2000 / BT-200 Configuration File

NOTE: The following samples are examples and should be used as a reference only. DO NOT CUT AND PASTE THESE EXAMPLES TO GENERATE YOUR CONFIGURATION FILES. Use the configuration files obtained from Grandstream with the specific release to generate your configuration files.

System Default Parameters:

NOTE: This is an example file and should be used for reference only.

```
# SIP Default Generic Configuration Parameters

#####
# Account 1      #
#####

# SIP Server
P47 = as.broadworks.net

# Outbound Proxy
P48 = alg.broadworks.net

# Use DNS SRV. 0 - no, 1 - yes.
P103 = 1

# SIP Registration. 0 - no, 1 - yes
P31 = 1

# Register Expiration (in minutes. default 1 hour, max 45 days)
P32 = 60

# Send DTMF. 0 - in audio, 1 - via RTP(RFC2833), 2 - via SIP INFO
P73 = 1

# Enable 100rel. 0 - no, 1 - yes
P272 = 1

# Special Feature. 102 - BroadSoft
P198 = 102

#####
# Account 2      #
#####

# SIP Server
P402 = as.broadworks.net

# Outbound Proxy
P403 = alg.broadworks.net

# Use DNS SRV. 0 - no, 1 - yes.
P408 = 1
```



```
# SIP Registration. 0 - no, 1 - yes
P410 = 1

# Register Expiration (in minutes. default 1 hour, max 45 days)
P412 = 60

# Send DTMF. 0 - in audio, 1 - via RTP(RFC2833), 2 - via SIP INFO
P416 = 1

# Enable 100rel. 0 - no, 1 - yes
P435 = 1

# Special Feature. 102 - BroadSoft
P424 = 102

#####
# Account 3          #
#####

# SIP Server
P502 = as.broadworks.net

# Outbound Proxy
P503 = alg.broadworks.net

# Use DNS SRV. 0 - no, 1 - yes.
P508 = 1

# SIP Registration. 0 - no, 1 - yes
P510 = 1

# Register Expiration (in minutes. default 1 hour, max 45 days)
P512 = 60

# Send DTMF. 0 - in audio, 1 - via RTP(RFC2833), 2 - via SIP INFO
P516 = 1

# Enable 100rel. 0 - no, 1 - yes
P535 = 1

# Special Feature. 102 - BroadSoft
P524 = 102

#####
# GXP-2000 only: Account 4      #
#####

# SIP Server
P602 = as.broadworks.net

# Outbound Proxy
P603 = alg.broadworks.net

# Use DNS SRV. 0 - no, 1 - yes.
P608 = 1

# SIP Registration. 0 - no, 1 - yes
P610 = 1

# Register Expiration (in minutes. default 1 hour, max 45 days)
```

```
P612 = 60

# Send DTMF. 0 - in audio, 1 - via RTP(RFC2833), 2 - via SIP INFO
P616 = 1

# Enable 100rel. 0 - no, 1 - yes
P635 = 1

# Special Feature. 102 - BroadSoft
P624 = 102
```

Phone-Specific Parameters:

NOTE: This is an example file and should be used for reference only.

```
# SIP Device-specific Configuration Parameters

#####
# Account 1          #
#####

# Account Active (In Use). 0 - no, 1 - yes
P271 = 1

# SIP User ID
P35 = 2405551111

# Authenticate ID
P36 = 1111@as.mycompany.com

# Authenticate password
P34 = welcome

# Display Name (John Doe)
P3 = Claire Smith

#####
# Account 2          #
#####

# Account Active (In Use). 0 - no, 1 - yes
P401 =

# Account 2 SIP User ID
P404 =

# Authenticate ID
P405 =

# Authenticate Password
P406 =

# Display Name (John Doe)
P407 =
```

```
#####
# Account 3          #
#####

# Account Active (In Use). 0 - no, 1 - yes
P501 =

# SIP User ID
P504 =

# Authenticate ID
P505 =

# Authenticate Password
P506 =

# Display Name (John Doe)
P507 =

#####
# GXP-2000 only: Account 4      #
#####

# Account Active (In Use). 0 - no, 1 - yes
P601 =

# Account 2 SIP User ID
P604 =

# Authenticate ID
P605 =

# Authenticate Password
P606 =

# Display Name (John Doe)
P607 =
```

Group Template File: GXV-GroupTemplate.txt

NOTE: This is an example file and should be used for reference only.

```
# SIP Default Generic Configuration Parameters

#####
# Account 1          #
#####

# SIP Server
P47 = as.broadworks.net

# Outbound Proxy
P48 = alg.broadworks.net
```

```
# Use DNS SRV. 0 - no, 1 - yes.
P103 = 1

# SIP Registration. 0 - no, 1 - yes
P31 = 1

# Register Expiration (in minutes. default 1 hour, max 45 days)
P32 = 60

# Send DTMF. 0 - in audio, 1 - via RTP(RFC2833), 2 - via SIP INFO
P73 = 1

# Enable 100rel. 0 - no, 1 - yes
P272 = 1

# Special Feature. 102 - BroadSoft
P198 = 102

#####
# Account 2          #
#####

# SIP Server
P402 = as.broadworks.net

# Outbound Proxy
P403 = alg.broadworks.net

# Use DNS SRV. 0 - no, 1 - yes.
P408 = 1

# SIP Registration. 0 - no, 1 - yes
P410 = 1

# Register Expiration (in minutes. default 1 hour, max 45 days)
P412 = 60

# Send DTMF. 0 - in audio, 1 - via RTP(RFC2833), 2 - via SIP INFO
P416 = 1

# Enable 100rel. 0 - no, 1 - yes
P435 = 1

# Special Feature. 102 - BroadSoft
P424 = 102

#####
# Account 3          #
#####

# SIP Server
P502 = as.broadworks.net

# Outbound Proxy
P503 = alg.broadworks.net

# Use DNS SRV. 0 - no, 1 - yes.
P508 = 1

# SIP Registration. 0 - no, 1 - yes
P510 = 1
```

```
# Register Expiration (in minutes. default 1 hour, max 45 days)
P512 = 60

# Send DTMF. 0 - in audio, 1 - via RTP(RFC2833), 2 - via SIP INFO
P516 = 1

# Enable 100rel. 0 - no, 1 - yes
P535 = 1

# Special Feature. 102 - BroadSoft
P524 = 102

#####
# GXP-2000 only: Account 4      #
#####

# SIP Server
P602 = as.broadworks.net

# Outbound Proxy
P603 = alg.broadworks.net

# Use DNS SRV. 0 - no, 1 - yes.
P608 = 1

# SIP Registration. 0 - no, 1 - yes
P610 = 1

# Register Expiration (in minutes. default 1 hour, max 45 days)
P612 = 60

# Send DTMF. 0 - in audio, 1 - via RTP(RFC2833), 2 - via SIP INFO
P616 = 1

# Enable 100rel. 0 - no, 1 - yes
P635 = 1

# Special Feature. 102 - BroadSoft
P624 = 102

# SIP Device-specific Configuration Parameters

#####
# Account 1      #
#####

# Account Active (In Use). 0 - no, 1 - yes
P271 = 1

# SIP User ID
P35 = %BWLINPORT-1%

# Authenticate ID
P36 = %BWAUTHUSER-1%

# Authenticate password
P34 = %BWAUTHPASSWORD-1%

# Display Name (John Doe)
```

```

P3 = %BWCLID-1%

#####
# Account 2          #
#####

# Account Active (In Use). 0 - no, 1 - yes
P401 = 1

# Account 2 SIP User ID
P404 = %BWLINPORT-2%

# Authenticate ID
P405 = %BWAUTHUSER-2%

# Authenticate Password
P406 = %BWAUTHPASSWORD-2%

# Display Name (John Doe)
P407 = %BWCLID-2%

#####
# Account 3          #
#####

# Account Active (In Use). 0 - no, 1 - yes
P501 = 1

# SIP User ID
P504 = %BWLINPORT-3%

# Authenticate ID
P505 = %BWAUTHUSER-3%

# Authenticate Password
P506 = %BWAUTHPASSWORD-3%

# Display Name (John Doe)
P507 = %BWCLID-3%

#####
# GXP-2000 only: Account 4          #
#####

# Account Active (In Use). 0 - no, 1 - yes
P601 = 1

# Account 2 SIP User ID
P604 = %BWLINPORT-4%

# Authenticate ID
P605 = %BWAUTHUSER-4%

# Authenticate Password
P606 = %BWAUTHPASSWORD-4%

# Display Name (John Doe)
P607 = %BWCLID-4%

```

Appendix B: BroadWorks Validation Package Test Items

The following table describes the items tested in each *BroadWorks Validation Package*.

BroadWorks Validation Package	Items Supported
Basic Call	<ul style="list-style-type: none"> Basic Call Origination / Termination Call Failure Codes Session Audit Ringback Dial Plan Inband DTMF RFC 2833/Negotiation Codec Renegotiation
BroadWorks Enhanced Services	<ul style="list-style-type: none"> Basic CommPilot Call Manager Functions Voice Messaging Audio MWI Voice Messaging Visual MWI Ring Splash Priority Alerting Priority Call Waiting Alternate Numbers Advanced Call Control Anonymous Call Remote Restart Call Park Retrieve – Answer with Hold
DUT Services – Call Control	<ul style="list-style-type: none"> Call Waiting Call Hold Blind Transfer Attended Transfer 3-Way Call Network Conference 3-Way Network Conference N-Way
DUT Services – Registration and Authentication	<ul style="list-style-type: none"> Authenticated Registration Maximum Registration Minimum Registration Rejected Registration Authenticated Origination Authenticated Re-INVITE Authenticated REFER BroadWorks Authentication

BroadWorks Validation Package	Items Supported
DUT Services - FAX	FAX Passthrough FAX T38
DUT Services – Busy Lamp Field	Basic BLF
Redundancy	DNS Registration Failover Call Setup Failover Mid-Call Failover
SBC/ALG	Registration Call Origination Call Termination
Shared Call Appearance	Line Seize Line Lamp Management Line Hold/Retrieve Multiple Call Arrangement SCA Bridging
Video	Integrated Video Phone Video Add-On
TCP	Basic

References

- [1] Grandstream Networks, Inc. 2007. *GXV-3000 / GXP-2000 / BT-200 User Manual*. Download @ http://www.grandstream.com/user_manuals/GXV3000.pdf, http://www.grandstream.com/user_manuals/GXP2000.pdf, http://www.grandstream.com/user_manuals/BT200.pdf AND GUI Interfaces http://www.grandstream.com/user_manuals/GUI/GUI_GXV3000.rar, http://www.grandstream.com/user_manuals/GUI/GUI_GXP2000.rar, http://www.grandstream.com/user_manuals/GUI/GUI_BT200.rar
- [2] Grandstream Networks, Inc. 2007. Grandstream Configuration Tool and Templates. Available from http://www.grandstream.com/DOWNLOAD/Configuration_Tool/.
- [3] BroadSoft, Inc. 2006. *BroadWorks Enhanced IP Phone Configuration Guide*, Release 14.0. Available from the BroadSoft KnowledgeBase at www.broadsoft.com/KnowledgeBase.
- [4] BroadSoft, Inc. 2006. *BroadWorks Device Inventory Guide*, Release 14.0. Available from the BroadSoft KnowledgeBase at www.broadsoft.com/KnowledgeBase.