

# fifthplay EnergySmart

## User Guide





# CONTENTS

## ▶ Introduction 7

- ▷ What is fifthplay EnergySmart? 7

## ▶ Installation 9

- ▷ Getting started 9
- ▷ Connecting the gateway 10
- ▷ Connecting the gateway to the wireless network 13
- ▷ Registering a new user 16
- ▷ Activating fifthplay EnergySmart 16

## ▶ Network 19

- ▷ General 19
  - Personalising the network 19
  - Consulting an overview of all devices in your network 19
- ▷ Rooms 19
  - Adding a new room 19
  - Editing the name of a room 19
  - Adding a schedule to a room 20
- ▷ Groups 20
  - Adding a new group 20
  - Adding devices to a group 20
  - Editing a group 21
  - Adding a schedule to a group 21
  - Removing a group 21

## ▶ Smart plugs 23

- ▷ Connecting the smart plugs 23
- ▷ Adding smart plugs to the system 24

# Contents

- ▷ Configuring the smart plugs 25
- ▷ Switching the smart plugs on and off 26
- ▷ Adding the smart plugs to a room 26
- ▷ Adding the smart plugs to a group 27
- ▷ Creating a schedule 27
- ▷ Amending an existing schedule 28
- ▷ Removing an existing schedule 28
- ▷ Allocating a schedule to a smart plug 29
- ▷ Adding Smart plugs to a schedule 29
- ▷ Removing Smart plugs from a schedule 30
- ▷ Erasing the history of your smart plugs 30

## ▶ **Smart meter 31**

- ▷ Adding the smart meter to the system 31
- ▷ Configuring the smart meter 32
- ▷ Viewing your consumption 33

## ▶ **Smart thermostat 35**

- ▷ Adding a smart thermostat to the system 35
- ▷ Configuring the smart thermostat 36
- ▷ Manually controlling the smart thermostat 37
- ▷ Consulting the current temperature 38
- ▷ About the schedule for the smart thermostat 38
- ▷ Adjusting the schedule 38
- ▷ Viewing the consumption of the smart thermostat 39

## ▶ **Smart DIN rail module 41**

- ▷ Adding the smart DIN rail module to the system 41
- ▷ Configuring the smart DIN rail module 42

# Contents

- ▷ Viewing the energy produced by the smart DIN rail module 43
- ▷ Configuring the kWh counter 43

## ▶ Consumption 45

- ▷ Consulting the current consumption of a device 45
- ▷ Viewing the consumption of a device 45
- ▷ Comparing the consumption of your devices 46
- ▷ Exporting the consumption of your devices 47
- ▷ Automatically exporting your results 47

## ▶ Tariffs 49

- ▷ About adding tariffs 49
- ▷ Altering the standard tariff 49
- ▷ Adding a new tariff 50
- ▷ Removing a tariff 51
- ▷ Calculating your projected cost savings 52

## ▶ Messages 53

- ▷ Reading messages 53
- ▷ Deleting messages 53
- ▷ Setting messages for unexpected consumption 54
- ▷ Configuring messages for exceeded target consumption 55
- ▷ Adding recipients 55
- ▷ Editing recipients 56
- ▷ Deleting recipients 56

## ▶ Personal settings 57

- ▷ Changing the language 57
- ▷ Changing your email address 57

# Contents

- ▷ Changing your mobile phone number 57
- ▷ Changing your address 58
- ▷ Altering your notification preferences 58
- ▷ Changing the name of your gateway 58
- ▷ Receiving a warning when the gateway is offline 59
- ▷ Setting your time zone 59
- ▷ Renewing your voucher 59
- ▷ Changing your password 60
- ▷ Changing your user name 60

## ▶ **Smartphones and tablet computers 61**

- ▷ Installing the fifthplay app 61

## ▶ **Troubleshooting 63**

- ▷ Gateway 63
- ▷ Wireless internet 64
- ▷ Smart plugs 65
- ▷ Smart thermostat 66
- ▷ Messages 67
- ▷ Support 67

# 1 Introduction

## 1.1 What is fifthplay EnergySmart?

With fifthplay EnergySmart, you can collect and analyse important energy data about your home or building in no time at all. This means that you will know exactly where your energy is being consumed and you will be able to rapidly intervene to rein in excessive energy consumption. In addition to energy consumption, you can also monitor energy production which allows you to increase the performance of your solar panels, for instance.

fifthplay EnergySmart gives you a real-time view of the behaviour of hundreds of measuring points at various sites. You will know immediately where energy is being consumed in excess.

fifthplay EnergySmart lets you analyse all of your data and view this in easy-to-use charts. This allows you to save both time and money, because you know immediately where you need to intervene. Several major advantages of fifthplay EnergySmart are:

- available at all times and everywhere via the internet and your smartphone
- user-friendly interface
- advanced analytical functions for electricity, water and gas
- dashboards which show real-time data
- data can be exported in a variety of formats
- automated reporting, alarm and notification services
- remote monitoring and data logging by means of our proprietary fifthplay gateway technology.

# *1 Introduction*



## 2 Installation

### 2.1 Getting started


- 1 Connect the gateway, see “Connecting the gateway” on page 10.
- 2 Register yourself as a new user, see “Registering a new user” on page 16.
- 3 Activate fifthplay EnergySmart, see “Activating fifthplay EnergySmart” on page 16.
- 4 Install your devices:
  - “Smart plugs” on page 23
  - “Smart meter” on page 31
  - “Smart thermostat” on page 35

# 2 Installation


## 2.2 Connecting the gateway

If you would like to connect your gateway to your wireless internet, go to [“Connecting the gateway to the wireless network” on page 13](#). The following instructions are for connecting the gateway to your internet modem or router using an Ethernet cable.


- 1 Open the cover on the underside of your gateway.



**TIP:** Make a note of the serial number and MAC address of your gateway. You will need these when you register as a user.




- 2 Use the Ethernet cable to connect your gateway to your internet modem or router.




## 2 Installation

- 3 Plug the network cable into your gateway.




*NOTE:* If you want to connect a smart meter, then you can also connect the P1/USB cable here, see “Adding the smart meter to the system” on page 31.

- 4 Close the cover.




## 2 Installation

- 5 Insert the plug into to the wall outlet.



The led light on the gateway will begin to flash green. The gateway is starting up. You will now hear a voice say “Your fifthplay device is starting up”. As soon as the led light stops flashing and remains green, you are connected to the internet and your gateway is working correctly.

**TIP:** Move your hand over the gateway to hear the current status of your device.




# 2 Installation

## 2.3 Connecting the gateway to the wireless network


You can only do this if your gateway has a wireless (Wi-Fi) module.

*NOTE:* Before you can connect to the wireless network, you should connect your gateway to your internet modem or router using the Ethernet cable. You can remove this cable again as soon as your gateway has connected to the wireless internet.

- 1 Open the cover on the underside of your gateway.




**TIP:** Make a note of the serial number and MAC address of your gateway. You will need these when you register as a user.




## 2 Installation


- 2 Use the Ethernet cable to connect your gateway to your internet modem or router.



- 3 Plug the network cable into your gateway.



- 4 Plug your gateway into the wall outlet.



# 2 Installation

- 5 Open the internet browser on your computer and type the following address so that your gateway can make contact with your internet modem or router:

Operating system	Address
Windows	<p>http://FP[MAC address of your gateway] <b>Example:</b> http://FP00112A211DAD</p> <p>If this address does not work, try putting .local at the end of the address. <b>Example:</b> http://FP00112A211DAD.local</p>
Mac OS	http://FP[MAC address of your gateway].local

Only enter the digits and letters of your MAC address, without the colons.



- 6 Click **Wi-Fi configuration**.
- 7 Select the wireless network you would like to connect to from the list.
- 8 Enter your password.
- 9 When the status changes to **ready**, you are connected to the wireless network. You can now remove the Ethernet cable from your gateway and your internet modem or router.

As soon as the led light on your gateway shines green, your gateway is connected to the wireless network. You can now close the cover on your gateway.

# 2 Installation

## 2.4 Registering a new user


You should only perform this action if you do not yet have a user account. If you do have an account, then you only need to install the gateway.

- 1 Visit [my.fifthplay.com](https://my.fifthplay.com).
- 2 Click **Register** in the **New user** window.
- 3 Enter the following information:
  - **Personal details**
  - **Login details**
  - **Gateway details**
- 4 Click **Register**.
- 5 Read and accept the terms and conditions.

A confirmation screen will appear.
- 6 Check your email and click the activation link in the email from fifthplay EnergySmart to activate your account.
- 7 Now log in to the website as an existing user.

You are now registered as a user and signed in to the website.

## 2.5 Activating fifthplay EnergySmart

- 1 Choose **settings > My settings** and click the  button.
- 2 Click **Add a new voucher**.
- 3 Read and accept the terms and conditions.
- 4 Enter the voucher code.
- 5 Click **Register**.

fifthplay EnergySmart is now activated. You can now install devices and intelligently manage your energy consumption.



# 2 *Installation*

Following steps:

- "Smart plugs" on page 23
- "Smart meter" on page 31
- "Smart thermostat" on page 35

# *2 Installation*

# 3 Network

## 3.1 General

### Personalising the network

You can give a name to your network if you wish. This can be convenient if you use various gateways and want to easily identify your networks for instance.

- 1 Go to the **Network** tab and choose **General > Network settings**.
- 2 Enter the name that you want to give to your network in the **Network name** field.
- 3 Click **Save**.

### Consulting an overview of all devices in your network

- 1 Go to the **Network** tab and choose **General > Network overview**.  
An overview of all devices and your current status will appear.
- 2 Click the devices if you would like more details.

## 3.2 Rooms

### Adding a new room

- 1 Go to the **Network** tab and click **+** on the left-hand menu next to **Rooms**.
- 2 Enter the name for the new room in the **Room details** dialogue box.  
*EXAMPLE:* Living room.
- 3 Click **Save**.

### Editing the name of a room

- 1 Go to the **Network** tab and click **Rooms**.
- 2 Click **✎** next to the room for which you want to edit the name.
- 3 Edit the name of the room in the **Room details** dialogue box.
- 4 Click **Save**.

# 3 Network

## Adding a schedule to a room

You should already have created a schedule. To create a schedule, see “Creating a schedule” on page 27.

- 1 Go to the **Schedules** tab and select **General > Apply a schedule**.
- 2 Select a schedule from the list.
- 3 Select the **Room** radio button.
- 4 Use the drop-down menu to select the room you want to add the schedule to.

*NOTE:* You can only select rooms to which you have already added smart plugs. To add smart plugs to a room, see “Adding the smart plugs to a room” on page 26.

- 5 Click **Schedule**.

## 3.3 Groups

### Adding a new group

- 1 Go to the **Network** tab and click **+** in the left-hand menu next to **Groups**.
- 2 Enter the name for your new group in the **Group details** tab.

*EXAMPLE:* Lights.

- 3 If you want to be able to consult the group as a whole, then select the **Visible on dashboard** check box.
- 4 Select the device that you want to add to the group in the **Devices** tab.

*NOTE:* You can still add other devices to the group later on.


- 5 Click **Save**.

### Adding devices to a group

- 1 Go to the **Network** tab and click **Groups**.
- 2 Click **↗** next to the group that you want to add devices to.
- 3 Check the devices that you want to add to this group in the **Devices** tab.
- 4 Click **Save**.

# 3 Network

## Editing a group


- 1 Go to the **Network** tab and click **Groups**.
- 2 Click  next to the group that you wish to edit.
- 3 Make the necessary amendments in the **Group details** tab.
- 4 Click **Save**.

## Adding a schedule to a group

You should already have created a schedule. To create a schedule, see [“Creating a schedule” on page 27](#).

- 1 Go to the **Schedules** tab and select **General > Apply a schedule**.
- 2 Select a schedule from the list.
- 3 Select the **Group** radio button.
- 4 Use the drop-down menu to select the group that you want to apply the schedule to.
- 5 Click **Schedule**.

## Removing a group

- 1 Go to the **Network** tab and click **Groups**.
- 2 Click  next to the group that you want to remove.

# 3 Network


# 4 Smart plugs

## 4.1 Connecting the smart plugs


- Did you buy the smart plugs in a package with your gateway? Then these are automatically connected to each other.
- Did you buy extra smart plugs? Then firstly you will have to connect these to the gateway, see [“Adding smart plugs to the system”](#) on page 24.

1 Plug the smart plugs into the wall outlet.

Ensure there is a distance of at least 1.6 meters between the gateway and the smart plugs.



2 Plug the devices that you want to manage into the smart plugs.



3 Log in to the website.

4 Go to the **Network** tab and choose **General > Network overview**.

Here you will see which smart plugs are already connected to the gateway.

5 Select **Groups > All devices** to get an overview of all of your smart plugs.


6 Connect your smart plugs.

# 4 Smart plugs

## 4.2 Adding smart plugs to the system


You only have to perform this task if you bought additional smart plugs for an existing gateway.

- 1 Note down the eight-digit serial number that is written on the rear of your smart plugs.




- 2 Plug the smart plugs into the wall outlet.

Ensure that there is a distance of at least 1.6 meters between the gateway and the smart plugs.



A red light will shine. This will extinguish when the smart plugs are connected to the gateway.

- 3 Plug the devices that you want to manage into the smart plugs.



- 4 Visit [my.fifthplay.com](https://my.fifthplay.com) and log in.
- 5 Go to the **Network** tab and choose **General** > **Add a plug**.
- 6 Enter the eight-digit serial number of the smart plugs.



# 4 Smart plugs

## 7 Click Add.

The plug will appear in the **Connectible plugs** list for the time being.

*NOTE:* As long as the smart plugs are in the **Connectible plugs** list, you can still remove them by clicking ✕. As soon as the smart plugs have been connected to the gateway, you will no longer be able to remove them.

## 8 Repeat steps 5 to 7 until you have added all of your smart plugs.

## 9 Click to close the window.

## 10 Go to the **Network** tab and select **General > Network Overview**.

Here you will see which smart plugs are already connected to the gateway.

## 11 Click **Start automatic scan**.

The smart plugs now appear with the **Active smart plugs**.

## 4.3 Configuring the smart plugs

### 1 Go to the **Network** tab and choose **Groups > All devices**.

### 2 Click in the right-hand column, next to the smart plugs that you want to configure.

### 3 Enter the **General settings** in the **Manage device** dialogue box:

- **Name:** The name that you want to give to your smart plug.
- **Serial number:** Entered automatically.
- **Is a producer:** Selected: only for devices which create their own electricity, for instance solar panels.
- **Type:** The type of device that the plug is used for.
- **Room:** The room in which the plug is to be used.
- **Switchable:** Selected: you can switch the plug on and off.

*NOTE:* If this check box is not selected, then you can only use the plug to measure the consumption of a device.

# 4 Smart plugs

- **Erase previously collected data:** Selected: all data that was previously measured by this smart plug will be erased.

**TIP:** Select this check box if you want to use the smart plug for another device and want to start measuring again. The previously collected data will be erased and you will only see the consumption of the device that is currently connected to this smart plug.

- 4 Click **Save**.
- 5 Click **Close** to close the dialogue box.

## 4.4 Switching the smart plugs on and off

You can use your smart plugs to remotely switch your devices on and off.

- 1 Go to the **Network** tab and choose **Groups > All devices**.
- 2 Click in the section **smart plugs** on the **On**  or **Off**  button in the **Switch** column to switch a device on or off.

**TIP:** You can, if you wish, switch all devices on and off at the same time by clicking the button **On** or **Off** in front of **All devices**. If you have created rooms or groups, you can also do this for each room or group.

## 4.5 Adding the smart plugs to a room


You can group smart plugs in a room. This makes it easier to manage devices for each room.

You should already have created a room. To create a room, see [“Adding a new room” on page 19](#).

- 1 Go to the **Network** tab page and choose **Rooms > DefaultRoom**.

Here you will find all of the smart plugs which have been connected to the gateway and which have not yet been allocated to a room. As soon as you allocate them to a room, they will no longer be visible in this list.

*NOTE:* Are you no longer able to select the name DefaultRoom because you have personalised the name of this room already? Then choose the room at the top of the list.

- 2 Click  in the right-hand column next to the smart plugs that you want to add to a room.



# 4 Smart plugs

- 3 Select the room to which you want to add the smart plug in the **Room** field in the **Manage device** dialogue box.
- 4 Click **Save**.
- 5 Click **Close**.

## 4.6 Adding the smart plugs to a group

You can add smart plugs to a group to manage them more easily. For instance, you can create a group called Lighting and categorize all of your lights within this group.


You should already have created a group. To create a group, see “Adding a new group” on page 20.

- 1 Go to the **Network** tab and choose **Groups > All devices**.  
Here you will find all of the smart plugs which are connected to the gateway.
- 2 Click  in the right-hand column next to the smart plugs that you want to add to a group.
- 3 Click the **Manage device** dialogue box on the **Manage groups** tab page.
- 4 In the **Available groups** list, select the group that you wish to allocate the smart plug to and click  to add the group to the **Allocated groups** list.

*NOTE:* You can add a plug to more than one group.

- 5 Click **Close**.

## 4.7 Creating a schedule

- 1 Go to the **Schedules** tab and click  in the left-hand column next to **Schedule Plugs** to create a new schedule.
- 2 Enter the name of the new schedule and click **Save**.
- 3 Click and drag your mouse over the table in the **Schedules** tab to draw a frame across the day(s) and time(s) when you want to apply a set-point.
- 4 Confirm when you want to apply this set-point and indicate its type in the dialogue box that appears:
  - **To:** When the smart plug should be on. This is the standard value.
  - **Off:** When the smart plug should be off.

# 4 Smart plugs

- **Standby killer:** During this consumption the smart plug will switch itself off. For example: When the smart plug for your TV registers a consumption that is lower than 15 Watts between 1 am and 6 am, meaning that the TV is in standby mode, then the smart plug will switch itself off.
- 5 Click the **Added plugs** tab on **Add a plug to the schedule**.
- 6 Select the smart plug(s) that you want to add.
- 7 Click **Save**.

## 4.8 Amending an existing schedule

You should already have created a schedule. To create a schedule, see “Creating a schedule” on page 27.

- 1 Go to the **Schedules** tab and choose **Schedule Plugs** > [**The schedule that you want to amend**].
- 2 Make any required alterations.
- 3 Click **Save**.

## 4.9 Removing an existing schedule

You should already have created a schedule. To create a schedule, see “Creating a schedule” on page 27.

- 1 Go to the **Schedules** tab and choose **Schedule Plugs** > [**The schedule that you want to schedule**] .
- 2 Click **Remove**.
- 3 Click **Yes** to confirm that you want to remove the schedule.

# 4 Smart plugs

## 4.10 Allocating a schedule to a smart plug

You should already have created a schedule. To create a schedule, see “Creating a schedule” on page 27.

- 1 Go to the **Schedules** tab and select **General > Apply a schedule**.
- 2 Select a schedule from the list.

*NOTE:* You can only allocate one schedule to a plug.

- 3 Select the **Plug** radio button.
- 4 Use the drop-down menu to select the group that you want to allocate the schedule to.
- 5 Click **Schedule**.

**TIP:** To quickly see which schedules have been added to which smart plugs, go to the **Network** tab and choose **Groups > All devices**. Here you can see the schedule allocated for any plug.

## 4.11 Adding Smart plugs to a schedule

- 1 Go to the **Schedules** tab page and choose **Schedule Plugs > [The schedule to which you want to add a smart plug]**.
- 2 Go to the **Added plugs** tab and click **Add a plug to the schedule**.
- 3 Select the smart plugs that you want to add.

*NOTE:* You can allocate a smart plug to only one schedule.

- 4 Click **Save**.

**TIP:** To quickly see which schedules have been added to which smart plugs, go to the **Network** tab and choose **Groups > All devices**. You can see the schedule allocated to each smart plug.

# 4 Smart plugs

## 4.12 Removing Smart plugs from a schedule

- 1 Go to the **Schedules** tab page and choose **Schedule Plugs** > [The schedule that you wish to remove a plug from].
- 2 Go to the **Added plugs** tab.
- 3 Click **Remove** under the plug that you want to remove.

## 4.13 Erasing the history of your smart plugs

When you want to use your smart plugs for another device, then it is best to erase the previously collected data.


- 1 Go to the **Network** tab and choose **Groups** > **All devices**.
- 2 Click **Edit** ✎ next to the plug whose collected data you want to erase.
- 3 Select the check box **Erase previously collected data**.
- 4 Click **Save**.
- 5 Click **Close**.

# 5 Smart meter

## 5.1 Adding the smart meter to the system

To be able to successfully connect the smart meter to fifthplay EnergySmart, the regional network manager must have activated the meter already. The fitter will do this when he connects your smart meter. Please note, it may take several days for your smart meter to be activated.

- 1 Use the P1/USB cable to connect your smart meter to your gateway.



*NOTE:* The P1 connection to the smart meter is on the right, behind the smart meter cable.

- 2 Visit [my.fifthplay.com](https://my.fifthplay.com) and log in.
- 3 Go to the **Network** tab and choose **General > Network overview**.
- 4 Click **Start automatic scan**.

After a few minutes you will be able to see the status of the smart meter:

- **Active smart meters:** The smart meter that is connected to the gateway and about which information will be received.

*NOTE:* The gas meter and/or the electricity meter.


- **Inactive smart meters:** This number should be set to 0/2 or 0/1, depending on the total number of smart meters present. When a smart meter is shown as inactive here, then it is possible that your smart meter is connected to the gateway but it is not working as it should, for instance because of a poor connection.

# 5 Smart meter

*NOTE:* Even if you only have one smart meter fitted in your home, various meters may appear in the application:

- four meters for electricity: one meter for each counter. These can be:
  - a counter for consumption at a high tariff
  - a counter for consumption at a low tariff
  - a counter for feeding back to a high tariff (when you have solar panels)
  - a counter for feeding back to a low tariff (when you have solar panels)
- a smart meter for gas
- a smart meter for water.

## 5.2 Configuring the smart meter

- 1 Go to the **Network** tab and choose **Groups > All devices**.
- 2 Click **Edit**  in the right-hand column next to the smart meter counter that you would like to configure.
- 3 Complete the following fields on each tab:
  - **Name:** Name of the meter or counter.
  - **Room:** Room that the meter belongs to.

**TIP:** Since this is a smart meter, it is sufficient to enter a name for your home in this field.

- **Sub-meter:**

Status	Meaning
Selected	The meter is a sub-segment meter. <b>NOTE:</b> You only have to select this when you have more than one smart meter in your house and this meter is not your main meter. Please note, this refers to the number of smart meters that are physically present, not the number of counters.
Not selected	The meter is a central meter.



# 5 Smart meter

- **Groups:** Group(s) that the meter belongs to.

*NOTE:* The fields **Meter type**, **Basic meter status**, **Basic time stamp** and **Is a producer** are completed automatically. You cannot make any changes to these fields.

## 5.3 Viewing your consumption

- 1 Go to the **Charts** tab and choose **Meters** > [The meter or counter for which you wish to view your consumption].
- 2 Select the following options above the displayed chart:
  - period
  - energy source
  - measurement unit

The chart will refresh automatically.

- 3 Move your cursor over the chart to see the precise values for each quarter.

**TIP:** Drag your cursor over part of the chart to see that part in greater detail. Click **Reset zoom** in the top right of the chart to return to the full-sized chart.


# 5 Smart meter

# 6 Smart thermostat

This module will be installed by the fitter.

## 6.1 Adding a smart thermostat to the system

- 1 Open the smart thermostat as described in the thermostat manual.
- 2 Write down the serial number, consisting of four symbols, or ask your fitter to do this.



- 3 Let the fitter install the smart thermostat.
- 4 Visit [my.fifthplay.com](https://my.fifthplay.com) and log in.
- 5 Go to the **Network** tab and choose **General > Add a thermostat**.
- 6 Enter the serial number of the smart thermostat.
- 7 Click **Add**.

The smart thermostat will appear in the list with the connectible thermostats.


*NOTE:* As long as the smart thermostat is in the **Connectible thermostats** list, you can still remove it by clicking **x**. Once the smart thermostat has been added to the system, it will no longer be possible to delete it.

- 8 When you have added the smart thermostat, click **Start new scan**.
- 9 Click **✕** to close the window.

The application can now be found in the **Network** tab in the **General > Network overview** screen. The smart thermostat now appears with the **Active thermostats**.

# 6 Smart thermostat

## 6.2 Configuring the smart thermostat

- 1 Go to the **Network** tab and choose **Groups > All devices**.
- 2 Click **Edit**  in the right-hand column next to the smart thermostat that you want to configure.
- 3 Enter the following information in the **General settings** tab:
  - **Name:** The name that you want to give to the smart thermostat.
  - **Room:** The room that you want to add the smart thermostat to.
  - **Current preferred value:** The preferred current temperature of your smart thermostat.

*NOTE:* The fields **Device ID**, **Type** and **Creation date** have fixed values and cannot be altered.

- 4 Enter the following values on the **Thermostats** tab:

Section	Field
Absence	<ul style="list-style-type: none"><li>• <b>Transition period from comfort to rest:</b> The time period in which the smart thermostat should not register any motion until it switches from comfort to rest. <b>TIP:</b> Do not set a value that is too short. Set it to 180 minutes for instance. In this way, the smart thermostat will not switch to rest while you are watching a film for instance, and the smart thermostat does not detect any motion.</li><li>• <b>Transition period from rest to anti-frost:</b> The time period in which the smart thermostat must be in rest before it switches to anti-frost.</li></ul>

# 6 Smart thermostat

Section	Field
Preferred value	<ul style="list-style-type: none"><li>• <b>Comfort:</b> The preferred temperature when the smart thermostat detects motion (meaning you are home).</li><li>• <b>Rest:</b> The temperature which the smart thermostat switches to if it has not detected any motion for the time period configured in the <b>Transition period from comfort to rest</b> field.</li><li>• <b>Max. preferred value:</b> The maximum temperature that the smart thermostat can reach. For instance, this prevents children from setting the smart thermostat at a temperature that is higher than the one you have configured here.</li><li>• <b>Anti-frost:</b> The temperature that the smart thermostat switches to when the time period configured in the <b>Transition period from rest to anti-frost</b> has elapsed. This temperature prevents your pipes from freezing while you are away from home for longer periods, for instance when you are on holiday. <p><b>NOTE:</b> This field is completed automatically. You cannot enter your own values.</p></li></ul>
Offset calibration	<b>Value:</b> The number of degrees by which the temperature of the smart thermostat varies from the actual temperature of the room.


- 5 Click **Save**.
- 6 Click **Close** to close the dialogue box.

## 6.3 Manually controlling the smart thermostat

You can also manually control and schedule the smart thermostat. For more information about this, read the user manual on [my.fifthplay.com](http://my.fifthplay.com).

# 6 Smart thermostat

## 6.4 Consulting the current temperature

- 1 Go to the **Network** tab and choose **Groups > All devices**.
- 2 Click **Refresh**  in the **Temperature** column next to the smart thermostat for which you want to consult the current temperature.

The current temperature will appear in several seconds.

## 6.5 About the schedule for the smart thermostat

The fifthplay EnergySmart schedule for the smart thermostat determines the mode of the smart thermostat. You can choose from 3 modes:

- Comfort
- Rest
- Anti-frost

The schedule is set to rest by default, but you can alter this by adding set-points.

## 6.6 Adjusting the schedule

The schedule is always set to the Rest mode by default. To personalise the schedule, you must select the periods for which you wish to set another mode, for example the Comfort mode. The period that you select a mode for is a set-point.

- 1 Go to the **Schedules** tab and choose **Schedule thermostats > Thermostat** in the left-hand column.
- 2 Drag your mouse over the table to specify when you want to use a set-point.

*EXAMPLE:* Select evenings for all week days.

**You can configure a maximum of 28 set-points per day.**

- 3 Check in the dialogue box that appears whether the selected period is correct and select the set-point you wish to use.

*EXAMPLE:* Select the Comfort set-point for the period from Monday to Friday between 17.00 and 24.00.

# 6 Smart thermostat

- 4 Click **Save**.
- 5 Repeat steps 2 to 4 until the schedule is to your satisfaction.
- 6 Click **Save**.

## 6.7 Viewing the consumption of the smart thermostat

- 1 Choose **Charts > Thermostats** and select the smart thermostat for which you wish to view your consumption.
- 2 Select the period for the consumption you wish to view.
- 3 Click in the legend at the bottom of the screen to set the data that you want to see in the chart:
  - **Desired temperature**
  - **Desired temperature (average)**
  - **Measured temperature**
  - **Measured temperature (average)**
- 4 Move your cursor over the chart to see the precise values for each quarter.

**TIP:** Drag your cursor over part of the chart to see that part in greater detail. Click **Reset zoom** in the top right of the chart to return to the full-sized chart.

## 6 *Smart thermostat*




# 7 Smart DIN rail module

This module will be installed by the fitter.

## 7.1 Adding the smart DIN rail module to the system

- 1 Note down the eight-digit serial number that is located on the rear side of the smart DIN rail module.



- 2 Have the smart DIN rail module installed by the fitter.
- 3 Visit [my.fifthplay.com](https://my.fifthplay.com) and log in.
- 4 Go to the **Network** tab and choose **General > Add a plug**.
- 5 Enter the eight-digit serial number of the smart DIN rail module.
- 6 Click **Add**.

The DIN rail will appear in the **Connectible plugs** list for the time being.


*NOTE:* As long as the DIN rail appears in the **Connectible plugs** list, you can still remove it by clicking **X**. Once the DIN rail has been connected to the gateway, you will no longer be able to remove it.

- 7 Click **X** to close the window.
- 8 Go to the **Network** tab and choose **General > Network overview**.
- 9 Click **Start automatic scan**.

The DIN rail now appears with the **Active smart plugs**.

# 7 Smart DIN rail module

## 7.2 Configuring the smart DIN rail module

- 1 Go to the **Network** tab and choose **Groups > All devices**.
- 2 Click **Edit**  in the right-hand column, next to the smart DIN rail module that you want to configure.
- 3 Set the **General settings** in the **Manage device** dialogue box:
  - **Name:** Enter the name that you want to give to your smart DIN rail module.
  - **Serial number:** Entered automatically.
  - **Is a producer:** Select this check box.
  - **Type:** Select the type of device: solar panels.
  - **Room:** Select the room to which the smart DIN rail module belongs.  
**TIP:** Since we are using solar panels here, it is sufficient to provide a name for your home in this field.
  - **Switchable:** Ensure that this check box is not selected so that you do not accidentally switch off the smart DIN rail module.
  - **Erase previously collected data:** If you select this check box, all previously measured data will be erased from this smart DIN rail module.
- 4 Click **Save**.
- 5 Click **Close** to close the dialogue box.

# 7 Smart DIN rail module

## 7.3 Viewing the energy produced by the smart DIN rail module

You can use the smart DIN rail module to monitor the output of your solar panels.

- 1 Go to the **Charts** tab and choose **Plugs > [your solar panels]** in the left-hand menu.
- 2 Select the following options above the displayed chart:
  - period
  - measurement unit


The chart will refresh automatically.

- 3 Move your cursor over the chart to see the precise values for each quarter.

**TIP:** Drag your cursor over part of the chart to see that part in greater detail. Click **Reset zoom** in the top right of the chart to return to the full-sized chart.

## 7.4 Configuring the kWh counter

If your system uses a separate kWh counter, then you can connect this to a specially-designed port in your gateway. A kWh counter generates a number of pulses per kWh. You can configure the number of pulses as described below. The kWh counter is installed by the fitter.

- 1 Go to the **Network** tab and choose **Groups > All devices**.
- 2 Click **Edit**  in the right-hand column next to the kWh counter.
- 3 Complete the following fields:

- **Name:** Name of the kWh counter.

*NOTE:* This name shows the place where the module for logging pulses has been connected and the input used for this. For example: IN 1.1 stands for input 1, port 1. If you want, you can change this name, for example: solar panels.

- **Room:** The room that the kWh counter belongs to.
- **Meter type:** Electricity.
- **Impulses/kWh:** The number of pulses corresponding to 1 kWh. For example: 2000.
- **Is a producer:** Select this to show that you are using an energy producer (solar panels).

# 7 Smart DIN rail module

- **Is a sub-meter:** Specify here whether it is a main meter or a sub-meter, see [“Configuring the smart meter”](#) on page 32.
- **Basic meter status:** The current status of the meter to which the logged results are added.
- **Basic time stamp:** Date and time when you submitted the basic meter status.


*NOTE:* The **Port** and **Location** fields are completed automatically. They show the input and port on the pulse brick that is connected to the meter. You cannot make any changes to these fields.

- 4 Click **Save**.

# 8 Consumption

## 8.1 Consulting the current consumption of a device

To find out how much electricity a device is consuming at a certain moment, you can view the current consumption.

- 1 Go to the **Network** tab and choose **Groups > All devices**.
- 2 Click **Refresh**  in the **Immediate power** column next to the device of which you wish to consult the current consumption.

**TIP:** Click **Refresh all** next to **All devices** to see the current consumption of all devices.

*NOTE:* It can take up to 15 minutes until the current consumption becomes visible.

- 3 To see the current consumption in chart form, click **Chart** .

*NOTE:* The chart is automatically updated every 5 seconds.

## 8.2 Viewing the consumption of a device

- 1 Go to the **Charts** tab and choose **Plugs > [the devices for which you want to view the consumption]** in the left menu.
- 2 Select the following items in the lists above the displayed chart:
  - period
  - energy source
  - measurement unit

The chart will refresh automatically.

*NOTE:* If you are viewing your consumption for the first time, then it may take a little time before your consumption is shown in the chart.

# 8 Consumption

3 Click in the legend at the bottom of the screen to set the data that you want to see in the chart:

- **consumption:** the actual consumption measured during the selected period.
- **average consumption:** the average consumption, calculated on the basis of the consumption measured during similar periods in the past.

*NOTE:* For example: If you have used the plug for five months and select the period **Last month** in step 2, then you will see the average consumption calculated on the basis of those five months.

4 Move your cursor over the chart to see the precise values for each quarter.

**TIP:** Drag your cursor over part of the chart to see that part in greater detail. Click **Reset zoom** in the top right of the chart to return to the full-sized chart.

## 8.3 Comparing the consumption of your devices

1 Go to the **Charts** tab and choose **Comparison**.

2 Select the check box next to the devices that you wish to compare.

*NOTE:* Only compare similar devices. For instance, it does not make sense to compare the consumption of your television with the consumption of your thermostat.

3 Select the following items in the drop-down menu at the top:

- period
- energy source
- measurement unit
- type of chart

The chart will refresh automatically.

4 Move your cursor over the chart to see the precise values for each quarter.

**TIP:** Drag your cursor over part of the chart to see that part in greater detail. Click **Reset zoom** in the top right of the chart to return to the full-sized chart.

# 8 Consumption

## 8.4 Exporting the consumption of your devices

- 1 Go to the **Charts** tab and choose **General > Start new export**.
- 2 In the **Date** field, select the period for which you want to create an export.
- 3 Select the network for which you want to create the export.
- 4 Click **Export**.
- 5 Go to the **Messages** tab and download the file.

## 8.5 Automatically exporting your results

- 1 Go to the **Charts** tab and choose **General > Configure auto-export**.
- 2 Select the check box **Active** to switch on the automated export.
- 3 Select how often you want the automatic export to be performed:
  - **Daily**
  - **Weekly**
  - **Monthly**
- 4 Select the network for which you want to perform an export.
- 5 Select the persons who you want to send the export to.

*NOTE:* If you do not yet have any contacts in the list or if you want to add a new contact, click **Open Address book** and then click **Add** to add a contact.

- 6 Click **Save**.

# 8 Consumption



# 9 Tariffs

## 9.1 About adding tariffs

Adding your current tariff allows you to calculate how much you are saving by using fifthplay EnergySmart.

## 9.2 Altering the standard tariff

- 1 Go to the **Tariffs** tab page and choose **Tariffs > Standard electricity**.
- 2 Complete the following fields:
  - **Meter type:** Which type of meter: electricity, gas or water?
  - **Name:** You can give your standard tariff another name if you wish.
  - **Price €/kWh:** The energy price per kilowatt-hour. Example: 0.2061 €/kWh.
  - **CO2 kg/kWh:** The CO2 emission expressed in kilograms per kilowatt-hour. Example: 0.3766 kg/kWh.
- 3 Complete the following fields where applicable:
  - **From:** The period from when you will use this tariff.  
*NOTE:* The start date cannot be in the past.
  - **To:** The period until when you want to use this tariff.
- 4 Check **Active** to show that this tariff is now applicable.
- 5 Click **Save**.  
A table will appear with a weekly overview that contains the entire tariff.
- 6 If you use high and low tariffs, click **Add a new period**.

*NOTE:* The high tariff is calculated as standard from Monday to Friday between 7 o'clock in the morning and 11 o'clock in the evening.

# 9 Tariffs

7 Enter the required values in the columns.

*EXAMPLE:* You have already entered a low tariff plan, but you still need to enter the more expensive high-tariff plan. Enter the following values:

- **Name:** High tariff
- **Period:** Weekdays
- **From:** 07:00
- **To:** 23:00
- **Price:** 0.2264 €/kWh

8 Click **Save** .

## 9.3 Adding a new tariff

1 Go to the **Tariffs** tab page click **+** next to **Tariffs**.

2 Complete the following fields:

- **Meter type:** Electricity or gas?
- **Name:** The name that you would like to give to your tariff.
- **Price €/kWh:** The energy price per kilowatt-hour. Example: 0.2061 €/kWh.
- **CO2 kg/kWh:** The CO2 emission expressed in kilograms per kilowatt-hour. Example: 0.3766 kg/kWh.

3 Complete the following fields where applicable:

- **From:** The period from when you will use this tariff.

*NOTE:* The start date cannot be in the past.

- **To:** The period until when you want to use this tariff.

4 Check **Active** to show that this tariff is now applicable.

5 Click **Save**.

A table will appear with a weekly overview that contains the entire tariff.


# 9 Tariffs

- 6 If you use high and low tariffs, click **Add a new period**.

*NOTE:* The high tariff is calculated as standard from Monday to Friday between 7 o'clock in the morning and 11 o'clock in the evening.

- 7 Enter the required values in the columns.

*EXAMPLE:* You have already entered a low tariff plan, but you still need to enter the more expensive high-tariff plan. Enter the following values:

- **Name:** High tariff
  - **Period:** Weekdays
  - **From:** 07:00
  - **To:** 23:00
  - **Price:** 0.2264 €/kWh
- 8 Click **Save** .

## 9.4 Removing a tariff

- 1 Go to the **Tariffs** tab page and choose **Tariffs > [The tariff that you want to remove]**.
- 2 Click **Remove**.
- 3 Click **Yes** to confirm that you want to remove this tariff.

# 9 Tariffs

## 9.5 Calculating your projected cost savings

To be able to calculate your projected cost saving, you must:

- have added a tariff, see [“Adding a new tariff” on page 50](#).
- have created a program, see [“Creating a schedule” on page 27](#).

On the basis of these details, fifthplay EnergySmart will calculate how much you can save by consistently using the chosen tariff.

- 1 Go to the **Schedules** tab page and choose **General > Calculate projected cost savings**.
- 2 Select the following:
  - **Schedules**
  - **Tariff**
  - A plug, group or room
- 3 Click **Calculate**.

The weekly or annual savings which you can make by using the chosen schedule will appear at the bottom of the screen.

# 10 Messages

## 10.1 Reading messages

When you receive messages, the number of messages will appear in the tab of the **Messages** tab page.

- 1 Go to the **Messages** tab.

You will see an overview of all of your messages. The most recent messages are at the top.

- 2 If the message contains an export, click the link in the message to download the exported data.

To export data, see:

- ["Exporting the consumption of your devices" on page 47](#)
- ["Automatically exporting your results" on page 47](#)

Messages always remain visible in the **Messages** tab. If you no longer wish to see these, then you should delete your messages, see ["Deleting messages" on page 53](#). You cannot archive your messages.

## 10.2 Deleting messages

- 1 Go to the **Messages** tab.
- 2 Do one of the following:

To	choose
delete all messages:	<b>Messages &gt; Delete all messages.</b>
delete specific messages:	<b>Messages &gt; Read your messages</b> , and click <b>✗</b> next to the message that you want to delete.

# 10 Messages

## 10.3 Setting messages for unexpected consumption

If you wish, you can be informed when a smart plug, room or group consumes more energy than normal, or even no longer consumes energy, over a certain period.

**For example:** If your deep-freezer is incorrectly closed it will consume more energy than when it is properly closed.

- 1 Go to the **Messages** tab and click **+** next to **Unexpected usage**.
  - 2 Select a file or a new template from the list and click **Next**.
  - 3 Complete the required fields and click **Next**.
  - 4 Select the reason why you are creating a profile and click **Next**.
  - 5 Click and drag your mouse over the table to draw a frame across the day(s) and time(s) when you wish to receive a message for unexpected usage.
  - 6 In the dialogue box that appears, indicate the circumstances in which you wish to receive a message:
    - **Inactive**
    - **Notifications for a value  $\geq X$**
    - **Notifications for a value  $\leq X$**
- NOTE:* In the last two options, also state the threshold value and how long this should occur before you receive a message.
- 7 Click **Save**.
  - 8 Click **Next**.
  - 9 Select which recipient will receive which messages and click **Save**.

# 10 Messages

## 10.4 Configuring messages for exceeded target consumption

You can set a daily, weekly or monthly target consumption. This means that you specify that you do not want to consume more than a set number of kilowatt-hours.

*NOTE:* For example: Using your smart plugs, you have measured that your television consumes 100 kilowatt-hours per week. You want to lower this consumption and set your weekly target consumption to 90 kilowatt-hours. As soon as you use more than 90 kilowatt-hours, you will receive a message.

- 1 Go to the **Messages** tab and click **+** next to **Target consumption**.
- 2 Select a file or a new template from the list and click **Next**.
- 3 Complete the required fields and click **Next**.
- 4 Select the reason why you are creating a profile and click **Next**.
- 5 Choose a time window and set the target value.

*EXAMPLE:* You do not want to consume more than 150 euros per month. For the time window, choose **Month** and choose **A fixed value** for the target value. Enter 150 for the fixed value and select **euro** from the list.

*NOTE:* If you want to consume less, you can also set **A percentage of the average value** as the target value. For example: 90 percent. You will then receive a message when you have consumed 90 percent of your current average consumption.

- 6 Select the **Proactive** check box to receive a warning before you exceed your target consumption. This time period is calculated on the basis of previous measurements.
- 7 Select which recipient will receive which messages and click **Save**.


## 10.5 Adding recipients

- 1 Go to the **Messages** tab and choose **Address book > Edit**.
- 2 Click **Add** in the dialogue box that appears.
- 3 Enter the requested information.




# 10 Messages

- 4 Click **Save**.


The recipient you have added will appear in the table with the recipients.

- 5 Click **Close**  to close the dialogue box.

## 10.6 Editing recipients

- 1 Go to the **Messages** tab and choose **Address book > Edit**.
- 2 Click **Edit**  in the dialogue box that appears next to the contact that you want to edit.
- 3 Make any required alterations.
- 4 Click **Save** .
- 5 Click **Close**  to close the dialogue box.

## 10.7 Deleting recipients

- 1 Go to the **Messages** tab and choose **Address book > Edit**.
- 2 Click **Delete** next to the contact that you want to delete in the dialogue box that appears.
- 3 Click **OK** to confirm.
- 4 Click **Close**  to close the dialogue box.



# 11 Personal settings

## 11.1 Changing the language

- 1 Click **my details** on the top right.
- 2 Click **Edit** in the **Personal details** tab.
- 3 In the **Language** field, select the language that you would like to use.
- 4 Click **Save**.

## 11.2 Changing your email address

- 1 Click **my details** on the top right.
- 2 Click **Edit** in the **Personal details** tab.
- 3 Enter the email address where you now would like to receive notifications in the **Email address** field.

*NOTE:* You can also enter a second email address if you wish. To do this, complete the **Alternative email address** field.

- 4 Click **Save**.

## 11.3 Changing your mobile phone number

- 1 Click **my details** on the top right.
- 2 Click **Edit** in the **Personal details** tab.
- 3 Enter the mobile phone number that you want to use from now on to receive notifications in the **GSM** field.
- 4 Click **Save**.

# 11 Personal settings

## 11.4 Changing your address

- 1 Click **my details** on the top right.
- 2 Click **Edit** in the **Address** tab.
- 3 Enter your address details.
- 4 Click **Save**.

## 11.5 Altering your notification preferences


- 1 Click **my details** on the top right.
- 2 Click **Edit** in the **Notifications** tab.
- 3 Select how you want to receive your notifications:
  - **Text message**
  - **Email**

*NOTE:* You can also select both check boxes if you wish.

- 4 Click **Save**.

## 11.6 Changing the name of your gateway

When you register your gateway, it will automatically be given the name FP[MAC address of the gateway]. This name will be used in the SMS that you receive when the gateway is offline and when you have set up SMS notifications for this. You can change this name, if you wish.


- 1 Click **settings** on the top right.
- 2 Click the  button.
- 3 Click **Change details**.
  
- 4 Enter a new name in the **Gateway name** field.

*NOTE:* This field should not be left empty.


- 5 Click **Save**.

# 11 Personal settings


## 11.7 Receiving a warning when the gateway is offline

- 1 Click **settings** on the top right.
- 2 Click the  button.
- 3 Click **Change details**.
  
- 4 Select the **Notify me if the gateway is offline** check box.
- 5 Use the drop-down menu to select how long the gateway should be offline before you receive a warning.
- 6 Click **Save**.

## 11.8 Setting your time zone

- 1 Click **settings** on the top right.
- 2 Click the  button.
- 3 Click **Change details**.
  
- 4 Select your time zone in the **Time zone** drop-down list.
- 5 Click **Save**.

## 11.9 Renewing your voucher

- 1 Click **settings** on the top right.
- 2 Click the  button.
- 3 Click **Renew** in the right-hand column.
- 4 Read and accept the standard terms and conditions.
- 5 Enter the voucher code.
- 6 Click **Register**.

# 11 Personal settings

## 11.10 Changing your password

- 1 Click **change password** on the top right.
- 2 Select the **Only change password** radio button.
- 3 Enter your current password in the **Old password** field.
- 4 Enter your new password in the **New password** field.
- 5 Enter your new password once again in the **Confirm new password** field.
- 6 Click **Save**.

## 11.11 Changing your user name

- 1 Click in the top right on **change password**.
- 2 Select the **Change single user name** radio button.
- 3 Enter your new username in the **New login** field.  
**Your login should always be an existing email address.**
- 4 Click **Save**.

# 12 Smartphones and tablet computers

Through the fifthplay app for smartphones and tables, you can use fifthplay EnergySmart anywhere to:

- switch your smart plugs on and off
- check the status of your devices
- check the current and average energy consumption of your devices
- consult charts with your current and average daily, monthly or annual consumption

## 12.1 Installing the fifthplay app

- 1 Depending on your operating system, do one of the following:

If you have	then visit
an iOS smartphone or tablet computer	the <a href="#">App Store</a> and search for fifthplay EnergySmart.
an Android smartphone or tablet computer	<a href="#">Google Play</a> and search for fifthplay EnergySmart.
a Windows phone	the <a href="#">Windows phone store</a> and search for fifthplay EnergySmart.

- 2 Install the app.
- 3 Log in to the app using the same user details as for the fifthplay EnergySmart website.

# *12 Smartphones and tablet computers*

# 13 Troubleshooting

## 13.1 Gateway

Symptom	Problem	Solution
A flashing red led light on the gateway.	There is a configuration problem.	Remove the plug from the wall outlet and wait for several minutes. Then try again. If you continue to experience problems, contact support.
	The gateway is faulty.	Contact support.
A flashing yellow led light on the gateway.	The gateway is not connected to the internet.	<ul style="list-style-type: none"><li>• Check whether the gateway is properly connected to your modem or router.</li><li>• Check whether your internet is working.</li></ul>
A yellow led light on the gateway.	The gateway is not connected to the web platform.	Check whether the gateway is properly connected to your modem or router.

# 13 Troubleshooting




## 13.2 Wireless internet

Symptom	Problem	Solution
You are unable to connect.	Your internet is not working.	Check your internet connection.
	The URL is incorrect.	<ul style="list-style-type: none"><li>• Check whether the URL begins with http:// and add this if necessary.</li><li>• Check whether the URL contains www and remove this if necessary.</li><li>• Check whether the URL ends in .local. If not, add this and try again. If it does, remove this and try again.</li></ul>
	Your internet browser does not recognise the URL.	Try a different internet browser.
	The gateway is not connecting.	Restart the gateway by unplugging it and then plugging it in again.
	The connection with your modem or router is not working.	<ol style="list-style-type: none"><li>1 Turn off the wireless internet on your computer.</li><li>2 Connect your gateway to your computer using the Ethernet cable.</li><li>3 Plug your gateway into the wall outlet.</li><li>4 Open your internet browser and complete this task as you would do when connecting to the wireless internet via a modem or router, see <a href="#">“Connecting the gateway to the wireless network” on page 13.</a></li></ol>



# 13 Troubleshooting

## 13.3 Smart plugs

Symptom	Problem	Solution
A red led light on the smart plug.	The smart plugs have been connected and are attempting to connect to the gateway.	You do not need to do anything.
A flashing red led light on the smart plug.	The smart plugs are not able to connect to the gateway.	The smart plugs are too near to or too far away from the gateway, see <a href="#">“Adding smart plugs to the system”</a> on page 24.
	The smart plugs have been configured as non-switchable and you pressed the button on the plug.	To make the smart plugs switchable, see <a href="#">“Configuring the smart plugs”</a> on page 25.
Schedule conflict in fifthplay EnergySmart.	You have attempted to add a schedule to a smart plug that is already part of a schedule. You can only add one schedule to a smart plug.	<ol style="list-style-type: none"><li>Do one of the following:<ul style="list-style-type: none"><li>If you wish to keep the allocated schedule, leave the <b>Do not overwrite</b> icon  in the <b>Overwrite</b> column.</li><li>If you wish to replace the allocated schedule with the current schedule, click the <b>Do not overwrite</b> icon  in the <b>Overwrite</b> column so that the <b>Overwrite</b> icon  appears.</li></ul></li><li>Click <b>Proceed</b>.</li></ol>

# 13 Troubleshooting

Symptom	Problem	Solution
The status in fifthplay EnergySmart is inactive.	There is a poor connection between your smart plug and your gateway.	<ul style="list-style-type: none"><li>• Move your hand over the gateway to check the status.</li><li>• Restart your smart plug, see <a href="#">“Configuring the smart plugs” on page 25.</a></li></ul>
	Your smart plug is not plugged in to the wall outlet.	Plug the smart plug into the wall outlet.
	Your smart plug is faulty.	If these solutions do not help, it is very likely that your smart plug is faulty. Contact support.


## 13.4 Smart thermostat

Symptom	Problem	Solution
The status in fifthplay EnergySmart is inactive.	The battery in the smart thermostat is dead.	Replace the battery.
	The smart thermostat is too far away from your gateway.	Move your smart thermostat closer to your gateway. <b>NOTE:</b> The maximum distance between the gateway and the smart thermostat is 30 meters and may not be blocked by more than one of the following: <ul style="list-style-type: none"><li>■ one solid wall</li><li>■ three partition walls</li><li>■ two brick walls.</li></ul>

# 13 Troubleshooting

Symptom	Problem	Solution
Not visible in fifthplay EnergySmart.	The smart thermostat is not installed correctly.	Contact support.
You cannot configure the <b>Current preferred value</b> in the <b>General settings</b> tab.	The smart thermostat is not (no longer) active.	See: <b>Solving problems &gt; Smart thermostat &gt; The status in fifthplay EnergySmart is inactive.</b>

## 13.5 Messages

Symptom	Problem	Solution
Target consumption - Internal server error.	You have selected the <b>A percentage of the average</b> radio button, but you have not entered a percentage value.	Enter a percentage value.
Unexpected consumption - You should have set at least one notification plan.	You have not set a period or value for receiving messages.	<ol style="list-style-type: none"><li>1 Click  to close the dialogue box with the error message.</li><li>2 Click <b>Previous</b>.</li><li>3 Select a period in the table and complete the fields.</li><li>4 Continue with the configuration of your messages profile.</li></ol>

## 13.6 Support

Are you unable to find a solution to your problem? Call us on 0900 30 555 or email your problem to [support@fifthplay.com](mailto:support@fifthplay.com).

# 13 Troubleshooting