

ORDERING REPLACEMENT PARTS

If you encounter any difficulties with this product, or if you need to order replacement parts, call the ICON Health & Fitness, Ltd. office, or write:

ICON Health & Fitness, Ltd.
Unit 4
Revie Road Industrial Estate
Revie Road
Beeston
Leeds, LS118JG
UK

Tel:

08457 089 009

Outside the UK: 0 (044) 113 387 7133
Fax: 0 (044) 113 387 7125

- The MODEL NUMBER of the product (PFEVBE12540)
- The NAME of the product (PROFORM® G600 weight storage bench)
- The SERIAL NUMBER of the product (see the front cover of this manual)
- The KEY NUMBER and DESCRIPTION of the part(s) (see the PART LIST and the EXPLODED DRAWING on pages 10 and 11)


PRO-FORM® G600

USER'S MANUAL

Model No. PFEVBE12540

Serial No. _____

Write the serial number in the space above for future reference.



Serial Number Decal (Under Seat)

QUESTIONS?

As a manufacturer, we are committed to providing complete customer satisfaction. If you have questions, or if there are missing or damaged parts, please call:


08457 089 009

Or write:
ICON Health & Fitness, Ltd.
Unit 4
Revie Road Industrial Estate
Revie Road
Beeston
Leeds, LS118JG
UK

email: csuk@iconeurope.com

⚠ CAUTION

Read all precautions and instructions in this manual before using this equipment. Save this manual for future reference.



Visit our website at

www.iconeurope.com

TABLE OF CONTENTS


WARNING DECAL PLACEMENT 2
 IMPORTANT PRECAUTIONS 3
 BEFORE YOU BEGIN 4
 ASSEMBLY 5
 ADJUSTMENTS 7
 EXERCISE GUIDELINES 8
 PART LIST 10
 EXPLODED DRAWING 11
 ORDERING REPLACEMENT PARTS Back Cover

WARNING DECAL PLACEMENT

The decal shown here has been placed on the weight bench. If the decal is missing or illegible, please call our Customer Service Department at 08457 089 009 and order a free replacement decal. Apply the decal in the location shown.


! WARNING

- Misuse of this product may result in serious injury.
- Read user's manual and follow all warnings and operating instructions prior to use.
- Do not allow children on or around machine.
- Replace label if damaged, illegible, or removed.



EXPLODED DRAWING—Model No. PFEVBE12540

R1104A



PART LIST—Model No. PFEVBE12540

R1104A

| Key No. | Qty. | Description | Key No. | Qty. | Description |
|---------|------|----------------------|---------|------|------------------------|
| 1 | 1 | Bench Frame | 13 | 2 | 10-pound Dumbbell |
| 2 | 1 | Left Stabiliser | 14 | 4 | M10 x 15mm Button Bolt |
| 3 | 1 | Right Stabiliser | 15 | 8 | M6 x 25mm Screw |
| 4 | 1 | Weight Tray | 16 | 4 | M10 x 28mm Button Bolt |
| 5 | 1 | Left Seat Bracket | 17 | 2 | M10 x 45mm Bolt |
| 6 | 1 | Right Seat Bracket | 18 | 6 | M10 Nylon Locknut |
| 7 | 1 | Seat | 19 | 8 | M6 Washer |
| 8 | 4 | 64mm Round Outer Cap | 20 | 4 | M10 Washer |
| 9 | 2 | Wheel | # | 1 | User's Manual |
| 10 | 2 | 3-pound Dumbbell | # | 1 | Exercise Guide |
| 11 | 2 | 5-pound Dumbbell | # | 1 | Hex Key |
| 12 | 2 | 8-pound Dumbbell | # | 1 | Grease Pack |

Note: “#” indicates a non-illustrated part. Specifications are subject to change without notice. See the back cover of this manual for information about ordering replacement parts.

IMPORTANT PRECAUTIONS

⚠ WARNING: To reduce the risk of serious injury, read the following important precautions before using the weight bench.

1. Read all instructions in this manual before using the weight bench. Use the weight bench only as described in this manual.
2. It is the responsibility of the owner to ensure that all users of the weight bench are adequately informed of all precautions.
3. The weight bench is intended for home use only. Do not use the weight bench in any commercial, rental, or institutional setting.
4. Use the weight bench only on a level surface. Cover the floor beneath the weight bench to protect the floor.
5. Always wear athletic shoes for foot protection whilst exercising.
6. Make sure that all parts are properly tightened each time the weight bench is used. Replace any worn parts immediately.
7. Keep children under 12 and pets away from the weight bench at all times.
8. Keep hands and feet away from moving parts.
9. The weight bench is designed to support a maximum user weight of 135 kg (300 lbs.), and a maximum total weight of 185 kg (410 lbs.).
10. If you feel pain or dizziness at any time whilst exercising, stop immediately and begin cooling down.

⚠ WARNING: Before beginning this or any exercise program, consult your physician. This is especially important for persons over the age of 35 or persons with pre-existing health problems. Read all instructions before using. ICON assumes no responsibility for personal injury or property damage sustained by or through the use of this product.


BEFORE YOU BEGIN

Thank you for selecting the PROFORM® G600 weight storage bench. The weight bench is designed to help you develop the major muscle groups of the upper body and offers a storage location for your dumbbell set. Whether your goal is to tone your body, build dramatic muscle size and strength, or improve your cardiovascular system, the weight bench will help you to achieve the specific results you want.

For your benefit, read this manual carefully before using the weight bench. If you have questions after

reading this manual, please call our Customer Service Department at **08457 089 009**. To help us assist you, please mention the product model number and serial number when calling. The model number is PFEVBE12540. The serial number can be found on a decal attached to the weight bench (see the front cover of this manual).

Before reading further, please review the drawing below and familiarise yourself with the parts that are labeled.



Rest for a short period of time after each set. The ideal resting periods are:

- Rest for three minutes after each set for a muscle building workout.
- Rest for one minute after each set for a toning workout.
- Rest for 30 seconds after each set for a weight loss workout.

Plan to spend the first couple of weeks familiarizing yourself with the equipment and learning the proper form for each exercise.


COOLING DOWN

End each workout with 5 to 10 minutes of stretching. Include stretches for both your arms and legs. Move

slowly as you stretch and do not bounce. Ease into each stretch gradually and go only as far as you can without strain. Stretching at the end of each workout is an effective way to increase flexibility.

STAYING MOTIVATED

For motivation, keep a record of each workout. List the date, the exercises performed, the resistance used, and the numbers of sets and repetitions completed. Record your weight and key body measurements at the end of every month. Remember, the key to achieving the greatest results is to make exercise a regular and enjoyable part of your everyday life.



EXERCISE GUIDELINES

THE FOUR BASIC TYPES OF WORKOUTS

MUSCLE BUILDING

To increase the size and strength of your muscles, push them close to their maximum capacity. Your muscles will continually adapt and grow as you progressively increase the intensity of your exercise. You can adjust the intensity level of an individual exercise in two ways:

- by changing the amount of resistance used
- by changing the number of repetitions or sets performed. (A “repetition” is one complete cycle of an exercise, such as one sit-up. A “set” is a series of repetitions.)

The proper amount of resistance for each exercise depends upon the individual user. You must gauge your limits and select the amount of resistance that is right for you. Begin with 3 sets of 8 repetitions for each exercise you perform. Rest for 3 minutes after each set. When you can complete 3 sets of 12 repetitions without difficulty, increase the amount of resistance.

TONING

You can tone your muscles by pushing them to a moderate percentage of their capacity. Select a moderate amount of resistance and increase the number of repetitions in each set. Complete as many sets of 15 to 20 repetitions as possible without discomfort. Rest for 1 minute after each set. Work your muscles by completing more sets rather than by using high amounts of resistance.

WEIGHT LOSS

To lose weight, use a low amount of resistance and increase the number of repetitions in each set. Exercise for 20 to 30 minutes, resting for a maximum of 30 seconds between sets.

CROSS TRAINING

Cross training is an efficient way to get a complete and well-balanced fitness program. An example of a balanced program is:

- Plan strength training workouts on Monday, Wednesday, and Friday.
- Plan 20 to 30 minutes of aerobic exercise, such as running on a treadmill or riding an elliptical exerciser or an exercise cycle, on Tuesday and Thursday.
- Rest from both strength training and aerobic exercise for at least one full day each week to give your body time to regenerate.

The combination of strength training and aerobic exercise will reshape and strengthen your body, plus develop your heart and lungs.

PERSONALIZING YOUR EXERCISE PROGRAM

Determining the exact length of time for each workout, as well as the number of repetitions or sets completed, is an individual matter. It is important to avoid overdoing it during the first few months of your exercise program. You should progress at your own pace and be sensitive to your body’s signals. If you experience pain or dizziness at any time whilst exercising, stop immediately and begin cooling down. Find out what is wrong before continuing. Remember that adequate rest and a proper diet are important factors in any exercise program.

WARMING UP

Begin each workout with 5 to 10 minutes of stretching and light exercise to warm up. Warming up prepares your body for more strenuous exercise by increasing circulation, raising your body temperature and delivering more oxygen to your muscles.

WORKING OUT

Each workout should include 6 to 10 different exercises. Select exercises for every major muscle group, emphasizing areas that you want to develop most. To give balance and variety to your workouts, vary the exercises from session to session.

Schedule your workouts for the time of day when your energy level is the highest. Each workout should be followed by at least one day of rest. Once you find the schedule that is right for you, stick with it.

EXERCISE FORM

Maintaining proper form is an essential part of an effective exercise program. This requires moving through the full range of motion for each exercise, and moving only the appropriate parts of the body. Exercising in an uncontrolled manner will leave you feeling exhausted. On the exercise guide accompanying this manual you will find photographs showing the correct form for several exercises, and a list of the muscles affected. See the muscle chart on the next page to find the names of the muscles.

The repetitions in each set should be performed smoothly and without pausing. The exertion stage of each repetition should last about half as long as the return stage. Proper breathing is important. Exhale during the exertion stage of each repetition and inhale during the return stroke. Never hold your breath.

ASSEMBLY

Make Things Easier for Yourself





Everything in this manual is designed to ensure that the weight bench can be assembled successfully by anyone. Most people find that by setting aside plenty of time, assembly will go smoothly.

Before beginning assembly, carefully read the following information and instructions:

- Assembly requires two persons.
- Place all parts in a cleared area and remove the packing materials. Do not dispose of the packing materials until assembly is completed.
- Tighten all parts as you assemble them, unless instructed to do otherwise.

- As you assemble the weight bench, make sure all parts are oriented as shown in the drawings.

The hex key and the following tools (not included) are required for assembly:


- **Two adjustable spanners** 
- **One rubber mallet** 
- **One standard screwdriver** 
- **One Phillips screwdriver** 
- **Lubricant, such as grease or petroleum jelly, and soapy water.**

Assembly will be more convenient if you have a socket set, a set of open-end or closed-end wrenches, or a set of ratchet wrenches.


1. **Before beginning assembly, make sure that you understand the information in the box above.**

Press two 64mm Round Outer Caps (8) onto the Right Stabiliser (3).

Lubricate an M10 x 45mm Bolt (17) with grease. Attach a Wheel (9) to the Right Stabiliser (3) with the Bolt and an M10 Nylon Locknut (18). **Do not overtighten the Locknut; the Wheel must be able to roll freely. Attach the other Wheel to the Right Stabiliser in the same manner.**




2. Attach the Right Stabiliser (3) to the Bench Frame (1) with two M10 x 15mm Button Bolts (14) and two M10 Washers (20).




- Press two 64mm Round Outer Caps (8) onto the Left Stabiliser (2).

Attach the Left Stabiliser (2) to the Bench Frame (1) with two M10 x 15mm Button Bolts (14) and two M10 Washers (20).




- Lubricate the hinges on the Left Seat Bracket (5) and the Right Seat Bracket (6) with grease.

Orient the Weight Tray (4) with the slots on the side shown. Attach the Weight Tray to the Bench Frame (1) with four M10 x 28mm Button Bolts (16), the two Seat Brackets (5, 6), and four M10 Nylon Locknuts (18). **Note: The Seat Brackets have stickers on them for identification.**



- Attach the Seat (7) to the Seat Brackets (5, 6) with eight M6 x 25mm Screws (15) and eight M6 Washers (19).



- Make sure that all parts are properly tightened before you use the weight bench.** The use of all remaining parts will be explained in ADJUSTMENTS, beginning on page 7.


ADJUSTMENTS

The steps below explain how the weight bench can be adjusted. See EXERCISE GUIDELINES on page 8 for important exercise information and see the accompanying exercise guide to learn the correct form for each exercise.

Make sure all parts are properly tightened each time the weight bench is used. Replace any worn parts immediately. The weight bench can be cleaned with a damp cloth and a mild, non-abrasive detergent. Do not use solvents.

STORING THE DUMBBELLS

To store a dumbbell, lift the Seat (7) and set the dumbbell in the Weight Tray (4).



MOVING THE WEIGHT BENCH

To move the weight bench, lift the handle so that the bench pivots onto the Wheels (9). Roll the bench to the new location and set the bench down.

